# R&S<sup>®</sup>FSWP Phase Noise Analyzer User Manual



1177563302 Version 12



Make ideas real



This manual describes the following R&S<sup>®</sup>FSWP models with firmware version 1.92 or higher:

- R&S<sup>®</sup>FSWP8 (1322.8003K08)
- R&S<sup>®</sup>FSWP26 (1322.8003K26)
- R&S<sup>®</sup>FSWP50 (1322.8003K50)

In addition, the following options are described:

- R&S FSWP-B21 (1325.3848.02)
- R&S FSWP-B24 (1325.3725.08)
- R&S FSWP-B24 (1325.3725.26)
- R&S FSWP-B24 (1325.3725.50)
- R&S FSWP-B60 (1322.9800.08)
- R&S FSWP-B60 (1322.9800.26)
- R&S FSWP-B60 (1322.9800.50)
- R&S FSWP-B64 (1322.9900.26)
- R&S FSWP-B64 (1322.9900.50)
- R&S FSWP-K4 (1325.5034.02)
- R&S FSWP-K33 (1325.5040.02)

© 2021 Rohde & Schwarz GmbH & Co. KG Mühldorfstr. 15, 81671 München, Germany Phone: +49 89 41 29 - 0 Email: info@rohde-schwarz.com Internet: www.rohde-schwarz.com Subject to change – data without tolerance limits is not binding. R&S<sup>®</sup> is a registered trademark of Rohde & Schwarz GmbH & Co. KG. Trade names are trademarks of the owners.

1177.5633.02 | Version 12 | R&S®FSWP

Throughout this manual, products from Rohde & Schwarz are indicated without the <sup>®</sup> symbol , e.g. R&S<sup>®</sup>FSWP is indicated as R&S FSWP.

# Contents

1	Preface	15
1.1	Key Features	15
1.2	Conventions Used in the Documentation	15
1.2.1	Typographical Conventions	15
1.2.2	Conventions for Procedure Descriptions	16
1.2.3	Notes on Screenshots	16
2	Safety Information	17
3	Documentation Overview	18
3.1	Getting Started Manual	18
3.2	User Manuals and Help	18
3.3	Service Manual	18
3.4	Instrument Security Procedures	19
3.5	Basic Safety Instructions	19
3.6	Data Sheets and Brochures	19
3.7	Release Notes and Open Source Acknowledgment (OSA)	19
3.8	Application Notes, Application Cards, White Papers, etc	19
3.8 4	Application Notes, Application Cards, White Papers, etc	
		20
4	Preparing for Use	20 20
4 4.1	Preparing for Use Putting into Operation	<b>20</b> <b>20</b> 21
<b>4</b> <b>4.1</b> 4.1.1	Preparing for Use Putting into Operation Unpacking and Checking the Instrument	<b>20</b> <b>20</b> 21 22
<b>4</b> <b>4.1</b> 4.1.1 4.1.2	Preparing for Use.         Putting into Operation.         Unpacking and Checking the Instrument.         Accessory List.	<b>20</b> 20 21 22 22
<b>4</b> <b>4.1.1</b> 4.1.2 4.1.3	Preparing for Use.         Putting into Operation.         Unpacking and Checking the Instrument.         Accessory List.         Placing or Mounting the Instrument.         Connecting the AC Power.	20 20 21 22 22 22 24
<b>4</b> <b>4.1.1</b> 4.1.2 4.1.3 4.1.4	Preparing for Use.         Putting into Operation.         Unpacking and Checking the Instrument.         Accessory List.         Placing or Mounting the Instrument.         Connecting the AC Power.	20 20 21 22 22 22 24 24
<b>4</b> <b>4.1.1</b> 4.1.2 4.1.3 4.1.4 4.1.5	Preparing for Use	20 20 21 22 22 22 24 24 24 25
<b>4</b> <b>4.1.1</b> 4.1.2 4.1.3 4.1.4 4.1.5 4.1.6	Preparing for Use	20 20 21 22 22 24 24 24 25 26
<b>4</b> 4.1.1 4.1.2 4.1.3 4.1.4 4.1.5 4.1.6 4.1.7	Preparing for Use	20 21 22 22 24 24 24 25 26 26
<b>4</b> 4.1.1 4.1.2 4.1.3 4.1.4 4.1.5 4.1.6 4.1.7 <b>4.2</b>	Preparing for Use         Putting into Operation         Unpacking and Checking the Instrument         Accessory List         Placing or Mounting the Instrument         Connecting the AC Power         Switching the Instrument On and Off         Performing a Self-Alignment and a Selftest         Checking the Supplied Options         Windows Operating System	20 21 22 22 24 24 24 25 26 26 26 28
<ol> <li>4.1.1</li> <li>4.1.2</li> <li>4.1.3</li> <li>4.1.4</li> <li>4.1.5</li> <li>4.1.6</li> <li>4.1.7</li> <li>4.2</li> <li>4.3</li> </ol>	Preparing for Use	20 21 22 22 22 24 24 24 25 26 26 26 28 28

4.5	Connecting to LAN	
4.6	Setting the Date and Time	31
4.7	Protecting Data Using the Secure User Mode	31
5	Instrument Tour	34
5.1	The Front Panel	34
5.1.1	Display (Touchscreen)	35
5.1.2	Power Key	37
5.1.3	System Control Keys	37
5.1.4	The Function Keys	38
5.1.5	The Keypad	39
5.1.6	Navigation Control	40
5.1.7	RF Input (50 Ω)	41
5.1.8	Signal Source Output	42
5.1.9	USB Ports	42
5.1.10	Power Sensors	42
5.1.11	Probe Power Connector (3 Pins)	42
5.1.12	Noise Source Control	43
5.1.13	Trigger Input and Output	43
5.1.14	Baseband Input	43
5.1.15	External Mixer (Optional)	43
5.1.16	DC Power Supply	44
5.1.17	LO AUX Input (Optional)	44
5.2	The Rear Panel	44
5.2.1	Removable Hard Disk	46
5.2.2	AC Power Connector and Main Power Switch	46
5.2.3	DisplayPort and DVI	46
5.2.4	LAN Connector	46
5.2.5	USB Ports	
5.2.6	IF / Video / Demod Output	47
5.2.7	IF Wide Out	47
5.2.8	Sync Trigger Input and Output	
5.2.9	AUX Port	47
5.2.10	GPIB Interface	48

5.2.11	External Generator Control (Optional)	
5.2.12	OCXO (Optional)	
5.2.13	REF INPUT / REF OUTPUT	
6	Trying Out the Instrument	50
6.1	Initial Setup	51
6.2	Measurements	
6.2.1	Measurement Selection	
6.2.2	The Phase Noise Measurement	53
6.2.3	The Additive Noise Measurement	
6.2.4	The Baseband Noise Measurement	58
6.2.5	The Pulsed Phase Noise Measurement	60
6.2.6	The Pulsed Additive Noise Measurement	60
6.2.7	Adding Another Measurement Channel	
6.3	Result Evaluation	
6.3.1	Trace Smoothing	63
6.3.2	Integration Ranges	65
6.3.3	The Cross-Correlation Gain Indicator	
6.3.4	Miscellaneous Evaluation Tools	67
6.4	Measurement Configuration	68
6.4.1	Frequency Configuration	68
6.4.2	The Half Decade Configuration Table	70
6.4.3	Pulsed Measurement Configuration	70
6.4.4	Signal Generation	71
6.4.5	DUT Power Supply	73
7	Operating the Instrument	74
7.1	Understanding the Display Information	
7.1.1	Channel Bar	
7.1.2	Window Title Bar	
7.1.3	Marker Information	
7.1.4	Spot Noise Information	78
7.1.5	Measurement Progress Information	79
7.1.6	Frequency Information in Diagram Footer	80
7.1.7	Instrument and Status Information	

7.1.8	Error Information	81
7.2	Accessing Functions	82
7.2.1	Toolbar	83
7.2.2	Softkeys	84
7.2.3	Context Menus	85
7.2.4	On-screen Keyboard	85
7.3	Changing the Focus	86
7.4	Entering Data	86
7.4.1	Entering Numeric Parameters	86
7.4.2	Entering Alphanumeric Parameters	87
7.5	Displaying Results	
7.5.1	Activating and Deactivating Channels	
7.5.2	Laying out the Result Display with the SmartGrid	90
7.5.3	Changing the Size of Windows	
7.5.4	Switching Between a Split and Maximized Window Display	95
7.5.5	Changing the Display	95
7.6	Remote Control	
7.6.1	Remote Desktop Connection	
7.6.2	Connecting a PC via the GPIB Interface	96
8	Applications	98
8.1	R&S MultiView	
8.2	Available Applications	
8.3	Starting an Application	
8.4	Running a Sequence of Measurements	103
8.4.1	The Sequencer Concept	103
8.4.2	Sequencer Settings	
8.4.3	How to Set Up the Sequencer	105
9	Measurements and Result Displays	107
9.1	Basics on Phase Noise Measurements	
9.1.1	Residual Effects	
9.2	Performing Measurements	
9.3	Selecting Measurements	
9.4	Result Displays	

10	Common Measurement Settings	123
10.1	Configuration Overview	123
10.2	Input Source	125
10.2.1	RF Input	125
10.2.2	Baseband Input	127
10.2.3	External Mixers	128
10.3	Level Characteristics	142
10.3.1	Signal Attenuation	142
10.3.2	Amplitude Characteristics	143
10.3.3	Diagram Scale	145
10.4	Frequency	146
10.5	Noise Measurement Configuration	151
10.5.1	Triggered Measurements (Phase Noise CW)	151
10.5.2	Measurement Range	151
10.5.3	Noise Configuration	152
10.5.4	Integrated Measurement Configuration	158
10.5.5	Spot Noise Information	161
10.5.6	Spur Display	
10.5.7	Frequency Stability Configuration	164
10.6	Output	165
10.6.1	DC Source Configuration	165
10.6.2	Signal Source Configuration	168
10.6.3	Miscellaneous Output	172
10.7	Pulsed Phase Noise and Pulsed Additive Noise Configuration	173
10.8	VCO Characterization Configuration	176
10.8.1	Sweep Configuration	
10.8.2	Trace Configuration	
10.9	Spot Noise vs Tune Configuration	180
10.9.1	Trace Configuration	
10.10	PN Transient Analysis Configuration	181
10.10.1	Frequency Configuration	
10.10.2	Trigger Configuration	183
10.10.3	Data Acquisition	186

10.10.4	Amplitude Configuration	
10.10.5	Diagram Scale	
10.10.6	Settling Time	190
10.10.7	Frequency Deviation	190
10.10.8	Trace Configuration	191
10.10.9	Marker Configuration	
10.10.10	Limit Lines	
11	Common Analysis and Display Functions	193
11.1	Result Display Configuration	
11.1.1	Basic Result Displays	
11.1.2	Laying out the Result Display with the SmartGrid	
11.2	Zoomed Displays	198
11.2.1	Single Zoom Versus Multiple Zoom	198
11.2.2	Zoom Functions	199
11.2.3	How to Zoom Into a Diagram	
11.3	Trace Configuration	
11.3.1	Basics on Traces	202
11.3.2	Trace Configuration	206
11.3.3	Trace Export and Import	
11.3.4	Copying Traces	214
11.3.5	Trace Math	214
11.3.6	Trace Labels	215
11.3.7	How to Configure Traces	215
11.3.8	References	216
11.4	Markers	223
11.4.1	Basics on Markers and Marker Functions	223
11.4.2	Marker Settings	
11.4.3	Marker Search Settings and Positioning Functions	229
11.5	Limit Lines	
11.5.1	Basics on Limit Lines	
11.5.2	Limit Line Settings and Functions	
11.5.3	How to Define Limit Lines	240
12	Data Management	

12.1	Restoring the Default Instrument Configuration (Preset)	244
12.2	Protecting Data Using the Secure User Mode	245
12.3	Storing and Recalling Instrument Settings and Measurement Data	247
12.3.1	Quick Save/Quick Recall	248
12.3.2	Configurable Storage and Recall	251
12.3.3	How to Save and Load Instrument Settings	256
12.4	Import/Export Functions	258
12.5	Creating Screenshots of Current Measurement Results and Settings	260
12.5.1	Print and Screenshot Settings	
12.5.2	How to Store or Print Screenshots of the Display	
12.5.3	Example for Storing Multiple Measurement Results to a PDF File	272
13	General Instrument Setup	275
13.1	Alignment	275
13.1.1	Basics on Alignment	275
13.1.2	Alignment Settings	277
13.1.3	How to Perform a Self-Test	280
13.1.4	How to Align the Instrument	280
13.1.5	How to Align the Touchscreen	281
13.2	Display Settings	281
13.2.1	Display Settings	281
13.2.2	How to Configure the Colors for Display and Printing	290
13.2.3	How to Work with the Soft Front Panels	291
13.3	Reference Frequency Settings	292
13.4	System Configuration Settings	296
13.4.1	Hardware Information	296
13.4.2	Information on Versions and Options	
13.4.3	System Messages	298
13.4.4	Firmware Updates	299
13.4.5	General Configuration Settings	301
13.5	Service Functions	303
13.5.1	R&S Support Information	304
13.5.2	Self-test Settings and Results	305
13.5.3	Calibration Signal Display	305

13.5.4	Service Functions	
13.5.5	Hardware Diagnostics	
14	Network and Remote Operation	311
14.1	Remote Control Basics	311
14.1.1	Remote Control Interfaces and Protocols	
14.1.2	SCPI (Standard Commands for Programmable Instruments)	
14.1.3	VISA Libraries	
14.1.4	Messages	321
14.1.5	SCPI Command Structure	
14.1.6	Command Sequence and Synchronization	
14.1.7	Status Reporting System	
14.1.8	General Programming Recommendations	349
14.2	The IECWIN Tool	350
14.3	Network and Remote Control Settings	351
14.3.1	General Network Settings	
14.3.2	GPIB Settings	354
14.3.3	Compatibility Settings	357
14.3.4	LAN Settings	
14.3.5	Remote Errors	
14.3.6	Returning to Manual Mode ("Local")	
14.4	How to Set Up a Network and Remote Control	
14.4.1	How to Configure a Network	
14.4.2	How to Operate the Instrument Without a Network	
14.4.3	How to Log on to the Network	
14.4.4	How to Share Directories (only with Microsoft Networks)	
14.4.5	How to Control the R&S FSWP via the Web Browser Interface	
14.4.6	How to Deactivate the Web Browser Interface	
14.4.7	How to Set Up Remote Desktop	
14.4.8	How to Start a Remote Control Session from a PC	
14.4.9	How to Return to Manual Operation	
15	Remote Control	
15.1	Conventions Used in SCPI Command Descriptions	
15.2	Common Suffixes	

15.3	Common Commands	
15.4	Selecting the Operating Mode and Application	389
15.4.1	Selecting Mode and Applications	
15.4.2	Performing a Sequence of Measurements	
15.4.3	Programming Example: Performing a Sequence of Measurements	395
15.5	Measurements and Result Displays	
15.5.1	Measurement Selection	397
15.5.2	Performing Measurements	
15.5.3	Querying Results	402
15.5.4	Programming Examples	412
15.6	Common Measurement Settings	413
15.6.1	Remote Commands to Configure the Input Source	413
15.6.2	Output	428
15.6.3	Remote Commands to Configure User Ports	441
15.6.4	Remote Commands to Configure Level Characteristics	443
15.6.5	Remote Commands to Configure the Frequency	449
15.6.6	Phase Noise Measurement Configuration	454
15.6.7	Pulsed Phase Noise Configuration	474
15.6.8	VCO Characterization Configuration	477
15.6.9	Spot Noise vs Tune Configuration	480
15.6.10	Transient Analysis	
15.7	Common Analysis and Display Functions	500
15.7.1	Display Configuration	500
15.7.2	Zoom	509
15.7.3	Trace Configuration	512
15.7.4	Marker	524
15.7.5	Limit Lines	537
15.7.6	Examples: Configuring the Result Display	549
15.8	Managing Settings and Results	552
15.8.1	Managing Files	
15.8.2	Selecting Items to Store	558
15.8.3	Saving and Loading Instrument Settings	561
15.8.4	Storing and Printing Screenshots	565

15.8.5	Saving Measurement Results	576
15.8.6	Examples: Managing Data	576
15.9	Configuring the R&S FSWP	579
15.9.1	Basic Instrument Setup	579
15.9.2	Configuring the Reference Frequency	581
15.9.3	Calibrating the R&S FSWP and Checking Temperature	585
15.9.4	Customizing the Screen Layout	589
15.9.5	Configuring Network and Remote Control	595
15.9.6	Checking the System Configuration	600
15.9.7	Using Service Functions	606
15.9.8	Reference: Command Set of 5052 Emulation	608
15.9.9	Reference: Command Set of Emulated PSA Models	610
15.10	Using the Status Register	614
15.10.1	General Status Register Commands	614
15.10.2	Reading Out the CONDition Part	615
15.10.3	Reading Out the EVENt Part	616
15.10.4	Controlling the ENABle Part	616
15.10.5	Controlling the Negative Transition Part	617
15.10.6	Controlling the Positive Transition Part	618
15.11	Programming Examples	618
15.11.1	Service Request	619
16	Maintenance	
16.1	Cleaning	
17	Troubleshooting	630
17.1	Error Information	630
17.2	Error Messages in Remote Control Mode	631
17.3	Troubleshooting Remote Operation	632
17.4	Miscellaneous Troubleshooting Hints	634
17.5	System Recovery	635
17.6	Collecting Information for Support	635

17.7	Contacting Customer Support	.637
	List of commands	639
	Index	651

# 1 Preface

This chapter provides safety-related information, key features of the instrument, and the conventions used in the documentation.

## 1.1 Key Features

The R&S FSWP phase noise analyzer and VCO tester with the following key features.

Measuring phase and amplitude noise with high sensitivity:

- Extremely low phase noise from internal sources
- Cross-correlation to improve phase noise sensitivity
- Accuracy of amplitude noise measurements significantly higher than with diode detectors
- Display of improvement in sensitivity through cross-correlation
- Up to 300 MHz frequency offset for phase noise measurements, up to 1 GHz for pure noise measurement

Phase noise measurements on pulsed sources at the push of a button:

- Simple test setup
- High sensitivity despite desensitization
- Automatic pulse parameter measurement

Internal source for measuring residual phase noise, also on pulsed signals:

- Simple and fast measurement
- Higher sensitivity through cross-correlation
- Residual phase noise on pulsed signals
- Additional inputs for an external source

More features:

- Signal and spectrum analyzer and phase noise analyzer up to 50 GHz in a single box
- High measurement speed
- Low-noise internal DC sources for VCO characterization
- Measuring transients or frequency hops (transient analysis)

## **1.2** Conventions Used in the Documentation

### 1.2.1 Typographical Conventions

The following text markers are used throughout this documentation:

Convention	Description
"Graphical user interface ele- ments"	All names of graphical user interface elements on the screen, such as dialog boxes, menus, options, buttons, and softkeys are enclosed by quotation marks.
[Keys]	Key and knob names are enclosed by square brackets.
Filenames, commands, program code	Filenames, commands, coding samples and screen output are distin- guished by their font.
Input	Input to be entered by the user is displayed in italics.
Links	Links that you can click are displayed in blue font.
"References"	References to other parts of the documentation are enclosed by quota- tion marks.

### 1.2.2 Conventions for Procedure Descriptions

When operating the instrument, several alternative methods may be available to perform the same task. In this case, the procedure using the touchscreen is described. Any elements that can be activated by touching can also be clicked using an additionally connected mouse. The alternative procedure using the keys on the instrument or the on-screen keyboard is only described if it deviates from the standard operating procedures.

The term "select" may refer to any of the described methods, i.e. using a finger on the touchscreen, a mouse pointer in the display, or a key on the instrument or on a key-board.

#### 1.2.3 Notes on Screenshots

When describing the functions of the product, we use sample screenshots. These screenshots are meant to illustrate as many as possible of the provided functions and possible interdependencies between parameters. The shown values may not represent realistic usage scenarios.

The screenshots usually show a fully equipped product, that is: with all options installed. Thus, some functions shown in the screenshots may not be available in your particular product configuration.

## 2 Safety Information

The product documentation helps you use the R&S FSWP safely and efficiently. Follow the instructions provided here and in the printed "Basic Safety Instructions". Keep the product documentation nearby and offer it to other users.

#### Intended use

The R&S FSWP is intended for the development, production and verification of electronic components and devices in industrial, administrative, and laboratory environments. Use the R&S FSWP only for its designated purpose. Observe the operating conditions and performance limits stated in the data sheet.

#### Where do I find safety information?

Safety information is part of the product documentation. It warns you about the potential dangers and gives instructions how to prevent personal injuries or damage caused by dangerous situations. Safety information is provided as follows:

- The printed "Basic Safety Instructions" provide safety information in many languages and are delivered with the R&S FSWP.
- Throughout the documentation, safety instructions are provided when you need to take care during setup or operation.

## 3 Documentation Overview

This section provides an overview of the R&S FSWP user documentation. Unless specified otherwise, you find most of the documents on the R&S FSWP product page at:

www.rohde-schwarz.com/manual/fswp

## 3.1 Getting Started Manual

Introduces the R&S FSWP and describes how to set up and start working with the product. Includes basic operations, typical measurement examples, and general information, e.g. safety instructions, etc.

A printed version is delivered with the instrument. A PDF version is available for download on the Internet.

## 3.2 User Manuals and Help

Separate user manuals are provided for the base unit and the firmware applications:

Base unit manual

Contains the description of all instrument modes and functions. It also provides an introduction to remote control, a complete description of the remote control commands with programming examples, and information on maintenance, instrument interfaces and error messages. Includes the contents of the getting started manual.

 Manuals for (optional) firmware applications Contains the description of the specific functions of a firmware application, including remote control commands. Basic information on operating the R&S FSWP is not included.

The contents of the user manuals are available as help in the R&S FSWP. The help offers quick, context-sensitive access to the complete information for the base unit and the firmware applications.

All user manuals are also available for download or for immediate display on the Internet.

## 3.3 Service Manual

Describes the performance test for checking the rated specifications, module replacement and repair, firmware update, troubleshooting and fault elimination, and contains mechanical drawings and spare part lists.

The service manual is available for download for registered users on the global Rohde & Schwarz information system (GLORIS):

https://gloris.rohde-schwarz.com

## 3.4 Instrument Security Procedures

Deals with security issues when working with the R&S FSWP in secure areas. It is available for download on the Internet.

## 3.5 Basic Safety Instructions

Contains safety instructions, operating conditions and further important information. The printed document is delivered with the instrument.

## 3.6 Data Sheets and Brochures

The data sheet contains the technical specifications of the R&S FSWP. It also lists the options and their order numbers, and optional accessories.

The brochure provides an overview of the instrument and deals with the specific characteristics.

See www.rohde-schwarz.com/brochure-datasheet/fswp

# 3.7 Release Notes and Open Source Acknowledgment (OSA)

The release notes list new features, improvements and known issues of the current firmware version, and describe the firmware installation.

The open source acknowledgment document provides verbatim license texts of the used open source software.

See www.rohde-schwarz.com/firmware/fswp

# 3.8 Application Notes, Application Cards, White Papers, etc.

These documents deal with special applications or background information on particular topics.

See www.rohde-schwarz.com/application/fswp

# 4 Preparing for Use

•	Putting into Operation	20
	Windows Operating System	
	Connecting USB Devices	
	Connecting an External Monitor	
	Connecting to LAN	
	Setting the Date and Time	
	Protecting Data Using the Secure User Mode	

## 4.1 Putting into Operation

This section describes the basic steps to be taken when setting up the R&S FSWP for the first time.

## **WARNING**

#### Risk of injury due to disregarding safety information

Observe the information on appropriate operating conditions provided in the data sheet to prevent personal injury or damage to the instrument. Read and observe the basic safety instructions provided with the instrument, in addition to the safety instructions in the following sections. In particular:

Do not open the instrument casing.

## NOTICE

#### Risk of instrument damage due to inappropriate operating conditions

Specific operating conditions are required to ensure accurate measurements and to avoid damage to the instrument. Observe the information on appropriate operating conditions provided in the basic safety instructions and the instrument's data sheet.

## NOTICE

#### Instrument damage caused by electrostatic discharge

Electrostatic discharge (ESD) can damage the electronic components of the instrument and the device under test (DUT). Electrostatic discharge is most likely to occur when you connect or disconnect a DUT or test fixture to the instrument's test ports. To prevent electrostatic discharge, use a wrist strap and cord and connect yourself to the ground, or use a conductive floor mat and heel strap combination.

## NOTICE

#### Risk of instrument damage due to inappropriate operating conditions

An unsuitable operating site or test setup can damage the instrument and connected devices. Before switching on the instrument, observe the information on appropriate operating conditions provided in the data sheet. In particular, ensure the following:

- All fan openings are unobstructed and the airflow perforations are unimpeded. A minimum distance of 10 cm to other objects is recommended.
- The instrument is dry and shows no sign of condensation.
- The instrument is positioned as described in the following sections.
- The ambient temperature does not exceed the range specified in the data sheet.
- Signal levels at the input connectors are all within the specified ranges.
- Signal outputs are connected correctly and are not overloaded.



#### EMI impact on measurement results

Electromagnetic interference (EMI) may affect the measurement results.

To suppress generated electromagnetic interference (EMI):

- Use suitable shielded cables of high quality. For example, use double-shielded RF and LAN cables.
- Always terminate open cable ends.
- Note the EMC classification in the data sheet.

•	Unpacking and Checking the Instrument	21
	Accessory List	
	Placing or Mounting the Instrument	
	Connecting the AC Power	
	Switching the Instrument On and Off	
	Performing a Self-Alignment and a Selftest	
	Checking the Supplied Options	
		-

#### 4.1.1 Unpacking and Checking the Instrument

Check the equipment for completeness using the delivery note and the accessory lists for the various items. Check the instrument for any damage. If there is damage, immediately contact the carrier who delivered the instrument. Make sure not to discard the box and packing material.

## A WARNING

#### Risk of injury during transportation

The carrying handles at the front and side of the casing are designed to lift or carry the instrument. Do not apply excessive force to the handles. If a handle is ripped off, the falling instrument can cause injury.

Be aware of the weight of the instrument when lifting it. Observe the information on transporting heavy instruments in the basic safety instructions provided with the instrument.



#### Packing material

Retain the original packing material. If the instrument needs to be transported or shipped later, you can use the material to protect the control elements and connectors.

#### 4.1.2 Accessory List

The instrument comes with the following accessories:

- Power cable
- Printed Getting Started manual

#### 4.1.3 Placing or Mounting the Instrument

The R&S FSWP is designed for use under laboratory conditions, either on a bench top or in a rack.

#### Bench Top Operation

If the R&S FSWP is operated on a bench top, the surface should be flat. The instrument can be used in horizontal position, standing on its feet, or with the support feet on the bottom extended.


## A WARNING

#### Risk of injury when stacking instruments

A stack of instruments can tilt over and cause injury if not stacked correctly. Furthermore, the instruments at the bottom of the stack can be damaged due to the load imposed by the instruments on top.

Observe the following instructions when stacking instruments:

- Never stack more than three instruments. If you need to stack more than three instruments, install them in a rack.
- The overall load imposed on the lowest instrument must not exceed 500 N.
- It is best if all instruments have the same dimensions (width and length).
   If you need to stack smaller instruments on the top, the overall load imposed on the lowest instrument must not exceed 250 N.
- If the instruments have foldable feet, fold them in completely.




A WARNING

#### Risk of injury if feet are folded out

The feet can fold in if they are not folded out completely or if the instrument is shifted. Collapsing feet can cause injury or damage the instrument.

- Fold the feet completely in or out to ensure stability of the instrument. Never shift the instrument when the feet are folded out.
- When the feet are folded out, do not work under the instrument or place anything underneath.
- The feet can break if they are overloaded. The overall load on the folded-out feet must not exceed 500 N.



#### Rackmounting

The R&S FSWP can be installed in a rack using a rack adapter kit (order no. see data sheet). The installation instructions are part of the adapter kit.

## NOTICE

#### Risk of instrument damage due to insufficient airflow in a rack

If you mount several instruments in a rack, you need an efficient ventilation concept to ensure that the instruments do not overheat. Insufficient airflow for a longer period can disturb the operation and even cause damage.

#### 4.1.4 Connecting the AC Power

In the standard version, the R&S FSWP is equipped with an AC power supply connector. The R&S FSWP can be used with different AC power voltages and adapts itself automatically to it. Refer to the datasheet for the requirements of voltage and frequency. The AC power connector is located on the rear panel of the instrument.

For details on the connector refer to Chapter 5.2.2, "AC Power Connector and Main Power Switch", on page 46.



Connect the R&S FSWP to the AC power supply using the supplied power cable. Since the instrument is assembled in line with the specifications for safety class EN61010, it may only be connected to an outlet that has a ground contact.

#### 4.1.5 Switching the Instrument On and Off

#### Switching the instrument on

Press the AC power switch on the rear panel to position "I".

The instrument is supplied with AC power. After booting, the instrument is ready for operation. A green LED above the [POWER] key indicates this. An orange LED indicates the instrument is in standby mode



#### Warm-up time for OCXO

When the instrument is switched on, the OCXO requires an extended warm-up time (see data sheet).

#### Switching the instrument off

1. Press the [POWER] key on the front panel.

The R&S FSWP switches to standby mode.

Set the AC power switch on the rear panel to position "O", or disconnect the instrument from the AC power supply.

The R&S FSWP changes into off mode.

## NOTICE

#### Risk of losing data

If you switch off the running instrument using the rear panel switch or by disconnecting the power cord, the instrument loses its current settings. Furthermore, program data can be lost.

Press the Power key first to shut down the application properly.

#### 4.1.6 Performing a Self-Alignment and a Selftest

During instrument start, the installed hardware is checked against the current firmware version to ensure the hardware is supported. If not, an error message is displayed ("WRONG\_FW") and you are asked to update the firmware. Until the firmware version is updated, self-alignment fails.

(For details refer to the R&S FSWP User Manual).

Furthermore, it may be necessary to align the data to a reference source by performing a self-alignment when strong temperature changes occur.



#### **Operating temperature**

Before performing this functional test, make sure that the instrument has reached its operating temperature (for details, refer to the data sheet).

A message in the status bar ("Instrument warming up...") indicates that the operating temperature has not yet been reached.

#### Performing a self-alignment

- 1. Press the [SETUP] key.
- 2. Press the "Alignment" softkey.
- 3. Select the "Start Self-Alignment" button in the "Alignment" dialog box.

Once the system correction values have been calculated successfully, a message is displayed.



#### To display the alignment results again later

- Press the [SETUP] key.
  - Press the "Alignment" softkey.

#### Performing a selftest

The selftest does not need to be repeated every time the instrument is switched on. It is only necessary when instrument malfunction is suspected.

- 1. Press the [SETUP] key.
- 2. Press the "Service" softkey.
- 3. Switch to the "Selftest" tab in the "Service" dialog box.
- 4. Select the "Start Selftest" button.

Once the instrument modules have been checked successfully, a message is displayed.

#### 4.1.7 Checking the Supplied Options

The instrument may be equipped with both hardware and firmware options. In order to check whether the installed options correspond to the options indicated on the delivery note, proceed as follows.

- 1. Press the [SETUP] key.
- 2. Press the "System Config" softkey.
- Switch to the "Versions + Options" tab in the "System Configuration" dialog box.
   A list with hardware and firmware information is displayed.
- 4. Check the availability of the hardware options as indicated in the delivery note.

## 4.2 Windows Operating System

The instrument contains the Microsoft Windows operating system which has been configured according to the instrument's features and needs. Changes in the system setup are only required when peripherals like a keyboard or a printer are installed or if the network configuration does not comply with the default settings. After the R&S FSWP is started, the operating system boots and the instrument firmware is started automatically.

#### **Tested software**

The drivers and programs used on the instrument under Microsoft Windows are adapted to the instrument. Only install update software released by Rohde & Schwarz to modify existing instrument software.

You can install additional software on the instrument; however, additional software can impair instrument function. Thus, run only programs that Rohde & Schwarz has tested for compatibility with the instrument software.

The following program packages have been tested:

- Symantec Endpoint Security virus-protection software
- FileShredder for reliable deletion of files on the hard disk

#### Service packs and updates

Microsoft regularly creates security updates and other patches to protect Windowsbased operating systems. These are released through the Microsoft Update website and associated update server. Instruments using Windows, especially those that connect to a network, should be updated regularly.

#### **Firewall settings**

A firewall protects an instrument by preventing unauthorized users from gaining access to it through a network. Rohde & Schwarz highly recommends the use of the firewall on your instrument. Rohde & Schwarz instruments are shipped with the Windows firewall enabled and preconfigured in such a way that all ports and connections for remote control are enabled.

Note that changing firewall settings requires administrator rights.

#### Virus protection

Take appropriate steps to protect your instruments from infection. Use strong firewall settings and scan any removable storage device used with a Rohde & Schwarz instrument regularly. It is also recommended that you install anti-virus software on the instrument. Rohde & Schwarz does NOT recommend running anti-virus software in the background ("on-access" mode) on Windows-based instruments, due to potentially degrading instrument performance. However, Rohde & Schwarz does recommend running it during non-critical hours.

For details and recommendations, see the following Rohde & Schwarz white paper:

1EF96: Malware Protection Windows 10

#### To access the "Start" menu

The Windows "Start" menu provides access to the Microsoft Windows functionality and installed programs.

		ш
-	-	11
		ш

Select the "Windows" icon in the toolbar, or press the "Windows" key or the [CTRL + ESC] key combination on the (external) keyboard.

The "Start" menu and the Windows taskbar are displayed.



The Windows taskbar also provides quick access to commonly used programs, for example Paint or WordPad. IECWIN, the auxiliary remote control tool provided free of charge and installed by Rohde & Schwarz, is also available from the taskbar or "Start" menu.

For details on the IECWIN tool, see the "Network and Remote Control" chapter of the R&S FSWP user manual.

All necessary system settings can be defined in the "Start > Settings" menu.

For required settings, refer to the Microsoft Windows documentation and to the hardware description.

## 4.3 Connecting USB Devices

The USB interfaces of the R&S FSWP allow you to connect USB devices, such as a mouse, directly to the instrument. Increase the number of possible connections using USB hubs. Due to the large number of available USB devices, there is almost no limit to the expansions that are possible with the R&S FSWP.

All USB devices can be connected to or disconnected from the instrument during operation.

#### To connect a USB device

1. Connect the device to the USB interface of the R&S FSWP.

The operating system automatically searches for a suitable device driver.

- 2. If Windows does not find a suitable driver:
  - a) If the driver software is on a CD, connect a USB CD-ROM drive to the instrument.
  - b) Specify a directory that contains the driver software.

#### To disconnect a USB device

Remove the device from the USB interface of the R&S FSWP.

Windows immediately detects the change in hardware configuration and deactivates the corresponding driver.

#### 4.3.1 Connecting a Keyboard

The keyboard is detected automatically when it is connected. The default input language is English – US.

However, you can also connect foreign language keyboards; currently the following languages are supported for the R&S FSWP:

- German
- Swiss
- French
- Russian

#### To configure the keyboard language

1. To access the Windows operating system, press the Windows key on the external keyboard.

 Select "Start > Settings > Time & language > Region & language > Add a language".

#### 4.3.2 Connecting a Printer

When printing a file, the instrument checks whether a printer is connected and turned on and whether the appropriate printer driver is installed. If necessary, printer driver installation is initiated. You only have to install a printer driver once.

You can load updated and improved driver versions or new drivers from an installation disk, USB memory stick or another external storage medium. If the instrument is integrated in a network, you can also install driver data stored in a network directory.

## 4.4 Connecting an External Monitor

You can connect an external monitor (or projector) to the DVI or display port connector on the instrument's rear panel.

(See also Chapter 5.2.3, "DisplayPort and DVI", on page 46).



#### Screen resolution and format

The touchscreen of the R&S FSWP is calibrated for a 16:10 format. If you connect a monitor or projector using a different format (e.g. 4:3), the calibration is not correct and the screen does not react to your touch actions properly.

The touchscreen has a screen resolution of 1280x800 pixels. Usually, the display of the external monitor is a duplicate of the instrument's monitor.

If you configure the external monitor to be used as the *only* display in the Windows configuration dialog box ("Show only on 2"), the maximum screen resolution of the monitor is used. In this case, you can maximize the R&S FSWP application window and see even more details. You cannot change the monitor's screen resolution via the standard Windows configuration dialog box.

However, you can restore the default instrument resolution (1280x800) on the monitor using the instrument function "Setup" > "Display" > "Configure Monitor" > "Screen Resolution: Restore to default".

The R&S FSWP supports a minimum resolution of 1280x768 pixels.

- 1. Connect the external monitor to the R&S FSWP.
- 2. Press the [SETUP] key.
- 3. Press the "Display" softkey.
- 4. Select the "Configure Monitor" tab in the "Display" dialog box.

The standard Windows "Screen Resolution" dialog box is displayed.

Change the a	ppearance of your displays	
		Detect Identify
Display:	1.T-55312D121) ¥	
<u>Resolution:</u> Orientation:	1280 × 800 (recommended)	
Multiple displays:	Show desktop only on 1	
This is currently yo	our main display.	Advanced setting
	er items larger or smäller ngs should I choose?	

- 5. If necessary, change the screen resolution to be used. Consider the information in the note above.
- 6. Select the instrument to be used for display:
  - "Display 1": internal monitor only
  - "Display 2": external monitor only
  - "Duplicate": both internal and external monitor
- 7. Tap "Apply" to try out the settings before they are accepted permanently, then you can easily return to the previous settings, if necessary.
- 8. Select "OK" if the settings are suitable.

## 4.5 Connecting to LAN

You can connect the instrument to a LAN for remote operation via a PC.

Provided the network administrator has assigned you the appropriate rights and adapted the Windows firewall configuration, you can use the interface, for example:

- To transfer data between a controlling device and the test device, e.g. to run a remote control program
- To access or control the measurement from a remote computer using the "Remote Desktop" application (or a similar tool)
- To connect external network devices (e.g. printers)
- To transfer data from a remote computer and back, e.g. using network folders
- NOTICE! Risk of network failure. Consult your network administrator before performing the following tasks:
  - Connecting the instrument to the network
  - Configuring the network
  - Changing IP addresses

Exchanging hardware

Errors can affect the entire network.

Connect the R&S FSWP to the LAN via the LAN interface on the rear panel of the instrument.

Windows automatically detects the network connection and activates the required drivers.

By default, the R&S FSWP is configured to use DHCP and no static IP address is configured.

For more information on LAN configuration, see the R&S FSWP user manual.

## 4.6 Setting the Date and Time

Users with administrator rights can set the date and time for the internal real time clock as follows:

#### **Opening the Date and Time Properties dialog box**

- 1. Press the [SETUP] key.
- 2. Press the "Display" softkey.
- 3. Select the "General" tab in the "Display" dialog box.
- 4. Press the "Set Date and Time" button to open the standard Windows "Date and Time Properties" dialog box.
- 5. If necessary, toggle the "Date and Time Format" between German (DE) and US.

After you have made a change and closed the dialog box, the new date and time is also adopted by the instrument.

## 4.7 Protecting Data Using the Secure User Mode

During normal operation, the R&S FSWP uses a solid-state drive to store its operating system, instrument firmware, instrument self-alignment data, and any user data created during operation.

#### Redirecting storage to volatile memory

Alternatively, to avoid storing any sensitive data on the R&S FSWP permanently, the *secure user mode* was introduced (option R&S FSWP-K33). In secure user mode, the instrument's solid-state drive is write-protected so that no information can be written to memory permanently. Data that the R&S FSWP normally stores on the solid-state drive is redirected to volatile memory instead, which remains available only until the instrument is switched off. This data includes:

Windows operating system files

- Firmware shutdown files containing information on last instrument state
- Self-alignment data
- General instrument settings such as the IP address
- Measurement settings
- User data created during operation (see also Table 12-1)
- Any data created by other applications installed on the R&S FSWP, for example, text editors (Notepad), the clipboard, or drawing tools.

Users can access data that is stored in volatile memory just as in normal operation. However, when the instrument's power is switched off, all data in this memory is cleared. Thus, in secure user mode, the instrument always starts in a defined, fixed state when switched on.

To store data such as measurement results permanently, it must be stored to an external storage device, such as a memory stick.



#### Limited storage space

The volatile memory used to store data in secure user mode is restricted to 256 MB. Thus, a "Memory full" error can occur although the hard disk indicates that storage space is still available.

#### Storing required data permanently

Any data that is to be available for subsequent sessions with the R&S FSWP must be stored on the instrument permanently, *before activating the secure user mode*. This includes predefined instrument settings, transducer factors and self-alignment data.



#### Self-alignment data

Note that self-alignment data becomes invalid with time and due to temperature changes. Therefore, to achieve optimal accuracy, it can be preferable to perform a new self-alignment at the start of each new session on the R&S FSWP.

#### **Restricted operation**

Since permanent storage is not possible, the following functions are not available in secure user mode:

- Firmware update
- Activating a new option key

Furthermore, since the "SecureUser" used in secure user mode does not have administrator rights, **administrative tasks** such as LAN configuration and some general instrument settings are not available. Refer to the description of the basic instrument setup ([SETUP] menu) to find out which functions are affected.

#### Activating and deactivating secure user mode

Only a user with administrator rights can activate (and deactivate) the secure user mode. Once activated, a restart is required. The special user "SecureUser" is then log-

ged on to the R&S FSWP automatically using the auto-login function. While the secure user mode is active, a message is displayed in the status bar at the bottom of the screen.

# (j

#### Secure passwords

By default, the initial password for both the administrator account and the "Secure-User" account is "894129". When the secure user mode is activated the first time after installation, you are prompted to change the passwords for all user accounts to improve system security. Although it is possible to continue without changing the passwords, it is strongly recommended that you do so.

You can change the password in Microsoft Windows for any user at any time via: "Start > Settings > Account > SignIn Options > Password > Change"

To deactivate the secure user mode, the "SecureUser" must log off and a user with administrator rights must log on.

Ç

#### Switching users when using the auto-login function

In the "Start" menu, select the arrow next to the "Shut down" button and then "Log off". The "Login" dialog box is displayed, in which you can enter the different user account name and password.

The secure user mode setting and auto-login is automatically deactivated when another user logs on. The "SecureUser" is no longer available.

For users with administrator rights, the secure user mode setting is available in the general system configuration settings (see "SecureUser Mode " on page 302).

#### **Remote control**

Initially after installation of the R&S FSWP-K33 option, secure user mode must be enabled manually once before remote control is possible.

(See SYSTem: SECurity[:STATe].)

Manual activation is necessary to prompt for a change of passwords.


# 5 Instrument Tour

On the instrument tour, you can learn about the different control elements and connectors on the front and back panel of the R&S FSWP.

- The Rear Panel......44

## 5.1 The Front Panel

This chapter describes the front panel, including all function keys and connectors.



#### Figure 5-1: Front panel of the R&S FSWP

- 1 = Display (touchscreen)
- 2 = Power key
- 3 = System control keys
- 4 = USB 2.0 interfaces
- 5 = Power sensor connector
- 6 = Probe power connector
- 7 = DC power connectors
- 8 = Baseband connectors
- 9 = Signal source output (optional)
- 10 = External LO input (optional)
- 11 = External mixer ports (optional)
- 12 = Noise source control
- 13 = RF input
- 14 = Trigger in- and output
- 15 = Keypad
- 16 = Navigation control
- 17 = Function keys

## NOTICE

#### Instrument damage caused by cleaning agents

Cleaning agents contain substances such as solvents (thinners, acetone, etc.), acids, bases, or other substances. Solvents can damage the front panel labeling, plastic parts, or screens, for example.

Never use cleaning agents to clean the outside of the instrument. Use a soft, dry, lintfree dust cloth instead.

•	Display (Touchscreen)	35
•	Power Key	
•	System Control Keys	37
•	The Function Keys	
•	The Keypad	
•	Navigation Control	
•	RF Input (50 Ω)	
•	Signal Source Output	
•	USB Ports	
•	Power Sensors	
•	Probe Power Connector (3 Pins)	
•	Noise Source Control.	
•	Trigger Input and Output	
•	Baseband Input	
•	External Mixer (Optional)	
•	DC Power Supply	
•	LO AUX Input (Optional)	

### 5.1.1 Display (Touchscreen)

The touchscreen on the front panel of the R&S FSWP displays the measurement results. Additionally, the screen display provides status and setting information and allows you to switch between various measurement tasks. The screen is touch-sensitive, offering an alternative means of user interaction for quick and easy handling of the instrument.

## NOTICE

#### **Risk of touchscreen damage**

Inappropriate tools or excessive force can damage the touchscreen.

Observe the following instructions when operating the touchscreen:

- Never touch the screen with ball point pens or other sharp objects, use your fingers instead.
  - As an alternative, you can use a stylus pen with a smooth soft tip.
- Never apply excessive force to the screen. Touch it gently.
- Never scratch the screen surface, for example with a finger nail.
- Never rub the screen surface strongly, for example with a dust cloth. For instructions on cleaning the screen, see Chapter 16.1, "Cleaning", on page 628.



- 1 = Toolbar: contains general functionality of the firmware.
- 2 = Channel tab: contains measurement channel.
- 3 = Channel bar: shows measurement settings.
- 4 = Result display: contains measurement results.
- 5 = Window title bar: contains diagram-specific (trace) information.
- 6 = Status bar: contains system messages, progress bar and date and time.
- 7 = Input field.
- 8 = Diagram footer: contains diagram-specific information.
- 9 = Softkeys: provide access to measurement functions.

A touchscreen is a screen that is touch-sensitive, i.e. it reacts in a specified way when a particular element on the screen is tapped by a finger or a pointing device, for example. Any user interface elements that can be clicked on by a mouse pointer can also be tapped on the screen to trigger the same behavior, and vice versa.

Using the touchscreen, the following tasks (among others) can be performed by the tap of your finger:

- Changing a setting
- Changing the display
- Moving a marker
- Zooming into a diagram
- Selecting a new evaluation method
- Scrolling through a result list
- Saving or printing results and settings

To imitate a right-click by mouse using the touchscreen, for example to open a contextsensitive menu for a specific item, press the screen for about 1 second.

### 5.1.2 Power Key

The Power key on the front panel turns the instrument on and off.



The color of the LED above the key shows its current state.

- Orange: instrument is in stand-by mode.
  - Green: instrument is running.

For more information see Chapter 4.1.5, "Switching the Instrument On and Off", on page 24.

# 5.1.3 System Control Keys

System control keys provide access to the basic instrument configuration.

Refer to the User Manual for an extensive description of the system configuration functionality.

PRE- SET	Resets the instrument to its default configuration.		
MODE	Selects a particular measurement application or operating mode.		
SETUP	<ul> <li>Provides functionality to configure basic instrument characteristics, for example:</li> <li>the LAN connection</li> <li>the date and time</li> <li>the display configuration</li> <li>the reference frequency</li> <li>firmware update and application installation</li> <li>service functions</li> <li>transducer configuration</li> </ul>		

	Provides access to the on-screen keyboard.
Turns full screen mode on and off.	
	Selects a window in split screen mode or browses through active windows in full screen mode.

# 5.1.4 The Function Keys

Function keys provide access to the most common measurement settings and functions.

Refer to the user manual for an extensive description of the measurement settings and functions.

FREQ CHANNEL	<ul> <li>Provides functionality to define frequency parameters, for example:</li> <li>the measurement range</li> <li>the signal frequency</li> </ul>
SPAN	Provides functionality to configure the measurement range.
AMPT	<ul> <li>Provides functionality to configure amplitude or level characteristics, for example:</li> <li>the attenuation</li> <li>the input impedance</li> <li>the scale of the level axis</li> <li>the preamplifier</li> </ul>
AUTO SET	Provides functionality to automatically define various parameters like the level or fre- quency.
BW	Provides functionality to define various filter bandwidths.
SWEEP	<ul> <li>Provides functionality to configure the measurement, for example:</li> <li>the measurement mode (single or continuous measurements)</li> <li>the number of measurements</li> </ul>
TRACE	<ul> <li>Provides functionality to configure data acquisition and analyze measured data, for example:</li> <li>the trace mode</li> <li>the displayed result</li> </ul>
TRIG	n/a
MKR	Provides functionality to activate and position absolute and relative markers (markers and delta markers).
PEAK SEARCH	Performs a peak search for active markers. If no marker is active, marker 1 is activated and the peak search is performed for it.

MKR FUNCT	n/a
MKR→	<ul> <li>Provides functionality to position and control markers, for example:</li> <li>to configure the marker search</li> <li>to configure the peak excursion</li> </ul>
MEAS	<ul> <li>Provides the measurement functions, for example:</li> <li>the phase noise measurement</li> <li>the AM noise measurement</li> <li>the pulsed noise measurement</li> <li>the spot noise vs tune measurement</li> </ul>
MEAS CONFIG	Provides functionality to configure the measurement.
LINES	Provides functionality to control display and limit lines.
INPUT / OUTPUT	Provides functionality to configure inputs and outputs.
RUN SINGLE	Starts a measurement in single measurement mode.
RUN CONT	Starts a measurement in continuous measurement mode.

# 5.1.5 The Keypad

The alphanumeric keys allow you to enter alphanumeric characters where necessary (for example in dialog boxes or input fields). The keypad containing the alphanumeric keys also provides keys that select a particular unit.

0	Provide access to numbers and (special) characters.		
9			
	Inserts a decimal point at the cursor position (".").		
-	Changes the sign of a numeric value or inserts a dash character ("-") in case of alphanumeric input.		
Hz dB	Select a particular unit for a numeric value. The labels on and next to the key state the units it selects.		
 GHz -dBm	Pressing one of the unit keys also completes the entry of a numeric value. Note that in case of level entries (dB, dBm etc.) or dimensionless values, all unit keys have the value "1" as multiplying factor and thus work like the [ENTER] key.		

ESC	<ul> <li>Provides the following functions:</li> <li>In dialog boxes:</li> <li>Closes all kinds of dialog boxes if edit mode is not active.</li> <li>Quits edit mode if it is active.</li> <li>Selects the "Cancel" button when available.</li> </ul>
	<ul> <li>In "Edit" dialog boxes:</li> <li>If data entry has been started, it retains the original value and closes the dialog box.</li> <li>If data entry has not been started or has been completed, it closes the dialog box.</li> </ul>
BACK- SPACE	Deletes the character to the left of the cursor (if an (alpha)numeric entry has been started already.
ENTER	<ul> <li>Provides the following functions:</li> <li>Completes the entry of input made with the alphanumeric keys (numeric or alphanumeric) and accepts the input. If you enter a numeric value that has a unit, the [ENTER] key works like the [HZ/DB] key.</li> <li>Selects the default or focused element in dialog boxes.</li> </ul>

# 5.1.6 Navigation Control

Navigation control consists of a rotary knob and cursor keys. These keys allow you to navigate within the display or within dialog boxes.

In addition to the rotary knob and the cursor keys, the navigation control also provides undo / redo functionality.

### Rotary knob

The rotary knob allows you to do several things:

- It increases or decreases any kind of numeric value. In most cases, the rotary knob changes numeric values with a fixed step size.
   Turning it to the right corresponds to an increase, turning it to the left to a decrease of a numeric value.
- It works like a cursor key in dialog boxes or lists (for example dropdown menus). In that case you can navigate to one of the items with the rotary knob. If the dialog box covers more than one screen page, it also scrolls through the dialog box. Turning it to the right corresponds to a downward movement. Moving it to the left to an upward movement.
- It moves around markers and other graphical elements on the screen. In most cases, the step size is fix.
- Pressing the rotary knob has the same effect as pressing the [ENTER] key as it confirms an entry or selection.

#### **Cursor keys**

The cursor keys allow you to do several things:

• The up and down keys increase or decrease any kind of numeric value if an input field is active.

The cursor keys change numeric values with a fixed step size.

- The cursor keys navigate through dialog boxes or lists (for example dropdown menus).
- The left and right keys move the cursor in an input field in the corresponding direction.
- The up and down keys move markers around. The step size is fix.
- The cursor keys allow you to navigate to a cell in a table.
- The cursor keys move a scroll bar (vertical or horizontal) in dialog boxes that have one.

#### Undo and redo functionality

UNDO	Reverts the software to an older state by erasing the last change you have applied. The undo function is useful, for example, if you are performing a measurement with several markers and a limit line and accidentally select a different measurement. In this case, a lot of settings would be lost. However, if you press [UNDO] immediately afterwards, the previous status is retrieved.
REDO	Reverses an undo action or repeats the most recently performed action.

(j)

The [UNDO] function is not available after a [PRESET] or "RECALL" operation. When these functions are used, the history of previous actions is deleted.

# 5.1.7 RF Input (50 Ω)

The RF Input allows you to connect a device under test (or DUT) to the R&S FSWP, usually via cable and an appropriate connector (for example a male N connector).

The supported frequency range depends on the R&S FSWP model you have. Refer to the datasheet for details.

The RF Input also serves as an attenuator in case you are measuring signal with high levels. The supported attenuation range depends on the R&S FSWP model you have. Refer to the datasheet for details..

# NOTICE

#### **Risk of instrument damage**

Do not overload the RF input. For maximum allowed values, see the data sheet.

When measuring unknown signals, always apply attenuation to protect the input mixer. Otherwise, the input mixer may be damaged or destroyed.

For AC coupling, a DC input voltage of 50 V must never be exceeded. For DC coupling, DC voltage must not be applied at the input. In both cases, noncompliance will destroy the input mixers.

# 5.1.8 Signal Source Output

The optional "Signal Source" output allows you to generate a signal that can be fed into the DUT or other external accessories like frequency dividers or amplifiers. You can connect the DUT or accessories with a cable that has a male N connector.

# NOTICE

#### Risk of damage to the R&S FSWP

The maximum supported reverse power is 30 dBm. Make sure that this value is not exceeded to avoid damage to the R&S FSWP.

The maximum DC output voltage is 0 V.

For details on configuring the signal source output and generating a signal, see the User Manual.

# 5.1.9 USB Ports

The three USB ports on the front panel (type A) allow you to connect devices like keyboards, mouses or memory sticks.



The R&S FSWP provides additional USB ports (including one type B port) on the rear panel.

All USB ports support standard 2.0.

### 5.1.10 Power Sensors

The female Lemosa connector allows you to connect power sensors of the R&S NRP-Zxy family to the R&S FSWP.

For an extensive list of supported power sensors, refer to the data sheet.

For details on configuring and using power sensors, see the User Manual.

### 5.1.11 Probe Power Connector (3 Pins)

The Probe Power connector allows you to supply external equipment with power (for example probes or transducers).

The three-pinned probe power connector supports supply voltages from +15 V to -12.6 V and ground. The maximum permissible current is 150 mA. This probe power connector is suitable, for example, for high-impedance probes.

# 5.1.12 Noise Source Control

The female BNC connector labeled "Noise Source" allows you to connect and control an external noise source, and supplies the required supply voltage.

You can use a noise source, for example, to measure the noise figure and gain of amplifiers and frequency converting devices.

Conventional noise sources require a voltage of +28 V in order to be switched on and 0 V to be switched off. The output supports a maximum load of 100 mA.

### 5.1.13 Trigger Input and Output

The female BNC connector labeled "Trigger Input / Output" allows you to receive an external trigger signal or send a trigger signal to another device.

When you are using the connector as a trigger input, you can apply voltages in the range from 0.5 V to 3.5 V (the default value is 1.4 V). The typical input impedance is 10 k $\Omega$ .

When you are using the connector as a trigger output, the TTL compatible signal is transmitted (0 V / 5 V).

Note that you can find another connector for trigger input and output on the rear panel.

For more information about controlling and configuring trigger input and output, refer to the User Manual.

### 5.1.14 Baseband Input

The two connectors labeled "Baseband Input 50  $\Omega$ " are two female BNC connectors that you can use to connect a DUT for Baseband Noise measurements.

When you perform measurements with two external mixers, the "Ch2" connector is the IF input for the second mixer. This function is available with the optional external mixer support.

# NOTICE

#### **Risk of instrument damage**

Do not overload the baseband input. An overload condition can damage or destroy the baseband inputs.

For maximum allowed values, see the data sheet.

### 5.1.15 External Mixer (Optional)

The two (optional) SMA connectors (LO OUT/IF IN and IF IN) allow you to connect external mixers.

External mixers increase the available frequency range. The way to connect an external mixer depends on the type of mixer and the test setup. For more information about connecting and controlling external mixers refer to the user manual.

If not in use, it is recommended to cover the SMA connectors with the provided protective caps.

# 5.1.16 DC Power Supply

The female BNC connectors labeled " $V_{Tune}$ ", " $V_{Aux}$ " and " $V_{Supply}$ " allow you to supply external devices, for example a DUT or an external reference oscillator, with the required voltage.

The  $V_{\text{Supply}}$  connector provides supply voltage from 0 V to +16 V, for example to provide voltage for an oscillator. The supported maximum current is 2000 mA.

The  $V_{Tune}$  connector provides tuning voltage from -10 V to +28 V. The supported maximum current is 20 mA.

The  $V_{Aux}$  connector provides DC voltage from -10 V to +10 V. The supported maximum current is 100 mA.

For more information about configuring the DC Power supply, refer to the User Manual.

## 5.1.17 LO AUX Input (Optional)

The two optional connectors labeled "LO AUX Input - Ch1" and "LO AUX Input - Ch2" are two female SMA connectors that you can use to connect an external local oscillator (LO). The external LO requires two connectors ("Ch1" and "Ch2") to work properly.

The "LO AUX Input" connectors are part of the optional Signal Source.

# NOTICE

#### Risk of instrument damage

Do not overload the LO AUX input. An overload condition can damage or destroy the inputs.

For maximum allowed values, see the data sheet.

# 5.2 The Rear Panel

The rear panel contains various connectors for various purposes.

### The Rear Panel




Figure 5-2: Rear panel of the R&S FSWP

- 1 = Removable hard disk
- 2 = AC power connector and power switch
- 3 = DisplayPort and DVI
- 4 = LAN interface
- 5 = USB ports
- 6 = IF / Video / Demod output
- 7 = Trigger in- / output
- 8 = Sync trigger input and output
- 9 = AUX port
- 10 = GPIB interface
- 11 = Ref input and output

For information about the trigger in- and output available on the rear panel, see Chapter 5.1.13, "Trigger Input and Output", on page 43.

The digital baseband in- and outputs shown in the image above are not supported by the R&S FSWP.

•	Removable Hard Disk	.46
•	AC Power Connector and Main Power Switch	46
•	DisplayPort and DVI	46
•	LAN Connector	46
•	USB Ports	. 46
•	IF / Video / Demod Output	. 47
•	IF Wide Out	.47
•	Sync Trigger Input and Output	.47
•	AUX Port	. 47
•	GPIB Interface	48
•	External Generator Control (Optional)	. 48
	OCXO (Optional)	
	REF INPUT / REF OUTPUT	

# 5.2.1 Removable Hard Disk

The removable hard disk is accessible from the rear of the instrument.

In addition to the operating system and the firmware, the R&S FSWP also stores measurement data on that disk. When you remove the hard disk, you can store it and the data on it somewhere secure.

### 5.2.2 AC Power Connector and Main Power Switch

The AC power supply and main power switch are located in a unit on the rear panel of the instrument.

The main power switch has the following states.

- Position "1": The instrument is supplied with power.
- Position "0": The instrument is disconnected from the power supply.

For details refer to Chapter 4.1.5, "Switching the Instrument On and Off", on page 24.

# 5.2.3 DisplayPort and DVI

You can connect an external monitor or other display device to the R&S FSWP. Another display device allows you to view the user interface on a bigger screen. Two different types of connectors are provided for this purpose:

- DisplayPort
- DVI (Digital Visual Interface)

For details see Chapter 4.4, "Connecting an External Monitor", on page 29.

### 5.2.4 LAN Connector

The LAN interface allows you to connect the R&S FSWP to a local network for remote control, printouts or data transfer. The assignment of the RJ-45 connector supports twisted-pair category 5 UTP/STP cables in a star configuration (UTP stands for *unshielded twisted pair*, and STP for *shielded twisted pair*).

For details see Chapter 14, "Network and Remote Operation", on page 311.

### 5.2.5 USB Ports

The four USB ports on the rear panel (type A) allow you to connect devices like keyboards, mouses or memory sticks.

The male USB connector (type B) allows you to connect the R&S FSWP to a computer and establish a remote control connection, for example.

All USB connectors support standard 2.0.

# 5.2.6 IF / Video / Demod Output

The two female BNC connectors can be used for various outputs:

- Output of the intermediate frequency (IF)
- Output of the video signal

Details about configuring the output type and characteristics are part of the user manual.

Note that you can use this connector for applications available with the optional spectrum analyzer hardware and analog modulation analysis application.

### 5.2.7 IF Wide Out

You can extend the signal analysis bandwidth of the R&S FSWP by installing a hardware option. The bandwidth extension allows for a linear bandwidth up to 320 MHz.

You can activate and deactivate the bandwidth extension manually in the I/Q analyzer that is integral part of the optional spectrum analyzer (R&S FSWP-B1) or other optional applications that require the spectrum analyzer hardware.

Together with the bandwidth extension an additional IF output connector is provided (if wide output). As opposed to the default IF / Video / Demod Output connector, the IF output frequency of the optional connector cannot be defined manually, but is determined automatically depending on the center frequency. For details on the used frequencies, see the data sheet. The IF Wide Output connector is used automatically when the bandwidth extension is activated (i.e. for bandwidths > 80 MHz).

# 5.2.8 Sync Trigger Input and Output

The "Sync Trigger Input / Output" connectors allow you to synchronize several devices (for example two R&S FSWPs) with respect to the trigger signal, but also the reference frequency. A 100 MHz signal can be output as a trigger or reference signal to another device, and an external trigger or reference signal can be received at the input connector by the R&S FSWP.

### 5.2.9 AUX Port

The 9 pole SUB-D male connector provides control signals for controlling external devices. The voltage levels are TTL compatible (max. 5 V).



Pin	Signal	Description
1	+5 V / max. 250 mA	Supply voltage for external circuits
2 to 7	I/O	Control lines for user ports (see User Manual)

Pin	Signal	Description
8	GND	Ground
9	READY FOR TRIGGER	Signal indicating that the instrument is ready to receive a trigger signal (Low active = 0 V)

# NOTICE

#### Short-circuit hazard

Always observe the designated pin assignment. A short-circuit can damage the port.

# 5.2.10 GPIB Interface

The GPIB interface is in compliance with IEEE488 and SCPI. A computer for remote control can be connected via this interface. To set up the connection, a shielded cable is recommended. For more details refer to "Setting Up Remote Control" in the User Manual.

### 5.2.11 External Generator Control (Optional)

The optional "External Generator Control" provides an additional GPIB interface and AUX port.

The GPIB connector can be used to connect an external generator to the R&S FSWP.

The AUX port is required for TTL synchronization, if supported by the generator (see Chapter 5.2.9, "AUX Port", on page 47).

For details on connecting an external generator see the "External Generator Control" section of the R&S FSWP User Manual.

# 5.2.12 OCXO (Optional)

This optional OCXO generates a 10 MHz reference signal with a very precise frequency. If installed, and if no external signal is used, this signal is used as an internal reference. It can also be used to synchronize other connected devices via the REF OUTPUT 10 MHz connector.



### Warm-up time for OCXO

When the instrument is switched on, the OCXO requires an extended warm-up time (see data sheet).

# 5.2.13 REF INPUT / REF OUTPUT

The REF INPUT connectors are used to provide an external reference signal to the R&S FSWP.

The REF OUTPUT connectors can be used to provide an external reference signal (or the optional OCXO reference signal) from the R&S FSWP to other devices that are connected to this instrument.

Various connectors are provided for different reference signals:

Connector	Reference signal	Usage
REF INPUT	120 MHz 010 dBm	To provide an external reference signal on the R&S FSWP.
REF OUTPUT	120 MHz 010 dBm	To provide the same external reference signal received by the REF INPUT 120 MHz connector to another device, when available.
REF OUTPUT	10 MHz 10 dBm	To provide the internal reference signal from the R&S FSWP to another device continuously. Also used to provide OCXO reference signal to another device.
REF INPUT	100 MHz 010 dBm	To provide an external reference signal on the R&S FSWP.
REF OUTPUT	100 MHz 6 dBm	To provide a 100 MHz reference signal from the R&S FSWP to another device.
REF OUTPUT	640 MHz 16 dBm	To provide a 640 MHz reference signal from the R&S FSWP to another device.



# SYNC TRIGGER

The SYNC TRIGGER connector can also be used to synchronize the reference frequency on several devices.

# 6 Trying Out the Instrument

#### **Overview of tutorials**

Initial setup:

- "Preparing the R&S FSWP" on page 51
- "Selecting the phase noise application" on page 51
- "Performing a preset" on page 52

#### Measurement selection

"Selecting a measurement" on page 53

The phase noise measurement

- "Measuring phase noise" on page 53
- "Measuring amplitude noise" on page 54
- "Measuring spurs" on page 54
- "Measuring spot noise" on page 54
- "Measuring integrated noise" on page 55
- "Test setup for measurements with two external mixers" on page 55

#### The additive noise measurement

"How to measure additive noise" on page 56

The baseband noise measurement

- "How to measure baseband noise at the RF input" on page 59
- "How to measure baseband noise at the baseband input" on page 59

The pulsed phase noise measurement

"How to measure the phase noise of a pulse" on page 60

The pulsed additive noise measurement

- "How to measure pulsed additive noise with an internally modulated pulse" on page 61
- "How to measure pulsed additive noise with an externally modulated pulse" on page 61

Trace smoothing

- "How to smooth the trace by averaging the measurement data" on page 63
- "How to smooth the trace by adjusting the number of XCORR operations" on page 63
- "How to smooth the trace graphically" on page 64
- "How to remove spurs from a trace" on page 64

#### Integration ranges

- "How to define integration ranges" on page 65
- "How to correct integrated measurements" on page 66

The cross-correlation gain indicator

"How to control the cross-correlation gain indicator (gray area)" on page 66

Miscellaneous evaluation tools

- "Zooming into the results" on page 67
- "Labeling traces" on page 67
- "Exporting measurement data" on page 67

Frequency configuration

- "How to define the measurement range" on page 68
- "How to search for signals" on page 69
- "How to define the capture range for the signal search" on page 69
- "How to define a carrier frequency manually" on page 69

The half decade configuration table

"How to work with the half decade configuration table" on page 70

Pulsed measurement configuration

"How to configure a gate for measurements on pulses" on page 70

Signal generation

- "How to generate a CW signal" on page 71
- "How to generate a pulse" on page 72
- "How to use an external pulse modulator (configuration)" on page 72

DUT power supply

- "How to supply DUTs with current or voltage" on page 73

- Result Evaluation......62

# 6.1 Initial Setup

#### Preparing the R&S FSWP

- 1. Connect the R&S FSWP to an electrical outlet as described in Chapter 4.1.4, "Connecting the AC Power", on page 24.
- 2. Turn on the R&S FSWP as described in Chapter 4.1.5, "Switching the Instrument On and Off", on page 24.

#### Selecting the phase noise application

- 1. Select the [MODE] key.
- 2. Select the "Phase Noise" item in the "Mode" dialog box.



Ō

#### There's more than one way to skin a cat

In most cases, the firmware of the R&S FSWP provides several ways to change measurement parameters. For example, the measurement range can be defined via the [FREQ] key, the "MEAS CONFIG" key or the "Overview" dialog box.

All procedures in this chapter use the "Overview" dialog box as a starting point (when possible). You can reach this dialog via the "Overview" softkey displayed at the bottom of the softkey bar on the right side of the diagram area.

#### Performing a preset

Before configuring and starting a new measurement, it is always recommended to perform a preset and restore the default configuration of the instrument or the measurement application.

- 1. Select the [PRESET] key on the front panel to restore the default state of the R&S FSWP.
- Enter the "Overview" dialog box and select the "Preset Channel" item to restore the default state of the selected measurement channel. All other measurement channels keep their custom configuration.

# 6.2 Measurements

Measuring the phase noise characteristics of a DUT requires a simple measurement setup consisting of the R&S FSWP and a DUT.

Some measurements require additional equipment.

- For additive noise measurements, the R&S FSWP must be equipped with the optional Signal Source hardware.
- For pulsed noise measurements, the R&S FSWP must be equipped with the optional Pulsed Phase Noise Measurement application.
- For pulsed additive noise measurements, the R&S FSWP must be equipped with the optional Pulsed Phase Noise Measurement application and the optional Signal Source hardware.

•	Measurement Selection	. 53
•	The Phase Noise Measurement	53
•	The Additive Noise Measurement	.56
	The Baseband Noise Measurement	
•	The Pulsed Phase Noise Measurement	60
	The Pulsed Additive Noise Measurement	
	Adding Another Measurement Channel	
	<b>3</b>	-

# 6.2.1 Measurement Selection

### Selecting a measurement

► Select the [MEAS] key.

The R&S FSWP opens a dialog box to select the measurement.

CW Measurements
Phase Noise
Additive Noise
Baseband Noise
Pulsed Measurements
Pulsed Phase Noise
Pulsed Additive Noise

# 6.2.2 The Phase Noise Measurement

### Test setup

Connect the DUT via cable to the RF input of the R&S FSWP as shown in the illustration.




Figure 6-1: Typical test setup for basic noise measurements

#### Measuring phase noise

1. Perform a [PRESET].

The application automatically starts a continuous measurement. First, it searches for a carrier signal (see How to search for signals). When one has been found, it measures the noise characteristics of the DUT in the default measurement (or frequency offset) range.

If no carrier could be found, a corresponding error message is displayed in the status bar below the diagram.

2. You can stop the measurement (to analyze the measurement data in detail) with the [RUN SGL] or [RUN CONT] key; [RUN SGL] performs one more measurement, then stops, [RUN CONT] stops immediately.

By default, two traces are displayed: the first trace shows the smoothed data without spurs, the second trace the raw data including spurs.

#### Measuring amplitude noise

The test setup is the same as shown above.

The default phase noise trace shows the phase noise characteristics of the DUT. In addition, you can also display the amplitude noise characteristics (or both together).

- 1. Enter the "Overview" dialog box and, from there, enter the "Analysis" dialog box.
- 2. Select the vertical "Trace" tab, and then the horizontal "Traces" tab.
- 3. For any trace, select "AM Noise" from the "Result" dropdown menu.

Mode	Result	State Value	State Threshold S	tate Offset
Trace 1 Clear Write 🗧	Phase Noise 🗧 🗧	✓ 1 %	0.0 dB	0.0 dB
Trace 2 Clear Write +	Phase Noise	1 %	0.0 dB	0.0 dB
Trace 3 Blank ÷	AM Noise	1 %	0.0 dB	
Trace 3 Blank ÷	Phase+AM Noise	1%	0.0 dB	0.0 dB
		F		

 Start a new measurement to determine the AM noise of the DUT. (The "Phase + AM Noise" menu item displays the sum of phase and amplitude noise.)

**Tip:** If you'd like to view both results separately at the same time, open two phase noise diagrams, one that shows the phase noise, the other showing the AM noise and perform a measurement.

In addition to the graphical representation of the phase noise characteristics, the application also provides several tables that show specific phase noise characteristics.

#### **Measuring spurs**

In addition to the graphical display of spurs in the diagram (spikes on the trace), the application also features a result display that contains a list of all detected spurs.

 Open the SmartGrid (
) and drag the "Spurious List" item from the evaluation bar into the display.



The spurious list contains all detected spurs (including their characteristics) on all traces and all windows.

More information:

- Spurious list
- Spur removal

#### Measuring spot noise

Spot noise is the phase noise or AM noise at a specific offset frequency (for example the phase noise at 500 kHz).

Open the SmartGrid (□) and drag the "Spot Noise" item from the evaluation bar into the display.

#### Spot Noise

The table contains a list of spot noise values for selected frequency offsets (in the default state, these are the decade edges) on each active trace.

More information:

Spot noise table

**Tip:** You can define custom spot noise frequencies in the "Spot Noise" tab of the "Noise Config" dialog box.

#### Measuring integrated noise

Integrated measurements show various noise characteristics, like the residual noise, integrated over a certain offset frequency range.

Open the SmartGrid (□) and drag the "Integrated Measurements" item from the evaluation bar into the display.

#### Integrated Measurements

The table contains a list of integrated measurement results.


More information:

• Integrated measurements

**Tip:** You can define custom integration ranges in the "Integration Ranges" tab of the "Noise Config" dialog box.

#### Test setup for measurements with two external mixers

Connect the DUT to the mixers and the mixers to the R&S FSWP as shown in the illustration.




- 1. Perform a [PRESET].
- Select the [MEAS] key and select the "Phase Noise" measurement.
- 3. Enter the "Overview" dialog box, and from there, enter the "Input" dialog box.
- Configure both mixers in the "External Mixer" tab of the "Input Source" dialog box. More information:
  - External mixer
- 5. Start the measurement ([RUN SGL] or [RUN CONT]).

# 6.2.3 The Additive Noise Measurement

Additive noise measurements require the signal source output that is available as an optional hardware component.

#### **Test setup**

Connect the DUT via cable to the RF input and the signal source output of the R&S FSWP as shown in the illustration.



#### How to measure additive noise

- 1. Perform a [PRESET].
- 2. Select the "Additive Noise" measurement via the [MEAS] key.
- Configure the signal source output as described in "How to generate a CW signal" on page 71.
- 4. Start the measurement ([RUN SGL] or [RUN CONT]).


The application measures the additive noise on the output frequency of the signal source in the default measurement (or frequency offset) range.

 You can stop the measurement (to analyze the measurement data in detail) with the [RUN SGL] or [RUN CONT] key; [RUN SGL] performs one more measurement, then stops, [RUN CONT] stops immediately. By default, two traces are displayed: the first trace shows the smoothed data without spurs, the second trace the raw data including spurs.

#### How to measure additive noise characteristics of amplifiers and dividers

Measuring the noise characteristics of amplifiers and dividers require a complex test setup. The test setup depends on the type of DUT you are testing and is explained here.

1. **Measuring the additive noise of amplifiers with an external signal source** The test setup for for this measurement looks like this:




- a) Configure the external signal source to generate the required fixed frequency.
- b) Connect the first power splitter to the amplifier and the second power splitter.
- c) Connect the amplifier to the RF input of the R&S FSWP.
- d) Connect the second power splitter to both LO AUX input channels of the R&S FSWP.

The power at each LO AUX input must have a level between 5 dBm and 10 dBm.

Except for the second power splitter, do not add any additional hardware to this signal path.

- e) If required, you can add an attenuator between the first splitter and the amplifier to reduce the amplifier input level.
- f) Select "Overview" > "Select Measurement" > "Additive Noise"
- g) Select "Overview" > "Input" > "Input Source" > "Radio Frequency" > "Local Oscillator" > "External"
- h) Start the measurement ([RUN SINGLE] or [RUN CONT].
- 2. Measuring the additive noise of a divider with an external signal source (without cross-correlation)




- a) Configure the external signal source to generate the required fixed frequency.
- b) Connect both frequency dividers to the first power splitter.
- c) Connect the first frequency divider to the RF input of the R&S FSWP.
- d) Connect the second power splitter to the other frequency divider and connect the resulting signal streams to both LO AUX input channels of the R&S FSWP. Regarding the frequency divider, make sure that both dividers are the same model and have the same dividing factor.

Also make sure that the frequency fed into all inputs of the R&S FSWP is the same.

e) Select "Overview" > "Select Measurement" > "Additive Noise"

- f) Select "Overview" > "Input" > "Input Source" > "Radio Frequency" > "Local Oscillator" > "External"
- g) Start the measurement ([RUN SINGLE] or [RUN CONT]. The results in this measurements are 3 dB higher than they actually are. This is because the divider at the LO AUX inputs is not cancelled out. To get the actual results, subtract 3 dB from the results, for example by shifting the trace by this amount ("Overview" > "Analysis" > "Traces" > "Traces" > "Trace Offset: 3 dB").
- 3. Measuring the additive noise of a divider with an external signal source (with cross-correlation)



- a) Configure the external signal source to generate the required fixed frequency.
- b) Connect the first frequency dividers to the first power splitter.
- c) Connect the first frequency divider to the RF input of the R&S FSWP.
- d) Connect the second power splitter to the first power splitter.
- e) Connect the other two frequency dividers to the second power splitter and connect the resulting signal streams to both LO AUX input channels of the R&S FSWP.

Regarding the frequency divider, make sure that all three dividers are the same model and have the same dividing factor.

Also make sure that the frequency fed into all inputs of the R&S FSWP is the same.

- f) Select "Overview" > "Select Measurement" > "Additive Noise"
- g) Select "Overview" > "Input" > "Input Source" > "Radio Frequency" > "Local Oscillator" > "External"
- h) Start the measurement ([RUN SINGLE] or [RUN CONT].


Compared to measurements on two dividers, this setup displays the correct additive noise of the first frequency divider. The results do not have to be corrected. The additive noise of the frequency dividers connected to the LO AUX inputs is cancelled out because of the cross-correlation properties in the two channels of the LO AUX input.

# 6.2.4 The Baseband Noise Measurement

Baseband Noise measurements measure the noise characteristics of a DUT over an absolute frequency span (not relative to carrier).

You can use either the RF input for these measurements, or the baseband inputs. The baseband inputs are DC coupled and extend the lower frequency range to 1 mHz (the lowest supported frequency on the RF input is 1 MHz). Using the baseband input, you can, for example, test the voltage supply of DC sources.

#### Test setup



\* = See text below for instructions on how to use the baseband input.

#### How to measure baseband noise at the RF input

For baseband noise measurements on the RF input, proceed as follows.

- 1. Connect the DUT to the RF input.
- 2. Perform a [PRESET].

The application automatically starts a continuous measurement and measures the noise characteristics of the DUT in the default frequency range.

- 3. Select the "Baseband Noise" measurement via the [MEAS] key.
- You can stop the measurement (to analyze the measurement data in detail) with the [RUN SGL] or [RUN CONT] key; [RUN SGL] performs one more measurement, then stops, [RUN CONT] stops immediately.

By default, two traces are displayed: the first trace shows the smoothed data without spurs, the second trace the raw data including spurs.

**Tip:** Integrated measurement results. Note that the "PM", "FM" and "Jitter" results are always "0" for baseband noise measurements.

#### How to measure baseband noise at the baseband input

For baseband noise measurements on the baseband input, proceed as follows.

- Connect the DUT to one of the baseband channels. If you want to cross-correlate the measurement, connect the DUT to both baseband channels (add a splitter to the test setup, if the DUT has just one output).
- 2. Perform a [PRESET].
- 3. Select the "Baseband Noise" measurement via the [MEAS] key.
- 4. Enter the "Overview" dialog box, and from there, enter the "Input" dialog box.
- 5. Select the vertical "Baseband" tab.


- 6. Turn on the baseband input.
- Select the "Input" channel you are using for the measurement ("CH1", "CH2" or "CH1xCH2".

The application automatically starts a continuous measurement and measures the noise characteristics of the DUT in the default frequency range.

### 6.2.5 The Pulsed Phase Noise Measurement

Noise measurements on pulses are available with the optional pulsed phase noise measurements firmware application.

#### Test setup



#### How to measure the phase noise of a pulse

- Connect the DUT via cable to the RF input of the R&S FSWP as shown in the illustration.
- 2. Perform a [PRESET].
- Select the [MEAS] key and select the "Pulsed Phase Noise" measurement.

The application tries to detect a pulse in the signal you have applied, using two automatic mechanisms:

- search for the pulse frequency
- detection of the pulse characteristics

If successful, it configures a gate based on the pulse characteristics and starts the noise measurement of the pulse.

The results are displayed the same way as in the other measurements (two traces in the diagram and results for the integrated measurements).


If no frequency or pulse could be found, a corresponding error message is displayed in the status bar below the diagram.

If required, you can also define the frequency and the pulse characteristics manually.

# 6.2.6 The Pulsed Additive Noise Measurement

Additive noise measurements on pulses require the optional pulsed phase noise measurements firmware application and the optional signal source output. The test setup depends on whether you use internal or external modulation with a pulse modulator.

#### Test setup (internal pulse modulation)




#### How to measure pulsed additive noise with an internally modulated pulse

- Connect the signal source (supplies the pulse) to the DUT. The pulse is modulated internally and output on the signal source.
- 2. Connect the DUT to the RF input.
- 3. Perform a [PRESET].
- 4. Select the [MEAS] key and select the "Pulsed Additive Noise" measurement.
- 5. Enter the "Overview" dialog box, and from there, enter the "Output" dialog box.
- 6. Select the "Signal Source" tab and turn on the "Pulse Modulator".
- 7. Configure the pulse characteristics.
- 8. Start the measurement with [RUN SGL] or [RUN CONT].

#### Test setup (external pulse modulation)



For pulsed measurements using the LO AUX input, do not apply pulses with a frequency below 1024 MHz. Pulses below that frequency will abort the measurement.



#### How to measure pulsed additive noise with an externally modulated pulse

1. Connect the signal source to the pulse modulator.

The signal source in that case provides a continuous wave signal which is modulated into a pulse by the pulse modulator.

- Connect the trigger 1 output to the pulse modulator. The signal provided on this output is a pulse and is required as a trigger signal for the external pulse modulator.
- 3. Connect the pulse modulator to the DUT.
- 4. Connect the DUT to the RF input.
- 5. Perform a [PRESET].
- 6. Select the [MEAS] key and select the "Pulsed Phase Noise" measurement.
- 7. Select the "Signal Source" tab and turn off the "Pulse Modulator".
- 8. Select the output at the Trigger 1 Output
- 9. Configure the pulse characteristics.
- 10. Start the measurement with [RUN SGL] or [RUN CONT].

### 6.2.7 Adding Another Measurement Channel

Measuring the noise characteristics in two different measurement channels allows you, for example, to capture and analyze two different data streams with different measurement configurations.

#### Adding another measurement channel

- 1. Select the [MODE] key.
- 2. Select the "Phase Noise" item in the "Mode" dialog box.

The firmware adds a second instance of the phase noise application which is independent of the first one.

# 6.3 Result Evaluation

The phase noise application provides several tools to control the data displayed in the various result displays. Some tools have an effect on the graphical result displays, other on the numerical results and still others on both graphical and numerical (for example in case the numerical results are based on the graphical results).

•	Trace Smoothing	63
	Integration Ranges	
	The Cross-Correlation Gain Indicator	
•	Miscellaneous Evaluation Tools	. 67

# 6.3.1 Trace Smoothing

#### How to smooth the trace by averaging the measurement data

When you average the trace, the application measures the data several times and builds an average over all measurements when it is done. Averaging measurement data yields a smoother trace.

Trace averaging is applied to all traces.

- 1. Enter the "Overview" dialog box, and from there, enter the "Noise Config" dialog box.
- 2. Define the number of measurements to be performed in the "Sweep / Average Count" input field, for example "10".



- 3. Start the measurement.
  - In case of a single measurement, the application performs x measurements over the frequency range you have defined. An average count of "10", for example, would result in 10 measurements.
  - In case of continuous measurements, the application performs a moving average over the average count.

#### How to smooth the trace by adjusting the number of XCORR operations

When you apply cross-correlation operations, the application is able to determine the phase noise characteristics at a certain frequency offset more precisely.

You can improve cross-correlation performance with the corresponding hardware option.

The number of cross-correlation operations applied in each half decade depends on a cross-correlation factor that you can define arbitrarily.

Cross-correlation operations are applied to all traces.

- 1. Enter the "Overview" dialog box, and from there, enter the "Noise Config" dialog box.
- 2. Define the cross-correlation factor as required in the "XCORR Factor" input field.



The application calculates the number of cross-correlations for each half decade based on this factor. You can see the resulting operations in the table of the "Noise Config" dialog box.

The number of operations calculated for each half decade targets a similar measurement time for all half decades, so that the measurement is done at roughly the same time in each half decade. You can also see the resulting number of operations in the green bar at the bottom of the diagram area.

More information:

Cross-correlation

#### How to smooth the trace graphically

When you apply trace smoothing, the existing data remains the same. The trace is smoothed by applying mathematical operations

Trace smoothing is applied to each trace individually.

- 1. Enter the "Overview" dialog box, and from there, enter the "Analysis" dialog box.
- 2. Select the vertical "Trace" tab, and then the horizontal "Traces" tab.
- For any trace, turn on "Smoothing" and define the amount by which the trace should be smoothed (in %) in the corresponding input field.

		Mode	Result	State Value	State Threshold	State Offset
Markers	Trace 1	Clear Write	Phase Noise	: 🗹 🛛 1 %	0.0 dB	0.0 dB

Trace smoothing is applied immediately after you have applied it to a trace.

More information:

Trace smoothing

#### How to remove spurs from a trace

By default, the application already shows a trace without spurs (the yellow one). However, you can decide for each trace individually whether it shows spurs or not.

Spur removal is done after traces have been smoothed in any way.

- 1. Enter the "Overview" dialog box, and from there, enter the "Analysis" dialog box.
- 2. Select the vertical "Trace" tab, and then the horizontal "Traces" tab.
- 3. For any trace, remove or display spurs individually. You can also enter a threshold that defines a level from which a spur is recognized as a spur.



The application removes all signals that are above the threshold from the trace spur removal is applied to. Signals with levels below the threshold are not regarded as spurs and are still displayed.

More information:

Spur removal

**Note:** Note that the threshold is always taken into account in the spur table, regardless of whether spur removal is on or off.

# 6.3.2 Integration Ranges

#### How to define integration ranges

For the integrated measurements (residual AM, FM and PM and jitter), you can define custom integration ranges.

By default, the integration range corresponds to the measurement range defined by the frequency offsets. Custom integration ranges can have any range you desire.

Integration is done after traces have been smoothed in any way.

- 1. Enter the "Overview" dialog box and, from there, enter the "Noise Config" dialog box.
- 2. Select the "Integrated Measurements" tab.

Phase N	oise Inte	grated Measurem	ents Spot Nois	e		
	Show	Range	Range Start	Range Stop	Weighting Filter	
Range 1	Trace 1	Meas Manual	1.0 kHz		NONE	•
Range 2	Trace 2	Meas Manual	20.0 kHz	400.0 kHz	NONE	•

Select the "Trace" whose data you would like to integrate from the "Show "dropdown menu.

**Tip:** If you select a trace that is currently not displayed in the diagram, no integrated measurement results will be displayed for the corresponding range.

- 4. Select "Manual" integration ranges.
- 5. Define the frequency ranges ("Range Start" and "Range Stop") over which you would like to integrate.

The application calculates the measurement results as defined. Result in the integrated measurements result table are adjusted accordingly (see "Measuring integrated noise" on page 55 for a description on how to view that table).



Figure 6-2: Custom integration range results (frequency range from 3 kHz to 500 kHz, applied to trace 2)

Note that the integration ranges are displayed graphically in the noise diagram.

xcorr 1 X	CORR 1	XCORR 10	xcorr 37 cy Offset	XCORR 130	xcorr 400 1.0 MHz
-140 dBc/Hz					
130 de lorn	1000		$\sim$		1 Rr_ dB
-120 dBc/Hz	1 1 1 1				-120 dB
-110 dBc/Hz					-1 1 dB
-100 dBc/Hz	1 1 1 1 1				-100 dB
-90 dBc/Hz					
-70 dBc/Hz					-70 dB
-60 dBc/Hz					
	Rang	<u>je 2</u>			
				Range 1	-40 dB
l Phase Noise	1.10		v PN Smth 1	<sup>k</sup> Ränge 1	

Figure 6-3: Custom integration ranges are represented in the diagram as colored lines

More information: Residual effects

#### How to correct integrated measurements

You can use so called weighting filters to compensate external effects that affect the phase noise in certain frequency ranges.

Weighting filters are applied before trace are smoothed and before integration is applied.

- 1. Enter the "Overview" dialog box, and from there, enter the "Noise Config" dialog box.
- 2. Select the "Integrated Measurements" tab.
- 3. Select a weighting filter from the corresponding dropdown menu.

Phase N	oise Integ	rated Measurem	ents Spot Nois	e (	
Ranges					
	Show	Range	Range Start	Range Stop	Weighting Filter
Range 1	Trace 1 🗘	Meas Manual	1.0 kHz		NONE
Range 2	Trace 2	Meas Manual	20.0 kHz	400.0 kHz	FILTER # 1
Range 3	None +	Meas Manual	1.0.kHz	1.0 MHz	FILTER NUMBER 2
- Range a	- Tone -	Manual			NONE

The dropdown menu contains all filters currently available on the hard disk of the R&S FSWP.

When you apply the weighting filter, the results are automatically corrected by the filter characteristics.

If you do not have a filter yet, or want to change filter characteristics for an existing filter, design one or change one.

More information:

- Weighting filter design
- Weighting filter management

# 6.3.3 The Cross-Correlation Gain Indicator

#### How to control the cross-correlation gain indicator (gray area)

The gray trace, or cross-correlation gain indicator, indicates the ideal position of the measurement trace for the current number of cross-correlation operations. Thus, the position of this area depends on the number of cross-correlations that are currently applied in each half decade.

This in turn indicates that measurement traces that are close to the gray area (even if only in places) can be improved by increasing the cross-correlation operations. On the other hand, when the measurement trace lies above the gray area throughout (about 10 dB), it is not possible to improve the results any more.

More information: XCORR gain indicator

1. Enter the "Overview" dialog box, and from there, enter the "Noise Config" dialog box.

- 2. Select the "Noise Config" tab.
- 3. Change the "XCORR Factor", run a single measurement, and see how the position of the gray area changes.



Figure 6-4: Increasing XCORR operations changes shape of gray area

4. If required, you can turn this area on and off as required with the "XCORR Gain Indicator" feature.

# 6.3.4 Miscellaneous Evaluation Tools

#### Zooming into the results

The zoom tool is useful if you want to see parts of the results in more detail.

- In the diagram, select the area you want to zoom in to (while doing this, the area is marked by a dotted line).
- 3. You can return to the full display any time with the "Unzoom" icon in the toolbar (🕄).

#### Labeling traces

Labeling traces with a short keyword is a good way to distinguish traces and see immediately what the trace actually represents.

- 1. Enter the "Overview" dialog box and, from there, enter the "Analysis" dialog box.
- 2. Select the vertical "Traces" tab and the horizontal "Trace Label" tab.
- 3. Turn on the trace label for a certain trace and define a string of text as a label.

The application adds a label to the trace. The color of the label is the same as the trace color.

Tip: You can move trace labels around via drag and drop.

#### Exporting measurement data

Exporting measurement data to a .dat file allows you to archive that data in external programs like a spreadsheet.

- 1. Enter the "Overview" dialog box and, from there, enter the "Analysis" dialog box.
- 2. Select the vertical "Traces" tab and the horizontal "Trace / Data Export" tab.

- 3. Select the data types as required (trace data only or together with numerical results and / or measurement settings).
- 4. Select the "Export to ASCII File" button and select the destination where you want to save that data.
- 5. View the .dat file that has been created with your preferred program.

# 6.4 Measurement Configuration

The Phase Noise application provides several tools that make the measurement process easier to handle or allow you to customize the measurement configuration according to your needs.

•	Frequency Configuration	.68
	The Half Decade Configuration Table	
	Pulsed Measurement Configuration	
	Signal Generation	
	DUT Power Supply	

# 6.4.1 Frequency Configuration

#### How to define the measurement range

The measurement range defines the carrier frequency offset over which the phase noise measurement takes place.

- 1. Enter the "Overview" dialog box, and from there, enter the "Noise Config" dialog box.
- 2. Select the "Noise Config" tab.
- 3. Define the measurement range with the "Start Offset" and "Stop Offset" properties.



The application adjusts the measurement range. You can see this change, for example, in the noise diagram result display.

**Note**: In case of baseband measurements, the measurement range is defined by an absolute start and stop frequency instead of offsets.

More information:

• Measurement range

#### How to search for signals

The application allows you to search for a carrier signal, instead of defining the carrier frequency manually.

- 1. Enter the "Overview" dialog box, and from there, enter the "Frequency" dialog box.
- 2. Turn on the "Auto Search" feature (it is on by default).
- Define the frequency range in which the search should take place ("Start" and "Stop"). By default the search is done in the maximum frequency range supported by the hardware.
- Define a "Threshold" for the search. Signals below the threshold are ignored during the search.

When the application finds a signal with appropriate characteristics, it starts a phase noise measurement in the measurement range you have defined. **Note**: Automatic signal search is only available in phase noise and pulsed phase noise measurements.

#### How to define the capture range for the signal search

The capture range represents the frequency bandwidth with which a signal is searched, and, if found, tracked.

A **normal capture range** is recommended for measurements on stable (or slowly drifting) DUTs. A **wide capture range** is recommended for DUTs whose frequency drifts over greater distances. In the latter case, a normal capture range would probably result in a scenario, where the signal drifts out of the capture range, and has to be searched again (which would slow down the measurement considerably).

- 1. Enter the "Overview" dialog box, and from there, enter the "Frequency" dialog box.
- Select an appropriate "Capture Range" for your DUT. Note: This feature is only available in phase noise and pulsed phase noise measurements.

#### How to define a carrier frequency manually

When you already know the frequency of the carrier signal, you can define it manually and reduce the measurement time.

- 1. Enter the "Overview" dialog box, and from there, enter the "Frequency" dialog box.
- 2. Turn off the "Auto Search" feature.
- 3. Define the "Signal Frequency".

The application performs the measurement on the defined frequency.

# 6.4.2 The Half Decade Configuration Table

#### How to work with the half decade configuration table

The half decade configuration table contains the measurement configuration for each half decade that is analyzed during a measurement.

You can either enter the values for the measurement bandwidth and number of crosscorrelation operations directly. Or you can let the application calculate ideal values for each half decade.

- 1. Enter the "Overview" dialog box, and from there, enter the "Noise Config" dialog box.
- Select automatic or manual configuration mode with the "Half Decade Config" feature.
- In case of an automatic configuration, define an "RBW" factor and an "XCORR Factor".

From these values, the application calculates the best and least time-consuming absolute resolution bandwidth and cross-correlation operations for each half decade.

 In case of a manual configuration, define the resolution bandwidth and number of cross-correlations for each half decade directly in the half decade configuration table as absolute values.

The relative "RBW" factor and "XCORR Factor" are ignored.

### 6.4.3 Pulsed Measurement Configuration

#### How to configure a gate for measurements on pulses

Noise measurements on pulses are available with the optional pulsed phase noise measurements firmware application.

By default, the application automatically detects the pulse characteristics and defines the gate characteristics based on the pulse. If required, you can also define these parameters manually.

- 1. Enter the pulsed phase noise measurement.
- Select the [MEAS CONFIG] key and enter the "Pulse" dialog box with the "Pulse Config" softkey.
- 3. In the "Pulse" dialog box, select "Manual" pulse detection.

The input fields for the "Pulse Repetition Interval" and those for the "Gate Characteristics" become available. You can change them if required.

4. Configure the "Pulse Rep Interval" as required.

5. Configure the gate as required ("Gate Type", "Gate Level", "Gate Delay" and "Gate Length").

The shape of the gate is represented by various lines and bars in the "Preview" diagram that is part of the dialog box.

Meas Time 1.0 ms	1 Magnitude		I IAP CIN
Pretrigger 100.0 µs			
	T dime		
	CF 50.0 MHz	1001 pts	100.0 µs/
Pulse Settings	Gate Settings		
Pulse Detection	Gate Type	evel Edge Off Gate Delay	500:0 ns
Auto	Detect Once		100 C
Pulse Rep Interval 2.0 us	Gate Level -1	10.0 dBm Gate Length	1.0 µs

More information:

• Pulsed phase noise

**Tip:** You can turn off the gate, if one is not required for the measurement. To do so, select "Gate Type: Off".

# 6.4.4 Signal Generation

#### How to generate a CW signal

Some measurement setups require you to feed a signal into the DUT. You can equip the R&S FSWP with an optional Signal Source that is able to generate such a signal.

Available only for additive noise measurements and with the optional signal source hardware component.

- 1. Enter the Additive Noise measurement.
- 2. Enter the "Overview" dialog box, and from there, enter the "Output" dialog box.
- 3. Select the "Signal Source" tab.
- 4. Define the frequency and level of the CW signal in the corresponding input fields.

DC Config	Source Power	On Off
	Channel Coupling	On Off
Signal		
Source	Frequency	1.0 GHz
Output	Level	0.0 dBm
output	Pulse Modulation	On Off
	DUT Bypass	On Off

5. Turn on the signal source with the "Source Power" feature.

**Tip:** You can turn the signal source on and off effectively with the "RF On/Off" button in the toolbar. The "RF Config" button provides access to a softkey menu that lets you change the signal source characteristics without entering a dialog box.

#### How to generate a pulse

Instead of a continuous wave signal, you can generate a pulse at the signal source output.

Available only for additive pulsed phase noise measurements and with the optional signal source hardware component.

- 1. Enter the "Overview" dialog box, and from there, enter the "Output" dialog box.
- 2. Select the "Signal Source" tab.
- Turn on the (internal) "Pulse Modulator". When the "Pulse Modulator" is off, a CW signal is generated. However, you can still generate a pulse with an external pulse modulator (a trigger signal is required for that, see "How to use an external pulse modulator (configuration)" on page 72).
- 4. Define the required pulse "Width" and "Period".
- 5. Turn on the signal source with the "Source Power" feature.


**Tip:** You can turn the signal source on and off easily with the "RF On/Off" button in the toolbar. The "RF Config" button provides access to a softkey menu that lets you change the signal source characteristics without entering a dialog box.

#### How to use an external pulse modulator (configuration)


Instead of generating a pulse internally, you can also use an external pulse modulator to generate a pulse required for testing of a DUT.

In this scenario, you can use a trigger signal (available at the trigger output) to control an external pulse modulator.

- 1. Enter the "Overview" dialog box, and from there, enter the "Output" dialog box.
- 2. Select the "Signal Source" tab.
- Turn off the (internal) "Pulse Modulator". When the (internal) "Pulse Modulator" is off, a CW signal is generated at the signal source.
- 4. Select the output type at the "Trigger 1 Output" (on the front panel) to generate a pulse at the trigger output.
  - "High" generates a high active pulse at the trigger 1 output.



"Low" generates a low active pulse at the trigger 1 output.



**Note:** In the phase noise application, the trigger connector on the front panel always serves as an output.

- 5. Define the required pulse "Width" and "Period".
- 6. Turn on the signal source with the "Source Power" feature.

**Tip:** You can turn the signal source on and off easily with the "RF On/Off" button in the toolbar. The "RF Config" button provides access to a softkey menu that lets you change the signal source characteristics without entering a dialog box.

## 6.4.5 DUT Power Supply

#### How to supply DUTs with current or voltage

Some measurement setups or DUTs require you to supply them with either voltage or current.

The R&S FSWP can provide both, when you set it up that way.

- 1. Enter the "Overview" dialog box and, from there, enter the "Output" dialog box.
- 2. Select the "DC Config" tab.

There you have the following options:

- Turn each of the three DC outputs on or off.
- Define the supplied voltage (or current in case of the V<sub>supply</sub> output).
- Define limits for the outputs. When you define limits, the supplied voltage will not go below or above these.
- DC power output
- 3. Turn on the output of voltage or current with the "DC Power" feature.

**Tip:** You can turn the output on and off easily with the "DC On / Off" button in the toolbar. The "DC Config" button provides access to a softkey menu that lets you define the signal characteristics without entering a dialog box.

#### Understanding the Display Information

# 7 Operating the Instrument

The following topics provide an overview on how to work with the R&S FSWP. They describe what kind of information is displayed in the diagram area, how to operate the R&S FSWP via the front panel keys and other interaction methods, and how to use the Online Help.

•	Understanding the Display Information	.74
	Accessing Functions	
	Changing the Focus	
	Entering Data	
	Displaying Results	
	Remote Control	

# 7.1 Understanding the Display Information

The following figure shows a measurement diagram in the Phase Noise application. All different information areas are labeled. They are explained in more detail in the following sections.



1 = Toolbar: contains general functionality of the firmware.

- 2 = Channel tab: contains measurement channel.
- 3 = Channel bar: shows measurement settings.
- 4 = Result display: contains measurement results.
- 5 = Window title bar: contains diagram-specific (trace) information.
- 6 = Status bar: contains system messages, progress bar and date and time.

Understanding the Display Information

- 7 = Input field.
- 8 = Diagram footer: contains diagram-specific information.
- 9 = Softkeys: provide access to measurement functions.

#### Hiding elements in the display

You can hide some of the elements in the display, for example the status bar or channel bar, in order to enlarge the display area for the measurement results ("Setup > Display > Displayed Items").

For details see the R&S FSWP User Manual.

•	Channel Bar	.75
•	Window Title Bar	. 77
•	Marker Information	.78
•	Spot Noise Information	.78
	Measurement Progress Information	
•	Frequency Information in Diagram Footer	80
	Instrument and Status Information	
•	Error Information	. 81

# 7.1.1 Channel Bar

Using the R&S FSWP you can handle several different measurement tasks (channels) at the same time (although they can only be performed asynchronously). For each channel, a separate tab is displayed on the screen. In order to switch from one channel display to another, simply select the corresponding tab.



Alternatively, if many tabs are displayed, select the tab selection list icon at the right end of the channel bar and select the channel you want to switch to from the list.



**MultiView tab** 

An additional tab labelled "MultiView" provides an overview of all active channels at a glance. In the "MultiView" tab, each individual window contains its own channel bar with an additional button. Tap this button to switch to the corresponding channel display quickly.



#### Icons in the channel bar

The star icon (a) on the tab label indicates that the displayed trace no longer matches the current instrument settings. This may be the case, for example, if a trace is frozen and the instrument settings are changed. As soon as a new measurement is performed, the icon disappears.

The exclamation mark ("!" or ) icon indicates that an error or warning is available for that measurement channel. This is particularly useful if the MultiView tab is displayed.

The <sup>(2)</sup> icon indicates the currently active channel during an automatic measurement sequence (**Sequencer** functionality).

Beneath the channel name, information on channel-specific settings for the measurement are displayed in the **channel bar**. Channel information varies depending on the active application.

In addition to the channel-specific settings, the channel bar above the diagram also displays information on instrument settings that affect the measurement results even though this is not immediately apparent from the display of the measured values. This information is displayed only when applicable for the current measurement.

The following table contains all labels that might be displayed in the Spectrum and Receiver applications.

Label	Information
Signal Frequency	Current carrier frequency of the applied signal.
Signal Level	Currently level measured on the carrier frequency.
Att	Current RF attenuation.
RBW	Current Resolution bandwidth (RBW). The RBW is a function of the start offset frequency of each half decade included in the measurement.
XCORR Factor	Current cross-correlation factor. The cross-correlation factor defines the number of cross-correlations are done in each half decade included in the measurement.
Meas Time (estimated)	Current estimated measurement time.
	The measurement time depends, among other things, on the offset frequency, the resolution bandwidth or the number of averages / cross-correlations that you have defined.
Source Frequency	Current frequency of the signal source output.
	Displayed if the optional signal source is installed.
Source Level	Current level of the signal source output.
	Displayed if the optional signal source is installed.
SGL	Current number of measurements performed in a single sweep. Only displayed if you are in single sweep measurement mode.
Count	The current signal count for measurement tasks that involve a specific number of subsequent sweeps.
Meas	Currently selected measurement (Phase Noise, Additive Phase Noise etc.).

Table 7-1: Channel settings displayed in the channel bar

#### Understanding the Display Information

Label	Information
Input ExtMix	Currently selected waveguide band of an external mixer. Only displayed if an external mixer is selected as an input source.
Gain	Difference between DUT signal level and signal source level.
	Displayed in Additive Noise measurements.

#### Icons for individual settings

A bullet next to the setting indicates that user-defined settings are used, not automatic settings. A green bullet indicates this setting is valid and the measurement is correct. A red bullet indicates an invalid setting that does not provide useful results.

# 7.1.2 Window Title Bar

Each channel in the R&S FSWP display may contain several windows. Each window can display either a graph or a table as a result of the channel measurement. Which type of result evaluation is displayed in which window is defined in the display configuration (see Chapter 7.5, "Displaying Results", on page 88). The window's title bar indicates which type of evaluation is displayed.

## **Trace Information in Window Title Bar**

Information on the displayed traces is indicated in the window title bar.

Resu	It type
Trace number	Spur removal
O1Clrw P	N Smth 5% Spur 5dB Offset 5dB
Trace color	Trace smoothing Trace offset
Trace mode	e
Trace color	Color of trace display in diagram
Trace number	Number of the trace (1 to 6)
Trace Mode	Abbreviation of the trace mode: <ul> <li>Clrw</li> <li>Clear Write trace</li> </ul> <li>Max</li> <li>Max Hold trace</li> <li>Min</li> <li>Min Hold trace</li> <li>Avg</li> <li>Average trace</li> <li>View</li> <li>Frozen trace</li> <li>WrH</li> <li>Write Hold trace</li>
Result type	Type of result the trace represents. PN AM PN + AM

Trace smoothing	Trace smoothing characteristics. Only displayed if trace smoothing has been turned on for a trace.
Spur removal	Spur removal characteristics. Only displayed if spur removal has been turned on for a trace.
Trace offset	Trace offset characteristics. Only displayed if an offset has been defined for a trace.

# 7.1.3 Marker Information

Marker information is provided either in the diagram grid or in separate marker tables, depending on the configuration.

#### Marker information in diagram grid

Within the diagram, the x-axis and y-axis positions of the last 2 markers or delta markers that were set are displayed, if available, as well as their index. The value in the square brackets after the index indicates the trace to which the marker is assigned. (Example: M2[1] defines marker 2 on trace 1.) For more than 2 markers, a separate marker table is displayed beneath the diagram by default.

#### Marker information in marker table

In addition to the marker information displayed within the diagram grid, separate marker tables may be added to the display. These tables provide the following information for all active markers:

Label	Information
Wnd	Window type the marker is positioned in. (Only if there is more than one window containing a phase noise diagram.)
Туре	Marker type: N (normal), D (delta), T (temporary, internal)
Ref	Reference (for delta markers)
Trc	Trace to which the marker is assigned
X-value	x-value of the marker
Y-value	y-value of the marker

#### Table 7-2: Regular marker table

# 7.1.4 Spot Noise Information

#### Spot noise information in diagram grid

The diagram contains information about all spot noise positions [T<x>]. Spot noise information is made up out of the position of the spot noise measurement on the x-axis and the y-axis. The value in the square brackets after the index indicates the trace to which the spot noise calculation is assigned (Example: [T1] indicates trace 1). Note that you can also display spot noise information in a separate table.

#### Spot noise information in spot noise table

The R&S FSWP also provides a numerical result table for the spot noise measurement. The spot noise table has to be added deliberately. Note that the spot noise table only contains information when the calculation of spot noise has been turned on.

Table 7-3: Spot noise information result table

Label	Information
Wnd	Measurement window that the spot noise has been calculated for. (Only if there is more than one window containing a phase noise diagram.)
Offset	Offset frequency or spot noise position on the x-axis of the Phase Noise dia- gram.
Noise [T <x>]</x>	Measured noise on the spot noise position for each active trace.

## 7.1.5 Measurement Progress Information

The Phase Noise result display shows the progress of the measurement in a series of green bars at the bottom of the diagram area. For each half decade in the measurement, the R&S FSWP adds a bar that spans the frequency range of the corresponding half decade.

The bar has several features.

- Measurement times less than 1 s
   The numbers within the green bar indicate the number of cross-correlation operations applied to the corresponding half decade.
- Measurement times greater than 1 s The numbers within the green bar show the progress of the cross-correlation operations in the half decade the application currently works on.

The first number is the current, the second number the total count of cross-correlations for that half decade. The bars of half decades in which a measurement is still running has a lighter tone of green than bars of half decades in which the measurement has already finished (see image below).

- A double-click on the bar opens the "Noise Config" dialog box to define the crosscorrelation factor for that half decade.
- A right-click on the bar opens a context menu.

1006/2000	XCORR 6000
XCORR Factor	
Phase Noise	
Residual Calcul	ations
Spot Noise	
DC Source Conf	fig
Display Config	

The context menu provides easy access to various parameters to set up the measurement.

## 7.1.6 Frequency Information in Diagram Footer

Graphical result displays contain information in the diagram footer. The information (beneath the diagram) depends on the result display.

The contents depend on the application and the result display.

Label	Information
Start offset	Start offset frequency
Stop offset	Stop offset frequency

## 7.1.7 Instrument and Status Information

Global instrument settings and functions, the instrument status and any irregularities are indicated in the status bar beneath the diagram.



In the MultiView tab the status bar always displays the information for the currently selected measurement.

The following information is displayed:

#### Instrument status

DC	<ul> <li>The state of the DC Power features.</li> <li>white label = DC Power has been turned off</li> <li>green label = DC Power has been turned on and is within the defined limits</li> <li>red label = DC Power has been turned on and violates the defined limits</li> </ul>
	The R&S FSWP is configured for operation with an external reference.

#### Progress

The status of the current operation is displayed in the status bar. This includes the remaining measurement time for measurements that last longer than 1 second.

Display of the remaining measurement time is supported by the following measurements:

- (Additive) phase noise
- Pulsed (additive) phase noise
- Baseband noise

Measuring 7.1 s



In the MultiView tab, the progress bar indicates the status of the currently selected measurement, not the measurement currently being performed by a Sequencer, for example.

#### Date and time

The date and time settings of the instrument are displayed in the status bar.

16.10.2020	
10:43:58	

#### Error messages and warnings

If errors or irregularities are detected, a keyword and an error message, if available, are displayed in the status bar.

# 7.1.8 Error Information

If errors or irregularities are detected, a keyword and an error message, if available, are displayed in the status bar.

Instrument warming up	¢

Depending on the type of message, the status message is indicated in varying colors.

Color	Туре	Description
red	Error	An error occurred at the start or during a measurement, e.g. due to missing data or wrong settings, so that the measurement cannot be started or completed correctly.
orange	Warning	An irregular situation occurred during measurement, e.g. the settings no lon- ger match the displayed results, or the connection to an external device was interrupted temporarily.
gray	Information	Information on the status of individual processing steps.
no color	No errors	No message displayed - normal operation.
green	Measurement successful	Some applications visualize that the measurement was successfull by show- ing a messsage.

Table 7-4: Status bar information - color coding



If any error information is available for a measurement channel, an exclamation mark is displayed next to the channel name (**I**). This is particularly useful when the MultiView tab is displayed, as the status bar in the MultiView tab always displays the information for the currently selected measurement only.

Furthermore, a status bit is set in the STATUS:QUEStionable:EXTended:INFO register for the application concerned (see "STATUS:QUEStionable:EXTended:INFO Register" on page 341). Messages of a specific type can be queried using the SYST:ERR:EXT? command, see SYSTem:ERRor:EXTended? on page 603.

Message	Meaning
IF OVLD	Overload of the IF signal path in the A/D converter or in the digital IF.
	Increase attenuation or remove the signal from the RF input.
LOUNL	Error in the instrument's frequency processing hardware was detected.
NO REF	Instrument was set to an external reference but no signal was detected on the reference input.
OVEN	The optional OCXO reference frequency has not yet reached its operating tempera- ture. The message usually disappears a few minutes after power has been switched on.
RF OVLD	Overload of the input mixer or of the analog IF path.
	Reduce the input level.
UNCAL	<ul> <li>One of the following conditions applies:</li> <li>Correction data has been switched off.</li> <li>No correction values are available, for example after a firmware update.</li> <li>Record the correction data by performing a self alignment</li> </ul>
WRONG_FW	The firmware version is out-of-date and does not support the currently installed hard- ware. Until the firmware version is updated, this error message is displayed and self- alignment fails.
	(For details refer to the R&S FSWP User Manual).

#### Table 7-5: Keywords in the status bar

# 7.2 Accessing Functions

All tasks necessary to operate the instrument can be performed using the user interface. Apart from instrument specific keys, all other keys that correspond to an external keyboard (for example arrow keys, [Enter] key) operate conform to Microsoft.

For most tasks, there are at least 2 alternative methods to perform them:

- Using the touchscreen
- Using other elements provided by the front panel, for example the keypad, rotary knob, or arrow and position keys.

The measurement and instrument functions and settings can be accessed by selecting one of the following elements:

- System and function keys on the front panel of the instrument
- Softkeys on the touchscreen
- Context menus for specific elements on the touchscreen
- Icons on the tool bar in the touchscreen
- Displayed setting on the touchscreen

•	Toolbar	. 83
	Softkeys	
	Context Menus	
•	On-screen Keyboard	.85

# 7.2.1 Toolbar

The icons in the toolbar provide access to general functions.

🔊 😭 🗒 📥 🦡 🖈 💦 🕵 🔝 🛋 🎘 🛱 🚱 🕫

Q

You can hide the toolbar display, for example when using remote control, in order to enlarge the display area for the measurement results ("Setup > Display > Displayed Items"). See the R&S FSWP User Manual for details.

	Windows: opens the Windows "Start" menu and task bar.
	Open: opens a file from the instrument or an external device ("Save/Recall" menu).
	Store: stores data on the instrument or an external device ("Save/Recall" menu).
ц	Print: defines print settings ("Print" menu).
•	Undo: reverts last operation
→	Redo: repeats previously reverted operation
R	Select: the cursor can be used to select (and move) elements in the display (markers, lines etc.).
Ľ⊕ <b></b>	Zoom mode: displays a dotted rectangle in the diagram that can be expanded to define the zoom area.
	Multiple zoom mode: multiple zoom areas can be defined for the same diagram.
1:1	Zoom off: displays the diagram in its original size.
	SmartGrid: activates "SmartGrid" mode to configure the screen layout.
(3)	Sequencer: opens the "Sequencer" menu to perform consecutive measurements.

DC On/Off	DC Power: turns the DC power output on and off.
DC Config	DC Configuration: provides quick access to configure the main parameters for DC power supply.
	Signal Source: turns the optional signal source output on and off.
On/Off	(Available when the optional signal source output is installed.)
RF	RF Config: provides quick access to configure the main parameters of the signal source.
Config	(Available when the optional signal source output is installed.)
<b>k</b> ?	Help (+ Select): allows you to select an element for which context-specific help is displayed.
?	Help: displays context-sensitive help topic for currently selected element.
Ō	Print immediately: prints the current display (screenshot) as configured.
In "SmartGrid" r	mode only:
×	Close: Exit "SmartGrid" mode.

## 7.2.2 Softkeys

Softkeys are virtual keys provided by the software. Thus, more functions can be provided than those that can be accessed directly via the function keys on the instrument. Softkeys are dynamic: depending on the selected function key, a different list of softkeys is displayed on the right side of the screen.

A list of softkeys for a certain function key is also called a menu. Softkeys can either perform a specific function or open a dialog box.

#### Recognizing the softkey status by color


Color	Meaning
orange associated dialog box is open	
blue	associated function is active; for toggle keys: currently active state
gray	instrument function is temporarily not available due to a specific setting or missing option



You can hide the softkey display, e.g. when using remote control, in order to enlarge the display area for the measurement results ("Setup > Display > Displayed Items"). See the User Manual for details.

# 7.2.3 Context Menus

Several items in the diagram area have context menus (for example markers, traces or the channel bar). If you right-click on one of these items (or tap it for about 1 second), a menu is displayed which contains the same functions as the corresponding softkey. This is useful, for example, when the softkey display is hidden.



# 7.2.4 On-screen Keyboard

The on-screen keyboard is an additional means of interacting with the instrument without having to connect an external keyboard.

Esc	~ 、	<sup>!</sup> 1	<sup>@</sup> 2	# 3	\$ 4	<sup>%</sup> 5 <sup>^</sup>		7	8	9	0 -		=
Tab	q	W	е	r	t	у	u	i	0	р	{[	}	Del
Caps		а	s	d	f	g ł	h j	k	I	\$	;	, Ent	er
Shift		z	Х	с	v	b	n	m			? /	$^{\sim}$	Shift
Fn	Ctrl	:	Alt						Alt	Ctrl	<	$\sim$	>

The on-screen keyboard display can be switched on and off as desired using the "On-Screen Keyboard" function key beneath the screen.



When you press this key, the display switches between the following options:

- Keyboard displayed at the top of the screen
- Keyboard displayed at the bottom of the screen
- No keyboard displayed



You can use the TAB key on the on-screen keyboard to move the focus from one field to another in dialog boxes.

# 7.3 Changing the Focus

Any selected function is always performed on the currently focused element in the display, e.g. a dialog field, diagram, or table row. Which element is focused is indicated by a blue frame (diagram, window, table) or is otherwise highlighted (softkey, marker etc.). Moving the focus is most easily done by tapping on the element on the touchscreen. Alternatively, use the "Tab" key on the on-screen keyboard or the rotary knob to move the focus from one element to the next on the display.



To move the focus between any displayed diagrams or tables in a window, press the "Change focus" key on the front panel. The focus moves from the diagram to the first table to the next table etc. and then back to the diagram, within the same window.

In fullscreen mode, where a single window is displayed in full size on the screen, this key switches the focus (and the display) from one active window to the next.

# 7.4 Entering Data

You can enter data in dialog boxes using any of the following methods:

- Using the touchscreen, via the on-screen keyboard
- Using other elements provided by the front panel, e.g. the keypad, rotary knob, or navigation keys

The rotary knob acts like the [ENTER] key when it is pressed.

Using a connected external keyboard

#### Transparent dialog boxes

You can change the transparency of the dialog boxes to see the results in the windows behind the dialog box. Thus, you can see the effects that the changes you make to the settings have on the results immediately.

To change the transparency, select the transparency icon at the top of the dialog box. A slider is displayed. To hide the slider, select the transparency icon again.



(The title bar of the dialog box is always slightly transparent and is not affected by the slider.)



#### Particularities in Windows dialog boxes

In some cases, e.g. if you want to install a printer, original Windows dialog boxes are used. In these dialog boxes, the rotary knob and function keys do not work. Use the touchscreen instead.

## 7.4.1 Entering Numeric Parameters

If a field requires numeric input, the keypad provides only numbers.

- Enter the parameter value using the keypad, or change the currently used parameter value by using the rotary knob (small steps) or the [UP] or [DOWN] keys (large steps).
- 2. After entering the numeric value via keypad, press the corresponding unit key. The unit is added to the entry.
- If the parameter does not require a unit, confirm the entered value by pressing the [ENTER] key or any of the unit keys.
   The editing line is highlighted to confirm the entry.

# 7.4.2 Entering Alphanumeric Parameters

If a field requires alphanumeric input, you can use the on-screen keyboard to enter numbers and (special) characters (see Chapter 7.2.4, "On-screen Keyboard", on page 85).

Alternatively, you can use the keypad. Every alphanumeric key represents several characters and one number. The decimal point key (.) represents special characters, and the sign key (-) toggles between capital and small letters. For the assignment, refer to Table 7-6.

C

You can change the default behavior of the keypad for text input. This is useful if you frequently enter numeric values in text fields, for example to define file names consisting of numbers.

For details, see "Number block behavior" on page 303.

#### To enter numbers and (special) characters via the keypad

- 1. Press the key once to enter the first possible value.
- 2. All characters available via this key are displayed.
- To choose another value provided by this key, press the key again, until your desired value is displayed.
- 4. With every key stroke, the next possible value of this key is displayed. If all possible values have been displayed, the series starts with the first value again. For information on the series, refer to Table 7-6.
- 5. To change from capital to small letters and vice versa, press the sign key (-).
- 6. When you have chosen the desired value, wait for 2 seconds (to use the same key again), or start the next entry by pressing another key.

#### To enter a blank

Press the "Space" bar, or press the "0" key and wait 2 seconds.

#### To correct an entry

- 1. Using the arrow keys, move the cursor to the right of the entry you want to delete.
- 2. Press the [BACKSPACE] key.

The entry to the left of the cursor is deleted.

3. Enter your correction.

#### To complete the entry

Press the [ENTER] key or the rotary knob.

#### To abort the entry

Press the [ESC] key.
 The dialog box is closed without changing the settings.

Key name (upper inscription)	Series of (special) characters and number provided
7	7 μ Ω ° € ¥ \$ ¢
8	A B C 8 Ä ÆÅ Ç
9	D E F 9 É
4	GHI4
5	JKL5
6	ΜΝΟ6ŇÖ
1	PQRS1
2	TUV2Ü
3	W X Y Z 3
0	<blank> 0 - @ + / \ &lt; &gt; = % &amp;</blank>
	.*:_,;"'?()#
-	<toggles and="" between="" capital="" letters="" small=""></toggles>

#### Table 7-6: Keys for alphanumeric parameters

# 7.5 Displaying Results

The R&S FSWP provides several instrument applications for different analysis tasks and different types of signals, for example the Phase Noise application, the optional Spectrum application or the optional I/Q Analyzer. For each application, a new measurement channel is created and displayed in a separate tab on the screen.

The results of a measurement channel can be evaluated in many different ways, both graphically and numerically. For each evaluation method the results are displayed in a separate window in the tab.


The R&S FSWP allows you to configure the display to suit your specific requirements and optimize analysis.

# 7.5.1 Activating and Deactivating Channels

When you activate an application, a new measurement channel is created which determines the measurement settings for that application. The same application can be activated with different measurement settings by creating several channels for the same application. Whenever you switch channels, the corresponding measurement settings are restored. Each channel is displayed in a separate tab on the screen.

An additional tab ("MultiView") provides an overview of all currently active channels at once.

Only one measurement can be performed at any time, namely the one in the currently active channel. However, in order to perform the configured measurements consecutively, a Sequencer function is provided.



#### To start a new channel

- 1. Select the [Mode] key.
- In the "Mode" dialog box, select the required application on the "New Channel" tab. A new tab is displayed for the new channel.

#### Remote command:

INSTrument:CREate[:NEW] on page 389/ INSTrument:CREate:DUPLicate
on page 389

#### To change the application in an active channel

- 1. Select the tab of the channel you want to change.
- 2. Select the [Mode] key.
- In the "Mode" dialog box, select the new application to be displayed on the "Replace Current Channel" tab. The selected application is displayed in the current channel.

#### **Remote command:**

INSTrument: CREate: REPLace on page 390

#### To close a measurement channel



Select the "Close" icon on the tab of the measurement channel.

The tab is closed, any running measurements are aborted, and all results for that channel are deleted.

#### **Remote command:**

INSTrument: DELete on page 390

## 7.5.2 Laying out the Result Display with the SmartGrid

Measurement results can be evaluated in many different ways, for example graphically, as summary tables, statistical evaluations etc. Each type of evaluation is displayed in a separate window in the channel tab. Up to 16 individual windows can be displayed per channel (i.e. per tab). To arrange the diagrams and tables on the screen, the Rohde & Schwarz SmartGrid function helps you find the target position simply and quickly.

Principally, the layout of the windows on the screen is based on an underlying grid, the SmartGrid. However, the SmartGrid is dynamic and flexible, allowing for many different layout possibilities. The SmartGrid functionality provides the following basic features:

- Windows can be arranged in columns or in rows, or in a combination of both.
- Windows can be arranged in up to four rows and four columns.
- Windows are moved simply by dragging them to a new position on the screen, possibly changing the layout of the other windows, as well.
- All evaluation methods available for the currently selected measurement are displayed as icons in the evaluation bar. If the evaluation bar contains more icons than can be displayed at once on the screen, it can be scrolled vertically. The same evaluation method can be displayed in multiple windows simultaneously.
- New windows are added by dragging an evaluation icon from the evaluation bar to the screen. The position of each new window depends on where you drop the evaluation icon in relation to the existing windows.

 All display configuration actions are only possible in SmartGrid mode. When Smart-Grid mode is activated, the evaluation bar replaces the current softkey menu display. When the SmartGrid mode is deactivated again, the previous softkey menu display is restored.

•	Background Information: The SmartGrid Principle	.91
	How to Activate SmartGrid Mode	
•	How to Add a New Result Window	93
	How to Close a Result Window	
	How to Arrange the Result Windows	

## 7.5.2.1 Background Information: The SmartGrid Principle

#### SmartGrid display

During any positioning action, the underlying SmartGrid is displayed. Different colors and frames indicate the possible new positions. The position in the SmartGrid where you drop the window determines its position on the screen.



Figure 7-1: Moving a window in SmartGrid mode

The brown area indicates the possible "drop area" for the window, i.e. the area in which the window can be placed. A blue area indicates the (approximate) layout of the window as it would be if the icon were dropped at the current position. The frames indicate the possible destinations of the new window with respect to the existing windows: above/below, right/left or replacement (as illustrated in Figure 7-2). If an existing window would be replaced, the drop area is highlighted in a darker color shade.

#### Positioning the window

The screen can be divided into up to four rows. Each row can be split into up to four columns, where each row can have a different number of columns. However, rows always span the entire width of the screen and may not be interrupted by a column. A single row is available as the drop area for the window in the SmartGrid. The row can be split into columns, or a new row can be inserted above or below the existing row (if the maximum of 4 has not yet been reached).




Figure 7-2: SmartGrid window positions

- 1 = Insert row above or below the existing row
- 2 = Create a new column in the existing row
- 3 = Replace a window in the existing row

#### SmartGrid functions

Once the evaluation icon has been dropped, icons in each window provide delete and move functions.



The "Move" icon allows you to move the position of the window, possibly changing the size and position of the other displayed windows.

The "Delete" icon allows you to close the window, enlarging the display of the remaining windows.

#### 7.5.2.2 How to Activate SmartGrid Mode

All display configuration actions are only possible in SmartGrid mode. In SmartGrid mode the evaluation bar replaces the current softkey menu display. When the Smart-Grid mode is deactivated again, the previous softkey menu display is restored.

To activate SmartGrid mode, do one of the following:



Select the "SmartGrid" icon from the toolbar.

• Select the "Display Config" button in the configuration "Overview" .

• Select the "Display Config" softkey from the [Meas Config] menu.

The SmartGrid functions and the evaluation bar are displayed.



To close the SmartGrid mode and restore the previous softkey menu select the "Close" icon in the right-hand corner of the toolbar, or press any key.

#### 7.5.2.3 How to Add a New Result Window

Each type of evaluation is displayed in a separate window. Up to 16 individual windows can be displayed per channel (i.e. per tab).

1. Activate SmartGrid mode.

All evaluation methods available for the currently selected measurement are displayed as icons in the evaluation bar.

- Select the icon for the required evaluation method from the evaluation bar. If the evaluation bar contains more icons than can be displayed at once on the screen, it can be scrolled vertically. Touch the evaluation bar between the icons and move it up or down until the required icon appears.
- Drag the required icon from the evaluation bar to the SmartGrid, which is displayed in the diagram area, and drop it at the required position. (See Chapter 7.5.2.5, "How to Arrange the Result Windows", on page 94 for more information on positioning the window).

#### Remote command:

LAYout:ADD[:WINDow]? on page 501 / LAYout:WINDow<n>:ADD? on page 507

#### 7.5.2.4 How to Close a Result Window

To close a window, activate SmartGrid mode and select the "Delete" icon for the window.



#### Remote command:

LAYout:REMove[:WINDow] on page 504 / LAYout:WINDow<n>:REMove on page 508

## 7.5.2.5 How to Arrange the Result Windows

1. Select an icon from the evaluation bar or the "Move" icon for an existing evaluation window.



- Drag the evaluation over the SmartGrid.
   A blue area shows where the window will be placed.
- 3. Move the window until a suitable area is indicated in blue.
- 4. Drop the window in the target area.

The windows are rearranged to the selected layout, and "Delete" and "Move" icons are displayed in each window.

5. To close a window, select the corresponding "Delete" icon.



#### **Remote command:**


LAYout:REPLace[:WINDow] on page 505 / LAYout:WINDow<n>:REPLace on page 508

LAYout:MOVE[:WINDow] on page 504

# 7.5.3 Changing the Size of Windows

Each channel tab may contain several windows to evaluate the measurement results using different methods. A "splitter" allows you to change the size of neighboring windows.

#### **Displaying Results**



# Q

The splitters are not available in SmartGrid mode.

To change the size of two neighboring windows, drag the splitter between the windows in either direction.

## 7.5.4 Switching Between a Split and Maximized Window Display

To get an overview of the results, displaying several windows at the same time may be helpful. However, the individual windows may become rather small. In this case it is useful to maximize an individual window to the entire screen temporarily in order to analyze the results in more detail.



To switch between a split and a maximized display without having to close and re-open windows, press the [SPLIT/MAXIMIZE] key on the front panel. In maximized display, the currently focused window is maximized. In split display, all active windows are displayed.

Alternatively, double-tap the title bar of a window to maximize it.

## 7.5.5 Changing the Display

The display can be optimized for your individual needs. The following display functions are available and are described in detail in Chapter 13.2, "Display Settings", on page 281 and Chapter 11.1, "Result Display Configuration", on page 193.

- Displaying a simulation of the entire front panel of the instrument on the screen ("Front Panel")
- Displaying the main function hardkeys in a separate window on the screen ("Mini Front Panel")
- Hiding or showing various screen elements
- Selecting a display theme and colors
- Changing the display update rate
- Activating or deactivating the touch-sensitivity of the screen
- Zooming into the diagram

# 7.6 Remote Control

In addition to working with the R&S FSWP interactively, located directly at the instrument, it is also possible to operate and control it from a remote PC. Various methods for remote control are supported:

- Connecting the instrument to a (LAN) network (See the R&S FSWP user manual.)
- Using the Windows Remote Desktop application in a LAN network
- Connecting a PC via the GPIB interface

How to configure the remote control interfaces is described in the User Manual.

The R&S FSWP is delivered with *IECWIN* installed, the auxiliary remote control tool provided free of charge by Rohde & Schwarz.

For details on the IECWIN tool, see the "Network and Remote Control" chapter of the R&S FSWP User Manual.

## 7.6.1 Remote Desktop Connection

Remote Desktop is a Windows application which can be used to access and control the instrument from a remote computer through a LAN connection. While the instrument is in operation, the instrument screen contents are displayed on the remote computer. Remote Desktop provides access to all of the applications, files, and network resources of the instrument. Thus, remote operation of the instrument is possible.

The Remote Desktop Client is part of the installed Windows operating system. For other versions of Windows, Microsoft offers the Remote Desktop Client as an add-on.

## 7.6.2 Connecting a PC via the GPIB Interface

You can connect a PC to the R&S FSWP via the GPIB interface to send remote commands to control and operate the instrument. You can configure the GPIB address and the ID response string. The GPIB language is set as SCPI by default but can be changed to emulate other instruments.

A GPIB interface is integrated on the rear panel of the instrument.

# 8 Applications

The R&S FSWP is a dedicated Phase Noise Analyzer whose main feature is the phase noise measurement application.

When equipped accordingly (with optional hardware or software), it is able to provide several additional applications for different analysis tasks (for example the spectrum application).

When you activate an application, the R&S FSWP creates a new measurement channel which in turn determines the measurement settings for that application. You can use the same application with different measurement settings by creating several channels for the same application. Each channel is represented by a separate tab on the screen.

Note that the number of channels can be limited by the available memory of the R&S FSWP.

# 8.1 R&S MultiView

Each application is displayed in a separate tab. An additional tab ("MultiView") provides an overview of all currently active channels at a glance. In the "MultiView" tab, each individual window contains its own channel bar with an additional button. Select this button to switch to the corresponding channel display quickly.



#### **Remote command:**

DISPlay: FORMat on page 500

# 8.2 Available Applications

Depending on its outfit, the R&S FSWP provides one or more applications for specific measurement tasks.

Phase Noise	99
Spectrum Monitor	99
Spectrum	
Analog Modulation Analysis	
I/Q Analyzer	100
Noise Figure	100
Pulse Measurements	101
Spurious Measurements	101
Transient Analysis	101
Vector Signal Analysis (VSA)	

#### Phase Noise

The phase noise application provides measurement functions to measure the phase noise characteristics of a DUT.

This application is used in the initial configuration.

For details, refer to Chapter 9, "Measurements and Result Displays", on page 107.

Remote command: INST:SEL PNO, see INSTrument[:SELect] on page 392

#### **Spectrum Monitor**

The spectrum monitor application provides measurement functions for basic I/Q data analysis.

It runs on the phase noise analyzer hardware and is available for free with firmware version 1.60.

Compared to the full I/Q analyzer, which runs on the optional spectrum analyzer hardware, it has the following characteristics and limitations.

• When you open a spectrum monitor, the frequency, level and input parameters are initially adopted from the phase noise application (you can change them in the spectrum monitor, of course).

Those settings are the same as in the full I/Q analyzer.

- Maximum analysis bandwidth of 20 MHz and sample rate of 25 MHz (and no support of bandwidth extensions).
- Advanced data acquisition settings are unavailable.
- I/Q data import and export are the same as in the full I/Q analyzer.
- Spectrograms, general marker functionality, marker functions and limit lines are the same as in the full I/Q analyzer.
- Only external triggers are supported.
- Only evaluation of the frequency spectrum is supported.

Trace mathematics are not available.

All other functionality is the same as that of the I/Q analyzer.

For details, refer to the user manual of the I/Q analyzer.

Remote command:

INST:SEL SMONitor, see INSTrument[:SELect] on page 392

#### Spectrum

The spectrum application is an optional application that is available with R&S FSWP-B1.

In the spectrum application, the provided functions correspond to those of a conventional spectrum analyzer. The analyzer measures the frequency spectrum of the RF input signal over the selected frequency range with the selected resolution and sweep time, or, for a fixed frequency, displays the waveform of the video signal.

For details, refer to the user manual of the spectrum analyzer measurement application.

Remote command: INST:SEL SAN, see INSTrument[:SELect] on page 392

#### **Analog Modulation Analysis**

The analog modulation analysis application requires an instrument equipped with the spectrum analyzer hardware (R&S FSWP-B1) and the analog modulation analysis option (R&S FSWP-K7).

The analog modulation analysis application provides measurement functions for demodulating AM, FM, or PM signals.

For details, refer to the user manual of the analog modulation analysis application.

Remote command:

INST:SEL ADEM, see INSTrument[:SELect] on page 392

#### I/Q Analyzer

The I/Q analyzer application requires an instrument equipped with the spectrum analyzer hardware component (R&S FSWP-B1).

The I/Q analyzer application provides measurement and display functions for I/Q data.

For details, refer to the user manual of the I/Q analyzer.

Remote command: INST:SEL IQ, see INSTrument[:SELect] on page 392

#### **Noise Figure**

The noise figure application requires an instrument equipped with the spectrum analyzer hardware (R&S FSWP-B1) and the noise figure Measurements option (R&S FSWP-K30).

For details, refer to the user manual of the noise figure measurement application.

Remote command: INST:SEL NOISE, see INSTrument[:SELect] on page 392

#### **Pulse Measurements**

The pulse application requires an instrument equipped with the spectrum analyzer hardware (R&S FSWP-B1) and the pulse measurements option (R&S FSWP-K6(S)). This application provides measurement functions for pulsed signals.

For details, refer to the user manual of the pulse measurement application.

Remote command:

INST:SEL PULSE, see INSTrument[:SELect] on page 392

#### **Spurious Measurements**

The Spurious Measurements application requires an instrument equipped with the Spurious Measurements option, R&S FSWP-K50. This application provides measurements and evaluations for spurious signal effects.

For details, refer to the user manual of the spurious measurements application.

Remote command:

INST:SEL SPUR, see INSTrument[:SELect] on page 392

#### **Transient Analysis**

The Transient Analysis application requires an instrument equipped with the Transient Analysis option, R&S FSWP-K60. This application provides measurements and evaluations for Transient Analysis.

For details, refer to the user manual of the transient analysis measurement application.

Remote command: INST:SEL TA, see INSTrument[:SELect] on page 392

#### Vector Signal Analysis (VSA)

The VSA application requires an instrument equipped with the spectrum analyzer hardware (R&S FSWP-B1) and the vector signal analysis option (R&S FSWP-K70). This application provides measurement and evaluations for vector signal analysis.

For details, refer to the VSA user manual.

Remote command:


INST:SEL DDEM, see INSTrument[:SELect] on page 392

# 8.3 Starting an Application

The default application that is running when you start the R&S FSWP is the phase noise application.

#### Access to application selection

► [MODE]



To select an application, select the corresponding button.

Q

To deactivate a channel, simply close the corresponding tab.

The remote commands required to perform these tasks are described in Chapter 15.4, "Selecting the Operating Mode and Application", on page 389.



The measurement channels are labeled with their default name. If that name already exists, a sequential number is added.

MultiView 🍀 Phase Noise ! 🗮 💉 Phase Noise 2 ! 🗮 💉 Phase Noise 3 ! 🗮 💌

In remote control, the name of the measurement channel can be changed. For details and an overview of default names, see INSTrument:LIST?.

New Channel	102
Replace Current Channel	102
Duplicate Current Channel	102

#### **New Channel**

The applications selected on this tab are started in a new measurement channel, i.e. a new tab in the display.

Remote command:

INSTrument:CREate[:NEW] on page 389
INSTrument[:SELect] on page 392

#### **Replace Current Channel**

The applications selected on this tab are started in the currently displayed measurement channel, replacing the current application.

Remote command: INSTrument:CREate:REPLace on page 390

#### **Duplicate Current Channel**

The currently active channel can be duplicated, i.e. a new channel of the same type and with the identical measurement settings is started. The name of the new channel is the same as the copied channel, extended by a consecutive number (e.g. "Spectrum" - > "Spectrum 2").

Remote command:

INSTrument:CREate:DUPLicate on page 389

# 8.4 Running a Sequence of Measurements

Only one measurement can be performed at any time, namely the one in the currently active channel. However, in order to perform the configured measurements consecutively, a Sequencer function is provided.

- Sequencer Settings......105
- How to Set Up the Sequencer.....105

# 8.4.1 The Sequencer Concept

The instrument can only activate one specific channel at any time. Thus, only one measurement can be performed at any time, namely the one in the currently active channel. However, in order to perform the configured measurements consecutively, a Sequencer function is provided, which changes the channel of the instrument as required. If activated, the measurements configured in the currently defined "Channel" s are performed one after the other in the order of the tabs.

For each individual measurement, the sweep count is considered. Thus, each measurement may consist of several sweeps. The currently active measurement is indicated by a I symbol in the tab label.

The result displays of the individual channels are updated in the tabs as the measurements are performed. Sequential operation itself is independent of the currently *displayed* tab.

#### Sequencer modes

Three different Sequencer modes are available:

Single Sequence

Similar to single sweep mode; each measurement is performed once, until all measurements in all defined "Channel" s have been performed.

Continuous Sequence

Similar to continuous sweep mode; the measurements in each defined "Channel" are performed one after the other, repeatedly, in the same order, until sequential operation is stopped. This is the default Sequencer mode.


#### • Channel-defined Sequence

First, a single sequence is performed. Then, only "Channel" s in continuous sweep mode are repeated continuously.

#### Running a Sequence of Measurements

#### **Example: Sequencer procedure**

Assume the following active channel definition:



Tab name	Application	Sweep mode	Sweep count
Spectrum	Spectrum	Cont. Sweep	5
Spectrum 2	Spectrum	Single Sweep	6
Spectrum 3	Spectrum	Cont. Sweep	2
IQ Analyzer	IQ Analyzer	Single Sweep	7

For Single Sequence, the following sweeps will be performed:

5x Spectrum, 6x Spectrum 2, 2 x Spectrum 3, 7x IQ Analyzer

For **Continuous Sequence**, the following sweeps will be performed:

5x Spectrum, 6x Spectrum 2, 2 x Spectrum 3, 7x IQ Analyzer,

5x Spectrum, 6x Spectrum 2, 2 x Spectrum 3, 7x IQ Analyzer,

•••

For **Channel-defined Sequence**, the following sweeps will be performed:

5x Spectrum, 6x Spectrum 2, 2 x Spectrum 3, 7x IQ Analyzer,

5x Spectrum, 2 x Spectrum 3,

5x Spectrum, 2 x Spectrum 3,

...

### Run Single/Run Cont and Single Sweep/Sweep Continuous keys

While the Sequencer is active, the [Run Single] and [Run Cont] keys control the Sequencer, not individual sweeps. [Run Single] starts the Sequencer in single mode, while [Run Cont] starts the Sequencer in continuous mode.

The "Single Sweep" and "Continuous Sweep" *softkeys* control the sweep mode for the currently selected channel only; the sweep mode only has an effect the next time the Sequencer activates that channel, and only for a channel-defined sequence. In this case, a channel in single sweep mode is swept only once by the Sequencer. A channel in continuous sweep mode is swept repeatedly.

## 8.4.2 Sequencer Settings



The "Sequencer" menu is available from the toolbar.

Sequencer State	105
Sequencer Mode	105

#### **Sequencer State**

Activates or deactivates the Sequencer. If activated, sequential operation according to the selected Sequencer mode is started immediately.

Remote command:

SYSTem: SEQuencer on page 394 INITiate: SEQuencer: IMMediate on page 393 INITiate: SEQuencer: ABORt on page 393

#### **Sequencer Mode**

Defines how often which measurements are performed. The currently selected mode softkey is highlighted blue. During an active Sequencer process, the selected mode softkey is highlighted orange.

"Single Sequence"

Each measurement is performed once, until all measurements in all active channels have been performed.

"Continuous Sequence"

The measurements in each active channel are performed one after the other, repeatedly, in the same order, until sequential operation is stopped.

This is the default Sequencer mode.

"Channel Defined Sequence"

First, a single sequence is performed. Then, only channels in continuous sweep mode are repeated.

Remote command:

INITiate:SEQuencer:MODE on page 394

## 8.4.3 How to Set Up the Sequencer

In order to perform the configured measurements consecutively, a Sequencer function is provided.

- 1. Configure a channel for each measurement configuration as required, including the sweep mode.
- 2. In the toolbar, select the "Sequencer" icon.



The "Sequencer" menu is displayed.

3. Toggle the "Sequencer" softkey to "On" .

A continuous sequence is started immediately.

4. To change the Sequencer mode and start a new sequence immediately, select the corresponding mode softkey, or press the [Run Single] or [Run Cont] key.

The measurements configured in the currently active channels are performed one after the other in the order of the tabs until the Sequencer is stopped. The result displays in the individual channels are updated as the measurements are performed.

#### To stop the Sequencer

To stop the Sequencer temporarily, press the highlighted [Run Single] or [Run Cont] key (not for a channel-defined sequence). To continue the Sequencer, press the key again.

To stop the Sequencer permanently, select the "Sequencer" icon in the toolbar and toggle the "Sequencer" softkey to "Off".

# 9 Measurements and Result Displays

The noise performance of a DUT is usually described by various effects and signal characteristics that can be measured by the R&S FSWP.

The R&S FSWP provides several measurements, each of which analyzes different noise characteristics for different types of signal.

All measurements support several result displays, each of which shows different aspects of the noise characteristics of the measured signal.

•	Basics on Phase Noise Measurements	107
•	Performing Measurements	108
•	Selecting Measurements	110
•	Result Displays	112

# 9.1 Basics on Phase Noise Measurements

• Res	idual Effects	10	).	7
-------	---------------	----	----	---

# 9.1.1 Residual Effects

Residual noise effects are modulation products that originate directly from the phase noise. It is possible to deduct them mathematically from the phase noise of a DUT.

The application calculates three residual noise effects. All calculations are based on an integration of the phase noise over a particular offset frequency range.

#### **Residual PM**

The residual phase modulation is the contribution of the phase noise to the output of a PM demodulator. It is evaluated over the frequency range you have defined.

Residual PM = 
$$\sqrt{2 \cdot \int_{f_{start}}^{f_{starp}} L(f_m) df_m} [rad]$$

with L(f) = single sideband phase noise [dBc/Hz]

## **Residual FM**

The residual frequency modulation is the contribution of the phase noise to the output of an FM demodulator. It is evaluated over the frequency range you have defined.

Residual FM = 
$$\sqrt{2 \cdot \int_{f_{stop}}^{f_{stop}} f_m^2 L(f_m) df_m} [Hz]$$

with  $L(f_m)$  = single sideband phase noise [dBc/Hz]  $f_m$  = frequency [Hz]

#### **Jitter**

The jitter is the RMS temporal fluctuation of a carrier with the given phase noise evaluated over a given frequency range of interest.

Jitter[s] = 
$$\frac{\text{ResidualPM[rad]}}{2\pi \cdot f_0}$$
  
with  $f_0$  = Carrier frequency




Figure 9-1: Residual noise based on an integration between 10 kHz and 100 kHz offset

# 9.2 Performing Measurements

#### To start single measurements

- 1. Configure the measurement range you would like to measure ("Frequency" dialog box, see Chapter 10.4, "Frequency", on page 146).
- Configure the number of measurements you would like to perform in a single measurement ("Sweep Config" dialog box, see " Sweep/Average Count " on page 157).

- 3. Define how the results are evaluated for display ("Trace" dialog box, see Chapter 11.3, "Trace Configuration", on page 202).
- 4. To start the measurement, select one of the following:
  - [RUN SINGLE] key
  - "Single Sweep" softkey in the "Sweep" menu

The defined number of sweeps are performed, then the measurement is stopped. While the measurement is running, the [RUN SINGLE] key is highlighted. To abort the measurement, press the [RUN SINGLE] key again. The key is no longer highlighted. The results are not deleted until a new measurement is started.

5. To repeat the same number of measurements without deleting the last trace, select the "Continue Single Sweep" softkey in the "Sweep" menu.

#### To start continuous measurements

- If you want to average the trace or search for a maximum over more (or less) than 10 measurements, configure the "Average/Sweep Count" ("Sweep Config" dialog box, see " Sweep/Average Count " on page 157).
- 2. To start the measurement, select one of the following:
  - [RUN CONT] key
  - "Continuous Sweep" softkey in the "Sweep" menu

After each sweep is completed, a new one is started automatically. While the measurement is running, the [RUN CONT] key is highlighted. To stop the measurement, press the [RUN CONT] key again. The key is no longer highlighted. The results are not deleted until a new measurement is started.

Single Sweep / Run Single	109
Continuous Sweep / Run Cont	110
Continue Single Sweep	110

#### Single Sweep / Run Single

Initiates a single measurement. The measurement is finished after all frequencies in the frequency list have been measured. If necessary, the application automatically determines the reference level before starting the actual measurement.

While the measurement is running, the "Single Sweep" softkey and the [RUN SINGLE] key are highlighted. The running measurement can be aborted by selecting the high-lighted softkey or key again.

**Note:** Sequencer. If the Sequencer is active, the "Single Sweep" softkey only controls the sweep mode for the currently selected channel. However, the sweep mode only takes effect the next time the Sequencer activates that channel, and only for a channel-defined sequence. In this case, the Sequencer sweeps a channel in single sweep mode only once.

Furthermore, the [RUN SINGLE] key controls the Sequencer, not individual sweeps. [RUN SINGLE] starts the Sequencer in single mode.

If the Sequencer is off, only the evaluation for the currently displayed channel is updated. For details on the Sequencer, see Chapter 8.4.1, "The Sequencer Concept", on page 103.

Remote command:

INITiate<n>[:IMMediate] on page 402

#### Continuous Sweep / Run Cont

Initiates a measurement and repeats it continuously until stopped. If necessary, the application automatically determines the reference level before starting the actual measurement.

While the measurement is running, the "Continuous Sweep" softkey and the [RUN CONT] key are highlighted. The running measurement can be aborted by selecting the highlighted softkey or key again. The results are not deleted until a new measurement is started.

**Note:** Sequencer. If the Sequencer is active, the "Continuous Sweep" softkey only controls the sweep mode for the currently selected channel. However, the sweep mode only takes effect the next time the Sequencer activates that channel, and only for a channel-defined sequence. In this case, a channel in continuous sweep mode is swept repeatedly.

Furthermore, the [RUN CONT] key controls the Sequencer, not individual sweeps. [RUN CONT] starts the Sequencer in continuous mode.

For details on the Sequencer, see Chapter 8.4.1, "The Sequencer Concept", on page 103.

Remote command:

INITiate<n>:CONTinuous on page 401

#### **Continue Single Sweep**

Repeats the number of measurements defined by the "Sweep Count", without deleting the trace of the last measurement.

While the measurement is running, the "Continue Single Sweep" softkey and the [RUN SINGLE] key are highlighted. The running measurement can be aborted by selecting the highlighted softkey or key again.

Remote command: INITiate<n>:CONMeas on page 400

# 9.3 Selecting Measurements

#### Access: [MEAS]

The R&S FSWP provides several noise measurements, each determining different noise aspects of different types of signal.

Phase noise Measurement
Additive noise measurements (optional)
Baseband noise measurement
VCO characterization
Spot noise vs tune

Selecting Measurements

PN Transient analysis	112
Pulsed phase noise measurements (optional)	112
Pulsed additive noise measurements (optional)	112

#### Phase noise Measurement

Provides tools to measure the noise characteristics of a continuous wave signal.

This measurement measures the combined noise characteristics of the components in the test setup.

Remote command: CONFigure:PNOise:MEASurement on page 397

#### Additive noise measurements (optional)

Provides tools to measure the additive noise characteristics of a continuous wave signal.

The optional signal source that is necessary for this measurement allows you to measure the noise characteristics of individual components in the test setup.

Remote command:

CONFigure: PNOise: MEASurement on page 397

#### **Baseband noise measurement**

Provides tools to measure the noise characteristics of a DUT in absolute terms (not relative to a carrier).

The measurement is designed to check the voltage supply of DC sources or to determine the noise characteristics of amplifiers. Baseband measurements are possible between 0 Hz and 30 MHz (absolute).

Remote command: CONFigure:PNOise:MEASurement on page 397

#### VCO characterization

Provides tools to measure various characteristics of DUTs whose characteristics change depending on the applied voltage or current. Examples would be voltage controlled oscillators (VCOs) or YIG oscillators.

The measurement is designed to evaluate DUT characteristics as a function of the tuning voltage (also known as sweep voltage).

Remote command:

CONFigure:VCO:MEASurement[:STATe] on page 399

#### Spot noise vs tune

Provides tools to measure the spot noise characteristic of DUTs whose spot noise characteristic changes depending on the applied voltage or current. Examples would be voltage controlled oscillators (VCOs) or YIG oscillators.

The measurement is designed to evaluate DUT spot noise characteristic as a function of the tuning voltage (also known as sweep voltage).

Remote command:

CONFigure:SNTune:MEASurement[:STATe] on page 398

#### **PN Transient analysis**

Provides tools to analyze the transient response of a DUT.

The measurement is designed to monitor the frequency and phase variations of a signal over time and to find out how long it takes until the signal is in a stable state.

Remote command:

CONFigure: TRANsient: MEASurement [:STATe] on page 398

#### Pulsed phase noise measurements (optional)

Provides tools to measure the noise characteristics of pulses.

The optional pulsed phase noise measurement application measures the combined noise characteristics of the components in the test setup.

Remote command: CONFigure:PNOise:MEASurement on page 397

#### Pulsed additive noise measurements (optional)

Provides tools to measure the additive noise characteristics of pulses.

The optional pulsed phase noise measurement application in combination with the optional signal source allows you to measure the noise characteristics of individual components in the test setup.

Remote command: CONFigure: PNOise: MEASurement on page 397

# 9.4 Result Displays

Result displays show different aspects of the measurement results in numerical or graphical form.

Depending on the measurement, one or more result displays are supported.

Phase noise, additive noise, baseband noise, pulsed phase noise and pulsed additive noise measurements:

- "Noise Diagram" on page 113
- "Integrated Measurements" on page 114
- "Spurious List" on page 115
- "Spot Noise" on page 116
- "Marker Table " on page 121
- "Allan Variance / Allan Deviation" on page 117 (Phase noise measurement only.)

VCO characterization measurements:

- "Frequency (VCO Characterization)" on page 118
- "Sensitivity" on page 118
- "Power" on page 118
- "Current / Voltage" on page 119
- "Power vs. Frequency" on page 119

**Result Displays** 

- "Harmonic Power" on page 119
- "Marker Table " on page 121

Spot noise vs tune measurements:

- "Spot Noise vs Tune PN" on page 120
- "Spot Noise vs Tune AM" on page 120
- "Marker Table " on page 121

Transient analysis

- "Frequency (Transient Analysis)" on page 120
- "Frequency Deviation" on page 121
- "Phase" on page 121
- "Marker Table " on page 121

Noise Diagram	
Integrated Measurements	
Spurious List	115
Spot Noise	
Allan Variance / Allan Deviation	117
Frequency (VCO Characterization)	118
Sensitivity	
Power	118
Current / Voltage	119
Power vs. Frequency	
Harmonic Power	
Spot Noise vs Tune PN	
Spot Noise vs Tune AM	
Frequency (Transient Analysis)	
Frequency Deviation	
Phase	
Marker Table	

#### **Noise Diagram**

The "Noise Diagram" result display shows the power level of the noise over a variable frequency offset from the carrier frequency.

The unit of both axes in the diagram is fix. The x-axis always shows the offset frequencies in relation to the carrier frequency on a logarithmic scale in Hz. It always has a logarithmic scale to make sure of an equal representation of offsets near and far away from the carrier. The range of offsets that the x-axis shows is variable and depends on the measurement range you have defined and the scope of the x-axis that you have set.

The y-axis always shows the noise power level contained in a 1 Hz bandwidth in relation to the level of the carrier.

The unit of the y-axis depends on which version of the "Noise Spectrum" diagram you have selected.

 "Noise Spectrum": Default display showing the single sideband phase noise with linear y-axis in dBc/Hz.

- "Noise Spectrum L(f)": Same as the "Noise Spectrum" without AM noise calculation.
- "Noise Spectrum SΦ(f)": Display showing the spectral density of phase fluctuations with linear y-axis in dB/Hz.
- "Noise Spectrum Sv(f)": Display showing the spectral density of frequency fluctuations with logarithmic y-axis in Hz/sqrt(Hz).
- "Noise Spectrum Sy(f)": Display showing the spectral density of fractional frequency fluctuations with logarithmic y-axis in 1/sqrt(Hz). The R&S FSWP adjusts numerical results like integrated measurements and spot noise accordingly. AM noise calculation is only supported by the "Noise Spectrum" result display.

The scale of the y-axis is variable. Usually it is best to use the automatic scaling that the application provides, because it makes sure that the whole trace is always visible. You can, however, also customize the range, the minimum and the maximum values on the y-axis by changing the y-axis scale.

The measurement results are displayed as traces in the diagram area. Up to six active traces at any time are possible. Each of those can have a different setup and thus show different aspects of the measurement results.

In the default state, the application shows two traces. A yellow one and a blue one. Both result from the same measurement data, but have been evaluated differently. On the first trace, smoothing has been applied, the second one shows the raw data.

The diagram also contains a grey area in its default state. This trace represents the cross-correlation gain indicator.

#### Remote command:

TRACe<n>[:DATA]? on page 408
TRACe<n>[:DATA]:X? on page 411
TRACe<n>[:DATA]:X:POINts? on page 411
TRACe<n>[:DATA]:Y? on page 411
TRACe<n>[:DATA]:Y? ON page 411

#### **Integrated Measurements**

The "Integrated Measurements" result display summarizes the residual effects results in a table.

The table consists of up to four rows with each row representing a different integration interval. Each row basically contains the same information, which depends on the residual effects configuration.

Result	Description
Wnd	Shows the number of the measurement window the integration is done in (usually "1", unless you have several noise diagrams open at the same time).
Range	Shows the index of the integration range (1 to 4).
Тгасе	Shows the number of the trace the integration is applied to.
Start / Stop Offset	Shows the start and stop offset of the integration interval.

#### **Result Displays**

Result	Description
Weighting	Shows the name of the weighting filter, if you have applied one.
Int Noise	Shows the integrated noise.
	The integral is calculated over the frequency range defined by the "Start" and "Stop" values.
PM*	Shows the residual PM result in degrees and rad.
	(Only available for Phase Noise traces.)
FM / AM*	Shows the residual FM results in Hz or the residual AM results in %, depending on the trace configura- tion.
	(Only available for Phase Noise traces.)
Jitter*	Shows the jitter in seconds.
	(Only available for Phase Noise traces.)

\* For baseband noise measurements, these values are always 0.

#### Remote command:

```
Int. PHN: FETCh<n>[:RANGe<j>]:PNOise<t>:IPN? on page 405
FM: FETCh<n>[:RANGe<j>]:PNOise<t>:RFM? on page 406
AM: FETCh<n>[:RANGe<j>]:PNOise<t>:RAM? on page 405
PM: FETCh<n>[:RANGe<j>]:PNOise<t>:RPM? on page 407
Jitter: FETCh<n>[:RANGe<j>]:PNOise<t>:RMS? on page 406
```

#### **Spurious List**

Spurs are peak levels at one or more offset frequencies and are caused mostly by interfering signals. The "Spurious List" result display shows the location of all detected spurs in a table.

Note that only signals above a certain threshold are regarded as spurs. This threshold is also considered in the spurious list if spur removal has been turned off for a trace.

The order of the spurs in the table depends on the sort order.

The table consists of a variable number of rows. For each detected spur, the table shows several results.

Wnd	Shows the number of the measurement window the spur is in (usually "1", unless you have several noise diagrams open at the same time).
Тгасе	Shows the trace that the spur is on.
Spur	Shows the spur number. Spurs are sorted by their frequency, beginning with the spur with the lowest frequency.
Offset*	Shows the position (offset frequency) of the spur.
Power**	Shows the power level of the spur in dBc.

#### **Result Displays**

Jitter\*\*

Shows the jitter value of the spur in s.

In addition to the jitter for each spur, the result display also shows the discrete jitter and the random jitter at the end of the table.

- The discrete jitter is the RMS average of all individual spur jitter values.
- The random jitter is the jitter contribution of the phase noise without spurs.

\* For baseband noise measurements, the result is the absolute frequency that the spur is located at.

\*\* For baseband noise measurements, the unit is variable.

\*\*\* For baseband noise measurements, the jitter is always 0.

#### Remote command:

FETCh<n>: PNOise<t>: SPURs? on page 403
FETCh<n>: PNOise<t>: SPURs: COUNt? on page 403
FETCh<n>: PNOise<t>: SPURs: JITTer? on page 404
FETCh<n>: PNOise<t>: SPURs: DISCrete? on page 404
FETCh<n>: PNOise<t>: SPURs: RANDom? on page 404

#### **Spot Noise**

The "Spot Noise" result display shows the noise at a certain frequency offset (or spot) that is part of the measurement range. It is thus like a fixed marker.

The unit of spot noise results is dBc/Hz (variable unit for baseband noise measurements). The application shows the results in a table.

The table consists of a variable number of  $10_x$  frequencies (depending on the measurement range), and a maximum of six user frequencies, with each row containing the spot noise information for a particular frequency offset.

The spot noise information is made up out of several values.

Offset Frequency*	Shows the offset frequency the spot noise is evalu- ated for. You can add any offset that is part of the measurement range.
	The number in brackets (T <x>) indicates the trace the result refers to.</x>
Noise[T <x>]</x>	Shows the noise for the corresponding offset fre- quency.
	The number in brackets (T <x>) indicates the trace the result refers to.</x>

\* For baseband noise measurements, the result is the absolute frequency of the spot.

#### Remote command:

Querying spot noise results on 10<sub>x</sub> offset frequencies: CALCulate<n>:SNOise<s>[:TRACe<t>]:DECades:X? on page 467 CALCulate<n>:SNOise<s>[:TRACe<t>]:DECades:Y? on page 467 Querying custom spot noise results: CALCulate<n>:SNOise<s>[:TRACe<t>]:Y? on page 468

#### Allan Variance / Allan Deviation

The "Allan Variance" and "Allan Deviation" result displays are tools to determine the frequency stability of a DUT over a long period of time (days or even months).

Frequency stability is a measure of how well a DUT is able to produce its specified frequency over time without deviating from that frequency. Because of the noise characteristics of oscillators, standard variance or deviation are not really applicable. Instead the Allan variance and deviation are the tools of choice for these statistical evaluations. Like the standard deviation, the Allan variance and deviation show how much the frequency of the DUT deviates from its specified (= average) value. Also like the standard variance and deviation, the deviation is the square root of the variance.

The R&S FSWP calculates the Allan variance from the phase noise spectrum using the following relationship:

$$\sigma_y^2(\tau) = 2 \int_0^{f_h} S_y(f) \frac{\sin^4(\pi\tau f)}{(\pi\tau f)} df$$

f<sub>h</sub> = integration bandwidth


S<sub>v</sub> = spectral density of fractional frequency fluctuations

 $\tau$  = observation time

f = offset frequency

Overall, low values, both variance and deviation, correspond to a stable DUT, high values to an unstable DUT.

When you measure the stability of an oscillator, the resulting curve has a characteristic shape. The shape is the same for variance and deviation.



The point of interest in the diagram is the minimum of the curve. First, the deviation is high, because of noise. During the progression of the observation, the noise averages out until the minimum is reached. The minimum thus corresponds to the point in time when the deviation from the specified frequency is at its lowest. After that, the stability deteriorates due to temperature effects and aging.

From the slope of the curve, you can also identify the type of noise that is in effect (white noise, flicker phase, white frequency, flicker frequency, random walk).

For a comprehensive discussion of the Allan variance, refer to application note 1EF69: Time Domain Oscillator Stability Measurement - Allan Variance.

The logarithmic x-axis corresponds to the observation time ("Tau"). Note that Tau is not the measurement time, but the evaluated time - the measurement lasts longer than Tau. Because the R&S FSWP calculates the Allan variance based on the measurement range of the phase noise measurement (offset frequency), the observation time corresponds to the measurement range and vice versa.

The start time also defines the measurement bandwidth or integration bandwidth ( $f_h$  in the equation above):

$$BW_{Meas} = \frac{1}{\tau_{Start}}$$

The measurement bandwidth is displayed in the diagram area.

The y-axis shows the variance or deviation. It also has a logarithmic scale.

Remote command:

Trace data: TRACe<n>[:DATA]? on page 408

Measurement bandwidth: [SENSe:]BWIDth:MEASurement? on page 408

#### Frequency (VCO Characterization)

The "Frequency" result display shows the frequency characteristics of the DUT as a function of the tuning voltage or current.

The x-axis shows the tuning characteristics of the DC source.

- For V<sub>supply</sub> the tuning voltage in Volt or current in Ampere, depending on the output type.
- For V<sub>tune</sub> and V<sub>aux</sub> the tuning voltage in Volt.

The tuning voltages (alternatively: current) applied during the measurement depends on the tuning range you have defined.

The y-axis shows the frequency on which the VCO operates at a given tuning voltage or current in Hz.

Remote command: TRACe<n>[:DATA]? on page 408

#### Sensitivity

The "Sensitivity" result display shows the slope of the DUT characteristics, expressed as the frequency change between measurement points.

The x-axis shows the tuning characteristics of the DC source.

- For V<sub>supply</sub> the tuning voltage in Volt or current in Ampere, depending on the output type.
- For V<sub>tune</sub> and V<sub>aux</sub> the tuning voltage in Volt.

The tuning voltages (alternatively: current) applied during the measurement depends on the tuning range you have defined.

The y-axis shows the sensitivity of the VCO at a given tuning voltage or current in Hz/V.

Remote command: TRACe<n>[:DATA]? on page 408

#### Power

The "Power" result display shows the output power characteristics of the DUT as a function of the tuning voltage or current.

The x-axis shows the tuning characteristics of the DC source.

- For V<sub>supply</sub> the tuning voltage in Volt or current in Ampere, depending on the output type.
- For V<sub>tune</sub> and V<sub>aux</sub> the tuning voltage in Volt.

The tuning voltages (alternatively: current) applied during the measurement depends on the tuning range you have defined.

The y-axis shows the output power of the VCO at a given tuning voltage or current in Hz.

Remote command: TRACe<n>[:DATA]? on page 408

#### **Current / Voltage**

The "Current / Voltage" result display shows the voltage or current that the DUT is supplied with by the selected fix source and displays the result for each measurement point. Each measurement point corresponds to a specific tuning voltage (or current) that was applied to the DUT.

The x-axis shows the tuning characteristics of the DC source.

- For V<sub>supply</sub> the tuning voltage in Volt or current in Ampere, depending on the output type.
- For V<sub>tune</sub> and V<sub>aux</sub> the tuning voltage in Volt.

The tuning voltages (alternatively: current) applied during the measurement depends on the tuning range you have defined.

The y-axis shows the current or voltage of the selected fix DC source. When  $V_{Supply}$  is configured to supply current and selected as the "Fix Source", the diagram shows the voltage in Volt. In all other cases, it shows the current in mA.

Remote command:

TRACe<n>[:DATA]? on page 408

#### Power vs. Frequency

The "Power vs. Frequency" result display shows the frequency characteristics of the DUT as a function of the tuning voltage or current.

The x-axis shows the frequency on which the VCO operates at a given tuning voltage or current in Hz.

The y-axis shows the output power of the VCO at a given tuning voltage or current in Hz.

Remote command: TRACe<n>[:DATA]? on page 408

#### Harmonic Power

The "Harmonic Power" result display explicitly shows the power of the fundamental wave and the power of the harmonics of a DUT measured for each measurement point.

The x-axis shows the tuning characteristics of the DC source.

- For V<sub>supply</sub> the tuning voltage in Volt or current in Ampere, depending on the output type.
- For V<sub>tune</sub> and V<sub>aux</sub> the tuning voltage in Volt.

The tuning voltages (alternatively: current) applied during the measurement depends on the tuning range you have defined.

The y-axis shows the output power of the DUT at a given tuning voltage or current in dBm.

**Result Displays** 

Remote command:

TRACe<n>[:DATA]? on page 408

#### Spot Noise vs Tune PN

The "Spot Noise vs Tune PN" result display shows the phase noise at specific frequency offsets measured on each measurement point. Each measurement point corresponds to a specific tuning voltage (or current) that was applied to the DUT.

The x-axis shows the tuning characteristics of the DC source.

- For V<sub>supply</sub> the tuning voltage in Volt or current in Ampere, depending on the output type.
- For V<sub>tune</sub> and V<sub>aux</sub> the tuning voltage in Volt.

The tuning voltages (alternatively: current) applied during the measurement depends on the tuning range you have defined.

The y-axis shows the phase noise measured at a given tuning voltage or current in dBc/Hz.

You can configure the traces to show the phase noise for specific frequency offsets relative to the carrier.

Remote command:

TRACe < n > [:DATA]? on page 408

#### Spot Noise vs Tune AM

The "Spot Noise vs Tune AM" result display shows the AM noise at specific frequency offsets measured on each measurement point. Each measurement point corresponds to a specific tuning voltage (or current) that was applied to the DUT.

The x-axis shows the tuning characteristics of the DC source.

- For V<sub>supply</sub> the tuning voltage in Volt or current in Ampere, depending on the output type.
- For V<sub>tune</sub> and V<sub>aux</sub> the tuning voltage in Volt.

The tuning voltages (alternatively: current) applied during the measurement depends on the tuning range you have defined.

The y-axis shows the AM noise measured at a given tuning voltage or current in dBc/Hz.

You can configure the traces to show the AM noise for specific frequency offsets relative to the carrier.

Remote command: TRACe<n>[:DATA]? on page 408

#### Frequency (Transient Analysis)

The "Frequency" result display shows the frequency characteristics of the transient response of the DUT over time.

The x-axis shows the time period over which the signal has been measured. The scale depends on the measurement time.

The y-axis shows the frequency, either in absolute or relative terms. For a relative scale, the offset frequencies displayed on the y-axis refer to the center frequency. In both cases, the grid line in the middle of the diagram represents the center frequency.

Remote command:

Trace data: TRACe<n>[:DATA]? on page 408 Y-axis scale: Chapter 15.6.10.1, "Frequency Configuration", on page 484

#### **Frequency Deviation**

The "Frequency Deviation" result display shows the frequency deviation of the transient response of the DUT from an ideal linear behavior over time.

The x-axis shows the time period over which the signal has been measured. The scale depends on the defined start and stop time.

The y-axis shows the deviation of the signal from the reference line within the timeframe between start and stop time. The scale of the y-axis depends on your configuration.

The frequency deviation calculation settings are described in Chapter 10.10.7, "Frequency Deviation", on page 190.

Remote command: Trace data: TRACe<n>[:DATA]? on page 408

#### Phase

The "Phase" result display shows the phase characteristics of the transient response of the DUT over time.

The x-axis shows the time period over which the signal has been measured. The scale depends on the measurement time.

The y-axis shows the phase. The scale of the y-axis depends on your configuration.

Remote command:

Trace data: TRACe<n>[:DATA]? on page 408 Y-axis scale: Chapter 15.6.10.5, "Y-Axis Scale", on page 491

#### **Marker Table**

Displays a table with the current marker values for the active markers.

This table is displayed automatically if configured accordingly.

Туре	Shows the marker type and number ("M" for a nor- mal marker, "D" for a delta marker).
Ref	Shows the reference marker that a delta marker refers to.
Trace	Shows the trace that the marker is positioned on.
X- / Y-Value	Shows the marker coordinates (usually frequency and level).

3 Marker Table		
1 - M1		•
Trace	1	
X-value	1.42889 kHz 😑	=
Y-value	-81.43 dBc/Hz	
1 - D2		
Reference	M1	
Trace		
X-value	0.0 Hz	
Y-value	0.0 dB	•

**Tip**: To navigate within long marker tables, simply scroll through the entries with your finger on the touchscreen.

Remote command:

LAY:ADD? '1', RIGH, MTAB, see LAYout:ADD[:WINDow]? on page 501 Results:

CALCulate<n>:MARKer<m>:X on page 529

# 10 Common Measurement Settings

Basic measurement settings that are common to many measurement tasks, regardless of the application or operating mode, are described here. If you are using an application other than the Phase Noise application, be sure to check the documentation for that application. The settings can deviate from the common settings described here.


•	Configuration Overview	.123
	Input Source	
	Level Characteristics	
	Frequency	
	Noise Measurement Configuration	
	Output	
	Pulsed Phase Noise and Pulsed Additive Noise Configuration	
	VCO Characterization Configuration	
	Spot Noise vs Tune Configuration	
	PN Transient Analysis Configuration	
	, , , , , , , , , , , , , , , , , , , ,	

# **10.1 Configuration Overview**

Overview

Access: "Overview"

Throughout the measurement channel configuration, an overview of the most important currently defined settings is provided in the "Overview". The "Overview" is displayed when you select the "Overview" icon, which is available at the bottom of all softkey menus.



In addition to the main measurement settings, the "Overview" provides quick access to the main settings dialog boxes. The individual configuration steps are displayed in the order of the data flow. Thus, you can easily configure an entire measurement channel from input over processing to output and analysis by stepping through the dialog boxes as indicated in the "Overview".

In particular, the "Overview" provides quick access to the following configuration dialog boxes (listed in the recommended order of processing):

- **Configuration Overview**
- 1. Input See Chapter 10.2, "Input Source", on page 125.
- Amplitude / Scaling See Chapter 10.3, "Level Characteristics", on page 142.
- 3. Frequency See Chapter 10.4, "Frequency", on page 146.
- 4. Noise See Chapter 10.5, "Noise Measurement Configuration", on page 151.
- 5. Output See Chapter 10.6, "Output", on page 165.
- Analysis See Chapter 11, "Common Analysis and Display Functions", on page 193.
- 7. Display Configuration

See Chapter 9, "Measurements and Result Displays", on page 107.

In addition, the dialog box provides the "Select Measurement" button that serves as a shortcut to select the measurement type.

Selecting the noise measurement type	
Preset Channel	125
Specific Settings for	

#### Selecting the noise measurement type

The R&S FSWP provides different types of measurements to measure the noise characteristics of a DUT.

- Phase Noise Phase noise and AM noise measurements for continuous wave signals.
- Additive Noise Phase noise and AM noise measurements for continuous wave signals including a signal source.

Available with the optional Signal Source hardware.

Baseband Noise Noise measurement in absolute terms over a selected frequency range.
VCO Characterization

Measurements to determine the characteristics of a voltage controlled oscillator (VCO).

- Spot Noise vs Tune Phase noise and AM noise measurements for a voltage controlled oscillator (VCO).
- Pulsed Phase Noise
   Phase noise and AM noise measurements for pulse signals.
   Available with the optional Pulsed Phase Noise measurement application.
- Pulsed Additive Noise
   Phase noise and AM noise measurements for pulse signals including a signal source.

Available with the optional Pulsed Phase Noise measurement application.

Remote command: CONFigure: PNOise: MEASurement on page 397

#### **Preset Channel**

Select the "Preset Channel" button in the lower left-hand corner of the "Overview" to restore all measurement settings **in the current channel** to their default values.

Do not confuse the "Preset Channel" button with the [Preset] *key*, which restores the entire instrument to its default values and thus closes **all channels** on the R&S FSWP (except for the default channel)!

See "Preset Mode " on page 302

Remote command: SYSTem:PRESet:CHANnel[:EXEC] on page 564

#### **Specific Settings for**

The channel may contain several windows for different results. Thus, the settings indicated in the "Overview" and configured in the dialog boxes vary depending on the selected window.

Select an active window from the "Specific Settings for" selection list that is displayed in the "Overview" and in all window-specific configuration dialog boxes.

The "Overview" and dialog boxes are updated to indicate the settings for the selected window.

# **10.2 Input Source**

The phase noise application supports input from several signal sources.

For more information about the available connectors, refer to the getting started manual.

•	RF Input	125
	Baseband Input	

### 10.2.1 RF Input

Access (RF input settings): "Overview" > "Input" > "Input Source" > "Radio Frequency" > "Config"

Access (schematic test setups): "Overview" > "Input" > "Input Source" > "Radio Frequency" > "Test Setup"

The RF Input is the default input source.

A typical test setup for measurements over the RF input depends on the selected measurement and the equipment used in the test setup. A schematic representation of such a setup is provided in the dialog box.

The DUT directly sends a signal to the RF input of the R&S FSWP.

• If necessary, the R&S FSWP can supply the DUT with power over the DC ports.



For more information about configuring the DC ports used in the setup, see Chapter 10.6.1, "DC Source Configuration", on page 165.

The remote commands required to configure the frequency are described in Chapter 15.6.1.1, "RF Input", on page 413.

Radio Frequency State	26
Input Coupling	26
Local Oscillator	

#### **Radio Frequency State**

Activates input from the "RF Input" connector.

Remote command:

INPut<ip>:SELect on page 414

#### Input Coupling

The RF input of the R&S FSWP can be coupled by alternating current (AC) or direct current (DC).

AC coupling blocks any DC voltage from the input signal. This is the default setting to prevent damage to the instrument. Very low frequencies in the input signal may be distorted.

However, some specifications require DC coupling. In this case, you must protect the instrument from damaging DC input voltages manually. For details, refer to the data sheet.


Remote command: INPut<ip>:COUPling on page 413

#### Local Oscillator

Selects the type of the local oscillator you are using for the measurement.

- Internal Uses the local oscillator of the R&S FSWP.
- External

Uses an external local oscillator, connected to the "LO AUX Input" (Ch1 and Ch2) of the R&S FSWP.



For an external LO, specify whether the signal at the input has a low or high "Level". A low level corresponds to signals with a level of approximately 0 dBm. A

high level corresponds to signals with a level between about +5 dBm and +10 dBm.

The exact definitions of low and high depend on the signal frequency and are specified in the data sheet.

Note that for low phase noise boards with material number 1331.6439.xx, the low / high setting is not available.

You can check the material number of the low phase noise board in the hardware information dialog box (column "order #, see Chapter 13.4.1, "Hardware Information", on page 296).

Available for additive noise measurements.

Remote command:

INPut<1|2>:LOSCillator:SOURce on page 414
INPut<1|2>:LOSCillator:SOURce:EXTernal:LEVel on page 414

#### 10.2.2 Baseband Input

Access (baseband input settings): "Overview" > "Input" > "Input Source" > "Baseband" > "Config"

Access (schematic test setups): "Overview" > "Input" > "Input Source" > "Baseband" > "Test Setup"

#### **Baseband measurements**

In addition to the RF input, baseband noise measurements also support measurements on the two channels of the baseband input.

You can either perform measurements on a single channel (select either "CH1" or "CH1" for that) or perform measurements on both channels simultaneously ("CH1 x CH2"). In the latter case, the I/Q data is cross-correlated before the results are displayed, which allows you to determine the noise characteristics of your DUT very accurately.

Remote command:

Input selection: INPut<ip>:SELect on page 414

Channel selection: INPut<1 | 2>: CONNector on page 415

The baseband input is always DC coupled, which allows you to measure the noise characteristics of a DUT near 0 Hz (DC) in the context of baseband noise measurements.

Note that you have to turn on the baseband input deliberately before you can use it. When the baseband input is active, the RF input is automatically turned off.

A typical test setup for measurements over the RF input depends on the selected measurement and the equipment used in the test setup. A schematic representation of such a setup is provided in the dialog box.

Input Source	Output
Radio Frequency	On Off
Baseband	Config Test Setup
Baseballu	Input CH1 CH2 CH1xCH2

See Chapter 6.2.4, "The Baseband Noise Measurement", on page 58 for more information on how to set up and perform baseband noise measurements.

#### Additive noise measurements (CW and pulsed)

If you are using an I/Q mixer in the test setup of an additive noise measurement, you can use the baseband inputs to analyze I and Q data streams.

Note that you have to turn on the baseband input deliberately before you can use it. When the baseband input is active, the RF input is automatically turned off.

Remote command:

Input selection: INPut<ip>:SELect on page 414

See Chapter 6.2.3, "The Additive Noise Measurement", on page 56 for more information on how to set up and perform additive noise measurements using the baseband input.

#### 10.2.3 External Mixers

Access (mixer settings): "Overview" > "Input" > "Input Source" > "External Mixer" > "Mixer Settings"

Access (basic settings): "Overview" > "Input" > "Input Source" > "External Mixer" > "Basic Settings"

Access (conversion loss table): "Overview" > "Input" > "Input Source" > "External Mixer" > "Conversion Loss Table"

Access (schematic test setups): "Overview" > "Input" > "Input Source" > "External Mixer" > "Test Setup"

The optional support for external mixers allows you to connect up to two external threeport mixers to the R&S FSWP. An external mixer allows you to perform measurements on frequencies that are out of the frequency range supported by the R&S FSWP.

# Ç

#### Note on using three-port mixers

When using three-port mixers, the LO signal output from the R&S FSWP and the IF input from the mixer are transmitted on separate connectors. The nominal LO level is 15.5 dBm.

External mixers are supported by several measurements in the phase noise application.

Phase noise measurement

Pulsed phase noise measurement

You can connect up to two external mixers and configure them individually (where necessary).

A typical test setup for measurements over the RF input depends on the selected measurement and the equipment used in the test setup. A schematic representation of such a setup is provided in the dialog box.

•	Basics on External Mixers	.129
•	Mixer Settings	133
-	Pagia Cattinga	126

#### 10.2.3.1 Basics on External Mixers

Some background knowledge on basic terms and principles used with external mixers is provided here for a better understanding of the required configuration settings.

•	Frequency Ranges	129
•	Bias Current	130
•	Conversion Loss Tables	131

#### **Frequency Ranges**

In a common spectrum analyzer, rather than providing one large (and thus inaccurate) filter, or providing several filters to cover the required frequency range of the input signal (at a high cost), a single, very accurate filter is used. Therefore, the input signal must be converted to the frequencies covered by the single accurate filter. This is done by a mixer, which converts and multiplies the frequency of the input signal with the help of the local oscillator (LO). The result is a higher and lower intermediate frequency (IF). The local oscillator can be tuned within the supported frequency range of the input signal.

In order to extend the supported frequency range of the input signal, an external mixer can be used. In this case, the LO frequency is output to the external mixer, where it is mixed with the RF input from the original input signal. In addition, the *harmonics* of the LO are mixed with the input signal, and converted to new intermediate frequencies. Thus, a wider range of frequencies can be obtained. The IF from the external mixer is then returned to the spectrum analyzer.

The frequency of the input signal can be expressed as a function of the LO frequency and the selected harmonic of the first LO as follows:

 $f_{in} = n * f_{LO} + f_{IF}$ 

Where:

**f**<sub>in</sub>: Frequency of input signal

n: Order of harmonic used for conversion

fLO: Frequency of first LO: 7.65 GHz to 16.00 GHz

 $\mathbf{f}_{\mathsf{IF}}$ : Intermediate frequency (variable; defined internally depending on RBW and span)

Thus, depending on the required frequency band, the appropriate order of harmonic must be selected. For commonly required frequency ranges, predefined bands with the appropriate harmonic order setting are provided. By default, the lowest harmonic order is selected that allows conversion of input signals in the whole band.

For the band "USER", the order of harmonic is defined by the user. The order of harmonic can be between 2 and 61, the lowest usable frequency being 16.88 GHz.

The frequency ranges for pre-defined bands are described in Table 15-3.



Changes to the band and mixer settings are maintained even after using the [PRESET] function. A "Preset band" function allows you to restore the original band settings.

#### Extending predefined ranges

In some cases, the harmonics defined for a specific band allow for an even larger frequency range than the band requires. By default, the pre-defined range is used. However, you can take advantage of the extended frequency range by overriding the defined start and stop frequencies by the maximum possible values ("RF Overrange" option).

#### Additional ranges

If due to the LO frequency the conversion of the input signal is not possible using one harmonic, the band must be split. An adjacent, partially overlapping frequency range can be defined using different harmonics. In this case, the sweep begins using the harmonic defined for the first range, and at a specified frequency in the overlapping range ("handover frequency"), switches to the harmonic for the second range.

#### **Bias Current**

Single-diode mixers generally require a DC voltage which is applied via the LO line. This DC voltage is to be tuned to the minimum conversion loss versus frequency. Such a DC voltage can be set via the "BIAS" function using the D/A converter of the R&S FSWP. The value to be entered is not the voltage but the short-circuit current. The current is defined in the "Bias Settings" or set to the value of the conversion loss table.

See "Bias Value " on page 137 and " Bias " on page 140.




Figure 10-1: Bias circuit of the R&S FSWP

The voltage  $U_0$  at the output of the operational amplifier can be set in the range –2.0 to +2.0 V. An open-circuit voltage  $U_{bias}$  of –0.5 to +0.5 V is obtained accordingly at the output of the voltage divider. A short-circuit current of  $I_{short} = U_0 / 200 \Omega = 10$  mA to + 10 mA is obtained for a short circuit at the output of the voltage divider. In order to use biasing it is not important to know the exact current flowing through the diode since the conversion loss must be set to a minimum with the frequency. Therefore, it makes no difference whether the setting is performed by an open-circuit voltage or by a short-circuit current. A DC return path is ensured via the 66  $\Omega$  resistor, which is an advantage in some mixers.

#### **Conversion Loss Tables**

Conversion loss tables consist of value pairs that describe the correction values for conversion loss at certain frequencies. Correction values for frequencies between the reference values are obtained by interpolation. Linear interpolation is performed if the table contains only two values. If it contains more than two reference values, spline interpolation is carried out. Outside the frequency range covered by the table the conversion loss is assumed to be the same as that for the first and last reference value (see Figure 10-2).

#### Input Source




Figure 10-2: Conversion loss outside the band's frequency range

Predefined conversion loss tables are often provided with the external mixer and can be imported to the R&S FSWP.

Alternatively, you can define your own conversion loss tables. Conversion loss tables are configured and managed in the "Conversion loss Table Settings" tab of the "External Mixer Configuration" dialog box.

See "Managing Conversion Loss Tables" on page 138 for more information about conversion loss tables.

#### Importing CVL tables

The conversion loss table to be used for a particular measurement range is also defined in the "External Mixer Configuration" dialog box.

The frequency range that the cvl table must cover depends on the used IF, which varies depending on the instrument and installed bandwidth extension options. Thus, external mixers from Rohde & Schwarz provide multiple conversion loss table files. When you select a storage path containing cvl files, or a particular cvl file from a Rohde & Schwarz mixer for import, all available files are copied to the C:\R\_S\INSTR\USER\cvl\ directory on the R&S FSWP. Provided .acl files are renamed according to the following syntax:

<serial\_number>\_<harmonic\_order>\_<IF>.acl,

#### e.g. 12345\_2\_1330M.acl

To select a conversion loss table for use in a measurement, you merely have to select the serial number for the external mixer in use. The R&S FSWP automatically selects the correct cvl file for the current IF. As an alternative, you can also select a user-defined conversion loss table (.acl file).



Before copying any files to the C:\R\_S\INSTR\USER\cvl\ directory, the R&S FSWP firmware moves any existing user-defined cvl tables to a backup subdirectory. To use a user-defined cvl table later, select the file in the C:\R\_S\INSTR\USER\cvl\backup directory.

A validation check is then performed on the selected table to ensure that it complies with the settings. In particular, the following is checked:

- The assigned band name
- The harmonic order
- The mixer type
- The table must contain at least one frequency that lies within the frequency range for the band

#### **Reference level**

The maximum possible reference level depends on the maximum used conversion loss value. Thus, the reference level can be adjusted for each range according to the used conversion loss table or average conversion loss value. If a conversion loss value is used which exceeds the maximum reference level, the reference level is adjusted to the maximum value permitted by the firmware.

#### 10.2.3.2 Mixer Settings

Access: "Overview" > "Input" > "Input Source" > "External Mixer" > "Mixer Settings"

With the R&S FSWP, you can control either one or two three-port mixers.

Most settings are applied globally for both mixers (like the frequency band settings). Settings that you can configure for each mixer separately are labeled accordingly in the description below.



External Mixer (State)	134
RF Start / RF Stop	134
Handover Freq	
Band	134

#### Input Source

F Overrange	35
reset Band	35
lixer XCORR	35
ange 1 / Range 21	35
armonic Type1	
armonic Order1	
onversion Loss	

#### External Mixer (State)

Activates or deactivates the external mixer for input. If activated, "ExtMix" is indicated in the channel bar of the application, together with the used band (see " Band " on page 134).

Remote command:

[SENSe:]MIXer<x>[:STATe] on page 423

#### RF Start / RF Stop

Displays the start and stop frequency of the selected band (read-only).

The frequency range for the user-defined band is defined via the harmonics configuration (see " Range 1 / Range 2 " on page 135).

For details on available frequency ranges, see table 15-3 on page 417.

Remote command:

[SENSe:]MIXer<x>:FREQuency:STARt on page 416
[SENSe:]MIXer<x>:FREQuency:STOP on page 417

#### Handover Freq

If due to the LO frequency the conversion of the input signal is not possible using one harmonic, the band must be split. An adjacent, partially overlapping frequency range can be defined using different harmonics. In this case, the sweep begins using the harmonic defined for the first range. At the specified "handover frequency" in the overlapping range, it switches to the harmonic for the second range.

The handover frequency can be selected freely within the overlapping frequency range.

Remote command:

[SENSe:]MIXer<x>:FREQuency:HANDover on page 416

#### Band

Defines the waveguide frequency band or user-defined frequency band to be used by the mixer.

The start and stop frequencies of the selected band are displayed in the "RF Start" and "RF Stop" fields.

For a definition of the frequency range for the pre-defined bands, see table 15-3 on page 417.

The mixer settings for the user-defined band can be selected freely. The frequency range for the user-defined band is defined via the harmonics configuration (see " Range 1 / Range 2 " on page 135).

Remote command: [SENSe:]MIXer<x>:HARMonic:BAND on page 417

#### **RF Overrange**

In some cases, the harmonics defined for a specific band allow for an even larger frequency range than the band requires. By default, the pre-defined range is used. However, you can take advantage of the extended frequency range by overriding the defined "RF Start" and "RF Stop" frequencies by the maximum values.

If "RF Overrange" is enabled, the frequency range is not restricted by the band limits ( "RF Start" and "RF Stop" ). In this case, the full frequency range that can be reached using the selected harmonics is used.

Remote command:

[SENSe:]MIXer<x>:RFOVerrange[:STATe] on page 421

#### **Preset Band**

Restores the presettings for the selected band.

**Note:** changes to the band and mixer settings are maintained even after using the [PRESET] function. This function allows you to restore the original band settings.

Remote command: [SENSe:]MIXer<x>:HARMonic:BAND:PRESet on page 418

#### Mixer XCORR

Turns the simultaneous use of two external mixers on and off.

Using two external mixers allows you to perform measurements with external crosscorrelation. Through cross-correlation operations, the noise of the DUT is kept constant while the noise of the signal path (including the external mixers) is reduced.

Remote command:

[SENSe:]MIXer<x>:XCORr on page 421

#### Range 1 / Range 2

Enables the use of one or two frequency ranges, where the second range is based on another harmonic frequency of the mixer to cover the band's frequency range.

For each range, you can define which harmonic to use and how the conversion loss is handled.

If you are using two mixers, this property is always the same for both mixers.

Remote command:

[SENSe:]MIXer<x>:HARMonic:HIGH:STATe on page 418

#### Harmonic Type

Defines if only even, only odd, or even and odd harmonics can be used for conversion. Depending on this selection, the order of harmonic to be used for conversion changes (see " Harmonic Order " on page 136). Which harmonics are supported depends on the mixer type.

If you are using two mixers, the harmonic type is always the same for both mixers.

Remote command:

[SENSe:]MIXer<x>:HARMonic:TYPE on page 419

#### Harmonic Order

Defines which order of the harmonic of the LO frequencies is used to cover the frequency range.

By default, the lowest order of the specified harmonic type is selected that allows conversion of input signals in the whole band. If due to the LO frequency the conversion is not possible using one harmonic, the band is split.

For the "USER" band, you define the order of harmonic yourself. The order of harmonic can be between 2 and 61, the lowest usable frequency being 16.88 GHz.

If you are using two mixers, the harmonic type is always the same for both mixers..

Remote command:

```
[SENSe:]MIXer<x>:HARMonic[:LOW] on page 419
[SENSe:]MIXer<x>:HARMonic:HIGH[:VALue] on page 418
```

#### **Conversion Loss**

Defines how the conversion loss is handled. The following methods are available:

If you are using two mixers, you can define the source of the conversion loss data for each mixer separately.

- "Average" Defines the average conversion loss for the entire frequency range in dB.
- "Table" Defines the conversion loss via the table selected from the list. Predefined conversion loss tables are often provided with the external mixer and can be imported to the R&S FSWP. Alternatively, you can define your own conversion loss tables. Imported tables are checked for compatibility with the current settings before being assigned. Conversion loss tables are configured and managed in the Conversion Loss Table tab.

For details on importing tables, see " Import Table " on page 139.

Remote command:

Average for range 1: [SENSe:]MIXer<x>:LOSS[:LOW] on page 420 Table for range 1: [SENSe:]MIXer<x>:LOSS:TABLe[:LOW] on page 420 Average for range 2: [SENSe:]MIXer<x>:LOSS:HIGH on page 419 Table for range 2: [SENSe:]MIXer<x>:LOSS:TABLe:HIGH on page 420

#### 10.2.3.3 Basic Settings

Access: "Overview" > "Input" > "Input Source" > "External Mixer" > "Basic Settings"

With the R&S FSWP, you can control either one or two three-port mixers.

Most settings are applied globally for both mixers (like the frequency band settings). Settings that you can configure for each mixer separately are labeled accordingly in the description below.

Input Source



LO Level	,
Bias Value	,
L Write to CVL table	

#### LO Level

Defines the LO level of the external mixer's LO port. Possible values are from 13.0 dBm to 17.0 dBm in 0.1 dB steps. Default value is 15.5 dB.

If you are using two mixers, you can define the LO level for each mixer separately.

#### Remote command:

[SENSe:]MIXer<x>:LOPower on page 423

#### **Bias Value**

Define the bias current for each range, which is required to set the mixer to its optimum operating point. It corresponds to the short-circuit current. The bias current can range from -10 mA to 10 mA. The actual bias current is lower because of the forward voltage of the mixer diode(s).

**Tip**: The trace in the currently active result display (if applicable) is adapted to the settings immediately so you can check the results.

To store the bias setting in the currently selected conversion loss table, select the Write to CVL table button.

The "Bias Value" is available for mixer 1 only.

Remote command:

[SENSe:]MIXer<x>:BIAS[:LOW] on page 422
[SENSe:]MIXer<x>:BIAS:HIGH on page 422

#### Write to CVL table ← Bias Value

Stores the bias setting in the currently selected "Conversion Loss Table" for the range (see "Managing Conversion Loss Tables" on page 138). If no conversion loss table is selected yet, this function is not available ( "CVL Table not selected" ).

Remote command:

[SENSe:]CORRection:CVL:BIAS on page 424

#### 10.2.3.4 Conversion Loss Table

#### **Managing Conversion Loss Tables**

Access: "Overview" > "Input" > "Input Source" > "External Mixer" > "Conversion Loss Table"

Conversion loss tables consist of value pairs that describe the correction values for conversion loss at certain frequencies. The correction values for frequencies between the reference points are obtained via interpolation.

The currently selected table for each range is displayed at the top of the dialog box. All conversion loss tables found in the instrument's  $C:\R_S\INSTR\USER\cvl\ directory$  are listed in the "Modify Tables" list.

Input Source	Output			
Radio Frequency	On	Off		
External	Mixer Settings	Basic Settings	Conversion Loss Table	Test Setup
Mixer	Modify Tables			
Baseband				New Table
				Edit Table
				Delete Tablé
				Import Table
U				

New Table	138
Edit Table	138
Delete Table	
Import Table	139

#### **New Table**

Opens the "Edit conversion loss table" dialog box to configure a new conversion loss table.

For details on table configuration, see "Editing Conversion Loss Tables" on page 139.

Remote command:

[SENSe:]CORRection:CVL:SELect on page 427

#### Edit Table

Opens the "Edit conversion loss table" dialog box to edit the selected conversion loss table.

For details on table configuration, see "Editing Conversion Loss Tables" on page 139.

Remote command:

[SENSe:]CORRection:CVL:SELect on page 427

#### Delete Table

Deletes the currently selected conversion loss table after you confirm the action.

Remote command:

[SENSe:]CORRection:CVL:CLEar on page 425

#### **Import Table**

Imports one or more stored conversion loss tables from any directory and copies them to the instrument's  $C:\R_S\INSTR\USER\cvl\ directory$ . They can then be assigned for use for a specific frequency range (see " Conversion Loss " on page 136).

#### Note:

Before copying any files to the C:\R\_S\INSTR\USER\cv1\ directory, the R&S FSWP firmware moves any existing user-defined cvl tables to a backup subdirectory. To use a user-defined cvl table later, select the file in the C:\R\_S\INSTR\USER\cv1\backup directory.

#### Remote command:


MMEM:COPY '<conversionlosstable>',C:\R S\INSTR\USER\cvl\

#### **Editing Conversion Loss Tables**

Access: "Overview" > "Input" > "Input Source" > "External Mixer" > "Conversion Loss Table" > "New Table" / "Edit Table"

Conversion loss tables can be newly defined and edited.

A preview pane displays the current configuration of the conversion loss function as described by the position/value entries.



File Name	140
Comment	140
Band	140
Harmonic Order	140
Bias	140
Mixer Name	141
Mixer S/N	
Mixer Type	141
Position / Value	

Insert Value	141
Delete Value	. 141
Shift x	142
Shift y	142
Save	

#### **File Name**

Defines the name under which the table is stored in the C:\R\_S\INSTR\USER\cvl\ directory on the instrument. The name of the table is identical with the name of the file (without extension) in which the table is stored. This setting is mandatory. The .ACL extension is automatically appended during storage.

Remote command: [SENSe:]CORRection:CVL:SELect on page 427

#### Comment

An optional comment that describes the conversion loss table. The comment is userdefinable.

Remote command: [SENSe:]CORRection:CVL:COMMent on page 425

#### Band

The waveguide or user-defined band to which the table applies. This setting is checked against the current mixer setting before the table can be assigned to the range.

For a definition of the frequency range for the pre-defined bands, see table 15-3 on page 417.

Remote command: [SENSe:]CORRection:CVL:BAND on page 424

#### Harmonic Order

The harmonic order of the range to which the table applies. This setting is checked against the current mixer setting before the table can be assigned to the range.

Remote command: [SENSe:]CORRection:CVL:HARMonic on page 426

#### Bias

The bias current which is required to set the mixer to its optimum operating point. It corresponds to the short-circuit current. The bias current can range from -10 mA to 10 mA. The actual bias current is lower because of the forward voltage of the mixer diode(s).

**Tip:** You can also define the bias interactively while a preview of the trace with the changed setting is displayed, see " Bias Value " on page 137.

Remote command:

[SENSe:]CORRection:CVL:BIAS on page 424

#### **Mixer Name**

Specifies the name of the external mixer to which the table applies. This setting is checked against the current mixer setting before the table can be assigned to the range.

Remote command:

[SENSe:]CORRection:CVL:MIXer on page 426

#### Mixer S/N

Specifies the serial number of the external mixer to which the table applies.

The specified number is checked against the currently connected mixer number before the table can be assigned to the range.

Remote command:

[SENSe:]CORRection:CVL:SNUMber on page 427

#### **Mixer Type**

Specifies whether the external mixer to which the table applies is a two-port or threeport type. This setting is checked against the current mixer setting before the table can be assigned to the range.

Remote command: [SENSe:]CORRection:CVL:PORTs on page 426

#### **Position / Value**

Each position/value pair defines the conversion loss value in dB for a specific frequency. The reference values must be entered in order of increasing frequencies. A maximum of 50 reference values can be entered. To enter a new value pair, select an empty space in the "Position" / "Value" table, or select the Insert Value button.

Correction values for frequencies between the reference values are interpolated. Linear interpolation is performed if the table contains only two values. If it contains more than two reference values, spline interpolation is carried out. Outside the frequency range covered by the table, the conversion loss is assumed to be the same as that for the first and last reference value.

The current configuration of the conversion loss function as described by the position/ value entries is displayed in the preview pane to the right of the table.

Remote command:

[SENSe:]CORRection:CVL:DATA on page 425

#### **Insert Value**

Inserts a new position/value entry in the table.

If the table is empty, a new entry at 0 Hz is inserted.

If entries already exist, a new entry is inserted above the selected entry. The position of the new entry is selected such that it divides the span to the previous entry in half.

#### **Delete Value**

Deletes the currently selected position/value entry.

#### Shift x

Shifts all positions in the table by a specific value. The value can be entered in the edit dialog box. The conversion loss function in the preview pane is shifted along the x-axis.

#### Shift y

Shifts all conversion loss values by a specific value. The value can be entered in the edit dialog box. The conversion loss function in the preview pane is shifted along the y-axis.

#### Save

The conversion loss table is stored under the specified file name in the C:\R S\INSTR\USER\cvl\ directory of the instrument.

# **10.3 Level Characteristics**

Measurement results usually consist of the measured signal levels (amplitudes) displayed on the vertical y-axis for the determined frequency spectrum (horizontal, x-axis). The settings for the vertical axis, regarding amplitude and scaling, are described here.

- Signal Attenuation.....142
- Diagram Scale.....145

### 10.3.1 Signal Attenuation

Signal attenuation reduces the level of the signal that you feed into the R&S FSWP. Reducing the level is necessary to protect the input mixer from signals with high levels, because high levels can cause an overload of the input mixer. An input mixer overload in turn can lead to incorrect measurement results or even damage or destroy the input mixer.

The level at the input mixer is determined by the set RF attenuation according to the formula:

level<sub>mixer</sub> = level<sub>input</sub> - RF attenuation

The maximum level that the input mixer can handle is 0 dBm. Levels above this value cause an overload. The R&S FSWP indicates an overload situation by the "RF OVLD" label in the status bar.

The R&S FSWP features a mechanical attenuator. The mechanical attenuator is located directly after the RF input of the R&S FSWP. Its step size is 5 dB.

#### Effects of the attenuator

Attenuation has a direct effect on the sensitivity of the analyzer - attenuation must be compensated for by reamplifying the signal levels after the mixer. Thus, high attenuation values cause the inherent noise (or noise floor) to rise, which in turn decreases the sensitivity of the analyzer. The highest sensitivity is obtained at an RF attenuation of 0 dB. Each additional 10 dB of attenuation reduces the sensitivity by 10 dB, i.e. the dis-

played noise is increased by 10 dB. To measure a signal with an improved signal-tonoise ratio, decrease the RF attenuation.

Another (positive) effect is that high attenuation also helps to avoid intermodulation.



For ideal sinusoidal signals, the displayed signal level is independent of the RF attenuation.

In the default state, the R&S FSWP automatically determines the attenuation according to the signal level that is currently applied. Automatic determination of the attenuation is a good way to find a compromise between a low noise floor, high intermodulation levels, and protecting the instrument from high input levels.

However, you can also define the attenuation manually, if necessary.

#### **10.3.2 Amplitude Characteristics**

Access: "Overview" > "Amplitude / Scaling" > "Amplitude"

Amplitude settings allow you to adapt the R&S FSWP for the signal that is fed into its input (for example the RF input).

Amplitude	Scale	
RF Attenuation		
Mode	Auto Manual	
Value	0.0 dB	
Signal		
Level Settin	g High Low	
Level Offset	t 0.0 dB	
Input Setting	IS	
Input Coupl	ing AC DC	

Functionality to configure amplitude characteristics described elsewhere:

- "Input Coupling " on page 126
- Level Setting

The remote commands required to configure the amplitude are described in Chapter 15.6.4, "Remote Commands to Configure Level Characteristics", on page 443.

Level Characteristics

Attenuating the signal	144
Shifting the level	144
Searching for the signal level	144

#### Attenuating the signal

You can either determine the attenuation automatically or manually. Signal attenuation is possible in 5 dB steps. The range is specified in the data sheet.

When you select "Auto" mode, the R&S FSWP determines the attenuation based on the level of the signal that is applied. Automatic determination of the attenuation makes sure that the ideal attenuation is always selected.

In "Manual" mode, the "Value" field becomes available and you can define an attenuation as required.

Not available for baseband noise measurements.

**NOTICE!** Risk of hardware damage due to high power levels.

When you decrease the attenuation manually, make sure that the signal level does not exceed the maximum level allowed at the RF input. Otherwise, an overload of the input mixer can cause hardware damage.

Remote command:

Mode: INPut<1|2>:ATTenuation:AUTO on page 447 Attenuation: INPut<1|2>:ATTenuation on page 447

#### Shifting the level

You can define an arithmetic level offset that is added to the measured level.

Defining a level offset is useful, for example, if you attenuate or amplify the signal before it is fed into the R&S FSWP. The R&S FSWP is then able to display the correct power results.

To determine the required offset, consider the external attenuation or gain applied to the input signal. For attenuation, define a positive offset so the R&S FSWP increases the displayed power values. If an external gain is applied, define a negative offset so the R&S FSWP decreases the displayed power values.

Not available for baseband noise measurements and VCO measurements.

Not available for baseband noise measurements.

Remote command:

[SENSe:]POWer:RLEVel:OFFSet on page 448

#### Searching for the signal level

The R&S FSWP automatically measures the level of the signal you have applied and keeps track of the measured signal levels.

The currently measured signal level is displayed in the channel bar.



Note that you should attenuate the signal if its level is too high, especially if you have no idea about the signal strength you are measuring. For more information, see "Attenuating the signal" on page 144.

The measurement starts only if the signal level is within the level threshold that you have defined via the "Auto Search" feature.

If the signal level is outside the threshold that you have defined, it is ignored.



Figure 10-3: Basic principle of the signal search feature

Signal search is not available for baseband noise measurements.

Remote command: Signal level: [SENSe:]POWer:RLEVel? on page 448 Threshold: [SENSe:]ADJust:CONFigure:LEVel:THReshold on page 448

# 10.3.3 Diagram Scale

Access: "Overview" > "Amplitude / Scaling" > "Scale"

The scale settings define the scale of the y-axis in graphical result displays.

Amplitude	Scale
Y Axis Scale	
Mode	Auto Manual
Тор	200.0 dBc/Hz
Range	500.0 dB
Bottom	-300.0 dBc/Hz
l	Auto Scale Once

The remote commands required to configure the amplitude are described in Chapter 15.6.4, "Remote Commands to Configure Level Characteristics", on page 443.

Scaling the y-axis	145	5
Selecting the unit of the y-axis	146	3

#### Scaling the y-axis

You can scale the y-axis of graphical result displays automatically or manually.

Scaling the axis automatically has the advantage that the application automatically selects the ideal scale for the current measurement results. When you select the "Auto" scale mode, the R&S FSWP adjusts the scale of the axis during the measurement.

When you select the "Manual" scale mode, you can select any scale that suits your needs. You can scale the axis by the following logic:

- Define a "Top" and "Bottom" value. The "Range" is adjusted accordingly.
- Define a "Top" value and a "Range". The "Bottom" value is adjusted accordingly.
- Define a "Range" and a "Bottom" value. The "Top" value is adjusted accordingly.
- When you change the "Top" or "Bottom" values only, the "Range" is adjusted.

• When you change the "Range" only, the "Bottom" value is adjusted.

In addition, you can perform a single automatic scale adjustment with the "Auto Scale Once" feature. When you do so, the R&S FSWP selects the ideal scale for the current measurement results, but will not update the scale for the next measurement.

Remote command:

Mode: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:AUTO on page 445 Top: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel on page 446 Bottom: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel:LOWer on page 446

```
Range: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe] on page 445
```

# Selecting the unit of the y-axis

Baseband noise measurements allow you to select one of several units in which the results are displayed.

You can select the desired unit from the "Y Axis Unit" dropdown menu.

Not available for all other measurements in the phase noise measurement application. The units used by other measurements depend on the selected diagram and cannot be changed manually.

# Remote command:

DISPlay[:WINDow<n>]:TRACe<t>:Y:UNIT on page 446

# **10.4 Frequency**

Access (carrier frequency): "Overview" > "Frequency"

Access (measurement range): "Overview" > "Noise Config" > "Noise Config"

Frequency settings allow you to control the characteristics of the measurement frequency.

Frequency

Auto Search	×
Signal Frequency	4.0 GHz
Level Setting	High Low
Auto Search	On Off
Signal Count	tin
Auto Search	
Start	1.0 MHz
Stop	26.501 GHz
Threshold	-20.0 dBm
Capture Range	Normal Wide 40 MHz
Low Pass	
State	On Off
Cutoff Frequency	1.0 MHz

The auto search features are available for phase noise and pulsed phase noise measurements.

The remote commands required to configure the frequency are described in Chapter 15.6.5, "Remote Commands to Configure the Frequency", on page 449.

Defining the signal frequency	147
Searching for a signal	
Capture Range	149
Defining the measurement range	
Measuring low frequency and low level signals	. 150
Low signal frequencies	
Low signal levels	150
L Multicarrier signals	
•	

# Defining the signal frequency

The "Signal Frequency" is the frequency the signal is transmitted with.

You can define it manually in the corresponding input field or let the R&S FSWP search for the signal frequency in an automatic frequency search (turn on the "Auto Search" in that case).

For pulsed measurements (phase noise and additive noise), the minimum supported carrier frequency is 30 MHz.

Not available for baseband noise measurements.

Remote command: [SENSe:]FREQuency:CENTer on page 452

#### Searching for a signal

The R&S FSWP automatically scans the frequency spectrum for any signals before a phase noise measurement begins. If it can find a signal on any frequency, it starts a measurement on that frequency.

The current signal frequency is displayed in the channel bar.

 MultiView #
 Phase Noise
 Image: Comparison of the image: Comparis

In case you already know the signal frequency, you can also turn off the "Auto Search" and define it manually. When you turn off automatic search, the R&S FSWP still verifies if a signal is present at the frequency you have defined and, if necessary, adjusts the frequency if the signal is a few Hz off. If you want to skip the signal verification and measure exactly the frequency you have entered manually, turn off the "Signal Count" feature. In that case, the R&S FSWP tunes to the frequency you have entered and measures its phase noise characteristics, even if no signal is present. Turning off the frequency counter can improve measurement speed, however.

The measurement starts only if a signal is present within the frequency search limits that you have defined via the "Auto Search" feature. The search range is defined by a minimum and maximum value. The maximum frequency range that you can scan depends on the hardware you are using. Note that a signal must also be within a certain level range for it to be detected.

No measurement will be initiated if no signal can be found in the frequency search range you have defined.




Figure 10-4: Basic principle of the signal search feature

During a frequency scan, the R&S FSWP steps through the frequency search range you have defined in a predefined step size (one step usually covers the full I/Q bandwidth).

Signal search is only available for phase noise and pulsed phase noise measurements. Remote command:

```
Signal frequency: [SENSe:]FREQuency:CENTer on page 452
Mode: [SENSe:]ADJust:CONFigure:FREQuency:AUTosearch[:STATe]
on page 449
Signal count: [SENSe:]ADJust:CONFigure:FREQuency:COUNt on page 449
```

Lower search limit: [SENSe:]ADJust:CONFigure:FREQuency:LIMit:LOW on page 450 Upper search limit: [SENSe:]ADJust:CONFigure:FREQuency:LIMit:HIGH on page 450

#### **Capture Range**

The "Capture Range" defines the bandwidth with which the R&S FSWP searches for a signal or tracks drifting signals.

Use a "Normal" capture range for stable or slowly drifting DUTs. For fast drifting DUTs, use a "Wide" capture range.

Use a "40 MHz" capture range to measure carriers swept from -40 MHz to +40 MHz relative to the center frequency. Additional spurs and restrictions of the measurement accuracy are possible for CW signals, or carriers swept in other frequency ranges. For specifics of the measurement accuracy, refer to the data sheet.

The capture range is available for the phase noise measurement.

Remote command: [SENSe:]SWEep:CAPTure:RANGe on page 454

#### Defining the measurement range

Noise measurements determine the noise of a DUT over a certain measurement range. The measurement range is defined by the two offset frequencies that you define ("Start Offset" and "Stop Offset").

The frequency offsets themselves are relative to the carrier frequency of the DUT: a frequency offset of 1 MHz, for example, measures the noise characteristics up to a distance of 1 MHz from the carrier. The maximum offset that you can define depends on the hardware you are using.

**Note:** For pulsed phase noise measurements (phase noise and additive), the maximum offset is limited to 30 MHz.

For baseband noise measurements, the frequency range is defined by absolute start and stop frequencies instead of relative offset frequencies. The center frequency represents the carrier frequency. The measurement range or span depends on the input you are using: For the RF input, it depends on the hardware you are using. For the baseband input, measurements up to 40 MHz are supported.

The measurement range thus defines the scale of the x-axis in the "Phase Noise" diagram.

The measurement range again is divided into several (logarithmic) decades, or, for configuration purposes, into half decades.

**Note:** For frequency stability measurements, the start and stop frequency offsets of the phase noise measurement are the reciprocal values of the start and stop values of the observation time ("Tau Start" and "Tau Stop").

Tau Start and Tau Stop thus define the scale of the x-axis in the "Allan Variance" and "Allan Deviation" diagrams.

Remote command:

Start offset: [SENSe:]FREQuency:STARt on page 452 Stop offset: [SENSe:]FREQuency:STOP on page 453 Start Tau: [SENSe:]TIME:STARt on page 461 Stop Tau: [SENSe:]TIME:STOP on page 461

# Measuring low frequency and low level signals

The R&S FSWP provides functionality to measure the phase noise of signals with a low frequency and / or a low signal level.

- Low frequencies can be measured by applying the low pass filter.
- Low signal levels can be measured by selecting the appropriate level setting.
- Very low signal levels can be measured by selecting the appropriate level setting and applying the low pass filter.

### Low signal frequencies ← Measuring low frequency and low level signals

The R&S FSWP provides a low pass filter that suppresses the DC offset of the I/Q mixer to measure signal frequencies below 1 MHz. Applying the filter results in a better sensitivity.

When you are measuring such signals, turn on the filter ("State"), and define its "Cutoff Frequency". The cutoff frequency should be the same as the signal frequency. For example, the cutoff frequency to measure a signal frequency of 100 Hz should also be 100 Hz.

Measuring low frequencies and levels is available for phase noise measurements on continuous wave signals.

Note that using the filter has several effects.

- The automatic search for a signal is not supported. Define the signal frequency manually instead.
- A signal count is not possible.
- The stop offset is limited to 30 % of the carrier signal frequency.

For measurements on frequencies below 10 MHz, you must use DC coupling (independent of the low pass filter).

Remote command:

Filter state: [SENSe:]FILTer:LPASs[:STATe] on page 451
Cutoff frequency: [SENSe:]FILTer:LPASs:FREQuency:MANual on page 451

#### Low signal levels ← Measuring low frequency and low level signals

The R&S FSWP supports different modes to measure signals with different levels.

Depending on the measurement, select the appropriate "Level Setting".

- "High": The R&S FSWP works like a traditional phase noise tester with zero IF and is therefore limited in the sensitivity.
- "Low": The R&S FSWP uses an IF of 15 MHz. Therefore, the DC offset of the I/Q mixers does not limit the sensitivity. It is recommended to use this level setting for signal levels below -20 dBm.

For very low signal levels (below approximately -40 dBm), the broadband noise in the demodulator becomes an issue and disables the measurement. To measure such signals, apply the low pass filter, because it reduces the noise bandwidth. The nominal improvement of the sensitivity is 10 dB for 10 MHz, 20 dB for 1 MHz cutoff frequency.

Note that using the filter has several effects.

- The automatic search for a signal is not supported. Define the signal frequency manually instead.
- A signal count is not possible.
- The stop offset is limited to 30 % of the carrier signal frequency.

Remote command:

Filter state: [SENSe:]FILTer:LPASs[:STATe] on page 451
Cutoff frequency: [SENSe:]FILTer:LPASs:FREQuency:MANual on page 451
Level setting: [SENSe:]POWer:RLEVel:MODE on page 454

#### Multicarrier signals ← Measuring low frequency and low level signals

You can also use the low pass filter when you want to measure the phase noise of a single carrier in a multicarrier signal. In that case, the cutoff frequency of the filter should be the same as the carrier spacing.

# **10.5** Noise Measurement Configuration

Noise measurements are performed based on several specific measurement parameters.

•	Triggered Measurements (Phase Noise CW)	151
•	Measurement Range	.151
	Noise Configuration	
	Integrated Measurement Configuration	
	Spot Noise Information	
	Spur Display	
	Frequency Stability Configuration	
		-

# 10.5.1 Triggered Measurements (Phase Noise CW)


The start of the noise measurements can be defined via the "Trigger" hardkey. If "Free Run" is selected, no trigger source is considered. You can start the measurement manually any time and stop it as required. If "External Trigger 1" is selected, a measurement starts when a TTL signal is fed into the specified input connector.

# 10.5.2 Measurement Range

Noise measurements determine the noise characteristics of a DUT over a particular measurement range. This **measurement range** is defined by two offset frequencies. The **frequency offsets** themselves are relative to the nominal frequency of the DUT.

The measurement range again is divided into several (logarithmic) decades, or, for configuration purposes, into **half decades**.

Noise Measurement Configuration





This breakdown into several half decades is made to speed up measurements. See "Working with the half decade configuration table" on page 157 for more information about the measurement configuration in each half decade.

The main issue in this context is the **resolution bandwidth** (RBW) and its effect on the measurement time. In general, it is best to use a resolution bandwidth as small as possible for the most accurate measurement results. However, accuracy comes at the price of measurement speed.

To avoid long measurement times, the application provides only a certain range of RBWs that are available for each half decade.

# 10.5.3 Noise Configuration

Access: "Overview" > "Noise Config" > "Noise Config"

The measurement range parameters define the way the phase noise of a DUT is measured.

#### Noise Measurement Configuration

Noise Config	Integrated M	easurements	Spot Noise	Spurious	Frequency S	tability	
Measurement C	onfiguration		Ha	alf Decade Cor	figuration		
Start Offset		1.0 kHz		Start Offset	Stop Offset	RBW	XCORR
Stop Offset		1.0 MHz		1.0 kHz	3.0 kHz	300.0 Hz	1
and a collected				3.0 kHz	10.0 kHz	300.0 Hz	1
Half Decade C	onfig	Auto	Manual	10.0 kHz	30.0 kHz	1.0 kHz	10
				30.0 kHz	100.0 kHz	3.0 kHz	37
RBW		10.0 %		100.0 kHz	300.0 kHz	10.0 kHz	130
Ultra-Small RB	Ws	On	Off	300.0 kHz	1.0 MHz	30.0 kHz	400
XCORR Factor		1					
XCORR Optimization		On	Off				
XCORR Optimi	zation Threshold	15.0 dB					
XCORR Gain I	ndicator	On	Off				
Capture Range	e	Normal Wide	40 MHz				
Sweep/Avg Co	ount	0					
Sweep Forwa	rd	On	Off				

The remote commands required to configure the measurement range are described in Chapter 15.6.6.1, "Noise Configuration", on page 455.

Functions to configure the measurement range described elsewhere:

- Start Offset
- Stop Offset
- Capture Range

Estimating the measurement time	.153
Defining the resolution bandwidth	154
Ultra-Small RBWs	154
Defining cross-correlation parameters	155
Turning the display of the cross-correlation gain indicator on and off	156
Capture Range	.156
Sweep/Average Count	157
Selecting the sweep direction	157
Working with the half decade configuration table	.157

# Estimating the measurement time

Based on the parameters you have defined for the noise measurement, the application estimates the total measurement time required to measure the noise characteristics over all half decades. It is displayed in the channel bar ("Meas Time" label).

The remaining measurement time of the current measurement is indicated in the progress bar in the status bar (for measurements that last longer than 1 second).

Measuring 7.1 s

Display of the remaining measurement time is supported by the following measurements:

- (Additive) phase noise
- Pulsed (additive) phase noise
- Baseband noise

The measurement time is function of the resolution bandwidth, cross-correlation factor and the number of averages defined for the measurement.

For resolution bandwidths below 0.1%, the estimated measurement time is not available.

Remote command:

[SENSe:]SWEep:TIME on page 459

# Defining the resolution bandwidth

The resolution bandwidth (RBW) is the filter bandwidth applied during the noise measurement. Noise measurements apply a different resolution bandwidth to each half decade that is measured: small bandwidths for small frequency offsets and higher bandwidths for larger frequency offsets (to speed up the measurement on larger frequency offsets).

You can define a custom resolution bandwidth for each half decade, or let the application selects an appropriate resolution bandwidth, depending on the "Half Decade Config" mode.

For an **automatic selection**, the resolution bandwidth that is applied to each half decade is a function of the frequency offset. By default, the resolution bandwidth is 10 % of the start offset of the half decade. If the start offset is, for example 10 kHz, the resulting resolution bandwidth is 1 kHz.

If necessary, you can change the resolution bandwidth factor. A selected set of percentages in the range from 0.1 % to 30 % is supported.

A resolution bandwidth factor below 0.1% is available with the Ultra-Small RBWs.

For a **manual selection**, you can enter the required resolution bandwidth as an absolute value in the corresponding cells of the half decade table.

Remote command:

Configuration mode: [SENSe:]SWEep:MODE on page 459 RBW factor: [SENSe:]LIST:BWIDth[:RESolution]:RATio on page 455 RBW: [SENSe:]LIST:RANGe<r>:BWIDth[:RESolution] on page 456

### **Ultra-Small RBWs**

Provides functionality to enable ultra-small resolution bandwidths (RBW) for the current measurement. It can only be used in phase noise and additive noise measurements.

The minimum RBW can be set to 0.0003% (instead of 0.1%) if this function is enabled. Also, only one measurement channel can be used due to memory limitation.

Be aware that if the function is enabled, and the function is enabled in an instrument saveset, recall of the saveset fails. If the function is enabled in a saveset used for startup recall, every second preset acts as if startup recall had been disabled.

If this function is enabled and RBWs below 0.1% are used, the estimated measurement time is not available.

Remote command:

[SENSe:]LIST:BWIDth[:RESolution]:USMall on page 458

#### **Defining cross-correlation parameters**

Cross-correlation is a method to calculate the noise characteristics by routing it through two different signal paths. The signal has correlated noise characteristics in both channels while the oscillators have uncorrelated noise characteristics. Through cross-correlation operations, the noise of the DUT is kept constant while the noise of the signal path is reduced.

You can define a custom number of cross-correlation operations for each half decade, or let the application select an appropriate number, depending on the "Half Decade Config" mode.

For an **automatic selection**, the number of cross-correlation operations that are performed depends on the half decade that is measured. Small offsets (which usually have a higher noise level) require fewer operations to get accurate results, while large offsets (whose noise levels can be very low) require more operations for accurate results.

The base number of the first decade is a fixed value. The number of operations for the other half decades is determined in such a way, that all operations are finished at roughly the same time.

For a **manual selection**, you can enter the required number of cross-correlation operations as an absolute value in the corresponding cells of the half decade table.

### Example:

The operations in the first half decade need 1 s to finish. The number of operations done in the other half decades is calculated with respect to this 1 s timeframe. For example, if the application can perform 10 cross-correlation operations in 1 s in another half decade, it will do so, but no more than that number.

You can control the number of cross-correlations for the first half decade with the cross-correlation factor ("XCORR Factor"). By multiplying this value with the base number of operations for the first half decade, the application calculates the time it takes to perform these operations in the first half decade and then adjusts the number of operations for all other half decades.

When you turn on the "XCORR Optimization" feature, cross-correlation operations are only performed as long as the measurement results still improve. When this is not the case, the R&S FSWP stops calculating results, even when the selected number of operations has not yet been reached. This is thus a good tool to speed up the measurement.

The point at which measurement results cannot be improved anymore is defined by the "XCORR Optimization Threshold". The threshold is the distance between the gain indicator and the actual trace. When the distance between those two traces exceeds the threshold in any given half decade, the R&S FSWP stops measuring in this half decade and resumes with the next one.

### Example:

The number of operations in a half decade is 30. When optimization is on, and the results do not improve any more after 20 operations, the application stops measurements in that half decade.

You can also finish the measurement of a specific half decade manually with the "Finish Segment" softkey available in the "Sweep" menu. The R&S FSWP resumes the measurement of the next half decade in that case.

For offsets greater than 30 MHz, each half decade is divided into smaller segments. For these offsets, the "Finish Segment" feature does not resume with the next half decade, but with the next offset segment.

Remote command:

Configuration mode: [SENSe:]SWEep:MODE on page 459 XCORR factor: [SENSe:]SWEep:XFACtor on page 460 XCORR number: [SENSe:]LIST:RANGe<r>:XCOunt on page 457 Optimization: [SENSe:]SWEep:XOPTimize[:STATe] on page 460 Optimization threshold: [SENSe:]SWEep:XOPTimize:THReshold on page 460 Finish segment: [SENSe:]SWEep:FSEGment on page 459

#### Turning the display of the cross-correlation gain indicator on and off

The phase noise diagram contains a grey area in its default state. This area represents the cross-correlation gain indicator.

It shows the rejection of uncorrelated noise dependent on the number of correlation averages. If the measurement trace itself lies on the cross-correlation gain indicator, further correlation will reduce the phase noise value. If some distance between the cross-correlation gain indicator and the measurement result is obtained, further correlation will not reduce the phase noise value any more, but only smooth the trace. When you turn on the "Optimize XCORR" feature, the measurement stops automatically when the gap between the cross-correlation gain indicator and the measurement stops automatically when the gap between the cross-correlation gain indicator and the measurement trace exceeds 10 dB.

You can turn the display of the gray area on and off as required.

Remote command: DISPlay:XGINdicator[:STATe] on page 455

#### Capture Range

The "Capture Range" defines the bandwidth with which the R&S FSWP searches for a signal or tracks drifting signals.

Use a "Normal" capture range for stable or slowly drifting DUTs. For fast drifting DUTs, use a "Wide" capture range.

Use a "40 MHz" capture range to measure carriers swept from -40 MHz to +40 MHz relative to the center frequency. Additional spurs and restrictions of the measurement accuracy are possible for CW signals, or carriers swept in other frequency ranges. For specifics of the measurement accuracy, refer to the data sheet.

The capture range is available for the phase noise measurement.

Remote command:

[SENSe:]SWEep:CAPTure:RANGe on page 454

### Sweep/Average Count

Defines the number of measurements to be performed in the single sweep mode. Values from 0 to 200000 are allowed. If the values 0 or 1 are set, one measurement is performed.

The sweep count is applied to all the traces in all diagrams.

For "Average" trace mode, the "Sweep Count" also determines the number of individual measurements used to average the trace.

In continuous sweep mode, a "Sweep Count" = 0 (default) calculates a moving average over 10 measurements. A "Sweep Count" = 1 calculates no averages.

#### Remote command:

[SENSe:]SWEep:COUNt on page 458

#### Selecting the sweep direction

The sweep direction selects the order in which the R&S FSWP measures the half decades.

For the reverse sweep ("Sweep Forward" = "Off"), the measurement sequence is:

- Analysis of half decades > 30 MHz
- Analysis of half decades between 30 MHz and 1 MHz
- Analysis of half decades < 1 MHz</li>

For the forward sweep ("Sweep Forward" = "On"), the measurement sequence is:

- Analysis of half decades < 1 MHz</li>
- Analysis of half decades between 30 MHz and 1 MHz
- Analysis of half decades > 30 MHz

Otherwise, the measurements are the are the same and yield the same results, regardless of the sweep direction you select. The difference is that results near the carrier are available faster when you select the forward sweep.

Remote command:

[SENSe:]SWEep:FORWard on page 458

#### Working with the half decade configuration table

The half decade configuration table shows the measurement characteristics for each half decade that is part of the measurement.

The features of the table depend on the "Half Decade Config" mode:

 For the automatic mode, the table is read only, the values in the table depend on the settings you have made for the noise measurements (RBW Factor and XCORR Factor).

The size (number of rows) depends on the number of half decades that you have defined.

Automatic half decade configuration is designed to yield the optimal measurement times for each half decade.

 For the manual mode, you can define custom values for the resolution bandwidth (RBW) and the number of cross-correlation operations.

The table contains the following values.

Start Offset

Start frequency offset of the half decade.

Depends on the frequency offsets you have defined.

• Stop Offset

Stop frequency offset of the half decade.

Depends on the frequency offsets you have defined.

RBW

Resolution bandwidth applied to the corresponding half decade during the measurement.

Depends on the resolution bandwidth factor you have defined.

Custom RBWs become available when you are using manual configuration mode.

XCORR

Shows the number of cross-correlation operations applied in the corresponding half decade.

Depends on the XCORR factor you have defined.

Custom cross-correlation operations become available when you are using manual configuration mode.

Remote command:

Configuration mode: [SENSe:]SWEep:MODE on page 459 Start offset: [SENSe:]LIST:RANGe<r>:FREQuency:STARt? on page 456 Stop offset: [SENSe:]LIST:RANGe<r>:FREQuency:STOP? on page 457 RBW: [SENSe:]LIST:RANGe<r>:BWIDth[:RESolution] on page 456 XCORR: [SENSe:]LIST:RANGe<r>:XCOunt on page 457

# 10.5.4 Integrated Measurement Configuration

Access: "Overview" > "Noise Config" > "Integrated Measurements"

You can control the integration ranges and data source (traces) that the calculations for integrated measurement results are based on.

For integrated measurements, the raw measurement data are used instead of the data smoothed by the trace smoothing functionality.

loise Con	ng Integ	rated measurem	ents Spot Nois	e spunous r	requency Stability
	-5 Range	is 6-10 Weight	ing Filter		
Rangm	show	Range	Range Start	Range Stop	Weighting Filter
Hange T	Irace 1	- Meas Manua	1.0 kHz	1.0 MHz	NONE ·
Range 2	None	- Meas Hanna	1.0 kHz	1.0 MHz	NONE ·
Range 3	None	- Heas Manua	a) republic		NONE
Range 4	None	- Manua	a fam.	1	NONE
Range 5	None	- Manua	al Come		NONE -

The remote commands required to configure residual calculations are described in Chapter 15.6.6.2, "Residual Calculation Configuration", on page 462.

Selecting the trace for residual calculations	159
Defining the integration range	
Working with weighting filters	
L Applying weighting filters	
L Managing weighting filters	
L Designing weighting filters	

# Selecting the trace for residual calculations

Residual calculations are only performed when you select an (active) trace that serves as the data source (when the selected trace is inactive, residual effects are not calculated).

You can select any trace as the data source ("Trace 1" to "Trace 6" in the dropdown menu), and define the frequency range over which the integration is performed.

When you select "None" from the dropdown menu, residuals effects are not calculated. Remote command:

CALCulate<n>[:RANGe<j>]:EVALuation:TRACe on page 463

#### Defining the integration range

You can define up to 10 integration ranges on different traces.

By default, the R&S FSWP integrates over the entire frequency range defined for the measurement (Range = "Meas"). You can, however, also define custom integration ranges (Range = "Manual").

In that case, the input fields next to the "Range" control become available to define a customized integration range. The application shows orange lines ("Range <x>") in the graphical result display to indicate custom ranges.

Phase Noise: United and the second se

#### Remote command:

State: CALCulate<n>[:RANGe<j>]:EVALuation[:STATe] on page 463
Start: CALCulate<n>[:RANGe<j>]:EVALuation:STARt on page 462
Stop: CALCulate<n>[:RANGe<j>]:EVALuation:STOP on page 462

#### Working with weighting filters

The weighting filter feature provides functionality to correct integrated measurements and thus compensate for external effects that affect the results in certain frequency ranges. A weighting filter is a useful feature if you already know that this is the case and would like to compensate for these effects.

Note that the weighting filter only has an effect on the integrated measurement results and has no effect in the noise diagram or other numerical results.

# Applying weighting filters ← Working with weighting filters

When you apply a weighting filter, the R&S FSWP takes the correction values defined in the weighting filter into account for the calculation of integrated measurements.

The "Weighting Filter" dropdown menu contains all weighting filters that are available on the internal hard disk of the R&S FSWP.

Remote command:

CALCulate<n>[:RANGe<j>]:EVALuation:WEIGhting on page 464

# Managing weighting filters - Working with weighting filters

The table in the "Residual Calculations" dialog box shows all currently available weighting filter.

From this dialog box, you have the following options.

- Edit a weighting filter that already exists (→ "Edit").
- Create a new weighting filter (→ "New").
- Create a new weighting filter based on an existing one (→ "Copy").
   If necessary, you can delete the selected filter at any time (→ "Delete").

Each of the options opens a dialog box that contains the functionality to characterize a weighting filter.

Remote command:

Select a filter: [SENSe:]CORRection:WEIGhting:SELect on page 465 Delete: [SENSe:]CORRection:WEIGhting:DELete on page 464

#### 

The R&S FSWP provides the following tools to design a weighting filter.

- "Name" / "Comment"
   Defines a name and / or comment of the weighting filter. The name defines the label by which the filter appears in the "Weighting Filter" dropdown menu.
- "Position" and "Value"

Define the data points of the weighting filter (including a graphical preview). They define by which amount (dB) residual effects are corrected for specific frequencies. For example, you could say that at a frequency of 100 MHz, the residual effects are corrected by 5 dB.

- "Insert Value" Inserts a weighting filter data point. Alternatively, you can click in the table itself to add a new data point.
- "Delete Value" Deletes the currently selected data point. The currently selected data point is highlighted blue.
- "Shift X" / "Shift Y" Shifts all data points of the weighting filter horizontally or vertically by a certain amount.
- "Save"

Saves and stores the weighting filter on the internal hard disk of the R&S FSWP.

A weighting filter consists of up to 625 data points. Each data point is a pair of values: the first value describes the frequency, the second value describes the level (correction value) for that frequency.

Frequencies must be entered in ascending order and must not overlap.

When you save the filter, the R&S FSWP uses the name of the weighting filter as the file name. If a weighting filter of the same name already exists, the R&S FSWP asks before it overwrites the existing file.

Remote command:


Name: [SENSe:]CORRection:WEIGhting:NAME on page 465 Comment: [SENSe:]CORRection:WEIGhting:COMMent on page 464 Data: [SENSe:]CORRection:WEIGhting:DATA on page 464

# 10.5.5 Spot Noise Information

Access: "Overview" > "Noise Config" > "Spot Noise"

Spot noise is the phase noise measured at a certain offset frequency. The information about spot noise is provided in the noise diagram (optionally) and in a separate spot noise information table.

The R&S FSWP provides several features to control the spot noise information.



The remote commands required to configure spot noise measurements are described in Chapter 15.6.6.3, "Spot Noise Configuration", on page 465.

Displaying spot noise information1	61
Selecting the spot noise positions1	61

#### **Displaying spot noise information**

By default, when you perform a measurement, the R&S FSWP displays the spot noise information in the diagram area.

You can turn off the displayed spot noise information any time, for example if you want a better view of the measurement results.

You can also select the trace the displayed spot noise information refers to from the "Trace" dropdown menu.

Remote command:

DISPlay:SNINfo[:STATe] on page 469 DISPlay:SNINfo:TRACe on page 469

# Selecting the spot noise positions

The R&S FSWP provides several methods to define the positions where the spot noise is measured.

By default, it calculates the spot noise on all "Decade Edges" (10<sup>x</sup> offset frequencies) in the measurement range. Therefore, the number of spot noise results depends on the measurement range.

If you want to evaluate the spot noise on positions other than the decade edges, you can add "User Defined" spot noise positions. When you turn on that feature, changes that you make to the "Offset" input fields are considered in the current measurement (by default, user defined spot noise positions are the decade edges).

You can define any offset frequency that is part of the measurement range as a new spot noise position. To exclude an offset frequency, uncheck the checkbox of the current offset.

The results for the user defined spot noise positions are displayed in the spot noise table in addition to the decade edge spot noise results.

When you turn off the "Decade Edges" spot noise positions, the spot noise table contains only the user defined spot noise positions.

Remote command: See Chapter 15.6.6.3, "Spot Noise Configuration", on page 465.

# 10.5.6 Spur Display

Access: "Overview" > "Noise Config" > "Spurious"

Spurs are (usually undesired) peak levels that can occur in the measured frequency range. They are represented by unusually tall spikes on the trace.

Noise Config	Integrated Measurements	Spot Noise Spurious Frequency Stability
Specifics for Dia	agram	Spurious Filter
Trace 1	Detection Threshold Hide	Mode Off Suppress Show
Trace 2	6.0 dB	Include Harmonics
Trace 3	6.0 dB	Range 1.0 * RBW
Trace 4	6.0 dB	Name NONE Offset
Trace 5	6.0 dB	
Trace 6	6.0 dB	
Specifics for Spurious List	1: Noise Spectrum	
Sort Order	Power Offset	Insert Delete Clear
Weighting Filte	er NONE -	Save
Spurious Color	Trace Shifted	

The remote commands required to configure the spur display are described in Chapter 15.6.6.4, "Spur Display", on page 469.

# **Hiding spurs**

Hiding spurs is a method to remove displayed peak levels visually.

You can apply spur removal to all active traces individually (spurious removal "Hide In Diagram"), and define a threshold (in dB) that defines when a peak level is recognized as a spur (spurious removal "Detection Threshold").

**Note**: In the spot noise vs tune measurement, spur removal properties apply to all traces.

Remote command:

```
State: DISPlay[:WINDow<n>]:TRACe<t>:SPURs:SUPPress on page 470
Value: DISPlay[:WINDow<n>]:TRACe<t>:SPURs:THReshold on page 470
State (SN vs Tune): [SENSe:]SPURs:SUPPress on page 483
Value (SN vs Tune): [SENSe:]SPURs:THReshold on page 483
```

# Sorting spurs

The sort order of the spurs in the spurious list result display depends on the "Sort Order" you select.

- "Power" Sorts the spurs according to their power (highest to lowest power).
- "Offset" Sorts the spurs according to their offset from the carrier (lowest to highest offset).

Remote command: [SENSe:]SPURs:SORT on page 471

#### Applying a spurious weighting filter

The spurious weighting filter feature provides functionality to apply a weighting filter to spurious analysis. For more information on how to apply, manage and design weighting filters, see "Working with weighting filters" on page 159.

Remote command:

[SENSe:]SPURs:WEIGhting on page 471

### Defining the spurious color

The spurious color feature provides functionality to enable an automatic shift of the color of the displayed spurious lines. The color setting is not changed by a preset of the instrument.

Remote command: [SENSe:]SPURs:COLor on page 473

# **Filtering spurs**

Filtering spurs is a method to show or hide items of the spurious list.

Mode	<ul> <li>"Off": No spurious filter is applied.</li> <li>"Suppress": The spurs in the spurious filter are removed from the spurious list, the diagram and dependent calculations.</li> <li>"Show": Only the spurs in the spurious filter are displayed in the spurious list, the diagram and dependent calculations.</li> </ul>
Include Har- monics	In addition to the spurs in the defined spurious filter list, also their har- monics are displayed or removed in the spurious list.
Range	Defines the filter range as a multiple of the resolution bandwidth.
Name	Displays the name of the currently selected spurious filter.

Spurious FilterThe spurious filter configuration table provides several managementManagementtools:

- "Insert": Adds a new offset frequency to the spurious filter.
- "Delete": Removes an existing offset frequency from the spurious filter.
- "Clear": Clears the spurious filter.
- "Save": Saves the spurious filter configuration. With this function, the name of the spurious filter can be defined.
- "Load": Loads an existing spurious filter configuration.

# Remote command:

```
[SENSe:]SPURs:FILTer:MODE on page 471
[SENSe:]SPURs:FILTer:HARMonics on page 472
[SENSe:]SPURs:FILTer:RANGe on page 472
[SENSe:]SPURs:FILTer:NAME? on page 472
[SENSe:]SPURs:FILTer:OFFSet on page 472
[SENSe:]SPURs:FILTer:CLEar on page 473
[SENSe:]SPURs:FILTer:SAVE on page 473
[SENSe:]SPURs:FILTer:LOAD on page 473
```

# 10.5.7 Frequency Stability Configuration

Access: "Overview" > "Noise Config" > "Frequency Stability"

The results of the frequency stability measurements (Allan variance and deviation) are derived from the phase noise measurement. Thus, the frequency stability measurements and the phase noise measurement use the same configuration.

The "Frequency Stability" dialog contains the most important settings for the frequency stability measurements. However, everything that you change in the phase noise configuration is also applied to the frequency stability measurements, and vice versa.

• "Tau Start" and "Tau Stop"

Tau start and stop define the observation time Tau for the frequency stability measurement. They are coupled to the measurement range. Tau start is the reciprocal value of the stop frequency offset. Tau stop is the reciprocal value of the start frequency offset.

For example, a measurement range from 1 mHz to 1 MHz would result in an observation time from 1  $\mu$ s to 1000 s and vice versa.

"RBW" and "XCORR"

Note that if you define the RBW and number of cross-correlation operations manually, the values of the half decade configuration table are also applied to the frequency stability measurements.

"Meas BW"

The measurement bandwidth (or integration bandwidth) is the reciprocal value of "Tau Start".

Noise Config	Integrated Measurements	Spot Noise	Spurious	Frequency Stability	
Frequency Stabi	lity				
Tau Start	<b>1.0</b> µs				
Tau Stop	1.0 ms				
Meas BW					
RBW					
XCORR Factor					

The remote commands required to configure frequency stability measurements are described in Chapter 15.6.6.1, "Noise Configuration", on page 455.

# 10.6 Output

The phase noise application is able to provide different kinds of output for various purposes.

For more information about the available connectors, refer to the getting started manual.

# 10.6.1 DC Source Configuration

Access (all DC port settings): "Overview" > "Output" > "Output" > "DC Config"

Access (most relevant DC port settings): 
(in the toolbar)

Access (DC port state): "Overview" > 📟 (in the toolbar)

The "DC Power" settings allow you to configure the DC power supply sources available on the front panel for different purposes.



# í

# Proper configuration of the DC ports

Setting DC voltages and currents properly is an important step during the configuration in order not to damage the device under test (DUT) by applying too much voltage or current!

Therefore it is recommended to connect the device under test (DUT) to the instrument after the DC settings have been made and verified.

The remote commands required to configure the DC power output are described in Chapter 15.6.2, "Output", on page 428.

Turning the DC output on and off	166
Coupling the output configuration across measurement channels	166
Configuring the DC power output	166
L Turning the output on and off L Selecting the output type (Vsupply only) L Defining the output level L Reading the actual output levels	167 .167 167

# Turning the DC output on and off

DC output power is only supplied when you turn on the DC power output in general with the "DC Power" feature.

You have to turn on at least one of the individual voltage supplies  $V_{supply}$ ,  $V_{tune}$  or  $V_{aux}$  ( $\rightarrow$  Output State) before you can turn on DC output in general.

When you turn off DC power supply in general, no power is supplied, even when the individual outputs have been turned on.

Remote command: SOURce:VOLTage[:STATe] on page 436

# Coupling the output configuration across measurement channels

You can couple the configuration of the DC power output and the (optional) signal source output across all active measurement channels.

When you turn on coupling, all active measurement channels apply the same configuration.

When you turn off coupling, you can define a different configuration for each measurement channel.

Remote command:

DC power: SOURce:VOLTage:CHANnel:COUPling on page 431 Signal source: SOURce:GENerator:CHANnel:COUPling on page 437

# Configuring the DC power output

The R&S FSWP features three outputs that allow you to supply external devices like the DUT or external measurement equipment with DC power.

The outputs are labeled " $V_{supply}$ " (supply voltage), " $V_{tune}$ " (tuning voltage) and " $V_{aux}$ " (auxiliary voltage). Each of the outputs has different characteristics regarding the supported voltage range and maximum output current, and is thus designed for different purposes.

**Note:** If you change one of the DC power output parameters during a measurement, the measurement is aborted and restarted.

For more information about the output connectors, refer to the getting started.

Basically, you can define the same parameters for all three outputs.

- "Turning the output on and off" on page 167
- "Selecting the output type (Vsupply only)" on page 167
- "Defining the output level" on page 167
- "Reading the actual output levels" on page 168

# Turning the output on and off $\leftarrow$ Configuring the DC power output

Apart from the general DC power output state, you can turn each individual output on and off. Output is generated only, when the required DC output is actually turned on.

By default, all outputs are turned off. When you want to use one of the outputs, turn it on.

Note that you have to turn on at least one of the outputs to be able to turn on the output in general.

#### Remote command:

 $\label{eq:supply:source:volTage:POWer<i>:LEVel[:STATe] on page 435 \\ V_{tune}: SOURce:VOLTage:CONTrol<i>:LEVel[:STATe] on page 433 \\ V_{aux}: SOURce:VOLTage:AUX:LEVel[:STATe] on page 431 \\ \end{tabular}$ 

# Selecting the output type (Vsupply only) $\leftarrow$ Configuring the DC power output

The supply voltage output ( $V_{supply}$ ) supports variable voltages and variable current. For this output, you can select whether you want to control the output in terms of current or voltage.

When you select "Voltage", you can define the output in terms of the voltage that is supplied. The supplied current is adjusted accordingly (up to the maximum current you have allowed).

When you select "Current", you can define the output in terms of the current that is supplied. The supplied voltage is adjusted accordingly (up to the maximum voltage you have allowed).

The other outputs are already limited regarding the output current; only the voltage is variable for these outputs.

**Note:** When you switch between "Voltage" and "Current", DC output is turned off as a precaution. You have to turn it on again deliberately.

Remote command: SOURce:VOLTage:POWer<i>:LEVel:MODE on page 435

# Defining the output level - Configuring the DC power output

For all three outputs, you can control the voltage that should be output to supply the DUT or other devices. The supported voltage range is different for each output (see data sheet for details).

In addition to the hardware limits regarding the range of output values, you can also define soft limits. These soft limits limit the output to a range that suits your needs. They thus help you to avoid accidentally defining an output level that is too high for the DUT you are testing.

Note that when you change the output voltage while a measurement is running, this measurement is aborted and restarted.

# Controlling the supply current for the $V_{supply}$ output

For the supply voltage output ( $V_{supply}$ ), you can select whether you want to control the output in terms of current or voltage ( $\rightarrow$  Output Type).

If you select output type "Voltage", you can define the output level and limits in terms of voltage (the current is adjusted, if necessary).

If you select output type "Current", you can define the output level and limits in terms of current (the voltage is adjusted, if necessary). In that case, the range defining the soft limits are also defined in terms of current.

In addition, you can define the maximum output current (or voltage) that is supplied in the "Max Curr / Volt" field.

For the other two outputs ( $V_{tune}$  and  $V_{aux}$ ), the maximum current that can be drawn by the DUT is fixed to the value supported by the hardware. The "Max Curr / Volt" information is read-only information for these two outputs.

#### Remote command:

Level V<sub>supply</sub>: SOURce:VOLTage:POWer<i>:LEVel:AMPLitude on page 433 Level V<sub>tune</sub>: SOURce:VOLTage:CONTrol<i>:LEVel:AMPLitude on page 432 Level V<sub>aux</sub>: SOURce:VOLTage:AUX:LEVel:AMPLitude on page 430 Limits V<sub>supply</sub>: SOURce:VOLTage:POWer<i>:LEVel:LIMit:LOW on page 434 / SOURce:VOLTage:POWer<i>:LEVel:LIMit:HIGH on page 434 Limits V<sub>tune</sub>: SOURce:VOLTage:CONTrol<i>:LEVel:LIMit:LOW on page 432 / SOURce:VOLTage:CONTrol<i>:LEVel:LIMit:HIGH on page 432 Limits V<sub>aux</sub>: SOURce:VOLTage:AUX:LEVel:LIMit:LOW on page 430 / SOURce: VOLTage:AUX:LEVel:LIMit:HIGH on page 430 Max. V / A: SOURce:VOLTage:POWer<i>:LIMit:HIGH on page 435

### Reading the actual output levels — Configuring the DC power output

The actual output levels (voltage and current) for each output source is displayed in the "Results" part of the dialog box.

When the output levels are as you have defined them, the font of these result values is green. If the voltage or current that is output differs from the values that you have defined, the font turns red.

This may be the case , for example. If the DUT draws too much current, and the voltage required for that current would exceed the limits you have defined.

Remote command:

Voltage: SOURce:VOLTage:SEQuence:RESult? on page 436
Current: SOURce:CURRent:SEQuence:RESult? on page 429
Power: SOURce:POWer:SEQuence:RESult? on page 430

# 10.6.2 Signal Source Configuration

Access (all settings): "Overview" > "Output" > "Output" > "Signal Source"

Access (most relevant signal source settings): 📟 (in the toolbar)

Access (state of the signal source): • (in the toolbar)

The "Signal Source" settings allow you to configure the internal signal source output.

You can use the signal source to feed a signal into the DUT. The signal is either a sine wave or a pulse. Its frequency and level of that signal are variable.

In the pulse measurement application, the output signal is always a pulse.

The output is available when you have installed the optional hardware component.

# NOTICE

#### Risk of damage to the instrument or DUT

Make sure that the DUT can handle the signal power that you output via the signal source. Power levels that are too high might damage the DUT.

Make also sure that the reflected power does not exceed 30 dBm. Power levels higher than that might damage or destroy the signal source output.



#### Restrictions and availability of the signal source

The signal source is available for (additive) phase noise, pulsed (additive) noise and transient measurements.

If you are using the signal source for normal phase noise and pulsed phase noise measurements, cross-correlation is no longer possible. The R&S FSWP shows a message that cross-correlation has been turned off if you turn on the signal source in these measurements. In addition, you can only use one external mixer (instead of two) if you are using the signal source.

Input Source	Output	
DC Config	Source Power	
Signal Source	Channel Coupling Source Frequency	
Output	Level	0.0 dBm
	Pulse Modulation	
	Pulse	
	Period	2.0 µs
	Width	1.0 µs
	Trigger 1 Output	off Low T)High I

The remote commands required to configure the signal source output are described in Chapter 15.6.2.2, "Signal Source", on page 437.

Functions to configure the signal source output described elsewhere:

"Coupling the output configuration across measurement channels" on page 166

Signal source state	170
Signal source frequency	
Signal source level	

Pulse modulation state	. 170
Bypassing the DUT	. 170
Pulse characteristics	. 171

#### Signal source state

A signal from the signal source is supplied only if you turn it on with "Source Power". Otherwise, the signal source output remains inactive.

Remote command: SOURce:GENerator[:STATe] on page 440

#### Signal source frequency

Select the "Frequency" of the signal generated at the signal source output and the "Frequency Stepsize".

The frequency stepsize defines the stepsize with which the signal frequency is changed.

Remote command:

Frequency: SOURce:GENerator:FREQuency on page 438
Stepsize: SOURce:GENerator:FREQuency:STEP on page 438

#### Signal source level

Selects the "Level" of the output signal.

When you define the signal level, make sure that your DUT can handle the power that you have defined. Otherwise, the DUT can be damaged.

For low phase noise boards with material number 1331.6439.xx, you can define an output level in 0.1 dB steps. For boards with a different material number, the stepsize is 1 dB.

You can check the material number of the low phase noise board in the hardware information dialog box (column "order #, see Chapter 13.4.1, "Hardware Information", on page 296).

Remote command: SOURce:GENerator:LEVel on page 438

#### Pulse modulation state

Turns the internal "Pulse Modulation" on and off.

When "Pulse Modulation" is on, the R&S FSWP generates a pulse with the defined pulse characteristics on the signal source output.

When "Pulse Modulation" is off, the R&S FSWP generates a continuous wave signal on the signal source output (a pulse can still be output on the trigger 1 output, however, for example to control an external pulse modulator).

Remote command: Pulse modulation: SOURce:GENerator:MODulation on page 439

#### Bypassing the DUT

The "DUT Bypass" feature measures the noise of the R&S FSWP.

This can come in handy when measuring the additive noise, and you would like to draw a trace that shows the contribution of the R&S FSWP to the overall noise characteristics.

The feature works for additive noise and pulsed additive noise measurements. It is also available in the optional applications, Spectrum application, the I/Q Analyzer etc.

Remote command:

SOURce: GENerator: DUTBypass on page 437

# **Pulse characteristics**

The signal source hardware allows you to generate a pulse when you perform pulsed measurements.

The pulse with the defined characteristics is generated internally when you turn on the Pulse Modulation feature.

• "Period"

The pulse period defines the distance between two consecutive pulses (off time of the pulse).

"Width"


The pulse width defines the length of the pulse (on time of the pulse). **Note**: Pulse period and width apply to the pulse that is output at the signal source as well as the pulse that is output at the trigger 1 output.

• "Trigger 1 Output"


Selects the pulse type sent to the trigger output.

You can use the signal on the trigger 1 output to control an external pulse modulator, for example.

- "Off": Provides no signal at the trigger output.
- "High": Provides a (high active) pulse with the defined width and period at the trigger output.



 "Low": Provides a (low active) pulse with the defined width and period at the trigger output.



Note that the pulse at the trigger output is generated even when the "Pulse Modulation" feature is turned off.

Remote command:

Period: SOURce:GENerator:PULSe:PERiod on page 439
Width: SOURce:GENerator:PULSe:WIDTh on page 440
Trigger Output: SOURce:GENerator:PULSe:TRIGger:OUTPut on page 439

# 10.6.3 Miscellaneous Output

Access: "Overview" > "Output" > "Output"

The "General Output" dialog box contains settings that allow you to configure various outputs available on the R&S FSWP.

Input Source	e Output
DC Config	
Signal Source	
Output	

The remote commands required to configure miscellaneous output are described in Chapter 15.6.2.3, "Miscellaneous Output", on page 441.

# 10.6.3.1 Output for Noise Sources

The R&S FSWP provides a connector ([NOISE SOURCE CONTROL]) with a voltage supply for an external noise source. By switching the supply voltage for an external noise source on or off in the firmware, you can activate or deactive the device as required.

External noise sources are useful when you are measuring power levels that fall below the noise floor of the R&S FSWP itself, for example when measuring the noise level of an amplifier.

In this case, you can first connect an external noise source (whose noise power level is known in advance) to the R&S FSWP and measure the total noise power. From this value you can determine the noise power of the R&S FSWP. Then when you measure the power level of the actual DUT, you can deduct the known noise level from the total power to obtain the power level of the DUT.

The noise source is controlled in the "Output" settings, see "Noise Source Control" on page 172

# 10.6.3.2 Output Configuration

# 

# Noise Source Control

The R&S FSWP provides a connector ("NOISE SOURCE CONTROL") with a 28 V voltage supply for an external noise source. By switching the supply voltage for an external noise source on or off in the firmware, you can enable or disable the device as required.

External noise sources are useful when you are measuring power levels that fall below the noise floor of the R&S FSWP itself, for example when measuring the noise level of an amplifier.

In this case, you can first connect an external noise source (whose noise power level is known in advance) to the R&S FSWP and measure the total noise power. From this value you can determine the noise power of the R&S FSWP. Then when you measure the power level of the actual DUT, you can deduct the known noise level from the total power to obtain the power level of the DUT.

Remote command:

DIAGnostic:SERVice:NSOurce on page 441

# 10.7 Pulsed Phase Noise and Pulsed Additive Noise Configuration

Access (measurement): "Overview" > "Select Measurement" > "Pulsed Phase Noise"

Access (measurement): "Overview" > "Select Measurement" > "Pulsed Additive Noise"

Access (settings): "Overview" > "Pulse"

When you equip the R&S FSWP with the optional pulsed phase noise measurement application, the R&S FSWP provides functionality to measure the phase noise and additive noise of pulsed signals.

This measurement mode only measures the noise during the time the pulse is transmitted, like a gated measurement does in a spectrum analyzer. The measurement only works when the application knows the pulse characteristics, so it can open up a gate during which it records and analyzes the signal data. The time when the gate opens is either controlled by an internal IF power trigger or an external pulse gate.

If necessary, the application is able to detect a pulse in the frequency spectrum. When a pulse has been found, it can also detect pulse characteristics automatically.

Of course, you can omit the signal search and automatic pulse characterisation and instead define these parameters manually.

Meas Time 1.0 ms	1	Magnitude		1 AP Chw
Pretrigger 100.0 µs				
Pulse Settings		F 50.0 MHz Sate Settinge	1001 pts	100.0 µs/
Pulse Detection	Auto Detect On	Gate Type	evel Edge Dtf Gate Delay	500.0 ns
Ruise Rep Interval		Gate Level -1	0.0 dBm Gate Length	1.0 µs

The remote commands required to configure pulses are described in Chapter 15.6.7, "Pulsed Phase Noise Configuration", on page 474.

#### Pulsed Phase Noise and Pulsed Additive Noise Configuration

Selecting the source for pulse gating1	74
Selecting the pulse detection mode	
Defining the pulse repetition interval1	75
Defining the gate characteristics	
L Selecting the gate type1	
L Defining the shape of the gate1	

#### Defining preview diagram characteristics

The application provides some feature that scale the "Preview" diagram shown in the dialog box.

The "Measurement Time" defines scale of the x-axis.

The "Pretrigger" defines an offset from the origin of the x-axis.

Both parameters have no effect on the actual measurement of the noise characteristics of the pulse.

Remote command: not supported

# Selecting the source for pulse gating

You can select the source for pulse gating.

When you select the "IF Power" source, the pulse gate is controlled by an internal IF power pulse gate. The R&S FSWP opens the gate when the signal meets or exceeds a certain IF power level. This is the default source.

When you select "Ext Trigger 1", the pulse gate is controlled by an external pulse gate. This requires an external source connected to the trigger 1 connector on the front panel of the R&S FSWP.

When you are using an external pulse gate, the following restrictions apply.

• Using an external pulse gate is only possible with a phase noise digitizer board revision 4.0 or higher.

You can check the version that you have in the hardware info dialog box.

- Defining a gate level is not possible.
- The pulse modulation in the signal source settings is always turned off.
- The trigger 1 output must be turned off.

Remote command:

[SENSe:]SWEep:PULSe:GATE on page 476

# Selecting the pulse detection mode

The easiest way to set up pulsed phase noise measurements is to let the application detect the pulse characteristics and configure the measurement accordingly. This is especially useful when you are measuring an unknown pulse.

After the pulse has been found, the application configures the following parameters:

- Pulse repetition interval
- Gate level
- Gate delay
- Gate length (for Gate Type = Edge)

You can also start the detection of the pulse characteristics deliberately with the "Auto Detect Once" feature.

When you already know the pulse characteristics, you can also configure the measurement manually by selecting "Manual" mode and entering the values as required.

Remote command:

[SENSe:]SWEep:PULSe:DETection on page 475

#### Defining the pulse repetition interval

The "Pulse Repetition Interval" defines the time between two consecutive pulse edges of the same polarity in seconds (requires at least two measured pulses). It thus defines the (statistical) frequency with which a pulse is transmitted.

In the default state, when automatic pulse detection is on, the application automatically determines the pulse repetition interval. If necessary, and you already know that value, you can also enter it directly in the corresponding input field.

In the preview diagram, the pulse repetition interval is indicated by a turquoise bar.

Remote command:

[SENSe:]SWEep:PULSe:PRI on page 476

#### Defining the gate characteristics

Gate characteristics define the type and shape of the gate.

Data is only acquired when the gate is active during the ON time of a pulse. Data transmitted during the OFF time of the pulse is ignored and thus not considered in the noise analysis. This method makes sure that the broadband noise that is present between pulses does not affect the noise results.

### Selecting the gate type $\leftarrow$ Defining the gate characteristics

The phase noise application supports several "Gate Types".

Level

The gate opens and starts the measurement when the signal exceeds a certain level, and stops when the level drops below that value.

Edge

The gate opens and starts the measurement when the signal exceeds a certain level, and stops after a certain time defined by the gate length.

• Off

No gate is used during the measurement, and the data during the OFF time of the pulse is also recorded and analyzed.

You can turn off the gate, for example, when you expect only low noise with little effect on the measurement results during the OFF time of the pulse.

Note that a lowpass filter that filters fundamentals and makes sure that only the pulse is analyzed is still active when you turn off the gate.

The gate mode is always "Off" in case pulse modulation is on.

Note that even when automatic pulse detection is on, you still can select the gate type, if necessary.

Remote command:

Gate type: [SENSe:]SWEep:EGATe:TYPE on page 475

#### Defining the shape of the gate ← Defining the gate characteristics

The shape of the gate is defined by several parameters that is visualized in the "Preview" diagram. In the default state, when automatic pulse detection is on, the gate characteristics are determined based on the pulse characteristics. In that case, changes here not necessary.

The "Gate Level" defines the signal level that opens the gate. As long as the signal level is below the gate level, no data is recorded. When the signal level rises above the gate level, the measurement starts. For the "Gate Type: Level", the gate level also defines the moment when the gate closes, and data acquisition stops.

In the preview diagram, the gate level is indicated by a red horizontal line. A label also indicates the currently defined gate level.

The "Gate Delay", defines a time offset between the moment the level rises above the gate level (= the beginning of the pulse) and the actual start of the measurement. When you define a gate delay, the first few measurement points after the gate opens are not considered in the measurement results.

In the preview diagram, the gate delay is indicated by a blue bar. The actual starting point of data acquisition is indicated by a red vertical line in the preview diagram.

The "Gate Length" defines the time period that the gate is open. It is closed when the time define by the gate length has elapsed. The gate length is only available for "Gate Type: Edge".

In the preview diagram, the gate length is indicated by a magenta colored bar. The end of the gate in that case is indicated by second red vertical line.



#### Remote command:

Level: [SENSe:]SWEep:EGATe:LEVel on page 475 Delay: [SENSe:]SWEep:EGATe:HOLDoff on page 474 Length: [SENSe:]SWEep:EGATe:LENGth on page 474

# 10.8 VCO Characterization Configuration

Access (measurement): "Overview" > "Select Measurement" > "VCO Characterization"

The VCO characterization measurement determines the characteristics of a DUT when you apply different input voltages or current (the tuning range or sweep range). The DUT can be, for example, a voltage controlled oscillator (VCO) or a YIG oscillator whose characteristic are a function of the applied current. The measurement provides results for characteristics like the oscillation frequency at a certain input voltage, the output power or the sensitivity of the DUT.

VCO measurements basically provide the following measurements types.

- Normal VCO measurements
   In a typical VCO measurement, the "Sweep Source" is connected to the tune port
   of the DUT. The "Fix Source" is connected to the supply port of the DUT.
- Pushing measurements Pushing measurements are possible when you connect the "Sweep Source" to the supply port of the DUT and the "Fix Source" to the tune port of the DUT. A pushing measurement typically measures the influence of a swept supply source on the DUT characteristics.

You can use all available DC sources as a sweep source (tuning source) or fix source ( $V_{supply}$ ,  $V_{tune}$  and  $V_{aux}$ ).

Most of the functionality for VCO characterization is the same as in the phase noise measurement, differences and additional functionality is described in this section of the documentation.

Refer to the following topics for more information about equivalent functionality.

- Input configuration: Chapter 10.2, "Input Source", on page 125
- Amplitude configuration and diagram scale: Chapter 10.3, "Level Characteristics", on page 142
- DC source configuration: Chapter 10.6.1, "DC Source Configuration", on page 165
- Measurement configuration: Chapter 9.2, "Performing Measurements", on page 108
- Limit line configuration: Chapter 11.5, "Limit Lines", on page 232
- Marker configuration: Chapter 11.4, "Markers", on page 223

Notable differences are the measurement configuration itself and the trace configuration, as described in this topic.

# **10.8.1 Sweep Configuration**

Access: "Overview" > "Sweep Config"

The "Sweep Config" dialog box contains two main features: DC source configuration and the sweep configuration (which corresponds to the tuning configuration).

DC Power (Global)			
Sweep Source	VTune VAux VSupply		
Fix Source	VTune VAux VSupply		
DC Source VTune			
State	On Off	Start	0.0 V
Mode		Stop	0.0 V
Value	0.0 V	Meas Points	10
Minimum	-10.0 V	Settling Time / Meas Point	1.0 ms
Maximum	28.0 V	Frequency Resolution	1.0 kHz

# **DC** source configuration

The functionality to configure the DC sources is basically the same as in the "DC Config" dialog box. The main difference is that the dialog box does not show all available DC sources. Instead, you have to select the DC source you would like to use.

- "Sweep Source"
   Selects the DC source that tunes the DUT. Voltage or current change supplied by the sweep source on each measurement point.
   Remote command:
   VCO characterization: CONFigure: VCO: SWEep: SOURce on page 479
   Spot noise vs tune: CONFigure: SNTune: SWEep: SOURce on page 481
- "Fix Source" Selects the DC source that is considered in the Current / Voltage result display. Current or voltage supplied by the fix source remains on a fix value during the measurement. Remote command: CONFigure:VC0:FIX:SOURce on page 477

For the other features, refer to the following topics.

- "Turning the DC output on and off" on page 166
- "Turning the output on and off" on page 167
- "Selecting the output type (Vsupply only)" on page 167
- "Defining the output level" on page 167

### Sweep settings

The sweep settings define the tuning properties. They control the output of the selected DC source over the course of a measurement: which voltage or current is applied for each measurement, the sweep range and the measurement time for each measurement point.

You can define sweep settings for each DC source individually.

Defining the sweep range	178
Defining the settling time	
Selecting the frequency resolution	

#### Defining the sweep range

The R&S FSWP characterizes a DUT by applying a series of (tuning) voltages or currents to the DUT. Each voltage or current is a measurement point. The number of measurements performed during a VCO characterization therefore depends on the number of measurement points.

You can define the first and last tuning value applied to the DUT with the "Start" and "Stop" values. Within this sweep range, the voltages or currents applied to the DUT depend on the number of "Meas Points". The measurement points not only define the number of measurements, but also the distance between voltages or currents.

# Example:

The start and stop values are 0 V and 5 V respectively. The number of measurement points is 10.

This means that a measurement is performed on every 0.5 V of voltage:

0 V, 0.5 V, 1 V, 1.5 V, etc.

# Remote command:

Start (VCO Characteristics): CONFigure:VCO:SWEep:STARt on page 479
Stop (VCO Characteristics): CONFigure:VCO:SWEep:STOP on page 479
Points (VCO Characteristics): CONFigure:VCO:SWEep:POINts on page 478
Start (Spot Noise vs Tune): CONFigure:SNTune:SWEep:STARt on page 481
Stop (Spot Noise vs Tune): CONFigure:SNTune:SWEep:STOP on page 481
Points (Spot Noise vs Tune): CONFigure:SNTune:SWEep:POINts on page 480

# Defining the settling time

When you apply a different tuning voltage (or current) to the DUT, it usually needs some time before its characteristics become stable. This time period is the settling time.

- The "Settling Time / Meas Point" property defines for how long you allow the DUT to settle, before the characteristics for each applied voltage or current are measured.
- The "Initial Settling Time" property defines for how long you allow the DUT to settle, before the characteristics of the first applied voltage or current of the tuning range are measured.

Remote command:

Settling time (VCO Characterization): CONFigure:VCO:SWEep:DELay[:POINt] on page 478

Settling time (Spot Noise vs Tune): CONFigure: SNTune: SWEep: DELay[:POINt] on page 480

Initial settling time (VCO characterization): CONFigure:VCO:SWEep:DELay: INITial on page 477

Initial settling time (Spot Noise vs Tune): CONFigure: SNTune: SWEep: DELay: INITial on page 480

#### Selecting the frequency resolution

The "Frequency Resolution" defines the accuracy with which the frequency of the DUT is measured on each measurement point.

Note that only discrete values for the frequency resolution are supported. If you enter a frequency resolution that is not supported, the next available frequency resolution is selected. For example, if you enter 200 Hz, which is not supported, the R&S FSWP selects 1 kHz instead.

#### Remote command:

CONFigure:VCO:SWEep:FCOunter:RESolution on page 478

# 10.8.2 Trace Configuration

In the VCO characterization measurement, you can select the Trace Mode for each trace.

# Traces in the Harmonic Power result display

In the Harmonic Power result display, each trace represents the power of one harmonic.

# **10.9 Spot Noise vs Tune Configuration**

Access (measurement): "Overview" > "Select Measurement" > "Spot Noise vs Tune"

The spot noise vs tune measurement determines the spot noise characteristics of a DUT when you apply different input voltages or current (the tuning range or sweep range). The DUT can be, for example, a voltage controlled oscillator (VCO) or a YIG oscillator whose characteristic are a function of the applied current. The measurement provides results for phase noise and AM noise characteristics at a certain input voltage or current.

You can use all available DC sources as a sweep source (tuning source) or fix source ( $V_{supply}$ ,  $V_{tune}$  and  $V_{aux}$ ).

Most of the functionality for spot noise vs tune measurements is the same as in the phase noise measurement. Differences and additional functionality are described in this section of the documentation.

Refer to the following topics for more information about equivalent functionality.

- Input configuration: Chapter 10.2, "Input Source", on page 125
- Amplitude configuration and diagram scale: Chapter 10.3, "Level Characteristics", on page 142
- Frequency configuration: Chapter 10.4, "Frequency", on page 146
- Noise configuration: Chapter 10.5.3, "Noise Configuration", on page 152
- Spot noise configuration: Chapter 10.5.5, "Spot Noise Information", on page 161
- Sweep configuration: Chapter 10.8.1, "Sweep Configuration", on page 177 Note: The "Fix Source" and "Frequency Resolution" settings are not available in the spot noise vs tune measurement.
- DC source configuration: Chapter 10.6.1, "DC Source Configuration", on page 165
- Measurement configuration: Chapter 9.2, "Performing Measurements", on page 108
- Limit line configuration: Chapter 11.5, "Limit Lines", on page 232
- Marker configuration: Chapter 11.4, "Markers", on page 223

The one notable difference is the trace configuration, as described in this topic.

Trace Configuration......181

# 10.9.1 Trace Configuration

Access: "Overview" > "Analysis" > "Traces" > "Traces"

Trace configuration is similar to that of other measurements with the following distinctive features.

- You can select the Trace Mode for each trace.
- Each trace shows the noise characteristics at a certain spot noise offset over the tuning range. You can customize the offset frequencies that a trace shows in the "Spot Noise Offset" input fields.

By default, for example, trace 1 shows the noise measured for each tuning voltage on a 1 kHz frequency offset.

Trace 2 shows the noise measured at each tuning voltage on a 10 kHz offset. etc.

If you change the spot noise offsets for a trace, you can restore the default values easily with the "Set Decade Offsets" feature.

Remote command:

See Chapter 15.6.6.3, "Spot Noise Configuration", on page 465.

 Trace smoothing and spur removal have the same effect as in other measurement, but can only be set globally for all traces instead of for each trace separately. Remote command:

See Chapter 15.6.9.2, "Trace Configuration", on page 482.

For all other trace functionality, refer to the following topics.

- Chapter 11.3.3, "Trace Export and Import", on page 209
- Chapter 11.3.4, "Copying Traces", on page 214
- Chapter 11.3.6, "Trace Labels", on page 215
- Trace mathematics are unavailable for spot noise vs tune measurements.

# **10.10 PN Transient Analysis Configuration**

Access (measurement): "Overview" > "Select Measurement" > "PN Transient Analysis"

Access (settings): "Overview"

The PN transient analysis measurement determines the frequency and phase characteristics of a signal over time. It is thus an appropriate measurement to analyze the transient response of a DUT and see how long it takes until the DUT reaches a stable state.

Parts of the functionality for transient analysis are the same as in the phase noise measurement, differences and additional functionality is described in this section of the documentation.

Refer to the following topics for more information about equivalent functionality.

- Input configuration: Chapter 10.2, "Input Source", on page 125
- DC source configuration: Chapter 10.6.1, "DC Source Configuration", on page 165

- Measurement configuration: Chapter 9.2, "Performing Measurements", on page 108
- Limit line configuration: Chapter 11.5, "Limit Lines", on page 232
- Marker configuration: Chapter 11.4, "Markers", on page 223

•	Frequency Configuration	.182
	Trigger Configuration	
	Data Acquisition	
	Amplitude Configuration	
	Diagram Scale	
	Settling Time	
	Frequency Deviation	
	Trace Configuration	
	Marker Configuration	
•	Limit Lines	. 192

# 10.10.1 Frequency Configuration

Access: "Overview" > "Frequency"

The frequency settings define the frequency characteristics of the signal and the amount of frequency information that is displayed.

Frequence	cy
Frequency	Range
Mode	Wide Narrow
Range	256 MHz 8 GHz
Frequency	r/Span
Center	4.128 GHz
Span	7.744 GHz
Start	256.0 MHz
Stop	8.0 GHz
Center Fre	equency Stepsize
Stepsize	0.1 * Span 🗘
X-Factor	

The remote commands required to configure the frequency are described in Chapter 15.6.10.1, "Frequency Configuration", on page 484.

Selecting the measurement mode	182
Defining the frequency range of the measurement	183
Defining a frequency step size	183

### Selecting the measurement mode

Transient analysis has two measurement modes, wideband and narrowband mode. The measurement mode selects the signal path that is used to measure the signal.

• Wideband mode ("Wide")

Select the wideband mode for measurements with a span > 40 MHz. Wideband mode only works in the frequency range between 256 MHz and 8 GHz. Thus, the maximum span is 7.774 GHz. Supported center frequencies are in the range between 276 MHz and 7.980 GHz. Narrowband mode ("Narrow") Select the narrowband mode for measurements with a span < 40 MHz. Narrowband mode works over the complete frequency range supported by your R&S FSWP.

If you select a span > 40 MHz in the specified frequency range, the R&S FSWP automatically selects the wideband mode.

If you select a span < 40 MHz, the R&S FSWP automatically selects the narrowband mode. The R&S FSWP also selects the narrowband mode automatically if you define a frequency that is outside of the frequency range supported by the wideband mode and reduces the span (for example a center frequency of 100 MHz reduces the span to 40 MHz).

Remote command: CONFigure:TRANsient:MODE on page 485

### Defining the frequency range of the measurement

The frequency parameters define the scale of the y-axis of the frequency result display.

- The bottom of the diagram corresponds to the "Start Frequency".
- The top of the diagram corresponds to the "Stop Frequency".
- The middle of the diagram corresponds to the "Center Frequency". The center frequency is the frequency of the signal you are measuring.
- The complete range of the y-axis corresponds to the selected span.

Note that changing any one of the frequency parameters can change the measurement mode you have selected.

Remote command:

Center frequency: [SENSe:]FREQuency:CENTer on page 452 Start frequency: [SENSe:]FREQuency:STARt on page 452 Stop frequency: [SENSe:]FREQuency:STOP on page 453 Span: [SENSe:]FREQuency:SPAN on page 487

### Defining a frequency step size

Defines the step size by which the center frequency is increased or decreased when you press the arrow keys.

The "Stepsize" is a function of the span.

- "0.1 \* Span": Changes the center frequency by 10 % of the current span.
- "X \* Span": Changes the center frequency by custom percentage of the current span. If you select this, you can define the percentage in the "X-Factor" input field.
- "Manual": Changes the center frequency by a custom value. If you select this, you can define the step size in Hz in the "Value" field.


Remote command:

Stepsize: [SENSe:]FREQuency:CENTer:STEP:LINK on page 486 Factor: [SENSe:]FREQuency:CENTer:STEP:LINK:FACTor on page 486 Manual: [SENSe:]FREQuency:CENTer:STEP on page 485

# 10.10.2 Trigger Configuration

Access: "Overview" > "Trigger"

Transient measurement support trigger functionality that allows you to control when a measurement begins.



The remote commands required to configure trigger are described in Chapter 15.6.10.4, "Trigger Configuration", on page 488.

Selecting the trigger source	184
Defining the trigger level and frequency	185
Trigger Offset	
Defining a trigger hysteresis	
Trigger Holdoff	
Defining a trigger slope	
Defining a trigger drop-out time	

### Selecting the trigger source

The "Trigger Source" selects the type of event whose condition must be met to start data acquisition.

The R&S FSWP supports the following trigger sources.

- "Free Run" No trigger source is considered. You can start the measurement manually any time and stop it as required.
- "Ext <x>"

A measurement starts when the TTL signal fed into the specified input connector meets or exceeds the specified trigger level.

"Ext Trigger 1" and "Ext Trigger 2" select the trigger connector to which you have connected the TTL signal. Note that the trigger connector must be configured as a trigger input.

• "Frequency"

A measurement starts when measured signal exceeds or falls below a specified frequency.

The frequency trigger available for transient measurements is an online trigger. An online trigger responds to a trigger event as soon as this event occurs while it is capturing data (a live trigger, so to speak). An offline trigger, on the other hand, first captures data, and looks if it can find a trigger event in that data.

### "I/Q Power"

A measurement starts when the R&S FSWP detects a rise or fall of the signal level within the demodulation bandwidth (span).

This trigger source is only available for narrow measurement mode.

Remote command:

TRIGger[:SEQuence]:SOURce on page 491

### Defining the trigger level and frequency

Trigger source other than the free run source initiate measurements on a certain condition.

For an external trigger, the condition is a "Level" value. The measurement starts when the trigger signal meets or exceeds that level.

For a frequency trigger, the condition is a "Frequency" value. The measurement starts when the input signal meets or exceeds that frequency.

Remote command:

Trigger level: TRIGger[:SEQuence]:LEVel[:EXTernal<1|2>] on page 490
Trigger frequency: TRIGger[:SEQuence]:FREQuency on page 489

### **Trigger Offset**

Defines the time offset between the trigger event and the start of the measurement.

Offset > 0:	Start of the measurement is delayed
Offset < 0:	Measurement starts earlier (pretrigger)

Remote command:

TRIGger[:SEQuence]:HOLDoff[:TIME] on page 490

### Defining a trigger hysteresis

The trigger "Hysteresis" is the distance in Hz to the trigger frequency that the trigger source must exceed before a trigger event occurs. Setting a hysteresis avoids unwanted trigger events caused by frequency oscillation around the trigger frequency.

The trigger hysteresis is available for the frequency trigger.

Remote command:

TRIGger[:SEQuence]:FREQuency:HYSTeresis on page 489

### **Trigger Holdoff**

Defines the minimum time (in seconds) that must pass between two trigger events. Trigger events that occur during the holdoff time are ignored.

Remote command:

TRIGger[:SEQuence]:IFPower:HOLDoff on page 490

### Defining a trigger slope

The trigger slope defines whether triggering occurs when the signal level or frequency rises to the trigger level or frequency or falls down to it.

Remote command: TRIGger[:SEQuence]:SLOPe on page 491

### Defining a trigger drop-out time

The drop-out time is the minimum time period that must have passed between two consecutive trigger events without initiating another measurement after the first trigger event has occurred and initiated a measurement.


For the frequency trigger, the drop-out time avoids the triggering of another measurement just because the frequency of the DUT is not yet stable.

### Example:

The trigger event is a certain frequency on falling slope.

The first trigger event that initiates the measurement occurs. After some time, the trigger frequency again falls below the trigger frequency - this happens several times, until the DUT is stable.

Without a drop-out time, the R&S FSWP would start a measurement each time the frequency falls below the trigger frequency. With a drop-out time, however, only the first trigger event initiates a measurement. The other trigger events after the first are ignored, because the undesired events are within the drop-out time.



For the external trigger, the drop-out time defines a minimum duration that the input signal must stay below the trigger level before triggering again. The dropout time helps you stabilize triggering when the analyzer is triggering on undesired events.

Remote command: TRIGger[:SEQuence]:DTIMe on page 489

# 10.10.3 Data Acquisition

Access: "Overview" > "Data Acquisition"

The data acquisition settings configure the signal capture. The measurement time defines the scale of the x-axis.



The remote commands required to configure the data acquisition are described in Chapter 15.6.10.3, "Data Acquisition", on page 487.

Functions in the "Data Acquisition" dialog box described elsewhere:

- Sweep count: "Sweep/Average Count " on page 157
- Continuous sweep: " Continuous Sweep / Run Cont " on page 110
- Single sweep: "Single Sweep / Run Single " on page 109
- Continue single sweep: "Continue Single Sweep " on page 110

Defining the measurement time	. 187
Defining the video bandwidth	. 187

### Defining the measurement time

The measurement time defines for how long the R&S FSWP measures the transient response.

The R&S FSWP always matches the scale of the x-axis of the result displays to the measurement time.

Remote command: [SENSe:]SWEep:TIME on page 459

### Defining the video bandwidth

The video filter is a lowpass filter that removes the higher frequency parts of the voltage from the signal (for example harmonics). This process makes the trace smoother and makes it easier to read out results.

You can set the bandwidth of this filter, the video bandwidth or VBW, automatically or manually ("VBW Mode").

In automatic VBW mode, the R&S FSWP automatically selects an appropriate video bandwidth for the signal you measure.

In manual VBW mode, you can define the video bandwidth you like in the "VBW" field. Remote command:

Mode: [SENSe:]BWIDth:VIDeo:AUTO on page 488 VBW: [SENSe:]BWIDth:VIDeo on page 488

# 10.10.4 Amplitude Configuration

Access: "Overview" > "Amplitude / Scaling" > "Amplitude"

The amplitude settings configure the characteristics of the input signal.

Amplitude Sca	ale
Reference Level	
Value	0.0 dBm
RF Attenuation	
Mode	Auto Manual
Value	0.0 dB
Input Settings	
Input Coupling	

The remote commands required to configure the amplitude are described in Chapter 15.6.10.2, "Amplitude Configuration", on page 487.

Functions in the "Amplitude" dialog box described elsewhere:

- RF attenuation: "Attenuating the signal" on page 144
- Input coupling: "Input Coupling " on page 126

### Defining a reference level

The reference level is the expected level of the signal you are measuring.

Because the hardware of the R&S FSWP is adapted according to this value, it is recommended that you set the reference level close above the expected maximum signal level.

The reference level is a value between 0 dB, and 30 dBm and is always coupled to the attenuation. When you turn on auto attenuation, the R&S FSWP selects an attenuation that results in a nominal signal level of (about) 0 dBm to protect the input mixer.

Remote command: INPut<1|2>:RLEVel on page 487

# 10.10.5 Diagram Scale

Access: "Overview" > "Amplitude / Scaling" > "Scale"

Depending on the result display you have selected (frequency or phase), you can adjust the scale of the y-axis as required.

Y Axis Scale Center		Y Axis Smile	
Center	11000		
	.128 GHz	Mode	Auto Manual
Span 7	.744 GH2	AF Coupling	AC DC
Start 2	56,0 MHz	Dev Per Division	is such
Stop 8	.0 GHz	Ref Position	
Mode	Absolute Relative	Ref Value	
Center Frequ	ency Stepsize		
Stepsize 0	,1 * Span 🕴		
1	6	Y Axis Unit	rad

The remote commands required to configure the diagram axes are described in Chapter 15.6.10.5, "Y-Axis Scale", on page 491.

Scaling the y-axis of the frequency diagram	
Scaling the y-axis of the phase diagram	
Selecting the AF coupling mode	
Positioning the zero-phase	
Positioning the zero-phase	

### Scaling the y-axis of the frequency diagram

The y-axis of the frequency result display always corresponds to the frequency parameters you have defined for the measurement.

The settings of the "Scale" dialog box are linked to the settings in the "Frequency" dialog box. If you change them in one place, they are automatically adjusted in the other.

In addition, you can select how the frequency is displayed on the y-axis.

- "Absolute": Frequencies are displayed as absolute frequencies.
- "Relative": Frequencies are displayed as relative frequencies that refer to the center frequency (offset to the center frequency).

In both cases, the center frequency is displayed in the middle of the y-axis.

Remote command:

Display mode: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:MODE on page 493

### Scaling the y-axis of the phase diagram

The phase result display supports various scaling possibilities for the y-axis, on which the phase is displayed.

The default "Y Axis Unit" for phase results is rad, but you can also select the unit degree, if you like.

By default, the R&S FSWP automatically scales the y-axis based on the measured signal.

When you select manual scaling "Mode", you can define the "Dev Per Division", the "Ref Position" and the "Ref Value" as required. In manual scaling mode, you can deliberately initiate a single automatic scaling with the "Auto Scale Once" feature.

The "Dev Per Division" defines the amount of phase deviation covered by each division of the diagram (the value multiplied by 10 is the complete value range of the y-axis). Note that the value defined per division refers to the default display of 10 divisions on the y-axis. If there are fewer divisions (for example because the window is reduced in height), the range per division is adjusted accordingly.

The "Ref Position" determines the position of the reference value for the phase deviation on the y-axis of the diagram. The position is a percentage of the diagram height with 100 % corresponding to the upper diagram border. The default setting is 50 % (diagram center).

The "Ref Value" determines the phase deviation displayed at the reference position.

Remote command:

Mode: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:AUTO on page 445
Deviation / division: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:PDIVision
on page 494
Reference position: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RPOSition
on page 494
Reference value: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RVALue
on page 495
Auto scale once: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:AUTO
on page 445
Unit: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:UNIT on page 495

### Selecting the AF coupling mode

The "AF Coupling" property controls the automatic correction of the phase and frequency offset of the input signal.

- "DC": The phase runs according to the existing frequency offset. In addition, the DC signal contains a phase offset of ±π.
- "AC": The frequency offset and phase offset are automatically corrected, i.e. the trace is always symmetric with respect to the zero line.

Remote command:

AF coupling: CONFigure: TRANsient [:WINDow<n>]: AF: COUPling on page 492

### Positioning the zero-phase

The R&S FSWP normalizes the last trace point in the phase diagram (right diagram border) to zero rad or degree.

You can also define a different position of the zero phase when you select manual "Zero Phase Ref Pos" mode. For manual zero-phase positioning, define any point on the x-axis (time value) as the zero-phase position, and the R&S FSWP adjusts the trace of the phase display accordingly.

Manual selection of the zero-phase position is available for DC AF coupling mode. Remote command:

Mode: CONFigure:TRANsient[:WINDow<n>]:AF:COUPling:RPOint:MODE
on page 492

Position: CONFigure:TRANsient[:WINDow<n>]:AF:COUPling:RPOint[:X]
on page 493

# 10.10.6 Settling Time

Access: "Overview" > "Frequency"

> "Settling Time"

The settling time calculation shows the time until the frequency of the DUT has reached a defined target corridor. The corridor is defined by the lower and the upper frequency limit. The calculated settling time is displayed in the channel bar.

Frequency	Trigger	Data Acquisition	Amplitude	Scale	Settling Time
Calculation					
State		On	Off		
Upper Frequ	ency Limit	8.0 GHz			
Lower Frequ	iency Limit	256.0 MHz			
Diagram		1: Frequency	•		
Trace		Trace1	-		

The remote commands required to configure the settling time calculation are described in Chapter 15.6.10.6, "Settling Time", on page 495.

# 10.10.7 Frequency Deviation

Access: "Overview" > "Frequency"

> "Frequency Deviation"

The "Frequency Deviation" result display shows the frequency deviation of the transient response of the DUT from an ideal linear behavior over time. The time frame is defined by the start and stop time.

### **PN Transient Analysis Configuration**

Frequency	Trigger	Data Acquisition	Amplitude	Scale	Settling Time	Frequency Deviation
Calculation						
State		On	Off			
Start		0.0 s				
Stop		1.0 ms				
Diagram		1: Frequency	•			
Trace		Trace1	-			

The frequency deviation result display is described in "Frequency Deviation" on page 121.

The remote commands required to configure the frequency deviation calculation are described in Chapter 15.6.10.7, "Frequency Deviation", on page 497.

# 10.10.8 Trace Configuration

Access: "Overview" > "Analysis" > "Traces"

You can display several traces in the transient analysis. Most trace functionality is the same as in the phase noise application. Trace settings specific to the transient analysis are described below, for more information about trace settings also available in other measurements, refer to the following topics.

	Mode		stance : Decay	
Frace 1	Clear Write	÷ 🔽	0.0 s	
Trace 2	Blank	÷ 🗹	0.0 s	
Trace 3	Blank	-	a.e.+	
Trace 4	Blank	•	10 c -	
Trace 5	Blank	•		
Trace 6	Blank	+	1.6×	
uick Confi				

The remote commands required to configure traces are described in Chapter 15.6.10.8, "Trace Configuration", on page 499.

Settings in the "Traces" dialog box described elsewhere:

- Select trace: "Trace 1 / Trace 2 / Trace 3 / Trace 4 / Trace 5 / Trace 6 " on page 207
- Trace mode: " Trace Mode " on page 207
- Trace export: Chapter 11.3.3, "Trace Export and Import", on page 209
- Trace copy: Chapter 11.3.4, "Copying Traces", on page 214
- Trace mathematics: Chapter 11.3.5, "Trace Math", on page 214 Note that trace mathematics are only available in the frequency diagram.

### PN Transient Analysis Configuration

- Trace labels: Chapter 11.3.6, "Trace Labels", on page 215
- Persistence: "Displaying persistence" on page 208

The remote commands required to configure traces are described in Chapter 15.6.10.8, "Trace Configuration", on page 499.

# 10.10.9 Marker Configuration

Access: "Overview" > "Analysis" > "Markers"

Marker functionality is the same as in other phase noise measurements. For more information, see Chapter 11.4, "Markers", on page 223.

# 10.10.10 Limit Lines

Access: "Overview" > "Analysis" > "Limit Lines"

You can use limit lines in the diagrams of the transient analysis. The basic principle of limit lines is the same as in other phase noise measurement only with a different scale (time on the x-axis and frequency or phase on the y-axis). Relative limits in the frequency diagram always refer to current center frequency you have defined for the transient measurement. Relative limits in the phase diagram always refer to the reference value.

For more information about configuring and using limit lines, see Chapter 11.5, "Limit Lines", on page 232.

# 11 Common Analysis and Display Functions

General methods and basic settings to display and analyze measurements, regardless of the operating mode, are described here. If you are using an application other than the phase noise application, be sure to check the documentation for that application. The settings can deviate from the common settings described here.

•	Result Display Configuration	193
	Zoomed Displays	
	Trace Configuration	
	Markers	
	Limit Lines	

# 11.1 Result Display Configuration

Measurement results can be evaluated in many different ways, for example graphically, as summary tables, statistical evaluations. Thus, the result display is highly configurable to suit your specific requirements and optimize analysis. Here you can find out how to optimize the display for your measurement results.

General display settings that are usually configured during initial instrument setup, independently of the current measurement, for example which items or colors are displayed on the screen, are described in Chapter 13.2, "Display Settings", on page 281.

Ba	asic R	Result I	Displ	ays		 		 	 	<i>′</i>	193
			_		1.1	 	~				

Laying out the Result Display with the SmartGrid......193

# 11.1.1 Basic Result Displays

Measurement results can be displayed and evaluated using various different methods, also at the same time. Depending on the currently selected measurement, in particular when using optional firmware applications, not all evaluation methods are available.

The result displays described here are available for most measurements in the phase noise application.

Find a list of supported result displays in Chapter 9, "Measurements and Result Displays", on page 107.

# 11.1.2 Laying out the Result Display with the SmartGrid

Measurement results can be evaluated in many different ways, for example graphically, as summary tables, statistical evaluations etc. Each type of evaluation is displayed in a separate window in the channel tab. Up to 16 individual windows can be displayed per channel (i.e. per tab). To arrange the diagrams and tables on the screen, the Rohde & Schwarz SmartGrid function helps you find the target position simply and quickly.

Principally, the layout of the windows on the screen is based on an underlying grid, the SmartGrid. However, the SmartGrid is dynamic and flexible, allowing for many different layout possibilities. The SmartGrid functionality provides the following basic features:

- Windows can be arranged in columns or in rows, or in a combination of both.
- Windows can be arranged in up to four rows and four columns.
- Windows are moved simply by dragging them to a new position on the screen, possibly changing the layout of the other windows, as well.
- All evaluation methods available for the currently selected measurement are displayed as icons in the evaluation bar. If the evaluation bar contains more icons than can be displayed at once on the screen, it can be scrolled vertically. The same evaluation method can be displayed in multiple windows simultaneously.
- New windows are added by dragging an evaluation icon from the evaluation bar to the screen. The position of each new window depends on where you drop the evaluation icon in relation to the existing windows.
- All display configuration actions are only possible in SmartGrid mode. When Smart-Grid mode is activated, the evaluation bar replaces the current softkey menu display. When the SmartGrid mode is deactivated again, the previous softkey menu display is restored.

•	Background Information: The SmartGrid Principle	194
•	How to Activate SmartGrid Mode	196
•	How to Add a New Result Window	196
•	How to Close a Result Window	197
•	How to Arrange the Result Windows	197
	0	

# 11.1.2.1 Background Information: The SmartGrid Principle

### SmartGrid display

During any positioning action, the underlying SmartGrid is displayed. Different colors and frames indicate the possible new positions. The position in the SmartGrid where you drop the window determines its position on the screen.

**Result Display Configuration** 



Figure 11-1: Moving a window in SmartGrid mode

The brown area indicates the possible "drop area" for the window, i.e. the area in which the window can be placed. A blue area indicates the (approximate) layout of the window as it would be if the icon were dropped at the current position. The frames indicate the possible destinations of the new window with respect to the existing windows: above/below, right/left or replacement (as illustrated in Figure 7-2). If an existing window would be replaced, the drop area is highlighted in a darker color shade.

### Positioning the window

The screen can be divided into up to four rows. Each row can be split into up to four columns, where each row can have a different number of columns. However, rows always span the entire width of the screen and may not be interrupted by a column. A single row is available as the drop area for the window in the SmartGrid. The row can be split into columns, or a new row can be inserted above or below the existing row (if the maximum of 4 has not yet been reached).




Figure 11-2: SmartGrid window positions

**Result Display Configuration** 

- 1 = Insert row above or below the existing row
- 2 = Create a new column in the existing row
- 3 = Replace a window in the existing row

### SmartGrid functions

Once the evaluation icon has been dropped, icons in each window provide delete and move functions.



The "Move" icon allows you to move the position of the window, possibly changing the size and position of the other displayed windows.

The "Delete" icon allows you to close the window, enlarging the display of the remaining windows.

### 11.1.2.2 How to Activate SmartGrid Mode

All display configuration actions are only possible in SmartGrid mode. In SmartGrid mode the evaluation bar replaces the current softkey menu display. When the Smart-Grid mode is deactivated again, the previous softkey menu display is restored.

To activate SmartGrid mode, do one of the following:



Select the "SmartGrid" icon from the toolbar.

- Select the "Display Config" button in the configuration "Overview".
- Select the "Display Config" softkey from the [Meas Config] menu.

The SmartGrid functions and the evaluation bar are displayed.



To close the SmartGrid mode and restore the previous softkey menu select the "Close" icon in the right-hand corner of the toolbar, or press any key.

### 11.1.2.3 How to Add a New Result Window

Each type of evaluation is displayed in a separate window. Up to 16 individual windows can be displayed per channel (i.e. per tab).

1. Activate SmartGrid mode.

All evaluation methods available for the currently selected measurement are displayed as icons in the evaluation bar.

 Select the icon for the required evaluation method from the evaluation bar. If the evaluation bar contains more icons than can be displayed at once on the screen, it can be scrolled vertically. Touch the evaluation bar between the icons and move it up or down until the required icon appears.  Drag the required icon from the evaluation bar to the SmartGrid, which is displayed in the diagram area, and drop it at the required position. (See Chapter 7.5.2.5, "How to Arrange the Result Windows", on page 94 for more information on positioning the window).

### **Remote command:**

LAYout:ADD[:WINDow]? on page 501 / LAYout:WINDow<n>:ADD? on page 507

## 11.1.2.4 How to Close a Result Window

To close a window, activate SmartGrid mode and select the "Delete" icon for the window.



### **Remote command:**

LAYout:REMove[:WINDow] on page 504 / LAYout:WINDow<n>:REMove on page 508

## 11.1.2.5 How to Arrange the Result Windows

1. Select an icon from the evaluation bar or the "Move" icon for an existing evaluation window.



- Drag the evaluation over the SmartGrid.
   A blue area shows where the window will be placed.
- 3. Move the window until a suitable area is indicated in blue.
- 4. Drop the window in the target area.

The windows are rearranged to the selected layout, and "Delete" and "Move" icons are displayed in each window.

5. To close a window, select the corresponding "Delete" icon.



### **Remote command:**

LAYout:REPLace[:WINDow] on page 505 / LAYout:WINDow<n>:REPLace on page 508

LAYout:MOVE[:WINDow] on page 504

# **11.2 Zoomed Displays**

You can zoom into the diagram to visualize the measurement results in greater detail. Using the touchscreen or a mouse pointer you can easily define the area to be enlarged.

•	Single Zoom Versus Multiple Zoom	198
•	Zoom Functions	199
•	How to Zoom Into a Diagram	200

# 11.2.1 Single Zoom Versus Multiple Zoom

Two different (graphical) zoom modes are available: single zoom and multiple zoom. A single zoom replaces the current diagram by a new diagram which displays an enlarged extract of the trace. This function can be used repetitively until the required details are visible. In multiple zoom mode, you can enlarge up to four different areas of the trace simultaneously. An overview window indicates the zoom areas in the original trace, while the zoomed trace areas are displayed in individual windows. The zoom areas can be moved and resized any time. The zoom area that corresponds to the individual zoom display is indicated in the lower right corner, between the scrollbars.



Figure 11-3: Single zoom

**Zoomed Displays** 



Figure 11-4: Multiple zoom

# 11.2.2 Zoom Functions

Access: "Zoom" icons in toolbar

Single Zoom	199
Multi-Zoom	199
Restore Original Display	200
Reactivating Zoom (Selection Mode)	

### Single Zoom



A single zoom replaces the current diagram by a new diagram which displays an enlarged extract of the trace. This function can be used repetitively until the required details are visible.

Remote command:

```
DISPlay[:WINDow<n>][:SUBWindow<w>]:ZOOM[:STATe] on page 511
DISPlay[:WINDow<n>][:SUBWindow<w>]:ZOOM:AREA on page 509
```

### Multi-Zoom



In multiple zoom mode, you can enlarge several different areas of the trace simultaneously. An overview window indicates the zoom areas in the original trace, while the zoomed trace areas are displayed in individual windows. The zoom area that corresponds to the individual zoom display is indicated in the lower right corner, between the scrollbars.

Remote command:

```
DISPlay[:WINDow<n>][:SUBWindow<w>]:ZOOM:MULTiple<zn>[:STATe]
on page 511
DISPlay[:WINDow<n>][:SUBWindow<w>]:ZOOM:MULTiple<zn>:AREA
on page 510
```

### **Restore Original Display**



Restores the original display, that is, the originally calculated displays for the entire capture buffer, and closes all zoom windows.

Remote command: DISPlay[:WINDow<n>][:SUBWindow<w>]:ZOOM[:STATe] on page 511

### Deactivating Zoom (Selection Mode)

Deactivates any zoom mode.

Tapping the screen no longer invokes a zoom, but selects an object.

Remote command:

DISPlay[:WINDow<n>][:SUBWindow<w>]:ZOOM[:STATe] on page 511

# 11.2.3 How to Zoom Into a Diagram

The remote commands required to zoom into a display are described in Chapter 15.7.2, "Zoom", on page 509.

The following tasks are described here:

- "To zoom into the diagram at one position" on page 200
- "To return to selection mode in the diagram" on page 201
- "To return to original display" on page 201
- "To zoom into multiple positions in the diagram" on page 201


### To zoom into the diagram at one position



Click on the "Single Zoom" icon in the toolbar.

Zoom mode is activated.

Tap and drag your finger in the diagram to select the area to be enlarged. The selected area is indicated by a dotted rectangle.




When you leave the touchscreen, the diagram is replaced by the zoomed trace area.

3. Repeat these steps, if necessary, to enlarge the diagram further.



### Scrolling in the zoomed display

You can scroll the diagram area to display the entire diagram using the scrollbars at the right and at the bottom of the diagram.



## To return to selection mode in the diagram

While you are in zoom mode, touching the screen changes the zoom area. In order to select or move a trace or marker, you must switch back to selection mode:



Select the "Selection Mode" icon in the toolbar.

# To return to original display



Click on the "Zoom Off" icon in the toolbar.

The original trace display is restored. Zoom mode remains active, however. To switch off zoom mode and return to selection mode, select the "Selection Mode" icon in the toolbar.

### To zoom into multiple positions in the diagram



Click on the "Multi-Zoom" icon in the toolbar. Multiple zoom mode is activated.  Select the first area in the diagram to be enlarged as described in "To zoom into the diagram at one position" on page 200. The selected area is indicated by a dotted rectangle.

When you have completed your selection, the original trace is shown in an overview diagram with the selected area indicated by a dotted rectangle. The zoomed trace area is displayed in a separate window (see Figure 11-4.

3. In the overview diagram, select the next area to be enlarged.

The second zoom area is indicated in the overview diagram, and a second zoom window is displayed.

Repeat these steps, if necessary, to zoom into further trace areas (up to four).

### To move or change zoom areas

In multiple zoom mode, you can change the size or position of the individual zoom areas easily at any time.

- 1. If necessary, switch off zoom mode and return to selection mode by selecting the "Selection Mode" icon in the toolbar.
- To resize a zoom area, tap directly on the corresponding frame in the overview window and drag the line to change the size of the frame.
   To move a zoom area, tap inside the corresponding frame in the overview window and drag the frame to the new position.

The contents of the zoom windows are adapted accordingly.

# **11.3 Trace Configuration**

•	Basics on Traces	202
•	Trace Configuration	206
	Trace Export and Import	
	Copying Traces	
	Trace Math	
•	Trace Labels	. 215
•	How to Configure Traces	. 215
	References	

# 11.3.1 Basics on Traces

•	Analyzing Several Traces - Trace Mode	203
	Trace Averaging	
	Spurs and Spur Removal	

### 11.3.1.1 Analyzing Several Traces - Trace Mode

If several measurement are performed one after the other, or continuous measurement are performed, the trace mode determines how the data for subsequent traces is processed. After each measurement, the trace mode determines whether:

- The data is frozen (View)
- The data is hidden (Blank)
- The data is replaced by new values (Clear Write)
- The data is replaced selectively (Max Hold, Min Hold, Average)

Each time the trace mode is changed, the selected trace memory is cleared.

The R&S FSWP supports the following trace modes:

Trace Mode	Description
Blank	Hides the selected trace.
Clear Write	Overwrite mode: the trace is overwritten by each measurement. This is the default set- ting. All available detectors can be selected.
Max Hold	The maximum value is determined over several measurements and displayed. The R&S FSWP saves the measurement result in the trace memory only if the new value is greater than the previous one.
Min Hold	The minimum value is determined from several measurements and displayed. The R&S FSWP saves the measurement result in the trace memory only if the new value is lower than the previous one.
Average	The average is formed over several measurements and displayed.
	The Sweep/Average Count determines the number of averaging procedures.
View	The current contents of the trace memory are frozen and displayed.
Write Hold	The trace is overwritten when new data is available, but only after all cross-correlation operations defined for a half decade are done.

Table 11-1: Overview of available trace modes

If a trace is frozen ( "View" mode), the measurement settings, apart from scaling settings, can be changed without impact on the displayed trace. The fact that the displayed trace no longer matches the current measurement settings is indicated by a yellow asterisk a on the tab label.

If you change any parameters that affect the scaling of the diagram axes, the R&S FSWP automatically adapts the trace data to the changed display range. This allows you to zoom into the diagram after the measurement to show details of the trace.

### 11.3.1.2 Trace Averaging

The application provides several methods of trace averaging that you can use separately or in any combination.

The order in which averaging is performed is as follows.

1. Cross-correlation

The application performs a certain number of cross-correlation operations in each half decade.

2. Sweep count.

The application measures the complete measurement range a particular number of times.

It again includes the cross-correlation operations as defined.

After the measurement over the sweep count is finished, the application displays the averaged results.

 Trace smoothing. Calculates the moving average for the current trace.

### **Sweep Count**


The sweep count defines the number of sweeps that the application performs during a complete measurements.

A sweep in this context is the measurement over the complete measurement range once. A complete measurement, however, can consist of more than one sweep. In that case, the application measures until the number of sweeps that have been defined are done. The measurement configuration stays the same all the time.

In combination with the average trace mode and cross-correlation operations, the sweep count averages the trace even more.

### **Trace Smoothing**

(Software-based) **smoothing** is a way to remove anomalies visually in the trace that can distort the results. The smoothing process is based on a moving average over the complete measurement range. The number of samples included in the averaging process (the *aperture* size) is variable and is a percentage of all samples that the trace consists of.



aperture size (e.g. 5% = 50 samples)

Figure 11-5: Sample size included in trace smoothing

The application smoothes the trace continuously. Smoothing is just an enhancement of the trace display, not of the data itself. It is always applied before trace averaging, max

hold, min hold or write hold. For the smoothing process, a median filter is applied on the logarithmic data.

You can turn trace smoothing on and off for all traces individually and compare, for example, the raw and the smooth trace.

The **median** trace smoothing uses a median filter which takes the median value over a sliding window. The window size can be set in the trace menu in percent of the total evaluation range. A median filter suppresses outliers while smoothing the underlying noise curve.

### 11.3.1.3 Spurs and Spur Removal

Most phase noise results contain unwanted spurs. Spurs are peak levels at one or more offset frequencies and are caused mostly by interfering signals. For some applications, you might want to identify the location of spurs. For other applications, spurs do not matter in evaluating the results and you might want to remove them from the trace to get a "smooth" phase noise trace.

### Spur display

Usually, spurs are visible on the trace as a peak. In addition, the R&S FSWP draws a straight, vertical line to represent the position of a spur visually. The length of these lines indicates the level of the spur in dBc and refers to the scale on the right side of the phase noise diagram.

The lines indicating a spur are not part of the trace data. When you export the trace, for example, the spur data is not exported.

Spur data is evaluated in the Spurious List.

### Spur suppression

The application allows you to (visually) remove spurs from the trace. Spur removal is based on an algorithm that detects and completely removes the spurs from the trace and fills the gaps with data that has been determined mathematically.

The spur removal functionality separates the actual spur power from the underlying phase noise and displays the latter in a two-stage process. The first stage of spur detection is based on an eigenvalue decomposition during the signal processing.

### Spur threshold

During the second stage, the application uses statistical methods to remove a spur. A spur is detected, if the level of the signal is above a certain threshold. The spur threshold is relative to an imaginary median trace that the application calculates.

If parts of the signal are identified as spurs, the application removes all signal parts above that level and substitutes them with the median trace.

**Trace Configuration** 




Figure 11-6: Spur detection and removal principle

# 11.3.2 Trace Configuration

Access: "Overview" > "Analysis" > "Traces" > "Traces"

Traces are the graphical representation of the measurement results. Depending on the trace configuration, they carry different information or evaluate the results differently.

	Mode	Result		Volue		Threshold	cinse Kill(est
Trace 1	cilear Write	PhaseNoise :	2	1.96	2	6.0 dß	é.o dé
Trace 2	Clear Write	Phase Noise		196		6.0 dB	0.0 d6
Trace 3	Extense :	Phase Noise		j-q <sub>p</sub>		6.0 dß	0.0 dB
Trace 4	Blank :	Phase Volse		j-q <sub>b</sub>		6.0 dB	0.0 JB
Trace 5	Blank :	Phase Noise		j n <sub>b</sub>		6.0 dB	0.0 dB
A saint	Blank	Phase (voise		i m		6.0 HB	0.0 dB

### **Restoring default traces**

The application allows you to easily restore the default trace configuration (Trace 1 and 2 with their respective default characteristics) with the "Preset all Traces" button.

### **Displaying all result types**

Similarly, you can easily display all available result type (PM, AM and overall noise) with the "Set Result Type" button. When you do so, the application displays three

Trace Configuration

traces in the diagram: One for the phase noise, one for the AM noise and the third showing the sum of the phase noise and AM noise (PN + AM).

Functions in the "Traces" dialog box described elsewhere:

"Hiding spurs" on page 162

The remote commands required to configure traces are described in Chapter 15.7.3.1, "Trace Characteristics", on page 512.

### Trace 1 / Trace 2 / Trace 3 / Trace 4 / Trace 5 / Trace 6

Selects the corresponding trace for configuration. The currently selected trace is highlighted.

Remote command: Selected via numeric suffix of:TRACe<1...6> commands DISPlay[:WINDow<n>] [:SUBWindow<w>]:TRACe<t>[:STATe] on page 515

### Trace Mode

Defines the update mode for subsequent traces.

For details, see Chapter 11.3.1.1, "Analyzing Several Traces - Trace Mode", on page 203.

- "Clear/ Write" Overwrite mode (default): the trace is overwritten by each measurement.
- "Max Hold" The maximum value is determined over several measurements and displayed. The R&S FSWP saves each trace point in the trace memory only if the new value is greater than the previous one. Not supported by Spot Noise vs Tune measurements.
- "Min Hold" The minimum value is determined from several measurements and displayed. The R&S FSWP saves each trace point in the trace memory only if the new value is lower than the previous one. Not supported by Spot Noise vs Tune measurements.
- "Average" The average is formed over several measurements.
- "View" The current contents of the trace memory are frozen and displayed.
- "Blank" Removes the selected trace from the display.
- "Write Hold" The trace is overwritten when new data is available, but only after all cross-correlation operations defined for a half decade are done. (Or when the trace cannot be improved further when "XCORR Optimization" is on). Example: 100 cross-correlation operations are defined for a half decade. The trace is updated when all 100 cross-correlations are done, not after each individual cross-correlation operation.

### Remote command:

DISPlay[:WINDow<n>]:TRACe<t>:MODE on page 512

### Selecting the displayed result

The R&S FSWP supports several noise characteristics that you can assign to a trace and thus display in the diagram.

"Phase Noise"

Shows the measured phase noise characteristics.

"AM Noise"

Shows the measured amplitude noise characteristics.

"Phase + AM Noise"

Shows the sum of the phase noise and AM noise characteristics.

The "AM Noise" and "Phase + AM Noise" traces are only available for the "Noise Spectrum" diagram, and not in its variations ("Noise Spectrum L(f)", "Noise Spectrum  $S\Phi(f)$ ", "Noise Spectrum Sv(f)", "Noise Spectrum Sy(f)").

Remote command:

DISPlay[:WINDow<n>]:TRACe<t>:RESult[:TYPE] on page 515

### **Smoothing traces**

The R&S FSWP allows you to smooth traces and thus remove unwanted anomalies.

You can apply smoothing to all active traces individually (Smoothing "State"), and define the magnitude of trace smoothing in percent (Smoothing "Value").

The range is from 1% to 20%.

**Note**: In the spot noise vs tune measurement, trace smoothing properties apply to all traces.

Remote command:

State: DISPlay[:WINDow<n>]:TRACe<t>:SMOothing[:STATe] on page 517
Value: DISPlay[:WINDow<n>]:TRACe<t>:SMOothing:APERture on page 517
State (SN vs Tune): [SENSe:]SMOothing[:STATe] on page 483
Value (SN vs Tune): [SENSe:]SMOothing:APERture on page 482

### Shifting the trace

Shifting the trace can be useful to subtract external noise sources from the results. The trace offset is a visual device that shifts the trace by certain level.

You can apply an offset to all active traces individually (Offset "State"), and define an offset in dB by which the trace should be shifted.

Remote command:

State: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel:OFFSet:STATe
on page 516

**Offset**: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel:OFFSet on page 516

### **Displaying persistence**

The term persistence has its origins in cathode ray tube devices (CRTs). It describes the time period one point on the display stays illuminated after it has been lit by the cathode ray. The higher the persistence, the longer you could observe the illuminated point on the display.

In the phase noise application, the persistence defines for how long a trace remains visible before it fades away. An event that has occurred a single time is visible for up to 8 seconds. As the statistical frequency of an event gets smaller at coordinates with signal parts that are not constantly there, the trace fades away.

A signal with constant frequency or phase characteristics does not show the effects of persistence on the trace. When the frequency or phase of a signal change slightly, however, the effect of persistence becomes visible through color changes or changes in the shape of the trace.

You can turn on persistence for all traces in the display ("State"). The "Decay" property defines the time that shadows of past traces remain visible in the display before fading away. With a decay of 0 s, all past traces remain visible.

When you change a measurement setting, the R&S FSWP resets the persistence effect.

Persistence is supported by phase noise measurements (CW and pulsed) and the transient measurement.

Remote command:

DISPlay[:WINDow<n>]:TRACe<t>:PERSistence[:STATe] on page 515
DISPlay[:WINDow<n>]:TRACe<t>:PERSistence:DECay on page 514

# 11.3.3 Trace Export and Import

Access: "Overview" > "Analysis" > "Traces" > "Trace / Data Export"

The R&S FSWP provides various evaluation methods for the results of a measurement. However, if you want to evaluate the data with external applications, you can export the measurement data to a standard format file (ASCII or XML).

The following data types can be exported (depending on the application):

- Trace data
- Table results, for example result summaries, marker peak lists.

You can also import existing trace data from a file, for example to compare your latest measurement results with results that you have saved some time ago.



### Availability of trace import

The trace import is available for the following measurements.

- Phase noise
- Pulsed phase noise
- Additive noise
- Pulsed additive noise
- Baseband noise



I/Q data can only be imported and exported in applications that process I/Q data, such as the I/Q analyzer or optional applications.

See the corresponding user manuals for those applications for details.

# (j

The standard data management functions (e.g. saving or loading instrument settings) that are available for all R&S FSWP applications are not described here.

See Chapter 12, "Data Management", on page 244 for a description of the standard functions.



The remote commands required to import and export traces are described in Chapter 15.7.3.3, "Trace Export and Import", on page 518.

Export all Traces and all Table Results	
Include Instrument & Measurement Settings	
Trace to Export	
Export Trace to ASCII File	211
L File Type	
L Decimal Separator	
L Column Separator	
L File Explorer	
Select ASCII File	
Source Window / Source Trace	
Destination Trace	
Import	
•	

### Export all Traces and all Table Results

Selects all displayed traces and result tables (e.g. Result Summary, marker table etc.) in the current application for export to an ASCII file.

Alternatively, you can select one specific trace only for export (see Trace to Export ).

The results are output in the same order as they are displayed on the screen: window by window, trace by trace, and table row by table row.

Remote command: FORMat:DEXPort:TRACes on page 521

# Include Instrument & Measurement Settings

Includes additional instrument and measurement settings in the header of the export file for result data.

Remote command:

FORMat:DEXPort:HEADer on page 520

### Trace to Export

Defines an individual trace to be exported to a file.

This setting is not available if Export all Traces and all Table Results is selected.

### **Export Trace to ASCII File**

Saves the selected trace or all traces in the currently active result display to the specified file and directory in the selected ASCII format.

"File Explorer": Instead of using the file manager of the R&S FSWP firmware, you can also use the Microsoft Windows File Explorer to manage files.

ASCII Trace Exp	ort Nam	e			X	
Drive: 🍉(C:) OS	- 1	Path: 📙	user (C:/gitESMain/ES-MAIN_	_20.10.9.0	_sim/user]	) -
Files					Size	•
🖿						
🗀 chan_tab						
🗀 config						
🗀 cvl						
🗀 data						
🗀 Demo						
🗀 gen						
🗎 LTE						
Noise					Þ	-
File Name	<b>File</b>					
File Type	.dat	.csv				
Decimal Separator	Point	Comma				
File Explorer					Save	

For details on the file format, see Chapter 11.3.8.1, "Reference: ASCII File Export Format", on page 216.

Note: Secure user mode.

In secure user mode, settings that are stored on the instrument are stored to volatile memory, which is restricted to 256 MB. Thus, a "memory limit reached" error can occur although the hard disk indicates that storage space is still available.

To store data permanently, select an external storage location such as a USB memory device.

For details, see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

Remote command:

MMEMory:STORe<n>:TRACe on page 576

### File Type ← Export Trace to ASCII File

Determines the format of the ASCII file to be imported or exported.

Depending on the external program in which the data file was created or is evaluated, a comma-separated list (CSV) or a plain data format (DAT) file is required.

Remote command: FORMat:DEXPort:FORMat on page 520

### Decimal Separator Export Trace to ASCII File

Defines the decimal separator for floating-point numerals for the data export/import files. Evaluation programs require different separators in different languages.

Remote command: FORMat:DEXPort:DSEParator on page 520

### Column Separator Export Trace to ASCII File

Selects the character that separates columns in the exported ASCII file. The character can be either a semicolon, a comma or a tabulator (tab).

### Example for semicolon:

Type;FSWP26;Version;1.80;Date;01.Jan 3000;

### Example for comma:

Type,FSWP26, Version,1.80, Date,01.Jan 3000,

Example for tabulator (tab after the last column is not visible):

Type FSWP26 Version 1.80 Date 01.Jan 3000

The selected column separator settings remains the same, even after a preset.

Remote command: FORMat:DEXPort:CSEParator on page 519

### File Explorer Export Trace to ASCII File

Opens the Microsoft Windows File Explorer.

Remote command: not supported

### Select ASCII File

The "Select ASCII File" button opens a dialog box to select results that you want to import.

You can select files with the extensions .csv or .dat.

Remote command: MMEMory:LOAD<n>:TRACe on page 521

### Source Window / Source Trace

Files that contain result data can contain the results of several measurements and result displays. The "Source Window" and "Source Trace" dropdown menus select the data that you would like to import.

The source data must be compatible to a currently active window.

### Example:

If you want to import trace 1 of a previously exported noise diagram:

 Select the phase noise measurement and open a noise diagram from the Smart-Grid.

Importing phase noise trace data into a transient measurement diagram is not possible.

- Select "Noise Diagram" from the "Source Window" dropdown menu.
- Select "1" from the "Source Trace" dropdown menu. If you select "All Traces", the R&S FSWP imports all traces of the selected result type.

Remote command:

MMEMory:LOAD<n>:TRACe on page 521

### **Destination Trace**

The "Destination Trace" dropdown menu becomes available when you select to import a single trace only.

In that case, you can select the trace number you want to write the trace data to.

If you select a trace that already exists, the trace import overwrites the currently displayed trace. Imported traces always get the trace mode "View".

### Example:

You have selected trace "1" as the trace you want to import from the "Source Trace" dropdown menu.

If you select "1: Clear Write" ("Clear Write" indicates the trace is currently displayed) from the "Destination Trace" dropdown menu, the import overwrites the trace. The trace mode for trace 1 is replaced by trace mode "View".

If you select "5: Blank" ("Blank" indicates that the trace is currently not displayed) from the "Destination Trace" dropdown menu, the imports adds a new trace to the diagram (with trace mode "View". All other traces remain in the diagram.

Remote command: MMEMory:LOAD<n>:TRACe on page 521

### Import

The "Import" button imports the selected trace(s).

THe R&S FSWP does not import numeric results associated with the imported trace (spot noise, values from the spurious list etc.)

### Remote command:

MMEMory:LOAD<n>:TRACe on page 521

# 11.3.4 Copying Traces

Access: "Overview" > "Analysis" > "Traces" > "Copy Trace"

Traces Trace /	Data Export	Copy Trace	Trace Math	Trace Label	
Source					
Trace 1	Trace 2	Trace 3			
	·		_		
	Copy to Trace 2	Copy to Trace 3			
Copy to Trace 4	Copy to Trace 5	Copy to Trace 6			

The remote commands required to copy traces are described in Chapter 15.7.3.2, "Trace Copy", on page 518.

### Copy Trace

Access: "Overview" > "Analysis" > "Traces" > "Copy Trace"

Or: [TRACE] > "Copy Trace"

Copies trace data to another trace.

Remote command: TRACe<n>:COPY on page 518

# 11.3.5 Trace Math

Access: "Overview" > "Analysis" > "Traces" > "Trace Math"

/ Data Export	Copy Trace	Trace Math	Trace Label	
T2-T3->T2	Trace Math	Off		
	T2-T3->T2	T2-T3->T2 Trace Math	T2-T3->T2 Trace Math Off	

The remote commands required to configure trace mathematics are described in Chapter 15.7.3.4, "Trace Mathematics", on page 522.

### Selecting the math operation

You can select one of several different math operations.

Each operation subtracts one trace from another as indicated on the corresponding button and writes the result to one of the traces. "T1 - T3 > T1", for example, subtracts trace 3 from trace 1 and writes the result to trace 1. You can apply one operation at a time.

To turn off trace mathematics, use the "Trace Math Off" feature.

Remote command:

Operation: CALCulate<n>:MATH[:EXPRession][:DEFine] on page 523 State: CALCulate<n>:MATH:STATe on page 522

# 11.3.6 Trace Labels

Access: "Overview" > "Analysis" > "Traces" > "Trace Label"

Trace labels are a way to assign a descriptive label to traces instead of the general "Trace <x>" label (default). The labels you use are arbitrary and are displayed in the diagram area. The font color corresponds to the color of the respective trace (for example yellow trace: yellow font).

100 kHz (workson D3[1] 0.00 dBm od-wee D3[1] 0.00 dBm

Figure 11-7: Example: the yellow and blue traces have a label.

You can define trace labels in the "Trace Label" tab of the "Trace" dialog box.

### How to assign trace labels

Trace labels can be configured via the "Trace Labels" dialog box.

1. Turn on the trace label for a specific trace and assign a label in the corresponding input field.

Note that a trace must be active. Otherwise assigning a label is not possible.

Move the trace label to any position on the display by dragging it to the new position.

Remote command:

State: DISPlay[:WINDow<n>]:TRACe<t>:LABel[:STATe] on page 513
Label: DISPlay[:WINDow<n>]:TRACe<t>:LABel:TEXT on page 514

# 11.3.7 How to Configure Traces

### 11.3.7.1 How to Export Trace Data and Numerical Results

The measured trace data and numerical measurement results in tables can be exported to an ASCII file. For each measurement point, the measured trace position and value are output. The file is stored with a .DAT extension. For details on the storage format, see Chapter 11.3.8.1, "Reference: ASCII File Export Format", on page 216.

### To export trace data and table results

Trace data can be exported from the "Trace" menu.

1. Press the [Trace] key, then select the "Trace Config" softkey and switch to the "Trace / Data Export" tab.

- Select "Export all Traces and all Table Results" to export all available measurement result data for the current application. Alternatively, select a specific "Trace to Export".
- 3. Optionally, select the "Include Instrument & Measurement Settings" option to insert additional information in the export file header.
- 4. If necessary, change the decimal separator used in the ASCII export file.
- 5. Select the "Export Trace to ASCII File" button.
- 6. In the file selection dialog box, select the storage location and file name for the export file.
- 7. Select "Save" to close the dialog box.
- 8. Export the data to the file.

# 11.3.8 References

### 11.3.8.1 Reference: ASCII File Export Format

Trace data can be exported to a file in ASCII format for further evaluation in other applications. This reference describes in detail the format of the export files for result data.

(For details see Chapter 11.3.7.1, "How to Export Trace Data and Numerical Results", on page 215).

The file consists of the header information (general configuration of the measurement) and the measurement results. Optionally, the header can be excluded from the file.

The file of the Phase Noise application contains several sections, each section containing related data as shown in the tables below. Each section can contain header information and / or result information (header information is represented by a blue font in the tables below).

The data of the file header consist of three columns, each separated by a semicolon: parameter name; numeric value; basic unit. The data section starts with the keyword "Trace <n>" (<n> = number of stored trace), followed by the measured data in one or several columns (depending on the measurement) which are also separated by a semicolon.

The results are output in the same order as they are displayed on the screen: window by window, trace by trace, and table row by table row.

Generally, the format of this ASCII file can be processed by spreadsheet calculation programs, e.g. MS Excel. Different language versions of evaluation programs may require a different handling of the decimal point. Thus you can define the decimal separator to be used (decimal point or comma).

Black font: result data is always exported to the file General measurement configuration	
Type; R&S FSWP;	Instrument model
Version;1.00;	Firmware version
Date;01. Jan 3000;	Date of data set storage
Tune Source;Vtune;	DC power source (Vsupply, Vtune, Vaux or None
VSupply;ON;	State of the supply voltage source (on or off)
Mode;Voltage;	Type of output on the supply voltage source (voltage or current)
Voltage Set;5.000;V;	
Voltage Min;4.750;V;	
Voltage Max;5.250;V;	
Voltage Meas;0.000;V;	Output characteristics of the supply voltage
Current Max;0.050000;A;	
Current Meas;0.000000;A;	
VTune;OFF;	State of the tuning voltage source (on or off)
Voltage Set;5.000;V;	
Voltage Min;4.750;V;	
Voltage Max;5.250;V;	
Voltage Meas;0.000;V;	Output characteristics of the tuning voltage
Current Max;0.050000;A;	
Current Meas;0.000000;A;	
VAux;OFF;	State of the auxiliary voltage source (on or off)
Voltage Set;5.000;V;	
Voltage Min;4.750;V;	
Voltage Max;5.250;V;	
Voltage Meas;0.000;V;	Output characteristics of the auxiliary voltage
Current Max;0.050000;A;	
Current Meas:0.000000:A:	
Mode:Phase Noise:	Application
Measurement;Phase Noise;	Measurement type
Input;RF;	Input source
RF Att;0.000000;dB;	RF attenuation
Coupling;AC;	Input coupling type
RBW;x;%;	Resolution bandwidth factor
XCORR Factor;x;	Cross-correlation factor
XCORR Optimize;ON;	State of cross-correlation optimization
Estimated Meas Time;x;s;	Estimated measurement time
Sweep Count;0;	Current sweep count
Signal frequency;190920481.7452;Hz;	Carrier frequency
Signal level;-43.160000;dBm;	Carrier signal level
Start;1000.000000;Hz;	Start offset frequency

Figure 11-8: Example

Half decade configuration (amount of data depends on number of half decades in measurement)	
SubSweep;1;	Number of half decade
Start;1000.000000;Hz;	Start offset frequency of half decade
Stop;3000.000000;Hz;	Stop offset frequency of half decade
RBW;30.00000;Hz;	Resolution bandwidth applied in half decade
XCORR Count;10;	Number of cross-correlation operations in half decade
()	

Integrated measurement configuration (amount of data depends on number of integration ranges)

Integrated Measurements Range;1;	Number of integration range
Start;1000.000000;Hz;	Start offset frequency of integration range
Stop;300000.000000;Hz;	Stop offset frequency of integration range
Weighting;ON;FilterName;	State and name of weighting filter
()	

Spot noise measurement configuration (amount of data depends on number of spot noise positions)	
SpotNoiseDecadeEdges;ON;	State of spot noise evaluation on decade edges
SpotNoiseUserDefined;ON;	State of user defined spot noise evaluation
SpotNoiseUserDefinedOffset;1;	User defined spot noise information
State;ON;	State of user defined spot noise information
Offset;500000.000000;Hz;	Position of user defined spot noise
()	

<b>Noise Spectrum measurement results</b> (amount of data depends on the number of phase measurement windows and the number of traces in each window)	
Window;1;Noise Spectrum;	Number and type of window
Trace;1;	Trace number
Trace Mode;CLR/WRITE;	Trace mode
Trace Result;PN;	Result type (phase noise or amplitude noise etc.)
Smoothing;ON;	State of trace smoothing
Smoothing value;10;%;	Trace smoothing aperture
Spurious Removal;OFF;	State of spur removal
Spurious Removal Threshold;x;dB;	Spur removal threshold
Trace Offset;ON;	State of trace offset
Trace Offset;x;dB;	Value of trace offset
Trace Label;ON;	State of trace label
Trace Label;LabelDesignation;	Trace label
X-Unit;Hz;	Unit of the x-axis
Y-Unit;dBc/Hz;	Unit of the y-axis
Values;601;	Number of measurement points
<x-value>;<y-value>;</y-value></x-value>	Results (one level for every measurement point)
()	
Trace;2;	
()	
Window;2;PhaseNoise;	
()	

Integrated measurement results (amount of data depends on the number of integration ranges)	
Window;3;Integrated Measurements;	Number and type of window
Window;Range;Trace;	Window and trace number a integration range applies to
Start Offset;Unit;	Start offset of the integration range
Stop Offset;Unit;	Stop offset of the integration range
Weighting;	Name of the weighting filter, if present
Int Noise;Unit;	Value for integrated noise
PM;Unit;	Value for the Residual PM
FM;Unit;	Value for the Residual FM
Jitter;Unit;	Value for the jitter
Window;3;Range2;Trace;	
()	

Spot noise measurement results (amount of data depends on the number of spot noise markers)	
Window;4;Spot Noise;	Number and type of window
Window;Trace;	Window and trace number the spot noise marker is positioned in
X-Value;Unit;	Position of the spot noise marker
Y-Value;Unit;	Spot noise
()	

Spur measurement results (amount of data depends on the number of spurs)	
Window;5;Spurious;	Number and type of window
Window;Trace;	Window and trace number the spurious is found in
Spur;	Number of the spurious
Offset Frequency;Unit;	Offset frequency of the spur
Power;Unit;	Level of the spur
Jitter;Unit;	Jitter of the spur
()	
Window;Trace;	Window and trace number the spurious is found in
Discrete Jitter;Unit;	Discrete jitter result
Random Jitter;Unit;	Random jitter result

Marker results	(amount of data depends on the number of active markers)
----------------	--

Window;6;Marker Table;	Number and type of window
Window;	Window the marker is in
Туре;	Marker type
Reference;	Reference marker
Trace;	Number of the trace the marker is on
X-Value;Unit;	Position of the marker on the x-axis, incl. unit
Y-Value;Unit;	Position of the marker on the y-axis, incl. unit
()	

VCO Characterization + Spot Noise	vs Tune: General measurement configuration
Type; R&S FSWP;	Instrument model
Version;1.00;	Firmware version
Date;01. Jan 3000;	Date of data set storage
VSupply;ON;	State of the supply voltage source (on or off)
Mode;Voltage;	Type of output on the supply voltage source (voltage or current)
Voltage Set;5.000;V;	
Voltage Min;4.750;V;	
Voltage Max;5.250;V;	
Voltage Meas;0.000;V;	Output characteristics of the supply voltage
Current Max;0.050000;A;	
Current Meas;0.000000;A;	
VTune;OFF;	State of the tuning voltage source (on or off)
Voltage Set;5.000;V;	
Voltage Min;4.750;V;	
Voltage Max;5.250;V;	
Voltage Meas;0.000;V;	Output characteristics of the tuning voltage
Current Max;0.050000;A;	
Current Meas;0.000000;A;	
VAux;OFF;	State of the auxiliary voltage source (on or off)
Voltage Set;5.000;V;	
Voltage Min;4.750;V;	
Voltage Max;5.250;V;	
Voltage Meas;0.000;V;	Output characteristics of the auxiliary voltage
Current Max;0.050000;A;	
Current Meas;0.000000;A;	
Mode;Phase Noise;	Application
Measurement;VCO Characterization;	Measurement type
Input;RF;	Input source
RF Att;0.000000;dB;	RF attenuation
Coupling;AC;	Input coupling type
Sweep Count;0;	Sweep count
Sweep Source;Vtune;	Sweep source (Vsupply,Vtune or Vaux)
Fix Source;Vsupply;	Fix source (Vsupply,Vtune or Vaux)
Sweep Start;0.000000;V;	Tuning range start value
Sweep Stop;5.000000;V;	Tuning range stop value
Meas Points;10;	Measurement points within the tuning range
Settling Time;0.001000;s;	Settling time for each measurement point
Initial Settling Time;0.001000;s;	Settling time before the measurement begins
Frequency Counter Resolution;1.000000000;Hz;	Start offset frequency

Trace Configuration

VCO Characterization + SN vs Tune: Results (amount of data depends on evaluated result displays)	
Window;1;Frequency;	Number and type of window (Frequency, Sensitivity etc.)
Trace;1;	Trace number
Trace Mode;CLR/WRITE;	Trace mode
Trace Label;ON;	State of trace label
Trace Label;LabelDesignation;	Trace label
X-Unit;V;	Unit of the x-axis
Y-Unit;Hz;	Unit of the y-axis
Values;601;	Number of measurement points
<x-value>;<y-value>;</y-value></x-value>	Results (one value for every measurement point)
()	
Trace;2;	
()	
Window;2;Power;	
()	

Blue font: header data only written to file if header data is exported, too. Black font: result data is always exported to the file					
Transient analysis: General measure	ement configuration				
Measurement;Transient Analysis;	Measurement type				
Input;RF;	Input source				
Mode;NARROW;	Transient analysis mode				
Center Freq;132500000.000000;Hz;	Center frequency				
Start;0.000000;Hz;	Start frequency				
Stop;2650000000.000000;Hz;	Stop frequency				
Span;2650000000.000000;Hz;	Frequency span				
Ref Level;0.000000;dBm;	Reference level				
Rf Att;10.00000;dB;	RF attenuation				
Coupling;AC;	Input coupling				
VBW;300000.000000;Hz;	Video bandwidth				
Meas Time;0.079500;s;	Measurement time				
Sweep Count;0;	Sweep count				

Transient analysis: results (amount of data depends on evaluated result displays)					
Window;1;Frequency vs Time;	Number and type of window (Frequency, phase etc.)				
Scale Mode;ABSOLUTE;	Scaling mode of the y-axis (frequency results only)				
AF Coupling;AC;	AF coupling mode (phase results only)				
Trace;1;	Trace number				
Trace Mode;CLR/WRITE;	Trace mode				
Trace Label;ON;	State of trace label				
Trace Label;LabelDesignation;	Trace label				
X-Unit;s;	Unit of the x-axis				
Y-Unit;Hz;	Unit of the y-axis				
Values;601;	Number of measurement points				
<x-value>;<y-value>;</y-value></x-value>	Results (one value for every measurement point)				
()					
Trace;2;					
()					

# 11.4 Markers

Markers help you analyze your measurement results by determining particular values in the diagram. Thus you can extract numeric values from a graphical display.

•	Basics	on	Markers	and	Marker	Functions.	 	 2	223	3
		_								

# 11.4.1 Basics on Markers and Marker Functions

Some background knowledge on marker settings and functions is provided here for a better understanding of the required configuration settings.

Markers are used to mark points on traces, to read out measurement results and to select a display section quickly. R&S FSWP provides 16 markers per display window. In the Phase Noise application, markers across measurement windows are independent from each other - thus you can move a marker in one window without moving it in another window.

• The easiest way to work with markers is using the touchscreen. Simply drag the marker and drop it at the required position. When a marker label is selected, a vertical line is displayed which indicates the marker's current x-value.

1 Phase Noise	O1Clr	w PN Smth 1% Spu	r 0dB o2Clrw PN
		M1[2]	-47.23 dBc/H
			22.050 kH
		D2[2]	-19.67 d
			51.163 kH
	Ψ.		
	l A		
		02	
		<u>ft</u>	
-SD-dBc/Hz			
-90 dBc/12	Ant the		
-100 dBc	a a a a a a a a a a a a a a a a a a a		
		No wy n	-120 dB
		- ha	
			-140 dB
XCORR 1 XCORR	1 XCORR 10	XCORR 30 XCORR	
1.0 kHz	Frequer	icy Offset	1.0 MHz

- Alternatively, change the position of the selected marker using the rotary knob. By default, the marker is moved from one pixel to the next.
- You can also set an active marker to a new position by defining its position on the x-axis numerically. When you select the softkey for a marker, an edit dialog box is displayed.
- The most commonly required marker settings and functions are also available as softkeys or via the context menu. Tap the marker on the touchscreen and hold your finger for about 2 seconds until the context menu is opened, then select the required entry.
- Softkeys for active markers (displayed on the screen) are highlighted blue. The softkey for the currently selected marker (for which functions are performed) is highlighted orange.
- To set individual markers quickly, use the softkeys in the "Marker" menu.
- To set up several markers at once, use the "Marker" dialog box.
- To position the selected marker to a special value, use the softkeys in the "Marker To" menu.

#### Marker types

All markers can be used either as normal markers or delta markers. A normal marker indicates the absolute signal value at the defined position in the diagram. A delta marker indicates the value of the marker relative to the specified reference marker (by default marker 1).

•	Activating Markers	224
•	Marker Results	224

### 11.4.1.1 Activating Markers

Only active markers are displayed in the diagram and in the marker table.

Active markers are indicated by a highlighted softkey.

By default, marker 1 is active and positioned on the maximum value (peak) of trace 1 as a normal marker. If several traces are displayed, the marker is set to the maximum value of the trace which has the lowest number and is not frozen (View mode). The next marker to be activated is set to the frequency of the next lower level (next peak) as a delta marker; its value is indicated as an offset to marker 1.

A marker can only be activated when at least one trace in the corresponding window is visible. If a trace is switched off, the corresponding markers and marker functions are also deactivated. If the trace is switched on again, the markers along with coupled functions are restored to their original positions, provided the markers have not been used on another trace.

#### 11.4.1.2 Marker Results

Normal markers point to a trace point on the x-axis and display the associated numeric value for that trace point. Delta markers indicate an offset between the level at the

delta marker position and the level at the position of the assigned reference marker, in dB.

The results can be displayed directly within the diagram area or in a separate table. By default, the first two active markers are displayed in the diagram area. If more markers are activated, the results are displayed in a marker table.

#### Marker information in diagram area

By default, the results of the last two markers or delta markers that were activated are displayed in the diagram area.



The following information is displayed there:

- The marker type (M for normal, D for delta, or special function name)
- The marker number (1 to 16)
- The assigned trace number in square brackets []
- The marker value on the y-axis, or the result of the marker function
- The marker position on the x-axis

#### Marker information in marker table

In addition to the marker information displayed within the diagram area, a separate marker table may be displayed beneath the diagram. This table provides the following information for all active markers:

Window	Window the marker is in (only if you have opened more than one Phase Noise dia- gram)
Туре	Marker type: N (normal), D (delta), T (temporary, internal) and number
Ref	Reference marker for delta markers
Тгс	Trace to which the marker is assigned
X-value	X-value of the marker
Y-value	Y-value of the marker

Table 11-2: Contents of the marker table in the Phase Noise application

# 11.4.2 Marker Settings

For more information about marker search, see Chapter 11.4.3, "Marker Search Settings and Positioning Functions", on page 229

## 11.4.2.1 Individual Marker Setup

Access: "Overview" > "Analysis" > "Markers" > "Markers"

Up to 17 markers or delta markers can be activated for each window simultaneously. Initial marker setup is performed using the "Marker" dialog box.

The markers are distributed among 3 tabs for a better overview. By default, the first marker is defined as a normal marker, whereas all others are defined as delta markers with reference to the first marker. All markers are assigned to trace 1, but only the first marker is active.

Markers	Selected		Search Config X-Value	Type	Ref	Link.id	Marker	Ira	œ
1-5	Marker 1.		1.0 kHz	sent famo	Morker	D1		1	•
6-11	Delta 1		0.0 Hz	90001-00	1. +	1	:	2	-
	Delta 2		1 District	Nomo Elena					
12-16	Deltà 3		1 1 1 4 4 1	Wann Frett/					
-	Delta 4		( o vit-	Serie Gene					
	Delta 5	Dalat		Teerm Factor					
			1	ll Marker Off	0.01				1

The remote commands required to define these settings are described in Chapter 15.7.4, "Marker", on page 524.

Selected Marker	
Marker State	226
Marker Position X-value	
Marker Type	227
Reference Marker	227
Linking to Another Marker	
Assigning the Marker to a Trace	228
Select Marker	
All Markers Off	228

#### **Selected Marker**

Marker name. The marker which is currently selected for editing is highlighted orange.

Remote command: Marker selected via suffix <m> in remote commands.

#### **Marker State**

Activates or deactivates the marker in the diagram.

Remote command:

CALCulate<n>:MARKer<m>[:STATe] on page 528 CALCulate<n>:DELTamarker<m>[:STATe] on page 526

#### **Marker Position X-value**

Defines the position (x-value) of the marker in the diagram. For normal markers, the absolute position is indicated. For delta markers, the position relative to the reference marker is provided.

Remote command:

CALCulate<n>:MARKer<m>:X on page 529 CALCulate<n>:DELTamarker<m>:X on page 527

#### Marker Type

Toggles the marker type.

The type for marker 1 is always "Normal", the type for delta marker 1 is always "Delta". These types cannot be changed.

**Note:** If normal marker 1 is the active marker, switching the "Mkr Type" activates an additional delta marker 1. For any other marker, switching the marker type does not activate an additional marker, it only switches the type of the selected marker.

"Normal" A normal marker indicates the absolute value at the defined position in the diagram.

"Delta" A delta marker defines the value of the marker relative to the specified reference marker (marker 1 by default).

#### Remote command:

CALCulate<n>:MARKer<m>[:STATe] on page 528 CALCulate<n>:DELTamarker<m>[:STATe] on page 526

#### **Reference Marker**

Defines a marker as the reference marker which is used to determine relative analysis results (delta marker values).

If the reference marker is deactivated, the delta marker referring to it is also deactivated.

Remote command:

CALCulate<n>:DELTamarker<m>:MREFerence on page 526

#### Linking to Another Marker

Links the current marker to the marker selected from the list of active markers. If the xaxis value of the initial marker is changed, the linked marker follows to the same position on the x-axis. Linking is off by default.

Using this function you can set two markers on different traces to measure the difference (e.g. between a max hold trace and a min hold trace or between a measurement and a reference trace).

#### Remote command:

CALCulate<n>:MARKer<ms>:LINK:TO:MARKer<md> on page 528 CALCulate<n>:DELTamarker<ms>:LINK:TO:MARKer<md> on page 525 CALCulate<n>:DELTamarker<m>:LINK on page 525

#### Assigning the Marker to a Trace

The "Trace" setting assigns the selected marker to an active trace. The trace determines which value the marker shows at the marker position. If the marker was previously assigned to a different trace, the marker remains on the previous frequency or time, but indicates the value of the new trace.

If a trace is turned off, the assigned markers and marker functions are also deactivated.

Remote command:

CALCulate<n>:MARKer<m>:TRACe on page 529

#### Select Marker

The "Select Marker" function opens a dialog box to select and activate or deactivate one or more markers quickly.

Selected	State	Selected	State	Selected	State
Marker 1	On Off	Delta 6	On Off	Delta 12	On Off
Delta 1	On Off	Delta 7	On Off	Delta 13	On Off
Delta 2	On Off	Delta 8	On Off	Delta 14	On Off
Delta 3	On Off	Delta 9	On Off	Delta 15	On Off
Delta 4	On Off	Delta 10	On Off	Delta 16	On Off
Delta 5	On Off	Delta 11	On Off		

#### Remote command:

CALCulate<n>:MARKer<m>[:STATe] on page 528 CALCulate<n>:DELTamarker<m>[:STATe] on page 526

#### All Markers Off

Deactivates all markers in one step.

Remote command: CALCulate<n>:MARKer<m>:AOFF on page 528

#### 11.4.2.2 General Marker Settings

Access: "Overview" > "Analysis" > "Markers" > "Settings"

Some general marker settings allow you to influence the marker behavior for all markers.



The remote commands required to define these settings are described in Chapter 15.7.4, "Marker", on page 524.

Marker Table Display	
Linked Markers	

#### Marker Table Display

Defines how the marker information is displayed.

"On" Displays the marker information in a table in a separate area beneath the diagram.

"Off" No separate marker table is displayed.

Remote command:

DISPlay[:WINDow<n>]:MTABle on page 530

#### Linked Markers

If enabled, the markers in all diagrams with the same x-axis are linked, i.e. when you move a marker in one window, the markers in all other windows are moved to the same x-value.

Remote command: CALCulate<n>:MARKer<m>:LINK on page 530

# 11.4.3 Marker Search Settings and Positioning Functions

Several functions are available to set the marker to a specific position quickly and easily, or to use the current marker position to define another characteristic value. In order to determine the required marker position, searches can be performed. The search results can be influenced by special settings.

Most marker positioning functions and the search settings are available in the [MKR  $\rightarrow$ ] menu.

Search settings are also available via the [Marker] key or in the vertical "Marker Config" tab of the "Analysis" dialog box (horizontal "Search Settings" tab).

#### 11.4.3.1 Marker Search Settings

Access: "Overview" > "Analysis" > "Markers" > "Search"

Markers are commonly used to determine peak values, i.e. maximum or minimum values, in the measured signal. Configuration settings allow you to influence the peak search results.

Markers	Marker Settings	Search Config	
Next Pea	k Mode Left	bsolute Right	
Peak Exc	ursion 1.0 dB		

The remote commands required to define marker search are described in Chapter 15.7.4.3, "Marker Search", on page 531.

Search Mode for Next Peak	
Peak Excursion	
Spurious Tracking	230

#### **Search Mode for Next Peak**

Selects the search mode for the next peak search.

"Left"	Determines the next maximum/minimum to the left of the current peak.
"Absolute"	Determines the next maximum/minimum to either side of the current peak.
"Right"	Determines the next maximum/minimum to the right of the current peak.

Remote command:

Find a list of remote commands in Chapter 15.7.4.4, "Positioning Markers", on page 532.

#### **Peak Excursion**

Defines the minimum level value by which a signal must rise or fall so that it is identified as a maximum or a minimum by the search functions.

Entries from 0 dB to 60 dB are allowed; the resolution is 0.1 dB. The default setting for the peak excursion is 1 dB.

For transient measurements, the peak excursion is either a value in Hz (frequency diagram) or rad / deg (phase diagram). The value range is from 0 Hz to 10 MHz (default: 50 kHz) and 0 rad to 10 rad (default: 0.5 rad) respectively.

#### Remote command:

CALCulate<n>:MARKer<m>:PEXCursion on page 531

#### **Spurious Tracking**

Spurs can be unstable regarding their frequency characteristics. In such cases, markers would not remain on the spur, but on the frequency you have set them on initially.

You can avoid this situation using spurious tracking. Spur tracking makes sure that the marker remains on the spur, even if the spur changes its frequency. When you turn on spur tracking, you can define a frequency range within which the R&S FSWP tracks the spur and adjusts the marker position automatically.

The tracking "Range" defines an area around the marker position and is a function of the resolution bandwidth (RBW) used in the half decade the marker is in. Note that the tracking range is dynamic and always relative to the latest marker position, not the initial marker position.

#### Example:

You are measuring with an RBW of 10 kHz and place the marker on a spur.

The tracking range is defined as 1 \* RBW = 10 kHz.

If the spur changes its position by up to  $\pm 10$  kHz, the R&S FSWP changes the marker position along with the spur.

Note that the spurious list contains the tracked spurs and always shows the latest position of the spur.

Remote command: State: CALCulate<n>:MARKer<m>:FUNCtion:SPTRacking[:STATe] on page 532 Range: CALCulate<n>:MARKer<m>:FUNCtion:SPTRacking:RANGe on page 531

#### 11.4.3.2 Positioning Functions

#### Access: [MKR →]

The following functions set the currently selected marker to the result of a peak search or set other characteristic values to the current marker value.

The remote commands required to position markers are described in Chapter 15.7.4.4, "Positioning Markers", on page 532.

Peak Search	231
Search Next Peak	
Search Minimum	
Search Next Minimum	

#### **Peak Search**

Sets the selected marker/delta marker to the maximum of the trace. If no marker is active, marker 1 is activated.

#### Remote command:

CALCulate<n>:MARKer<m>:MAXimum[:PEAK] on page 535 CALCulate<n>:DELTamarker<m>:MAXimum[:PEAK] on page 533

#### Search Next Peak

Sets the selected marker/delta marker to the next (lower) maximum of the assigned trace. If no marker is active, marker 1 is activated.

#### Remote command:

CALCulate<n>:MARKer<m>:MAXimum:NEXT on page 534 CALCulate<n>:MARKer<m>:MAXimum:RIGHt on page 535 CALCulate<n>:MARKer<m>:MAXimum:LEFT on page 534 CALCulate<n>:DELTamarker<m>:MAXimum:NEXT on page 533 CALCulate<n>:DELTamarker<m>:MAXimum:RIGHt on page 533 CALCulate<n>:DELTamarker<m>:MAXimum:LEFT on page 532

#### Search Minimum

Sets the selected marker/delta marker to the minimum of the trace. If no marker is active, marker 1 is activated.

#### Remote command:

CALCulate<n>:MARKer<m>:MINimum[:PEAK] on page 536 CALCulate<n>:DELTamarker<m>:MINimum[:PEAK] on page 534

#### **Search Next Minimum**

Sets the selected marker/delta marker to the next (higher) minimum of the selected trace. If no marker is active, marker 1 is activated.

Remote command:

```
CALCulate<n>:MARKer<m>:MINimum:NEXT on page 535
CALCulate<n>:MARKer<m>:MINimum:LEFT on page 535
CALCulate<n>:MARKer<m>:MINimum:RIGHt on page 536
CALCulate<n>:DELTamarker<m>:MINimum:NEXT on page 534
CALCulate<n>:DELTamarker<m>:MINimum:LEFT on page 533
CALCulate<n>:DELTamarker<m>:MINimum:LEFT on page 533
```

# 11.5 Limit Lines

Limit lines help you analyze a measurement trace.

# 11.5.1 Basics on Limit Lines

Limit lines are used to define amplitude curves or spectral distribution boundaries in the result diagram which are not to be exceeded. They indicate, for example, the upper limits for interference radiation or spurious waves which are allowed from a device under test (DUT). When transmitting information in TDMA systems (e.g. GSM), the amplitude of the bursts in a time slot must adhere to a curve that falls within a specified tolerance band. The lower and upper limits may each be specified by a limit line. Then, the amplitude curve can be controlled either visually or automatically for any violations of the upper or lower limits (GO/NOGO test).

The R&S FSWP supports limit lines with a maximum of 200 data points. Eight of the limit lines stored in the instrument can be activated simultaneously. The number of limit lines stored in the instrument is only limited by the capacity of the storage device used.

Limit line data can also be exported to a file in ASCII (CSV) format for further evaluation in other applications. Limit lines stored in the specified ASCII (CSV) format can also be imported to the R&S FSWP for other measurements.

## Compatibility

Limit lines are compatible with the current measurement settings, if the following applies:

- The x unit of the limit line has to be identical to the current setting.
- The y unit of the limit line has to be identical to the current setting.

#### Validity

Only limit lines that fulfill the following conditions can be activated:

- Each limit line must consist of a minimum of 2 and a maximum of 200 data points.
- The frequencies/times for each data point must be defined in ascending order; however, for any single frequency or time, two data points may be entered (to define a vertical segment of a limit line).
- Gaps in frequency or time are not allowed. If gaps are desired, two separate limit lines must be defined and then both enabled.
- The entered frequencies or times need not necessarily be selectable in R&S FSWP. A limit line may also exceed the specified frequency or time range. The minimum frequency for a data point is -200 GHz, the maximum frequency is 200 GHz. For the time range representation, negative times may also be entered. The allowed range is -1000 s to +1000 s.





Figure 11-9: Example for an upper limit line

# Thresholds

If the y-axis for the limit line data points uses relative scaling, an additional absolute **threshold** can be defined for the limit check. In this case, both the threshold value and the relative limit line must be exceeded before a violation occurs.



# **Offsets and Shifting**

A configured limit line can easily be moved vertically or horizontally. Two different methods to do so are available:

 An offset moves the entire line in the diagram without editing the configured values or positions of the individual data points. This option is only available if relative scaling is used.

Thus, a new limit line can be easily generated based upon an existing limit line which has been shifted horizontally or vertically.

 Defining a shift width for the values or position of the individual data points changes the line configuration, thus changing the position of the line in the diagram.

# Limit Check Results

A limit check is automatically performed as soon as any of the limit lines is activated ("Visibility" setting). Only the specified "Traces to be Checked" are compared with the active limit lines. The status of the limit check for each limit line is indicated in the diagram. If a violation occurs, the limit check status is set to "MARG" for a margin violation, or to "Fail" for a limit violation.

Limit Lines




Figure 11-10: Margin violation for limit check

MultiView	Spectrur	n					
Ref Level 0.00		RBW 50		r.			
1 Frequency S		2 Ha	Prote mond parts in				• LAP Clrw
Limit Check Line UPPER	k		FAIL.		D2[1] M1[1]		-53,97 dB 3,3970 MHz -84,81 dBm 30,0000 MHz
UPPLELIME				$\wedge$			
-10 d8m							
-sto /iBir							
-76 den							
-st. 50m						A Min	
<b>N</b> M	1/1		H HAN				
CF 20.0 MHz			1001 pts		4.0 MHz/		Span 40.0 MHz

Figure 11-11: Limit violation for limit check

# (i

# Storing and Recalling Limit Lines

Limit lines can be stored with the configuration settings so they can be recalled for other measurements at a later time (see Chapter 12.3, "Storing and Recalling Instrument Settings and Measurement Data", on page 247). Note, however, that any changes made to the limit lines *after* storing the configuration file cannot be restored and will be overwritten by the stored values when the configuration file is recalled. Always remember to store the settings again after changing the limit line values.

After recalling measurement settings, the limit line values applied to the measurement may be different to those displayed in the "Limit Lines" dialog box; see "Saving and recalling transducer and limit line settings" on page 248.

# 11.5.2 Limit Line Settings and Functions

Access: "Overview" > "Analysis" > "Lines"

or: [LINES] > "Line Config"

Up to 8 limit lines can be displayed simultaneously in the R&S FSWP. Many more can be stored on the instrument.



# Stored limit line settings

When storing and recalling limit line settings, consider the information provided in "Saving and recalling transducer and limit line settings" on page 248.

# 11.5.2.1 Limit Line Management

Access: "Overview" > "Analysis" > "Lines" > "Limit Lines"

or: [LINES] > "Line Config" > "Limit Lines"

For the limit line overview, the R&S FSWP searches for all stored limit lines with the file extension .LIN in the limits subfolder of the main installation folder. The overview allows you to determine which limit lines are available and can be used for the current measurement.

For details on settings for individual lines see Chapter 11.5.2.2, "Limit Line Details", on page 238.

For more basic information on limit lines see Chapter 11.5.1, "Basics on Limit Lines", on page 232.

Name	237
Unit	
Compatibility	
Visibility	
Traces to be Checked	
Comment	

#### Limit Lines

Included Lines in Overview (View Filter)	237
Create New Line	
Edit Line	238
Copy Line	238
Delete Line	238
Disable All Lines	238

## Name

The name of the stored limit line.

#### Unit

The unit in which the y-values of the data points of the limit line are defined.

#### Compatibility

Indicates whether the limit line definition is compatible with the current measurement settings.

For more information on which conditions a limit line must fulfill to be compatible, see "Compatibility" on page 232.

#### Visibility

Displays or hides the limit line in the diagram. Up to 8 limit lines can be visible at the same time. Inactive limit lines can also be displayed in the diagram.

Remote command:

CALCulate<n>:LIMit:LOWer:STATe on page 539 CALCulate<n>:LIMit:UPPer:STATe on page 541 CALCulate<n>:LIMit:ACTive? on page 538

#### **Traces to be Checked**

Defines which traces are automatically checked for conformance with the limit lines. As soon as a trace to be checked is defined, the assigned limit line is active. One limit line can be activated for several traces simultaneously. If any of the "Traces to be Checked" violate any of the active limit lines, a message is indicated in the diagram.

Remote command:

CALCulate<n>:LIMit:TRACe<t>:CHECk on page 541

#### Comment

An optional description of the limit line.

#### Included Lines in Overview (View Filter)

Defines which of the stored lines are included in the overview.

"Show Com- patible"	Only compatible lines Whether a line is compatible or not is indicated in the Compatibility setting.
"Show All"	All stored limit lines with the file extension .LIN in the limits sub- folder of the main installation folder (if not restricted by "Show Lines for all Modes" setting).

Limit Lines

**Create New Line** Creates a new limit line.

**Edit Line** Edit an existing limit line configuration.

**Copy Line** Copy the selected limit line configuration to create a new line.

Remote command: CALCulate<n>:LIMit:COPY on page 538

### **Delete Line**

Delete the selected limit line configuration. Remote command: CALCulate<n>:LIMit:DELete on page 539

#### **Disable All Lines**

Disable all limit lines in one step.

Remote command: CALCulate<n>:LIMit:STATe on page 540

## 11.5.2.2 Limit Line Details

Access: "Overview" > "Analysis" > "Lines" > "Limit Lines" > "New" / "Edit" / "Copy To"

or: [LINES] > "Line Config" > "Limit Lines" > "New" / "Edit" / "Copy To"

Name	
Comment	
X-Axis	
Y-Axis	
Data Points	239
Insert Value	
Delete Value	
Shift x	
Shift y	
Save	

#### Name

Defines the limit line name. All names must be compatible with Windows conventions for file names. The limit line data is stored under this name (with a .LIN extension).

Remote command: CALCulate<n>:LIMit:NAME on page 546

#### Comment

Defines an optional comment for the limit line.

#### Remote command:

CALCulate<n>:LIMit:COMMent on page 542

### X-Axis

Describes the horizontal axis on which the data points of the limit line are defined. Includes the following settings:

- Unit:
  - "Hz" : for frequency domain
  - "s" : for time domain
  - V: for VCO Characterization or Spot Noise vs Tune
  - mA: for VCO Characterization or Spot Noise vs Tune
- Scaling mode: absolute or relative values Not supported
- Scaling: linear or logarithmic

#### Remote command:

CALCulate<n>:LIMit:LOWer:MODE on page 544 CALCulate<n>:LIMit:UPPer:MODE on page 547 CALCulate<n>:LIMit:CONTrol:DOMain on page 543 CALCulate<n>:LIMit:CONTrol:SPACing on page 544

#### **Y-Axis**

Describes the vertical axis on which the data points of the limit line are defined. Includes the following settings:

- Level unit
- Scaling mode: absolute or relative (dB/%) values Relative limit values refer to the center frequency (frequency diagram) or the reference value (phase diagram).
- Limit type: upper or lower limit; values must stay above the lower limit and below the upper limit to pass the limit check

Available for transient measurements.

#### Remote command:

```
CALCulate<n>:LIMit:UNIT on page 546
CALCulate<n>:LIMit:LOWer:SPACing on page 545
CALCulate<n>:LIMit:UPPer:SPACing on page 547
```

#### **Data Points**

Each limit line is defined by a minimum of 2 and a maximum of 200 data points. Each data point is defined by its position (x-axis) and value (y-value). Data points must be defined in ascending order. The same position can have two different values.

Remote command:

```
CALCulate<n>:LIMit:CONTrol[:DATA] on page 542
CALCulate<n>:LIMit:LOWer[:DATA] on page 544
CALCulate<n>:LIMit:UPPer[:DATA] on page 546
```

#### Insert Value

Inserts a data point in the limit line above the selected one in the "Edit Limit Line" dialog box.

#### **Delete Value**

Deletes the selected data point in the "Edit Limit Line" dialog box.

# Shift x

Shifts the x-value of each data point horizontally by the defined shift width.

Remote command:

CALCulate<n>:LIMit:CONTrol:SHIFt on page 543

#### Shift y

Shifts the y-value of each data point vertically by the defined shift width.

Remote command: CALCulate<n>:LIMit:LOWer:SHIFt on page 545 CALCulate<n>:LIMit:UPPer:SHIFt on page 547

#### Save

Saves the currently edited limit line under the name defined in the "Name" field.

# 11.5.3 How to Define Limit Lines

Access: "Overview" > "Analysis" > "Lines" > "Limit Lines"

or: [LINES] > "Line Config" > "Limit Lines"

The following tasks are described here:

- "How to find compatible limit lines" on page 240
- "How to activate and deactivate a limit check" on page 240
- "How to edit existing limit lines" on page 241
- "How to copy an existing limit line" on page 241
- "How to delete an existing limit line" on page 241
- "How to configure a new limit line" on page 241
- "How to move the limit line vertically or horizontally" on page 242

#### How to find compatible limit lines

▶ In the "Line Config" dialog box, select the "View Filter" option: "Show Compatible" .

All stored limit lines with the file extension .LIN in the limits subfolder of the main installation folder of the instrument that are compatible to the current measurement settings are displayed in the overview.

#### How to activate and deactivate a limit check

A limit check is automatically performed as soon as any of the limit lines is activated.

1. To activate a limit check:

Select the "Check Traces" setting for a limit line in the overview and select the trace numbers to be included in the limit check. One limit line can be assigned to several traces.

The specified traces to be checked are compared with the active limit lines. The status of the limit check is indicated in the diagram.

2. To deactivate a limit line, deactivate all "Traces to be Checked" for it.

To deactivate all limit lines at once, select the "Disable All Lines" button.

The limit checks for the deactivated limit lines are stopped and the results are removed form the display.

#### How to edit existing limit lines

Existing limit line configurations can be edited.

- 1. In the "Line Config" dialog box, select the limit line.
- 2. Select the "Edit" button.
- Edit the line configuration as described in "How to configure a new limit line" on page 241.
- 4. Save the new configuration by selecting the "Save" button.

If the limit line is active, the edited limit line is displayed in the diagram.

### How to copy an existing limit line

- 1. In the dialog box, select the limit line.
- 2. Select the "Line Config" "Copy To" button.
- Define a new name to create a new limit with the same configuration as the source line.
- Edit the line configuration as described in "How to configure a new limit line" on page 241.
- 5. Save the new configuration by selecting the "Save" button.

The new limit line is displayed in the overview and can be activated.

#### How to delete an existing limit line

- 1. In the "Line Config" dialog box, select the limit line.
- 2. Select the "Delete" button.
- 3. Confirm the message.

The limit line and the results of the limit check are deleted.

#### How to configure a new limit line

1. In the "Line Config" dialog box, select the "New" button.

The "Edit Limit Line" dialog box is displayed. The current line configuration is displayed in the preview area of the dialog box. The preview is updated after each change to the configuration.

- 2. Define a "Name" and, optionally, a "Comment" for the new limit line.
- 3. Define the x-axis configuration:
  - Time domain or frequency domain

- Absolute or relative limits
- Linear or logarithmic scaling
- 4. Define the y-axis configuration:
  - Level unit
  - Absolute or relative limits
  - Upper or lower limit line
- 5. Define the data points: minimum 2, maximum 200:
  - a) Select "Insert Value" .
  - b) Define the x-value ( "Position" ) and y-value ( "Value" ) of the first data point.
  - c) Select "Insert Value" again and define the second data point.
  - d) Repeat this to insert all other data points.

To insert a data point before an existing one, select the data point and then "Insert Value" .

To insert a new data point at the end of the list, move the focus to the line after the last entry and then select "Insert Value".

To delete a data point, select the entry and then "Delete Value" .

- Check the current line configuration in the preview area of the dialog box. If necessary, correct individual data points or add or delete some.
   If necessary, shift the entire line vertically or horizontally by selecting the "Shift x" or "Shift y" button and defining the shift width.
- Optionally, define a "Margin" at a fixed distance to the limit line. The margin must be within the valid value range and is not displayed in the diagram or preview area.
- 8. Optionally, if the y-axis uses relative scaling, define an absolute "Threshold" as an additional criteria for a violation.
- 9. Save the new configuration by selecting the "Save" button.

The new limit line is displayed in the overview and can be activated.

### How to move the limit line vertically or horizontally

A configured limit line can easily be moved vertically or horizontally. Thus, a new limit line can be easily generated based upon an existing limit line which has been shifted horizontally.

- 1. In the "Line Config" dialog box, select the limit line.
- To shift the complete limit line parallel in the horizontal direction, select the "X-Offset" button and enter an offset value.
   To shift the complete limit line parallel in the vertical direction, select the "Y-Offset" button and enter an offset value.
- 3. To shift the individual data points of a limit line by a fixed value (all at once):
  - a) Select the "Edit" button.
  - b) In the "Edit Limit Line" dialog box, select the "Shift x" or "Shift y" button and define the shift width.

c) Save the shifted data points by selecting the "Save" button.

If activated, the limit line is shifted in the diagram.

# 12 Data Management

The R&S FSWP allows you to store and load instrument settings, as well as import and export measurement data for analysis later. Finally, you can store or print the measurement results displayed on the screen.

General storage and import/export functions are available via the toolbar. Some special storage functions are (also) available via softkeys or dialog boxes in the corresponding menus, for example trace data export.

# 12.1 Restoring the Default Instrument Configuration (Preset)

When delivered, the R&S FSWP has a default configuration. You can restore this defined initial state at any time as a known starting point for measurements. This is often recommendable as a first step in troubleshooting when unusual measurement results arise.



#### Factory default configuration

The factory default configuration is selected such that the RF input is always protected against overload, provided that the applied signal levels are in the allowed range for the instrument.

Alternatively to the factory default settings, you can define user-specific recall settings to be restored after a preset or reboot, see "To recall settings automatically after preset or reboot" on page 258.

#### To restore the default instrument configuration for all channels at once

Press the [PRESET] key.



After you use the [PRESET] function, the history of previous actions is deleted, i.e. any actions performed previously cannot be undone or redone using the [UNDO/REDO] keys.

#### Remote command:

\*RST or SYSTem: PRESet

#### To restore the default configuration for a single channel

The default measurement settings can also be reset for an individual channel only, rather than resetting the entire instrument.

In the "Overview", select the "Preset Channel" button.

The factory default settings are restored to the current channel. Note that a userdefined recall settings file is **NOT** restored.

#### **Remote command:**

SYSTem:PRESet:CHANnel[:EXEC] on page 564

# 12.2 Protecting Data Using the Secure User Mode

During normal operation, the R&S FSWP uses a solid-state drive to store its operating system, instrument firmware, instrument self-alignment data, and any user data created during operation.

#### Redirecting storage to volatile memory

Alternatively, to avoid storing any sensitive data on the R&S FSWP permanently, the *secure user mode* was introduced (option R&S FSWP-K33). In secure user mode, the instrument's solid-state drive is write-protected so that no information can be written to memory permanently. Data that the R&S FSWP normally stores on the solid-state drive is redirected to volatile memory instead, which remains available only until the instrument is switched off. This data includes:

- Windows operating system files
- Firmware shutdown files containing information on last instrument state
- Self-alignment data
- General instrument settings such as the IP address
- Measurement settings
- User data created during operation (see also Table 12-1)
- Any data created by other applications installed on the R&S FSWP, for example, text editors (Notepad), the clipboard, or drawing tools.

Users can access data that is stored in volatile memory just as in normal operation. However, when the instrument's power is switched off, all data in this memory is cleared. Thus, in secure user mode, the instrument always starts in a defined, fixed state when switched on.

To store data such as measurement results permanently, it must be stored to an external storage device, such as a memory stick.

# í

#### Limited storage space

The volatile memory used to store data in secure user mode is restricted to 256 MB. Thus, a "Memory full" error can occur although the hard disk indicates that storage space is still available.

#### Storing required data permanently

Any data that is to be available for subsequent sessions with the R&S FSWP must be stored on the instrument permanently, *before activating the secure user mode*. This includes predefined instrument settings, transducer factors and self-alignment data.



## Self-alignment data

Note that self-alignment data becomes invalid with time and due to temperature changes. Therefore, to achieve optimal accuracy, it can be preferable to perform a new self-alignment at the start of each new session on the R&S FSWP.

#### **Restricted operation**

Since permanent storage is not possible, the following functions are not available in secure user mode:

- Firmware update
- Activating a new option key

Furthermore, since the "SecureUser" used in secure user mode does not have administrator rights, **administrative tasks** such as LAN configuration and some general instrument settings are not available. Refer to the description of the basic instrument setup ([SETUP] menu) to find out which functions are affected.

#### Activating and deactivating secure user mode

Only a user with administrator rights can activate (and deactivate) the secure user mode. Once activated, a restart is required. The special user "SecureUser" is then logged on to the R&S FSWP automatically using the auto-login function. While the secure user mode is active, a message is displayed in the status bar at the bottom of the screen.

# (j

#### Secure passwords

By default, the initial password for both the administrator account and the "Secure-User" account is "894129". When the secure user mode is activated the first time after installation, you are prompted to change the passwords for all user accounts to improve system security. Although it is possible to continue without changing the passwords, it is strongly recommended that you do so.

You can change the password in Microsoft Windows for any user at any time via: "Start > Settings > Account > SignIn Options > Password > Change"

To deactivate the secure user mode, the "SecureUser" must log off and a user with administrator rights must log on.



#### Switching users when using the auto-login function

In the "Start" menu, select the arrow next to the "Shut down" button and then "Log off". The "Login" dialog box is displayed, in which you can enter the different user account name and password.

The secure user mode setting and auto-login is automatically deactivated when another user logs on. The "SecureUser" is no longer available.

For users with administrator rights, the secure user mode setting is available in the general system configuration settings (see "SecureUser Mode" on page 302).

#### **Remote control**

Initially after installation of the R&S FSWP-K33 option, secure user mode must be enabled manually once before remote control is possible.

(See SYSTem: SECurity [:STATe].)

Manual activation is necessary to prompt for a change of passwords.

# 12.3 Storing and Recalling Instrument Settings and Measurement Data



F)

Access: "Save" / "Open" icon in the toolbar

Possibly you would like to restore or repeat a measurement you performed under specific conditions on the instrument. Or you want to evaluate imported data in another application on the R&S FSWP and would like to restore the measurement settings applied during measurement. In these cases, you can store and recall instrument and measurement settings, and possibly other related measurement data.

Two different methods are available for managing instrument settings:

- Quick Save/Quick Recall a defined set of instrument settings or channels are stored or recalled quickly in just one step
- Configurable Save/Recall a user-defined set of instrument settings or channels are stored to a definable storage location



#### Restrictions when recalling measurement settings

When recalling a saved configuration file, the following restrictions apply:

- The R&S FSWP must support the frequency range defined in the configuration file.
- Configuration files created on a R&S FSWP with certain options in use do not work on an R&S FSWP without these options.
- Files created with newer firmware versions may not work with a previous version.
- Files created on an instrument other than the R&S FSWP do not work on the R&S FSWP.

#### Storing and Recalling Instrument Settings and Measurement Data

# (j

## Saving instrument settings in secure user mode

Be sure to store instrument settings that you require beyond the current session before SecureUser Mode is enabled; see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

Settings that are saved via QuickSave in secure user mode are only available during the current session. As soon as the power is switched off on the R&S FSWP, the data is cleared.

#### Saving and recalling transducer and limit line settings

If a limit lines file was in use when the save set was stored (with the save item "Current Settings" only) the R&S FSWP assumes that these limit lines values should remain valid after every recall of that save set. Thus, even if the limit lines file is changed and the original save set file is recalled later, the *originally stored* limit lines values are recalled and applied to the measurement. In the "Edit" limit lines dialog box, however, the *changed* limit lines file values are displayed, as no updated limit lines file was loaded.

The same applies to limit line settings.

The same applies to integrated measurements' weighting filter.

Similarly, if you want to apply the changed limit values after recalling the save set, you must force the application to reload the limit file. To do so, simply open the "Edit Limit Line" dialog box (see Chapter 11.5.2, "Limit Line Settings and Functions", on page 236) and toggle the "Y-Axis" unit. Due to that change, the limit line file is automatically reloaded, and the changed limit values are applied to the current measure-

matically reloaded, and the changed limit values are applied to the current measurement. Now a new save set with the updated limit values can be created.

- How to Save and Load Instrument Settings......256

# 12.3.1 Quick Save/Quick Recall

The "Quick Save" and "Quick Recall" functions allow you to store instrument settings or channels very easily and quickly in one step. Up to ten different sets of settings can be stored to or recalled from "save sets". Each save set is identified by its storage date and type (instrument or specific "Channel") in the display. The save sets are stored in the C:\R\_S\INSTR\QuickSave directory, in files named QuickSave1.dfl to QuickSave10.dfl. Only the current measurement settings are stored, not any additional data such as traces, limit line or transducer files (see Chapter 12.3.2.1, "Stored Data Types", on page 251). Source calibration files for an optional external generator, if available, are included.

#### Storing and Recalling Instrument Settings and Measurement Data



#### Saving instrument settings in secure user mode

Settings that are saved via Quick Save in secure user mode are stored to the SDRAM, and are only available during the current session. As soon as the power is switched off on the R&S FSWP, the data is cleared (see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31).

During recall, save sets of type "Instrument" replace the settings of the entire instrument. All other save sets start a new channel with the stored settings.



If a channel with the same name as the "Channel" to be restored is already active, the name for the new channel is extended by a consecutive number:



#### 12.3.1.1 Quick Save / Quick Recall Settings



Þ

Access: "Save" / "Open" icon in the toolbar > "Quick Save" / "Quick Recall"

Both dialog boxes are very similar and closely related.

Save				<b>• ×</b>
Quick Save Sav	e			
Save Sets				
QuickSave 1	QuickSave 2	QuickSave 3	QuickSave 4	QuickSave 5
QuickSave 6	QuickSave 7	QuickSave 8	QuickSave 9	QuickSave 10
Туре:				
In with	nstrument 1 all Channels			
	rent Channel: Spectrum			

#### Storing and Recalling Instrument Settings and Measurement Data

QuickSave 1 / / QuickSave 10	250
L Rename	
L Write Protection	
Storage Type (Save only)	
Recall	

#### QuickSave 1 / ... / QuickSave 10

Selects one of the save sets to store the current settings in or to be recalled. At the time of storage, the "QuickSave 1 / ... / QuickSave 10" placeholder is replaced by a label indicating the storage date and time and the storage type.

Right-click on one of the QuickSave buttons to display a context menu with additional functions for the save set.

Save	Sets	
Ou	ickSave 1	QuickSave 2
		<b>C</b>
	Rename	<u>ا</u>
	Write Pr	rotection

During recall, save sets of type "Instrument" replace the settings of the entire instrument. All other save sets start a new channel with the stored settings.

**Note:** Saving instrument settings in secure user mode.

Settings that are saved via Quick Save in secure user mode are only available during the current session. As soon as the power is switched off on the R&S FSWP, the data is cleared (see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31).

### Rename ← QuickSave 1 / ... / QuickSave 10

Displays an input field to rename the save set, if write protection is disabled.

#### Write Protection ← QuickSave 1 / ... / QuickSave 10

Enables or disables write protection for the save set. If enabled, the save set cannot be renamed or overwritten.

#### Storage Type (Save only)

Defines which type of settings are stored in the save set.

"Instrument The instrument settings for all currently active "Channel" s are stored. with all Chan-

nels"

"Current Chan- Only the instrument settings for the currently selected measurement nel" "Channel" s are stored.

#### Recall

Restores the instrument settings as saved in the selected settings file. If the settings file contains settings for a specific "Channel" only, a new channel with the stored settings is activated, otherwise all "Channel" s and instrument settings are overwritten with the stored settings.

**Note:** After you use the "Recall" function, the history of previous actions is deleted, i.e. any actions performed previously cannot be undone or redone using the [UNDO/ REDO] keys.

Remote command: MMEMory:LOAD:STATe on page 562

# 12.3.2 Configurable Storage and Recall

The more sophisticated storage and recall functions allow you to define which settings are stored, and where the settings file is stored to. Any settings file can be selected for recall.

- Startup Recall Settings......255

#### 12.3.2.1 Stored Data Types

The following types of data can be stored to and loaded from files via the "Save" dialog box on the R&S FSWP:

Item	Description
Current Settings	Current instrument and measurement settings.
All Transducers	All transducer factor <i>files</i> . (Note: Restoring a saveset overwrites transducer factor files on the hard disk that have the same name as those in the saveset. For more information, see "Saving and recalling transducer and limit line settings" on page 248.) (Not in the phase noise application.)
All Traces	All active traces.
All Limit Lines	All limit line <i>files</i> .
All Weighting Filters	All weighting filter <i>files</i> . (Only in the phase noise application.)
Spectrograms	Spectrogram trace data (only available if spectrogram display is currently active). (Only in applications that feature a spectrogram, for example the (optional) spectrum application.)

Table 12-1: Items that can be stored to files

#### 12.3.2.2 Storage Location and Filename

The data is stored on the internal flash disk or, if selected, on a memory stick or network drive. The operating system, firmware and stored instrument settings are located on drive C.



#### Saving instrument settings in secure user mode

In secure user mode all data is stored to the SDRAM, and is only available during the current session. As soon as the power is switched off on the R&S FSWP, the data is cleared (see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31). Other storage locations cannot be selected in this mode.

The storage location and filename are selected in a file selection dialog box which is displayed when you perform a storage function.

By default, the name of a settings file consists of a base name followed by an underscore and three numbers, e.g. limit\_lines\_005. In the example, the base name is limit\_lines. The base name can contain characters, numbers and underscores. The file extension dfl is added automatically. The default folder for settings files is C:\R S\INSTR\Save.



#### File name restrictions

File names must be compatible with the Windows conventions for file names. In particular, they must not contain special characters such as ":", "\*", "?".

#### 12.3.2.3 Save and Recall Dialog Boxes




F)

Access: "Save" / "Open" icon in the toolbar > "Save" / "Recall"

Both dialog boxes are very similar and closely related.

### Storing and Recalling Instrument Settings and Measurement Data



Selecting Storage Location - Drive/ Path/ Files	253
File Name	254
Comment	254
File Explorer	. 254
File Type	254
Items:	. 254
Save File	. 254
Recall in New Channel / Recall in Current Channel	255

### Selecting Storage Location - Drive/ Path/ Files

Select the storage location of the file on the instrument or an external drive.

Note: Saving instrument settings in secure user mode.

In secure user mode, settings that are stored on the instrument are stored to volatile memory, which is restricted to 256 MB. Thus, a "memory limit reached" error can occur although the hard disk indicates that storage space is still available.

To store data permanently, select an external storage location such as a USB memory device.

For details, see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

Remote command:

MMEMory: CATalog on page 553

### **File Name**

Contains the name of the data file without the path or extension.

By default, the name of a user file consists of a base name followed by an underscore. Multiple files with the same base name are extended by three numbers, e.g. limit\_lines\_005.

File names must be compatible with the Windows conventions for file names. In particular, they must not contain special characters such as ":", "\*", "?".

For details on the filename and location, see Chapter 12.3.2.2, "Storage Location and Filename", on page 252.

### Comment

An optional description for the data file. A maximum of 60 characters can be displayed.

Remote command: MMEMory:COMMent on page 554

### **File Explorer**

Opens the Microsoft Windows File Explorer.

Remote command: not supported

### File Type

Determines whether the global instrument settings with all "Channel" s are stored or recalled, or the current "Channel" settings only.

### Items:

Defines which data and settings are stored or are recalled. Depending on the "File Type", either channels only, or global settings are available. Which items are available also depends on the installed options (see also Chapter 12.3.2.1, "Stored Data Types", on page 251).

Depending on the application, items may or may not be available. For example, saving spectrogram data is only possible in applications that feature a spectrogram.

# Remote command:

```
MMEMory:Select[:ITEM]:All on page 559
MMEMory:Select[:ITEM]:DeFault on page 559
MMEMory:Select[:ITEM]:NONE on page 560
MMEMory:Select[:ITEM]:HWSettings on page 559
MMEMory:Select[:ITEM]:LINes:All on page 560
MMEMory:Select[:ITEM]:SGRam on page 560
MMEMory:Select[:ITEM]:TRACe<1...3>[:ACTive] on page 560
MMEMory:Select[:ITEM]:TRANsducer:All on page 561
```

### Save File

Saves the settings file with the defined filename.

**Note:** Secure user mode. In secure user mode, settings that are stored on the instrument are stored to volatile memory, which is restricted to 256 MB. Thus, a "memory limit reached" error can occur although the hard disk indicates that storage space is still available.

#### Storing and Recalling Instrument Settings and Measurement Data

For details, see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

Remote command:

MMEMory:STORe<1|2>:STATe on page 563
MMEMory:STORe<1|2>:STATe:NEXT on page 563

### **Recall in New Channel / Recall in Current Channel**

Access: "Open" icon in the toolbar > "Startup Recall"

Restores the instrument settings as saved in the selected settings file. If the settings file contains settings for a specific "Channel" only, select "Recall in New Channel" to activate a new channel with the stored settings. Select "Recall in Current Channel" to replace the current "Channel" settings.

**Note:** After you use the "Recall" function, the history of previous actions is deleted, i.e. any actions performed previously cannot be undone or redone using the [UNDO/ REDO] keys.

Remote command: MMEMory:LOAD:STATe on page 562

# 12.3.2.4 Startup Recall Settings

F P

Quick Recall
Recall

Startup Recall
On Off

Select File

Drive: 
C:) OS Path: 
QuickSave (C:/Applications/FSWP/
Files
Size
...
QuickSave 1.dfl
Pile Name
QuickSave 1.dfl
QuickSave 1.dfl
Comment
QuickSave I.dfl
Select File

Startup Recall	255
Selecting Storage Location - Drive/ Path/ Files	
File Name	
Comment	256

### Startup Recall

Activates or deactivates the startup recall function. If activated, the settings stored in the selected file are loaded each time the instrument is started or preset. If deactivated, the default settings are loaded.

Note that only *instrument* settings files can be selected for the startup recall function, not "Channel" files.

Remote command:

MMEMory:LOAD:AUTO on page 562

### Selecting Storage Location - Drive/ Path/ Files

Select the storage location of the file on the instrument or an external drive.

Note: Saving instrument settings in secure user mode.

In secure user mode, settings that are stored on the instrument are stored to volatile memory, which is restricted to 256 MB. Thus, a "memory limit reached" error can occur although the hard disk indicates that storage space is still available.

To store data permanently, select an external storage location such as a USB memory device.

For details, see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

Remote command: MMEMory:CATalog on page 553

### File Name

Contains the name of the data file without the path or extension.

By default, the name of a user file consists of a base name followed by an underscore. Multiple files with the same base name are extended by three numbers, e.g. limit lines 005.

File names must be compatible with the Windows conventions for file names. In particular, they must not contain special characters such as ":", "\*", "?".

For details on the filename and location, see Chapter 12.3.2.2, "Storage Location and Filename", on page 252.

#### Comment

An optional description for the data file. A maximum of 60 characters can be displayed. Remote command:

MMEMory:COMMent on page 554

# 12.3.3 How to Save and Load Instrument Settings

Instrument settings can be saved to a file and loaded again later, so that you can repeat the measurement with the same settings. Optionally, user-defined measurement settings can automatically be restored each time you start or preset the instrument.

### To save and recall instrument settings using the Quick Save function



- 1. Select the "Save" icon from the toolbar.
- Select whether the instrument settings for all "Channel" s are stored, or only those for the current "Channel".

## Storing and Recalling Instrument Settings and Measurement Data

3. Select one of the save sets in which the settings are stored ( "QuickSaveX" ).

The selected settings are stored to the file

C:\R\_S\INSTR\QuickSave\QuickSaveX.dfl.

**Note:** If you make any changes to the settings *after* storing the configuration file, remember to save the settings again. Otherwise those settings cannot be restored and will be overwritten by the stored values when the configuration file is recalled.



- 4. To restore the settings, select the "Open" icon from the toolbar.
- Select the save set in which the settings were stored ( "QuickSaveX" ). The selected settings are restored to the instrument or channel.

### To save configurable instrument settings

- 1. Select the "Save" icon from the toolbar.
  - 2. In the "Save" dialog box, switch to the "Save" tab.
  - 3. In the file selection dialog box, select a filename and storage location for the settings file.
  - 4. Optionally, define a comment to describe the stored settings.
  - 5. Select whether the instrument settings for **all** "Channel" s are stored, or only those for the **current** "Channel".
  - Select the items to be saved with the settings. Either the settings for the currently selected "Channel" only, or the settings for all "Channel" s can be stored. Various other items, such as lines or traces etc., can be stored as well (see Chapter 12.3.2.1, "Stored Data Types", on page 251).
  - 7. Select "Save" .

A file with the defined name and path and the extension .dfl is created.



If you make any changes to the settings *after* storing the configuration file, remember to save the settings again. Otherwise those settings cannot be restored and will be overwritten by the stored values when the configuration file is recalled.

### To recall configurable instrument settings

- 1. Select the "Open" icon from the toolbar.
- 2. In the "Recall" dialog box, switch to the "Recall" tab.
- 3. In the file selection dialog box, select the filename and storage location of the settings file.

**Note:** The "File Type" indicates whether the file contains instrument settings for **all** "Channel" s, or only those for the current "Channel" .

- 4. If several items were saved, select which items are restored.
- If a "Channel" was saved, select whether the settings will replace the settings in the current "Channel", or whether a new channel with the saved settings will be opened.
- 6. Select "Recall" .

The settings and selected items from the saved measurement are restored and you can repeat the measurement with the same settings. Note that any changes made to the settings *after* storing the configuration file will be overwritten by the stored values when the configuration file is recalled.

### To recall settings automatically after preset or reboot

You can define the settings that are restored when you preset or reboot the instrument.

- Configure the settings as required and save them as described in "To save configurable instrument settings" on page 257.
- 2. In the "Save/Recall" menu, select "Startup Recall" .
- 3. From the file selection dialog box, select the recall settings to restore.
- 4. Select "Select File" .
- 5. Set "Startup Recall" to "On" .

Now when you press the [PRESET] key or reboot the instrument, the defined settings will be restored.

6. To restore the factory preset settings, set "Startup Recall" to "Off" .

# 12.4 Import/Export Functions

P

Access: "Save" / "Open" icon in the toolbar > "Import" / "Export"

The R&S FSWP provides various evaluation methods for the results of the performed measurements. However, you may want to evaluate the data with further, external applications. In this case, you can export the measurement data to a standard format file (ASCII or XML). Some of the data stored in these formats can also be re-imported to the R&S FSWP for further evaluation later, for example in other applications.

The following data types can be exported (depending on the application):

- Trace data
- Table results, such as result summaries, marker peak lists etc.
- I/Q data (in applications that process I/Q data)

The following data types can be imported (depending on the application):

I/Q data (in applications that process I/Q data)



I/Q data can only be imported and exported in applications that process I/Q data, such as the I/Q analyzer or other optional applications.

See the corresponding user manuals for those applications for details.



These functions are only available if no measurement is running.

In particular, if Continuous Sweep / Run Cont is active, the import/export functions are not available.

Import	
Export	
L Trace Export Configuration	
L I/Q Export	
L File Explorer	



F)

F)

Access: "Save/Recall" > Import

Provides functions to import data.

Currently, only I/Q data can be imported, and only by applications that process I/Q data.

See the R&S FSWP I/Q Analyzer user manual for more information.



Access: "Save/Recall" > Export

Opens a submenu to configure data export.

For more information, see "Export Trace to ASCII File " on page 211.

### Trace Export Configuration ← Export

Opens the "Traces" dialog box to configure the trace and data export settings.

Chapter 11.3.3, "Trace Export and Import", on page 209

### I/Q Export ← Export

Opens a file selection dialog box to define an export file name to which the I/Q data is stored. This function is only available in single sweep mode.

It is only available in applications that process I/Q data, such as the I/Q Analyzer or other optional applications.

For details, see the description in the R&S FSWP I/Q Analyzer User Manual ("Importing and Exporting I/Q Data").

**Note:** Storing large amounts of I/Q data (several Gigabytes) can exceed the available (internal) storage space on the R&S FSWP. In this case, it can be necessary to use an external storage medium.

Note: Secure user mode.

In secure user mode, settings that are stored on the instrument are stored to volatile memory, which is restricted to 256 MB. Thus, a "memory limit reached" error can occur although the hard disk indicates that storage space is still available.

To store data permanently, select an external storage location such as a USB memory device.

For details, see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

File Explorer  $\leftarrow$  I/Q Export  $\leftarrow$  Export Opens the Microsoft Windows File Explorer. Remote command:

not supported

# 12.5 Creating Screenshots of Current Measurement Results and Settings

To document the graphical results and the most important settings for the currently performed measurement, you can create a screenshot of the current display. Screenshots can either be printed or stored to a file.

# 12.5.1 Print and Screenshot Settings



Access: "Print" icon in the toolbar

For step-by-step instructions, see Chapter 12.5.2, "How to Store or Print Screenshots of the Display", on page 269.

Remote commands for these settings are described in Chapter 15.8.4, "Storing and Printing Screenshots", on page 565.

# 2 🖸

To print a screenshot of the current display with the current settings immediately, without switching to the "Print" menu, use the "Print immediately" icon in the toolbar.

•	Print Content Settings	261
	Print Preview Functions	
•	Printer Settings	.264
•	Page Setup	267
	Print Color Settings	


### 12.5.1.1 Print Content Settings



Access: "Print" > "Print Config" > "Content" tab

The content settings determine which data is included in the printout.

Note that some content settings are independent of the selected printing device, others are printing device-specific.



### **Print Screenshot**

Selects all measurement results displayed on the screen for the current channel (or "MultiView"): diagrams, traces, markers, marker lists, limit lines, etc., including the channel bar and status bar, for printout on a single page. Displayed items belonging to the software user interface (e.g. softkeys) are not included. The position and size of the elements in the printout is identical to the display.

This setting is independent of the printing device.

Remote command: HCOPy:CONTent on page 567

### **Print Multiple Windows**

Includes only the selected windows in the printout. All currently active windows for the current channel (or "MultiView") are available for selection. How many windows are printed on a single page of the printout is user-definable (see "Windows Per Page " on page 268).

This option is only available when printing on a printer or to a PDF file (see " Destination " on page 266). If the Destination is currently set to an image file or the clipboard for the selected printing device, it is automatically changed to be a PDF file.

### Remote command:

HCOPy:CONTent on page 567
HCOPy:PAGE:WINDow<1|2>:STATe on page 574
HCOPy:PAGE:WINDow<1|2>:CHANnel:STATe on page 573

#### Comment

Defines an optional comment to be included in the printout of the display. Maximum 120 characters are allowed. Up to 60 characters fit in one line. In the first line, a manual line-feed can be forced at any point by entering "@".

The comment is printed in the top left corner of each printout page. If a comment should not be printed, it must be deleted.

This setting is independent of the printing device.

**Tip**: The current date and time can be inserted automatically, see " Print Date and Time " on page 263.

Remote command: HCOPy:ITEM:WINDow<1|2>:TEXT on page 570

#### **Print Logo**

Activates/deactivates the printout of the Rohde & Schwarz company logo in the upper right corner.

This setting is independent of the printing device.

Remote command: DISPlay: LOGO on page 565

#### **Print Page Count**

Includes the page number for printouts consisting of multiple windows (" Print Multiple Windows " on page 262).

This setting is independent of the printing device.

Remote command: HCOPy: PAGE: COUNT: STATe on page 570

### Select Device 1/2

Selects the printing device to be configured.

Two different printout devices can be configured, for example one for printing and one for storage to a file. When you execute the "Print immediately" function, the selected printing device and its settings determine the behavior of the R&S FSWP.

### **Print Dialog**

Includes any currently displayed dialog in the screenshot printout.

This setting is (printing) device-specific and only available if Print Screenshot is selected.

### **Print Date and Time**

Includes or removes the current date and time at the bottom of the printout.

This setting is (printing) device-specific.

Remote command: HCOPy:TDSTamp:STATe<1 | 2> on page 575


### 12.5.1.2 Print Preview Functions



Access: "Print"

The "Print Preview" of the printout according to the current configuration is available in all "Print Settings" dialog tabs.

The preview display (not the functions) is device-specific (see " Select Device 1/2 " on page 263).



Zoom In / Zoom Out	
Fit Page	
Zoom 1:1	
Page Up / Page Down	
Print	

## Zoom In / Zoom Out

Zooms into (enlarges) or zooms out of (decreases) the preview display. Note that the zoom functions affect only the preview, not the printout itself.

### Fit Page

Adapts the preview display zoom factor so that one complete page is visible as large as possible in the available display space. Note that the zoom functions affect only the preview, not the printout itself.

### Zoom 1:1

Displays the printout in its original size, as it will be printed.

### Page Up / Page Down

Depending on the selected contents (see Chapter 12.5.1.1, "Print Content Settings", on page 261), the printout can consist of multiple pages. Use these functions to scroll within the preview to see the individual pages.

### Print

Starts to print or store the selected screen contents to a file (see Chapter 12.5.1.1, "Print Content Settings", on page 261).

Whether the output is sent to the printer or stored in a file or the clipboard depends on the selected printing device and the printing device settings (see Chapter 12.5.1.3, "Printer Settings", on page 264).

If the output is stored to a file, a file selection dialog box is opened to select the filename and location. The default path is C:\R\_S\INSTR\USER.


### Remote command:

HCOPy[:IMMediate<1|2>] on page 570
HCOPy[:IMMediate<1|2>]:NEXT on page 570

### 12.5.1.3 Printer Settings



Access: "Print" > "Print Config" > "Printer" tab





Printer settings are (printing) device-specific. That means you can configure two different printing devices (for example, a printer and a file) and switch between configurations easily simply by selecting the appropriate device before printing.

Select Device 1/2	. 265
Destination	. 266
Suppress File Name Dialog	266
Printer Name	
Print to file	. 266
Install Printer	. 267

# Select Device 1/2

Selects the printing device to be configured.

Two different printout devices can be configured, for example one for printing and one for storage to a file. When you execute the "Print immediately" function, the selected printing device and its settings determine the behavior of the R&S FSWP.

### Destination

Defines the medium to which the printout is output.

 "File" Stores the printout to a file in the selected format. The filename is queried at the time of storage, or a default name is used (see Suppress File Name Dialog ). Multiple windows can only be printed to a file in PDF format. If you select an image file format, the content setting is automatically set to Print Screenshot . Page settings are not available for image files; however, you can configure the colors used for the screenshot (see Chapter 12.5.1.5, "Print Color Settings", on page 268).
 "Clipboard" Copies the printout to the clipboard. Since only single pages can be copied, only screenshots can be copied to this destination, not multiple windows (aso Chapter 12.5.1.4, "Drint Content Settings").

copied, only screenshots can be copied to this destination, not multiple windows (see Chapter 12.5.1.1, "Print Content Settings", on page 261). Page settings are not available; however, you can configure the colors used for the screenshot (see Chapter 12.5.1.5, "Print Color Settings", on page 268). If you select the clipboard as the printing destination, the content setting is automatically set to Print Screenshot.

"Printer" Sends the printout to the printer selected from the Printer Name list.

Remote command:

HCOPy:DESTination<1|2> on page 568
HCOPy:DEVice:LANGuage<1|2> on page 569

### Suppress File Name Dialog

If the Destination is a file, the file selection dialog box is not displayed. Instead, the default storage location and filename are used.

(C:\R\_S\INSTR\USER\FSWP\_ScreenShot\_<date and time>).

### **Printer Name**

Defines the printer to print to if a printer is selected as the Destination .

Any printers detected in the network are listed for selection.

**Tip**: the printout can also be stored in a print file using the selected printer driver, see " Print to file " on page 266.

Remote command:

```
SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT] on page 575
SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt on page 575
SYSTem:COMMunicate:PRINter:SELect<1|2> on page 575
```

### Print to file

If a printer is selected as the Destination , use this option to store the data in a .prn file using the selected printer driver.

### **Install Printer**

This softkey opens the standard Windows dialog box to install a new printer. All printers that are already installed are displayed.

Only user accounts with administrator rights can install a printer.

For further information, refer to the Microsoft Windows documentation.

# 12.5.1.4 Page Setup

Access: "Print	" > "Priı	nt Config" > "Pag 	je Setup" tab	
Content P	rinter	Page Setup	Color	
Select Device			Device 1	Device 2
Device Setting	s for De	vice 1		
Orientation		Portrait		
Windows Pe	r Page	1		
Scaling		Maintain aspec	t ratio	Size to fit
Margins				
Тор	4.23 r	nm		
Bottom	<b>4.23</b> r	nm		
Left	<b>4.23</b> r	nm		
Right	<b>4.23</b> r	nm		
Margin Unit		mm		in



Page settings are (printing) device-specific. That means you can configure two different printing devices (for example, a printer and a file) and switch between configurations easily simply by selecting the appropriate device before printing.

Page settings are only available when printing on a printer or to a PDF file (see " Destination " on page 266).

Select Device 1/2	
Orientation	
Windows Per Page	
Scaling	
Margins	

### Select Device 1/2

Selects the printing device to be configured.

Two different printout devices can be configured, for example one for printing and one for storage to a file. When you execute the "Print immediately" function, the selected printing device and its settings determine the behavior of the R&S FSWP.

### Orientation

Selects the page orientation of the printout: portrait or landscape.

Remote command: HCOPy:PAGE:ORIentation<1|2> on page 572

### Windows Per Page

Defines how many windows are displayed on a single page of the printout. This setting is only available if Print Multiple Windows is active (see Chapter 12.5.1.1, "Print Content Settings", on page 261).

If more than one window is printed on one page, each window is printed in equal size.

Remote command:

HCOPy:PAGE:WINDow<1|2>:COUNt on page 573

### Scaling

Determines the scaling of the windows in the printout if Print Multiple Windows is active (see Chapter 12.5.1.1, "Print Content Settings", on page 261).

If more than one window is printed on one page (see Windows Per Page ), each window is printed in equal size.

"Maintain	Each window is printed as large as possible while maintaining the
aspect ratio"	aspect ratio of the original display.

"Size to fit" Each window is scaled to fit the page size optimally, not regarding the aspect ratio of the original display.

Remote command:

HCOPy:PAGE:WINDow<1|2>:SCALe on page 573

### Margins

Defines margins for the printout page on which no elements are printed. The margins are defined according to the selected unit.


### Remote command:

```
HCOPy: PAGE: MARGin<1 | 2>: BOTTom on page 571
HCOPy: PAGE: MARGin<1 | 2>: LEFT on page 571
HCOPy: PAGE: MARGin<1 | 2>: RIGHt on page 571
HCOPy: PAGE: MARGin<1 | 2>: TOP on page 572
HCOPy: PAGE: MARGin<1 | 2>: UNIT on page 572
```

# 12.5.1.5 Print Color Settings



Access: "Print" > "Print Config" > "Color" tab



The settings provided here are identical to those in the "Print Colors" section of the "Display" > "Theme + Color" dialog box.

See " Print Colors " on page 287.

# 12.5.2 How to Store or Print Screenshots of the Display

The measurement results displayed on the screen can be printed or stored to a file very easily.

Two different scenarios can be configured in parallel, assigned to different printing devices. You can then perform one or the other simply by selecting the corresponding printing device and the "Print" function.

### To start printing or storing results to a file



If the R&S FSWP has already been set up according to your current requirements, simply press the "Print immediate" icon at the far right end of the toolbar.

The current measurement display is printed or stored to a file, as configured.

### To print a screenshot

This configuration assumes a printer has already been installed. To install a new printer, use the Install Printer function (common Microsoft Windows procedure).



1. Select the "Printer" tool in the toolbar.

The "Print Settings" dialog box is displayed.

 Select "Device 1" or "Device 2" to define which printing device you want to configure.

(Note: Some settings are independent of the printing-device.)

- In the "Content" tab, define the elements of the screen and additional information to be included in the printout.
  - a) Select "Print Screenshot" to include all elements displayed on the screen in a single-page printout.
  - b) Optionally, add a comment to be printed at the top of the printout.
  - c) Optionally, activate the date and time or the logo so they are added to the printout.
  - d) Optionally, activate "Print Dialog" to include any dialog boxes currently displayed on the screen in the printout. This is useful, for example, to document the used settings for a particular result.
  - e) Check the "Print Preview" to make sure all relevant elements of the display are visible.
- 4. In the "Printer" tab, select "Printer" as the "Destination" .
- 5. Select the "Printer Name" to print to from the list of installed printers.
- 6. In the "Page Setup" tab, configure the layout of the printout page.
  - a) Select the page orientation.
  - b) Define the page margins.
  - c) Check the "Print Preview" to make sure all relevant elements of the display are visible.
- 7. In the "Color" tab, define the colors to be used for the printout.
  - a) By default, "Optimized Colors" are used to improve the visibility of the colors. The background is always printed in white and the grid in black. For a printout that reflects exactly what you see on the screen, select "Screen Colors (Screenshot)".
  - b) Check the "Print Preview" to find out if the setting is appropriate.
- 8. Select "Print" to execute the print function.

The screenshot is printed on the printer as configured.



 To print another screenshot using the same configuration any other time, simply press the "Print immediate" icon at the far right end of the toolbar. If you use different printing scenarios alternately, perform the following steps to print another screenshot:

- a) Select the 🛄 "Printer" tool in the toolbar.
- b) Select "Device 1" or "Device 2" to select the configured printing device.
- c) Select "Print" to execute the print function.

### To store a printout containing multiple windows



1. Select the "Printer" tool in the toolbar.

The "Print Settings" dialog box is displayed.

- Select "Device 1" or "Device 2" to define which printing device you want to configure.
- In the "Content" tab, define the elements of the screen and additional information to be included in the printout.
  - a) Select "Print Selected Windows" to include the selected windows in the printout, possibly on multiple pages.
  - b) Select the result displays in the currently selected channel to be included in the printout.

**Tip**: Select the "MultiView" before configuring the printout to include result displays from any active channel.

- c) Optionally, add a comment to be printed at the top of each page of the printout.
- d) Optionally, activate the date and time or the logo so they are added to the printout pages.
- 4. Check the "Print Preview" to make sure all required result displays are included.
  - a) Scroll through the individual pages of the printout using "Page Up" and "Page Down" .
  - b) Use the zoom functions to make sure all relevant parts of the result display are visible.
- 5. In the "Printer" tab, select "File" as the "Destination" .
- 6. Select the file format from the selection list.
- By default, you define the filename individually for each print operation. To avoid having the "File Selection" dialog box being displayed for each print operation, select "Suppress File Name Dialog". In this case, the previously used or default storage location and filename are used. (C:\R\_S\INSTR\USER\FSWP ScreenShot <date and time>).
- 8. In the "Page Setup" tab, configure the layout of the printout page.
  - a) Select the page orientation.
  - b) Define the page margins.
  - c) Check the "Print Preview" to make sure all relevant elements of the display are visible.

- 9. In the "Color" tab, define the colors to be used for the printout.
  - a) By default, "Optimized Colors" are used to improve the visibility of the colors. The background is always printed in white and the grid in black. For a printout that reflects the colors you see on the screen, but with a white background, select "Screen Colors (Print)".
  - b) Check the "Print Preview" to find out if the setting is appropriate.
- 10. Select "Print" to execute the print function.
- 11. If you did not select the option to suppress the dialog, enter a filename in the file selection dialog box.

The selected data elements are stored to the file as configured.




- 12. To store another file using the same configuration any other time, simply press the "Print immediate" icon at the far right end of the toolbar. If you use different printing scenarios alternately, perform the following steps to store another file:
  - a) Select the 🛄 "Printer" tool in the toolbar.
  - b) Select "Device 1" or "Device 2" to select the configured printing device.
  - c) Select "Print" to execute the print function.

# 12.5.3 Example for Storing Multiple Measurement Results to a PDF File

The following example describes the procedure to store results from measurements in the Spectrum application and the I/Q Analyzer to a single PDF file.

- Configure and perform the measurements in the Spectrum application and I/Q Analyzer as required. Configure at least the following result displays:
  - Frequency Sweep, Spectrogram (Spectrum)
  - Magnitude, Spectrum (I/Q Analyzer)
- Switch to the "MultiView" tab to display an overview of the result displays in all active channels.






3. Select the "Printer" tool in the toolbar.

The "Print Settings" dialog box is displayed.

- 4. Select "Device 1" to configure the settings for this printing device.
- 5. In the "Content" tab, select "Print Selected Windows" .
- 6. Select the result displays listed in step 1.
- 7. Enter the comment *Measurement Test Report* to be inserted at the top of each page.
- 8. Select "Print Page Count" and "Print Date and Time" .
- 9. In the "Content" tab, select "Print Selected Windows" .
- 10. In the "Printer" tab, select "File" as the "Destination" .
- 11. Select "PDF" from the file format selection list.
- 12. Select "Suppress File Name Dialog" .
- 13. In the "Page Setup" tab, select "Landscape" as the "Orientation" .
- 14. Select "Windows Per Page" : 1 to print a single result display on each page.
- 15. Select the "Scaling" option "Size to fit" to maximize the result display on each page.
- In the "Color" tab, select "Screen Colors (Print)" for a printout that reflects the colors you see on the screen, but with a white background.
- 17. Check the "Print Preview" to make sure all required result displays are included and all relevant data elements are visible.
  - a) Scroll through the individual pages of the printout using "Page Up" and "Page Down".

- b) Use the zoom functions to make sure all relevant parts of the result display are visible.
- 18. Select "Print" to execute the print function.

The selected data elements are stored to the file as configured.



# 13 General Instrument Setup

# Access: [SETUP]

Some basic instrument settings can be configured independently of the selected operating mode or application. Usually, you will configure most of these settings initially when you set up the instrument according to your personal preferences or requirements and then only adapt individual settings to special circumstances when necessary. Some special functions are provided for service and basic system configuration.



### Network and Remote Settings, Display Settings

Settings for network and remote operation are described in Chapter 14, "Network and Remote Operation", on page 311.

Display settings are described in Chapter 13.2.1, "Display Settings", on page 281.

•	Alignment	275
	Display Settings	
	Reference Frequency Settings	
	System Configuration Settings	
	Service Functions	

# 13.1 Alignment

# 13.1.1 Basics on Alignment

When you put the instrument into operation for the first time or when strong temperature changes occur, align the data to a reference source (see "Temperature check" on page 276).

The correction data and characteristics required for the alignment are determined by the firmware. It compares the results at different settings with the known characteristics of the high-precision calibration signal source at 64 MHz.



Depending on the installation settings, an automatic self-alignment is performed directly after installation, and a dialog is displayed indicating how much warm-up time is still required before self-alignment can be performed.



During instrument start, the firmware checks whether the installed hardware is supported. If not, an error message is displayed ("Wrong Firmware Version") and you are asked to update the firmware. Until the firmware version is updated, self-alignment fails.

# í

If you start a self-alignment remotely and then select the "Local" softkey while the alignment is still running, the instrument only returns to the manual operation state after the alignment is completed.

During self-alignment, do not connect a signal to the RF input connector. Running a self-alignment with a signal connected to the RF input can lead to false measurement results.

# Alignment results

The alignment results are displayed and contain the following information:

- Date and time of last correction data record
- Overall results of correction data record
- List of found correction values according to function/module

The results are classified as follows:

PASSED	Calibration successful without any restrictions
СНЕСК	Deviation of correction value larger than expected, correction could however be per- formed
FAILED	Deviations of correction value too large, no correction was possible. The found correction data is not applicable.

The results are available until the next self-alignment process is started or the instrument is switched off.

### **Temperature check**

During self-alignment, the instrument's frontend temperature is measured (as soon as the instrument has warmed up completely). This temperature is used as a reference for a continuous temperature check during operation. If the current temperature deviates from the stored self-alignment temperature by a certain degree, a warning is displayed in the status bar. The warning indicates the resulting deviation in the measured power levels. A status bit in the STATUS:QUEStionable:TEMPerature register indicates a possible deviation. The current temperature of the frontend can be queried using a remote command (see SOURce<si>:TEMPerature:FRONtend on page 588).

### **Touchscreen alignment**

When the device is delivered, the touchscreen is initially calibrated. However, to ensure that the touchscreen responds to the finger contact correctly, a touchscreen alignment is required.

Alignment of the touchscreen is useful:

- At first use
- After an image update or after exchanging a hard disk
- If you notice that touching a specific point on the screen does not achieve the correct response

- If the position of the instrument has been changed and you cannot look straight on the screen
- If another person operates the instrument

# 13.1.2 Alignment Settings

Access: [Setup] > "Alignment"

Both the instrument and the touchscreen can be aligned when necessary (see Chapter 13.1.1, "Basics on Alignment", on page 275).


# Automatic self-alignment

During installation of the R&S FSWP firmware, you can configure an automatic selfalignment to be performed directly after installation. In addition, you can activate a preceding warmup time before self-alignment, which is strongly recommended. If you do not activate this option, make sure the instrument has reached its operating temperature before installing the firmware. Furthermore, you can force the instrument to shut down after self-alignment. Note, however, that you cannot switch the instrument back on remotely afterwards.

R&S FSW K60		Info
RAS FSW K70	^	lino
R&S FSW K72 and K73		
R&S FSW K76 and K77		
R&S FSW K82 and K83		
R&S FSW K84 and K85		
R&S FSW K91		
R&S FSW K95		
R&S FSW K100		
R&S FSW K118	E	
R&S FSW K192		
Self Alignment after Update (Not recommended! Make sure Warm-Up already dor	iel)	
Self Alignment after Warm-Up Time (Recommended)		N. 404.24
Shutdown after Self Alignment (Restart from remote PC will not be possible!)	_	Reboot
R&S FSW Installation File Verification	-	Send Log

The additional settings for self-alignment can also be activated or deactivated during operation in the "Alignment" settings dialog (see Await Warm-Up Operation before Self Alignment and Shut down Device after Self Alignment.)

## Alignment





### Self-alignment results in secure user mode

Be sure to store self-alignment results before SecureUser Mode is enabled; see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

In secure user mode, the results are not stored permanently. Thus, if the currently stored self-alignment results are not suitable, you must perform a self-alignment each time you switch on the R&S FSWP.

Start Self Alignment	278
Abort Self Alignment	
Await Warm-Up Operation before Self Alignment	279
Schedule	279
Shut down Device after Self Alignment	279
Reuse Old Alignment Data	279
Starting Touch Screen Alignment	280
Alignment Results:	
Starting Touch Screen Alignment	280

### Start Self Alignment

Starts recording correction data for the instrument. If the correction data acquisition fails or if the correction values are deactivated, a corresponding message is displayed in the status field.

For details, see Chapter 13.1.1, "Basics on Alignment", on page 275.

# Note:

A running Sequencer operation is aborted when you start a self-alignment.

During self-alignment, do not connect a signal to the RF input connector. Running a self-alignment with a signal connected to the RF input can lead to false measurement results.

### Remote command:

\*CAL? on page 385, see also CALibration [:ALL]? on page 586

### Abort Self Alignment

As long as the self-alignment data is being collected, the procedure can be canceled using the "Abort Self Alignment" button.

**Note:** If you start a self-alignment remotely, then select the "Local" softkey while the alignment is still running, the instrument only returns to the manual operation state after the alignment is completed. In this case, you cannot abort a self-alignment manually.

### Await Warm-Up Operation before Self Alignment

Displays a message indicating the remaining warmup time required before self-alignment is performed. After the warmup operation has completed, self-alignment is started automatically.

### Schedule

If enabled, a self-alignment is performed regularly at specific days and time.

Set alignment schedule 🛛 🔍 🗙				
Time of day	14:17			
O every day	specific days			
Montag	Dienstag 🗸	Mittwoch		
Donnerstag	Freitag	Samstag		
Sonntag				

### Shut down Device after Self Alignment

If activated, the R&S FSWP is automatically shut down after self-alignment is completed. Note that the instrument cannot be restarted via remote control.

### **Reuse Old Alignment Data**

If data from a previous self-alignment is available on the instrument, it can be reused even though the instrument claims the instrument is uncalibrated. This is useful, for example, after activating a software option or updating the firmware to a beta version. After rebooting the instrument, you must re-activate this function if you still want to reuse the old alignment data.

Note, however, that **re-using old alignment data can lead to inaccurate measurement results, or even cause the R&S FSWP firmware to fail altogether**. For measurements using old alignment data, an [OLD CAL] message is indicated in the status bar (instead of [UNCAL], which indicates that a new self-alignment is actually required.)

To measure with the accuracy specified in the data sheet, always perform a selfalignment when the instrument calls for it.

# **Starting Touch Screen Alignment**

Starts the touchscreen alignment.

Tap the 4 markers on the screen as you are asked to do. The touchscreen is aligned according to the executed pointing operations.

### **Alignment Results:**

Information on whether the alignment was performed successfully and on the applied correction data is displayed. The results are available until the next self-alignment process is started or the instrument is switched off.

### Remote command:

CALibration:RESult? on page 586

# 13.1.3 How to Perform a Self-Test

You do not have to repeat the self-test every time you switch on the instrument. It is only necessary when instrument malfunction is suspected.



# Operating temperature

Before performing this functional test, make sure that the instrument has reached its operating temperature (for details, refer to the data sheet).

- 1. Select [SETUP].
- 2. Select "Service" .
- 3. Select "Selftest" .

Once the instrument modules have been checked successfully, a message is displayed.

# 13.1.4 How to Align the Instrument



# **Operating temperature**

Before performing this functional test, make sure that the instrument has reached its operating temperature (for details, refer to the data sheet).

### To perform a self-alignment

Make sure no signal is connected to the RF input connector. Running a self-alignment with a signal connected to the RF input can lead to false measurement results.

- 1. Select [SETUP].
- 2. Select "Alignment" .
- 3. Select "Start Self Alignment" .

4. To abort the self-alignment process, select "Abort Self Alignment" .

Once the system correction values have been calculated successfully, a message is displayed.

### To display the alignment results again later

Select [SETUP] > "Alignment".

# 13.1.5 How to Align the Touchscreen

### To align the touchscreen

- 1. Press the [Setup] key.
- 2. Select the "Alignment" softkey.
- 3. Select "Touch Screen Alignment" .

A blinking cross appears in the lower left corner of the screen.

4. Touch and hold the blinking cross until it stops blinking. Repeat this action for the crosses in the other corners.

# 13.2 Display Settings

# 13.2.1 Display Settings

Access: [Setup] > "Display"

Some general display settings are available regardless of the current application or operating mode. For information on optimizing your display for measurement results, see Chapter 11.1, "Result Display Configuration", on page 193.

•	General Display Settings	281
•	Displayed Items.	283
	Display Theme and Colors	
	External Monitor Settings	

### 13.2.1.1 General Display Settings

Access: [Setup] > "Display" > "General"

This section includes general screen display behavior and date and time display.

**Display Settings** 

General	Displayed Items	Theme + Colo		Config	ure Monitor	Touch
Touch Scre	en		Display			
Т	Touch On ouch Diagram Off Touch Off		Display Upda	ite Rate	Fast Slow	
Date and Ti	ime					
Set Date and Time						
Date and	Time Format US	DE				

Deactivating and Activating the Touchscreen	
Display Update Rate	
Set Date and Time	
Date and Time Format	

### **Deactivating and Activating the Touchscreen**

The touchscreen function can be deactivated, e.g. when the instrument is being used for demonstration purposes and tapping the screen must not provoke an action.

To reactivate the touchscreen, simply press the [Setup] key on the front panel. The "Display" dialog box is opened automatically and the "Touch Screen" option is set to "On".

"Touch On" Touchscreen function is active for the entire screen.

"Touch Off" Touchscreen is deactivated for the entire screen.

"Touch Diagram Off"

Touchscreen is deactivated for the diagram area of the screen, but active for the surrounding softkeys, toolbars and menus.

### Remote command:

DISPlay: TOUChscreen [:STATe] on page 590

### **Display Update Rate**

By default, a fast update rate ensures the most recent measurement results on the display. However, when performance is poor due to slow data transfer (for example during remote control), it can be helpful to decrease the frequency with which the screen display is updated.

### Set Date and Time

Sets the current date and time for the internal real-time clock on the instrument. This function uses the standard Windows "Date and Time Properties" dialog box. Setting the clock requires administrator rights.

Select the "Set Date and Time" button in the "Display" dialog box, or select the date and time display in the status bar to open the Windows dialog box.

Remote command:

SYSTem: DATE on page 580 SYSTem: TIME on page 580

## Date and Time Format

Switches the time and date display on the screen between US and German (DE) format.

Remote command: DISPlay[:WINDow<n>]:TIME:FORMat on page 591

# 13.2.1.2 Displayed Items

Access: [Setup] > "Display" > "Displayed Items"

Several elements on the screen display can be hidden or shown as required, for example to enlarge the display area for the measurement results.

General Displayed Items	Theme + Color	Configure Monitor
Toolbar		in Off
Status Bar		n Off
Softkey Bar		n Off
Channel Bar		n Off
Annotation		n Off
Date and Time		n Off
Front Panel		n Off
Mini Front Panel		n Off

Toolbar	283
Status Bar	284
Softkey Bar	284
Channel Bar	
Diagram Footer (Annotation)	284
Date and Time	284
Front Panel	284
Mini Front Panel	285

# Toolbar

The toolbar provides access to frequently used functions via icons at the top of the screen. Some functions, such as zooming, finding help, printing screenshots or storing and loading files are not accessible at all without the toolbar.

Remote command:

DISPlay:TBAR[:STATe] on page 590

### **Status Bar**

The status bar beneath the diagram indicates the global instrument settings, the instrument status and any irregularities during measurement or display.

Some of the information displayed in the status bar can be queried from the status registry via remote commands.

Remote command:

DISPlay:SBAR[:STATe] on page 590

### Softkey Bar

Softkeys are virtual keys provided by the software. Thus, more functions can be provided than can be accessed directly via the function keys on the device.

The functions provided by the softkeys are often also available via dialog boxes. However, some functions are not accessible at all without the softkey bar.

**Note:** The softkey bar is hidden while the SmartGrid is displayed and restored automatically when the SmartGrid is closed.

Remote command: DISPlay:SKEYs[:STATe] on page 590

### **Channel Bar**

The channel bar provides information on firmware and measurement settings for a specific channel.

Remote command:

DISPlay: ANNotation: CBAR on page 589

### **Diagram Footer (Annotation)**

The diagram footer beneath the diagram contains information on the x-axis of the diagram display, such as:

- The current center frequency and span settings
- The displayed span per division
- The number of sweep points

Remote command:

DISPlay: ANNotation: FREQuency on page 590

### **Date and Time**

The date and time display can be switched off independently of the status bar.

You can set the current date and time and configure the display format in the "General" tab of the "Display" dialog box.

Remote command: DISPlay[:WINDow<n>]:TIME on page 591

### Front Panel

The "Front Panel" display simulates the entire front panel of the device (except for the external connectors) on the screen. Thus, you can interact with the R&S FSWP without the keypad and keys on the front panel of the device. That is useful, for example, when working with an external monitor or operating via remote control from a computer.

### **Display Settings**



To activate or deactivate the front panel temporarily, press the [F6] key on the external keyboard (if available) or the remote computer.

For more information, see Chapter 13.2.3, "How to Work with the Soft Front Panels", on page 291.

### Remote command:

SYSTem:DISPlay:FPANel[:STATe] on page 592

### Mini Front Panel

If you require a front panel display but do not want to lose too much space for results in the display area, a mini front panel is available. The mini version displays only the main function keys in a separate window in the display area.

Mini SoftFrontPanel	×
FREQ CHANNELSPANAMPT SCALEAUTO SETBWSWEEPTRACETRIG	MKR PEAK SEARCH MKR FUNCT MKR ->
MEAS MEAS LINES INPUT/ CONFIG	RUN SINGLE RUN CONT
Preset Mode Setup	Redo Undo
Tile-Max Toggle	Close Panel

### Note:

You can also activate the mini front panel using the key combination [ALT + m] (be aware of the keyboard language defined in the operating system!). That is useful when you are working from a remote PC and the front panel function is not active.

### Remote command:


SYSTem:DISPlay:FPANel[:STATe] on page 592

# 13.2.1.3 Display Theme and Colors

Access: [Setup] > "Display" > "Theme + Color"

You can configure the used colors and styles of display elements on the screen.

For step-by-step instructions see Chapter 13.2.2, "How to Configure the Colors for Display and Printing", on page 290.



### **Display Settings**

Theme	
Screen Colors	
Print Colors	
Showing Print Colors on Display	
Modifying User-Defined Color Assignments	
L Selecting the Object	
L Predefined Colors	
L Preview	
Defining User-specific Colors	
Restoring the User Settings to Default Colors	

### Theme

The theme defines the colors and style used to display softkeys and other screen objects.

The default theme is "BlueOcean" .

Remote command: DISPlay:THEMe:SELect on page 594

### **Screen Colors**

Two different color sets are provided by the instrument, a third user-defined set can be configured.

The default color schemes provide optimum visibility of all screen objects when regarding the screen from above or below. Default setting is "Default Colors 1".

If "User Defined Colors" is selected, a user-defined color set can be defined (see "Defining User-specific Colors" on page 289).

### Remote command:

DISPlay:CMAP<it>:DEFault<ci> on page 592

### **Print Colors**

Defines the color settings used for printout.

In addition to the predefined settings, a user-defined color set can be configured (see "Defining User-specific Colors" on page 289).

If "Show Print Colors on Display" is activated, the currently selected print colors are displayed as a preview for your selection.

Gui setting	Description	Remote command
"Optimized Colors"	Selects an optimized color setting for the printout to improve the visibility of the colors (default setting). Trace 1 is blue, trace 2 black, trace 3 green, and the markers are turquoise. The background is always printed in white and the grid in black.	HCOP:CMAP:DEF2
"Screen Colors (Print)"	Selects the current screen colors for the printout. The background is always printed in white and the grid in black.	HCOP:CMAP:DEF1
"Screen Colors (Screenshot)"	Selects the current screen colors without any changes for a screenshot.	HCOP:CMAP:DEF4
"User Defined Colors"	Selects the user-defined color setting.	HCOP:CMAP:DEF3

### Remote command:

HCOPy:CMAP<it>:DEFault<ci> on page 566

### **Showing Print Colors on Display**

Temporarily shows the currently selected print colors on the screen display. This function can be used as a preview for printing.

### **Modifying User-Defined Color Assignments**

You can configure the colors used to display and print individual screen objects according to your specific requirements.

The colors are configured in the (identical) "Screen Color Setup" / "Printer Color Setup" dialog boxes.

Selected Object:			
Background	-		
Predefined Colors			
Preview			
Userdefined Colors			
ОК	Cancel		

### 

Selects the object for which the color is to be defined. Colors can be defined for the following objects:

- Background
- Grid
- Individual traces
- Display lines
- Limit lines and check results
- Markers and marker information

### Remote command:

Each object is assigned to a specific suffix of the CMAP commands, see Chapter 15.9.4.3, "CMAP Suffix Assignment", on page 594.

#### 

Displays the available colors from the predefined color set that can be used for the selected object.

Remote command: HCOPy:CMAP<it>:PDEFined on page 567

#### **Preview** — Modifying User-Defined Color Assignments

Indicates the currently selected color that will be used for the selected object.

#### **Defining User-specific Colors**

In addition to the colors in the predefined color set you can configure a user-specific color to be used for the selected object.

When you select "Userdefined Colors...", the set of predefined colors is replaced by a color palette and color configuration settings.

Sackground		
review	Tini:	50
newiew	Ci Tini: Saturation: Brightness: ARGB:	0
Pres	Saturanan Brighinesse	0 0 1f000000

The color palette allows you to select the color directly. The color settings allow you to define values for tint, saturation and brightness.

Remote command: HCOPy:CMAP<it>:HSL on page 566

#### **Restoring the User Settings to Default Colors**

In addition to the predefined color settings, a user-defined setting can be configured. By default, the same settings as defined in "Default Colors 1" are used. They can then be modified according to user-specific requirements (see "Modifying User-Defined Color Assignments" on page 288).

The "Set to Default" function restores the original default settings for the user-defined color set. You can select which of the three default settings are restored.

Remote command: DISPlay:CMAP<it>:PDEFined on page 593

#### 13.2.1.4 External Monitor Settings

Access: [Setup] > "Display" > "Configure Monitor"

You can connect an external monitor (or projector) to the DVI or display port connector on the instrument's rear panel.



#### Screen resolution and format

The touchscreen of the R&S FSWP is calibrated for a 16:10 format. If you connect a monitor or projector using a different format (e.g. 4:3), the calibration is not correct and the screen does not react to your touch actions properly.

The touchscreen has a screen resolution of 1280x800 pixels. Usually, the display of the external monitor is a duplicate of the instrument's monitor.

If you configure the external monitor to be used as the *only* display in the Windows configuration dialog box ("Show only on 2"), the maximum screen resolution of the monitor is used. In this case, you can maximize the R&S FSWP application window and see even more details. You cannot change the monitor's screen resolution via the standard Windows configuration dialog box.

However, you can restore the default instrument resolution (1280x800) on the monitor using the instrument function "Setup" > "Display" > "Configure Monitor" > "Screen Resolution: Restore to default".

General Displayed Ite	ms Theme + Color Configure Monitor
External Monitor	Setup
Screen Resolution	Restore to Default

Setup	0
Screen Resolution: Restore to Default	0

#### Setup

Opens the standard Windows configuration dialog box to configure the used display devices.

#### Screen Resolution: Restore to Default

The default screen resolution (1280 x 800) is restored in the Windows configuration settings. This is useful, for instance, if the instrument was connected to a display device and was adapted to different requirements.

## 13.2.2 How to Configure the Colors for Display and Printing

You can configure the style and colors with which various screen objects are displayed or printed.

#### To select a color set

- 1. Press the [Setup] key and select the "Display" softkey.
- 2. Select the "Theme + Color" tab.
- 3. In the "Screen Colors" area, do one of the following:
  - Select a predefined set of colors for screen display.
  - Select "User Defined Colors" to configure the color set yourself.

- 4. In the "Print Colors" area, do one of the following:
  - Select a predefined set of colors for printing screenshots.
  - Select "User Defined Colors" to configure the color set yourself.
- Activate the "Show Print Colors on Display" option to see a preview of the print colors.

#### To configure a user-defined color set

- 1. In the "Theme + Color" tab of the "Display" dialog box, select "User Defined Colors" either for the screen or the print colors.
- 2. Select "Modify User Defined Colors" .

The "Screen Color Setup" dialog box is opened.

- From the "Selected Object:" list, select the object to which you want to assign a color.
- 4. Do one of the following:
  - Select a color from the "Predefined Colors" .
  - Select the "Userdefined Colors ..." button to define a different color.

The "Preview" area indicates the currently selected color.

- 5. To assign a user-specific color to the selected object, do one of the following:
  - Select the color from the palette.
  - Enter values for the "Tint:", "Saturation:", and "Brightness:".
     Note: In the continuous color spectrum ("Tint:"), 0 % represents red and 100 % represents blue.
  - Enter an "ARGB:" value in hexadecimal format.
- Select the next object to which you want to assign a color from the "Selected Object:" list.
- Repeat these steps until you have assigned a color to all objects you want to configure.
- 8. Select "OK" to close the dialog box.

The colors are applied to the assigned objects.

## 13.2.3 How to Work with the Soft Front Panels

Basic operation with the soft front panels is identical to normal operation, except for the following aspects:

To activate a key, select the key on the touchscreen.

To simulate the use of the rotary knob, use the additional keys displayed between the keypad and the arrow keys:

Icon	Function
٠	Turn left
0	Enter
•	Turn right

#### Mini front panel

The mini front panel provides only the keys on the touchscreen, to operate the R&S FSWP via an external monitor or remote desktop.

By default, the "Auto close" option is activated and the mini front panel window closes automatically after you select a key. This is useful if you only require the mini front panel display occasionally to press a single function key.

If you want the window to remain open, deactivate the "Auto close" option. You can close the window manually by selecting "Close planel" or the key combination [ALT + M] (be aware of the keyboard language defined in the operating system!).

#### To display the soft front panel or mini front panel

- 1. Press the [Setup] key and select the "Display" softkey.
- 2. Select the "Displayed Items" tab.
- 3. Select "Front Panel" : "On" or "Mini Front Panel" : "On" .

To activate or deactivate the front panel temporarily, press the [F6] key on the external keyboard (if available) or on the remote computer.

# 13.3 Reference Frequency Settings

Access: [Setup] > "Reference"



Reference Frequency Input	293
L Behavior in case of missing external reference	
L Tuning Range	
L Frequency	
Loop Bandwidth	
Reference Frequency Output	
Resetting the Default Values	
Advanced reference frequency configuration	

#### **Reference Frequency Input**

The R&S FSWP can use the internal reference source or an external reference source as the frequency standard for all internal oscillators. A 10 MHz crystal oscillator is used as the internal reference source. In the external reference setting, all internal oscillators of the R&S FSWP are synchronized to the external reference frequency.

External references are connected to one of the REF INPUT or the SYNC TRIGGER connectors on the rear panel.

**Note:** The optional, and more precise OCXO signal can replace the internal reference source.

The default setting is the internal reference. When an external reference is used, EXT REF is displayed in the status bar.

The following reference inputs are available:

Table 13-1: Available Reference Frequency Input

Setting	Source Connector	Frequency	Tuning Range	Loop Band- width	Description
Internal	(OCXO)	10 MHz	-	1-100 Hz	Internal reference signal or optional OCXO
External Reference 10 MHz	REF INPUT 150 MHz	10 MHz	+/- 6 ppm	1-100 Hz	Fixed external 10 MHZ reference fre- quency Good phase noise performance
External Reference 150MHz	REF INPUT 150 MHz	150 MHz in 1 Hz steps	+/- 0.5 ppm	0.1 Hz (fixed)	Variable external reference frequency in 1 Hz steps Good external phase noise suppres- sion. Small tuning range.
			+/- 6 ppm	1-30 Hz	Variable external reference frequency in 1 Hz steps Wide tuning range.
External Reference 100 MHz	REF INPUT 100 MHz / 1 GHz	100 MHz	+/- 6 ppm	1-300 Hz	External reference Good phase noise performance
External Reference 1 GHz	REF INPUT 100 MHz / 1 GHz	1 GHz	+/- 6 ppm	1-300 Hz	External reference
Sync Trigger	SYNC TRIGGER INPUT	100 MHz	+/- 6 ppm	1-300 Hz	External reference

#### Remote command:

[SENSe:]ROSCillator:SOURce on page 584
SOURce<si>:EXTernal<ext>:ROSCillator:EXTernal:FREQuency
on page 583

#### Behavior in case of missing external reference ← Reference Frequency Input

If an external reference is selected but none is available, there are different ways the instrument can react.

"Show Error The error message "External reference missing" is displayed if no valid external reference signal is available. Additionally, the flag "NO REF" is displayed to indicate that no synchronization was performed for the last measurement.

"Switch to The instrument automatically switches back to the internal reference if no external reference is available. Note that you must re-activate the external reference if it becomes available again at a later time.

#### Remote command:

[SENSe:]ROSCillator:SOURce on page 584
[SENSe:]ROSCillator:SOURce:EAUTo? on page 584

#### 

The tuning range is only available for the variable external reference frequency. It determines how far the frequency may deviate from the defined level in parts per million  $(10^{-6})$ .

- "+/- 0.5 ppm" With this smaller deviation a very narrow fixed loop bandwidth of 0.1 Hz is realized. With this setting the instrument can synchronize to an external reference signal with a very precise frequency. Due to the very narrow loop bandwidth, unwanted noise or spurious components on the external reference input signal are strongly attenuated. Furthermore, the loop requires about 30 seconds to reach a locked state. During this locking process, "NO REF" is displayed in the status bar.
- "+/- 6 ppm" The larger deviation allows the instrument to synchronize to less precise external reference input signals.

#### Remote command:

[SENSe:]ROSCillator:TRANge on page 585

#### 

Defines the external reference frequency to be used (for variable connectors only).

#### Loop Bandwidth Reference Frequency Input

Defines the speed of internal synchronization with the reference frequency. The setting requires a compromise between performance and increasing phase noise.

For a variable external reference frequency with a narrow tuning range (+/- 0.5 ppm), the loop bandwidth is fixed to 0.1 Hz and cannot be changed.

Remote command:

[SENSe:]ROSCillator:LBWidth on page 582

#### **Reference Frequency Output**

A reference frequency can be provided by the R&S FSWP to other devices that are connected to this instrument. If activated, the reference signal is output to the corresponding connector.

"Output 100 MHz"

Provides a 100 MHz reference signal to the REF OUTPUT 100 MHz connector.

"Output 640 MHz"

Provides a 640 MHz reference signal to the REF OUTPUT 640 MHz connector.

"Output Sync Trigger"

Provides a 100 MHz reference signal to the SYNC TRIGGER OUT-PUT connector.

#### Remote command:

[SENSe:]ROSCillator:0640 on page 582 [SENSe:]ROSCillator:OSYNc on page 583

#### **Resetting the Default Values**

The values for the "Tuning Range", "Frequency" and "Loop Bandwidth" are stored for each source of "Reference Frequency Input".

When you switch the input source, the previously defined settings are restored. You can restore the default values for all input sources using the "Preset Channel" function.

#### Advanced reference frequency configuration

The cross-correlation hardware options (R&S FSWP-B60 and -B61) provide a second internal reference frequency. This reference signal is phase locked to the reference frequency of the base instrument with a different loop bandwidth. If you have an R&S FSWP equipped with one of these options, you can synchronize the reference frequencies (internal and external).

The "Coupling" property turns coupling of the two references on and off.

If you select "Auto" coupling, the R&S FSWP uses the following logic.

- The R&S FSWP turns on coupling if you have selected the internal reference frequency of the base instrument.
- The R&S FSWP turns on the coupling if the tuning range for an external reference frequency is ± 0.5 ppm. We also recommend to manually couple the references in that case to avoid spurs.

If an external reference has better accuracy than 0.5 ppm, the R&S FSWP also turns on the coupling.

 The R&S FSWP turns off the coupling if the selected tuning range for an external reference frequency is ± 6 ppm. Because the OCXO of the R&S FSWP-B60 and -B61 can handle only ± 0.5 ppm, it is tuned with a DA converter.

You can also define the speed of the synchronization between the two references with the "Bandwidth" setting.

If you select "Auto", the R&S FSWP automatically selects an appropriate bandwidth.

The default bandwidth is 20 mHz. To yield the best results in phase noise measurements, the coupling bandwidth should be as low as possible.

For measurements with a start offset > 1 Hz, we recommend that you select a coupling bandwidth of 1 Hz to speed up the settling time of the reference loop.

 When the signal source is on, the R&S FSWP selects a coupling bandwidth of 100 kHz. With this setting the phase noise of the signal source and the receiving path correlate, which leads to better results measuring additive phase noise on frequency translating DUTs.

Remote command:

State: [SENSe:]ROSCillator:COUPling:MODE on page 582
Bandwidth (mode): [SENSe:]ROSCillator:COUPling:BANDwidth:MODE
on page 581
Bandwidth (value): [SENSe:]ROSCillator:COUPling:BANDwidth on page 581

## **13.4 System Configuration Settings**

Access: [Setup] > "System Configuration"

•	Hardware Information	.296
•	Information on Versions and Options	297
•	System Messages.	298
	Firmware Updates	

## 13.4.1 Hardware Information

Access: [Setup] > "System Configuration" > "Hardware Info"

An overview of the installed hardware in your R&S FSWP is provided.

Every listed component is described by its serial number, order number, model information, hardware code, and hardware revision.

This information can be useful when problems occur with the instrument and you require support from Rohde & Schwarz.

#### System Configuration Settings

Hardware Info	Versions + Options	System Messages	Firmware Upda	nte	Config		
	COMPONENT		Contraction of the local distance of the loc	-		- 10	
FRONTEND BOAR	D	10000			10.	11.0	
DIGITAL MOTHER	BOARD			-			
DETECTOR BOAR	D			-			
MICROWAVE CON	VERTER BASE BOARD	1000				10.00	
MICROWAVE CON	VERTER FRONTEND			10		10.00	
RF ATTENUATOR						-	
RF PREAMPLIFIEF	R BOARD			-		10.00	
SYNTHESIZER BO	ARD	1000	1000	-	- 10	100	
SYNTHESIZER BO	ARD 2	interest.	1000			-	
REFERENCE BOAR	2D ···			-			
REFERENCE BOAR	2 ZD 2			-			í.
осхо				-	1.00	1.00	
FRONTPANEL BOA	ARD					10.00	
LOW PHASE NOIS	E BOARD			-		-	
PHASE NOISE DIG	SITIZER BOARD			-	100	date:	
SIGNAL SOURCE A	ATTENUATOR	1000		-	- 10	in the second	
EXTERNAL GENER	ATOR CONTROL BOARD					10.00	Į.
				1 march 1		1	

#### **Remote command:**

DIAGnostic:SERVice:HWINfo? on page 602

## 13.4.2 Information on Versions and Options

Access: [Setup] > "System Configuration" > "Versions + Options"

Information on the firmware version and options installed on your instrument is provided. The unique Rohde & Schwarz device ID is also indicated here, as it is required for license and option administration.

You can also install new firmware options in this dialog box.

The table also contains:

 The open source acknowledgements (PDF file) for the firmware and other software packages used by the R&S FSWP



#### Installing options in secure user mode

Be sure to install any new options before SecureUser Mode is enabled; see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

For restricted users in secure user mode, this function is not available!



#### **Expired option licenses**

If an option is about to expire, a message box is displayed to inform you. You can then use the "Install Option" function to enter a new license key.

If an option has already expired, a message box appears for you to confirm. In this case, all instrument functions are unavailable (including remote control) until the R&S FSWP is rebooted. You must then use the "Install Option" function to enter the new license key.

#### System Configuration Settings

Hardware Info	Versions + Options	System M	lessages	Firmware U	pdate	Config	
	Item		Option	Version	[	License	•
R&S Device ID				1322.8003K26			
Instrument Firmwa	are						
BIOS				47.11- SIM			
Image				0.0.0			=
Device Installation				0.0.0			
PCIE-FPGA				13.02			
SA-FPGA				6.46			
MB-FPGA				0.0.0.0			
SYNTH-FPGA				0.0.0.0			
SYNTH-FPGA 2				0.0.0.0			
REF-FPGA				0.0.0.0			
MWC-FPGA				0.0.0.0			
PNDIGIT-FPGA				0.32			
Data Sheet				01.00			
Time Control Mana	igement				active		
Smart Card Service	9				installec	1	•
	Install Option			Install	Option b	y XML	

#### Remote commands:

SYSTem:FORMat:IDENt on page 604

DIAGnostic:SERVice:BIOSinfo? on page 601

DIAGnostic:SERVice:VERSinfo? on page 602

#### **Open Source Acknowledgment: Open**

Displays a PDF file containing information on open source code used by the R&S FSWP firmware.

#### **Install Option**

Opens an edit dialog box to enter the license key for the option that you want to install.

Only user accounts with administrator rights are able to install options.

#### Install Option by XML

Opens a file selection dialog box to install an additional option to the R&S FSWP using an XML file. Enter or browse for the name of an XML file that contains the option key and select "Select".

Only user accounts with administrator rights are able to install options.

## 13.4.3 System Messages

Access: [Setup] > "System Configuration" > "System Messages"

The system messages generated by the R&S FSWP are displayed.

The messages are displayed in the order of their occurrence; the most recent messages are placed at the top of the list. Messages that have occurred since you last visited the system messages tab are marked with an asterisk '\*'.

System Configuration Settings

Hardware Info	Versions + Options	System Messages	Firmware Update	Config
			_Clos	nr All Messa
				n An Messa

If the number of error messages exceeds the capacity of the error buffer, "Message Buffer Overflow" is displayed. To clear the message buffer use the "Clear All Messages" button.

The following information is available:

No	device-specific error code
Message	brief description of the message
Component	hardware messages: name of the affected module
	software messages: name of the affected software
Date/Time	date and time of the occurrence of the message

#### **Remote command:**

SYSTem:ERRor:LIST? on page 603

## 13.4.4 Firmware Updates

Access: [Setup] > "System Configuration" > "Firmware Update"

During instrument start, the installed hardware is checked against the current firmware version to ensure the hardware is supported. If not, an error message is displayed ("Wrong Firmware Version") and you are asked to update the firmware. Until the firmware version is updated, self-alignment fails. To see which components are not supported, see the System Messages.

The firmware on your R&S FSWP may also need to be updated in order to enable additional new features or if reasons for improvement come up. Ask your sales representative or check the Rohde&Schwarz website for availability of firmware updates. A firmware update package includes at least a setup file and release notes.




Before updating the firmware on your instrument, read the release notes delivered with the firmware version.

## Installing options in secure user mode

Be sure to perform any firmware updates before SecureUser Mode is enabled; see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

For restricted users in secure user mode, this function is not available!



Enter the name or browse for the firmware installation file and press the "Install" button.

#### Remote command:

SYSTem:FIRMware:UPDate on page 604

#### How to Update the Instrument Firmware

- Download the update package from the Rohde&Schwarz website and store it on a memory stick, on the instrument, or on a server network drive that can be accessed by the instrument.
- NOTICE! Stop measurement. The firmware update must not be performed during a running measurement.

If a measurement is running, stop it by pressing the highlighted [Run Cont] or [Run Single] key.

- 3. Select the [Setup] key.
- 4. Select the "System Config" softkey.
- 5. Select the "Firmware Update" tab.
- In the file selection dialog box select the FSWPSetup\*.exe file.
   "File Explorer": Instead of using the file manager of the R&S FSWP firmware, you can also use the Microsoft Windows File Explorer to manage files.
- 7. Select "Install" to start the update.
- 8. After the firmware update, the R&S FSWP reboots automatically.
- 9. Depending on the previous firmware version, a reconfiguration of the hardware might be required during the first startup of the firmware. The reconfiguration starts automatically, and a message box informs you about the process. When the reconfiguration has finished, the instrument again reboots automatically.

Note: Do not switch off the instrument during the reconfiguration process!

Now the firmware update is complete.

It is recommended that you perform a self-alignment after the update (see Chapter 13.1.4, "How to Align the Instrument", on page 280).

#### 13.4.5 General Configuration Settings

Access: [Setup] > "System Configuration" > "Config"

General system settings, for example concerning the initial behaviour of the R&S FSWP after booting, can also be configured.

Hardware Info Versions + Options	System Messages Firmware Update Config
Preset Mode	SAN MSRA PNO
Out of range value behavior in entry fields and dialogs	Warning Set Max/Min Value

#### **Preset Mode**

The preset mode selects the application that is started after an instrument preset.

The presettings can be defined in the "Config" tab of the "System Configuration" dialog box.

For details on operating modes see Chapter 8, "Applications", on page 98.

"SAN"	Signal and Spectrum Analyzer mode (Only when the optional Spectrum application has been installed.)
"MSRA"	Multi-Standard Radio Analysis mode (Only when the optional Spectrum application has been installed.)
"PNO"	Phase Noise application

Remote command:

SYSTem:PRESet:COMPatible on page 605

#### Out-of-range value behavior

By default, if you enter a value that is outside the valid range in an input field for a setting, a warning is displayed and the value is not accepted. Alternatively, entries below the minimum value can automatically be set to the minimum possible entry, and entries above the maximum value set to the maximum possible entry. This behavior avoids errors and facilitates setting correct values.

#### SecureUser Mode

If activated, the R&S FSWP requires a reboot and then automatically logs in using the "SecureUser" account.

Data that the R&S FSWP normally stores on the solid-state drive is redirected to volatile memory instead. Data that is stored in volatile memory can be accessed by the user during the current instrument session; however, when the instrument's power is removed, all data in volatile memory is erased.

The Secure User Mode can only be activated or deactivated by a user with administrator rights.

**Note:** Storing instrument settings permanently. Before you activate secure user mode, store any instrument settings that are required beyond the current session, such as predefined instrument settings, transducer files, or self-alignment data.

For details on the secure user mode see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

#### Remote command:

SYSTem:SECurity[:STATe] on page 605

**Note:** Initially after installation of the R&S FSWP-K33 option, secure user mode must be enabled manually once before remote control is possible.

#### Changing the password ← SecureUser Mode

When the secure user mode is activated the first time after installation, you are prompted to change the passwords for all user accounts in order to improve system security.

#### Service Functions

RequestNewPass		
User: Instrume	nt system, current password for this user st	hould be changed
	New password	
	Repeat new password	
Show password		
Keyboard	Cancel	Save

To save the new password, select "Save". The password dialog for the next user is displayed, until you have been prompted to change the password all user accounts.

If you cancel the dialog without changing the password, the password dialog for the next user is displayed, until you have been prompted to change the password all user accounts. Although it is possible to continue in secure user mode without changing the passwords (and you will not be prompted to do so again), it is strongly recommended that you do define a more secure password for all users.

By default, the password characters are not displayed to ensure confidentiality during input. To display the characters, select "Show password" .

To display the onscreen keyboard, select "Keyboard" .

#### Number block behavior

Defines the default behavior of the keypad on the front panel of the R&S FSWP for **text** input. Depending on the type of values you most frequently enter using the keypad, a different default is useful.

"123" Numeric values are entered when you press a key on the keypad. To enter alphanumeric values, use an external or the on-screen keyboard, or switch this setting.

"ABC" (Default) Every key on the keypad represents several characters and one number. If you press the key multiple times in quick succession, you toggle through the symbols assigned to the key. For the assignment, refer to Table 7-6.

# 13.5 Service Functions

Access: [Setup] > "Service"

When unexpected problems arise with the R&S FSWP some service functions may help you solve them.

For more helpful information for support, see also Chapter 17.6, "Collecting Information for Support", on page 635

•	R&S Support Information	304
•	Self-test Settings and Results	305
	Calibration Signal Display	
	Service Functions	
	Hardware Diagnostics.	
-		000

## 13.5.1 R&S Support Information

Access: [Setup] > "Service" > "R&S Support"

In case of errors you can store useful information for troubleshooting and send it to your Rohde & Schwarz support center.

R&S Support Selftest Calibration Sign	al Service Function H	lardware Diagnos	stics
Create R&S Support Information	Location: C:\Applications\		
In case of problems, please write an email with attach the Support Information file and send the email to the Rohde&Schwarz Sup			
Save Device Footprint	Location: C:\Applications\		
Contact Information			
Customer Support Europe, Africa, Middle East	Phone +49 89 4129 12345 customersupport@rohde-sch	nwarz.com	
Customer Support North America:	Phone 1-888-TEST-RSA (1-8 customer:support@rsa.rohde		
Customer Support Latin America:	Phone +1-410-910-7988 customersupport.la@rohde-:	schwarz.com	
Customer Support Asia/Pacific:	Phone +65 65 13 04 88 customersupport.asia@rohd	le-schwarz.com	
Customer Support China:	Phone +86-800-810-8228 / customersupport.china@roh		

#### **Create R&S Support Information**

Creates a \*.zip file with important support information. The \*.zip file contains the system configuration information ( "Device Footprint" ), the current eeprom data and a screenshot of the screen display.

This data is stored to the C:\R\_S\INSTR\USER directory on the instrument.

The file name consists of the unique device ID and the current date and time of the file creation.

If you contact the Rohde & Schwarz support to get help for a certain problem, send these files to the support in order to identify and solve the problem faster.

Remote command:

DIAGnostic:SERVice:SINFo? on page 607

#### **Save Device Footprint**

Creates an \*.xml file with information on installed hardware, software, image and FPGA versions. The \*.xml file is stored under C:\Program Files (x86)\Rohde-Schwarz\FSWP\<version>\devicedata\ xml\ on the instrument. It is also included in the service ZIP file (see " Create R&S Support Information " on page 304).

## 13.5.2 Self-test Settings and Results

Access: [Setup] > "Service" > "Selftest"

If the R&S FSWP fails you can perform a self-test of the instrument to identify any defective modules.

R&S Support Selftest	Signal Path Check	Calibration Signal	Service Function	Hardware Diagnostics	
	Selftest Results:				
Start Selftest	Selftest state: P FW-Version: 1.00 Date (dd/mm/yyyy) Runtime: 00:00 CPU-Temp.: 67	ASSED 1: 02/02/0016 Time: 16:16:	16		-
Abort Selftest					
					_
					•

Once the self-test is started, all modules are checked consecutively and the test result is displayed. You can abort a running test.

In case of failure a short description of the failed test, the defective module, the associated value range and the corresponding test results are indicated.



A running Sequencer process is aborted when you start a self-test.

If you start a self-test remotely, then select the "Local" softkey while the test is still running, the instrument only returns to the manual operation state after the test is completed. In this case, the self-test cannot be aborted.

#### **Remote command:**

\*TST? on page 388

DIAGnostic:SERVice:STESt:RESult? on page 588

## 13.5.3 Calibration Signal Display

Access: [Setup] > "Service" > "Calibration Signal"

Alternatively to the RF input signal from the front panel connector you can use the instrument's calibration signal as the input signal, for example to perform service functions on.

R&S Support	Selftest	Calibration Signal	Service Function	Hardware Diagnostics	
None					
Calibratic	on Frequenc	y RF			
Sp	ectrum	Narrowband	Broadband		
Fre	equency	64.0 MHz			
Calibratic	on Frequenc	y MW			
Fre	equency	8.0 GHz			
Calibratic	on Synthesiz	er 2			
Fre	equency	10.00035885	MHz		
1					

NONE	
Calibration Frequency RF	306
L Spectrum	
L Frequency	
Calibration Frequency MW	
Calibration Synthesizer 2	

#### NONE

Uses the current RF signal at the input, i.e. no calibration signal (default).

```
Remote command:
```

DIAGnostic:SERVice:INPut[:SELect] on page 587

#### **Calibration Frequency RF**

Uses the internal calibration signal as the RF input signal.

Remote command:

DIAGnostic:SERVice:INPut[:SELect] on page 587 DIAGnostic:SERVice:INPut:PULSed:CFRequency on page 587

#### Spectrum - Calibration Frequency RF

Defines whether a broadband or narrowband calibration signal is sent to the RF input.

"Narrowband" Used to calibrate the absolute level of the frontend at 64 MHz.

"Broadband" Used to calibrate the IF filter.

Remote command:

DIAGnostic:SERVice:INPut:RF[:SPECtrum] on page 587

#### 

Defines the frequency of the internal broadband calibration signal to be used for IF filter calibration (max. 64 MHz).

For narrowband signals, 64 MHz is sent.

#### **Calibration Frequency MW**

Uses the microwave calibration signal as the RF input (for frequencies higher than 8 GHz). This function is used to calibrate the YIG-filter on the microwave converter. The microwave calibration signal is pulsed.

You can define whether the distance between input pulses is small or wide.

Remote command:

DIAGnostic:SERVice:INPut[:SELect] on page 587 DIAGnostic:SERVice:INPut:MC[:DISTance] on page 587

#### **Calibration Synthesizer 2**

This function is used to check the phase noise of the synthesizers on a certain frequency. You can define the frequency in the corresponding input field.

If you enter a frequency on which calibration is not possible, the R&S FSWP uses the next available frequency.

Available if the R&S FSWP is equipped with the optional hardware and has more than one synthesizer.

For more information on the calibration process, refer to the service manual.

#### Remote command:

DIAGnostic:SERVice:INPut[:SELect] on page 587 DIAGnostic:SERVice:INPut:SYNThtwo[:FREQuency] on page 588

## 13.5.4 Service Functions

Access: [Setup] > "Service" > "Service Function"


## NOTICE

#### Using service functions

The service functions are not necessary for normal measurement operation. Incorrect use can affect correct operation and/or data integrity of the R&S FSWP.

Therefore, only user accounts with administrator rights can use service functions and many of the functions can only be used after entering a password. These functions are described in the instrument service manual.

#### Service Functions



Service Function	
Send	
Numeric Mode	
Clear History	
Password	
Clear Results	
Save Results	
Result List	

#### **Service Function**

Selects the service function by its numeric code or textual name.

The selection list includes all functions previously selected (since the last "Clear History" action).

#### Remote command:

DIAGnostic:SERVice:SFUNction on page 606

## Send

Starts the selected service function.

Remote command: DIAGnostic:SERVice:SFUNction on page 606

#### **Numeric Mode**

If activated, the service function is selected by its numeric code. Otherwise, the function is selected by its textual name.

#### **Clear History**

Deletes the list of previously selected service functions.

#### Password

Most service functions require a special password as they may disrupt normal operation of the R&S FSWP. There are different levels of service functions, depending on how restrictive their use is handled. Each service level has a different password.

"Reset Password" clears any previously entered password and returns to the most restrictive service level.

Remote command: SYSTem:PASSword[:CENable] on page 608 SYSTem:PASSword:RESet on page 608

#### **Clear Results**

Clears the result display for all previously performed service functions.

Remote command:

DIAGnostic:SERVice:SFUNction:RESults:DELete on page 607

#### Save Results

Opens a file selection dialog box to save the results of all previously performed service functions to a file.

Remote command: DIAGnostic:SERVice:SFUNction:RESults:SAVE on page 607

#### **Result List**

The Results List indicates the status and results of the executed service functions.

## 13.5.5 Hardware Diagnostics

In case problems occur with the instrument hardware, some diagnostic tools provide information that may support troubleshooting.

The hardware diagnostics tools are available in the "Hardware Diagnostics" tab of the "Service" dialog box.

elays Cycle Counter	
Туре	Counter
Mechanical Attenuation 5 dB	0
Mechanical Attenuation 10 dB	23
Mechanical Attenuation 20 dB	0
Mechanical Attenuation 40 dB	0
Calibration Source	0
AC/DC-Coupling	0
Preamplifier	0
Signal Source: Mechanical Attenuation 10 dB	0
Signal Source: Mechanical Attenuation 20 dB	0
Signal Source: Mechanical Attenuation 40 dB	0
Signal Source: Calibration Source	0
	1

## **Relays Cycle Counter**

The hardware relays built into the R&S FSWP may fail after a large number of switching cycles (see data sheet). The counter indicates how many switching cycles the individual relays have performed since they were installed.

Remote command:

DIAGnostic: INFO: CCOunt? on page 601

# 14 Network and Remote Operation

In addition to working with the R&S FSWP interactively, located directly at the instrument, it is also possible to operate and control it from a remote PC. Various methods for remote control are supported:

- Connecting the instrument to a (LAN) network
- Using the web browser interface in a LAN network
- Using the Windows Remote Desktop application in a LAN network
- Connecting a PC via the GPIB interface

How to configure the remote control interfaces is described in Chapter 14.4, "How to Set Up a Network and Remote Control", on page 362.

•	Remote Control Basics	.311
•	The IECWIN Tool	350
•	Network and Remote Control Settings	.351
	How to Set Up a Network and Remote Control	

# 14.1 Remote Control Basics

Basic information on operating an instrument via remote control is provided here. This information applies to all applications and operating modes on the R&S FSWP.



For additional information on remote control of spectrum analyzers see the following application notes available from the Rohde & Schwarz website:

1EF62: Hints and Tricks for Remote Control of Spectrum and Network Analyzers 1MA171: How to use Rohde & Schwarz Instruments in MATLAB 1MA208: Fast Remote Instrument Control with HiSLIP

•	Remote Control Interfaces and Protocols	
•	SCPI (Standard Commands for Programmable Instruments)	
•	VISA Libraries	
•	Messages	
	SCPI Command Structure	
•	Command Sequence and Synchronization	
	Status Reporting System	
	General Programming Recommendations	

## 14.1.1 Remote Control Interfaces and Protocols

The instrument supports different interfaces and protocols for remote control. The following table gives an overview.

Interface	Protocols, VISA*) address string	Remarks		
Local Area Network	HiSLIP High-Speed LAN Instrument Protocol (IVI-6.1)     TCPIP::host address::hislip0[::INSTR]	A LAN connector is located on the rear panel of the instrument.		
(LAN)	Library: VISA     socket communication (Raw Ethernet, simple Telnet)	The interface is based on TCP/IP and supports various protocols.		
		For a description of the protocols refer to:		
	SOCKET Library: VISA or socket controller	VXI-11 Protocol		
		HiSLIP Protocol		
		Socket Communication		
GPIB (IEC/ IEEE Bus Interface)	VISA <sup>*)</sup> address string: GPIB::primary address[::INSTR] (no secondary address)	A GPIB bus interface according to the IEC 625.1/IEEE 488.1 standard is located on the rear panel of the instru- ment.		
		For a description of the interface refer to 14.1.1.2 GPIB Interface (IEC 625/ IEEE 418 Bus Interface).		
USB	VISA*) address string:	USB connectors are located on the		
	USB:: <vendor id="">::<product_id>::<serial_number>[::INSTR]</serial_number></product_id></vendor>	front and rear panel of the instrument. For a description of the interface refer to 14.1.1.3 USB Interface.		
· ·	*) VISA is a standardized software interface library providing input and output functions to communicate with instruments. A VISA installation on the controller is a prerequisite for remote control using the indicated interfaces.			
(See also Ch	(See also Chapter 14.1.3, "VISA Libraries", on page 320).			

#### Table 14-1: Remote control interfaces and protocols



Within this interface description, the term GPIB is used as a synonym for the IEC/IEEE bus interface.

## 14.1.1.1 LAN Interface

To be integrated in a LAN, the instrument is equipped with a LAN interface, consisting of a connector, a network interface card and protocols. The network card can be operated with the following interfaces:

- 10 Mbit/s Ethernet IEEE 802.3
- 100 Mbit/s Ethernet IEEE 802.3u
- 1Gbit/s Ethernet IEEE 802.3ab

For remote control via a network, the PC and the instrument must be connected via the LAN interface to a common network with TCP/IP network protocol. They are connected using a commercial RJ45 cable (shielded or unshielded twisted pair category 5). The TCP/IP network protocol and the associated network services are preconfigured on the instrument. Software for instrument control and the VISA program library must be installed on the controller.

#### **VISA** library

Instrument access is usually achieved from high level programming platforms using VISA as an intermediate abstraction layer. VISA encapsulates the low level VXI, GPIB, LAN or USB function calls and thus makes the transport interface transparent for the user. See Chapter 14.1.3, "VISA Libraries", on page 320 for details.

The R&S FSWP supports various LAN protocols such as VXI11, RSIB, raw socket or the newer HiSLIP protocol.

#### **IP address**

Only the IP address or a valid DNS host name is required to set up the connection. The host address is part of the "VISA resource string" used by the programs to identify and control the instrument.

The VISA resource string has the form:

```
TCPIP::host address[::LAN device name][::INSTR]
```

or

TCPIP::host address::port::SOCKET

where:

- TCPIP designates the network protocol used
- host address is the IP address or host name of the device
- LAN device name defines the protocol and the instance number of a subinstrument;
  - inst0 selects the VXI-11 protocol (default)
  - hislip0 selects the newer HiSLIP protocol
- INSTR indicates the instrument resource class (optional)
- port determines the used port number
- SOCKET indicates the raw network socket resource class

#### Example:

- Instrument has the IP address 192.1.2.3; the valid resource string using VXI-11 protocol is: TCPIP::192.1.2.3::INSTR
- The DNS host name is *FSWP26-123456*; the valid resource string using HiSLIP is: TCPIP::FSWP26-123456::hislip0
- A raw socket connection can be established using: TCPIP::192.1.2.3::5025::SOCKET



#### Identifying instruments in a network

If several instruments are connected to the network, each instrument has its own IP address and associated resource string. The controller identifies these instruments by the resource string.

For details on configuring the LAN connection, see Chapter 14.4.1, "How to Configure a Network", on page 363.

•	VXI-11 Protocol.	314
•	HiSLIP Protocol	.314
•	Socket Communication	314
•	LAN Web Browser Interface	.315

#### VXI-11 Protocol

The VXI-11 standard is based on the ONC RPC (Open Network Computing Remote Procedure Call) protocol which in turn relies on TCP/IP as the network/transport layer. The TCP/IP network protocol and the associated network services are preconfigured. TCP/IP ensures connection-oriented communication, where the order of the exchanged messages is adhered to and interrupted links are identified. With this protocol, messages cannot be lost.

#### **HiSLIP Protocol**

The HiSLIP (High Speed LAN Instrument Protocol) is the successor protocol for VXI-11 for TCP-based instruments specified by the IVI foundation. The protocol uses two TCP sockets for a single connection - one for fast data transfer, the other for non-sequential control commands (e.g. Device Clear or SRQ).

HiSLIP has the following characteristics:

- High performance as with raw socket network connections
- Compatible IEEE 488.2 support for Message Exchange Protocol, Device Clear, Serial Poll, Remote/Local, Trigger, and Service Request
- Uses a single IANA registered port (4880), which simplifies the configuration of firewalls
- Supports simultaneous access of multiple users by providing versatile locking mechanisms
- Usable for IPv6 or IPv4 networks

(j)

Using VXI-11, each operation is blocked until a VXI-11 device handshake returns. However, using HiSLIP, data is sent to the device using the "fire and forget" method with immediate return. Thus, a successful return of a VISA operation such as <code>viWrite()</code> does not guarantee that the instrument has finished or started the requested command, but is delivered to the TCP/IP buffers.

For more information see also the application note:

#### 1MA208: Fast Remote Instrument Control with HiSLIP

#### **Socket Communication**

An alternative way for remote control of the software is to establish a simple network communication using sockets. The socket communication, also referred to as "Raw Ethernet communication", does not necessarily require a VISA installation on the remote controller side. It is available by default on all operating systems.

The simplest way to establish socket communication is to use the built-in telnet program. The telnet program is part of every operating system and supports a communication with the software on a command-by-command basis. For more convenience and to enable automation by means of programs, user-defined sockets can be programmed.

Socket connections are established on a specially defined port. The socket address is a combination of the IP address or the host name of the instrument and the number of the port configured for remote-control. All R&S FSWP use port number 5025 for this purpose. The port is configured for communication on a command-to-command basis and for remote control from a program.

#### LAN Web Browser Interface

The LAN web browser interface allows for easy configuration of the LAN and remote control of the R&S FSWP without additional installation requirements.

The instrument's LAN web browser interface works correctly with all W3C compliant browsers.

Via the web browser interface to the R&S FSWP you can control the instrument remotely from another PC. Manual instrument controls are available via the front panel simulation. File upload and download between the instrument and the remote PC is also available. Using this feature, several users can access *and operate* the R&S FSWP simultaneously. This is useful for troubleshooting or training purposes.

For details, see Chapter 14.4.1.4, "How to Configure the LAN Using the Web Browser Interface", on page 366 and Chapter 14.4.5, "How to Control the R&S FSWP via the Web Browser Interface", on page 372.



If you do not want other users in the LAN to be able to access and operate the R&S FSWP you can deactivate this function.

See Chapter 14.4.6, "How to Deactivate the Web Browser Interface", on page 373.



## Restrictions

Only user accounts with administrator rights can use the LAN web browser functionality.

#### To display the LAN web browser interface

In the address field of the browser on your PC, type the host name or IP address of the instrument, for example: http://10.113.10.203.

The instrument home page (welcome page) opens.

#### **Remote Control Basics**

Status     Instrument Model     FSWP-26 Phase Noise Analyzer       Utilities     Manufacturer     Rohe & Schwarz GmbH & Co. KG       Instrument Control     Serial Number       Web Control     LXI Version     1.4 LXI Core 2011       File Dynold     LXI Version     1.4 LXI Core 2011       File Upload     DNS Host Name(s)     FSWP-1       Manage Licenses     Firmware Revision     1.10       Current Time     Tuesday, 2015/07/14, 13:16:22       Help     Current Time source     Operating System       Gossary     VISA resource string     TCPIP:	LXI 🍝 Inst	rument Properties		
Status     Instrument Model     FSWP-26 Phase Noise Analyzer       Utilities     Manufacturer     Rohe & Schwarz GmbH & Co. KG       Instrument Control     Serial Number       Web Control     LXI Version     1.4 LXI Core 2011       File Dynold     LXI Version     1.4 LXI Core 2011       File Upload     DNS Host Name(s)     FSWP-1       Manage Licenses     Firmware Revision     1.10       Current Time     Tuesday, 2015/07/14, 13:16:22       Help     Current Time source     Operating System       Gossary     VISA resource string     TCPIP:	Home			
Utilities     Instrument Model     FSWP-26 Phase Noise Analyzer       Manufacturer     Rohde & Schwarz GmbH & Co. KG       Instrument Control     Serial Number       Web Control     Description       File Downoad     LXI Version       File Downoad     LXI Extended Features       LXI Extended Features     LXI HISLIP       File Downoad     DNS Host Name(s)       File Ownoad     FSWP-30       License Manager     IP Address       IP Address     Instrument Time       Current Time     Tuesday, 2015/07/14, 13:16:22       Glossary     VISA resource string	Lan Configuration			
Winnes     Manufacturer     Rohde & Schwarz GmbH & Co. KG       Instrument Control     Serial Number       Web Control     LXI Version     R&S FSWP-90       LXI Version     1.4 LXI Core 2011       File Download     LXI Extended Features     LXI HISLIP       File Upload     DNS Host Name(s)     FSWP-International Control       Manage Licenses     Firmware Revision     1.10       Current Time     Tuesday, 2015/07/14, 13:16:22       Glossary     VISA resource string     TCPIP:	Status			
Instrument Control     Serial Number       Web Control     Description     R&S FSWP-90       LXI Version     1.4 LXI Core 2011       File Download     LXI Extended Features     LXI HISLIP       File Upload     DNS Host Name(s)     FSWP-90       LCensee Manager     IP Address     Image Licenses       Manage Licenses     Firmware Revision     1.10       Current Time     Tuesday, 2015/07/14, 13:16:22       Glossary     VISA resource string     TCPIP:	Vtilities			
Web Control     Description     R&S FSWP-90       LXI Version     1.4 LXI Core 2011       File Download     LXI Extended Features     LXI HISLIP       File Upload     DVS Host Name(s)     FSWP-90       Mack Address     FSWP-90       Manage Licenses     Filmware Revision     1.10       Current Time     Tuesday, 2015/07/14, 13:16:22       Glossary     VISA resource string     TCPIP:			Rohde & Schwarz GmbH & Co. KG	
Web Control     LXI Version     1.4 LXI Core 2011       File Download     LXI Extended Features     LXI HISLIP       File Upload     DNS Host Name(s)     FSWP	Instrument Control			
File Download     LXI Extended Features     LXI HISLIP       File Upload     DNS Host Name(s)     FSWP-       License Manager     IP Address     IP       IP Address     IP     IP       Current Time     Tuesday, 2015/07/14, 13:16:22       Current Time source     Operating System       Glossary     VISA resource string     TCPIP:	Web Control			
File Upload     DNS Host Name(s)     FSWP-       License Manager     IP Address     Image Licenses       Manage Licenses     IP Address     Image Licenses       Manage Licenses     Firmware Revision     1.10       Current Time     Tuesday, 2015/07/14, 13:16:22       Glossary     VISA resource string     TCPIP:	File Download			
MAC Address     IP Address       IP Address     IP Address       Manage Licenses     Firmware Revision       Current Time     Tuesday, 2015/07/14, 13:16:22       Current Time source     Operating System       Glossary     VISA resource string       TCPIP::     thislip0::INSTR	File Upload			
Manage Licenses         Firmware Revision         1.10           Giossary         Current Time         Tuesday, 2015/07/14, 13:16:22           Glossary         VISA resource string         CPIP::         InstD:://INSTR				
Manage Lockses         Current Time         Tuesday, 2015/07/14, 13:16:22           Current Time source         Operating System         inst0::INSTR           Glossary         VISA resource string         TCPIP::         inst0::INSTR	License Manager	IP Address		
Current Time         Tuesday, 2015/07/14, 13:16:22           Current Time source         Operating System           Glossary         VISA resource string         TCPIP::	Manage Licenses	Firmware Revision	1.10	
Glossary VISA resource string TCPIP:	munuge Electraca	Current Time	Tuesday, 2015/07/14, 13:16:22	
Glossary VISA resource string TCPIP:: thislipD::INSTR	Help	Current Time source	Operating System	
	Glossary	VISA resource string		
WWW.ronde-schwarz.com Device Indicator INACTIVE (press to toggle)	www.rohde-schwarz.com	Device Indicator	INACTIVE (press to toggle)	
	Stat	tus		
Status		error		

The navigation pane of the browser interface contains the following elements:

- "LAN"
  - "Home" opens the instrument home page.

The home page displays device information, including the VISA resource string in read-only format.

The "Device Indicator" button allows you to physically identify the instrument. This is useful if you have several instruments and want to know which instrument the LAN home page belongs to. To identify the instrument, activate the "Device Indicator". Then check the "LAN Status" indicator of the instruments.

"LAN Configuration" allows you to configure LAN parameters and to initiate a ping.

(See "Ping Client" on page 368.)

- "Utilities" provides access to an event log.
- "Instrument Control"
  - "Web Control" provides remote access to the instrument via VNC (no installation required). Manual instrument controls are available via the front panel simulation.
  - "File Download" downloads files from the instrument.
  - "File Upload" uploads files to the instrument.

(See Chapter 14.4.5, "How to Control the R&S FSWP via the Web Browser Interface", on page 372.)

- "License Manager"
  - "License Manager" allows you to install or uninstall license keys and to activate, register or unregister licenses.
- "Help"

"www.rohde-schwarz.com" opens the Rohde & Schwarz home page.

## 14.1.1.2 GPIB Interface (IEC 625/IEEE 418 Bus Interface)

A GPIB interface is integrated on the rear panel of the instrument.

By connecting a PC to the R&S FSWP via the GPIB connection you can send remote commands to control and operate the instrument.

To be able to control the instrument via the GPIB bus, the instrument and the controller must be linked by a GPIB bus cable. A GPIB bus card, the card drivers and the program libraries for the programming language used must be provided in the controller. The controller must address the instrument with the GPIB bus address (see Chapter 14.4.1.5, "How to Change the GPIB Instrument Address", on page 368). You can set the GPIB address and the ID response string. The GPIB language is set as SCPI by default and cannot be changed for the R&S FSWP.

#### **Notes and Conditions**

In connection with the GPIB interface, note the following:

- Up to 15 instruments can be connected
- The total cable length is restricted to a maximum of 15 m or 2 m times the number of devices, whichever is less; the cable length between two instruments should not exceed 2 m.
- A wired "OR"-connection is used if several instruments are connected in parallel.
- Any connected IEC-bus cables should be terminated by an instrument or controller.

#### **GPIB Interface Messages**

Interface messages are transmitted to the instrument on the data lines, with the attention line (ATN) being active (LOW). They are used for communication between the controller and the instrument and can only be sent by a computer which has the function of a GPIB bus controller. GPIB interface messages can be further subdivided into:

- Universal commands: act on all instruments connected to the GPIB bus without previous addressing
- Addressed commands: only act on instruments previously addressed as listeners

The following figure provides an overview of the available communication lines used by the GPIB interface.

**Remote Control Basics** 




Figure 14-1: Communication lines used by the GPIB interface

## Universal Commands

Universal commands are encoded in the range 10 through 1F hex. They affect all instruments connected to the bus and do not require addressing.

Command	Effect on the instrument
DCL (Device Clear)	Aborts the processing of the commands just received and sets the com- mand processing software to a defined initial state. Does not change the instrument settings.
IFC (Interface Clear) *)	Resets the interfaces to the default setting.
LLO (Local Lockout)	The "Local" softkey is disabled. Manual operation is no longer available until GTL is executed.
SPE (Serial Poll Enable)	Ready for serial poll.
SPD (Serial Poll Disable)	End of serial poll.
PPU (Parallel Poll Unconfig- ure)	End of the parallel-poll state.
*) IFC is not a real universal connected to the bus and does	ommand, it is sent via a separate line; however, it also affects all instruments s not require addressing

#### Addressed Commands

Addressed commands are encoded in the range 00 through 0F hex. They only affect instruments addressed as listeners.

Command	Effect on the instrument
GET (Group Execute Trigger)	Triggers a previously active instrument function (e.g. a sweep). The effect of the command is the same as with that of a pulse at the external trigger signal input.
GTL (Go to Local)	Transition to the "local" state (manual control).
GTR (Go to Remote)	Transition to the "remote" state (remote control).
PPC (Parallel Poll Configure)	Configures the instrument for parallel poll.
SDC (Selected Device Clear)	Aborts the processing of the commands just received and sets the command processing software to a defined initial state. Does not change the instrument setting.

## 14.1.1.3 USB Interface

For remote control via the USB connection, the PC and the instrument must be connected via the USB type B interface. A USB connection requires the VISA library to be installed. VISA detects and configures the R&S instrument automatically when the USB connection is established. You do not have to enter an address string or install a separate driver.

#### **USB** address

The used USB address string is:

USB::<vendor ID>::product ID>::<serial number>[::INSTR]

where:

- <vendor ID> is the vendor ID for Rohde & Schwarz (0x0AAD)
- <product ID> is the product ID for the Rohde & Schwarz instrument
- <serial number> is the individual serial number on the rear of the instrument

#### Table 14-2: Product IDs for R&S FSWP

Instrument model	Product ID
FSWP8	11E
FSWP26	11F
FSWP50	120

#### Example:

USB::0x0AAD::0x0011F::100001::INSTR

0x0AAD is the vendor ID for Rohde & Schwarz

0x0011F is the product ID for the R&S FSWP26

100001 is the serial number of the particular instrument

## 14.1.2 SCPI (Standard Commands for Programmable Instruments)

SCPI commands - messages - are used for remote control. Commands that are not taken from the SCPI standard follow the SCPI syntax rules. The R&S FSWP supports the SCPI version 1999. The SCPI standard is based on standard IEEE 488.2 and aims at the standardization of device-specific commands, error handling and the status registers. The tutorial "Automatic Measurement Control - A tutorial on SCPI and IEEE 488.2" from John M. Pieper (R&S order number 0002.3536.00) offers detailed information on concepts and definitions of SCPI.

Tables provide a fast overview of the bit assignment in the status registers. The tables are supplemented by a comprehensive description of the status registers.

## 14.1.3 VISA Libraries

VISA is a standardized software interface library providing input and output functions to communicate with instruments. The I/O channel (LAN or TCP/IP, USB, ...) is selected at initialization time by one of the following:

- The channel–specific address string ("VISA resource string") indicated in Table 14-1
- An appropriately defined VISA alias (short name).

A VISA installation is a prerequisite for remote control using the following interfaces:

- Chapter 14.1.1.2, "GPIB Interface (IEC 625/IEEE 418 Bus Interface)", on page 317
- Chapter 14.1.1.1, "LAN Interface", on page 312

• Chapter 14.1.1.3, "USB Interface", on page 319

For more information about VISA, refer to the user documentation.

## 14.1.4 Messages

The messages transferred on the data lines are divided into the following categories:

Interface messages

Interface messages are transmitted to the instrument on the data lines, with the attention line being active (LOW). They are used to communicate between the controller and the instrument. Interface messages can only be sent by instruments that have GPIB bus functionality. For details see the sections for the required interface.

Instrument messages

Instrument messages are employed in the same way for all interfaces, if not indicated otherwise in the description. Structure and syntax of the instrument messages are described in Chapter 14.1.5, "SCPI Command Structure", on page 322. A detailed description of all messages available for the instrument is provided in the chapter "Remote Control Commands".

There are different types of instrument messages, depending on the direction they are sent:

- Commands
- Instrument responses

#### Commands

Commands (program messages) are messages the controller sends to the instrument. They operate the instrument functions and request information. The commands are subdivided according to two criteria:

- According to the effect they have on the instrument:
  - Setting commands cause instrument settings such as a reset of the instrument or setting the frequency.
  - Queries cause data to be provided for remote control, e.g. for identification of the instrument or polling a parameter value. Queries are formed by directly appending a question mark to the command header.
- According to their definition in standards:
  - Common commands: their function and syntax are precisely defined in standard IEEE 488.2. They are employed identically on all instruments (if implemented). They refer to functions such as management of the standardized status registers, reset and self-test.
  - Instrument control commands refer to functions depending on the features of the instrument such as frequency settings. Many of these commands have also been standardized by the SCPI committee. These commands are marked as "SCPI confirmed" in the command reference chapters. Commands without this SCPI label are device-specific; however, their syntax follows SCPI rules as permitted by the standard.

#### Instrument responses

Instrument responses (response messages and service requests) are messages the instrument sends to the controller after a query. They can contain measurement results, instrument settings and information on the instrument status.

## 14.1.5 SCPI Command Structure

SCPI commands consist of a header and, in most cases, one or more parameters. The header and the parameters are separated by a "white space" (ASCII code 0 to 9, 11 to 32 decimal, e.g. blank). The headers may consist of several mnemonics (keywords). Queries are formed by appending a question mark directly to the header.

The commands can be either device-specific or device-independent (common commands). Common and device-specific commands differ in their syntax.

#### 14.1.5.1 Syntax for Common Commands

Common (= device-independent) commands consist of a header preceded by an asterisk (\*), and possibly one or more parameters.

*RST	RESET	Resets the instrument.
*ESE	EVENT STATUS ENABLE	Sets the bits of the event status enable registers.
*ESR?	EVENT STATUS QUERY	Queries the contents of the event status register.
*IDN?	IDENTIFICATION QUERY	Queries the instrument identification string.

Table 14-3: Examples of common commands

#### 14.1.5.2 Syntax for Device-Specific Commands

(i

Not all commands used in the following examples are necessarily implemented in the instrument. For demonstration purposes only, assume the existence of the following commands for this section:

- DISPlay[:WINDow<1...4>]:MAXimize <Boolean>
- FORMat:READings:DATA <type>[,<length>]
- HCOPy:DEVice:COLor <Boolean>
- HCOPy:DEVice:CMAP:COLor:RGB <red>, <green>, <blue>
- HCOPy[:IMMediate]
- HCOPy:ITEM:ALL
- HCOPy:ITEM:LABel <string>
- HCOPy:PAGE:DIMensions:QUADrant[<N>]
- HCOPy:PAGE:ORIentation LANDscape | PORTrait
- HCOPy:PAGE:SCALe <numeric value>
- MMEMory:COPY <file\_source>,<file\_destination>
- SENSE:BANDwidth|BWIDth[:RESolution] <numeric value>
- SENSe:FREQuency:STOP <numeric value>
- SENSe:LIST:FREQuency <numeric\_value>{,<numeric\_value>}

٠	Long and short form	323
•	Numeric Suffixes	323
	Optional Mnemonics	324

#### Long and short form

The mnemonics feature a long form and a short form. The short form is marked by upper case letters, the long form corresponds to the complete word. Either the short form or the long form can be entered; other abbreviations are not permitted.

#### Example:

HCOPy:DEVice:COLor ON is equivalent to HCOP:DEV:COL ON.



#### Case-insensitivity

Upper case and lower case notation only serves to distinguish the two forms in the manual, the instrument itself is case-insensitive.

#### **Numeric Suffixes**

If a command can be applied to multiple instances of an object, e.g. specific channels or sources, the required instances can be specified by a suffix added to the command. Numeric suffixes are indicated by angular brackets (<1...4>, <n>, <i>) and are replaced by a single value in the command. Entries without a suffix are interpreted as having the suffix 1.

## Example:

**Definition**: HCOPy: PAGE: DIMensions: QUADrant [<N>]

Command: HCOP: PAGE: DIM: QUAD2

This command refers to the quadrant 2.



#### Different numbering in remote control

For remote control, the suffix may differ from the number of the corresponding selection used in manual operation. SCPI prescribes that suffix counting starts with 1. Suffix 1 is the default state and used when no specific suffix is specified.

Some standards define a fixed numbering, starting with 0. If the numbering differs in manual operation and remote control, it is indicated for the corresponding command.

#### **Optional Mnemonics**

Some command systems permit certain mnemonics to be inserted into the header or omitted. These mnemonics are marked by square brackets in the description. The instrument must recognize the long command to comply with the SCPI standard. Some commands are considerably shortened by these optional mnemonics.

## Example:

**Definition**: HCOPy[:IMMediate] **Command**: HCOP:IMM is equivalent to HCOP



#### Optional mnemonics with numeric suffixes

Do not omit an optional mnemonic if it includes a numeric suffix that is relevant for the effect of the command.

#### Example:

**Definition**:DISPlay[:WINDow<1...4>]:MAXimize <Boolean>

Command: DISP:MAX ON refers to window 1.

In order to refer to a window other than 1, you must include the optional WINDow parameter with the suffix for the required window.

DISP:WIND2:MAX ON refers to window 2.

#### 14.1.5.3 SCPI Parameters

Many commands are supplemented by a parameter or a list of parameters. The parameters must be separated from the header by a "white space" (ASCII code 0 to 9, 11 to 32 decimal, e.g. blank).

The parameters required for each command and the allowed range of values are specified in the command description.

Allowed parameters are:

## Remote Control Basics

•	Numeric Values	. 325
•	Special Numeric Values	325
•	Boolean Parameters	326
•	Text Parameters	. 326
•	Character Strings	326
	Block Data	

## **Numeric Values**

Numeric values can be entered in any form, i.e. with sign, decimal point and exponent. Values exceeding the resolution of the instrument are rounded up or down. The mantissa may comprise up to 255 characters, the exponent must lie inside the value range -32000 to 32000. The exponent is introduced by an "E" or "e". Entry of the exponent alone is not allowed.

#### Example:

SENS: FREQ: STOP 1500000 = SENS: FREQ: STOP 1.5E6

#### Units

For physical quantities, the unit can be entered. If the unit is missing, the basic unit is used. Allowed unit prefixes are:

- G (giga)
- MA (mega), MOHM, MHZ
- K (kilo)
- M (milli)
- U (micro)
- N (nano)

#### Example:

SENSe:FREQ:STOP 1.5GHz = SENSe:FREQ:STOP 1.5E9

Some settings allow relative values to be stated in percent. According to SCPI, this unit is represented by the PCT string.

## Example:

```
HCOP:PAGE:SCAL 90PCT
```

## **Special Numeric Values**

The following mnemonics are special numeric values. In the response to a query, the numeric value is provided.

- MIN and MAX: denote the minimum and maximum value.
- DEF: denotes a preset value which has been stored in the EPROM. This value conforms to the default setting, as it is called by the \*RST command.
- UP and DOWN: increases or reduces the numeric value by one step. The step width can be specified via an allocated step command for each parameter which can be set via UP and DOWN.

- INF and NINF: INFinity and negative INFinity (NINF) represent the numeric values 9.9E37 or -9.9E37, respectively. INF and NINF are only sent as instrument responses.
- NAN: Not A Number (NAN) represents the value 9.91E37. NAN is only sent as a instrument response. This value is not defined. Possible causes are the division of zero by zero, the subtraction of infinite from infinite and the representation of missing values.

## Example:

Setting command: SENSe:LIST:FREQ MAXimum

Query: SENS:LIST:FREQ? Response: 3.5E9



## Queries for special numeric values

The numeric values associated to MAXimum/MINimum/DEFault can be queried by adding the corresponding mnemonic after the quotation mark.

Example: SENSe:LIST:FREQ? MAXimum

Returns the maximum numeric value as a result.

## **Boolean Parameters**

Boolean parameters represent two states. The "ON" state (logically true) is represented by "ON" or a numeric value 1. The "OFF" state (logically untrue) is represented by "OFF" or the numeric value 0. The numeric values are provided as the response for a query.

## Example:

Setting command: HCOPy: DEV: COL ON Query: HCOPy: DEV: COL?

\_\_\_\_\_

Response: 1

## **Text Parameters**

Text parameters observe the syntactic rules for mnemonics, i.e. they can be entered using a short or long form. Like any parameter, they have to be separated from the header by a white space. In the response to a query, the short form of the text is provided.

## Example:

Setting command: HCOPy:PAGE:ORIentation LANDscape Query: HCOP:PAGE:ORI? Response: LAND

#### **Character Strings**

Strings must always be entered in quotation marks (' or ").

## Example:

HCOP:ITEM:LABel "Test1" HCOP:ITEM:LABel 'Test1'

## **Block Data**

Block data is a format which is suitable for the transmission of large amounts of data. For example, a command using a block data parameter has the following structure:

FORMat:READings:DATA #45168xxxxxxx

The ASCII character # introduces the data block. The next number indicates how many of the following digits describe the length of the data block. In the example the 4 following digits indicate the length to be 5168 bytes. The data bytes follow. During the transmission of these data bytes all end or other control signs are ignored until all bytes are transmitted.

#0 specifies a data block of indefinite length. The use of the indefinite format requires a NL^END message to terminate the data block. This format is useful when the length of the transmission is not known or if speed or other considerations prevent segmentation of the data into blocks of definite length.

## 14.1.5.4 Overview of Syntax Elements

The following tables provide an overview of the syntax elements and special characters.

	-
:	The colon separates the mnemonics of a command.
;	The semicolon separates two commands of a command line. It does not alter the path.
,	The comma separates several parameters of a command.
?	The question mark forms a query.
*	The asterisk marks a common command.
	Quotation marks introduce a string and terminate it (both single and double quotation marks are possible).
#	The hash symbol introduces binary, octal, hexadecimal and block data. • Binary: #B10110 • Octal: #O7612 • Hexa: #HF3A7 • Block: #21312
	A "white space" (ASCII-Code 0 to 9, 11 to 32 decimal, e.g. blank) separates the header from the parameters.

#### Table 14-4: Syntax elements

#### Table 14-5: Special characters

1	Parameters
	A vertical stroke in parameter definitions indicates alternative possibilities in the sense of "or". The effect of the command differs, depending on which parameter is used.
	Example:
	Definition:HCOPy:PAGE:ORIentation LANDscape   PORTrait
	Command HCOP: PAGE: ORI LAND specifies landscape orientation
	Command HCOP: PAGE: ORI PORT specifies portrait orientation
	Mnemonics
	A selection of mnemonics with an identical effect exists for several commands. These mnemonics are indicated in the same line; they are separated by a vertical stroke. Only one of these mnemonics needs to be included in the header of the command. The effect of the command is independent of which of the mnemonics is used.
	Example:
	DefinitionSENSE:BANDwidth BWIDth[:RESolution] <numeric_value></numeric_value>
	The two following commands with identical meaning can be created:
	SENS:BAND:RES 1
	SENS:BWID:RES 1
[]	Mnemonics in square brackets are optional and may be inserted into the header or omitted.
	Example: HCOPy[:IMMediate]
	HCOP: IMM is equivalent to HCOP
{}	Parameters in curly brackets are optional and can be inserted once or several times, or omitted.
	<pre>Example: SENSe:LIST:FREQuency <numeric_value>{,<numeric_value>}</numeric_value></numeric_value></pre>
	The following are valid commands:
	SENS:LIST:FREQ 10
	SENS:LIST:FREQ 10,20
	SENS:LIST:FREQ 10,20,30,40

## 14.1.5.5 Structure of a Command Line

A command line may consist of one or several commands. It is terminated by one of the following:

- <New Line>
- New Line> with EOI
- EOI together with the last data byte

Several commands in a command line must be separated by a semicolon ";".

## Example:

MMEM:COPY "Test1", "MeasurementXY";:HCOP:ITEM ALL

This command line contains two commands. The first command belongs to the MMEM system, the second command belongs to the HCOP system. If the next command belongs to a different command system, the semicolon is followed by a colon.

## Example:

HCOP:ITEM ALL;:HCOP:IMM

This command line contains two commands. Both commands are part of the HCOP command system, i.e. they have one level in common.

If the successive commands belong to the same system, having one or several levels in common, the command line can be abbreviated. When abbreviating the command line, the second command begins with the level below HCOP. The colon after the semicolon is omitted. The abbreviated form of the command line reads as follows:

HCOP:ITEM ALL;IMM

## Example:

HCOP:ITEM ALL

HCOP:IMM

A new command line always begins with the complete path.

# 14.1.5.6 Responses to Queries

A query is defined for each setting command unless explicitly specified otherwise. It is formed by adding a question mark to the associated setting command. According to SCPI, the responses to queries are partly subject to stricter rules than in standard IEEE 488.2.

- The requested parameter is transmitted without a header. **Example:** HCOP: PAGE: ORI?, **Response**: LAND
- Maximum values, minimum values and all other quantities that are requested via a special text parameter are returned as numeric values.
   Example: SENSe: FREQuency: STOP? MAX, Response: 3.5E9
- Numeric values are output without a unit. Physical quantities are referred to the basic units or to the units set using the Unit command. The response 3.5E9 in the previous example stands for 3.5 GHz.
- Truth values (Boolean values) are returned as 0 (for OFF) and 1 (for ON).
   Example: Setting command: HCOPY: DEV: COL ON

Query: HCOPy: DEV: COL? Response: 1

- Text (character data) is returned in a short form. Example: Setting command: HCOPy:PAGE:ORIentation LANDscape Query: HCOP:PAGE:ORI? Response: LAND
- Invalid numerical results In some cases, particularly when a result consists of multiple numeric values, invalid values are returned as 9.91E37 (not a number).

# 14.1.6 Command Sequence and Synchronization

IEEE 488.2 defines a distinction between overlapped and sequential commands:

- A sequential command is one which finishes executing before the next command starts executing. Commands that are processed quickly are usually implemented as sequential commands.
- An overlapping command is one which does not automatically finish executing before the next command starts executing. Usually, overlapping commands take longer to process and allow the program to do other tasks while being executed. If overlapping commands do have to be executed in a defined order, e.g. in order to avoid wrong measurement results, they must be serviced sequentially. This is called synchronization between the controller and the instrument.

Setting commands within one command line, even though they may be implemented as sequential commands, are not necessarily serviced in the order in which they have been received. In order to make sure that commands are actually carried out in a certain order, each command must be sent in a separate command line.

## Example: Commands and queries in one message

The response to a query combined in a program message with commands that affect the queried value is not predictable.

The following commands always return the specified result:

:FREQ:STAR 1GHZ;SPAN 100;:FREQ:STAR?

Result:

100000000 (1 GHz)

Whereas the result for the following commands is not specified by SCPI:

:FREQ:STAR 1GHz;STAR?;SPAN 1000000

The result could be the value of STARt before the command was sent since the instrument might defer executing the individual commands until a program message terminator is received. The result could also be 1 GHz if the instrument executes commands as they are received.



As a general rule, send commands and queries in different program messages.

## Example: Overlapping command with \*OPC

The instrument implements INITiate[:IMMediate] as an overlapped command. Assuming that INITiate[:IMMediate] takes longer to execute than \*OPC, sending the following command sequence results in initiating a sweep and, after some time, setting the OPC bit in the ESR:

INIT; \*OPC.

Sending the following commands still initiates a sweep:

INIT; \*OPC; \*CLS

However, since the operation is still pending when the instrument executes \*CLS, forcing it into the "Operation Complete Command Idle" State (OCIS), \*OPC is effectively skipped. The OPC bit is not set until the instrument executes another \*OPC command.

## 14.1.6.1 Preventing Overlapping Execution

To prevent an overlapping execution of commands, one of the commands **\*OPC**, **\*OPC**? or **\*WAI** can be used. All three commands cause a certain action only to be carried out after the hardware has been set. The controller can be forced to wait for the corresponding action to occur.

Com- mand	Action	Programming the controller
*OPC	Sets the Operation Complete bit in the ESR after all previous commands have been exe- cuted.	<ul> <li>Setting bit 0 in the ESE</li> <li>Setting bit 5 in the SRE</li> <li>Waiting for service request (SRQ)</li> </ul>
*OPC?	Stops command processing until 1 is returned. This occurs when all pending opera- tions are completed.	Send *OPC? directly after the command whose processing must be terminated before other commands can be executed.
*WAI	Stops further command processing until all commands sent before *WAI have been exe- cuted.	Send *WAI directly after the command whose processing must be terminated before other commands are executed.

Table 14-6: Synchronization using \*OPC, \*OPC? and \*WAI

Command synchronization using \*WAI or \*OPC? is a good choice if the overlapped command takes only little time to process. The two synchronization commands simply block overlapped execution of the command. Append the synchronization command to the overlapping command, for example:

### SINGle; \*OPC?

For time consuming overlapped commands, you can allow the controller or the instrument to do other useful work while waiting for command execution. Use one of the following methods:

## \*OPC with a service request

- 1. Set the OPC mask bit (bit no. 0) in the ESE: \*ESE 1
- 2. Set bit no. 5 in the SRE: \*SRE 32 to enable ESB service request.
- 3. Send the overlapped command with \*OPC .

4. Wait for a service request.

The service request indicates that the overlapped command has finished.

## \*OPC? with a service request

- 1. Set bit no. 4 in the SRE: \*SRE 16 to enable MAV service request.
- 2. Send the overlapped command with \*OPC?.
- 3. Wait for a service request.

The service request indicates that the overlapped command has finished.

## Event status register (ESE)

- 1. Set the OPC mask bit (bit no. 0) in the ESE: \*ESE 1
- 2. Send the overlapped command without \*OPC, \*OPC? or \*WAI.
- 3. Poll the operation complete state periodically (with a timer) using the sequence: \*OPC; \*ESR?

A return value (LSB) of 1 indicates that the overlapped command has finished.

# 14.1.7 Status Reporting System

The status reporting system stores all information on the current operating state of the instrument, and on errors which have occurred. This information is stored in the status registers and in the error queue. Both can be queried via GPIB bus or LAN interface (STATUS... commands.

(See Chapter 15.10, "Using the Status Register", on page 614).

•	Hierarchy of Status Registers	332
	Structure of a SCPI Status Register	
	Contents of the Status Registers	
	Application of the Status Reporting System	
	Parent Veluces of the Ototus Denerting Conterns	0.40

## 14.1.7.1 Hierarchy of Status Registers

As shown in the following figure, the status information is of hierarchical structure.

## **Remote Control Basics**




Figure 14-2: Graphical overview of the R&S FSWP status registers hierarchy

#### • STB, SRE

The STatus Byte (STB) register and its associated mask register Service Request Enable (SRE) form the highest level of the status reporting system. The STB provides a rough overview of the instrument status, collecting the information of the lower-level registers.

## ESR, SCPI registers

The STB receives its information from the following registers:

- The Event Status Register (ESR) with the associated mask register standard Event Status Enable (ESE).
- The STATUS: OPERation and STATUS: QUEStionable registers which are defined by SCPI and contain detailed information on the instrument.
- IST, PPE

The IST flag ("Individual STatus"), like the SRQ, combines the entire instrument status in a single bit. The PPE fulfills the same function for the IST flag as the SRE for the service request.

Output buffer

The output buffer contains the messages the instrument returns to the controller. It is not part of the status reporting system but determines the value of the MAV bit in the STB and thus is represented in the overview.

All status registers have the same internal structure.



# SRE, ESE

The service request enable register SRE can be used as ENABLE part of the STB if the STB is structured according to SCPI. By analogy, the ESE can be used as the ENABLE part of the ESR.

# 14.1.7.2 Structure of a SCPI Status Register

Each standard SCPI register consists of 5 parts. Each part has a width of 16 bits and has different functions. The individual bits are independent of each other, i.e. each hardware status is assigned a bit number which is valid for all five parts. Bit 15 (the most significant bit) is set to zero for all parts. Thus the contents of the register parts can be processed by the controller as positive integers.




Figure 14-3: The status-register model

## Description of the five status register parts

The five parts of a SCPI register have different properties and functions:

CONDition

The CONDition part is written into directly by the hardware or the sum bit of the next lower register. Its contents reflect the current instrument status. This register part can only be read, but not written into or cleared. Its contents are not affected by reading.

## • PTRansition / NTRansition

The two transition register parts define which state transition of the CONDition part (none, 0 to 1, 1 to 0 or both) is stored in the EVENt part.

The **Positive-TRansition** part acts as a transition filter. When a bit of the CONDition part is changed from 0 to 1, the associated PTR bit decides whether the EVENt bit is set to 1.

- PTR bit =1: the EVENt bit is set.
- PTR bit =0: the EVENt bit is not set.

This part can be written into and read as required. Its contents are not affected by reading.

The **Negative-TRansition** part also acts as a transition filter. When a bit of the CONDition part is changed from 1 to 0, the associated NTR bit decides whether the EVENt bit is set to 1.

- NTR bit =1: the EVENt bit is set.
- NTR bit =0: the EVENt bit is not set.

This part can be written into and read as required. Its contents are not affected by reading.

EVENt

The EVENt part indicates whether an event has occurred since the last reading, it is the "memory" of the condition part. It only indicates events passed on by the transition filters. It is permanently updated by the instrument. This part can only be read by the user. Reading the register clears it. This part is often equated with the entire register.

ENABle

The ENABLE part determines whether the associated EVENt bit contributes to the sum bit (see below). Each bit of the EVENt part is "ANDed" with the associated ENABLE bit (symbol '&'). The results of all logical operations of this part are passed on to the sum bit via an "OR" function (symbol '+').

ENABLe bit = 0: the associated EVENt bit does not contribute to the sum bit ENABLe bit = 1: if the associated EVENt bit is "1", the sum bit is set to "1" as well. This part can be written into and read by the user as required. Its contents are not affected by reading.

## Sum bit

The sum bit is obtained from the EVENt and ENABLe part for each register. The result is then entered into a bit of the CONDition part of the higher-order register.

The instrument automatically generates the sum bit for each register. Thus an event can lead to a service request throughout all levels of the hierarchy.

## 14.1.7.3 Contents of the Status Registers

In the following sections, the contents of the status registers are described in more detail.

#### **Remote Control Basics**

•	STATus:QUEStionable:ACPLimit Register	.340
•	STATus:QUEStionable:EXTended Register	341
•	STATus:QUEStionable:EXTended:INFO Register	341
•	STATus:QUEStionable:FREQuency Register	342
•	STATus:QUEStionable:LIMit Register	342
•	STATus:QUEStionable:LMARgin Register	343
•	STATus:QUEStionable:POWer Register	344
•	STATus:QUEStionable:POWer:DCPNoise	344
•	STATus:QUEStionable:PNOise	.345
•	STATus:QUEStionable:TEMPerature Register	345
•	STATus:QUEStionable:TIMe Register	346

## Status Byte (STB) and Service Request Enable Register (SRE)

The STatus Byte (STB) is already defined in IEEE 488.2. It provides a rough overview of the instrument status by collecting the pieces of information of the lower registers. A special feature is that bit 6 acts as the sum bit of the remaining bits of the status byte.

The STB can thus be compared with the CONDition part of an SCPI register and assumes the highest level within the SCPI hierarchy.

The STB is read using the command \*STB? or a serial poll.

The STatus Byte (STB) is linked to the Service Request Enable (SRE) register. Each bit of the STB is assigned a bit in the SRE. Bit 6 of the SRE is ignored. If a bit is set in the SRE and the associated bit in the STB changes from 0 to 1, a service request (SRQ) is generated. The SRE can be set using the command \*SRE and read using the command \*SRE?.

Bit No.	Meaning
01	Not used
2	Error Queue not empty The bit is set when an entry is made in the error queue. If this bit is enabled by the SRE, each entry of the error queue generates a service request. Thus an error can be recognized and specified in greater detail by polling the error queue. The poll provides an informative error mes- sage. This procedure is to be recommended since it considerably reduces the problems involved with remote control.
3	QUEStionable status register summary bit The bit is set if an EVENt bit is set in the QUEStionable status register and the associated ENABle bit is set to 1. A set bit indicates a questionable instrument status, which can be speci- fied in greater detail by querying the STATUS:QUEStionable status register.
4	MAV bit (message available) The bit is set if a message is available in the output queue which can be read. This bit can be used to enable data to be automatically read from the instrument to the controller.
5	ESB bit Sum bit of the event status register. It is set if one of the bits in the event status register is set and enabled in the event status enable register. Setting of this bit indicates a serious error which can be specified in greater detail by polling the event status register.

Table 14-7: Meaning of the bits used in the status byte

Bit No.	Meaning
6	MSS bit (main status summary bit)
	The bit is set if the instrument triggers a service request. This is the case if one of the other bits of this registers is set together with its mask bit in the service request enable register SRE.
7	STATus: OPERation status register summary bit
	The bit is set if an EVENt bit is set in the OPERation status register and the associated ENABle bit is set to 1. A set bit indicates that the instrument is just performing an action. The type of action can be determined by querying the STATUS:OPERation status register.

## IST Flag and Parallel Poll Enable Register (PPE)

As with the SRQ, the IST flag combines the entire status information in a single bit. It can be read by means of a parallel poll (see "Parallel Poll" on page 347) or using the command \*IST?.

The parallel poll enable register (PPE) determines which bits of the STB contribute to the IST flag. The bits of the STB are "ANDed" with the corresponding bits of the PPE, with bit 6 being used as well in contrast to the SRE. The IST flag results from the "ORing" of all results. The PPE can be set using commands \*PRE and read using command \*PRE?.

## Event Status Register (ESR) and Event Status Enable Register (ESE)

The ESR is defined in IEEE 488.2. It can be compared with the EVENt part of a SCPI register. The event status register can be read out using command \*ESR?.

The ESE corresponds to the ENABLe part of a SCPI register. If a bit is set in the ESE and the associated bit in the ESR changes from 0 to 1, the ESB bit in the STB is set. The ESE register can be set using the command \*ESE and read using the command \*ESE?.

Bit No.	Meaning
0	Operation Complete
	This bit is set on receipt of the command *OPC exactly when all previous commands have been executed.
1	Not used
2	Query Error
	This bit is set if either the controller wants to read data from the instrument without having sent a query, or if it does not fetch requested data and sends new instructions to the instrument instead. The cause is often a query which is faulty and hence cannot be executed.
3	Device-dependent Error
	This bit is set if a device-dependent error occurs. An error message with a number between -300 and -399 or a positive error number, which denotes the error in greater detail, is entered into the error queue.
4	Execution Error
	This bit is set if a received command is syntactically correct but cannot be performed for other reasons. An error message with a number between -200 and -300, which denotes the error in greater detail, is entered into the error queue.

Table 14-8: Meaning of the bits used in the event status register

Bit No.	Meaning
5	Command Error
	This bit is set if a command is received, which is undefined or syntactically incorrect. An error message with a number between -100 and -200, which denotes the error in greater detail, is entered into the error queue.
6	User Request
	This bit is set when the instrument is switched over to manual control.
7	Power On (supply voltage on)
	This bit is set on switching on the instrument.

## STATus:OPERation Register

The STATus:OPERation register contains information on current activities of the R&S FSWP. It also contains information on activities that have been executed since the last read out.

Bit No.	Meaning
0	CALibrating
	This bit is set as long as the instrument is performing a calibration.
1-2	Not used
3	SWEeping
	Sweep is being performed in base unit (applications are not considered); identical to bit 4 Available in the optional Spectrum application.
4	MEASuring
	Measurement is being performed in base unit (applications are not considered); identical to bit 3 Available in the optional Spectrum application.
5	Waiting for TRIgger
	Instrument is ready to trigger and waiting for trigger signal.
	Available in the optional Spectrum application.
6-7	Not used
8	HardCOPy in progress
	This bit is set while the instrument is printing a hardcopy.
9	Not used
10	Range completed
	This bit is set when a range in the sweep list has been completed if "Stop after Range" has been activated.
	Available in the optional Spectrum application.
11-14	Not used
15	This bit is always 0.

Table 14-9: Meaning of the bits used in the STATus:OPERation register

## STATus:QUEStionable Register

The STATus:QUEStionable register contains information on instrument states that do not meet the specifications.

You can read out the register with STAT: QUES: COND or STAT: QUES: EVEN.

(j

The STATUS:QUEStionable register "sums up" the information from all subregisters (e.g. bit 2 sums up the information for all STATUS:QUEStionable:TIMe registers). For some subregisters, there may be separate registers for each active channel. Thus, if a status bit in the STATUS:QUEStionable register indicates an error, the error may have occurred in any of the channel-specific subregisters. In this case, you must check the subregister of each channel to determine which channel caused the error. By default, querying the status of a subregister always returns the result for the currently selected channel.

Bit No.	Meaning
0 - 1	Unused
2	TIMe This bit is set if a time error occurs in any of the active channels. The STATus:QUEStionable:TIMe Register provides more information on the error type. Available in the optional Spectrum application.
3	POWer This bit is set if the measured power level in any of the active channels is questionable. The STATus:QUEStionable:POWer Register provides more information on the error type.
4	TEMPerature This bit is set if the temperature is questionable.
5	FREQuency This bit is set if there is anything wrong with the frequency of the local oscillator or the reference frequency in any of the active channels. The STATus:QUEStionable:FREQuency Register provides more information on the error type.
6 - 7	Unused
8	CALibration This bit is set if the R&S FSWP is unaligned ("UNCAL" display)
9	LIMit This bit is set if a limit value is violated in any of the active channels in any window. The STATus:QUEStionable:LIMit Register provides more information on the error type.
10	LMARgin This bit is set if a margin is violated in any of the active channels in any window. The STATus:QUEStionable:LMARgin Register provides more information on the error type. Available in the optional Spectrum application.

#### Table 14-10: Meaning of the bits used in the STATus:QUEStionable register

Bit No.	Meaning
11	SYNC (device-specific)
	This bit is set if the R&S FSWP is not synchronized to the signal that is applied.
	The R&S FSWP is not synchronized if the results deviate too much from the expected value during premeasurements
12	ACPLimit
	This bit is set if a limit during ACLR measurements is violated in any of the active channels.
	The STATus:QUEStionable:ACPLimit Register provides more information on the error type.
	Available in the optional Spectrum application.
13	PNOise
	This bit is set if an event occurs in the Phase Noise measurement.
	The "STATus:QUEStionable:PNOise" on page 345 provides more information on the event type.
15	This bit is always 0.

# STATus:QUEStionable:ACPLimit Register

Available for the Spectrum application.

The STATus:QUEStionable:ACPLimit register contains information about the results of a limit check during ACLR measurements. A separate ACPLimit register exists for each active channel.

You can read out the register with STATus:QUEStionable:ACPLimit:CONDition? or STATus:QUEStionable:ACPLimit[:EVENt]?

Table 14-11: Meaning of the bits used in the STATus:QUEStionable:ACPLimit register

Bit No.	Meaning
0	ADJ UPPer FAIL
	This bit is set if the limit is exceeded in the upper adjacent channel
1	ADJ LOWer FAIL
	This bit is set if the limit is exceeded in the <b>lower adjacent</b> channel.
2	ALT1 UPPer FAIL
	This bit is set if the limit is exceeded in the <b>upper 1st alternate</b> channel.
3	ALT1 LOWer FAIL
	This bit is set if the limit is exceeded in the <b>lower 1st alternate</b> channel.
4	ALT2 UPPer FAIL
	This bit is set if the limit is exceeded in the <b>upper 2nd alternate</b> channel.
5	ALT2 LOWer FAIL
	This bit is set if the limit is exceeded in the <b>lower 2nd alternate</b> channel.
6	ALT3 11 LOWer/UPPer FAIL
	This bit is set if the limit is exceeded in one of the lower or upper alternate channels 3 11.
7	CACLR FAIL
	This bit is set if the CACLR limit is exceeded in one of the gap channels.

Bit No.	Meaning
8	GAP ACLR FAIL
	This bit is set if the ACLR limit is exceeded in one of the gap channels.
9 to 14	Unused
15	This bit is always 0.

## STATus:QUEStionable:EXTended Register

The STATUS:QUEStionable:EXTended register contains further status information not covered by the other status registers of the R&S FSWP. A separate EXTended register exists for each active channel.

You can read out the register with STATus:QUEStionable:EXTended:CONDition? or STATus:QUEStionable:EXTended[:EVENt]?

Table 14-12: Meaning of the bits used in the STATus:QUEStionable:EXTended register

Bit No.	Meaning
0	not used
1	INFO
	This bit is set if a status message is available for the application.
	Which type of message occurred is indicated in the STATus:QUEStionable:EXTended:INFO Register.
2 to 14	Unused
15	This bit is always 0.

#### STATus:QUEStionable:EXTended:INFO Register

The STATUS: QUEStionable: EXTended: INFO register contains information on the type of messages that occur during operation of the R&S FSWP. A separate INFO register exists for each active channel.

You can read out the register with STATUS:QUEStionable:EXTended:INFO: CONDition? or STATUS:QUEStionable:EXTended:INFO[:EVENt]?. You can query all messages that occur for a specific channel using the command SYSTem: ERRor:EXTended? on page 603.

Table 14-13: Meaning of the bits used in the STATus:QUEStionable:EXTended:INFO register

Bit No.	Meaning
0	MESSage This bit is set if event or state has occurred that may lead to an error during further operation.
1	INFO This bit is set if an informational status message is available for the application.
2	WARNing This bit is set if an irregular situation occurs during measurement, e.g. the settings no longer match the displayed results, or the connection to an external device was interrupted temporarily.

Bit No.	Meaning
3	ERRor
	This bit is set if an error occurs during a measurement, e.g. due to missing data or wrong set- tings, so that the measurement cannot be completed correctly.
4	FATal
	This bit is set if a serious error occurs in the application and regular operation is no longer possible.
5 to 14	Unused
15	This bit is always 0.

# STATus:QUEStionable:FREQuency Register

The STATus:QUEStionable:FREQuency register contains information about the condition of the local oscillator and the reference frequency. A separate frequency register exists for each active channel.

You can read out the register with STATus:QUEStionable:FREQuency: CONDition? or STATus:QUEStionable:FREQuency[:EVENt]?.

Bit No.	Meaning
0	OVEN COLD
	This bit is set if the reference oscillator has not yet attained its operating temperature. "OCXO" is displayed.
1	LO UNLocked
	This bit is set if the local oscillator no longer locks. "LOUNL" is displayed.
2 to 7	Not used
8	EXTernalREFerence
	This bit is set if you have selected an external reference oscillator but did not connect a useable external reference source.
	In that case the synthesizer can not lock. The frequency in all probability is not accurate.
9 to 14	Not used
15	This bit is always 0.

# STATus:QUEStionable:LIMit Register

The STATus:QUEStionable:LIMit register contains information about the results of a limit check when you are working with limit lines.

A separate LIMit register exists for each active channel and for each window.

Bit No.	Meaning
0	LIMit 1 FAIL
	This bit is set if limit line 1 is violated.
1	LIMit 2 FAIL
	This bit is set if limit line 2 is violated.
2	LIMit 3 FAIL
	This bit is set if limit line 3 is violated.
3	LIMit 4 FAIL
	This bit is set if limit line 4 is violated.
4	LIMit 5 FAIL
	This bit is set if limit line 5 is violated.
5	LIMit 6 FAIL
	This bit is set if limit line 6 is violated.
6	LIMit 7 FAIL
	This bit is set if limit line 7 is violated.
7	LIMit 8 FAIL
	This bit is set if limit line 8 is violated.
8 to 14	Unused
15	This bit is always 0.

Table 14-15: Meaning of the bits used in the STATus:QUEStionable:LIMit register

## STATus:QUEStionable:LMARgin Register

This register contains information about the observance of limit margins.

A separate LMARgin register exists for each active channel and for each window.

```
It can be read using the commands
```

```
STATus:QUEStionable:LMARgin:CONDition? and
STATus:QUEStionable:LMARgin[:EVENt]?.
```

Table 14-16: Meaning of the bits used in the STATus:QUEStionable:LMARgin register

Bit No.	Meaning
0	LMARgin 1 FAIL
	This bit is set if limit margin 1 is violated.
1	LMARgin 2 FAIL
	This bit is set if limit margin 2 is violated.
2	LMARgin 3 FAIL
	This bit is set if limit margin 3 is violated.
3	LMARgin 4 FAIL
	This bit is set if limit margin 4 is violated.
4	LMARgin 5 FAIL
	This bit is set if limit margin 5 is violated.

Bit No.	Meaning
5	LMARgin 6 FAIL This bit is set if limit margin 6 is violated.
6	LMARgin 7 FAIL This bit is set if limit margin 7 is violated.
7	LMARgin 8 FAIL This bit is set if limit margin 8 is violated.
8 to 14	Not used
15	This bit is always 0.

# STATus:QUEStionable:POWer Register

The STATus:QUEStionable:POWer register contains information about possible overload situations that may occur during operation of the R&S FSWP. A separate power register exists for each active channel.

You can read out the register with STATus:QUEStionable:POWer:CONDition? or STATus:QUEStionable:POWer[:EVENt]?

Bit No.	Meaning
0	OVERload
	This bit is set if an overload occurs at the RF input, causing signal distortion but not yet causing damage to the device.
	The R&S FSWP displays the keyword "RF OVLD".
1	Unused
2	IF_OVerload
	This bit is set if an overload occurs in the IF path.
	The R&S FSWP displays the keyword "IF OVLD".
3	Input Overload
	This bit is set if the signal level at the RF input connector exceeds the maximum.
	The RF input is disconnected from the input mixer to protect the device. In order to re-enable measurement, decrease the level at the RF input connector and reconnect the RF input to the mixer input.
	The R&S FSWP displays the keyword "INPUT OVLD".
	(Available with the optional Spectrum application.)
4 to 13	Unused
14	DCPNoise
	This bit is set in case of an event at the DC power supply.
	For more information see "STATus:QUEStionable:POWer:DCPNoise" on page 344.
15	This bit is always 0.

# STATus:QUEStionable:POWer:DCPNoise

Available for the phase noise application.

The STATus:QUEStionable:POWer:DCPNoise register contains information about the state and condition of the DC power supply. A separate POWer:DCPNoise register exists for each active channel.

You can read out the register with STATus:QUEStionable:POWer:DCPNoise: CONDition? or STATus:QUEStionable:POWer:DCPNoise[:EVENt]?.

Table 14-18: Meaning of the bits used in the STATus:QUEStionable:POWer:DCPNoise register

Bit No.	Meaning	
0	V <sub>supply</sub> / I <sub>supply</sub> This bit is set if something is wrong with the voltage or current supply.	
1	V <sub>tune</sub> This bit is set if something is wrong with the tuning voltage supply.	
2	V <sub>aux</sub> This bit is set if something is wrong with the auxiliary voltage supply.	
3 to 14	Unused	
15	This bit is always 0.	

## STATus:QUEStionable:PNOise

Available for the phase noise application.

The STATus:QUEStionable:PNOise register contains information about the state and condition of the phase noise application. A separate PNOise register exists for each active channel.

You can read out the register with STATus:QUEStionable:PNOise:CONDition? on page 615 or STATus:QUEStionable:PNOise[:EVENt]? on page 616.

Table 14-19: Meaning of the bits used in the STATus:QUEStionable:PNOise register

Bit No.	Meaning	
0	Unused	
1	SIGNal not found This bit is set when no signal could be found during the signal search.	
2	PULSe not found This bit is set when no pulse could be found during the signal search of pulsed phase noise measurements.	
3 to 14	Unused	
15	This bit is always 0.	

## STATus:QUEStionable:TEMPerature Register

The STATus:QUEStionable:TEMPerature register contains information about possible temperature deviations that may occur during operation of the R&S FSWP. A separate temperature register exists for each active channel.

You can read out the register with STATus:QUEStionable:TEMPerature: CONDition? or STATus:QUEStionable:TEMPerature[:EVENt]?

Bit No.	Meaning	
0 This bit is set if the frontend temperature sensor deviates by a certain degree from the alignment temperature.		
	During warmup, this bit is always 1.	
	For details see "Temperature check" on page 276.	
1 to 14	Unused	
15	This bit is always 0.	

Table 14-20: Meaning of the bits used in the STATus:QUEStionable:TEMPerature register

#### STATus:QUEStionable:TIMe Register

Available for the Spectrum application.

The STATUS: QUEStionable: TIMe register contains information about possible time errors that may occur during operation of the R&S FSWP. A separate time register exists for each active channel.

Table 14-21: Meaning of the bits used in the STATus:QUEStionable:TIMe register

Bit No.	Meaning
0	not used
1	Sweep time too low This bit is set if the sweep time is too low.
2 to 14	Unused
15	This bit is always 0.

## 14.1.7.4 Application of the Status Reporting System

The purpose of the status reporting system is to monitor the status of one or several devices in a measuring system. To do this and react appropriately, the controller must receive and evaluate the information of all devices. The following standard methods are used:

- Service request (SRQ) initiated by the instrument
- Serial poll of all devices in the bus system, initiated by the controller in order to find out who sent a SRQ and why
- Parallel poll of all devices
- Query of a **specific instrument status** by means of commands
- Query of the error queue

## **Service Request**

Under certain circumstances, the instrument can send a service request (SRQ) to the controller. A service request is a request from an instrument for information, advice or treatment by the controller. Usually this service request initiates an interrupt at the controller, to which the control program can react appropriately. As evident from Figure 14-2, an SRQ is always initiated if one or several of bits 2, 3, 4, 5 or 7 of the status byte are set and enabled in the SRE. Each of these bits combines the information of a

further register, the error queue or the output buffer. The ENABLe parts of the status registers can be set such that arbitrary bits in an arbitrary status register initiate an SRQ. In order to make use of the possibilities of the service request effectively, all bits should be set to "1" in enable registers SRE and ESE.

The service request is the only possibility for the instrument to become active on its own. Each controller program should cause the instrument to initiate a service request if errors occur. The program should react appropriately to the service request.

## Use of the command \*OPC to generate an SRQ at the end of a sweep

- CALL InstrWrite (analyzer, "\*ESE 1") 'Set bit 0 in the ESE (Operation Complete)
- 2. CALL InstrWrite (analyzer, "\*SRE 32") 'Set bit 5 in the SRE (ESB)
- CALL InstrWrite(analyzer, "\*INIT;\*OPC") 'Generate an SRQ after operation complete

After its settings have been completed, the instrument generates an SRQ.

# Serial Poll

In a serial poll, just as with command \*STB, the status byte of an instrument is queried. However, the query is realized via interface messages and is thus clearly faster.

The serial poll method is defined in IEEE 488.1 and used to be the only standard possibility for different instruments to poll the status byte. The method also works for instruments which do not adhere to SCPI or IEEE 488.2.

The serial poll is mainly used to obtain a fast overview of the state of several instruments connected to the controller.

## **Parallel Poll**

In a parallel poll, up to eight instruments are simultaneously requested by the controller using a single command to transmit 1 bit of information each on the data lines, i.e., to set the data line allocated to each instrument to a logical "0" or "1".

In addition to the SRE register, which determines the conditions under which an SRQ is generated, there is a Parallel Poll Enable register (PPE) which is ANDed with the STB bit by bit, considering bit 6 as well. This register is ANDed with the STB bit by bit, considering bit 6 as well. The results are ORed, the result is possibly inverted and then sent as a response to the parallel poll of the controller. The result can also be queried without parallel poll using the command \*IST?.

The instrument first has to be set for the parallel poll using the command PPC. This command allocates a data line to the instrument and determines whether the response is to be inverted. The parallel poll itself is executed using PPE.

The parallel poll method is mainly used to find out quickly which one of the instruments connected to the controller has sent a service request. To this effect, SRE and PPE must be set to the same value.

## Query of an instrument status

Each part of any status register can be read using queries. There are two types of commands:


- The common commands \*ESR?, \*IDN?, \*IST?, \*STB? query the higher-level registers.
- The commands of the STATus system query the SCPI registers (STATus:QUEStionable...)

The returned value is always a decimal number that represents the bit pattern of the queried register. This number is evaluated by the controller program.

Queries are usually used after an SRQ in order to obtain more detailed information on the cause of the SRQ.

## Decimal representation of a bit pattern

The STB and ESR registers contain 8 bits, the SCPI registers 16 bits. The contents of a status register are specified and transferred as a single decimal number. To make this possible, each bit is assigned a weighted value. The decimal number is calculated as the sum of the weighted values of all bits in the register that are set to 1.



#### Example:

The decimal value 40 = 32 + 8 indicates that bits no. 3 and 5 in the status register (e.g. the QUEStionable status summary bit and the ESB bit in the STatus Byte ) are set.

### **Error Queue**

Each error state in the instrument leads to an entry in the error queue. The entries of the error queue are detailed plain text error messages that can be looked up in the Error Log or queried via remote control using SYSTem:ERRor[:NEXT]? Each call of SYSTem:ERRor[:NEXT]? provides one entry from the error queue. If no error messages are stored there any more, the instrument responds with 0, "No error".

The error queue should be queried after every SRQ in the controller program as the entries describe the cause of an error more precisely than the status registers. Especially in the test phase of a controller program the error queue should be queried regularly since faulty commands from the controller to the instrument are recorded there as well.

## 14.1.7.5 Reset Values of the Status Reporting System

The following table contains the different commands and events causing the status reporting system to be reset. None of the commands, except \*RST and

SYSTem: PRESet, influence the functional instrument settings. In particular, DCL does not change the instrument settings.

Event	Switching on supply voltage Power-On-Status- Clear		DCL, SDC (Device Clear,	*RST or SYS- Tem:PRE Set	STA- Tus:PRE- Set	*CLS
Effect	0	1	Selected Device Clear)			
Clear STB, ESR	-	yes	-	-	-	yes
Clear SRE, ESE	-	yes	-	-	-	-
Clear PPE	-	yes	-	-	-	-
Clear EVENt parts of the registers	-	yes	-	-	-	yes
Clear ENABle parts of all OPERation and QUEStionable registers;	-	yes	-	-	yes	-
Fill ENABle parts of all other registers with "1".						
Fill PTRansition parts with "1";	-	yes	-	-	yes	-
Clear NTRansition parts						
Clear error queue	yes	yes	-	-	-	yes
Clear output buffer	yes	yes	yes	1)	1)	1)
Clear command processing and input buffer	yes	yes	yes	-	-	-
1) The first command in a comm	and line that	immediatel	· follows a <f< td=""><td></td><td>IESSAGE TE</td><td>ERMINA-</td></f<>		IESSAGE TE	ERMINA-

Table 14-22: Resetting the status reporting system

 The first command in a command line that immediately follows a <PROGRAM MESSAGE TERMIN, TOR> clears the output buffer.

# 14.1.8 General Programming Recommendations

## Initial instrument status before changing settings

Manual operation is designed for maximum possible operating convenience. In contrast, the priority of remote control is the "predictability" of the instrument status. Thus, when a command attempts to define incompatible settings, the command is ignored and the instrument status remains unchanged, i.e. other settings are not automatically adapted. Therefore, control programs should always define an initial instrument status (e.g. using the \*RST command) and then implement the required settings.

## **Command sequence**

As a general rule, send commands and queries in different program messages. Otherwise, the result of the query may vary depending on which operation is performed first (see also Chapter 14.1.6.1, "Preventing Overlapping Execution", on page 331).

## **Reacting to malfunctions**

The service request is the only possibility for the instrument to become active on its own. Each controller program should instruct the instrument to initiate a service request in case of malfunction. The program should react appropriately to the service request.

#### **Error queues**

The error queue should be queried after every service request in the controller program as the entries describe the cause of an error more precisely than the status registers. Especially in the test phase of a controller program the error queue should be queried regularly since faulty commands from the controller to the instrument are recorded there as well.

# 14.2 The IECWIN Tool

The R&S FSWP is delivered with *IECWIN* installed, an auxiliary tool provided free of charge by R&S. IECWIN is a program to send SCPI commands to a measuring instrument either interactively or from a command script.



The R&S IECWIN32 tool is provided free of charge. The functionality may change in a future version without notice.

IECWIN offers the following features:

- Connection to instrument via several interfaces/protocols (GPIB, VISA, named pipe (if IECWIN is run on the instrument itself), RSIB)
- Interactive command entry
- Browsing available commands on the instrument
- Error checking following every command
- Execution of command scripts
- Storing binary data to a file
- Reading binary data from a file
- Generation of a log file

For command scripts, IECWIN offers the following features:

- Synchronization with the instrument on every command
- Checking expected result for query commands (as string or numeric value)
- Checking for expected errors codes
- Optional pause on error
- Nested command scripts
- Single step mode
- Conditional execution, based on the \*IDN and \*OPT strings

Ç

You can use the IECWIN to try out the programming examples provided in the R&S FSWP User Manuals.

## Starting IECWIN

IECWIN is available from the Windows "Start" menu on the R&S FSWP, or by executing the following file:

C:\Program Files (x86)\Rohde-Schwarz\FSWP\<version>\iecwin32.exe

You can also copy the program to any Windows PC or laptop. Simply copy the iecwin32.exe, iecwin.chm and rsib32.dll files from the location above to the same folder on the target computer.

When the tool is started, a "Connection settings" dialog box is displayed. Define the connection from the computer the IECWIN tool is installed on to the R&S FSWP you want to control. If you are using the tool directly on the R&S FSWP, you can use an NT Pipe (COM Parser) connection, which requires no further configuration. For help on setting up other connection types, check the tool's online help (by clicking the "Help" button in the dialog box).



The IECWIN offers an online help with extensive information on how to work with the tool.

# 14.3 Network and Remote Control Settings

Access: [SETUP] > "Network + Remote"



#### Network settings in secure user mode

Be sure to store all network settings before SecureUser Mode is enabled; see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

If the currently stored network settings are not suitable, you must correct them each time you switch on the R&S FSWP in secure user mode, as the settings are not stored permanently in this case.

The remote commands required to define these settings are described in Chapter 15.9.5, "Configuring Network and Remote Control", on page 595.

Step-by-step instructions are provided in Chapter 14.4, "How to Set Up a Network and Remote Control", on page 362.

•	General Network Settings	. 352
	GPIB Settings	
	Compatibility Settings	
	LAN Settings	
	Remote Errors	
	Returning to Manual Mode ("Local")	

# 14.3.1 General Network Settings

Access: [SETUP] > "Network + Remote" > "Network" tab

The R&S FSWP can be operated in a local area network (LAN), for example to control the instrument from a remote PC or use a network printer.



Network settings can only be edited in the firmware if a LAN cable is connected to the R&S FSWP.

# NOTICE

## **Risk of network problems**

All parameters can be edited here; however, beware that changing the computer name has major effects in a network.

For details, see Chapter 14.4, "How to Set Up a Network and Remote Control", on page 362.




## Network settings in secure user mode

Be sure to store all network settings before SecureUser Mode is enabled; see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

If the currently stored network settings are not suitable, you must correct them each time you switch on the R&S FSWP in secure user mode, as the settings are not stored permanently in this case.

#### Network and Remote Control Settings



Computer Name	353
IP Address	
Subnet Mask	354
DHCP	354
Network Configuration	
5	

## **Computer Name**

Each instrument is delivered with an assigned computer name, but this name can be changed. The naming conventions of Windows apply. If too many characters and/or numbers are entered, an error message is displayed in the status line.

The default instrument name is a non-case-sensitive string with the following syntax:

<Type><variant>-<serial\_number>

```
For example FSWP26-123456
```

The serial number can be found on the rear panel of the instrument. It is the third part of the device ID printed on the bar code sticker:



## **IP Address**

Defines the IP address. The TCP/IP protocol is preinstalled with the IP address 10.0.0.10. If the DHCP server is available ("DHCP On"), the setting is read-only.

The IP address consists of four number blocks separated by dots. Each block contains 3 numbers in maximum (e.g. 100.100.100.100), but also one or two numbers are allowed in a block (as an example see the preinstalled address).

#### Subnet Mask

Defines the subnet mask. The TCP/IP protocol is preinstalled with the subnet mask 255.255.255.0. If the DHCP server is available ("DHCP On"), this setting is read-only.

The subnet mask consists of four number blocks separated by dots. Each block contains 3 numbers in maximum (e.g. 100.100.100.100), but also one or two numbers are allowed in a block (as an example see the preinstalled address).

#### DHCP

Switches between DHCP server available (On) or not available (Off). If a DHCP server is available in the network, the IP address and subnet mask of the instrument are obtained automatically from the DHCP server.

## **Network Configuration**

Opens the standard Windows "Network Configuration" dialog box for further configuration.

# 14.3.2 GPIB Settings

Access: [SETUP] > "Network + Remote" > "GPIB" tab

Alternatively to connecting the R&S FSWP to a LAN, the GPIB interface can be used to connect a remote PC. For details see Chapter 14.1.1.2, "GPIB Interface (IEC 625/ IEEE 418 Bus Interface)", on page 317).

#### Network and Remote Control Settings

Network GPIB Compatibility LXI Remote Errors				
GPIB Address	18			
Identification String	26,1322.8003K26/100005,1.90-19.8.4.0 Beta			
	Reset to Fac	ctory String		
Remote Display Update	On	off		
GPIB Terminator	LFEOI	EOI		
*IDN Format	New	Legacy		
I/O Logging	On	off		
Display Remote Errors	On	Off		
Set Hardware Immediately	On	Off		

GPIB Address	355
Identification String	355
Reset to Factory String	355
Remote Display Update	356
GPIB Terminator	356
*IDN Format	356
I/O Logging	356
Display Remote Errors	
Set Hardware Immediately	

## **GPIB Address**

Defines the GPIB address. Values from 0 to 30 are allowed. The default address is 20. Remote command:

SYSTem:COMMunicate:GPIB[:SELF]:ADDRess on page 596

## **Identification String**

Defines the identification string for the R&S FSWP which is provided as a response to the \*IDN? query. Maximum 36 characters are allowed.

Remote command: SYSTem:IDENtify[:STRing] on page 598

## **Reset to Factory String**

Restores the default identification string. Each R&S FSWP has a unique ID according to the following syntax:

Rohde&Schwarz,FSWP,<Unique number>

Remote command:

SYSTem: IDENtify: FACTory on page 598

#### **Remote Display Update**

Defines whether the display of the R&S FSWP is updated when changing from manual operation to remote control.

Turning off the display update function improves performance during remote control.

**Note:** Usually, this function remains available on the display during remote operation. However, it can be disabled remotely. In this case, the display is not updated during remote operation, and cannot be turned on again locally until local operation is resumed.

Remote command: SYSTem:DISPlay:UPDate on page 597

#### **GPIB** Terminator

Changes the GPIB receive terminator.

"LFEOI" According to the standard, the terminator in ASCII is <LF> and/or <EOI>.

"EOI" For binary data transfers (e.g. trace data) from the control computer to the instrument, the binary code used for <LF> might be included in the binary data block, and therefore should not be interpreted as a terminator in this particular case. This can be avoided by using only the receive terminator EOI.

Remote command:

SYSTem:COMMunicate:GPIB[:SELF]:RTERminator on page 596

## \*IDN Format

Defines the response format to the remote command \*IDN? (see \*IDN? on page 386). This function is intended for re-use of existing control programs together with the R&S FSWP.

"Leg" Legacy format, as in the R&S FSP/FSU/FSQ family.

"New" R&S FSWP format.

Remote command:

SYSTem: FORMat: IDENt on page 604

### I/O Logging

Activates or deactivates the SCPI error log function. All remote control commands received by the R&S FSWP are recorded in a log file. The files are named according to the following syntax:

C:\R S\INSTR\ScpiLogging\ScpiLog.<no.>

where <no.> is a sequential number

A new log file is started each time logging was stopped and is restarted.

Logging the commands may be extremely useful for debug purposes, e.g. in order to find misspelled keywords in control programs.

Remote command:

SYSTem: CLOGging on page 580

#### **Display Remote Errors**

Activates and deactivates the display of errors that occur during remote operation of the R&S FSWP. If activated, the R&S FSWP displays a message box at the bottom of the screen that contains the type of error and the command that caused the error.

-141: Invalid character data INST:SEL WOOHOO



The error message remains in place when you switch to "Local" mode. To close the message box, select the  $\bowtie$  "Close" icon.

Only the most recent error is displayed in remote mode. However, in local mode, all errors that occurred during remote operation are listed in a separate tab of the "Network + Remote" dialog box (see Chapter 14.3.5, "Remote Errors", on page 360).

Remote command:

SYSTem:ERRor:DISPlay on page 597 SYSTem:ERRor:CLEar:REMote on page 597

#### Set Hardware Immediately

Determines when the remote commands that change hardware settings on the R&S FSWP are executed.

If enabled (default), remote commands are always executed immediately when they are received by the instrument.

If disabled, remote commands that cause changes to the hardware are only executed when an appropriate command is executed explicitly.

Regardless of this setting, the firmware automatically sets the hardware when a sweep is started.

Postponing hardware changes is useful, for example, when switching measurement channels. When you switch channels, the settings from the previous channel are used by default. However, if you have to change the frequency and level values for the new channel measurement, the default settings cause unnecessary hardware settling times.

This setting is not changed by the preset function.

## Remote command:

SYSTem:SHIMmediate:STATe on page 599 SYSTem:SHIMmediate ONCE on page 600

# 14.3.3 Compatibility Settings

The R&S FSWP supports different system languages that are compatible to other products.

Note that aside from the "Language" feature (and for PSA compatibility, the "Wideband" feature), all other functions in this dialog are currently not supported.

Language	
Wideband	

#### Language

Defines the system language used to control the instrument.

The following languages are supported.

- SCPI
- 5052

For a list of supported commands, see Chapter 15.9.8, "Reference: Command Set of 5052 Emulation", on page 608.

 PSA For a list of supported commands, see Chapter 15.9.9, "Reference: Command Set of Emulated PSA Models", on page 610.

The 5052 language is only available in the Phase Noise application. If you select the 5052 mode in an application other than the Phase Noise application, the R&S FSWP automatically closes all applications and opens one channel with the Phase Noise application.

The PSA language is only available for the Spectrum application. If you select the PSA mode in an application other than the Spectrum application, the R&S FSWP automatically closes all applications and opens one channel with the Spectrum application.

Remote command:

SYSTem:LANGuage on page 598

#### Wideband

This setting defines which option is returned when the **\*OPT?** query is executed, depending on the state of the wideband option.

It is only available for PSA89600 emulation.

"Off"	No wideband is used.
	The option is indicated as "B7J".
"40 MHz"	The 40 MHz wideband is used.
	The option is indicated as "B7J, 140".
"80 MHz"	The 80 MHz wideband is used.
	The option is indicated as "B7J, 122".

Remote command:

SYSTem: PSA: WIDeband on page 599

# 14.3.4 LAN Settings

Access: [SETUP] > "Network + Remote" > "LAN" tab

In a LAN network, the R&S FSWP can be accessed via any web browser (e.g. the Microsoft Internet Explorer) to perform the following tasks:

Modifying network configurations

- Modifying device configurations
- Monitoring connections from the device to other devices

The "LAN" tab of the "Network + Remote" dialog box provides basic LAN configuration functions and information for the R&S FSWP.

Alternatively, you can change the LAN settings using the web browser interface.

For details see Chapter 14.4.1.4, "How to Configure the LAN Using the Web Browser Interface", on page 366.

Only user accounts with administrator rights are able to use LAN configuration and web browser functionality.

Network GPIB Compatibility	LAN Remote Errors
Current LAN Configuration:	
Computer Name	MU747837
MAC Address	8C:EC:4B:B5:54:71
IP Address	10.111.0.216
LAN Password	LxiWebIfc
	LAN Reset

Current LAN Configuration	
LAN Password	
LAN Reset	

# **Current LAN Configuration**

Displays the current LAN information from the R&S FSWP (read-only).

"Computer name"	Name of the R&S FSWP as defined in the operating system (see also "Computer Name" on page 353)
"MAC address"	Media Access Control address (MAC address), a unique identifier for the network card in the R&S FSWP
"IP address"	IP address of the R&S FSWP as defined in the operating system (see also "IP Address" on page 354).

## LAN Password

Password for LAN configuration. The default password is *LxiWeblfc*.

Remote command:

SYSTem:LXI:PASSword on page 599

#### LAN Reset

Resets the "LAN" configuration to its default settings (LCI function).

Parameter	Value
TCP/IP Mode	DHCP + Auto IP Address
Dynamic DNS	Enabled
ICMP Ping	Enabled
Password for "LAN" configuration	LxiWeblfc

The LAN settings are configured in the "Network" tab of the "Network + Remote" dialog box or using the instrument's "LAN" web browser interface.

Remote command:


SYSTem:LXI:LANReset on page 599

# 14.3.5 Remote Errors

Access: [SETUP] > "Network + Remote" > "Remote Errors " tab

The error messages generated by the R&S FSWP during remote operation are displayed here.

The messages are displayed in the order of their occurrence; the most recent messages are placed at the top of the list.





The most recent error message during remote operation can be displayed on the screen, see "Display Remote Errors" on page 357.

If the number of error messages exceeds the capacity of the error buffer, the oldest error message is removed before the newest one is inserted. To clear the message buffer use the "Clear Error List" button. It is automatically cleared when the R&S FSWP is shut down.

The following information is available:

No	Device-specific error code
Error	Brief description of the error
Date/Time	Time the message occurred

#### **Remote command:**

SYSTem: ERRor: LIST? on page 603

#### **Clear Error List**

Deletes the error message buffer for remote operation.

**Note:** The remote error list is automatically cleared when the R&S FSWP is shut down. Remote command:

SYSTem:ERRor:CLEar:REMote on page 597

# 14.3.6 Returning to Manual Mode ("Local")

When switched on, the instrument is always in the manual measurement mode and can be operated via the front panel. As soon as the instrument receives a remote command, it is switched to the remote control mode.

In remote control mode, all keys of the instrument except the [PRESET] key are disabled. The "LOCAL" softkey and the Remote Display Update softkey are displayed.

#### Local

The instrument switches from remote to manual operation, but only if the local lockout function has not been activated in the remote control mode (see "GPIB Interface Messages" on page 317).

Furthermore, when you return to manual operation, the following happens:

- All front panel keys are enabled.
- The main softkey menu of the current mode is displayed.
- The measurement diagrams, traces and display fields are displayed again.
- If, at the time of pressing the "LOCAL" softkey, the synchronization mechanism via \*OPC, \*OPC? or \*WAI is active, the currently running measurement procedure is aborted and synchronization is achieved by setting the corresponding bits in the registers of the status reporting system.
- Bit 6 (User Request) of the Event Status Register is set. If the status reporting system is configured accordingly, this bit immediately causes the generation of a service request (SRQ) to inform the control software that the user wishes to return to front panel control. For example, this can be used to interrupt the control program and to correct instrument settings manually. This bit is set each time the "LOCAL" softkey is pressed.

**Note:** Before you switch back to manual operation, all remote command processing must be completed. Otherwise, the instrument will switch back to remote control immediately.

If you select the "Local" softkey while a self-alignment or a self-test is still running (which was started remotely), the instrument only returns to the manual operation state when the alignment or test is completed.

Remote command: SYSTem:KLOCk on page 598

# 14.4 How to Set Up a Network and Remote Control

# NOTICE

#### **Risk of network failure**

Consult your network administrator before performing the following tasks:

- Connecting the instrument to the network
- Configuring the network
- Changing IP addresses
- Exchanging hardware

Errors can affect the entire network.

#### **Remote operation**

You can operate the instrument remotely from a connected computer using SCPI commands (see Chapter 14.1.2, "SCPI (Standard Commands for Programmable Instruments)", on page 320). Before you send remote commands you must configure the instrument in a LAN network or connect it to a PC via the GPIB interface as described in Chapter 14.4.1, "How to Configure a Network", on page 363.

#### Remote Desktop

In production test and measurement, a common requirement is central monitoring of the T&M instruments for remote maintenance and remote diagnostics. Equipped with the Remote Desktop software of Windows, the R&S FSWP ideally meets requirements for use in production. The computer that is used for remote operation is called "control-ler" here.

The following tasks can be performed using Remote Desktop:

- Access to the control functions via a virtual front panel (soft front panel)
- Printout of measurement results directly from the controller
- Storage of measured data on the controller's hard disk

This documentation provides basic instructions on setting up the Remote Desktop for the R&S FSWP. For details refer to the Microsoft Windows operating system documentation.

# 14.4.1 How to Configure a Network

A precondition for operating or monitoring the instrument remotely is that it is connected to a LAN network or a PC connected to the GPIB interface. Setup is described here.

# (j

#### Windows Firewall Settings

A firewall protects an instrument by preventing unauthorized users from gaining access to it through a network. Rohde & Schwarz highly recommends the use of the firewall on your instrument. R&S instruments are shipped with the Windows firewall enabled and preconfigured in such a way that all ports and connections for remote control are enabled. For more details on firewall configuration see the Microsoft Windows help system and the R&S White Paper (available from the Rohde & Schwarz website):

1EF96: Malware Protection Windows 10

#### 14.4.1.1 How to Connect the Instrument to the Network

There are two methods to establish a LAN connection to the instrument:

- A non-dedicated network (Ethernet) connection from the instrument to an existing network made with an ordinary RJ-45 network cable. The instrument is assigned an IP address and can coexist with a computer and with other hosts on the same network.
- A dedicated network connection (Point-to-point connection) between the instrument and a single computer made with a (crossover) RJ-45 network cable. The computer must be equipped with a network adapter and is directly connected to the instrument. The use of hubs, switches, or gateways is not required, however, data transfer is still performed using the TCP/IP protocol. An IP address has to be assigned to the instrument and the computer, see Chapter 14.4.1.2, "How to Assign the IP Address", on page 364.

**Note:** As the R&S FSWP uses a 1 GBit LAN, a crossover cable is not necessary (due to Auto-MDI(X) functionality).

To establish a non-dedicated network connection, connect a commercial RJ-45 cable to one of the LAN ports.
 To establish a dedicated connection, connect a (crossover) RJ-45 cable between the instrument and a single PC.

If the instrument is connected to the LAN, Windows automatically detects the network connection and activates the required drivers.

The network card can be operated with a 1 GBit Ethernet IEEE 802.3u interface.

#### 14.4.1.2 How to Assign the IP Address

Depending on the network capacities, the TCP/IP address information for the instrument can be obtained in different ways.

- If the network supports dynamic TCP/IP configuration using the Dynamic Host Configuration Protocol (DHCP), all address information can be assigned automatically.
- If the network does not support DHCP, or if the instrument is set to use alternate TCP/IP configuration, the addresses must be set manually.

By default, the instrument is configured to use dynamic TCP/IP configuration and obtain all address information automatically. This means that it is safe to establish a physical connection to the LAN without any previous instrument configuration.

When a DHCP server is used, a new IP address may be assigned each time the PC is restarted. This address must first be determined on the PC itself. Thus, when using a DHCP server, it is recommended that you use the permanent computer name, which determines the address via the DNS server (see "Using a DNS server to determine the IP address" on page 365).

# NOTICE

#### **Risk of network errors**

Connection errors can affect the entire network. If your network does not support DHCP, or if you choose to disable dynamic TCP/IP configuration, you must assign valid address information before connecting the instrument to the LAN. Contact your network administrator to obtain a valid IP address.

#### Assigning the IP address on the instrument

- 1. Press the [SETUP] key.
- 2. Press the "Network + Remote" softkey.
- 3. Select the "Network" tab.
- 4. In the "Network + Remote" dialog, toggle the "DHCP On/Off" setting to the required mode.

If DHCP is "Off", you must enter the IP address manually, as described in the following steps.

**Note:** When DHCP is changed from "On" to "Off", the previously set IP address and subnet mask are retrieved.

If DHCP is "On", the IP address of the DHCP server is obtained automatically. The configuration is saved, and you are prompted to restart the instrument. You can skip the remaining steps.

**Note:** When a DHCP server is used, a new IP address may be assigned each time the instrument is restarted. This address must first be determined on the instrument itself. Thus, when using a DHCP server, it is recommended that you use the permanent computer name, which determines the address via the DNS server

(See "Using a DNS server to determine the IP address" on page 365 and Chapter 14.4.1.3, "How to Change the Instrument Name", on page 366).

- Enter the "IP Address", for example 192.0.2.0. The IP address consists of four number blocks separated by dots. Every block contains a maximum of 3 numbers.
- Enter the "Subnet Mask", for example 255.255.255.0. The subnet mask consists of four number blocks separated by dots. Every block contains a maximum of 3 numbers.
- 7. Close the dialog box.


If you have entered an invalid IP address or subnet mask, the message "out of range" is displayed in the status line. If the settings are correct, the configuration is saved, and you are prompted to restart the instrument.

8. Confirm the displayed message ("Yes" button) to restart the instrument.

#### Using a DNS server to determine the IP address

If a DNS server is configured on the R&S FSWP, the server can determine the current IP address for the connection using the permanent computer name.

- Obtain the name of your DNS domain and the IP addresses of the DNS and WINS servers on your network (see Chapter 14.4.1.3, "How to Change the Instrument Name", on page 366).
- 2. Press the [Setup] key and then the "Network + Remote" softkey.
- 3. In the "Network" tab, select the "Open Dialog 'Network Connections" button.
- 4. Double-tap the "Local Area Network" entry.
- In the "Local Area Connection Status" dialog box, select the "Properties" button. The items used by the LAN connection are displayed.
- 6. Tap the entry named "Internet Protocol Version 4 (TCP/IPv4)" to highlight it.



- 7. Select the "Properties" button.
- On the "General" tab, select "Use the following DNS server addresses" and enter your own DNS addresses.

For more information refer to the Microsoft Windows operating system Help.

#### 14.4.1.3 How to Change the Instrument Name

In a LAN that uses a DNS server (Domain Name System server), each PC or instrument connected in the LAN can be accessed via an unambiguous computer name instead of the IP address. The DNS server translates the host name to the IP address. This is especially useful when a DHCP server is used, as a new IP address may be assigned each time the instrument is restarted.

Each instrument is delivered with an assigned computer name, but this name can be changed.

#### To change the instrument's computer name

- 1. Press the [Setup] key and then the "Network + Remote" softkey. The current "Computer Name" is displayed in the "Network" tab.
- 2. Enter the new computer name and close the dialog box.

The configuration is saved, and you are prompted to restart the instrument.

3. Confirm the displayed message ("Yes" button) to restart the instrument.

#### 14.4.1.4 How to Configure the LAN Using the Web Browser Interface

The instrument's "LAN" web browser interface works correctly with all W3C compliant browsers.

In the web browser, open the http://<instrument-hostname> or http:// <instrument-ip-address> page, e.g. http://10.113.10.203. The default password to change "LAN" configurations is LxiWeblfc.

The "Instrument Home Page" (welcome page) opens.

<b>ROHDE&amp;SCHWARZ</b>	LXI I		
LXI	Instrument Properties		
Home			
Lan Configuration			
Status			
Utilities	Instrument Model	FSWP-26 Phase Noise Analyzer	
	Manufacturer	Rohde & Schwarz GmbH & Co. KG	
Instrument Control	Serial Number		
Web Control	Description	R&S FSWP-90	
File Download	LXI Version	1.4 LXI Core 2011	
File Upload	LXI Extended Features	LXI HISLIP	
File Opload	DNS Host Name(s) MAC Address	FSWP-	
License Manager	IP Address		
	Firmware Revision	1 10	
Manage Licenses	Current Time	Tuesday, 2015/07/14, 13:16:22	
Help	Current Time source	Operating System	
неф		TCPIP:: ::inst0::INSTR	
Glossary	VISA resource string	TCPIP:: hislip0::INSTR	
www.rohde-schwarz.com	Device Indicator	INACTIVE (press to toggle)	
	Status		
	No error		© 2015 ROHDE&SCHWARZ, All rights reserved.
			o zo to non bitto of manz. All igns reserved.

The instrument home page displays device information, including the VISA resource string, in read-only format.



Press the "Device Indicator" button on the "Instrument Home Page" to activate or deactivate the "LAN" status icon on the status bar of the R&S FSWP. A green "LAN" status symbol indicates that a LAN connection has been established; a red symbol indicates an error, for example, that no LAN cable is connected. When a device is connecting to the instrument, the "LAN" icon blinks. The "Device Indicator" setting is not password-protected.

The most important control elements in the navigation pane of the browser interface are the following:

- "LAN Configuration" opens the menu with configuration pages.
- "Status" displays information about the "LAN" status of the instrument.

## LAN Configuration

The LAN configuration consists of three parts:

- "IP configuration" provides all mandatory LAN parameters.
- "Advanced LAN Configuration" provides further LAN settings.
- "Ping Client" provides the ping utility to verify the connection between the instrument and other devices.

## **IP** Configuration

The "LAN Configuration > IP configuration" web page displays all mandatory LAN parameters and allows their modification.

For the manual configuration mode, the static IP address, subnet mask, and default gateway are used to configure the LAN. The automatic configuration mode uses DHCP server or Dynamic Link Local Addressing (Automatic IP) to obtain the instrument IP address.



Changing the LAN configuration is password-protected. The default password is *Lxi-Weblfc* (notice upper and lower case characters).

You can change the LAN password in the "Network + Remote" dialog box, see Chapter 14.3.4, "LAN Settings", on page 358.

#### Advanced LAN Configuration

The "LAN Configuration > Advanced LAN Configuration" parameters are used as follows:

- The "Negotiation" configuration field provides different Ethernet speed and duplex mode settings. In general, the "Auto Detect" mode is sufficient.
- "ICMP Ping" must be enabled to use the ping utility.
- "VXI-11" is the protocol that is used to detect the instrument in the LAN.
- mDNS and DNS-SD are two additional protocols: Multicast DNS and DNS Service Discovery. They are used for device communication in zero configuration networks working without DNS and DHCP

#### **Ping Client**

Ping is a utility that verifies the connection between the instrument and another device. The ping command uses the ICMP echo request and echo reply packets to determine whether the LAN connection is functional. Ping is useful for diagnosing IP network or router failures. The ping utility is not password-protected.

To initiate a ping between the instrument and a second connected device:

- 1. Enable "ICMP Ping" on the "Advanced LAN Configuration" page (enabled after an LCI).
- Enter the IP address of the second device without the ping command and without any further parameters into the "Destination Address" field (e.g. 10.113.10.203).
- 3. Select "Submit".

#### 14.4.1.5 How to Change the GPIB Instrument Address

In order to operate the instrument via remote control, it must be addressed using the GPIB address. The remote control address is factory-set to 20, but it can be changed if

it does not fit in the network environment. For remote control, addresses 0 through 30 are allowed. The GPIB address is maintained after a reset of the instrument settings.

#### Setting the GPIB address

- 1. On the R&S FSWP, press the [SETUP] key.
- 2. Press the "Network + Remote" softkey.
- 3. In the "Network + Remote" dialog box, select the "GPIB" tab.
- 4. In the "GPIB Address" field, enter a value between 0 and 30.

#### Remote command:

SYST:COMM:GPIB:ADDR 18

#### **14.4.2** How to Operate the Instrument Without a Network

To operate the instrument without a network connection either temporarily or permanently, no special measures are necessary. Microsoft Windows automatically detects the interruption of the network connection and does not set up the connection when the instrument is switched on.

If you are not prompted to enter the user name and password, proceed as described in Chapter 14.4.3.3, "How to Configure the Automatic Login Mechanism", on page 370.

# 14.4.3 How to Log on to the Network

Microsoft Windows requires that users identify themselves by entering a user name and password in a login window. You can set up two types of user accounts, either an administrator account with unrestricted access to the computer/domain or a standard user account with limited access. The instrument provides an auto-login function for the administrator account, i.e. login with unrestricted access is carried out automatically in the background. By default, the user name for the administrator account is "Instrument", and the user name for the standard user account is "NormalUser". In both cases the initial password is "894129". You can change the password in Microsoft Windows for any user at any time. Some administrative tasks require administrator rights (e.g. firmware updates or the configuration of a LAN network).

Refer to Chapter 13, "General Instrument Setup", on page 275 to find out which functions are affected.

At the same time you log on to the operating system, you are automatically logged on to the network. As a prerequisite, the user name and the password must be identical on the instrument and on the network.

#### 14.4.3.1 How to Create Users

After the software for the network has been installed, the instrument issues an error message the next time it is switched on because there is no user named "instrument"

(= default user ID for Windows auto-login) in the network. Thus, a matching user must be created in the R&S FSWP and in the network, the password must be adapted to the network password, and the auto-login mechanism must then be deactivated.

The network administrator is responsible for creating new users in the network.



Select the "Windows" icon in the toolbar to access the operating system.

- 2. Select "Start > Settings > Accounts > Other users".
- 3. Select "Add someone else to this PC".
- 4. In the "Microsoft account" dialog box, enter the new user name and password.
- 5. Select "OK".
- Select "Finish". The new user is created.

#### 14.4.3.2 How to Change the User Password

After the new user has been created on the instrument, the password must be adapted to the network password.



Select the "Windows" icon in the toolbar to access the operating system.

- 2. Press [Ctrl + Alt + Delete], then select "Change a password".
- 3. Enter the user account name.
- 4. Enter the old password.
- 5. Enter the new password in the upper text line and repeat it in the following line.
- Press [Enter]. The new password is now active.

#### 14.4.3.3 How to Configure the Automatic Login Mechanism

#### Adapting the auto-login function to a new password

If you change the password that is used during auto-login, this function no longer works. Adapt the settings for the auto-login function first.

1. Open the C:\R\_S\INSTR\USER\user\AUTOLOGIN.REG file in any text editor (e.g. Notepad).

- In the line "DefaultPassword"="894129", replace the default password (894129) by the new password for automatic login.
- 3. Save the changes to the file.
- 4. In the Windows "Start" menu, select "Run". The "Run" dialog box is displayed.
- 5. Enter the command C:\R S\INSTR\USER\user\AUTOLOGIN.REG.
- 6. Press the [ENTER] key to confirm.

The auto-login function is reactivated with the changed password. It will be applied the next time the instrument is switched on.

#### Switching users when using the auto-login function

Which user account is used is defined during login. If auto-login is active, the login window is not displayed. However, you can switch the user account to be used even when the auto-login function is active.



- 1. Select the "Windows" icon in the toolbar to access the operating system of the R&S FSWP (see also "To access the "Start" menu" on page 27).
- Press [CTRL] + [ALT] + [DEL], then select "Sign out".

The "Login" dialog box is displayed, in which you can enter the different user account name and password.

#### Deactivating the auto-login function

When shipped, the instrument is already configured to automatically log on the "instrument" user under Microsoft Windows. To deactivate the auto-login function, perform the following steps:

- In the "Start" menu, select "Run". The "Run" dialog box is displayed.
- 2. Enter the command C:\R\_S\INSTR\USER\user\NO\_AUTOLOGIN.REG.
- Press the [ENTER] key to confirm. The auto-login function is deactivated. The next time you switch on the instrument, you are prompted to enter your user name and password before the firmware is started.

#### Reactivating the auto-login function

To reactivate the auto-login function after manually deactivating it, perform the following steps:

- 1. In the "Start" menu, select "Run". The "Run" dialog box is displayed.
- 2. Enter the command C:\R S\INSTR\USER\user\AUTOLOGIN.REG.
- 3. Press the [ENTER] key to confirm.

The auto-login function is reactivated. It will be applied the next time the instrument is switched on.

# 14.4.4 How to Share Directories (only with Microsoft Networks)

Sharing directories makes data available for other users. This is only possible in Microsoft networks. Sharing is a property of a file or directory.

- 1. In the "Start" menu, select "Programs", "Accessories" and then select "Windows Explorer".
- 2. Select the desired folder with the right mouse button.
- In the context menu, select "Sharing with > Specific people". The dialog box for sharing a directory is displayed.
- 4. Select a user from the list or add a new name and select the "Add" button.
- 5. Select the "Share" button.
- Select "Done" to close the dialog box. The drive is shared and can be accessed by the selected users.

## 14.4.5 How to Control the R&S FSWP via the Web Browser Interface

Via the LAN web browser interface to the R&S FSWP, one or more users can control the instrument remotely from another PC without additional installation. Most instrument controls are available via the front panel simulation. File upload and download between the instrument and the remote PC is also available.

#### To access the R&S FSWP via the web browser interface

- 1. Start a web browser that supports html5 (W3C compliant).
- 2. Enter the IP address of the R&S FSWP in the browser's address bar.

The R&S FSWP's Welcome page is displayed.

3. In the navigation pane, select "Instrument Control > Web Control".

The instrument's display is shown in a new browser window, with a software front panel displayed beside or below it.

 Use the mouse cursor to access the functionality in the software front panel or in the display as you would directly on the instrument's front panel.

#### To exchange files with the R&S FSWP

You can download files, for example stored measurement data, from the R&S FSWP to the remote PC, or upload files, for example limit line definitions, from the PC to the R&S FSWP.

1. In the web browser, select the Welcome page window.

 In the navigation pane, select "Instrument Control" > "File Upload" or "File Download".

LAN	File Download	
Home		
Lan Configuration		
Utilities	Select a file and click the button 'Download File'	
Instrument Control	Log Files	
Web Control File Download File Upload		
License Manager		
Manage Licenses	Selected File: Licenselnfo.1312.8000K26-100005-xx.txt Download File	
Help		
Glossary	Status	
www.rohde-schwarz.com	No error	
	© 2020 ROHDE&S	CHWARZ. A

The most commonly used folders on the instrument are displayed, for example those that contain user data, as well as the top-most  $M_Y$  Computer folder, from which you can access all other folders on the instrument.

- To download a file from the R&S FSWP, select the file from the displayed folders and then select "Download File".
- 4. To upload a file to the R&S FSWP:
  - a) From the displayed folders in the web browser window, select the folder on the R&S FSWP to which you want to copy a file.
  - b) Under "File to Upload", select "Browse" to open a file selection dialog box and select the required file on the PC.
  - c) Select "Upload" to copy the file from the PC to the defined folder on the R&S FSWP.

# 14.4.6 How to Deactivate the Web Browser Interface

If you want to prevent other users in the LAN from accessing or operating the R&S FSWP via its LAN web browser interface, you must deactivate this function. Note that **after a firmware update** the function is **automatically active** again until you deactivate it manually.

# To deactivate the LAN web browser interface



Select the "Windows" icon in the toolbar to access the operating system.

- 2. In the "Start" menu, select "Control Panel".
- 3. Select "System and Security" > "Administrative Tools".
- 4. From the list on the right, select "Services".
- 5. From the list of local services, select "R&S TightVNC Server".

Services (L	Services (Local)						
	R&S TightVnc Server	Name R&S mDNS Service	Description Enables h	R&S TightVnc Ser	ver Properties (Lo	cal Computer)	
	Description: Service for	R&S Portmap	ONC/RPC	General Log On	Recovery Depende	ncies	
	TightVncServer	R&S Proxy Installatio R&S TightVnc Server	Service fo Service fo	Service name:	Underver		
		R&S WebServer	nginx Web	Display name:	R&S TightVnc Serv	er	
		R&S Websocket Prox Remote Access Auto Remote Access Conn	Service ac Creates a Manages	Description:	Service for TightVn	cServer	
		Remote Desktop Conf Remote Desktop Serv Remote Desktop Serv	Remote D Allows use	Path to executabl "c:\Program Files	e: (x86)\Common Files\F	lohde-Schwarz\Tigt	ntVnc\tvnserver.ex
		Remote Procedure C		Startup type:	Disabled		
		Remote Procedure C Remote Registry	In Windo Enables re	Help me configur	e service startup optibi	15	
		RIP Listener	Listens for	Service status:	Stopped		
111 F	Extended Standard	•	-	Stan	Stop	<u>P</u> ause	Resume
_	(Extended)(Standard)			You can specify there.	he start parameters the	t apply when you st	art the service from
				Start barameters			

- 6. Set "Startup type" to "Disabled".
- 7. Select "Stop".
- 8. Select "Apply".

The next time a user enters the IP address of the instrument in a web browser, an error message is displayed:

Failed to connect to server (code. 1006)

# 14.4.7 How to Set Up Remote Desktop

Remote Desktop is a Windows application which can be used to access and control the instrument from a remote computer through a LAN connection. While the instrument is in operation, the instrument screen contents are displayed on the remote computer, and Remote Desktop provides access to all of the applications, files, and network resources of the instrument. Thus, remote operation of the R&S FSWP is possible.

With Microsoft Windows, Remote Desktop Client is part of the operating system. For other versions of Windows, Microsoft offers the Remote Desktop Client as an add-on. For details refer to the Microsoft Windows operating system documentation.

With the factory settings, the default "instrument" user can connect to the R&S FSWP with the Remote Desktop program of the controller immediately. No further configuration is required. However, if the connection fails or other users need to connect, this section provides basic instructions on setting up the Remote Desktop for the R&S FSWP.

#### 14.4.7.1 How to Configure the R&S FSWP for Remote Operation via Remote Desktop

 Create a fixed IP address for the TCP/IP protocol as described in Chapter 14.4.1.2, "How to Assign the IP Address", on page 364.

**Note:** To avoid problems, use a fixed IP address. When a DHCP server is used, a new IP address is assigned each time the instrument is restarted. This address must first be determined on the instrument itself. Thus, using a DHCP server is not suitable for remote operation of the R&S FSWP via Remote Desktop.



Select the "Windows" icon in the toolbar to access the operating system.

- In the Windows "Start" menu, select "Settings > System".
- 4. Search for "remote access".
- 5. Select "Allow remote access to your computer".
- Define which users are to be given access to the R&S FSWP via Remote Desktop. Note: The user account under which configuration is carried out is automatically enabled for Remote Desktop.

×

#### System Properties

Computer Name	Hardware	Advanced	System Protectio	n Remote
Remote Assist	ance			
Allow Rem	ote Assistan	ce connectio	ns to this computer	r i i i i i i i i i i i i i i i i i i i
What happens	when Lena	ble Remote A	Assistance?	
				Advanced
Remote Deskt	à			
Choose an op	ion, and the	n specify who	) can connect.	
🔵 Don't allow	remote con	nections to th	is computer	
Allow remo	te connectio	ins to this cor	nputer	
			outers running Rer nentication (recom	
Help me choos	<u>se</u>		S	elect Users
		OK	Cance	Apply

- a) Select the "Select Users" button.
- b) Select the users or create new user accounts as described in Chapter 14.4.3.1, "How to Create Users", on page 369.
- c) Select "OK" to confirm the settings.
- The R&S FSWP is now ready for connection setup with the Remote Desktop program of the controller.

#### 14.4.7.2 How to Configure the Controller



#### **Remote Desktop Client**

With Microsoft Windows, Remote Desktop Client is part of the operating system and can be accessed via "Start > Programs > Accessories > Remote Desktop Connection". For other versions of Windows, Microsoft offers the Remote Desktop Client as an addon.



Select the "Windows" icon in the toolbar to access the operating system.

 From the "Start" menu, select "All Programs > Accessories > Remote Desktop Connection".

The "Remote Desktop Connection" dialog box is displayed.

 Select the "Options >>" button. The dialog box is expanded to display the configuration data.

Remot	e Desktop Conr	nection				0
4	Remote Conn					
General	Display Local	Resources	Programs	Experier	nce Adva	anced
Logon s	ettings					
1	Enter the nan	në of the re	moté compu	ter:		
	Computer:	123456				×
	User name:	instrume	nt			
	You will be as	ked for cre	edentials whe	en you cor	inect.	
	Allow me t	o save cre	dentials			
Connec	tion settings					
1	Save the curr saved conne		ction setting:	s to an RD	P file or op	en a
	Save		Save As.		Open.	
				_	_	
<u>Option</u>	ns			Connec	t	Help

4. Open the "Experience" tab.

The settings on this tab are used to select and optimize the connection speed.

 In the list, select the appropriate connection (for example: LAN (10 Mbps or higher)).

Depending on your selection (and how powerful the connection is), the options are activated or deactivated.

- 6. To improve the performance, you can deactivate the "Desktop background", "Show contents of window while dragging" and "Menu and window animation" options.
- Open the "Local Resources" tab for enabling printers, local drives and serial interfaces.
- If you will need to access drives of the controller from the R&S FSWP (e.g. in order to store settings or to copy files from the controller to the R&S FSWP), select "More", then enable the "Drives" option.

Configure remote audio settings.		
Settings		
Apply Windows key combinations:		
Only when using the full screen	~	
Example: ALT+TAB		
ces and resources		
Choose the devices and resources your remote session.	s that you want to use in	
Printers 20	lipboard	
More		
Deskton Connection		×
	and and a second	
	mputer that you want to	
mari carde		_
orts		
1Ves		
ther supported Plug and Play (PnP)	devices	
	Apply Windows key combinations: Only when using the full screen Example: ALT+TAB ces and resources Choose the devices and resources your remote session. Printers Printers More Desktop Connection Remote Desktop Connection es and resources ne devices and resources on this cour ir remote session.	Apply Windows key combinations: Only when using the full screen Example: ALT+TAB ces and resources Choose the devices and resources that you want to use in your remote session. Printers Printers Clipboard More Desktop Connection Remote Desktop Connection es and resources the devices and resources on this computer that you want to irremote session. main cards tats

Windows will then map drives of the controller to the corresponding network drives.

- To use printers connected to the controller while accessing them from the R&S FSWP, activate the "Printers" option. Do not change the remaining settings.
- Open the "Display" tab. The options for configuring the R&S FSWP screen display are displayed.
- 11. Under "Remote desktop size", you can set the size of the R&S FSWP window on the desktop of the controller.
- 12. Under "Colors", do not change the settings.
- 13. Set the "Display the connection bar when I use the full screen" option:

- If activated, a bar showing the network address of the R&S FSWP will appear at the top edge of the screen. You can use this bar to reduce, minimize or close the window.
- If deactivated, the only way you can return to the controller desktop from the R&S FSWP screen in full screen mode is to select "Disconnect" from the "Start" menu.

#### 14.4.7.3 How to Start and Close the Remote Desktop

#### To set up a connection to the R&S FSWP

- 1. In the "Remote Desktop Connection" dialog box (see Chapter 14.4.7.2, "How to Configure the Controller", on page 376), open the "General" tab.
- In the "Computer" field, enter the IP address of the R&S FSWP.
   In the "User name" field, enter *instrument* to log in as an administrator, or *Normal User* to log in as a standard user.
   In the "Password" field, enter *894129*.
- 3. To save the connection configuration for later use:
  - a) Select the "Save As" button. The "Save As" dialog box is displayed.
  - b) Enter the name for the connection information (\*.RDP).
- 4. To load an existing connection configuration:
  - a) Select the "Open" button.
     The "Open" dialog box is displayed.
  - b) Select the \*.RDP file.
- 5. Select the "Connect" button. The connection is set up.
- If the "Disk drives" option is activated on the "Local Resources" tab, a warning is displayed indicating that the drives are enabled for access from the R&S FSWP. Select "OK" to confirm the warning.
- 7. After a few moments, the R&S FSWP screen is displayed.

If a dark screen appears or a dark square appears in the upper left-hand corner of the screen, you must restart the R&S FSWP in order to see the modified screen resolution.

Analyzer	<ul> <li>Press the key combination [ALT] + [F4].</li> <li>The R&amp;S FSWP firmware is shut down, which may take a few seconds.</li> <li>On the desktop, double-tap the "Analyzer" icon.</li> </ul>
----------	---

The firmware restarts and then automatically opens the "Soft Front Panel", i.e. the user interface on which all front panel controls and the rotary knob are mapped to buttons.

For more information see Chapter 13.2.3, "How to Work with the Soft Front Panels", on page 291.

 To deactivate or activate the "Softfrontpanel", press the [F6] key. After the connection is established, the R&S FSWP screen is displayed in the "Remote Desktop" application window.



The Windows "Start" menu can be made available by expanding the "Remote Desktop" window to full size.

During the connection with the controller, the login entry is displayed on the R&S FSWP screen.

#### To terminate Remote Desktop control

The connection can be terminated by the controller or by a user at the R&S FSWP:

- 1. On the controller, close the "Remote Desktop" window at any time. The connection to the R&S FSWP is terminated.
- On the R&S FSWP, a user logs on. The connection to the controller is terminated as a result. A message is displayed on the controller display indicating that another user has assumed control of the instrument.

#### Restoring the connection to the R&S FSWP

Follow the instructions above for setting up a connection to the R&S FSWP. If the connection is terminated and then restored, the R&S FSWP remains in the same state.

#### 14.4.7.4 How to Shut Down the R&S FSWP via Remote Operation

- Select the R&S FSWP softfrontpanel and close the application with the key combination [ALT] + [F4].
- Select the desktop and press the key combination [ALT] + [F4]. A safety query is displayed to warn you that the instrument cannot be reactivated via remote operation and asks you whether you want to continue the shutdown process.
- Respond to the safety query with "Yes".
   The connection with the controller is terminated and the R&S FSWP is shut down.

# 14.4.8 How to Start a Remote Control Session from a PC

When you switch on the R&S FSWP, it is always in manual operation state ("local" state) and can be operated via the front panel.

#### To start remote control

 Send an addressed command (GTR - Go to Remote) from a controller to the instrument.

The instrument is switched to remote control ("remote" state). Operation via the front panel is disabled. Only the "Local" softkey is displayed to return to manual operation. The instrument remains in the remote state until it is reset to the manual state via the instrument or via remote control interfaces. Switching from manual operation to remote control and vice versa does not affect the other instrument settings.

2. During program execution, send the SYSTem:DISPlay:UPDate ON command to activate the display of results (see SYSTem:DISPlay:UPDate on page 597).

The changes in the device settings and the recorded measurement values are displayed on the instrument screen.

- 3. To obtain optimum performance during remote control, send the SYSTem:DISPlay:UPDate OFF command to hide the display of results and diagrams again (default setting in remote control).
- 4. To prevent unintentional return to manual operation, disable the keys of the instrument using the universal command LLO.

Switching to manual mode is only possible via remote control then. This function is only available for the GPIB interface.

5. To enable the keys of the R&S FSWP again, switch the instrument to local mode (GTL - Go to Local), i.e. deactivate the REN line of the remote control interface.

If the instrument is operated exclusively in remote control, it is recommended that you switch off the display. For details see "Remote Display Update" on page 356.

## 14.4.9 How to Return to Manual Operation

Before you switch back to manual operation, all remote command processing must be completed. Otherwise, the instrument will switch back to remote control immediately.

Select the "Local" softkey, or use the following GPIB command: status = viGpibControlREN(vi, VI\_GPIB\_REN\_ADDRESS\_GTL)



If you select the "Local" softkey while a self-alignment or a self-test is still running (which was started remotely), the instrument only returns to the manual operation state when the alignment or test is completed.

Conventions Used in SCPI Command Descriptions

# 15 Remote Control

Conventions Used in SCPI Command Descriptions	
Common Suffixes.	
Common Commands.	
Selecting the Operating Mode and Application	
Measurements and Result Displays	
Common Measurement Settings	413
Common Analysis and Display Functions	
Managing Settings and Results	
Configuring the R&S FSWP	
Using the Status Register	
Programming Examples	618

# **15.1 Conventions Used in SCPI Command Descriptions**

Note the following conventions used in the remote command descriptions:

Command usage

If not specified otherwise, commands can be used both for setting and for querying parameters.

If a command can be used for setting or querying only, or if it initiates an event, the usage is stated explicitly.

#### • Parameter usage

If not specified otherwise, a parameter can be used to set a value and it is the result of a query.

Parameters required only for setting are indicated as **Setting parameters**. Parameters required only to refine a query are indicated as **Query parameters**. Parameters that are only returned as the result of a query are indicated as **Return values**.

#### Conformity

Commands that are taken from the SCPI standard are indicated as **SCPI confirmed**. All commands used by the R&S FSWP follow the SCPI syntax rules.

#### Asynchronous commands

A command which does not automatically finish executing before the next command starts executing (overlapping command) is indicated as an **Asynchronous command**.

#### • Reset values (\*RST)

Default parameter values that are used directly after resetting the instrument (\*RST command) are indicated as **\*RST** values, if available.

Default unit

The default unit is used for numeric values if no other unit is provided with the parameter.

#### Manual operation

If the result of a remote command can also be achieved in manual operation, a link to the description is inserted.

# 15.2 Common Suffixes

In the application, the following common suffixes are used in remote commands:

Table 15-1: Common suffixes used in remote commands in the application

Suffix	Value range	Description
<m></m>	1 to 16	Marker
		(or spot noise marker)
<n></n>	1 to 16	Window (in the currently selected channel)
<t></t>	1 to 6	Trace
< i>	1 to 8	Limit line
<j></j>	110	Selects an integrated measurement range.
<k></k>	18 (Limit line)	Selects a limit or display line.
	1   2 (Display line)	
<r></r>	1x	Selects a half decade.
		The value range depends on the number of half decades. The first half decade in the measurement always has the value "1". For subsequent half decades, add "1" to get the value "x" (the fourth half decade, for example, would have the value "4").
<s></s>	16	Selects a (user defined) spot noise marker.
<x></x>	12	Selects a mixer in the test setup.



# Selecting windows in multiple channels

Note that the suffix <n> always refers to a window in the currently selected channel.

# 15.3 Common Commands

*CAL?	
*CLS	
*ESE	
*ESR?	
*IDN?	
*IST?	
*OPC	
*OPT?	
*PCB	
*PRE	
*PSC	
*RST	
*SRE	
*STB?	

#### **Common Commands**

*TRG	
*TST?	
*WAI	

#### \*CAL?

Calibration query

Initiates a calibration of the instrument and then queries the calibration status. Responses > 0 indicate errors.

**Note:** If you start a self-alignment remotely, then select the "Local" softkey while the alignment is still running, the instrument only returns to the manual operation state after the alignment is completed.

Usage:	Query only	
--------	------------	--

Manual operation: See " Start Self Alignment " on page 278

#### \*CLS

Clear status

Sets the status byte (STB), the standard event register (ESR) and the EVENt part of the QUEStionable and the OPERation registers to zero. The command does not alter the mask and transition parts of the registers. It clears the output buffer.

Usage: Setting only

#### \*ESE <Value>

Event status enable

Sets the event status enable register to the specified value. The query returns the contents of the event status enable register in decimal form.

#### Parameters:

<Value> Range: 0 to 255

#### \*ESR?

Event status read

Returns the contents of the event status register in decimal form and then sets the register to zero.

Return values:				
<contents></contents>	Range:	0	to	255
Usage:	Query only			

#### \*IDN?

Identification

Returns the instrument identification.

Return values: <id></id>	"Rohde&Schwarz, <device type="">,<part number="">/<serial num-<br="">ber&gt;,<firmware version="">"</firmware></serial></part></device>
Example:	Rohde&Schwarz,FSWP-26,1322.8003K26/100005,1.00
Usage:	Query only
Manual operation:	See "*IDN Format" on page 356

#### \*IST?

Individual status query

Returns the contents of the IST flag in decimal form. The IST flag is the status bit which is sent during a parallel poll.

# Return values:

<istflag></istflag>	0   1
Usage:	Query only

#### \*OPC

Operation complete

Sets bit 0 in the event status register when all preceding commands have been executed. This bit can be used to initiate a service request. The query writes a "1" into the output buffer when all preceding commands have been executed, which is useful for command synchronization.

#### \*OPT?

Option identification query

Queries the options included in the instrument. For a list of all available options and their description, refer to the data sheet.

Usage: Query only

## \*PCB <Address>

Pass control back

Indicates the controller address to which remote control is returned after termination of the triggered action.

#### Setting parameters:

<Address> Range: 0 to 30

Usage:

\***PRE** <Value>

Parallel poll register enable

Sets parallel poll enable register to the indicated value. The query returns the contents of the parallel poll enable register in decimal form.

# Parameters:

<Value> Range: 0 to 255

Setting only

#### \*PSC <Action>

Power on status clear

Determines whether the contents of the ENABle registers are preserved or reset when the instrument is switched on. Thus a service request can be triggered when the instrument is switched on, if the status registers ESE and SRE are suitably configured. The query reads out the contents of the "power-on-status-clear" flag.

#### Parameters:

1
ne contents of the status registers are preserved.
esets the status registers.

#### \*RST

#### Reset

Sets the instrument to a defined default status. The default settings are indicated in the description of commands.

The command is equivalent to SYSTem: PRESet.

Usage:

Setting only

#### \*SRE <Contents>

Service request enable

Sets the service request enable register to the indicated value. This command determines under which conditions a service request is triggered.

#### Parameters:

<Contents>

Contents of the service request enable register in decimal form. Bit 6 (MSS mask bit) is always 0.

Range: 0 to 255

#### \*STB?

Status byte query

Reads the contents of the status byte in decimal form.

Usage: Query only

#### \*TRG

#### Trigger

Triggers all actions waiting for a trigger event. In particular, \*TRG generates a manual trigger signal. This common command complements the commands of the TRIGger subsystem.

\*TRG corresponds to the INITiate: IMMediate command.

Usage: Event

#### \*TST?

Self-test query

Initiates self-tests of the instrument and returns an error code.

**Note:** If you start a self-test remotely, then select the "Local" softkey while the test is still running, the instrument only returns to the manual operation state after the test is completed. In this case, the self-test cannot be aborted.

#### **Return values:**

<errorcode></errorcode>	<pre>integer &gt; 0 (in decimal format) An error occurred. (For details, see the Service Manual supplied with the instrument). 0 No errors occurred.</pre>
Usage:	Query only

#### \*WAI

Wait to continue

Prevents servicing of the subsequent commands until all preceding commands have been executed and all signals have settled (see also command synchronization and \*OPC).

Usage:

Event

# **15.4 Selecting the Operating Mode and Application**

# 15.4.1 Selecting Mode and Applications

DISPlay:ATAB	39
INSTrument:CREate:DUPLicate	39
INSTrument:CREate[:NEW]	39
INSTrument:CREate:REPLace	
INSTrument:DELete	90
INSTrument:LIST?	91
INSTrument:REName	92
INSTrument[:SELect]	92

#### DISPlay:ATAB <State>

This command switches between the MultiView tab and the most recently displayed channel. If only one channel is active, this command has no effect.

#### Parameters:

<State>

ON | OFF | 0 | 1 OFF | 0 Switches the function off ON | 1 Switches the function on

#### INSTrument:CREate:DUPLicate

This command duplicates the currently selected channel, i.e creates a new channel of the same type and with the identical measurement settings. The name of the new channel is the same as the copied channel, extended by a consecutive number (e.g. "IQAnalyzer" -> "IQAnalyzer 2").

The channel to be duplicated must be selected first using the INST: SEL command.

This command is not available if the MSRA Master channel is selected.

Example:	INST:SEL 'PhaseNoise' INST:CRE:DUPL Duplicates the channel named 'PhaseNoise' and creates a new channel named 'PhaseNoise 2'.
Usage:	Event
Manual operation:	See " Duplicate Current Channel " on page 102

#### INSTrument:CREate[:NEW] <ChannelType>, <ChannelName>

This command adds an additional measurement channel. You can configure up to 10 measurement channels at the same time (depending on available memory).

# See also

- INSTrument[:SELect] on page 392
- INSTrument: DELete on page 390

#### Parameters:

<channeltype></channeltype>	Channel type of the new channel. For a list of available channel types see INSTrument:LIST? on page 391.
<channelname></channelname>	String containing the name of the channel. Note that you can not assign an existing channel name to a new channel; this will cause an error.
Example:	INST:CRE SAN, 'Spectrum 2' Adds an additional spectrum display named "Spectrum 2".
Manual operation:	See "New Channel" on page 102

INSTrument:CREate:REPLace <ChannelName1>,<ChannelType>,<ChannelName2>

This command replaces a channel with another one.

Setting parameters: <channelname1> <channeltype></channeltype></channelname1>	String containing the name of the channel you want to replace. Channel type of the new channel. For a list of available channel types see INSTrument:LIST? on page 391.
<channelname2></channelname2>	String containing the name of the new channel. Note: If the specified name for a new channel already exists, the default name, extended by a sequential number, is used for the new channel (see INSTrument:LIST? on page 391). Channel names can have a maximum of 31 characters, and must be compatible with the Windows conventions for file names. In particular, they must not contain special characters such as ":", "*", "?".
Example:	<pre>INST:CRE:REPL 'PhaseNoise', PNO, 'PNO2' Replaces the channel named "PhaseNoise" by a new channel of type "Phase Noise" named "PNO2".</pre>
Usage:	Setting only
Manual operation:	See "Replace Current Channel" on page 102

#### INSTrument:DELete <ChannelName>

This command deletes a channel.

If you delete the last channel, the default "Phase Noise" channel is activated.

Setting parameters: <channelname></channelname>	String containing the name of the channel you want to delete. A channel must exist in order to be able delete it.
Example:	INST:DEL 'PhaseNoise' Deletes the channel with the name 'PhaseNoise'.
Usage:	Setting only

#### **INSTrument:LIST?**

This command queries all active channels. This is useful in order to obtain the names of the existing channels, which are required in order to replace or delete the channels.

Return values:
----------------

<channeltype>, <channelname></channelname></channeltype>	For each channel, the command returns the channel type and channel name (see tables below). Tip: to change the channel name, use the INSTrument: REName command.
Example:	INST:LIST? <b>Result for 2 channels</b> : 'PNO','PhaseNoise','PNO','Phase Noise 2'

#### Usage:

# Query only Table 15-2: Available channel types and default channel names

		•
Application	<channeltype> Parameter</channeltype>	Default Channel Name*)
Phase Noise	PNOise	Phase Noise
Spectrum Monitor	SMONitor	Spectrum Monitor
Spectrum (R&S FSWP-B1)	SANalyzer	Spectrum
I/Q Analyzer (R&S FSWP- B1)	IQ	IQ Analyzer
Pulse Measurements (R&S FSWP-K6)	PULSe	Pulse
Analog Modulation Analy- sis (R&S FSWP-K7)	ADEMod	Analog Demod
Noise Figure Measure- ments (R&S FSWP-K30)	NOISe	Noise
Fast Spur Search (R&S FSWP-K50)	SPUR	Spurious
Transient Analysis (R&S FSWP-K60)	ТА	Transient Analysis
Vector Signal Analysis (R&S FSWP-K70)	DDEM	VSA
Note: the default channel name is also listed in the table. If the specified name for a new channel already		

Note: the default channel name is also listed in the table. If the specified name for a new channel already exists, the default name, extended by a sequential number, is used for the new channel.

INSTrument: REName < Channel Name1>, < Channel Name2>

This command renames a channel.

#### Setting parameters:

<channelname1></channelname1>	String containing the name of the channel you want to rename.
<channelname2></channelname2>	String containing the new channel name. Note that you cannot assign an existing channel name to a new channel; this will cause an error. Channel names can have a maximum of 31 characters, and must be compatible with the Windows conventions for file names. In particular, they must not contain special characters such as ":", "*", "?".
Example:	INST:REN 'PhaseNoise', 'PNO' Renames the channel with the name 'PhaseNoise' to 'PNO'.
Usage:	Setting only

INSTrument[:SELect] <ChannelType> | <ChannelName>

This command activates a new channel with the defined channel type, or selects an existing channel with the specified name.

Also see

- INSTrument:CREate[:NEW] on page 389
- Chapter 15.4.3, "Programming Example: Performing a Sequence of Measurements", on page 395

## **Parameters:**

<channeltype></channeltype>	Channel type of the new channel. For a list of available channel types see INSTrument:LIST? on page 391.
<channelname></channelname>	String containing the name of the channel.
Example:	INST IQ Activates a channel for the I/Q Analyzer application (evaluation mode). INST 'MyIQSpectrum' Selects the channel named 'MyIQSpectrum' (for example before executing further commands for that channel).

Manual operation:	See "Phase Noise" on page 99 See "Spectrum Monitor" on page 99 See "Spectrum" on page 100 See "Analog Modulation Analysis" on page 100 See "I/Q Analyzer" on page 100 See "Noise Figure" on page 100 See "Pulse Measurements" on page 101 See "Spurious Measurements" on page 101 See "Transient Analysis" on page 101
	See "Vector Signal Analysis (VSA)" on page 101 See "New Channel" on page 102

# **15.4.2** Performing a Sequence of Measurements

INITiate:SEQuencer:ABORt	393
INITiate:SEQuencer:IMMediate	393
INITiate:SEQuencer:MODE	
SYSTem:SEQuencer	

#### INITiate:SEQuencer:ABORt

This command stops the currently active sequence of measurements.

You can start a new sequence any time using INITiate: SEQuencer: IMMediate on page 393.

Usage: Event

Manual operation: See "Sequencer State " on page 105

#### INITiate:SEQuencer:IMMediate

This command starts a new sequence of measurements by the Sequencer.

Its effect is similar to the INITiate<n>[:IMMediate] command used for a single measurement.

Before this command can be executed, the Sequencer must be activated (see SYSTem: SEQuencer on page 394).

SYST: SEQ ON Activates the Sequencer. INIT: SEQ: MODE SING Sets single sequence mode so each active measurement will be performed once. INIT: SEQ: IMM Starts the sequential measurements.

Manual operation: See " Sequencer State " on page 105

Example:

#### INITiate:SEQuencer:MODE <Mode>

Defines the capture mode for the entire measurement sequence and all measurement groups and channels it contains.

**Note:** In order to synchronize to the end of a measurement sequence using \*OPC, \*OPC? or \*WAI you must use SINGle Sequence mode.

#### Parameters:

<Mode>

#### SINGle

Each measurement group is started one after the other in the order of definition. All measurement channels in a group are started simultaneously and performed once. After *all* measurements are completed, the next group is started. After the last group, the measurement sequence is finished.

#### **CONTinuous**

Each measurement group is started one after the other in the order of definition. All measurement channels in a group are started simultaneously and performed once. After *all* measurements are completed, the next group is started. After the last group, the measurement sequence restarts with the first one and continues until it is stopped explicitely.

\*RST: CONTinuous

Manual operation: See " Sequencer Mode " on page 105

#### SYSTem:SEQuencer <State>

This command turns the Sequencer on and off. The Sequencer must be active before any other Sequencer commands (INIT:SEQ...) are executed, otherwise an error will occur.

A detailed programming example is provided in Chapter 15.4.3, "Programming Example: Performing a Sequence of Measurements", on page 395.

## Parameters:

<State>

ON | OFF | 0 | 1

#### ON | 1

The Sequencer is activated and a sequential measurement is started immediately.

#### OFF | 0

The Sequencer is deactivated. Any running sequential measurements are stopped. Further Sequencer commands (INIT: SEQ...) are not available.

\*RST: 0

Example:	SYST: SEQ ON Activates the Sequencer. INIT: SEQ: MODE SING Sets single Sequencer mode so each active measurement will be performed once. INIT: SEQ: IMM Starts the sequential measurements. SYST: SEQ OFF
Manual operation:	See " Sequencer State " on page 105

# 15.4.3 Programming Example: Performing a Sequence of Measurements

This example demonstrates how to perform several measurements in a sequence in a remote environment.

Note that it is based on the optional Spectrum application. Doing this for the Phase Noise application, however, works the same way.

```
//2xSpectrumanalyzer + 2xIQ, start Sequencer at the end, test OPC?
// _____
//----Preparing the instrument and first channel ------
*RST
//Activate new IQ channel
INSTrument:CREate:NEW IQ, 'IQ 1'
//Set sweep count for new IQ channel
SENS:SWEEP:COUNT 6
//Change trace modes for IQ channel
DISP:TRAC1:MODE BLANK
DISP:TRAC2:MODE MAXH
DISP:TRAC3:MODE MINH
//Switch to single sweep mode
INIT:CONT OFF
//switch back to first (default) analyzer channel
INST:SEL 'Spectrum';*WAI
//Switch into SEM
SENSe:SWEep:MODE ESPectrum
//Load Sem standard file for W-CDMA
SENSe:ESPectrum:PRESet:STANdard 'WCDMA\3GPP\DL\3GPP DL.xml'
//Set sweep count in Spectrum channel
SENS:SWEEP:COUNT 5
//-----Creating a second measurement channel -----
//Create second IQ channel
INSTrument:CREate:NEW IQ, 'IQ 2'
//Set sweep count
```

#### Selecting the Operating Mode and Application

```
SENS:SWEEP:COUNT 2
//Change trace modes
DISP:TRAC1:MODE MAXH
DISP:TRAC2:MODE MINH
//Create new analyzer channel
INSTrument:CREate:NEW SANalyzer, 'Spectrum 2'
//Activate ACLR measurement in channel 'Spectrum 2'
CALCulate:MARKer:FUNCtion:POWer:SELect ACPower
//Load W-CDMA Standard
CALCulate:MARKer:FUNCtion:POWer:PRESet FW3Gppcdma
//Change trace modes
DISP:TRAC2:MODE MAXH
DISP:TRAC1:MODE MINH
//----Performing a sweep and retrieving results-----
//Change sweep count
SENS:SWEep:COUNt 7
//Single Sweep mode
INIT:CONT OFF
//Switch back to first IQ channel
INST:SEL 'IQ 1';*WAI
//Perform a measurement
INIT:IMM; *OPC?
//Retrieve results
CALC:MARK:Y?
//Activate Multiview
DISPlay:ATAB
                ON
//----Performing a sequence of measurements with the Sequencer-----
//Activate Sequencer
SYSTem:SEQuencer ON
//Start sweep in Sequencer
INITiate:SEQuencer:IMMediate;*OPC?
//Switch into first IQ channel to get results
INST:SEL 'IQ 1';*WAI
CALCulate:MARKer:MAXimum
CALC:MARK:Y?
//Change sweep time in IQ
SENS:SWE:TIME 300us
//Switch to single Sequencer mode
INITiate:SEQuencer:MODE SINGle
//Sweep all channels once, taking the sweep count in each channel into account
INITiate:SEQuencer:IMMediate;*OPC?
//Set marker to maximum in IQ1 and query result
CALCulate:MARKer:MAXimum
CALC:MARK:Y?
//Switch to second IQ channel and retrieve results
INST:SEL 'IO 2';*WAI
```

CALCulate:MARKer:MIN

Measurements and Result Displays

```
CALC:MARK:Y?

//Switch to first Spectrum channel

INST:SEL 'Spectrum';*WAI

//Query one of the SEM results

CALCulate:MARKer:FUNCtion:POWer:RESult? CPOWer

//Switch to second Spectrum channel

INST:SEL 'Spectrum 2';*WAI

//Query channel power result

CALCulate:MARKer:FUNCtion:POWer:RESult? ACPower
```

# 15.5 Measurements and Result Displays

•	Measurement Selection	397
•	Performing Measurements	.399
•	Querying Results	.402
	Programming Examples	

# 15.5.1 Measurement Selection

CONFigure:PNOise:MEASurement	397
CONFigure:SNTune:MEASurement[:STATe]	398
CONFigure:TRANsient:MEASurement[:STATe]	
CONFigure:VCO:MEASurement[:STATe]	

## CONFigure:PNOise:MEASurement < Measurement>

This command selects the measurement.

- To select the Spot Noise vs Tune measurement, use CONFigure: SNTune: MEASurement[:STATe].
- To select the VCO characterization, use CONFigure:VCO:MEASurement[: STATe].
- To select the Transient Analysis measurement, use CONFigure:TRANsient: MEASurement[:STATe].

#### **Parameters:**

<Measurement> BASeband Selects the Baseband Noise measurement. PNOise Select the Phase Noise measurement. PPNoise Selects the Pulsed Phase Noise measurement. PRESidual Selects the Additive Pulsed Phase Noise measurement. RESidual Selects the Additive Noise measurement.

	*RST:	PNOise
Example:	//Select the additive noise measurement CONF:PNO:MEAS RES	
Manual operation:	See "Phase noise Measurement" on page 111 See "Additive noise measurements (optional)" on page 111 See "Baseband noise measurement" on page 111 See "Pulsed phase noise measurements (optional)" on page 112 See "Pulsed additive noise measurements (optional)" on page 112 See "Selecting the noise measurement type" on page 124	

## CONFigure:SNTune:MEASurement[:STATe] <State>

This command selects the Spot Noise vs Tune measurement.

- To select the VCO characterization measurement, use CONFigure:VCO: MEASurement[:STATe].
- To select the Transient Analysis measurement, use CONFigure:TRANsient: MEASurement[:STATe].
- To select other measurements, use CONFigure: PNOise: MEASurement.

#### **Parameters:**

<state></state>	ON   1 Selects the Spot Noise vs Tune measurement.	
	<b>OFF   0</b> Selects the Phase Noise measurement (CONF: PNO: MEAS PNO).	
	*RST: OFF	
Example:	//Select the phase noise measurement CONF:VCO:MEAS OFF	
Manual operation:	See "Spot noise vs tune" on page 111	

#### CONFigure:TRANsient:MEASurement[:STATe] <State>

This command selects the PN Transient Analysis measurement.

- To select the Spot Noise vs Tune measurement, use CONFigure: SNTune: MEASurement[:STATe].
- To select the VCO characterization measurement, use CONFigure:VCO: MEASurement[:STATe].
- To select other measurements, use CONFigure: PNOise: MEASurement.

#### Parameters:

<State>

**ON | 1** Selects the PN Transient Analysis measurement.

	OFF   0 Selects the Phase Noise measurement (CONF: PNO: MEAS PNO).	
	*RST: OFF	
Example:	//Select the phase noise measurement CONF:VCO:MEAS OFF	
Manual operation:	See "PN Transient analysis" on page 112	

## CONFigure:VCO:MEASurement[:STATe] <State>

This command selects the VCO Characterization measurement.

- To select the Spot Noise vs Tune measurement, use CONFigure: SNTune: MEASurement[:STATe].
- To select the Transient Analysis measurement, use CONFigure:TRANsient: MEASurement[:STATe].
- To select other measurements, use CONFigure: PNOise: MEASurement.

#### **Parameters:**

<state></state>	ON   1 Selects the VCC	Characterization measurement.
	<b>OFF   0</b> Selects the Phase PNO).	e Noise measurement (CONF: PNO: MEAS
	*RST: OFI	=
Example:	//Select the phase noise measurement CONF:VCO:MEAS OFF	
Manual operation:	See "VCO chara	cterization" on page 111

# 15.5.2 Performing Measurements

ABORt	
INITiate <n>:CONMeas</n>	400
INITiate <n>:CONTinuous.</n>	
INITiate <n>[:IMMediate]</n>	402

#### ABORt

This command aborts the measurement in the current channel and resets the trigger system.

To prevent overlapping execution of the subsequent command before the measurement has been aborted successfully, use the **\*OPC?** or **\*WAI** command after ABOR and before the next command.

For details see Chapter 14.1.6.1, "Preventing Overlapping Execution", on page 331.

#### Note on blocked remote control programs:

If a sequential command cannot be completed, for example because a triggered sweep never receives a trigger, the remote control program will never finish and the remote channel to the R&S FSWP is blocked for further commands. In this case, you must interrupt processing on the remote channel first in order to abort the measurement.

To do so, send a "Device Clear" command from the control instrument to the R&S FSWP on a parallel channel to clear all currently active remote channels. Depending on the used interface and protocol, send the following commands:

- Visa: viClear()
- GPIB: ibclr()
- **RSIB**: RSDLLibclr()

Now you can send the ABORt command on the remote channel performing the measurement.

Example:	ABOR; : INIT: IMM Aborts the current measurement and immediately starts a new one.
Example:	ABOR; *WAI INIT: IMM Aborts the current measurement and starts a new one once abortion has been completed.
Usage:	Event

## INITiate<n>:CONMeas

This command restarts a (single) measurement that has been stopped (using ABORt) or finished in single measurement mode.

The measurement is restarted at the beginning, not where the previous measurement was stopped.

As opposed to INITiate<n>[:IMMediate], this command does not reset traces in maxhold, minhold or average mode. Therefore it can be used to continue measurements using maxhold or averaging functions.

#### Suffix:

<n>

irrelevant

Example:	<pre>INIT:CONT OFF Switches to single measurement mode. DISP:WIND:TRAC:MODE AVER Switches on trace averaging. SWE:COUN 20 Setting the measurement counter to 20 measurements. INIT; *WAI Starts the measurement and waits for the end of the 20 mea- surements. INIT:CONM; *WAI Continues the measurement (next 20 measurements) and waits for the end</pre>
	for the end. Result: Averaging is performed over 40 measurements.
Manual operation:	See " Continue Single Sweep " on page 110

## INITiate<n>:CONTinuous <State>

This command controls the measurement mode for an individual channel.

Note that in single measurement mode, you can synchronize to the end of the measurement with \*OPC, \*OPC? or \*WAI. In continuous measurement mode, synchronization to the end of the measurement is not possible. Thus, it is not recommended that you use continuous measurement mode in remote control, as results like trace data or markers are only valid after a single measurement end synchronization.

For details on synchronization see Chapter 14.1.6, "Command Sequence and Synchronization", on page 330.

If the measurement mode is changed for a channel while the Sequencer is active the mode is only considered the next time the measurement in that channel is activated by the Sequencer.

Suffix: <n></n>	irrelevant	
Parameters:		
<state></state>	ON   OFF   0   1	
	ON   1 Continuous measurement	
	OFF   0	
	Single measurement	
	*RST: 1	
Example:	INIT:CONT OFF Switches the measurement mode to single measurement. INIT:CONT ON Switches the measurement mode to continuous measurement.	
Manual operation:	See " Continuous Sweep / Run Cont " on page 110	

#### INITiate<n>[:IMMediate]

This command starts a (single) new measurement.

With measurement count or average count > 0, this means a restart of the corresponding number of measurements. With trace mode MAXHold, MINHold and AVERage, the previous results are reset on restarting the measurement.

You can synchronize to the end of the measurement with \*OPC, \*OPC? or \*WAI.

For details on synchronization see Chapter 14.1.6, "Command Sequence and Synchronization", on page 330.

Suffix: <n>

irrelevant

Manual operation: See "Single Sweep / Run Single " on page 109

# 15.5.3 Querying Results

Commands to query results described elsewhere:

- CALCulate<n>:SNOise<s>[:TRACe<t>]:DECades:X? on page 467
- CALCulate<n>:SNOise<s>[:TRACe<t>]:DECades:Y? on page 467
- CALCulate<n>:SNOise<s>[:TRACe<t>]:Y? on page 468

FETCh <n>[:RANGe<j>]:PNOise<t>:DUT:GAIN?</t></j></n>	
FETCh <n>:PNOise<t>:SPURs?</t></n>	403
FETCh <n>:PNOise<t>:SPURs:COUNt?</t></n>	
FETCh <n>:PNOise<t>:SPURs:DISCrete?</t></n>	
FETCh <n>:PNOise<t>:SPURs:JITTer?</t></n>	404
FETCh <n>:PNOise<t>:SPURs:RANDom?</t></n>	
FETCh <n>[:RANGe<j>]:PNOise<t>:IPN?</t></j></n>	
FETCh <n>[:RANGe<j>]:PNOise<t>:RAM?</t></j></n>	405
FETCh <n>[:RANGe<j>]:PNOise<t>:RFM?</t></j></n>	406
FETCh <n>[:RANGe<j>]:PNOise<t>:RMS?</t></j></n>	406
FETCh <n>[:RANGe<j>]:PNOise<t>:RPM?</t></j></n>	
MMEMory:STORe <n>:SPURs</n>	
[SENSe:]BWIDth:MEASurement?	
TRACe <n>[:DATA]?</n>	408
TRACe <n>[:DATA]:LINear?</n>	
TRACe <n>:POINts?</n>	410
TRACe <n>[:DATA]:X?</n>	411
TRACe <n>[:DATA]:X:POINts?</n>	
TRACe <n>[:DATA]:Y?</n>	
TRACe <n>[:DATA]:Y:POINts?</n>	

#### FETCh<n>[:RANGe<j>]:PNOise<t>:DUT:GAIN?

This command queries the DUT gain.

The DUT gain is the ratio of the power measured at the DUT output and the power applied to the DUT input (signal power at the signal source output).

Measurements and Result Displays

Suffix: <n></n>	irrelevant
<j></j>	irrelevant
<t></t>	irrelevant
Return values: <values></values>	<numeric value=""> Default unit: dB</numeric>
Example:	<pre>//Query DUT gain FETC:RANG:PNO:DUT:GAIN? would return, e.g. 2.28</pre>
Usage:	Query only

# FETCh<n>:PNOise<t>:SPURs?

This command queries the location and level of all spurs that have been detected.

Suffix: <n> <t> Return values: <spurcoordinates></spurcoordinates></t></n>	Window Trace Returns two values (frequency and level) for each each spur that
opurocordinatoo	has been detected.
Example:	<pre>//Query spur characteristics FETC: PNO: SPUR? would return, e.g. 1999.232666, -0.639974, 6494.312500, -0.760579, 19992.324219, -0.639974</pre>
Usage:	Query only
Manual operation:	See "Spurious List" on page 115

#### FETCh<n>:PNOise<t>:SPURs:COUNt?

This command queries the number of spurious included in the spurious list.

Suffix:	
<n></n>	1n Window
<t></t>	1n Trace
Return values: <count></count>	Number of spurious
Example:	FETCh:PNO:SPURs:COUNt?

Measurements and Result Displays

Usage: Query only

Manual operation: See "Spurious List" on page 115

# FETCh<n>:PNOise<t>:SPURs:DISCrete?

This command queries the discrete jitter result.

Suffix: <n></n>	Window
<t></t>	Trace
<b>Return values:</b> <jitter></jitter>	<numeric value=""> Default unit: s</numeric>
Example:	//Query discrete jitter FETC: PNO: SPUR: DISC? would return, e.g. 2.3e-08
Usage:	Query only
Manual operation:	See "Spurious List" on page 115

## FETCh<n>:PNOise<t>:SPURs:JITTer?

This command queries the jitter of the measured spurs.

Suffix:	
<n></n>	Window
<t></t>	Trace
Return values:	
<jitter></jitter>	<numeric value=""></numeric>
	Default unit: s
Example:	<pre>//Query jitter of spurs FETC: PNO: SPUR: JITT? would return, e.g. +2.199886328E+004, +2.440125142E-012, +7.332938281E+004, []</pre>
Usage:	Query only
Manual operation:	See "Spurious List" on page 115

#### FETCh<n>:PNOise<t>:SPURs:RANDom?

This command queries the random jitter result.

Suffix: <n>

Window

<t></t>	Trace
<b>Return values:</b> <arg0></arg0>	<numeric value=""> Default unit: s</numeric>
Example:	//Query random jitter FETC: PNO: SPUR: RAND? would return, e.g. 3.59e-09
Usage:	Query only
Manual operation:	See "Spurious List" on page 115

# FETCh<n>[:RANGe<j>]:PNOise<t>:IPN?

This command queries the integrated phase noise.

Suffix: <n></n>	Window
<j></j>	Integration range
<t></t>	Тгасе
Return values: <level></level>	<numeric value=""> Default unit: dBc</numeric>
Example:	<pre>//Query integrated phase noise FETC:RANG2:PNO2:IPN? would return, e.g16.79</pre>
Usage:	Query only
Manual operation:	See "Integrated Measurements" on page 114

# FETCh<n>[:RANGe<j>]:PNOise<t>:RAM?

This command queries the residual AM.

Window
Integration range
Trace
<numeric value=""></numeric>
In case of Baseband Noise measurements, the result is always 0.
Default unit: PCT

Example:	//Query residual AM
	<pre>FETC:RANG2:PNO:RAM?</pre>
	would return, e.g.
	0.01196555513888597
Usage:	Query only
Manual operation:	See "Integrated Measurements" on page 114

## FETCh<n>[:RANGe<j>]:PNOise<t>:RFM?

This command queries the residual FM.

Suffix:	Window
<n></n>	WINDOW
<j></j>	Integration range
<t></t>	Trace
<b>Return values:</b> <frequency></frequency>	<numeric value=""> In case of Baseband Noise measurements, the result is always 0. Default unit: Hz</numeric>
Example:	//Query residual FM FETC:RANG2:PNO:RFM? would return, e.g. 88110000
Usage:	Query only
Manual operation:	See "Integrated Measurements" on page 114

# FETCh<n>[:RANGe<j>]:PNOise<t>:RMS?

This command queries the residual RMS jitter.

Suffix: <n></n>	Window
<j></j>	Integration range
<t></t>	Trace
<b>Return values:</b> <jitter></jitter>	<numeric value=""></numeric>
	In case of Baseband Noise measurements, the result is always 0.
	Default unit: s

page 114

Example:	//Query RMS jitter
	<pre>FETC:RANG2:PNO2:RMS?</pre>
	would return, e.g.
	0.02175
Usage:	Query only
Manual operation:	See "Integrated Measurements" on

## FETCh<n>[:RANGe<j>]:PNOise<t>:RPM?

This command queries the residual PM.

Suffix:	
<n></n>	Window
<j></j>	Integration range
<t></t>	Trace
<b>Return values:</b> <phase></phase>	<numeric value=""> In case of Baseband Noise measurements, the result is always 0. Default unit: deg</numeric>
Example:	//Query residual PM FETC:RANG2:PNO:RPM? would return, e.g. 11.73
Usage:	Query only
Manual operation:	See "Integrated Measurements" on page 114

## MMEMory:STORe<n>:SPURs <FileName>[, <Trace>]

This command exports the spur information to a file.

#### Secure User Mode

In secure user mode, settings that are stored on the instrument are stored to volatile memory, which is restricted to 256 MB. Thus, a "memory limit reached" error can occur although the hard disk indicates that storage space is still available.

To store data permanently, select an external storage location such as a USB memory device.

For details, see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

Suffix:

<n>

1..n Window

Setting parameters: <filename></filename>	String containing the path and name of the target file.
<trace></trace>	<numeric value=""> (integer only)</numeric>
	Trace from which the spur information is collected. If you do not define a trace, all spurs over all traces are expor- ted.
Example:	<pre>//Store spur information of trace 1 MMEM:STOR:SPUR 'c:\spurs.asc',1</pre>
Usage:	Setting only

## [SENSe:]BWIDth:MEASurement?

This command queries the measurement bandwidth of the frequency stability measurements (Allan variance and deviation).

Return values: <bandwidth></bandwidth>	<numeric value=""> Default unit: Hz</numeric>
Example:	//Query measurement bandwidth BWID:MEAS?
Usage:	Query only
Manual operation:	See "Allan Variance / Allan Deviation" on page 117

# TRACe<n>[:DATA]? <Trace>

This command queries the trace data (measurement results).

Suffix:	
<n></n>	1n
	Window
Query parameters:	
<trace></trace>	TRACE1     TRACE6
	Queries the data of one of the colored line traces.
	XGINdicator
	Queries the data of the cross-correlation gain indicator (grey area).
Return values:	
<result></result>	Phase noise measurements
	Coordinates of the trace as list of comma-separated values, beginning at the nearest offset frequency. • Baseband noise measurements
	Coordinates of the trace as list of comma-separated values, beginning at the start frequency. • VCO characterization

	Coordinates of the trace as list of comma-separated values, beginning at the first sweep voltage. • Spot noise vs tune Coordinates of the trace as list of comma-separated values, beginning at the first sweep voltage. • Transient analysis Coordinates of the trace (frequency or phase) as a list of comma-separated values, over the defined measurement time.
Example:	<pre>//Query trace data TRAC? TRACE1 would return the data of trace 1, e.g.: 1000.000000,-82.326393,1011.579712,-82.411499, 1023.292969,-82.538643,[]</pre>
Usage:	Query only
Manual operation:	See "Noise Diagram" on page 113 See "Allan Variance / Allan Deviation" on page 117 See "Frequency (VCO Characterization)" on page 118 See "Sensitivity" on page 118 See "Power" on page 118 See "Current / Voltage" on page 119 See "Power vs. Frequency" on page 119 See "Harmonic Power" on page 119 See "Spot Noise vs Tune PN" on page 120 See "Spot Noise vs Tune AM" on page 120 See "Frequency (Transient Analysis)" on page 120 See "Frequency Deviation" on page 121 See "Phase" on page 121

TRACe <n>[:DATA]:LINear? &lt;</n>	Trace>, <points>[,</points>	<start>, <stop>]</stop></start>
-----------------------------------	-----------------------------	---------------------------------

This command queries the trace data with linear interpolation.

# Suffix:

<n>

1..n Window

#### Query parameters:

<trace></trace>	<ul> <li>TRACE1     TRACE6</li> <li>Queries the data of one of the colored line traces.</li> <li>XGINdicator</li> <li>Queries the data of the cross-correlation gain indicator (grey area).</li> </ul>
<points></points>	<numeric value=""> (integer only) Defines the number of linearily spaced measurement points that are returned within the specified frequency range (defined by the start and stop values).</numeric>

<start></start>	<numeric value=""></numeric>
	Defines the start offset of the frequency range whose trace data you like to query. The start offset must be within the measurement range you have defined. If you do not define a start and stop offset, the com- mand returns the trace data for the complete measurement range that was defined. Minimum start offset is 0 Hz. Default unit: Hz
<stop></stop>	<numeric value=""></numeric>
	Defines the stop offset of the frequency range whose trace data you like to query. The stop offset must be within the measurement range you have defined. If you do not define a start and stop offset, the com- mand returns the trace data for the complete measurement range that was defined. Maximum stop offset depends on the measurement range. Default unit: Hz
Return values:	
<result></result>	String that contains the trace data as comma-separated values. Each data point consists of two values: offset frequency in Hz and level in dBc/Hz. The number of value pairs depends on the number of points you have defined.
Example:	<pre>//Query linear trace data TRAC:LIN? TRACE1,5,100,100000 would return, e.g. 100.000000,0.000000,25075.000000,-139.424408, 50050.000000,-140.380112,75025.000000, -139.754211,100000.00000,-141.686478</pre>
Usage:	Query only

## TRACe<n>:POINts? <Trace>

This command queries the number of measurement points of a specific trace.

Suffix:	
<n></n>	1n
	Window
Query parameters:	
<trace></trace>	TRACe1   TRACe2   TRACe3   TRACe4   TRACe5   TRACe6
	XGINdicator
	"XGINdicator" only available for phase noise measurements.
Return values:	
<points></points>	<numeric value=""> (integer)</numeric>

Example:	//Query number of measurement points of a trace in window 2
	TRAC2:POIN? TRACE1

Usage: Query only

# TRACe<n>[:DATA]:X? <Trace>

Queries X trace values merged with spurs for a given window and trace.

Suffix: <n></n>	1n Window
Query parameters: <trace></trace>	TRACe1   TRACe2   TRACe3   TRACe4   TRACe5   TRACe6
<b>Return values:</b> <result></result>	Comma separated list of X values
Usage:	Query only
Manual operation:	See "Noise Diagram" on page 113

## TRACe<n>[:DATA]:X:POINts? <Trace>

Queries number of points of trace data merged with spurs.

Suffix:	
<n></n>	1n
	Window
Query parameters:	
<trace></trace>	TRACe1   TRACe2   TRACe3   TRACe4   TRACe5   TRACe6
Return values:	
<points></points>	<numeric value=""> (integer)</numeric>
Usage:	Query only
-	
Manual operation:	See "Noise Diagram" on page 113

# TRACe<n>[:DATA]:Y? <Trace>

Queries Y trace values merged with spurs for a given window and trace.

Suffix: <n></n>	1n Window
Query parameters: <trace></trace>	TRACe1   TRACe2   TRACe3   TRACe4   TRACe5   TRACe6
<b>Return values:</b> <result></result>	Comma separated list of Y values
Usage:	Query only

Manual operation: See "Noise Diagram" on page 113

#### TRACe<n>[:DATA]:Y:POINts? <Trace>

Queries number of points of trace data merged with spurs.

Suffix: <n>

<Trace>

1..n Window

Query parameters:

TRACe1 | TRACe2 | TRACe3 | TRACe4 | TRACe5 | TRACe6

Return values: <Points>

<numeric value> (integer)

Usage: Query only

Manual operation: See "Noise Diagram" on page 113

# 15.5.4 Programming Examples

#### Performing a phase noise measurement

```
//Preset
*RST
//Select single sweep mode
INIT:CONT OFF
// Configure start and stop offset
SENS:FREQ:START 1kHz
SENS:FREQ:STOP 1MHZ
// Configure RBW in %
LIST:BWID:RAT 10
// Configure cross correllation factor
SWE:XFAC 1
// Start synchronized measurement
INIT:IMM; *OPC?
// Turn on marker 1 in window 1
CALC1:MARK1:STAT ON
// Set marker 1 stimulus
CALC1:MARK1:X 300 kHz
// Query marker 1 result
CALC1:MARK1:Y?
```

# **15.6 Common Measurement Settings**

Remote Commands to Configure the Input Source	
Output	
Remote Commands to Configure User Ports	
Remote Commands to Configure Level Characteristics	
Remote Commands to Configure the Frequency	
Phase Noise Measurement Configuration	
Pulsed Phase Noise Configuration	
VCO Characterization Configuration	
Spot Noise vs Tune Configuration	
Transient Analysis	

# 15.6.1 Remote Commands to Configure the Input Source

•	RF Input	413
•	Baseband Input	415
•	External Mixer	415

# 15.6.1.1 RF Input

INPut <ip>:COUPling</ip>	413
INPut <ip>:SELect</ip>	414
INPut<1 2>:LOSCillator:SOURce	414
INPut<1 2>:LOSCillator:SOURce:EXTernal:LEVel	

## INPut<ip>:COUPling <CouplingType>

This command selects the coupling type of the RF input.

Suffix:	
<ip></ip>	1   2
	irrelevant
Parameters:	
<couplingtype></couplingtype>	AC   DC
	AC
	AC coupling
	DC
	DC coupling
	*RST: AC
Example:	INP:COUP DC
Manual operation:	See " Input Coupling " on page 126

#### INPut<ip>:SELect <Source>

This command selects the signal source for measurements, i.e. it defines which connector is used to input data to the R&S FSWP.

Suffix:

<ip>

1 | 2 irrelevant

Parameters:		
<source/>	ABB	
	Analog Baseband signal	
	RF	
	Radio Frequency ("RF INPUT" connector	r)
	*RST: RF	
Manual operation:	See " Radio Frequency State " on page 1	126

## INPut<1|2>:LOSCillator:SOURce <Location>

This command selects the type of local oscillator in the test setup.

Prerequisites for this command

• Select additive noise or pulsed additive noise measurement (CONFigure: PNOise:MEASurement).

#### Suffix:

<1|2>

1|2 irrelevant

# Parameters: <Location>

#### EXTernal

External local oscillator connected to the "LO AUX Input" of the R&S FSWP.

## INTernal

Internal local oscillator of the R&S FSWP.

\*RST: INTernal

Example: //Select external oscillator CONF:PNO:MEAS RES INP:LOSC:SOUR EXT

Manual operation: See "Local Oscillator" on page 126

# INPut<1|2>:LOSCillator:SOURce:EXTernal:LEVel <Level>

This command selects the level of an external LO signal that is fed into the R&S FSWP.

#### Prerequisites for this command

• Select additive noise or pulsed additive noise measurement (CONFigure: PNOise:MEASurement).

• Select an external local oscillator (INPut<1|2>:LOSCillator:SOURce).

<b>Suffix:</b> <1 2>	1 2 irrelevant
Parameters: <level></level>	HIGH LO signal with high level characteristics. LOW LO signal with low level characteristics. *RST: HIGH
Example:	//Select an external LO with low signal level CONF:PNO:MEAS RES INP:LOSC:SOUR EXT INP:LOSC:SOUR:EXT:LEV LOW
Manual operation:	See "Local Oscillator" on page 126

## 15.6.1.2 Baseband Input

## INPut<1|2>:CONNector <Mode>

This command selects the measurement channel for baseband noise measurements.

Suffix:	
<1 2>	1 2
	irrelevant
Parameters:	
<mode></mode>	CH1
	Measurement on baseband channel 1.
	CH2
	Measurement on baseband channel 2.
	XCOR
	Measurement on both baseband channels (cross-correlation measurements).
Example:	//Perform measurement on baseband channel 1 INP:CONN CH1

### 15.6.1.3 External Mixer

•	Mixer Settings	416
•	Basic Settings	422
•	Conversion Loss Table	423

**Common Measurement Settings** 

### **Mixer Settings**

[SENSe:]MIXer <x>:FREQuency:HANDover</x>	416
[SENSe:]MIXer <x>:FREQuency:STARt</x>	
[SENSe:]MIXer <x>:FREQuency:STOP</x>	
[SENSe:]MIXer <x>:HARMonic:BAND</x>	
[SENSe:]MIXer <x>:HARMonic:BAND:PRESet</x>	
[SENSe:]MIXer <x>:HARMonic:HIGH[:VALue]</x>	
[SENSe:]MIXer <x>:HARMonic:HIGH:STATe</x>	
[SENSe:]MIXer <x>:HARMonic:TYPE</x>	
[SENSe:]MIXer <x>:HARMonic[:LOW]</x>	
[SENSe:]MIXer <x>:LOSS:HIGH</x>	
[SENSe:]MIXer <x>:LOSS:TABLe:HIGH</x>	
[SENSe:]MIXer <x>:LOSS:TABLe[:LOW]</x>	
[SENSe:]MIXer <x>:LOSS[:LOW]</x>	
[SENSe:]MIXer <x>:PORTs</x>	
[SENSe:]MIXer <x>:RFOVerrange[:STATe]</x>	
[SENSe:]MIXer <x>:XCORr</x>	

#### [SENSe:]MIXer<x>:FREQuency:HANDover <Frequency>

This command defines the frequency at which the mixer switches from one range to the next (if two different ranges are selected). The handover frequency for each band can be selected freely within the overlapping frequency range.

This command is only available if the external mixer is active (see [SENSe: ]MIXer<x>[:STATe] on page 423).

#### Suffix:

<χ>	1n irrelevant
Parameters: <frequency></frequency>	Default unit: HZ
Example:	MIX ON Activates the external mixer. MIX: FREQ: HAND 78.0299GHz Sets the handover frequency to 78.0299 GHz.
Manual operation:	See " Handover Freq " on page 134

#### [SENSe:]MIXer<x>:FREQuency:STARt

This command sets or queries the frequency at which the external mixer band starts.

Suffix:	
<χ>	1n irrelevant
Example:	MIX: FREQ: STAR? Queries the start frequency of the band.
Manual operation:	See " RF Start / RF Stop " on page 134

#### [SENSe:]MIXer<x>:FREQuency:STOP

This command sets or queries the frequency at which the external mixer band stops.

Suffix:	
<χ>	1n irrelevant
Example:	MIX: FREQ: STOP? Queries the stop frequency of the band.
Manual operation:	See " RF Start / RF Stop " on page 134

#### [SENSe:]MIXer<x>:HARMonic:BAND <Band>

This command selects the external mixer band. The query returns the currently selected band.

This command is only available if the external mixer is active (see [SENSe: ]MIXer<x>[:STATe] on page 423).

#### Suffix:

<χ>	1n
	irrelevant

## Parameters:

<band></band>	KA   Q   U   V   E   W   F   D   G   Y   J   USER
	Standard waveguide band or user-defined band.

Manual operation: See " Band " on page 134

## Table 15-3: Frequency ranges for pre-defined bands

Band	Frequency start [GHz]	Frequency stop [GHz]
KA (A) *)	26.5	40.0
Q	33.0	50.0
U	40.0	60.0
V	50.0	75.0
E	60.0	90.0
W	75.0	110.0
F	90.0	140.0
D	110.0	170.0
G	140.0	220.0
J	220.0	325.0
Y	325.0	500.0
USER	32.18	68.22
	(default)	(default)
*) The band	formerly referred to as "A" is now named "KA".	

#### [SENSe:]MIXer<x>:HARMonic:BAND:PRESet

This command restores the preset frequency ranges for the selected standard waveguide band.

**Note:** Changes to the band and mixer settings are maintained even after using the [PRESET] function. Use this command to restore the predefined band ranges.

Suffix:	
<x></x>	1n irrelevant
Example:	MIX:HARM:BAND:PRES Presets the selected waveguide band.
Manual operation:	See " Preset Band " on page 135

#### [SENSe:]MIXer<x>:HARMonic:HIGH[:VALue] <HarmOrder>

This command specifies the harmonic order to be used for the high (second) range.

Suffix:		
<χ>	1n	
	irrelevant	
Parameters:		
<harmorder< th=""><th colspan="2">numeric value</th></harmorder<>	numeric value	
	Range:	2 to 61 (USER band); for other bands: see band definition
Example:	MIX:HARM	:HIGH:STAT ON
·	MIX:HARM	:HIGH 2
Manual operation:	See " Harm	onic Order " on page 136

#### [SENSe:]MIXer<x>:HARMonic:HIGH:STATe <State>

This command specifies whether a second (high) harmonic is to be used to cover the band's frequency range.

Sı	Jff	ix:

< <u>x</u> >	1n	
Parameters: <state></state>	ON   OFF *RST:	ON
Example:	MIX:HARM:HIGH:STAT ON	
Manual operation:	See " Range 1 / Range 2 " on page 135	

#### [SENSe:]MIXer<x>:HARMonic:TYPE <OddEven>

This command specifies whether the harmonic order to be used should be odd, even, or both.

Which harmonics are supported depends on the mixer type.

Suffix: <x></x>	1n irrelevant
Parameters: <oddeven></oddeven>	ODD   EVEN   EODD <b>ODD   EVEN   EODD</b> *RST: EVEN
Example:	MIX:HARM:TYPE ODD
Manual operation:	See " Harmonic Type " on page 135

## [SENSe:]MIXer<x>:HARMonic[:LOW] <HarmOrder>

This command specifies the harmonic order to be used for the low (first) range.

Suffix: <x></x>	1n irrelevant	
Parameters: <harmorder></harmorder>	Range: *RST:	2 to 61 (USER band); for other bands: see band definition 2 (for band F)
Example:	MIX:HARM	3
Manual operation:	See " Harm	onic Order " on page 136

## [SENSe:]MIXer<x>:LOSS:HIGH <Average>

This command defines the average conversion loss to be used for the entire high (second) range.

Suffix: <x></x>	1n Mixer	
Parameters: <average></average>	Range: *RST: Default unit:	0 to 100 24.0 dB dB
Example:	MIX:LOSS:	HIGH 20dB
Manual operation:	See " Conve	ersion Loss " on page 136

#### [SENSe:]MIXer<x>:LOSS:TABLe:HIGH <FileName>

This command defines the conversion loss table to be used for the high (second) range.

Suffix:

<χ>

1..n Mixer

Setting	parameters:
---------	-------------

octang parameters.	
<filename></filename>	String containing the path and name of the file, or the serial number of the external mixer whose file is required. The R&S FSWP automatically selects the correct cvl file for the cur- rent IF. As an alternative, you can also select a user-defined conversion loss table (.acl file).
<b>Return values:</b> <filename></filename>	As the result of a query, the actually used file is returned.
Manual operation:	See " Conversion Loss " on page 136

#### [SENSe:]MIXer<x>:LOSS:TABLe[:LOW] <FileName>

This command defines the file name of the conversion loss table to be used for the low (first) range.

· · ·	
Suffix:	
<χ>	1n
	Mixer
Parameters:	
<filename></filename>	String containing the path and name of the file, or the serial number of the external mixer whose file is required. The R&S FSWP automatically selects the correct cvl file for the cur- rent IF. As an alternative, you can also select a user-defined conversion loss table (.acl file).
Example:	MIX:LOSS:TABL '101567'
	MIX:LOSS:TABL?
	//Result:
	'101567 MAG 6 B5000 3G5.B5G'
	101201 WG 0 P2000 203. P20
Manual operation:	See " Conversion Loss " on page 136

## [SENSe:]MIXer<x>:LOSS[:LOW] <Average>

This command defines the average conversion loss to be used for the entire low (first) range.

#### Suffix:

<χ>

1..n Mixer

Parameters: <average></average>	Range: *RST: Default unit:	24.0 dB
Example:	MIX:LOSS	20dB
Manual operation:	See " Conve	ersion Loss " on page 136

## [SENSe:]MIXer<x>:PORTs <PortType>

This command queries the connected mixer type. Currently, only three-port mixers are supported.

Suffix: <x></x>	1n irrelevant
Parameters:	
<porttype></porttype>	2   3
	2
	Two-port mixer.
	3
	Three-port mixer.
	*RST: 2
Example:	MIX:PORT 3

## [SENSe:]MIXer<x>:RFOVerrange[:STATe] <State>

If enabled, the band limits are extended beyond "RF Start" and "RF Stop" due to the capabilities of the used harmonics.

Suffix:	
<χ>	1n
	irrelevant
Parameters:	
<state></state>	ON   OFF   1   0
	*RST: 0
Manual operation:	See " RF Overrange " on page 135

### [SENSe:]MIXer<x>:XCORr <State>

This command turns cross-correlation with two external mixers on and off.

#### Suffix:

<χ>

1..n irrelevant

Parameters: <state></state>	ON   OFF   1   0 *RST: ON
Example:	//Turn on cross-correlation with two mixers
Manual operation:	See "Mixer XCORR" on page 135

## **Basic Settings**

[SENSe:]MIXer <x>:BIAS:HIGH</x>	422
[SENSe:]MIXer <x>:BIAS[:LOW]</x>	422
[SENSe:]MIXer <x>[:STATe]</x>	
[SENSe:]MIXer <x>:LOPower</x>	
r	

#### [SENSe:]MIXer<x>:BIAS:HIGH <BiasSetting>

This command defines the bias current for the high (last) range.

This command is only available if the external mixer is active (see [SENSe: ]MIXer<x>[:STATe] on page 423).

## Suffix:

<x></x>	1n irrelevant	
<b>Parameters:</b> <biassetting></biassetting>	*RST: Default unit	0.0 A : A
Manual operation:	See " Bias '	Value " on page 137

## [SENSe:]MIXer<x>:BIAS[:LOW] <BiasSetting>

This command defines the bias current for the low (first) range.

This command is only available if the external mixer is active (see [SENSe: ]MIXer<x>[:STATe] on page 423).

# Suffix: <x>

1..n irrelevant

# Parameters:

<BiasSetting>

\*RST: 0.0 A Default unit: A

Manual operation: See "Bias Value " on page 137

## [SENSe:]MIXer<x>[:STATe] <State>

Activates or deactivates the use of a connected external mixer as input for the measurement. This command is only available if the optional External Mixer is installed and an external mixer is connected.

Suffix:	1n
< <sub>X</sub> >	irrelevant
Parameters:	ON   OFF   1   0
<state></state>	*RST: 0
Example:	MIX ON
Manual operation:	See "External Mixer (State)" on page 134

#### [SENSe:]MIXer<x>:LOPower <Level>

This command specifies the LO level of the external mixer's LO port.

Suffix: <x></x>	1n irrelevant	
Parameters:		
<level></level>	numeric value	
	Range:         13.0 dBm to 17.0 dBm           Increment:         0.1 dB           *RST:         15.5 dBm	
Example:	MIX:LOP 16.0dBm	
Manual operation:	See " LO Level " on page 137	

# **Conversion Loss Table**

[SENSe:]CORRection:CVL:BAND	4
[SENSe:]CORRection:CVL:BIAS	4
[SENSe:]CORRection:CVL:CATalog?	4
[SENSe:]CORRection:CVL:CLEar	
[SENSe:]CORRection:CVL:COMMent	5
[SENSe:]CORRection:CVL:DATA	5
[SENSe:]CORRection:CVL:HARMonic	6
[SENSe:]CORRection:CVL:MIXer	6
[SENSe:]CORRection:CVL:PORTs	6
[SENSe:]CORRection:CVL:SELect	
[SENSe:]CORRection:CVL:SNUMber	7

#### [SENSe:]CORRection:CVL:BAND <Band>

This command defines the waveguide band for which the conversion loss table is to be used. This setting is checked against the current mixer setting before the table can be assigned to the range.

Before this command can be performed, the conversion loss table must be selected (see [SENSe:]CORRection:CVL:SELect on page 427).

This command is only available with option B21 (External Mixer) installed.

Parameters:	
<band></band>	K KA Q U V E W F D G Y J USER
	Standard waveguide band or user-defined band. For a definition of the frequency range for the pre-defined bands, see Table 15-3). *RST: F (90 GHz - 140 GHz)
Example:	CORR:CVL:SEL 'LOSS_TAB_4' Selects the conversion loss table. CORR:CVL:BAND KA Sets the band to KA (26.5 GHz - 40 GHz).
Manual operation:	See "Band " on page 140

#### [SENSe:]CORRection:CVL:BIAS <BiasSetting>

This command defines the bias setting to be used with the conversion loss table.

Before this command can be performed, the conversion loss table must be selected (see [SENSe:]CORRection:CVL:SELect on page 427.

This command is only available with option B21 (External Mixer) installed.

Paran	neters:
-------	---------

<biassetting></biassetting>	*RST: 0.0 A Default unit: A
Example:	CORR:CVL:SEL 'LOSS_TAB_4' Selects the conversion loss table. CORR:CVL:BIAS 3A
Manual operation:	See " Write to CVL table " on page 137 See " Bias " on page 140

#### [SENSe:]CORRection:CVL:CATalog?

This command queries all available conversion loss tables saved in the C:\R S\INSTR\USER\cvl\ directory on the instrument.

This command is only available with option B21 (External Mixer) installed.

<b>Return values:</b> <files></files>	'string'
	Comma-separated list of strings containing the file names.
	Contraining the menanes.
Example:	CORR:CVL:CAT?
Usage:	Query only

#### [SENSe:]CORRection:CVL:CLEar

This command deletes the selected conversion loss table. Before this command can be performed, the conversion loss table must be selected (see [SENSe:]CORRection:CVL:SELect on page 427).

This command is only available with option B21 (External Mixer) installed.

Example:	CORR:CVL:SEL 'LOSS_TAB_4'
	Selects the conversion loss table. CORR:CVL:CLE
Manual operation:	See " Delete Table " on page 139

#### [SENSe:]CORRection:CVL:COMMent <Text>

This command defines a comment for the conversion loss table. Before this command can be performed, the conversion loss table must be selected (see [SENSe:]CORRection:CVL:SELect on page 427).

This command is only available with option B21 (External Mixer) installed.

#### Parameters:

<Text>

Example:	CORR:CVL:SEL 'LOSS_TAB_4' Selects the conversion loss table.
	CORR:CVL:COMM 'Conversion loss table for FS_Z60'
Manual operation:	See " Comment " on page 140

#### [SENSe:]CORRection:CVL:DATA {<Freq>, <Level>}...

This command defines the reference values of the selected conversion loss tables. The values are entered as a set of frequency/level pairs. A maximum of 50 frequency/ level pairs may be entered. Before this command can be performed, the conversion loss table must be selected (see [SENSe:]CORRection:CVL:SELect on page 427).

This command is only available with option B21 (External Mixer) installed.

#### **Parameters:**

<Freq> The frequencies have to be sent in ascending order. Default unit: HZ

<level></level>	Default unit: DB
Example:	CORR:CVL:SEL 'LOSS_TAB_4' Selects the conversion loss table. CORR:CVL:DATA 1MHZ,-30DB,2MHZ,-40DB
Manual operation:	See " Position / Value " on page 141

#### [SENSe:]CORRection:CVL:HARMonic <HarmOrder>

This command defines the harmonic order for which the conversion loss table is to be used. This setting is checked against the current mixer setting before the table can be assigned to the range.

Before this command can be performed, the conversion loss table must be selected (see [SENSe:]CORRection:CVL:SELect on page 427.

This command is only available with option B21 (External Mixer) installed.

Parameters: <harmorder></harmorder>	Range:	2 to 65
Example:		SEL 'LOSS_TAB_4' conversion loss table. HARM 3
Manual operation:	See " Harm	onic Order " on page 140

#### [SENSe:]CORRection:CVL:MIXer <Type>

This command defines the mixer name in the conversion loss table. This setting is checked against the current mixer setting before the table can be assigned to the range.

Before this command can be performed, the conversion loss table must be selected (see [SENSe:]CORRection:CVL:SELect on page 427).

This command is only available with option B21 (External Mixer) installed.

#### **Parameters:**

<type></type>	string Name of mixer with a maximum of 16 characters
Example:	CORR:CVL:SEL 'LOSS_TAB_4' Selects the conversion loss table. CORR:CVL:MIX 'FS_Z60'
Manual operation:	See " Mixer Name " on page 141

## [SENSe:]CORRection:CVL:PORTs <PortType>

This command defines the mixer type in the conversion loss table. This setting is checked against the current mixer setting before the table can be assigned to the range.

Before this command can be performed, the conversion loss table must be selected (see [SENSe:]CORRection:CVL:SELect on page 427).

This command is only available with option B21 (External Mixer) installed.

Parameters:					
<porttype></porttype>	2 3				
	*RST:	2			
Example:	CORR:CV Selects t CORR:CV	he conv	ersion lo		
Manual operation:	See " Mi	xer Type	e " on pag	ge 14 <sup>-</sup>	1

#### [SENSe:]CORRection:CVL:SELect <FileName>

This command selects the conversion loss table with the specified file name. If <file\_name> is not available, a new conversion loss table is created.

This command is only available with option B21 (External Mixer) installed.

Parameters: <filename></filename>	String containing the path and name of the file.
Example:	CORR:CVL:SEL 'LOSS_TAB_4'
Manual operation:	See " New Table " on page 138 See " Edit Table " on page 138 See " File Name " on page 140

#### [SENSe:]CORRection:CVL:SNUMber <SerialNo>

This command defines the serial number of the mixer for which the conversion loss table is to be used. This setting is checked against the current mixer setting before the table can be assigned to the range.

Before this command can be performed, the conversion loss table must be selected (see [SENSe:]CORRection:CVL:SELect on page 427).

This command is only available with option B21 (External Mixer) installed.

Parameters: <serialno></serialno>	Serial number with a maximum of 16 characters
Example:	CORR:CVL:SEL 'LOSS_TAB_4' Selects the conversion loss table. CORR:CVL:MIX '123.4567'
Manual operation:	See " Mixer S/N " on page 141

# 15.6.2 Output

•	DC Power	428
•	Signal Source	437
	Miscellaneous Output	

#### 15.6.2.1 DC Power

SOURce:CURRent:AUX:LIMit:HIGH?	
SOURce:CURRent:CONTrol <i>:LIMit:HIGH?</i>	
SOURce:CURRent:POWer <i>:LIMit:HIGH</i>	
SOURce:CURRent:SEQuence:RESult?	
SOURce:POWer:SEQuence:RESult?	430
SOURce:VOLTage:AUX:LEVel:AMPLitude	430
SOURce:VOLTage:AUX:LEVel:LIMit:HIGH	
SOURce:VOLTage:AUX:LEVel:LIMit:LOW	
SOURce:VOLTage:AUX:LEVel[:STATe]	
SOURce:VOLTage:CHANnel:COUPling	
SOURce:VOLTage:CONTrol <i>:LEVel:AMPLitude</i>	
SOURce:VOLTage:CONTrol <i>:LEVel:LIMit:HIGH</i>	
SOURce:VOLTage:CONTrol <i>:LEVel:LIMit:LOW</i>	
SOURce:VOLTage:CONTrol <i>:LEVel[:STATe]</i>	
SOURce:VOLTage:POWer <i>:LEVel:AMPLitude</i>	
SOURce:VOLTage:POWer <i>:LEVel:LIMit:HIGH</i>	
SOURce:VOLTage:POWer <i>:LEVel:LIMit:LOW</i>	
SOURce:VOLTage:POWer <i>:LEVel:MODE</i>	
SOURce:VOLTage:POWer <i>:LEVel[:STATe]</i>	
SOURce:VOLTage:POWer <i>:LIMit:HIGH</i>	
SOURce:VOLTage:SEQuence:RESult?	
SOURce:VOLTage[:STATe]	

## SOURce:CURRent:AUX:LIMit:HIGH?

This command returns the maximum current of the  $\ensuremath{\mathsf{V}_{\mathsf{aux}}}$  connector.

Return values: <current></current>	<numeric value=""> The return value is always 0.1 A.</numeric>
Example:	<pre>//Query maximum current SOUR:CURR:AUX:LIM:HIGH? returns 0.1</pre>
Usage:	Query only

## SOURce:CURRent:CONTrol<i>:LIMit:HIGH?

This command returns the maximum current of the  $V_{\text{tune}}\xspace$  connector.

Suffix:	
<i></i>	1n
	irrelevant
Return values:	
<current></current>	<numeric value=""></numeric>
	The return value is always 0.02 A.
	Default unit: A
Example:	<pre>//Query maximum current SOUR:CURR:CONT:LIM:HIGH? returns 0.02</pre>
Usage:	Query only

#### SOURce:CURRent:POWer<i>:LIMit:HIGH <Current>

This command defines the maximum current of the  $V_{\text{supply}}$  connector.

Prerequisites for this command

 V<sub>supply</sub> is controlled in terms of voltage (SOURce:VOLTage:POWer<i>:LEVel: MODE).

#### Suffix:

<i></i>	1n irrelevant	
Parameters:		
<current></current>	<numeric value=""></numeric>	
	Range: *RST: Default unit:	2
Example:		aximum output current of 1000 mA :POW:LIM:HIGH 1

### SOURce:CURRent:SEQuence:RESult?

This command queries the actually measured current on the DC power sources.

Prerequisites for this command

• Turn on the DC power source (SOURce:VOLTage[:STATe]).

Example:	//Query current on all DC power sources	
	SOUR:CURR:SEQ:RES?	
	would return, e.g.	
	0.000000, -0.100000, -0.020000	
Usage:	Query only	
Manual operation:	See "Reading the actual output levels" on page 168	

#### SOURce:POWer:SEQuence:RESult?

This command queries the actually measured power (U\*I) on the DC power sources.

Prerequisites for this command

• Turn on DC power sources (SOURce:VOLTage[:STATe]).

Example:	<pre>//Query power output by the DC power sources SOUR:POW:SEQ:RES? would return, e.g. 0.000000, 1.000000, 0.200000</pre>	
Usage:	Query only	
Manual operation:	See "Reading the actual output levels" on page 168	

## SOURce:VOLTage:AUX:LEVel:AMPLitude <Voltage>

This command defines the output voltage for the  $V_{aux}$  source.

Parameters: <voltage></voltage>	<numeric value=""></numeric>	
	Range: -10 to 10 *RST: 0 Default unit: V	
Example:	//Defines an output voltage of 1 V on the V <sub>aux</sub> source SOUR:VOLT:AUX:LEV:AMPL 1	
Manual operation:	See "Defining the output level" on page 167	

#### SOURce:VOLTage:AUX:LEVel:LIMit:HIGH <Voltage>

This command defines the maximum voltage that may be supplied by the  $V_{\text{aux}}$  source.

Parameters: <voltage></voltage>	<numeric value=""></numeric>	
	Range: -10 to 10 *RST: 0 Default unit: V	
Example:	<pre>//Define a maximum voltage of 5 V SOUR:VOLT:AUX:LEV:LIM:HIGH 5</pre>	
Manual operation:	See "Defining the output level" on page 167	

#### SOURce:VOLTage:AUX:LEVel:LIMit:LOW <Voltage>

This command defines the minimum voltage that may be supplied by the  $V_{\text{aux}}$  source.

Parameters: <voltage></voltage>	<numeric value=""></numeric>	
	Range: *RST: Default unit:	0
Example:	<pre>//Define a minimum voltage of -5 V SOUR:VOLT:AUX:LEV:LIM:LOW -5</pre>	
Manual operation:	See "Definir	ng the output level" on page 167

## SOURce:VOLTage:AUX:LEVel[:STATe] <State>

This command turns the auxiliary voltage source  $\left(V_{aux}\right)$  on and off.

Note that DC power is actually supplied only if you additionally activate the outputs in general.

Prerequisites for this command

• Turn on DC power sources (SOURce:VOLTage[:STATe]).

Parameters: <state></state>	ON   OFF   1   0 *RST: OFF
Example:	//Turns on the V <sub>aux</sub> source. SOUR:VOLT:AUX:LEV ON
Manual operation:	See "Turning the output on and off" on page 167

#### SOURce:VOLTage:CHANnel:COUPling <State>

This command couples or decouples the DC power configuration across measurement channels.

Parameters: <state></state>	<b>ON   1</b> DC power configuration is the same across all measurement channels.
	OFF   0 DC power configuration is different for each measurement chan- nel. *RST: ON
Example:	//Use a different DC power setup for each active measurement channel SOUR:VOLT:CHAN:COUP OFF
Manual operation:	See "Coupling the output configuration across measurement channels" on page 166

## SOURce:VOLTage:CONTrol<i>:LEVel:AMPLitude <Voltage>

This command defines the output voltage for the  $V_{\text{tune}}\xspace$  source.

Suffix: <i></i>	1n irrelevant	
	Intelevant	
Parameters:		
<voltage></voltage>	<numeric value=""></numeric>	
	Range: -10 to 28 *RST: 0 Default unit: V	
Example:	//Defines an output voltage of 1 V on the $V_{tune}$ source <code>SOUR:VOLT:CONT:LEV:AMPL 1</code>	
Manual operation:	See "Defining the output level" on page 167	

## SOURce:VOLTage:CONTrol<i>:LEVel:LIMit:HIGH <Voltage>

This command defines the maximum voltage that may be supplied by the  $\mathrm{V}_{\mathrm{tune}}$  source.

Suffix: <i></i>	1n irrelevant	
Parameters:		
<voltage></voltage>	<numeric value=""></numeric>	
	Range:-10 to 28*RST:0Default unit:V	
Example:	<pre>//Defines a maximum voltage of 5 V SOUR:VOLT:CONT:LEV:LIM:HIGH 5</pre>	
Manual operation:	See "Defining the output level" on page 167	

## SOURce:VOLTage:CONTrol<i>:LEVel:LIMit:LOW <Voltage>

This command defines the minimum voltage that may be supplied by the  $\rm V_{tune}$  source.

Suffix: <j></j>	irrelevant
Parameters: <voltage></voltage>	<numeric value=""> Range: -10 to 28 *RST: 0 Default unit: V</numeric>
Example:	<pre>//Define a minimum voltage of -5 V SOUR:VOLT:CONT:LEV:LIM:LOW -5</pre>

Manual operation: See "Defining the output level" on page 167

## SOURce:VOLTage:CONTrol<i>:LEVel[:STATe] <State>

This command turns the tuning voltage source ( $V_{tune}$ ) on and off.

Note that DC power is actually supplied only if you additionally activate the outputs in general.

Prerequisites for this command

• Turn on DC power sources (SOURce: VOLTage[:STATe]).

#### Suffix:

<j>

1n	
irrelevant	

Parameters:		
<state></state>	ON   OFF   1   0	
	*RST: OFF	
Example:	//Turn on the $V_{tune}$ voltage source	
	SOUR:VOLT:CONT:LEV ON	

Manual operation: See "Turning the output on and off" on page 167

# SOURce:VOLTage:POWer<i>:LEVel:AMPLitude <Voltage/Current>

This command defines the output voltage for the  $V_{supply}$  source.

Suffix: <j></j>	1n irrelevant	
Parameters: <voltage current=""></voltage>	<numeric value=""> The type of value depends on whether you control the output in terms of current or voltage (SOURCe:VOLTage:POWer<i>: LEVel:MODE). When you control it in terms of voltage, the value is a voltage (V). When you control it in terms of current, the value is the cur- rent (A). Range: 0 to 16 V or 2000 mA *RST: 0 V or 2000 mA Default unit: V or A</i></numeric>	
Example:	//Define an output voltage of 1 V on the V <sub>supply</sub> source SOUR:VOLT:POW:LEV:AMPL 1	
Manual operation:	See "Defining the output level" on page 167	

# SOURce:VOLTage:POWer<i>:LEVel:LIMit:HIGH <Voltage/Current>

This command defines the maximum voltage that may be supplied by the  $V_{\mbox{supply}}$ source.

## Suffix:

<j>

1..n irrelevant

# Daramotore

Parameters:		
<voltage current=""></voltage>	<numeric value=""></numeric>	
	The type of value depends on whether you control the output in terms of current or voltage (SOURce:VOLTage:POWer <i>: LEVel:MODE). When you control it in terms of voltage, the value is a voltage (V). When you control it in terms of current, the value is the current (A).</i>	
	Range:         0 to 16 V or 2000 mA           *RST:         16 V or 2000 mA           Default unit:         V or A	
Example:	//Define a maximum current of 1000 mA SOUR:VOLT:POW:LEV:LIM:HIGH 1000MA	
Manual operation:	See "Defining the output level" on page 167	

# SOURce:VOLTage:POWer<i>:LEVel:LIMit:LOW <Voltage/Current>

This command defines the minimum voltage that may be supplied by the  $V_{\text{supply}}$  source.

Suffix: <i></i>	irrelevant	
Parameters: <voltage current=""></voltage>	<numeric value=""> The type of value depends on whether you control the output in terms of current or voltage (SOURce:VOLTage:POWer<i>: LEVel:MODE). When you control it in terms of voltage, the value is a voltage (V). When you control it in terms of current, the value is the cur- rent (A). Range: 0 to 16 V or 2000 mA *RST: 16 V or 2000 mA</i></numeric>	
Example:	//Define a minimum current of 500 mA SOUR:VOLT:POW:LEV:LIM:LOW 500MA	
Manual operation:	See "Defining the output level" on page 167	

## SOURce:VOLTage:POWer<i>:LEVel:MODE <Mode>

This command selects whether you want to control the output in terms of current or voltage.

Suffix:			
<i></i>	1n		
	irrelevant		
Parameters:			
<mode></mode>	CURRent		
	Control the output in terms of current. <b>VOLTage</b>		
	Controls the output in terms of voltage.		
	*RST: VOLTage		
Example:	//Control the V <sub>supply</sub> source in terms of voltages		
-	SOUR:VOLT:POW:LEV:MODE VOLT		
Manual operation:	See "Selecting the output type (Vsupply only)" on page 167		

# SOURce:VOLTage:POWer<i>:LEVel[:STATe] <State>

This command turns the supply voltage source (V<sub>supply</sub>) on and off.

Note that DC power is actually supplied only if you additionally activate the outputs in general.

Prerequisites for this command

• Turn on DC power sources (SOURce:VOLTage[:STATe]).

Suffix:	1n	
<i></i>	irrelevant	
Parameters:	ON   OFF   1   0	
<state></state>	*RST: ON	
Example:	//Turn on the V <sub>supply</sub> voltage source SOUR:VOLT:POW:LEV ON	
Manual operation:	See "Turning the output on and off" on page 167	

# SOURce:VOLTage:POWer<i>:LIMit:HIGH <Voltage>

This command defines the maximum current or voltage that may be supplied by the  $V_{\mbox{supply}}$  source.

Suffix:

<j>

1..n irrelevant

Parameters: <voltage></voltage>	<numeric value=""></numeric>		
	The type of value depends on whether you control the output in terms of current or voltage (SOURce:VOLTage:POWer <i>: LEVel:MODE). When you control it in terms of voltage, the value is a current</i>		
	(A). When you control it in terms of current, the value is a voltage (V).		
	Range:         0 to 16 V or 2000 mA           *RST:         16 V or 2000 mA           Default unit:         V or A		
Example:	<pre>//Define a maximum output of 1000 mA SOUR:VOLT:POW:LEV:MODE VOLT SOUR:VOLT:POW:LIM:HIGH 1000MA</pre>		
Manual operation:	See "Defining the output level" on page 167		

#### SOURce:VOLTage:SEQuence:RESult?

This command queries the actually measured voltages on the DC power sources.

Prerequisites for this command

• Turn on DC power sources (SOURce: VOLTage[:STATe]).

Example:	<pre>//Query voltages of the DC power sources SOUR:VOLT:SEQ:RES? would return, e.g. 0.000000, -10.000000, -10.000000</pre>	
Usage:	Query only	
Manual operation:	See "Reading the actual output levels" on page 168	

## SOURce:VOLTage[:STATe] <State>

This command turns DC power sources on and off in general.

When you turn off the DC power sources, no power is supplied even when you have turned on one of the sources individually with one of the following commands.

- SOURce:VOLTage:AUX:LEVel[:STATe]
- SOURce:VOLTage:CONTrol<i>:LEVel[:STATe]
- SOURce:VOLTage:POWer<i>:LEVel[:STATe]

Note that you can turn on the global power supply if at least one of the individual supplies has been turned on.

Parameters:

<State>

ON | 1 DC power sources are ready for use.

	OFF   0 DC power sources are turned off. *RST: OFF	
Example:	//Turn on signal source SOUR:VOLT:AUX:LEV ON SOUR:VOLT ON	
Manual operation:	See "Turning the DC output on and off" on page 166	

# 15.6.2.2 Signal Source

SOURce:GENerator:DUTBypass	437
SOURce:GENerator:CHANnel:COUPling	437
SOURce:GENerator:FREQuency	438
SOURce:GENerator:FREQuency:STEP	438
SOURce:GENerator:LEVel	438
SOURce:GENerator:MODulation	
SOURce:GENerator:PULSe:PERiod	
SOURce:GENerator:PULSe:TRIGger:OUTPut	
SOURce:GENerator:PULSe:WIDTh	440
SOURce:GENerator[:STATe]	

## SOURce:GENerator:DUTBypass <State>

This command turns the DUT bypass on and off.

When you turn on the bypass, the application measures the noise characteristics of the R&S FSWP.

The DUT bypass is available with the optional Signal Source hardware component.

Parameters: <state></state>	ON   OFF   1   0	
	*RST:	OFF
Example:	//Turn on DUT bypass SOUR:GEN:DUTB ON	
Manual operation:	See "Bypassing the DUT" on page 170	

## SOURce:GENerator:CHANnel:COUPling <State>

ON | 1

This command couples or decouples the signal source configuration across measurement channels.

## Parameters:

<State>

Signal source configuration is the same across all measurement channels.

	<b>OFF   0</b> Signal source configuration is different for each measurement channel.	
	*RST:	ON
Example:		ame signal source configuration across all channels : CHAN: COUP ON
Manual operation:		ling the output configuration across measurement on page 166

# SOURce:GENerator:FREQuency <Frequency>

This command defines the frequency of the signal that is generated by the signal source.

Parameters: <frequency></frequency>	<numeric value=""> Default unit: Hz</numeric>
Example:	See SOURce:GENerator[:STATe] on page 440.
Manual operation:	See "Signal source frequency" on page 170

# SOURce:GENerator:FREQuency:STEP <Stepsize>

This command defines the frequency stepsize of the signal generated by the optional signal source.

Parameters:	
-------------	--

<stepsize></stepsize>	1 mHz   1 Hz   1 kHz   1 MHz   1 GHz	
	*RST: 1 MHz	
	Default unit: Hz	
Example:	//Define signal source stepsize SOUR:GEN:FREQ:STEP 1KHZ	
Manual operation:	See "Signal source frequency" on page 170	

## SOURce:GENerator:LEVel <Level>

This command defines the level of the signal that is generated by the signal source.

## Parameters:

<level></level>	<numeric value=""></numeric>
	Default unit: dBm
Example:	See SOURce:GENerator[:STATe] on page 440.
Manual operation:	See "Signal source level" on page 170

### SOURce:GENerator:MODulation <State>

This command turns internal pulse modulation for pulsed measurements on and off.

Parameters: <state></state>	<ul> <li>ON   1</li> <li>A pulse is output on the signal source.</li> <li>You can define the pulse characteristics with</li> <li>SOURCe: GENerator: PULSe: PERiod</li> <li>SOURce: GENerator: PULSe: WIDTh</li> <li>OFF   0</li> <li>A sine signal is output on the signal source.</li> <li>*RST: OFF</li> </ul>
Example:	<pre>//Generate and output a pulse on the signal source SOUR:GEN:MOD ON SOUR:GEN:PULS:PER 10MS SOUR:GEN:PULS:WIDT 1MS</pre>
Manual operation:	See "Pulse modulation state" on page 170

## SOURce:GENerator:PULSe:PERiod <PulsePeriod>

This command defines the pulse period (distance between two consecutive pulses) of the pulse that is generated.

Prerequisites for this command

- Optional pulsed phase noise measurements.
- Turn on signal source (SOURce: GENerator [: STATe]).
- Turn on pulse modulation (SOURce:GENerator:MODulation).

#### **Parameters:**

<pulseperiod></pulseperiod>	<numeric value=""></numeric>	
	*RST: 10 ms	
	Default unit: s	
Example:	//Generate a pulse with a length of 15 ms and a pulse period of	
	50 ms.	
	SOUR:GEN ON	
	SOUR:GEN:MOD ON	
	SOUR:GEN:PULS:WIDT 15MS	
	SOUR:GEN:PULS:PER 50MS	
Manual operation:	See "Pulse characteristics" on page 171	

# SOURce:GENerator:PULSe:TRIGger:OUTPut <SignalLevel>

This command selects the signal type provided at the trigger output connector.

\_

The signal can be used, for example, to control an external pulse modulator.

Parameters:	
<signallevel></signallevel>	HIGH
	Provides a high active pulse at the trigger output.
	Note that the signal is provided even if internal pulse modulation has been turned off.
	You can define the pulse characteristics with
	•SOURce:GENerator:PULSe:WIDTh
	•SOURce:GENerator:PULSe:PERiod
	LOW
	Provides a low active pulse at the trigger output. Note that the signal is provided even if internal pulse modulation has been turned off.
	<b>OFF   0</b> Provides no signal at the trigger output. *RST: OFF
Example:	//Generate a low pulse at the trigger output SOUR:GENPULS:TRIG:OUTP LOW
Manual operation:	See "Pulse characteristics" on page 171

# SOURce:GENerator:PULSe:WIDTh <PulseWidth>

This command defines the length of the pulse that is generated.

Prerequisites for this command

- Optional pulsed phase noise measurements.
- Turn on signal source (SOURce: GENerator [: STATe]).
- Turn on pulse modulation (SOURce:GENerator:MODulation).

#### Parameters:

<pulsewidth></pulsewidth>	<numeric value=""></numeric>	
	*RST: 1 ms Default unit: s	
Example:	//Generate a pulse with a length of 15 ms SOUR:GEN ON SOUR:GEN:MOD ON SOUR:GEN:PULS:WIDT 15MS	
Manual operation:	See "Pulse characteristics" on page 171	

## SOURce:GENerator[:STATe] <State>

This command turns the optional signal source output on and off.

When you turn on the signal source, the R&S FSWP generates a signal with the frequency and level defined with SOURce:GENerator:FREQuency and SOURce: GENerator:LEVel.

Parameters: <state></state>	ON   OFF   1   0 *RST: OFF
Example:	<pre>//Turn on the signal source output SOUR:GEN:FREQ 100MHZ //Generate a signal at 100 MHz and a level of -10 dBm. SOUR:GEN:LEV -10 SOUR:GEN ON</pre>
Manual operation:	See "Signal source state" on page 170

#### 15.6.2.3 Miscellaneous Output

#### DIAGnostic:SERVice:NSOurce <State>

This command turns the 28 V supply of the BNC connector labeled [noise source control] on the R&S FSWP on and off.

#### **Parameters:**

<state></state>	ON   OFF   0   1	
	OFF   0 Switches the function off	
	<b>ON   1</b> Switches the function on	
Example:	DIAG:SERV:NSO ON	
Manual operation:	See "Noise Source Control" on page 172	

# 15.6.3 Remote Commands to Configure User Ports

INPut <ip>:UPORt:STATe</ip>	441
INPut <ip>:UPORt[:VALue]</ip>	
OUTPut <up>:UPORt:STATe</up>	
OUTPut <up>:UPORt[:VALue]</up>	

#### INPut<ip>:UPORt:STATe <State>

This command toggles the control lines of the user ports for the **AUX PORT** connector. This 9-pole SUB-D male connector is located on the rear panel of the R&S FSWP.

See the R&S FSWP Getting Started manual for details.

Suffix:

<ip>

1 | 2 irrelevant

Parameters: <State>

ON | 1 User port is switched to INPut OFF | 0 User port is switched to OUTPut \*RST: 1

## INPut<ip>:UPORt[:VALue]

This command queries the control lines of the user ports.

For details see OUTPut<up>:UPORt[:VALue] on page 442.

#### Suffix:

<ip>

1 | 2 irrelevant

# Return values:

<level></level>	bit values ir	n hexadecimal format
	TTL type vo	oltage levels (max. 5V)
	Range:	#B00000000 to #B00111111
Example:	INP:UPOR	?
	//Result	: #B00100100
	Pins 5 and	7 are active.

## OUTPut<up>:UPORt:STATe <State>

This command toggles the control lines of the user ports for the **AUX PORT** connector. This 9-pole SUB-D male connector is located on the rear panel of the R&S FSWP.

Suffix: <up></up>	irrelevant
Parameters:	
<state></state>	ON   OFF   0   1
	<b>OFF   0</b> User port is switched to INPut
	<b>ON   1</b> User port is switched to OUTPut
Example:	OUTP:UPOR:STAT ON

## OUTPut<up>:UPORt[:VALue] <Value>

This command sets the control lines of the user ports.

The assignment of the pin numbers to the bits is as follows:

Bit	7	6	5	4	3	2	1	0
Pin	N/A	N/A	5	3	4	7	6	2

~ ~~

Bits 7 and 6 are not assigned to pins and must always be 0.

The user port is written to with the given binary pattern.

If the user port is programmed to input instead of output (see INPut<ip>:UPORt: STATe on page 441), the output value is temporarily stored.

Suffix: <up></up>	irrelevant
<b>Parameters:</b> <value></value>	bit values in hexadecimal format
	TTL type voltage levels (max. 5V) Range: #B00000000 to #B00111111
Example:	OUTP:UPOR #B00100100 Sets pins 5 and 7 to 5 V.

# **15.6.4 Remote Commands to Configure Level Characteristics**

Functions to configure level characteristics described elsewhere:

- INPut<ip>:COUPling
- [SENSe:]POWer:RLEVel:MODE

DISPlay[:WINDow <n>]:TRACe<t>:X[:SCALe]</t></n>	443
DISPlay[:WINDow <n>]:TRACe<t>:X[:SCALe]:AUTO</t></n>	444
DISPlay[:WINDow <n>]:TRACe<t>:X:SPACing?</t></n>	.444
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]</t></n>	445
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:AUTO</t></n>	445
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:RLEVel</t></n>	.446
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:RLEVel:LOWer</t></n>	446
DISPlay[:WINDow <n>]:TRACe<t>:Y:UNIT</t></n>	446
INPut<1 2>:ATTenuation	
INPut<1 2>:ATTenuation:AUTO	447
[SENSe:]ADJust:CONFigure:LEVel:THReshold	
[SENSe:]POWer:RLEVel?	
[SENSe:]POWer:RLEVel:OFFSet	

## DISPlay[:WINDow<n>]:TRACe<t>:X[:SCALe] <Range>

This command defines the display range of the x-axis.

Prerequisites for this command

• Turn off automatic scaling of the x-axis (DISPlay[:WINDow<n>]:TRACe<t>: X[:SCALe]:AUTO).

Suffix:

<n>

<t>

1..n Window 1..n irrelevant

Parameters: <range></range>	Default unit: Depending on the selected diagram
Example:	//Define a value range of 100 MHz. DISP:TRAC:X:AUTO OFF DISP:TRAC:X 100 MHz

# DISPlay[:WINDow<n>]:TRACe<t>:X[:SCALe]:AUTO <Mode>

This command turns automatic configuration of the horizontal axis on and off.

Suffix: <n></n>	1n Window
<t></t>	1n irrelevant
Parameters:	
<mode></mode>	ON   1 Scales the x-axis after each measurement. OFF   0 Allows you to define the scale manually. ONCE Scales the x-axis once. The scale remains the same for subsequent measurements. *RST: ON
Example:	//Select manual scaling of the x-axis. DISP:TRAC:X:AUTO OFF

# DISPlay[:WINDow<n>]:TRACe<t>:X:SPACing?

This command queries the scale of the x-axis in any measurement window.

Suffix: <n></n>	1n Window
<t></t>	1n irrelevant
Return values: <spacing></spacing>	<b>LINear</b> X-axis has a linear scale. <b>LOGarithmic</b> X-axis has a logarithmic scale.
Example:	//Query scale of the x-axis in the second measurement window DISP:WIND2:TRAC:X:SPAC?
Usage:	Query only

# DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe] <Range>

This command defines the value range displayed on the y-axis.

Prerequisites for this command

• Turn off automatic scaling of the y-axis (DISPlay[:WINDow<n>]:TRACe<t>: Y[:SCALe]:AUTO).

# Suffix:

<n></n>	1n Window
<t></t>	1n irrelevant
Parameters: <range></range>	<numeric value=""> Default unit: Depending on the selected diagram</numeric>
Example:	<pre>//Define a value range of 100 dB. DISP:TRAC:Y:AUTO OFF DISP:TRAC:Y 100</pre>
Manual operation:	See "Scaling the y-axis" on page 145

# DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:AUTO <Mode>

This command turns automatic scaling of the y-axis in graphical result displays on and off.

Suffix:	
<n></n>	1n Window
<t></t>	1n irrelevant
Parameters:	
<mode></mode>	<b>ON   1</b> Scales the y-axis after each measurement.
	OFF   0 Allows you to define the scale manually.
	ONCE
	Scales the y-axis once. The scale remains the same for subsequent measurements. *RST: ON
Example:	//Select manual scaling of the y-axis. DISP:TRAC:Y:AUTO OFF
Manual operation:	See "Scaling the y-axis" on page 145 See "Scaling the y-axis of the phase diagram" on page 189

## DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel <Level>

This command defines the maximum level displayed on the y-axis.

Prerequisites for this command

• Turn off automatic scaling of the y-axis (DISPlay[:WINDow<n>]:TRACe<t>: Y[:SCALe]:AUTO).

## Suffix:

<n></n>	1n Window
<t></t>	1n irrelevant
Parameters:	
<level></level>	<numeric value=""></numeric>
	Default unit: Depending on the selected diagram
Example:	//Define maximum level on the y-axis DISP:TRAC:Y:RLEV -20
Manual operation:	See "Scaling the y-axis" on page 145

## DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel:LOWer <Level>

This command defines the minimum level displayed on the y-axis.

Prerequisites for this command

• Turn off automatic scaling of the y-axis (DISPlay[:WINDow<n>]:TRACe<t>: Y[:SCALe]:AUTO).

## Suffix:

<n></n>	1n Window
<t></t>	1n irrelevant
Parameters:	
<level></level>	<numeric value=""></numeric>
	Default unit: Depending on the selected diagram
Example:	<pre>//Query minimum level on the y-axis DISP:TRAC:Y:RLEV:LOW? would return, e.g135</pre>
Manual operation:	See "Scaling the y-axis" on page 145

# DISPlay[:WINDow<n>]:TRACe<t>:Y:UNIT <Unit>

This command selects the unit of the y-axis.

Available for baseband noise measurements.

Suffix:	
<n></n>	1n Window
<t></t>	1n irrelevant
Parameters:	
<unit></unit>	DBM_hz   DBV_hz   DBUV_hz   HZ   DEG   RAD   V_SQRT_HZ *RST: DBM_hz
Example:	//Display the baseband noise results in the unit dBV/Hz. DISP:TRAC:Y:UNIT DBV
Manual operation:	See "Selecting the unit of the y-axis" on page 146

# INPut<1|2>:ATTenuation < Attenuation>

This command defines the RF attenuation for the RF input.

Prerequisites for this command

• Turn off automatic attenuation configuration (INPut<1|2>:ATTenuation:AUTO).

# Suffix:

<1 2>	1 2 irrelevant
Parameters: <a>Attenuation&gt;</a>	<numeric value=""> (integer only)</numeric>
	Range: See data sheet Increment: 5 Default unit: dB
Example:	//Defines an attenuation of 10 dB INP:ATT:AUTO OFF INP:ATT 10
Manual operation:	See "Attenuating the signal" on page 144

## INPut<1|2>:ATTenuation:AUTO <State>

This command turns automatic configuration of the attenuation on and off.

<b>Suffix:</b> <1 2>	1 2 irrelevant
Parameters:	
<state></state>	ON   1

**ON | 1** Automatically defines the ideal attenuation based on the current signal level.

	<b>OFF   0</b> Allows you to define the attenuation manually with INPut<1 2>:ATTenuation
	*RST: ON
Example:	//Turn on automatic configuration of the attenuation INP:ATT:AUTO ON
Manual operation:	See "Attenuating the signal" on page 144

# [SENSe:]ADJust:CONFigure:LEVel:THReshold <Level>

This command defines the threshold of the signal search.

Prerequisites for this command

• Turn on the automatic signal search with [SENSe:]ADJust:CONFigure: FREQuency:AUTosearch[:STATe]

# Parameters:

<level></level>	<numeric value=""></numeric>
	Default unit: dBm
Example:	<pre>//Define a threshold of -10 dBm ADJ:CONF:LEV:THR -10</pre>

Manual operation: See "Searching for the signal level" on page 144

## [SENSe:]POWer:RLEVel?

This command queries the currently measured signal level.

Return values: <level></level>	<numeric value=""> Default unit: dBm</numeric>
Example:	//Query signal level POW:RLEV? would return, e.g. -9.28192
Usage:	Query only
Manual operation:	See "Searching for the signal level" on page 144

# [SENSe:]POWer:RLEVel:OFFSet <Offset>

This command defines an arithmetic level offset. The offset is applied to the signal level.

The level offset takes external attenuation or gain into account.

Parameters: <offset></offset>	<numeric th="" va<=""><th>alue&gt;</th></numeric>	alue>
	Range: *RST: Default unit:	-100 to 200 0 dB
Example:	<pre>//Define a le POW:RLEV:</pre>	offset of 20 dB
Manual operation:	See "Shifting	g the level" on page 144

# 15.6.5 Remote Commands to Configure the Frequency

[SENSe:]ADJust:CONFigure:FREQuency:AUTosearch[:STATe]	
[SENSe:]ADJust:CONFigure:FREQuency:COUNt	449
[SENSe:]ADJust:CONFigure:FREQuency:LIMit:HIGH	450
[SENSe:]ADJust:CONFigure:FREQuency:LIMit:LOW	450
[SENSe:]FILTer:LPASs:FREQuency:MANual	451
[SENSe:]FILTer:LPASs[:STATe]	451
[SENSe:]FREQuency:CENTer	
[SENSe:]FREQuency:STARt	
[SENSe:]FREQuency:STOP	453
[SENSe:]POWer:RLEVel:MODE	454
[SENSe:]SWEep:CAPTure:RANGe	454

# [SENSe:]ADJust:CONFigure:FREQuency:AUTosearch[:STATe] <State>

This command turns the automatic (carrier) frequency search on and off.

When you turn of the automatic frequency search, you can define the signal frequency with [SENSe:]FREQuency:CENTer.

Parameters: <state></state>	ON   OFF   1   0
Example:	//Define a signal frequency of 100 MHz ADJ:CONF:FREQ:AUT OFF FREQ:CENT 100MHZ
Manual operation:	See "Searching for a signal" on page 148

# [SENSe:]ADJust:CONFigure:FREQuency:COUNt <State>

This command turns verification of the signal frequency on and off.

# Prerequisites for this command

• Turn off automatic signal search ([SENSe:]ADJust:CONFigure:FREQuency: AUTosearch[:STATe]).

Parameters: <state></state>	<b>OFF   0</b> Turns off the frequency counter and measures the frequency you have entered without verifiying it.	
	<b>ON   1</b> Turns on the have entere	e frequency counter and verfifies the frequency you ed.
	*RST:	OFF (automatic signal search is on)
Example:	ADJ:CONF: ADJ:CONF:	e frequency counter :FREQ:AUT OFF :FREQ:COUN OFF F 93.423MHZ
Manual operation:	See "Searc	hing for a signal" on page 148

## [SENSe:]ADJust:CONFigure:FREQuency:LIMit:HIGH <Frequency>

This command defines the upper limit of the frequency search range.

Prerequisites for this command

• Turn on the automatic signal search with [SENSe:]ADJust:CONFigure: FREQuency:AUTosearch[:STATe]

#### **Parameters:**

<frequency></frequency>	<numeric value=""></numeric>		
	Range: *RST: Default unit:	See data sheet 8 GHz Hz	
Example:	ADJ:CONF:	equency search range from 10 MHz to 500 MHz FREQ:LIM:LOW 10MHZ FREQ:LIM:HIGH 500MHZ	
Manual operation:	See "Search	ning for a signal" on page 148	

## [SENSe:]ADJust:CONFigure:FREQuency:LIMit:LOW <Frequency>

This command defines the lower limit of the frequency search range.

Prerequisites for this command

• Turn on the automatic signal search with [SENSe:]ADJust:CONFigure: FREQuency:AUTosearch[:STATe]

Parameters: <frequency></frequency>	<numeric value=""></numeric>	
	Range:See data sheet*RST:1 MHzDefault unit:Hz	
Example:	<pre>//Define a frequency search range from 10 MHz to 500 MHz ADJ:CONF:FREQ:LIM:LOW 10MHZ ADJ:CONF:FREQ:LIM:UPP 500MHZ</pre>	
Manual operation:	See "Searching for a signal" on page 148	

#### [SENSe:]FILTer:LPASs:FREQuency:MANual <Frequency>

This command defines the cutoff frequency of the low pass filter you can use to measure small carrier frequencies.

Prerequisites for this command

• Turn on low pass filter ([SENSe:]FILTer:LPASs[:STATe]).

#### Parameters:

<frequency></frequency>	<numeric value=""></numeric>	
	*RST: 1 MHz	
	Default unit: Hz	
Example:	//Configure low pass filter	
	FILT:LPAS ON	
	FILT:LPAS:FREQ:MAN 500KHZ	
Manual operation:	See "Low signal frequencies" on page 150 See "Low signal levels" on page 150	

### [SENSe:]FILTer:LPASs[:STATe] <State>

This command turns a low pass filter for measurements on small carrier frequencies on and off.

Effects of using thelow pass filter:

- Auto search feature is turned off ([SENSe:]ADJust:CONFigure:FREQuency: AUTosearch[:STATe]).
- Signal count is turned off ([SENSe:]ADJust:CONFigure:FREQuency:COUNt).
- The stop offset is limited to 30 % of the filter cut-off frequency ([SENSe: ] FREQuency:STOP).
- DC coupling should be used for measurements on carrier frequencies below 1 MHz (INPut<ip>: COUPling).

Parameters: <state></state>	ON   OFF   1   0 When you turn on the filter, you can define a cutoff frequency with [SENSe:]FILTer:LPASs:FREQuency:MANual. *RST: OFF
Example:	//Turn on low pass filter FILT:LPAS ON
Manual operation:	See "Low signal frequencies" on page 150 See "Low signal levels" on page 150

## [SENSe:]FREQuency:CENTer <Frequency>

## CW, pulsed and VCO measurements:

This command defines or queries (in case of automatic frequency search) the current signal frequency.

#### Transient measurement:

This command defines the center frequency of the transient measurement.

Parameters: <frequency></frequency>	<numeric value=""></numeric>
	Default unit: Hz
Example:	//Query signal frequency FREQ:CENT?
Example:	//Define center frequency FREQ:CENT 1GHZ
Manual operation:	See "Defining the signal frequency" on page 147 See "Searching for a signal" on page 148 See "Defining the frequency range of the measurement" on page 183

[SENSe:]FREQuency:STARt <Frequency>

#### CW, pulsed and VCO measurements:

This command defines the start frequency offset of the measurement range.

#### Transient measurement:

This command defines the start frequency of the transient measurement.

## Frequency stability measurement:

The start frequency offset is coupled to the stop time of the frequency stability measurement ([SENSe:]TIME:STOP).

If you change the start frequency offset, the stop time is adjusted accordingly. For example, 1 mHz corresponds to 1000 s.

Parameters: <frequency></frequency>	Offset frequencies in half decade steps. Range: See data sheet	
	*RST: 1 kHz Default unit: Hz	
Example:	//Define a start offset of 10 kHz FREQ:STAR 10KHZ	
Example:	<pre>//Define a span of 500 MHz from 500 MHz to 1 GHz FREQ:STAR 500MHZ FREQ:STOP 1GHZ</pre>	
Manual operation:	See "Defining the measurement range" on page 149 See "Defining the frequency range of the measurement" on page 183	

# [SENSe:]FREQuency:STOP <Frequency>

# CW, pulsed and VCO measurements:

This command defines the stop frequency offset of the measurement range.

#### **Transient measurement:**

This command defines the stop frequency of the transient measurement.

#### Frequency stability measurement:

The stop frequency offset is coupled to the start time of the frequency stability measurement ([SENSe:]TIME:STARt).

If you change the stop frequency offset, the start time is adjusted accordingly. For example, 1 MHz corresponds to 1 ms.

## **Parameters:**

<frequency></frequency>	Offset frequ	Offset frequencies in half decade steps.		
	Range: *RST: Default unit:			
Example:	//Define a stop offset of 10 MHz FREQ:STOP 10MHZ			
Example:	<pre>//Define a span of 500 MHz from 500 MHz to 1 GHz FREQ:STAR 500MHZ FREQ:STOP 1GHZ</pre>			
Manual operation:	See "Defining the measurement range" on page 149 See "Defining the frequency range of the measurement" on page 183			

#### [SENSe:]POWer:RLEVel:MODE <Level>

This command selects the level measurement mode.

## **Parameters:**

<level></level>	<b>HIGH</b> Use this mode to measure normal signal levels.
	<b>LOW</b> Use this mode to measure low signal levels. When you select this mode, apply a low pass filter and define its characteristics with:
	•[SENSe:]FILTer:LPASs[:STATe]
	•[SENSe:]FILTer:LPASs:FREQuency:MANual
	*RST: HIGH
Example:	//Measure low level signal POW:RLEV:MODE LOW
Manual operation:	See "Low signal levels" on page 150

#### [SENSe:]SWEep:CAPTure:RANGe <CaptureRange>

This command selects the signal capture range.

## Parameters:

## <CaptureRange> NORMal Normal capture range for stable DUTs or DUTs whose frequency drifts slowly over a short distance. WIDE Wide capture range for DUTs whose frequency drifts quickly and over big distances. R40Mhz This setting is designed to work with carriers swept in -40 MHz to +40 MHz around the center frequency. Additional spurs and restrictions of the measurement accuracy are possible for CW signals. For specifics of the measurement accuracy, refer to the data sheet. \*RST: **NORMal** Example: //Select a wide signal capture range SWE:CAPT:RANG WIDE Manual operation: See "Capture Range" on page 149

# 15.6.6 Phase Noise Measurement Configuration

•	Noise Configuration	455
	Residual Calculation Configuration	
•	Spot Noise Configuration	
	Spur Display	
	Spot Noise Configuration	

# 15.6.6.1 Noise Configuration

Remote commands to configure the measurement range described elsewhere:

- [SENSe:] FREQuency:STARt on page 452
- [SENSe:] FREQuency:STOP on page 453

DISPlay:XGINdicator[:STATe]	
[SENSe:]LIST:BWIDth[:RESolution]:RATio	
[SENSe:]LIST:RANGe <r>:BWIDth[:RESolution]</r>	456
[SENSe:]LIST:RANGe <r>:FREQuency:STARt?</r>	
[SENSe:]LIST:RANGe <r>:FREQuency:STOP?</r>	457
[SENSe:]LIST:RANGe <r>:XCOunt</r>	
[SENSe:]LIST:BWIDth[:RESolution]:USMall	
[SENSe:]SWEep:COUNt	458
[SENSe:]SWEep:FORWard	458
[SENSe:]SWEep:FSEGment	
[SENSe:]SWEep:MODE	
[SENSe:]SWEep:TIME	
[SENSe:]SWEep:XFACtor	
[SENSe:]SWEep:XOPTimize[:STATe]	
[SENSe:]SWEep:XOPTimize:THReshold	460
[SENSe:]TIME:STARt	
[SENSe:]TIME:STOP	

## DISPlay:XGINdicator[:STATe] <State>

This command turns the cross-correlation gain indicator (gray area in the Noise Spectrum result display) on and off.

#### **Parameters:**

<state></state>	ON   OFF   1   0	
	*RST: ON	
Example:	//Remove the gray area from the diagram area. DISP:XGIN OFF	
Manual operation:	See "Turning the display of the cross-correlation gain indicator on and off" on page 156	

## [SENSe:]LIST:BWIDth[:RESolution]:RATio <Percentage>

This command defines the factor that the resolution bandwidth applied to each half decade is based on.

## More information

Parameters:				
<percentage></percentage>	<numeric value=""></numeric>			
	Range:	0.1	to	30
	*RST:	10		
	Default unit:	PC	Г	

Example: //Define an RBW factor of 3 % LIST:BWID:RAT 3

Manual operation: See "Defining the resolution bandwidth" on page 154

# [SENSe:]LIST:RANGe<r>:BWIDth[:RESolution] <BandWidth>

This command defines the resolution bandwidth applied in a half decade.

The application of the command depends on the half decade configuration mode ([SENSe:]SWEep:MODE):

- Automatic mode: The RBW can only be queried, because it is calculated based on an RBW factor.
- Manual mode: The RBW can be defined directly as an absolute value.

#### Suffix:

<r></r>	1n Half decade
Parameters: <bandwidth></bandwidth>	<numeric value=""> *RST: Automatic configuration mode is on. Default unit: Hz</numeric>
Example:	//Define an RBW of 1 kHz for the fifth half decade SWE:MODE MAN LIST:RANG5:BWID 1KHZ
Manual operation:	See "Defining the resolution bandwidth" on page 154 See "Working with the half decade configuration table" on page 157

## [SENSe:]LIST:RANGe<r>:FREQuency:STARt?

This command queries the start frequency offset of a half decade.

Suffix: <r></r>	1n Half decade
Return values: <frequency></frequency>	<numeric value=""> Default unit: Hz</numeric>
Example:	<pre>//Query start frequency for fifth half decade LIST:RANG5:FREQ:STAR? would return, e.g. 100000</pre>
Usage:	Query only
Manual operation:	See "Working with the half decade configuration table" on page 157

## [SENSe:]LIST:RANGe<r>:FREQuency:STOP?

This command queries the stop frequency offset of a half decade.

Suffix: <r></r>	1n Half decade
Return values: <frequency></frequency>	<numeric value=""> Default unit: Hz</numeric>
Example:	<pre>//Query stop frequency offset for fifth half decade LIST:RANG5:FREQ:STOP? would return, e.g. 300000</pre>
Usage:	Query only
Manual operation:	See "Working with the half decade configuration table" on page 157

# [SENSe:]LIST:RANGe<r>:XCOunt <Count>

This command defines the number of cross-correlation operations done in a half decade.

The application of the command depends on the half decade configuration mode ([SENSe:]SWEep:MODE):

- Automatic mode: The number of cross-correlations can only be queried, because it is calculated based on an RBW factor.
- Manual mode: The number of cross-correlations can be defined directly as an absolute value.

#### Suffix:

#### <r>

1..n Half decade

Parameters: <count></count>	<numeric value=""> (integer only) *RST: Automatic configuration mode is on. Default unit:</numeric>
Example:	<pre>//Define 50 cross-correlation operations for the fifth half decade SWE:MODE MAN LIST:RANG5:XC0 50</pre>
Manual operation:	See "Defining cross-correlation parameters" on page 155 See "Working with the half decade configuration table" on page 157

## [SENSe:]LIST:BWIDth[:RESolution]:USMall <State>

Provides functionality to enable ultra-small resolution bandwidths (RBW) for the current measurement.

**Parameters:** <State> ON | OFF | 1 | 0 \*RST: OFF Example: SENS:LIST:BWID:RES:USM ON Manual operation: See "Ultra-Small RBWs" on page 154

## [SENSe:]SWEep:COUNt <SweepCount>

This command defines the number of measurements that the application uses to average traces.

In continuous measurement mode, the application calculates the moving average over the average count.

In single measurement mode, the application stops the measurement and calculates the average after the average count has been reached.

## **Parameters:**

<sweepcount></sweepcount>	When you set a sweep count of 0 or 1, the R&S FSWP performs one single measurement in single measurement mode. In continuous measurement mode, if the sweep count is set to 0, a moving average over 10 measurements is performed.		
	Range: *RST:	0 to 200000 0	
Example:	INIT: CON Switches to INIT; *WAI	mber of measurements to 64. I OFF single measurement mode.	
Manual operation:	See " Swee	p/Average Count " on page 157	

#### [SENSe:]SWEep:FORWard <SweepForward>

This command selects the sweep direction.

Parameters:			
<sweepforward></sweepforward>	ON		
	Measure	ement in forward direction	۱.
	OFF		
	Measure	ement in reverse direction	۱.
	*RST:	OFF	

Example: //Sweep in forward direction SWE:FORW ON

Manual operation: See "Selecting the sweep direction" on page 157

## [SENSe:]SWEep:FSEGment

This command stops a measurement in any given half decade and resumes the measurement of the next half decade.

Usage: Event

Manual operation: See "Defining cross-correlation parameters" on page 155

## [SENSe:]SWEep:MODE <Mode>

This command selects the configuration mode of the half decade table.

Parameters: <mode></mode>	<pre>MANual Manual mode: allows you to select a custom resolution band- width and number of cross-correlations for each half decade. • Define the RBW for a half decade with [SENSe:]LIST: RANGe<r>: BWIDth[:RESolution]. • Define the number of cross-correlations for a half decade with [SENSe:]LIST:RANGe<r>: XCOunt.</r></r></pre>
	<pre>NORMal Automatic mode: the application selects the resolution band- width and number of cross-correlations based on the RBW and XCORR factors. • Define the RBW factor with [SENSe:]LIST:BWIDth[: RESolution]:RATio. • Define the XCORR factor with [SENSe:]SWEep:XFACtor. *RST: NORMal</pre>
Example:	<pre>//Automatically select RBW and XCORR based on an RBW fac- tor of 5 % and an XCORR factor of 1.5. SWE:MODE NORM LIST:BWID:RAT 5 LIST:RANG5:XCO 1.5</pre>
Manual operation:	See "Defining the resolution bandwidth" on page 154 See "Defining cross-correlation parameters" on page 155 See "Working with the half decade configuration table" on page 157

#### [SENSe:]SWEep:TIME <Time>

# CW, pulsed and VCO measurements (query only):

This command queries the estimated measurement time.

#### Transient measurement:

This command defines the measurement time

#### **Parameters:**

<time></time>	<numeric value=""> Default unit: s</numeric>
Example:	//Query measurement time SWE:TIME? would return, e.g. 0.050432
Example:	//Define measurement time SWE:TIME 2S
Manual operation:	See "Estimating the measurement time" on page 153 See "Defining the measurement time" on page 187

#### [SENSe:]SWEep:XFACtor <Factor>

This command defines the cross-correlation factor (XCORR factor) that defines the cross-correlation operations in each half decade.

Parameters:		
<factor></factor>	<numeric value=""></numeric>	
	Range: 1	
Example:	//Define an XCORR factor of 10	
	SWE:XFAC 10	
Manual operation:	See "Defining cross-correlation parameters" on page 155	

## [SENSe:]SWEep:XOPTimize[:STATe] <State>

This command turns optimization of the cross-correlation operations on and off.

#### Parameters:

<state></state>	ON   OFF   1   0 *RST: ON
Example:	SWE:XOPT OFF Turns off optimization (always performs the full number of opera- tions).
Manual operation:	See "Defining cross-correlation parameters" on page 155

## [SENSe:]SWEep:XOPTimize:THReshold <Threshold>

This command defines the threshold for the cross-correlation optimization feature.

When the threshold (distance between measured values and gain indicator) is reached in any given half decade, the measurement in that half decade stops and resumes to measure the next one. Prerequisites for this command

• Turn on XCORR optimization ([SENSe:]SWEep:XOPTimize[:STATe] on page 460).

#### **Parameters:**

Manual operation:	See "Defining cross-correlation parameters" on page 155
Example:	//Define a threshold of 15 dB SWE:XOPT:THR 15
	Default unit: dB
<threshold></threshold>	<numeric value=""></numeric>

#### [SENSe:]TIME:STARt <Tau>

This command defines the start time for the frequency stability measurements.

Effects of this command

 The start time is coupled to the stop frequency offset of the measurement range of the phase noise measurement ([SENSe:]FREQuency:STOP).
 If you change the start time, the R&S FSWP adjusts the stop frequency offset accordingly. For example, 1 MHz stop offset corresponds to 1 µs.

#### **Parameters:**

<tau></tau>	<numeric value=""> *RST: 1 ms Default unit: s</numeric>
Example:	//Define start time for frequency stability measurement TIME:STAR 1US
Manual operation:	See "Defining the measurement range" on page 149

#### [SENSe:]TIME:STOP <Tau>

This command defines the stop time for the frequency stability measurements.

Effects of this command

 The stop time is coupled to the start frequency offset of the measurement range of the phase noise measurement ([SENSe:]FREQuency:STARt).
 If you change the stop time, the R&S FSWP adjusts the start frequency offset accordingly. For example, 1 mHz start offset corresponds to 1000 s.

# Parameters:

<tau></tau>	<numeric value=""></numeric>	
	*RST: 1 ms Default unit: s	
Example:	//Define stop time for frequency stability measurement TIME:STAR 1000S	
Manual operation:	See "Defining the measurement range" on page 149	

## 15.6.6.2 Residual Calculation Configuration

For manual operation, see Chapter 10.5.4, "Integrated Measurement Configuration", on page 158.

CALCulate <n>[:RANGe<j>]:EVALuation:STARt</j></n>	
CALCulate <n>[:RANGe<j>]:EVALuation:STOP</j></n>	
CALCulate <n>[:RANGe<j>]:EVALuation:TRACe</j></n>	463
CALCulate <n>[:RANGe<j>]:EVALuation[:STATe]</j></n>	463
CALCulate <n>[:RANGe<j>]:EVALuation:WEIGhting</j></n>	464
[SENSe:]CORRection:WEIGhting:COMMent	
[SENSe:]CORRection:WEIGhting:DATA	
[SENSe:]CORRection:WEIGhting:DELete	464
[SENSe:]CORRection:WEIGhting:NAME	
[SENSe:]CORRection:WEIGhting:SELect.	

## CALCulate<n>[:RANGe<j>]:EVALuation:STARt <Frequency>

This command defines the start frequency of a custom integration range for residual effects calculation.

Prerequisites for this command

• Turn off integration over the complete measurement range (CALCulate<n>[: RANGe<j>]:EVALuation[:STATe]).

Suffix:			
<n></n>	Window		
<j></j>	Integration	range	
Parameters: <frequency></frequency>	<numeric th="" va<=""><th colspan="2">numeric value&gt;</th></numeric>	numeric value>	
	Range: *RST: Default unit	Depends on the measurement range. 1 MHz : Hz	
Example:	<pre>See CALCulate<n>[:RANGe<j>]:EVALuation[:STATe].</j></n></pre>		
Manual operation:	See "Defining the integration range" on page 159		

## CALCulate<n>[:RANGe<j>]:EVALuation:STOP <Frequency>

This command defines the stop frequency of a custom integration range for residual effects calculation.

Prerequisites for this command

• Turn off integration over the complete measurement range (CALCulate<n>[: RANGe<j>]:EVALuation[:STATe]).

#### Suffix:

<n></n>	Window

<j> Integration range

Parameters: <frequency></frequency>	<numeric value=""></numeric>	
	Range: *RST: Default unit:	Depends on the measurement range. 1 kHz Hz
Example:	See CALCu	<pre>late<n>[:RANGe<j>]:EVALuation[:STATe].</j></n></pre>
Manual operation:	See "Definir	ng the integration range" on page 159

# CALCulate<n>[:RANGe<j>]:EVALuation:TRACe <Trace1>

This command selects the trace for calculation of residual effects.

Suffix: <n></n>	Window	
<j></j>	Integration range	
Parameters: <trace1></trace1>	TRACE1     TRACE6Selects the trace. You can select a trace that is inactive, but for residual effect calculation, it must be active.NONETurns off residual calculation for the respective range.*RST:Depends on the range.	
Example:	//Use trace 1 as the data source for range 2 CALC:RANG2:EVAL:TRAC TRACE1	
Manual operation:	See "Selecting the trace for residual calculations" on page 159	

# CALCulate<n>[:RANGe<j>]:EVALuation[:STATe] <State>

This command turns integration of the entire measurement range for residual calculations on and off.

Suffix: <n></n>	Window
<j></j>	Integration range
Parameters: <state></state>	ON   1 Integrates over the complete measurement range. OFF   0 Integrates over a custom measurement range.
Example:	<pre>//Define an integration range from 1 kHz to 3 kHz in range 2 CALC:RANG2:EVAL OFF CALC:RANG2:EVAL:STAR 100000 CALC:RANG2:EVAL:STOP 300000</pre>
Manual operation:	See "Defining the integration range" on page 159

#### CALCulate<n>[:RANGe<j>]:EVALuation:WEIGhting <Name>

This command selects a weighting filter whose values are applied to the calculation of residual effects.

Suffix: <n></n>	Window	
<j></j>	Integration range	
Setting parameters: <name></name>	String containing the name of the filter. *RST: NONE	
Example:	<pre>//Apply a weighting filter to the residual calculations in integration range 1 CALC:RANG1:EVAL:WEIG 'A FILTER'</pre>	
Manual operation:	See "Applying weighting filters" on page 159	

## [SENSe:]CORRection:WEIGhting:COMMent <Name>

This command defines a comment for a weighting filter whose values are applied to the calculation of residual effects.

#### Setting parameters:

<name></name>	String containing the comment.
Example:	See [SENSe:]CORRection:WEIGhting:NAME on page 465.
Manual operation:	See "Designing weighting filters" on page 160

#### [SENSe:]CORRection:WEIGhting:DATA {<freq>, <level>}...

This command defines the shape of the weighting filter whose values are applied to the calculation of residual effects.

The shape of the weighting filter is defined by two or more pairs of frequency and level values.

#### **Parameters:**

<freq></freq>	<numeric value=""> Default unit: Hz</numeric>
<level></level>	<numeric value=""> Default unit: dB</numeric>
Example:	See [SENSe:]CORRection:WEIGhting:NAME on page 465.
Manual operation:	See "Designing weighting filters" on page 160

## [SENSe:]CORRection:WEIGhting:DELete

This command deletes the currently selected weighting filter.

### Prerequisites for this command

• Select a weighting filter with [SENSe:]CORRection:WEIGhting:SELect on page 465.

Example:	//Delete the currently selected weighting filter CORR:WEIG:DEL
Usage:	Event
Manual operation:	See "Managing weighting filters" on page 159

## [SENSe:]CORRection:WEIGhting:NAME <Name>

This command defines the name for a weighting filter whose values are applied to the calculation of residual effects.

#### Setting parameters:

<Name> String containing the name of the filter.

Example:	//Create a weighting filter called "FILTER", with a comment and a few data points		
	CORR:WEIG:NAME 'FILTER'		
	CORR:WEIG:COMM 'Here's an example for a		
	filter.'		
	CORR:WEIG:DATA 10MHZ,ODB,20MHZ,2DB,40MHZ,5DB		
Manual operation:	See "Designing weighting filters" on page 160		

## [SENSe:]CORRection:WEIGhting:SELect <Name>

This command selects a weighting filter whose values are applied to the calculation of residual effects.

Setting parameters: <name></name>	String containing the name of the weighting filter.
Example:	<pre>//Select a weighting filter called "filter" CORR:WEIG:SEL 'FILTER'</pre>
Manual operation:	See "Managing weighting filters" on page 159

# 15.6.6.3 Spot Noise Configuration

CALCulate <n>:SNOise<s>:AOFF</s></n>	466
CALCulate <n>:SNOise<s>:STATe</s></n>	466
CALCulate <n>:SNOise<s>:X</s></n>	466
CALCulate <n>:SNOise<s>[:TRACe<t>]:DECades:X?</t></s></n>	467
CALCulate <n>:SNOise<s>[:TRACe<t>]:DECades:Y?</t></s></n>	467
CALCulate <n>:SNOise<s>[:TRACe<t>]:DECades[:STATe]</t></s></n>	468
CALCulate <n>:SNOise<s>[:TRACe<t>]:USERdefined[:STATe]</t></s></n>	468
CALCulate <n>:SNOise<s>[:TRACe<t>]:Y?</t></s></n>	.468
DISPlay:SNINfo[:STATe]	469
DISPlay:SNINfo:TRACe	.469

#### CALCulate<n>:SNOise<s>:AOFF

This command turns all spot noise information off (custom and 10<sup>x</sup> information). It also turns user defined spot noise markers off.

In the Spot Noise vs Tune measurement, the command also selects "Trace Mode" = "Blank" for all traces.

Suffix: <n></n>	irrelevant
<s></s>	irrelevant
Example:	//Turn off all spot noise information CALC:SNO:AOFF
Usage:	Event

## CALCulate<n>:SNOise<s>:STATe <State>

This command turns a custom spot noise position on and off.

In the Spot Noise vs Tune measurement, turning off a spot noise position also selects "Trace Mode" = "Blank" for the corresponding spot noise trace. Turning on a spot noise position selects the trace mode that was selected last for the corresponding spot noise trace.

Suffix: <n></n>	irrelevant
<\$>	Spot noise marker
Parameters: <state></state>	ON   OFF   1   0 *RST: All ON
Example:	<pre>See CALCulate<n>:SNOise<s>[:TRACe<t>]: USERdefined[:STATe].</t></s></n></pre>

## CALCulate<n>:SNOise<s>:X <Frequency>...

This command defines the horizontal position of a custom spot noise position. The position is changed in all windows.

Suffix:	
<n></n>	irrelevant
<s></s>	Spot noise marker
Parameters:	
<frequency></frequency>	For minimum and maximum offsets, refer to the data sheet. The default values are the decade edges (1 kHz, 10 kHz etc.)
	Default unit: Hz

Example: See CALCulate<n>:SNOise<s>[:TRACe<t>]: USERdefined[:STATe].

## CALCulate<n>:SNOise<s>[:TRACe<t>]:DECades:X?

This command queries the horizontal position of the  $10^{x}$  offset frequency spot noise information.

C	uf	fiv	
J	uı		

<n></n>	irrelevant
<\$>	irrelevant
<t></t>	irrelevant
<b>Return values:</b> <frequency></frequency>	List of offset frequencies, one for each 10 <sup>x</sup> spot noise position. The number of return values depends on the measurement range. Default unit: Hz
Example:	//Query spot noise information CALC:SNO:DEC:X? would return, e.g. 1000,100000,1000000
Usage:	Query only
Manual operation:	See "Spot Noise" on page 116

# CALCulate<n>:SNOise<s>[:TRACe<t>]:DECades:Y?

This command queries the vertical position of the  $10^{x}$  offset frequency spot noise information.

Suffix: <n> <s> <t></t></s></n>	Window irrelevant Trace
<b>Return values:</b> <level></level>	List of phase noise level values, one for each 10 <sup>×</sup> spot noise positions. The number of return values depends on the measurement range. Default unit: dBc/Hz
Example:	<pre>//Query spot noise information CALC:SNO:DEC:Y? would return, e.g. -152.560974121094, -136.443389892578, -145.932891845703, -152.560974121094</pre>

Usage: Query only

Manual operation: See "Spot Noise" on page 116

## CALCulate<n>:SNOise<s>[:TRACe<t>]:DECades[:STATe] <State>

This command turns the spot noise calculation on every  $10^{x}$  offset frequency on and off.

Suffix: <n></n>	irrelevant
<s></s>	irrelevant
<t></t>	irrelevant
Parameters: <state></state>	ON   OFF   1   0 *RST: ON
Example:	//Turn on the spot noise calculation for all decade edges. CALC:SNO:DEC ON

# CALCulate<n>:SNOise<s>[:TRACe<t>]:USERdefined[:STATe] <State>

This command turns calculation of custom spot noise positions on and off

Suffix: <n> <s></s></n>	irrelevant irrelevant
<t></t>	irrelevant
Parameters: <state></state>	ON   OFF   1   0 *RST: OFF
Example:	<pre>//Turn on user defined spot noise positions CALC:SNO:USER ON //Turn on custom spot noise marker 2 at an offset of 500 kHz CALC:SNO3:STAT ON CALC:SNO3:X 500000 //Query spot noise CALC:SNO3:Y? would return, e.g. -90.1154022217</pre>

# CALCulate<n>:SNOise<s>[:TRACe<t>]:Y?

This command queries the level measured for a custom spot noise position.

Prerequisites for this command

• Use custom spot noise positions (CALCulate<n>:SNOise<s>[:TRACe<t>]: USERdefined[:STATe]).

Suffix: <n></n>	Window
<s></s>	Spot noise marker
<t></t>	Trace
<b>Return values:</b> <level></level>	Phase noise level at the spot noise position. Default unit: dBc/Hz
Example:	<pre>See CALCulate<n>:SNOise<s>[:TRACe<t>]: USERdefined[:STATe].</t></s></n></pre>
Usage:	Query only
Manual operation:	See "Spot Noise" on page 116

### DISPlay:SNINfo[:STATe] <State>

This command turns the display of spot noise information in the diagram area on and off.

Param	eters:
-------	--------

<state></state>	ON   OFF   1   0	
	*RST: ON	
Example:	//Display the spot noise information DISP:SNIN ON	
Manual operation:	See "Displaying spot noise information" on page 161	

### DISPlay:SNINfo:TRACe <Trace>

This command selects the trace for which spot noise information is evaluated.

#### Parameters:

<trace></trace>	Range: *RST:	1 to 6 1
Example:	//Evaluate s	spot noise for trace 2.
Manual operation:	See "Displa	aying spot noise information" on page 161

### 15.6.6.4 Spur Display

DISPlay[:WINDow <n>]:TRACe<t>:SPURs:SUPPress</t></n>	
DISPlay[:WINDow <n>]:TRACe<t>:SPURs:THReshold</t></n>	
[SENSe:]SPURs:SORT	471

#### **Common Measurement Settings**

[SENSe:]SPURs:WEIGhting	471
[SENSe:]SPURs:FILTer:MODE	471
[SENSe:]SPURs:FILTer:HARMonics	472
[SENSe:]SPURs:FILTer:RANGe	
[SENSe:]SPURs:FILTer:NAME?	
[SENSe:]SPURs:FILTer:OFFSet	
[SENSe:]SPURs:FILTer:CLEar	473
[SENSe:]SPURs:FILTer:SAVE	
[SENSe:]SPURs:FILTer:LOAD	473
[SENSe:]SPURs:COLor	473

#### DISPlay[:WINDow<n>]:TRACe<t>:SPURs:SUPPress <State>

This command turns spur removal for a specific trace on and off.

When you turn on spur removal, you can define a level threshold with DISPlay[:WINDow < n >]:TRACe < t >: SPURs:THReshold.

In the Spot Noise vs Tune measurement, you can only remove spurs over all traces. Use [SENSe:]SPURS:SUPPress in that case.

Suffix:	
<n></n>	1n Window
<t></t>	1n Trace
Parameters:	
<state></state>	ON   OFF   1   0
	*RST: OFF
Example:	<pre>See DISPlay[:WINDow<n>]:TRACe<t>:SMOothing[: STATe].</t></n></pre>
Manual operation:	See "Hiding spurs" on page 162

#### DISPlay[:WINDow<n>]:TRACe<t>:SPURs:THReshold <Threshold>

This command defines a level threshold for spur removal.

Prerequisites for this command

Turn on spur removal (DISPlay[:WINDow<n>]:TRACe<t>:SPURs:THReshold
 ).

In the Spot Noise vs Tune measurement, you can only define a threshold that applies to all traces. Use [SENSe:]SPURS:THReshold in that case.

Suffix:

<n> 1..n Window <t> 1..n Trace

Parameters: <threshold></threshold>	<numeric value=""> *RST: 0 Default unit: dB</numeric>
Example:	See DISPlay[:WINDow <n>]:TRACe<t>:SMOothing[: STATe].</t></n>
Manual operation:	See "Hiding spurs" on page 162

### [SENSe:]SPURs:SORT <Order>

This command selects the sort order of the spurs in the spur list.

Parameters: <order></order>	<b>POWer</b> Sorts spurs according to their power.
	OFFSet Sorts spurs according to their offset from the carrier. *RST: POWer
Example:	//Select spur sort order SPUR:SORT POW
Manual operation:	See "Sorting spurs" on page 163

#### [SENSe:]SPURs:WEIGhting <Weightingfilter>

This command selects a spurious weighting filter.

Setting parameters: </br><Weightingfilter>

Example:	//Select no defined weighting filter		
	SENS:SPUR:WEIG NONE		

Manual operation: See "Applying a spurious weighting filter" on page 163

#### [SENSe:]SPURs:FILTer:MODE <Mode>

This command defines the spurious filter mode

Parameters:

<Mode>

OFF | SUPPress | SHOW OFF

No spurious filter is applied.

#### SUPPress

The spurs in the spurious filter are removed from the spurious list, the diagram and dependent calculations.

#### SHOW

	Only the spurs in the spurious filter are displayed in the spurious list, the diagram and dependent calculations.
Example:	SENS:SPUR:FILT:MOD OFF
Manual operation:	See "Filtering spurs" on page 163

#### [SENSe:]SPURs:FILTer:HARMonics <State>

This command defines if harmonics are included in the spurious filter.

Parameters: <state></state>	
Example:	<pre>//Exclude harmonics from the spurious filter SENS:SPUR:FILT:HARM OFF</pre>
Manual operation:	See "Filtering spurs" on page 163

### [SENSe:]SPURs:FILTer:RANGe <Range>

This command defines the range of the spurious filter. The range is defined as a multiple of the resolution bandwidth.

#### **Parameters:**

<Range>

**Example:** SENS:SPUR:FILT:RANG 1

Manual operation: See "Filtering spurs" on page 163

### [SENSe:]SPURs:FILTer:NAME?

This command returns the name of the selected spurious filter.

Example:	SENS:SPUR:FILT:NAME?
Usage:	Query only
Manual operation:	See "Filtering spurs" on page 163

#### [SENSe:]SPURs:FILTer:OFFSet <OffsetValues>...

This command creates a new offset table with defined frequency ranges.

Parameters: <offsetvalues></offsetvalues>	Default unit: Hz	
Example:	SENS:SPUR:FILT:OFFS 1.3e3, 2.6e5	5
Manual operation:	See "Filtering spurs" on page 163	

#### [SENSe:]SPURs:FILTer:CLEar

This command clears the currently selected spurious filter.

**Example:** SENS:SPUR:FILT:CLE

Usage: Event

Manual operation: See "Filtering spurs" on page 163

### [SENSe:]SPURs:FILTer:SAVE <Filename>

This command saves the spurious filter configuration to a file. The spurious filter name can be defined.

Location of filter files: C:\R S\instr\SpuriousFilter\

Setting parameters:

<Filename>

**Example:** SENS:SPUR:FILT:SAVE "MyFile"

Usage: Setting only

Manual operation: See "Filtering spurs" on page 163

#### [SENSe:]SPURs:FILTer:LOAD <Filename>

This command loads an existing spurious filter configuration from a file.

Location of filter files: C:\R S\instr\SpuriousFilter\

Setting parameters:

<Filename>

Example: SENS:SPUR:FILT:LOAD "MyFile"

Usage: Setting only

Manual operation: See "Filtering spurs" on page 163

#### [SENSe:]SPURs:COLor < Color>

Provides functionality to enable an automatic shift of the color of the displayed spurious lines.

#### **Parameters:**

Example: SENS:SPUR:COL TRAC

Manual operation: See "Defining the spurious color" on page 163

### 15.6.7 Pulsed Phase Noise Configuration

[SENSe:]SWEep:EGATe:HOLDoff	474
[SENSe:]SWEep:EGATe:LENGth	
[SENSe:]SWEep:EGATe:LEVel	
[SENSe:]SWEep:EGATe:TYPE	
[SENSe:]SWEep:PULSe:DETection	
[SENSe:]SWEep:PULSe:GATE	476
[SENSe:]SWEep:PULSe:PRI	476

#### [SENSe:]SWEep:EGATe:HOLDoff <GateDelay>

This command defines the gate delay time.

Prerequisites for this command

- Optional pulsed phase noise measurement application.
- Turn off automatic pulse detection ([SENSe:]SWEep:PULSe:DETection).

#### **Parameters:**

<gatedelay></gatedelay>	<numeric value=""></numeric>	
	*RST: Default unit	Automatic pulse detection is on.
Example:	SWE:PULS:	<b>ate delay of 10 μs</b> . DET MAN HOLD 10us
Manual operation:	See "Definii	ng the shape of the gate" on page 175

#### [SENSe:]SWEep:EGATe:LENGth <Length>

This command defines the gate length.

Prerequisites for this command

- Optional pulsed phase noise measurement application.
- Turn off automatic pulse detection ([SENSe:]SWEep:PULSe:DETection).
- Select gate mode "Edge" ([SENSe:]SWEep:EGATe:TYPE).

# Parameters: <Length>

Example:

<numeric value>
\*RST: Automatic pulse detection is on.

Default unit: s
//Define a gate length of 200 $\mu$ s

SWE:PULS:DET MAN SWE:EGAT:TYPE EDGE SWE:EGAT:LENG 200us

Manual operation: See "Defining the shape of the gate" on page 175

#### [SENSe:]SWEep:EGATe:LEVel <Level>

This command defines the gate level.

Prerequisites for this command

- Optional pulsed phase noise measurement application.
- Turn off automatic pulse detection ([SENSe:]SWEep:PULSe:DETection).

#### Parameters:

<level></level>	<numeric value=""></numeric>	
	*RST: Automatic pulse detection is on. Default unit: dBm	
Example:	//Define a gate level of -10 dBm SWE:PULS:DET MAN SWE:EGAT:LEV -10	
Manual operation:	See "Defining the shape of the gate" on page 175	

### [SENSe:]SWEep:EGATe:TYPE <GateType>

This command selects the gate type.

Prerequisites for this command

• Optional pulsed phase noise measurement application.

#### Parameters:

<gatetype></gatetype>	<b>EDGE</b> The gate opens when the gate level has been exceeded and closes when the time defined by the gate length has elapsed.
	<b>LEVel</b> The gate opens when the gate level has been exceeded and closes when the signal level again falls below the gate level.
	<b>OFF</b> The gate is off.
Example:	//Select gate type SWE:EGAT:TYPE EDGE
Manual operation:	See "Selecting the gate type" on page 175

### [SENSe:]SWEep:PULSe:DETection <Mode>

This command selects the pulse detection mode.

#### Prerequisites for this command

• Optional pulsed phase noise measurement application.

#### Parameters:

#### <Mode>

Initiates an automatic detection of the pulse characteristics with a subsequent configuration of the gate before you start a measurement.

#### MANual

AUTO

Allows you to manually configure the pulse measurement characteristics.

### ONCE

Initiates an immediate, automatic detection of the pulse characteristics with a subsequent configuration of the gate.

Example: //Configure the measurement based on the detected pulse SWE:PULS:DET AUTO

Manual operation: See "Selecting the pulse detection mode" on page 174

### [SENSe:]SWEep:PULSe:GATE <PulseGate>

This command selects the source for the pulse gate.

#### **Parameters:**

<pulsegate></pulsegate>	<pre>EXTernal Selects an external pulse gate connected to trigger 1 connector. Prerequisites: • Turn off trigger 1 output (SOURce:GENerator:PULSe: TRIGger:OUTPut). Effects: • Pulse modulation is turned off (SOURce:GENerator: MODulation).</pre>
	IFPower Selects the internal IF power pulse gate. *RST: IFPower
Example:	//Select internal pulse gate SWE:PULS:GATE IFP
Manual operation:	See "Selecting the source for pulse gating" on page 174

#### [SENSe:]SWEep:PULSe:PRI <Time>

This command defines the pulse repetition interval.

Prerequisites for this command

- Optional pulsed phase noise measurement application.
- Turn off automatic pulse detection ([SENSe:]SWEep:PULSe:DETection).

Parameters: <time></time>	<numeric value=""> *RST: Automatic pulse detection is on. Default unit: s</numeric>
Example:	//Define a pulse repetition interval of 500 µs. SWE:PULS:DET MAN SWE:PULS:PRI 500US
Manual operation:	See "Defining the pulse repetition interval" on page 175

# 15.6.8 VCO Characterization Configuration

Sweep Configuration......477

### 15.6.8.1 Sweep Configuration

CONFigure:VCO:FIX:SOURce	477
CONFigure:VCO:SWEep:DELay:INITial	
CONFigure:VCO:SWEep:DELay[:POINt]	
CONFigure:VCO:SWEep:FCOunter:RESolution	
CONFigure:VCO:SWEep:POINts	
CONFigure:VCO:SWEep:SOURce	
CONFigure:VCO:SWEep:STARt	479
CONFigure:VCO:SWEep:STOP	

### CONFigure:VCO:FIX:SOURce < PowerSource>

This command selects the DC source that is considered in the Current / Voltage result display.

### Parameters:

<powersource></powersource>	<b>VAUX</b> Selects the V <sub>aux</sub> connector.
	<b>VSUPply</b> Selects the V <sub>supply</sub> connector.
	VTUNe Selects the V <sub>tune</sub> connector. *RST: VSUPply
Example:	//Measure the V <sub>aux</sub> connector in the Supply Current / Voltage result. CONF:VCO:FIX:SOUR VAUX

### CONFigure:VCO:SWEep:DELay:INITial <SettlingTime>

This command defines an initial delay time that allows the DUT to settle before the first measurement starts.

Parameters: <pre><settlingtime></settlingtime></pre>	<numeric th="" va<=""><th>lue&gt;</th></numeric>	lue>
	*RST: Default unit:	10 ms s
Example:		nitial settling time of a 100 ms. SWE:DEL:INIT 100MS
Manual operation:	See "Definin	g the settling time" on page 179

### CONFigure:VCO:SWEep:DELay[:POINt] <SettlingTime>

This command defines a delay time that allows the DUT to settle when a new tuning voltage is applied and before the measurement starts.

Parameters: <pre><settlingtime></settlingtime></pre>	<numeric th="" va<=""><th>lue&gt;</th></numeric>	lue>
	*RST: Default unit:	10 ms s
Example:		ettling time of a 100 ms. SWE:DEL 100MS
Manual operation:	See "Definir	ng the settling time" on page 179

### CONFigure:VCO:SWEep:FCOunter:RESolution <Frequency>

This command selects the frequency resolution for VCO characterization.

Parameters: <frequency></frequency>	<numeric value=""></numeric>
	If you select a frequency resolution that is not supported, the next available frequency resolution is selected.
	*RST: 1 kHz Default unit: Hz
Example:	//Select a frequency resolution of 100 Hz. CONF:VCO:SWE:FCO 100HZ
Manual operation:	See "Selecting the frequency resolution" on page 179

#### CONFigure:VCO:SWEep:POINts <MeasPoints>

This command defines the number of measurement points for the VCO measurement.

Parameters: <measpoints></measpoints>	<numeric value=""> (integer only) *RST: 10</numeric>
Example:	See CONFigure:VCO:SWEep:SOURce.
Manual operation:	See "Defining the sweep range" on page 178

### CONFigure:VCO:SWEep:SOURce < PowerSource>

This command selects the source (connector) which tunes the VCO.

### **Parameters:**

<powersource></powersource>	<b>VAUX</b> Selects the $V_{aux}$ connector as the sweep source.
	<b>VSUPly</b> Selects the V <sub>supply</sub> connector as the sweep source.
	<b>VTUNe</b> Selects the $V_{tune}$ connector as the sweep source.
Example:	<pre>//Select the V<sub>supply</sub> connector as the tuning source CONF:VCO:SWE:SOUR VSUP //Select the type of output at the V<sub>supply</sub> connector SOUR:VOLT:POW:LEV:MODE VOLT //Configure a tuning range with 10 measurement points CONF:VCO:SWE:STAR 0V CONF:VCO:SWE:STAR 0V CONF:VCO:SWE:STOP 5V CONF:VCO:SWE:POIN 10 //Turn on the output of the tuning signal. SOUR:VOLT:POW:LEV ON</pre>

### CONFigure:VCO:SWEep:STARt <Value>

This command defines the start value of the tuning range.

### Parameters:

i ulumotors.	
<value></value>	<numeric value=""></numeric>
	The unit depends on whether you tune the VCO with a voltage or current (see CONFigure:VCO:SWEep:SOURce).
	*RST: 0 Default unit: V or A
Example:	See CONFigure: VCO: SWEep: SOURce.
Manual operation:	See "Defining the sweep range" on page 178

### CONFigure:VCO:SWEep:STOP <Value>

This command defines the stop value of the tuning range.

Parameters: <value></value>	
	The unit depends on whether you tune the VCO with a voltage or current (see CONFigure: VCO: SWEep: SOURce).
	*RST: 0 Default unit: V or A
Example:	See CONFigure: VCO: SWEep: SOURce.

Manual operation: See "Defining the sweep range" on page 178

### 15.6.9 Spot Noise vs Tune Configuration

•	Sweep Configuration
٠	Trace Configuration

### 15.6.9.1 Sweep Configuration

CONFigure:SNTune:SWEep:DELay:INITial	180
CONFigure:SNTune:SWEep:DELay[:POINt]4	180
CONFigure:SNTune:SWEep:POINts	180
CONFigure:SNTune:SWEep:SOURce	481
CONFigure:SNTune:SWEep:STARt	481
CONFigure:SNTune:SWEep:STOP4	

### CONFigure:SNTune:SWEep:DELay:INITial <SettlingTime>

This command defines an initial delay time that allows the DUT to settle before the first measurement starts.

### Parameters:

<settlingtime></settlingtime>	<numeric value=""></numeric>
	*RST: 10 ms Default unit: s
Example:	//Define an initial settling time of a 100 ms. CONF:VCO:SWE:DEL:INIT 100MS
Manual operation:	See "Defining the settling time" on page 179

### CONFigure:SNTune:SWEep:DELay[:POINt] <SettlingTime>

This command defines a delay time that allows the DUT to settle when a new tuning voltage is applied and before the measurement starts.

#### **Parameters:**

<settlingtime></settlingtime>	<numeric value=""></numeric>
	*RST: 10 ms Default unit: s
Example:	//Define a settling time of a 100 ms CONF:SNT:SWE:DEL 100MS
Manual operation:	See "Defining the settling time" on page 179

### CONFigure:SNTune:SWEep:POINts <MeasPoints>

This command defines the number of measurement points for the VCO measurement.

Parameters:	
<measpoints></measpoints>	<numeric value=""> (integer only)</numeric>
	*RST: 10
Example:	See CONFigure:SNTune:SWEep:SOURce.
Manual operation:	See "Defining the sweep range" on page 178

### CONFigure:SNTune:SWEep:SOURce < PowerSource>

This command selects the source (connector) which tunes the VCO.

Parameters: <powersource></powersource>	<b>VAUX</b> Selects the $V_{aux}$ connector as the sweep source.
	<b>VSUPly</b> Selects the $V_{supply}$ connector as the sweep source.
	<b>VTUNe</b> Selects the $V_{tune}$ connector as the sweep source.
Example:	//Selects the V <sub>supply</sub> connector as the tuning source CONF:SNT:SWE:SOUR VSUP //Select the type of output at the V <sub>supply</sub> connector SOUR:VOLT:POW:LEV:MODE VOLT
	<pre>//Configure a tuning range with 10 measurement points CONF:SNT:SWE:STAR 0V CONF:SNT:SWE:STOP 5V CONF:SNT:SWE:POIN 10 //Turn on the output of the tuning signal</pre>
	//Turn on the output of the tuning signal SOUR:VOLT:POW:LEV ON

### CONFigure:SNTune:SWEep:STARt <Value>

This command defines the start value of the tuning range.

<b>Parameters:</b> <value></value>	<numeric value=""> The unit depends on whether you tune the VCO with a voltage or current (see CONFigure: SNTune: SWEep: SOURce).</numeric>	
	*RST: 0 Default unit: V or A	
Example:	See CONFigure:SNTune:SWEep:SOURce.	
Manual operation:	See "Defining the sweep range" on page 178	

### CONFigure:SNTune:SWEep:STOP <Value>

This command defines the stop value of the tuning range.

<b>Parameters:</b> <value></value>	<numeric value=""></numeric>	
	The unit depends on whether you tune the VCO with a volta or current (see CONFigure: SNTune: SWEep: SOURce).	
	*RST: 0 Default unit: V or A	
Example:	See CONFigure:SNTune:SWEep:SOURce.	
Manual operation:	See "Defining the sweep range" on page 178	

### 15.6.9.2 Trace Configuration

Commands to configure traces described elsewhere:

- CALCulate<n>:SNOise<s>:AOFF on page 466
- CALCulate<n>:SNOise<s>:STATe on page 466
- CALCulate<n>:SNOise<s>:X on page 466
- DISPlay[:WINDow<n>]:TRACe<t>:MODE on page 512
- DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>[:STATe] on page 515

[SENSe:]SMOothing:APERture	32
[SENSe:]SMOothing[:STATe]	33
[SENSe:]SPURs:SUPPress	
[SENSe:]SPURs:THReshold	

#### [SENSe:]SMOothing:APERture <Value>

This command defines the magnitude (aperture) of trace smoothing.

Prerequisites for this command

- Select Spot Noise vs Tune measurement (CONFigure:SNTune:MEASurement[: STATe]).
- Turn on trace smoothing ([SENSe:]SMOothing[:STATe]).

This command smoothes all traces. If you need to smooth each trace separately (possible in all measurements except Spot Noise vs Tune), use DISPlay[:WINDow<n>]: TRACe<t>:SMOothing:APERture.

### Parameters:

<value></value>	<numeric value=""></numeric>	
	Range: 1 to 20 *RST: 1 Default unit: PCT	
Example:	<pre>//Smooth the traces by a magnitude of 10 % SMO ON SMO:APER 10</pre>	
Manual operation:	See "Smoothing traces" on page 208	

### [SENSe:]SMOothing[:STATe] <State>

This command turns trace smoothing for a specific trace on and off.

When you turn on trace smoothing, you can define the smoothing magnitude with [SENSe:]SMOothing:APERture.

Prerequisites for this command

• Select Spot Noise vs Tune measurement (CONFigure:SNTune:MEASurement[: STATe]).

This command smoothes all traces. If you need to smooth each trace separately (possible in all measurements except Spot Noise vs Tune), use DISPlay[:WINDow<n>]: TRACe<t>:SMOothing[:STATe].

Parameters: <state></state>	ON   OFF   1   0
Example:	//Smooth the traces by a magnitude of 10 % SMO ON SMO:APER 10
Manual operation:	See "Smoothing traces" on page 208

#### [SENSe:]SPURs:SUPPress <State>

This command turns spur removal for all traces and windows on and off.

When you turn on spur removal, you can define a level threshold with [SENSe:]SPURS:THReshold.

Prerequisites for this command

• Select Spot Noise vs Tune measurement (CONFigure:SNTune:MEASurement[: STATe]).

If you need to remove spurs for each trace separately (possible in all measurements except Spot Noise vs Tune), use DISPlay[:WINDow<n>]:TRACe<t>:SPURs: SUPPress.

### Parameters:

<state></state>	ON   OFF   1   0
Example:	//Remove spurs SPUR:SUPP ON
Manual operation:	See "Hiding spurs" on page 162

#### [SENSe:]SPURs:THReshold <Threshold>

This command defines a level threshold for spur removal.

Prerequisites for this command

• Select Spot Noise vs Tune measurement (CONFigure: SNTune: MEASurement [: STATe]).

Turn on spur removal (DISPlay[:WINDow<n>]:TRACe<t>:SPURs:THReshold
 ).

The threshold applies to all traces. If you need to define a threshold for each trace separately (possible in all measurements except Spot Noise vs Tune), use DISPlay[: WINDow<n>]:TRACe<t>:SPURS:THReshold.

**Parameters:** 

<threshold></threshold>	<numeric value=""></numeric>
	*RST: 0 Default unit: dB
Example:	//Remove spurs SPUR:SUPP ON SPUR:THR 5
Manual operation:	See "Hiding spurs" on page 162

### 15.6.10 Transient Analysis

•	Frequency Configuration	484
•	Amplitude Configuration	487
	Data Acquisition	
	Trigger Configuration	
	Y-Axis Scale	
•	Settling Time	. 495
	Frequency Deviation	
	Trace Configuration	
	Marker Configuration	
	Limit Lines.	

### 15.6.10.1 Frequency Configuration

Commands to configure the frequency described elsewhere.

- Center frequency: [SENSe:] FREQuency:CENTer
- Start frequency: [SENSe:]FREQuency:STARt
- Stop frequency: [SENSe:]FREQuency:STOP

CONFigure:TRANsient:MODE	485
[SENSe:]FREQuency:CENTer:STEP	485
[SENSe:]FREQuency:CENTer:STEP:LINK	
[SENSe:]FREQuency:CENTer:STEP:LINK:FACTor	486
[SENSe:]FREQuency:SPAN	

### CONFigure:TRANsient:MODE <OrderBy>

This command selects the transient measurement mode.

### Parameters:

Falameters.		
<orderby></orderby>	NARRow	
Narrowband mode: For measurement with a frequency s		
40 MHz.		
If you define a span < 40 MHz while wideband is selected		
define a frequency range outside the supported frequence		
	range, the R&S FSWP automatically selects narrowband mode	
	and adjusts the center, start and stop frequencies, if necessary.	
	WIDE	
	Wideband mode: For measurements with a frequency span > 40 MHz, but only in frequency range between 276 MHz and 7.980 GHz.	
	If you define a span > 40 MHz while narrowband mode is	
	selected, the R&S FSWP automatically selects wideband mode,	
	and adjusts the center, start and stop frequencies, if necessary.	
	*RST: WIDE	
Example:	//Configure measurement with wideband mode	
Example:	//Configure measurement with wideband mode	
Example:	FREQ:CENT 1GHZ	
Example:	FREQ:CENT 1GHZ FREQ:SPAN 100MHZ	
Example:	FREQ:CENT 1GHZ FREQ:SPAN 100MHZ CONF:TRAN:MODE?	
Example:	FREQ:CENT 1GHZ FREQ:SPAN 100MHZ CONF:TRAN:MODE? //returns	
Example:	FREQ:CENT 1GHZ FREQ:SPAN 100MHZ CONF:TRAN:MODE? //returns WIDE	
Example:	FREQ:CENT 1GHZ FREQ:SPAN 100MHZ CONF:TRAN:MODE? //returns WIDE //Select narrowband mode instead - keeps center frequency but	
Example:	FREQ:CENT 1GHZ FREQ:SPAN 100MHZ CONF:TRAN:MODE? //returns WIDE //Select narrowband mode instead - keeps center frequency but reduces span	
Example:	FREQ:CENT 1GHZ FREQ:SPAN 100MHZ CONF:TRAN:MODE? //returns WIDE //Select narrowband mode instead - keeps center frequency but reduces span CONF:TRAN:MODE NARR	
Example:	FREQ:CENT 1GHZ FREQ:SPAN 100MHZ CONF:TRAN:MODE? //returns WIDE //Select narrowband mode instead - keeps center frequency but reduces span CONF:TRAN:MODE NARR FREQ:CENT?	
Example:	FREQ:CENT 1GHZ FREQ:SPAN 100MHZ CONF:TRAN:MODE? //returns WIDE //Select narrowband mode instead - keeps center frequency but reduces span CONF:TRAN:MODE NARR FREQ:CENT? //returns	
Example:	FREQ:CENT 1GHZ FREQ:SPAN 100MHZ CONF:TRAN:MODE? //returns WIDE //Select narrowband mode instead - keeps center frequency but reduces span CONF:TRAN:MODE NARR FREQ:CENT? //returns 100000000	
Example:	FREQ:CENT 1GHZ FREQ:SPAN 100MHZ CONF:TRAN:MODE? //returns WIDE //Select narrowband mode instead - keeps center frequency but reduces span CONF:TRAN:MODE NARR FREQ:CENT? //returns 100000000 FREQ:SPAN?	
Example:	FREQ:CENT 1GHZ FREQ:SPAN 100MHZ CONF:TRAN:MODE? //returns WIDE //Select narrowband mode instead - keeps center frequency but reduces span CONF:TRAN:MODE NARR FREQ:CENT? //returns 1000000000 FREQ:SPAN? //returns	
Example:	FREQ:CENT 1GHZ FREQ:SPAN 100MHZ CONF:TRAN:MODE? //returns WIDE //Select narrowband mode instead - keeps center frequency but reduces span CONF:TRAN:MODE NARR FREQ:CENT? //returns 100000000 FREQ:SPAN?	

Manual operation: See "Selecting the measurement mode" on page 182

### [SENSe:]FREQuency:CENTer:STEP <Frequency>

This command defines a frequency stepsize.

Prerequisites for this command

• Select custom stepsize ([SENSe:]FREQuency:CENTer:STEP:LINK).

### **Parameters:**

<Frequency>

<numeric value> Default unit: Hz

Example:	//Define frequency stepsize
	FREQ:CENT:STEP:LINK OFF
	FREQ:CENT:STEP 15MHZ

Manual operation: See "Defining a frequency step size" on page 183

### [SENSe:]FREQuency:CENTer:STEP:LINK <Mode>

This command selects the frequency step size mode.

### Parameters:

<mode></mode>	The step size is either a function of the span (x % of the span) or an absolute value.
	OFF
	Step size is a custom percentage of the span or an absolute custom value in Hz.
	You can define a percentage with [SENSe:]FREQuency:
	CENTer:STEP:LINK:FACTor.
	You can define a custom value with [SENSe:]FREQuency:
	CENTer:STEP.
	SPAN
	Step size is 10 % of the span.
	*RST: SPAN
Example:	//Select a custom step size FREQ:CENT:STEP:LINK OFF
	FREQ:CENT:STEP:LINK:FACT 20
Manual operation:	See "Defining a frequency step size" on page 183

### [SENSe:]FREQuency:CENTer:STEP:LINK:FACTor <Percentage>

This command defines a custom frequency step size.

Parameters:	
< Doroontaga>	

<percentage></percentage>	<numeric value=""> The value is a percentage. The step size is a function of the p centage and the span: Step size = x % * span</numeric>	
	Range: 0 to 100 *RST: 10 Default unit: PCT	
Example:	<pre>//Select a custom step size FREQ:CENT:STEP:LINK OFF FREQ:CENT:STEP:LINK:FACT 20</pre>	
Manual operation:	See "Defining a frequency step size" on page 183	

#### [SENSe:]FREQuency:SPAN <Frequency>

This command defines the frequency span.

Parameters:

<frequency></frequency>	<numeric value=""></numeric>	
	Default unit: Hz	

Example:	//Define a fre	quency span
	FREQ:SPAN	500MHZ

Manual operation: See "Defining the frequency range of the measurement" on page 183

### 15.6.10.2 Amplitude Configuration

Commands to configure the amplitude described elsewhere.

- Attenuation mode: INPut<1|2>:ATTenuation:AUTO
- Attenuation level: INPut<1|2>:ATTenuation
- Input coupling: INPut<ip>:COUPling

#### INPut<1|2>:RLEVel <Reflevel>

This command defines the reference level (expected signal level).

Note that the reference level is coupled to the attenuation.

**Suffix:** <1|2>

1|2 irrelevant

Parameters:		
<reflevel></reflevel>	<numeric value=""></numeric>	
	*RST:	0
	Default unit:	dBm

Example: //Define reference level INP:RLEV 10DBM

Manual operation: See "Defining a reference level" on page 187

### 15.6.10.3 Data Acquisition

Commands to configure data acquisition described elsewhere.

- Measurement time: [SENSe:]SWEep:TIME
- Sweep mode: INITiate<n>:CONTinuous
- Sweep control: INITiate<n>[:IMMediate]
- Sweep control: ABORt

on page 187

[SENSe:]AVERage <n>:COUNt</n>	488
[SENSe:]BWIDth:VIDeo	488
ISENSe:IBWIDth:VIDeo:AUTO	488
[1	

#### [SENSe:]AVERage<n>:COUNt <AverageCount>

This command defines the number of measurements that the application uses to average traces.

In case of continuous sweep mode, the application calculates the moving average over the average count.

In case of single sweep mode, the application stops the measurement and calculates the average after the average count has been reached.

Suffix:

<n>

irrelevant

#### [SENSe:]BWIDth:VIDeo <Bandwidth>

This command defines the video bandwidth.

Prerequisites for this command

• Turn off automatic VBW selection ([SENSe:]BWIDth:VIDeo:AUTO).

Parameters: <bandwidth></bandwidth>	Default unit: HZ
Example:	//Select VBW manually BWID:VID:AUTO OFF BWID:VID 819672
Manual operation:	See "Defining the video bandwidth"

#### [SENSe:]BWIDth:VIDeo:AUTO <State>

This command turns automatic selection of the video bandwidth on and off.

Parameters:	
<state></state>	ON   OFF   1   0
	*RST: ON
Example:	//Turn on automatic VBW selection BWID:VID:AUTO ON
Manual operation:	See "Defining the video bandwidth" on page 187

### 15.6.10.4 Trigger Configuration

TRIGger[:SEQuence]:DTIMe	
TRIGger[:SEQuence]:FREQuency	
TRIGger[:SEQuence]:FREQuency:HYSTeresis	
TRIGger[:SEQuence]:HOLDoff[:TIME]	490

**Common Measurement Settings** 

TRIGger[:SEQuence]:IFPower:HOLDoff	
TRIGger[:SEQuence]:LEVel[:EXTernal<1]2>]	
TRIGger[:SEQuence]:SLOPe	
TRIGger[:SEQuence]:SOURce	

### TRIGger[:SEQuence]:DTIMe <Time>

This command defines the trigger drop-out time.

Parameters:	
<time></time>	<numeric value=""></numeric>
	*RST: 0 Default unit: s
Example:	//Define a drop-out time TRIG:DTIM 200MS
Manual operation:	See "Defining a trigger drop-out time" on page 185

### TRIGger[:SEQuence]:FREQuency <Frequency>

This command defines the trigger frequency.

Prerequisites for this command

• Select the frequency trigger (TRIGger [: SEQuence] : SOURce).

Parameters:	
<frequency></frequency>	<numeric value=""></numeric>
	Default unit: Hz
Example:	//Configure frequency trigger
	TRIG:SOUR FREQ
	TRIG:FREQ 1GHZ

Manual operation: See "Defining the trigger level and frequency" on page 185

#### TRIGger[:SEQuence]:FREQuency:HYSTeresis <Hysteresis>

This command defines the trigger hysteresis.

Prerequisites for this command

• Select the frequency trigger (TRIGger [: SEQuence] : SOURce).

### Parameters:

<hysteresis></hysteresis>	<numeric value=""></numeric>	
	*RST: 100 kHz Default unit: Hz	
Example:	//Define a trigger hysteresis TRIG:SOUR FREQ TRIG:FREQ:HYST 200KHZ	
Manual operation:	See "Defining a trigger hysteresis" on page 185	

### TRIGger[:SEQuence]:HOLDoff[:TIME] <Offset>

Defines the time offset between the trigger event and the start of the measurement.

**Parameters:** 

<offset></offset>	*RST: 0 s Default unit: S
Example:	TRIG:HOLD 500us
Manual operation:	See "Trigger Offset " on page 185

#### TRIGger[:SEQuence]:IFPower:HOLDoff <Period>

This command defines the holding time before the next trigger event.

Note that this command can be used for **any trigger source**, not just IF Power (despite the legacy keyword).

#### **Parameters:**

<period></period>	Range: *RST: Default unit:	0sto10s 0s S
Example:	TRIG: IFP:	R EXT ernal trigger source. HOLD 200 ns Iding time to 200 ns.
Manual operation:	See " Trigge	er Holdoff " on page 185

### TRIGger[:SEQuence]:LEVel[:EXTernal<1|2>] <Level>

This command defines the external trigger level.

Prerequisites for this command

• Select the external trigger (TRIGger [:SEQuence]:SOURce).

<b>Suffix:</b> <1 2>	1 2 Selects the trigger port.
Parameters:	
<level></level>	<numeric value=""></numeric>
	Default unit: V
Example:	//Configure external trigger on trigger port 2 TRIG:SOUR EXT2 TRIG:LEV:EXT2 1.4V
Manual operation:	See "Defining the trigger level and frequency" on page 185

#### TRIGger[:SEQuence]:SLOPe <Slope>

This command selects the trigger slope.

Parameters:

<slope></slope>	<b>NEGative</b> Triggering occurs on a falling signal edge. <b>POSitive</b> Triggering occurs on a rising signal edge.	
	*RST:	POSitive
	K31.	FOSILIVE
Example:	//Select trigg	
Manual operation:	See "Definii	ng a trigger slope" on page 185

# TRIGger[:SEQuence]:SOURce <Source>

This command selects the trigger source.

Param	eters:
-------	--------

i arameters.		
<source/>	<b>EXTernal   EXT2</b> External trigger: The measurement starts when the signal applied to the input connector meets or exceeds a certain level.	
	<b>FREQuency</b> Frequency trigger: The measurement starts when the signal applied to the RF input meets or exceeds a certain frequency.	
	IMMediate Free run: No trigger is used.	
	<b>IQPower</b> Power trigger: The measurement starts when the signal level within the demodulation bandwidth rises or falls by a certain amount.	
	*RST: IMMediate	
Example:	//Select trigger source TRIG:SOUR FREQ	
Manual operation:	See "Selecting the trigger source" on page 184	

#### 15.6.10.5 Y-Axis Scale

Commands to scale the y-axis in the frequency result display described elsewhere.

- Center frequency: [SENSe:]FREQuency:CENTer Start frequency: [SENSe:]FREQuency:STARt Stop frequency: [SENSe:]FREQuency:STOP Span: [SENSe:]FREQuency:SPAN
- **Stepsize**: [SENSe:] FREQuency:CENTer:STEP:LINK
- Stepsize factor: [SENSe:]FREQuency:CENTer:STEP:LINK:FACTor

Commands to scale the y-axis in the phase result display described elsewhere.

- Mode: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:AUTO •
- Auto scale once: DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:AUTO

CONFigure:TRANsient[:WINDow <n>]:AF:COUPling</n>	492
CONFigure:TRANsient[:WINDow <n>]:AF:COUPling:RPOint:MODE</n>	
CONFigure:TRANsient[:WINDow <n>]:AF:COUPling:RPOint[:X]</n>	493
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:MODE</t></n>	493
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:PDIVision</t></n>	494
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:RPOSition</t></n>	494
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:RVALue</t></n>	495
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:UNIT</t></n>	495

### CONFigure:TRANsient[:WINDow<n>]:AF:COUPling <Mode>

This command selects the AF coupling mode.

<b>Suffix:</b> <n></n>	1n Window
Parameters: <mode></mode>	AC AC coupling: Frequency offset and phase offset are automati- cally corrected and DC signal contains a phase offset of ±π. DC DC coupling: Phase runs according to the existing frequency off- set. *RST: AC
Example:	//Select AF coupling mode CONF:TRAN:AF:COUP AC
Manual operation:	See "Selecting the AF coupling mode" on page 189

### CONFigure:TRANsient[:WINDow<n>]:AF:COUPling:RPOint:MODE <Mode>

This command selects the zero phase positioning mode.

Suffix: <n></n>	1n Window
Parameters:	
<mode></mode>	<b>AUTO</b> Positions the zero phase at the end of the trace (right diagram border).
	<b>MANual</b> Manual selection the position of the zero phase. You can define the zero phase position with CONFigure: TRANsient[:WINDow <n>]:AF:COUPling:RPOint[:X].</n>

#### \*RST: AUTO

Example: //Select zero phase positioning mode CONF:TRAN:AF:COUP:RPO:MODE AUTO

Manual operation: See "Positioning the zero-phase" on page 189

### CONFigure:TRANsient[:WINDow<n>]:AF:COUPling:RPOint[:X] <Position>

This command defines the position of the zero phase.

Prerequisites for this command

- Turn on manual selection of the zero phase position (CONFigure:TRANsient[: WINDow<n>]:AF:COUPling:RPOint:MODE).
- Select "DC" AF coupling (CONFigure: TRANsient [:WINDow<n>]: AF: COUPling on page 492).

#### Suffix:

<n></n>	1n Window
<b>Parameters:</b> <position></position>	<numeric value=""> Default unit: s</numeric>
Example:	<pre>//Define position of the zero phase manually CONF:TRAN:AF:COUP:RPO:MODE MAN CONF:TRAN:AF:COUP:RPO 1US</pre>
Manual operation:	See "Positioning the zero-phase" on page 189

#### DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:MODE <Mode>

This command selects how frequencies are displayed on the y-axis.

Prerequisites for this command

• Frequency result display must be available and selected.

#### Suffix:

<n></n>	1n Window
<t></t>	1n irrelevant
Parameters: <mode></mode>	ABSolute Displays the frequencies in absolute values. RELative

Displays the frequencies as an offset to the center frequency. \*RST: ABSolute

Example:	//Display frequencies in relative terms
	DISP:TRAC:Y:MODE REL

Manual operation: See "Scaling the y-axis of the frequency diagram" on page 188

### DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:PDIVision <Value>

This command defines the range of a single diagram division on the y-axis of the phase result display.

Prerequisites for this command

• Phase result display must be available and selected.

Suffix:	
<n></n>	1n Window
<t></t>	1n irrelevant
Parameters:	
<value></value>	<numeric value=""></numeric>
	Default unit: Depends on the selected unit (rad or deg)
Example:	<pre>//Display 0.5 rad per grid division DISP:TRAC:Y:UNIT DISP:TRAC:Y:PDIV 0.5</pre>
Menuel exercition.	Cap "Capting the visit of the phase diagram" on page 10

Manual operation: See "Scaling the y-axis of the phase diagram" on page 189

#### DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RPOSition <Position>

This command defines the position of the reference value on the y-axis.

Prerequisites for this command

• Phase result display must be available and selected.

Suffix: <n></n>	1n Window
<t></t>	1n irrelevant
Parameters:	
<position></position>	Percentage of the diagram height with 100 % corresponding to the upper diagram border *RST: 50 Default unit: PCT
Example:	//Shift reference position to top of the diagram DISP:TRAC:Y:RPOS 100
Manual operation:	See "Scaling the y-axis of the phase diagram" on page 189

### DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RVALue <RefValue>

This command defines the value assigned to the reference position.

Prerequisites for this command

• Phase result display must be available and selected.

Suffix: <n></n>	1n Window
<t></t>	1n irrelevant
Parameters: <refvalue></refvalue>	<numeric value=""> *RST: 0 Default unit: Depends on the selected unit (deg or rad)</numeric>
Example:	<pre>//Define reference value in rad DISP:TRAC:Y:UNIT RAD DISP:TRAC:Y:RVAL 5</pre>
Manual operation:	See "Scaling the y-axis of the phase diagram" on page 189

#### DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:UNIT <YScalUnit>

This command selects the unit in which the phase results are displayed.

Prerequisites for this command

• Phase result display must be available and selected.

### Suffix:

<n></n>	1n Window
<t></t>	1n irrelevant
<b>Parameters:</b> <yscalunit></yscalunit>	DEG   RAD
	*RST: RAD
Example:	//Select unit for phase results DISP:TRAC:Y:UNIT DEG
Manual operation:	See "Scaling the y-axis of the phase diagram" on page

### 15.6.10.6 Settling Time

CALCulate <n>:SETTling:TIME:STATe</n>	
CALCulate <n>:SETTling:TIME:DIAGram</n>	496
CALCulate <n>:SETTling:TIME:TRACe</n>	
5	

189

#### **Common Measurement Settings**

CALCulate <n>:SETTling:TIME:FREQuency:LIMit:LOWer</n>	
CALCulate <n>:SETTling:TIME:FREQuency:LIMit:UPPer</n>	
CALCulate <n>:SETTling:TIME:RESult?</n>	497

### CALCulate<n>:SETTling:TIME:STATe <State>

This command defines the state of settling time measurement.

Suffix:	
<n></n>	irrelevant
Parameters: <state></state>	ON   OFF   1   0
	*RST: 0
Example:	CALC1:SETT:TIME:STAT OFF

### CALCulate<n>:SETTling:TIME:DIAGram <Diagram>

This command selects the diagram for settling time calculation.

Suffix: <n></n>	irrelevant	
<b>Parameters:</b> <diagram></diagram>	Number of the diagram	
Example:	CALC:SETT:TIME:DIAG	1

### CALCulate<n>:SETTling:TIME:TRACe <Trace>

This command selects the trace for settling time calculation.

Suffix: <n></n>	irrelevant
Parameters: <trace></trace>	TRACe1   TRACe2   TRACe3   TRACe4   TRACe5   TRACe6
Example:	CALC:SETT:TIME:TRAC Trace1

### CALCulate<n>:SETTling:TIME:FREQuency:LIMit:LOWer <Frequency>

This command defines the lower frequency of settling time measurement.

Suffix: <n></n>	irrelevant
Parameters: <frequency></frequency>	Default unit: Hz
Example:	CALC1:SETT:TIME:LOW:FREQ:LIM 100

#### CALCulate<n>:SETTling:TIME:FREQuency:LIMit:UPPer <Frequency>

This command defines the upper frequency of settling time measurement.

Suffix: <n></n>	irrelevant	
Parameters: <frequency></frequency>	Default unit: Hz	
Example:	CALC1:SETT:TIME:UPP:FREQ:LIM	1000

### CALCulate<n>:SETTling:TIME:RESult?

This command returns the settling time.

Suffix:	
<n></n>	irrelevant
Example:	CALC1:SETT:TIME:RES?
Usage:	Query only

#### 15.6.10.7 Frequency Deviation

CALCulate <n>:FREQuency:DEViation:STATe</n>	
CALCulate <n>:FREQuency:DEViation:DIAGram</n>	
CALCulate <n>:FREQuency:DEViation:TRACe</n>	
CALCulate <n>:FREQuency:DEViation:STARt</n>	
CALCulate <n>:FREQuency:DEViation:STOP</n>	
CALCulate <n>:FREQuency:DEViation:REGRession?</n>	
CALCulate <n>:FREQuency:DEViation:REGRession:POINts?</n>	
CALCulate <n>:FREQuency:DEViation:SLOPe?</n>	

### CALCulate<n>:FREQuency:DEViation:STATe <State>

This command defines the state of frequency deviation measurement.

Suffix: <n></n>	irrelevant
Parameters: <state></state>	ON   OFF   1   0 *RST: 0
Example:	CALC1:FREQ:DEV:STAT OFF

### CALCulate<n>:FREQuency:DEViation:DIAGram <Diagram>

This command selects the diagram for frequency deviation calculation.

Suffix: <n>

irrelevant

### Parameters:

<diagram></diagram>	Number of the diagram	
Example:	CALC:FREQ:DEV:DIAG	1

### CALCulate<n>:FREQuency:DEViation:TRACe <Trace>

This command selects the trace for frequency deviation calculation.

Suffix: <n></n>	irrelevant
Parameters: <trace></trace>	TRACe1   TRACe2   TRACe3   TRACe4   TRACe5   TRACe6
Example:	CALC:FREQ:DEV:TRAC Trace1

### CALCulate<n>:FREQuency:DEViation:STARt <Range>

This command defines the start frequency of frequency deviation measurement.

Suffix: <n></n>	irrelevant
Parameters: <range></range>	Default unit: s
Example:	CALC1:FREQ:DEV:STAR 100

### CALCulate<n>:FREQuency:DEViation:STOP <Range>

This command defines the stop frequency of frequency deviation measurement.

Suffix: <n></n>	irrelevant	
<b>Parameters:</b> <range></range>	Default unit: s	
Example:	CALC1:FREQ:DEV:STOP	1000

### CALCulate<n>:FREQuency:DEViation:REGRession?

This command returns the data of the regression line.

Suffix:	
<n></n>	irrelevant
Example:	CALC1:FREQ:DEV:REGR?
Usage:	Query only

#### CALCulate<n>:FREQuency:DEViation:REGRession:POINts?

This command queries the number of points of the regression line.

Suffix: <n></n>	irrelevant
<b>Return values:</b> <points></points>	
Example:	CALC1:FREQ:DEV:REGR:POIN?
Usage:	Query only

#### CALCulate<n>:FREQuency:DEViation:SLOPe?

This command returns the slope of the regression line. A single floating point value with the unit Hz/s is returned.

Suffix:	
<n></n>	irrelevant
Example:	CALC1:FREQ:DEV:SLOP?
Usage:	Query only

#### 15.6.10.8 Trace Configuration

Commands to configure transient analysis traces described elsewhere.

- Trace state: DISPlay [:WINDow<n>] [:SUBWindow<w>]:TRACe<t>[:STATe]
- Trace mode: DISPlay[:WINDow<n>]:TRACe<t>:MODE
- **Persistence**: DISPlay[:WINDow<n>]:TRACe<t>:PERSistence[:STATe]
- **Decay**: DISPlay[:WINDow<n>]:TRACe<t>:PERSistence:DECay
- Trace copy: TRACe<n>:COPY
- Trace labels: DISPlay[:WINDow<n>]:TRACe<t>:LABel[:STATe]
- Trace labels: DISPlay[:WINDow<n>]:TRACe<t>:LABel:TEXT
- Trace export: Chapter 15.7.3.3, "Trace Export and Import", on page 518
- Trace mathematics: Chapter 15.7.3.4, "Trace Mathematics", on page 522

#### 15.6.10.9 Marker Configuration

See Chapter 15.7.4, "Marker", on page 524 for a complete list of commands to control markers.

#### 15.6.10.10 Limit Lines

See Chapter 15.7.5, "Limit Lines", on page 537 for a complete list of commands to control limit lines.

Common Analysis and Display Functions

# **15.7 Common Analysis and Display Functions**

•	Display Configuration	.500
	Zoom	
•	Trace Configuration	.512
•	Marker	.524
•	Limit Lines	.537
•	Examples: Configuring the Result Display	. 549

# 15.7.1 Display Configuration

DISPlay:FORMat	500
DISPlay:WSELect?	500
DISPlay[:WINDow <n>][:SUBWindow<w>]:SELect</w></n>	
DISPlay[:WINDow <n>]:SIZE</n>	501
LAYout:ADD[:WINDow]?	
LAYout:CATalog[:WINDow]?	
LAYout:IDENtify[:WINDow]?	503
LAYout:MOVE[:WINDow]	
LAYout:REMove[:WINDow]	504
LAYout:REPLace[:WINDow]	505
LAYout:SPLitter	505
LAYout:WINDow <n>:ADD?</n>	507
LAYout:WINDow <n>:IDENtify?</n>	
LAYout:WINDow <n>:REMove</n>	
LAYout:WINDow <n>:REPLace</n>	

### DISPlay:FORMat <Format>

This command determines which tab is displayed.

<b>Parameters:</b> <format></format>	<b>SPLit</b> Displays the MultiView tab with an overview of all active chan- nels	
	SINGIe Displays the *RST:	e measurement channel that was previously focused. SING
Example:	DISP:FORM	1 SPL

### DISPlay:WSELect?

This command queries the currently active window (the one that is focused) in the currently selected measurement channel.

#### Return values:

<SelectedWindow> Index number of the currently active window. Range: 1 to 16 Usage: Query only

#### DISPlay[:WINDow<n>][:SUBWindow<w>]:SELect

This command sets the focus on the selected result display window.

This window is then the active window.

For measurements with multiple results in subwindows, the command also selects the subwindow. Use this command to select the (sub)window before querying trace data.

#### Suffix:

<n></n>	Window
<w></w>	subwindow Not supported by all applications
Example:	//Put the focus on window 1 DISP:WIND1:SEL
Example:	<pre>//Put the focus on subwindow 2 in window 1 DISP:WIND1:SUBW2:SEL</pre>

#### DISPlay[:WINDow<n>]:SIZE <Size>

This command maximizes the size of the selected result display window *temporarily*. To change the size of several windows on the screen permanently, use the LAY:SPL command (see LAYout:SPLitter on page 505).

Suffix	
<n></n>	

Window

LARGe

### Parameters:

<Size>

Maximizes the selected window to full screen. Other windows are still active in the background.

#### SMALI

Reduces the size of the selected window to its original size. If more than one measurement window was displayed originally, these are visible again.

\*RST: SMALI

**Example:** DISP:WIND2:SIZE LARG

LAYout:ADD[:WINDow]? <WindowName>,<Direction>,<WindowType>

This command adds a window to the display in the active channel.

This command is always used as a query so that you immediately obtain the name of the new window as a result.

To replace an existing window, use the LAYout:REPLace[:WINDow] command.

Query parameters: <windowname></windowname>	String containing the name of the existing window the new win- dow is inserted next to. By default, the name of a window is the same as its index. To determine the name and index of all active windows, use the LAYout:CATalog[:WINDow]? query.
<direction></direction>	LEFT   RIGHt   ABOVe   BELow Direction the new window is added relative to the existing win- dow.
<windowtype></windowtype>	text value Type of result display (evaluation method) you want to add. See the table below for available parameter values.
Return values: <newwindowname></newwindowname>	When adding a new window, the command returns its name (by default the same as its number) as a result.
Example:	LAY:ADD? '1', LEFT, MTAB Result: '2' Adds a new window named '2' with a marker table to the left of window 1.

### Usage: Query only

### Manual operation: See " Marker Table " on page 121

### Table 15-4: <WindowType> parameter values for the phase noise application

Parameter value	Window type
ADEViation	Allan deviation <sup>5</sup>
AVARiance	Allan variance <sup>5</sup>
DIAGram	Noise spectrum <sup>1</sup>
FDEViation	Frequency Deviation <sup>4</sup>
FREQuency	Frequency <sup>2,4</sup>
HARMonic	Harmonic power <sup>2</sup>
INOise	Integrated noise <sup>1</sup>
LF	Noise spectrum L(f) <sup>6</sup>
MTABle	Marker table <sup>1,2,3,4</sup>
PFRequency	Power vs frequency <sup>2</sup>
PHASe	Phase <sup>4</sup>
PNOise	Noise spectrum <sup>1</sup>
POWer	Power <sup>2</sup>
RNOise	Integrated noise <sup>1</sup>

#### **Common Analysis and Display Functions**

Parameter value	Window type
SENSitivity	Sensitivity <sup>2</sup>
SNOise	Spot noise <sup>1</sup>
SNTam	Spot noise vs tune AM <sup>3</sup>
SNTPn	Spot noise vs tune PN <sup>3</sup>
SNU	Noise spectrum Sv(f) <sup>6</sup>
SPHI	Noise spectrum SΦ(f) <sup>6</sup>
SPURs	Spurious list <sup>1</sup>
SUPPly	Supply current / voltage <sup>2</sup>
SY	Noise spectrum Sy(f) <sup>6</sup>

<sup>1</sup> Phase noise, additive noise, baseband noise, pulsed phase noise and pulsed additive noise measurements

<sup>2</sup> VCO characterization

<sup>3</sup> Spot noise vs tune

<sup>4</sup> Transient analysis

<sup>5</sup> Phase noise

<sup>6</sup> Phase noise, additive noise, pulsed phase noise and pulsed additive noise measurements

### LAYout:CATalog[:WINDow]?

This command queries the name and index of all active windows in the active channel from top left to bottom right. The result is a comma-separated list of values for each window, with the syntax:

<WindowName\_1>,<WindowIndex\_1>..<WindowName\_n>,<WindowIndex\_n>

<b>Return values:</b> <windowname></windowname>	string Name of the window. In the default state, the name of the window is its index.
<windowindex></windowindex>	numeric value Index of the window.
Example:	LAY: CAT? Result: '2',2,'1',1 Two windows are displayed, named '2' (at the top or left), and '1' (at the bottom or right).
Usage:	Query only

#### LAYout:IDENtify[:WINDow]? <WindowName>

This command queries the **index** of a particular display window in the active channel.

Note: to query the name of a particular window, use the LAYout:WINDow<n>: IDENtify? query.

# Query parameters:

<windowname></windowname>	String containing the name of a window.
Return values: <windowindex></windowindex>	Index number of the window.
Example:	LAY:WIND:IDEN? '2' Queries the index of the result display named '2'. Response: 2
Usage:	Query only

LAYout:MOVE[:WINDow] <WindowName>, <WindowName>, <Direction>

Setting parameters: <windowname></windowname>	String containing the name of an existing window that is to be moved. By default, the name of a window is the same as its index. To determine the name and index of all active windows in the active channel, use the LAYout: CATalog[:WINDow]? query.
<windowname></windowname>	String containing the name of an existing window the selected window is placed next to or replaces. By default, the name of a window is the same as its index. To determine the name and index of all active windows in the active channel, use the LAYout:CATalog[:WINDow]? query.
<direction></direction>	LEFT   RIGHt   ABOVe   BELow   REPLace Destination the selected window is moved to, relative to the ref- erence window.
Example:	LAY:MOVE '4', '1', LEFT Moves the window named '4' to the left of window 1.
Example:	LAY: MOVE '1', '3', REPL Replaces the window named '3' by window 1. Window 3 is deleted.
Usage:	Setting only

### LAYout:REMove[:WINDow] <WindowName>

This command removes a window from the display in the active channel.

Setting parameters: <windowname></windowname>	String containing the name of the window. In the default state, the name of the window is its index.
Example:	LAY: REM '2' Removes the result display in the window named '2'.

Usage: Setting only

LAYout:REPLace[:WINDow] <WindowName>,<WindowType>

This command replaces the window type (for example from "Diagram" to "Result Summary") of an already existing window in the active channel while keeping its position, index and window name.

To add a new window, use the LAYout: ADD[:WINDow]? command.

### Setting parameters:

<windowname></windowname>	String containing the name of the existing window. By default, the name of a window is the same as its index. To determine the name and index of all active windows in the active channel, use the LAYout:CATalog[:WINDow]? query.
<windowtype></windowtype>	Type of result display you want to use in the existing window. See LAYout:ADD[:WINDow]? on page 501 for a list of available window types.
Example:	LAY:REPL:WIND '1', MTAB Replaces the result display in window 1 with a marker table.
Usage:	Setting only

#### LAYout:SPLitter <Index1>, <Index2>, <Position>

This command changes the position of a splitter and thus controls the size of the windows on each side of the splitter.

Compared to the DISPlay[:WINDow<n>]:SIZE on page 501 command, the LAYout:SPLitter changes the size of all windows to either side of the splitter permanently, it does not just maximize a single window temporarily.

Note that windows must have a certain minimum size. If the position you define conflicts with the minimum size of any of the affected windows, the command will not work, but does not return an error.

# **Remote Control**

# **Common Analysis and Display Functions**




Figure 15-1: SmartGrid coordinates for remote control of the splitters

Setting parameters: <index1> <index2></index2></index1>	The index of one window the splitter controls. The index of a window on the other side of the splitter.
<position></position>	New vertical or horizontal position of the splitter as a fraction of the screen area (without channel and status bar and softkey menu). The point of origin ( $x = 0$ , $y = 0$ ) is in the lower left corner of the screen. The end point ( $x = 100$ , $y = 100$ ) is in the upper right corner of the screen. (See Figure 15-1.) The direction in which the splitter is moved depends on the screen layout. If the windows are positioned horizontally, the splitter also moves horizontally. If the windows are positioned vertically, the splitter also moves vertically. Range: 0 to 100
Example:	LAY: SPL 1, 3, 50 Moves the splitter between window 1 ('Frequency Sweep') and 3 ('Marker Table') to the center (50%) of the screen, i.e. in the fig- ure above, to the left.

Example:	LAY:SPL 1,4,70 Moves the splitter between window 1 ('Frequency Sweep') and 3 ('Marker Peak List') towards the top (70%) of the screen. The following commands have the exact same effect, as any combination of windows above and below the splitter moves the splitter vertically. LAY:SPL 3,2,70 LAY:SPL 4,1,70 LAY:SPL 2,1,70
Usage:	Setting only

# LAYout:WINDow<n>:ADD? <Direction>,<WindowType>

This command adds a measurement window to the display. Note that with this command, the suffix <n> determines the existing window next to which the new window is added, as opposed to LAYout:ADD[:WINDow]?, for which the existing window is defined by a parameter.

To replace an existing window, use the LAYout:WINDow<n>:REPLace command.

This command is always used as a query so that you immediately obtain the name of the new window as a result.

Suffix: <n></n>	Window
Query parameters: <direction></direction>	LEFT   RIGHt   ABOVe   BELow
<windowtype></windowtype>	Type of measurement window you want to add. See LAYout:ADD[:WINDow]? on page 501 for a list of available window types.
Return values: <newwindowname></newwindowname>	When adding a new window, the command returns its name (by default the same as its number) as a result.
Example:	LAY:WIND1:ADD? LEFT, MTAB Result: '2' Adds a new window named '2' with a marker table to the left of window 1.
Usage:	Query only

#### LAYout:WINDow<n>:IDENtify?

This command queries the **name** of a particular display window (indicated by the <n> suffix) in the active channel.

**Note**: to query the index of a particular window, use the LAYout:IDENtify[: WINDow]? command.

Suffix: <n></n>	Window
Return values: <windowname></windowname>	String containing the name of a window. In the default state, the name of the window is its index.
Example:	LAY:WIND2:IDEN? Queries the name of the result display in window 2. Response: '2'
Usage:	Query only

# LAYout:WINDow<n>:REMove

This command removes the window specified by the suffix <n> from the display in the active channel.

The result of this command is identical to the LAYout:REMove [:WINDow] command.

Suffix: <n></n>	Window
Example:	LAY:WIND2:REM Removes the result display in window 2.
Usage:	Event

# LAYout:WINDow<n>:REPLace <WindowType>

This command changes the window type of an existing window (specified by the suffix <n>) in the active channel.

The effect of this command is identical to the LAYout:REPLace[:WINDow] command.

To add a new window, use the LAYout:WINDow<n>:ADD? command.

Suffix: <n></n>	Window
Setting parameters: <windowtype></windowtype>	Type of measurement window you want to replace another one with. See LAYout:ADD[:WINDow]? on page 501 for a list of available window types.
Example:	LAY:WIND2:REPL MTAB Replaces the result display in window 2 with a marker table.
Usage:	Setting only


# 15.7.2 Zoom

DISPlay[:WINDow <n>][:SUBWindow<w>]:ZOOM:AREA</w></n>	
DISPlay[:WINDow <n>][:SUBWindow<w>]:ZOOM:MULTiple<zn>:AREA</zn></w></n>	
DISPlay[:WINDow <n>][:SUBWindow<w>]:ZOOM:MULTiple<zn>[:STATe]</zn></w></n>	511
DISPlay[:WINDow <n>][:SUBWindow<w>]:ZOOM[:STATe]</w></n>	511

# DISPlay[:WINDow<n>][:SUBWindow<w>]:ZOOM:AREA <x1>,<y1>,<x2>,<y2>

This command defines the zoom area.

To define a zoom area, you first have to turn the zoom on.



1 = origin of coordinate system (x1 = 0, y1 = 0)

2 = end point of system (x2 = 100, y2 = 100)

3 = zoom area (e.g. x1 = 60, y1 = 30, x2 = 80, y2 = 75)

# Suffix:


<n></n>	Window
<w></w>	subwindow Not supported by all applications
Parameters:	
<x1></x1>	Diagram coordinates in % of the complete diagram that define the zoom area. The lower left corner is the origin of coordinate system. The upper right corner is the end point of the system. Range: 0 to 100 Default unit: PCT
<y1></y1>	Diagram coordinates in % of the complete diagram that define the zoom area. The lower left corner is the origin of coordinate system. The upper right corner is the end point of the system. Range: 0 to 100 Default unit: PCT
<x2></x2>	Diagram coordinates in % of the complete diagram that define the zoom area. The lower left corner is the origin of coordinate system. The upper right corner is the end point of the system. Range: 0 to 100 Default unit: PCT


<y2> Diagram coordinates in % of the complete diagram that define the zoom area. The lower left corner is the origin of coordinate system. The upper right corner is the end point of the system. Range: 0 to 100 Default unit: PCT Manual operation: See " Single Zoom " on page 199

Manual operation. See Single 20011 on page 199

# DISPlay[:WINDow<n>][:SUBWindow<w>]:ZOOM:MULTiple<zn>:AREA <x1>,<y1>,<x2>,<y2>

This command defines the zoom area for a multiple zoom.





To define a zoom area, you first have to turn the zoom on.

1 = origin of coordinate system (x1 = 0, y1 = 0)

2 = end point of system (x2 = 100, y2= 100)

3 = zoom area (e.g. x1 = 60, y1 = 30, x2 = 80, y2 = 75)

Suffix: <n></n>	Window
<w></w>	subwindow Not supported by all applications
<zn></zn>	Selects the zoom window.
Parameters:	
<x1></x1>	Diagram coordinates in % of the complete diagram that define the zoom area. The lower left corner is the origin of coordinate system. The upper right corner is the end point of the system. Range: 0 to 100 Default unit: PCT
<y1></y1>	Diagram coordinates in % of the complete diagram that define the zoom area. The lower left corner is the origin of coordinate system. The upper right corner is the end point of the system. Range: 0 to 100 Default unit: PCT

<x2></x2>	Diagram coordinates in % of the complete diagram that define the zoom area. The lower left corner is the origin of coordinate system. The upper right corner is the end point of the system.
	Range: 0 to 100 Default unit: PCT
<y2></y2>	Diagram coordinates in % of the complete diagram that define the zoom area. The lower left corner is the origin of coordinate system. The upper right corner is the end point of the system.
	Range: 0 to 100 Default unit: PCT
Manual operation:	See " Multi-Zoom " on page 199

# DISPlay[:WINDow<n>][:SUBWindow<w>]:ZOOM:MULTiple<zn>[:STATe] <State>

Suffix:	
<n></n>	Window
<w></w>	subwindow Not supported by all applications
<zn></zn>	Selects the zoom window. If you turn off one of the zoom windows, all subsequent zoom windows move up one position.
Parameters:	
<state></state>	ON   OFF   0   1
	OFF   0
	Switches the function off
	ON   1
	Switches the function on
Manual operation:	See " Multi-Zoom " on page 199

This command turns the multiple zoom on and off.

# DISPlay[:WINDow<n>][:SUBWindow<w>]:ZOOM[:STATe] <State>

This command turns the zoom on and off.

Suffix:	
<n></n>	Window
<w></w>	subwindow Not supported by all applications
Parameters:	
<state></state>	ON   OFF   0   1
	OFF   0 Switches the function off

	ON   1 Switches the function on
Example:	DISP: ZOOM ON Activates the zoom mode.
Manual operation:	See " Single Zoom " on page 199 See " Restore Original Display " on page 200 See " Deactivating Zoom (Selection Mode) " on page 200

# **15.7.3 Trace Configuration**

•	Trace Characteristics	
•	Trace Copy	
	Trace Export and Import	
	Trace Mathematics.	
	Formats for Returned Values: ASCII Format and Binary Format	

# 15.7.3.1 Trace Characteristics

#### Commands to configure traces described elsewhere.

- DISPlay[:WINDow<n>]:TRACe<t>:SPURs:SUPPress
- DISPlay[:WINDow<n>]:TRACe<t>:SPURs:THReshold

DISPlay[:WINDow <n>]:TRACe<t>:MODE</t></n>	512
DISPlay[:WINDow <n>]:TRACe<t>:LABel[:STATe]</t></n>	513
DISPlay[:WINDow <n>]:TRACe<t>:LABel:TEXT</t></n>	.514
DISPlay[:WINDow <n>]:TRACe<t>:PERSistence:DECay</t></n>	514
DISPlay[:WINDow <n>]:TRACe<t>:PERSistence[:STATe]</t></n>	515
DISPlay[:WINDow <n>]:TRACe<t>:RESult[:TYPE]</t></n>	515
DISPlay[:WINDow <n>][:SUBWindow<w>]:TRACe<t>[:STATe]</t></w></n>	515
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:RLEVel:OFFSet</t></n>	516
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:RLEVel:OFFSet:STATe</t></n>	516
DISPlay[:WINDow <n>]:TRACe<t>:SMOothing:APERture</t></n>	517
DISPlay[:WINDow <n>]:TRACe<t>:SMOothing[:STATe]</t></n>	517
DISPlay[:WINDow <n>]:TRACe<t>:SMOothing[:STATe]</t></n>	517

# DISPlay[:WINDow<n>]:TRACe<t>:MODE <Mode>

This command selects the trace mode. If necessary, the selected trace is also activated.

In case of max hold, min hold or average trace mode, you can set the number of single measurements with [SENSe:]SWEep:COUNt. Note that synchronization to the end of the measurement is possible only in single sweep mode.

# Suffix:

<n>

Window

<t>

#### Trace

# Parameters:

<Mode>

#### WRITe

Overwrite mode: the trace is overwritten by each sweep. This is the default setting.

#### AVERage

The average is formed over several sweeps. The "Sweep/Average Count" determines the number of averaging procedures.

#### MAXHold

The maximum value is determined over several sweeps and displayed. The R&S FSWP saves the sweep result in the trace memory only if the new value is greater than the previous one.

#### MINHold

The minimum value is determined from several measurements and displayed. The R&S FSWP saves the sweep result in the trace memory only if the new value is lower than the previous one.

#### VIEW

The current contents of the trace memory are frozen and displayed.

#### **BLANk**

Hides the selected trace.

# WRHold

The trace is overwritten when new data is available, but only after all cross-correlation operations defined for a half decade are done.

\*RST: Depends on the trace.

Example: INIT:CONT OFF

Switching to single sweep mode. SWE:COUN 16 Sets the number of measurements to 16. DISP:TRAC3:MODE WRIT Selects clear/write mode for trace 3. INIT; \*WAI Starts the measurement and waits for the end of the measurement.

Manual operation: See " Trace Mode " on page 207

# DISPlay[:WINDow<n>]:TRACe<t>:LABel[:STATe] <State>

This command turns the display of the trace label for a specific trace on and off.

The command can only be applied to active traces.

Suffix: <n>

1..n Window

<t></t>	1n Trace
Parameters: <state></state>	ON   OFF   1   0 *RST: OFF
Example:	<pre>//Turn on the label for trace 2 DISP:TRAC2:LAB ON</pre>

# DISPlay[:WINDow<n>]:TRACe<t>:LABel:TEXT <Label>

This command defines the contents of a trace label.

Suffix: <n></n>	1n Window	
<t></t>	1n Trace	
Parameters: <label></label>	String containing the trace label.	
Example:	<pre>//Assign a label to trace 2. DISP:TRAC2:LAB:TEXT 'A YELLOW TRACE'</pre>	

# DISPlay[:WINDow<n>]:TRACe<t>:PERSistence:DECay <Decay>

This command defines the time period that an event remains visible until it fades away (decay).

Prerequisites for this command

• Turn on persistence (DISPlay[:WINDow<n>]:TRACe<t>:PERSistence[: STATe]).

Suffix: <n></n>	1n Window	
<t></t>	1n Trace	
Parameters: <decay></decay>	<numeric value=""> Range: 0 s to 8 s *RST: 0 Default unit: s</numeric>	
Example:	<pre>//Turn on persistence for trace 2 with a decay of 2 seconds DISP:TRAC2:PERS ON DISP:TRAC2:PERS:DEC 2s</pre>	
Manual operation:	See "Displaying persistence" on page 208	

# DISPlay[:WINDow<n>]:TRACe<t>:PERSistence[:STATe] <State>

This command turns persistence for a trace on and off.

Suffix:		
<n></n>	1n Window	
<t></t>	1n Trace	
Parameters:		
<state></state>	ON   OFF   1   0	
	*RST: OFF	
Example:	//Turn on persistence for trace 2 DISP:TRAC2:PERS ON	
Manual operation:	See "Displaying persistence" on page 208	

# DISPlay[:WINDow<n>]:TRACe<t>:RESult[:TYPE] <Resulttype>

This command selects the type of noise represented by the trace.

Suffix: <n></n>	1n Window
<t></t>	1n Trace
Parameters:	
<resulttype></resulttype>	PN Phase noise results. AM
	AM noise results.
	<b>PNAM</b> Sum of phase noise and AM noise.
Example:	//Show AM noise characteristics on trace 2 DISP:TRAC2:RES AM
Manual operation:	See "Selecting the displayed result" on page 207

# DISPlay[:WINDow<n>][:SUBWindow<w>]:TRACe<t>[:STATe] <State>

This command turns a trace on and off.

The measurement continues in the background.

Suffix: <n>

- Window
- <w>

subwindow Not supported by all applications

<t></t>	Trace
Parameters: <state></state>	ON   OFF   0   1 <b>OFF   0</b> Switches the function off <b>ON   1</b> Switches the function on
Example:	DISP:TRAC3 ON
Manual operation:	See " Trace 1 / Trace 2 / Trace 3 / Trace 4 / Trace 5 / Trace 6 " on page 207

# DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel:OFFSet <Offset>

This command defines the amount by which a trace is shifted.

Prerequisites for this command

• Turn on trace offset (DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel: OFFSet:STATe).

Suffix: <n></n>	1n irrelevant	
<t></t>	1n irrelevant	
Parameters:		
<offset></offset>	<numeric value=""></numeric>	
	*RST: 0 Default unit: dB	
Example:	<pre>//Define a level offset of 10 dB DISP:TRAC:Y:RLEV:OFFS 10</pre>	
Manual operation:	See "Shifting the trace" on page 208	

# DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel:OFFSet:STATe <State>

This command turns the offset for a trace on and off.

When you turn that feature on, the trace is shifted vertically by a certain amount.

Suffix:	
<n></n>	1n
	Window
<t></t>	1n
	Trace

Parameters: <state></state>	ON   OFF   1   0 *RST: OFF
Example:	<pre>//Shift trace 2 vertically by 10 dB. DISP:TRAC2:Y:RLEV:OFFS:STAT ON DISP:TRAC2:Y:RLEV:OFFS 10</pre>
Manual operation:	See "Shifting the trace" on page 208

#### DISPlay[:WINDow<n>]:TRACe<t>:SMOothing:APERture <Aperture>

This command defines the magnitude (aperture) of trace smoothing.

Prerequisites for this command

• Turn on trace smoothing (DISPlay[:WINDow<n>]:TRACe<t>:SMOothing[: STATe]).

In the Spot Noise vs Tune measurement, trace smoothing applies to either all traces or none. Use [SENSe:]SMOothing[:STATe] in that case.

Suffix:	
<n></n>	1n Window
<t></t>	1n Trace
Parameters:	
<aperture></aperture>	<numeric value=""></numeric>
	Range: 1 to 20
	*RST: 1
	Default unit: PCT
Example:	<pre>See DISPlay[:WINDow<n>]:TRACe<t>:SMOothing[: STATe].</t></n></pre>
Manual operation:	See "Smoothing traces" on page 208

#### DISPlay[:WINDow<n>]:TRACe<t>:SMOothing[:STATe] <State>

This command turns trace smoothing for a specific trace on and off.

When you turn on trace smoothing, you can define the smoothing magnitude with DISPlay[:WINDow<n>]:TRACe<t>:SMOothing:APERture.

In the Spot Noise vs Tune measurement, trace smoothing applies to either all traces or none. Use [SENSe:]SMOothing[:STATe] in that case.

#### Suffix:

<n>

1..n Window

<t></t>	1n Trace
Parameters: <state></state>	ON   OFF   1   0 *RST: Depends on the trace.
Example:	<pre>//Turns on trace 3 (average mode based on 10 measurements) to display the AM noise results DISP:TRAC3:MODE AVER SWE:COUN 10 DISP:TRAC3:RES AM //Smooth the trace by a magnitude of 10 % DISP:TRAC3:SMO ON DISP:TRAC3:SMO:APER 10 //Remove spurs from trace 3 DISP:TRAC3:SPUR:SUPP ON DISP:TRAC3:SPUR:THR 5</pre>
Manual operation:	See "Smoothing traces" on page 208

# 15.7.3.2 Trace Copy

TRACe<n>:COPY <TraceNumber>, <TraceNumber>

This command copies data from one trace to another.

Suffix: <n></n>	Window
Parameters: <tracenumber></tracenumber>	<b>TRACE1   TRACE2   TRACE3   TRACE4   TRACE5   TRACE6</b> The first parameter is the destination trace, the second parame- ter is the source. (Note the 'e' in the parameter is required!)
Example:	TRAC:COPY TRACE1, TRACE2 Copies the data from trace 2 to trace 1.
Manual operation:	See " Copy Trace " on page 214

# 15.7.3.3 Trace Export and Import

FORMat[:DATA]		
FORMat:DEXPort:	CSEParator	
FORMat:DEXPort:	DSEParator	
FORMat:DEXPort:	FORMat	
FORMat:DEXPort:	HEADer	
FORMat:DEXPort:	TRACes	
MMEMory:LOAD <r< td=""><th>n&gt;:TRACe</th><td>521</td></r<>	n>:TRACe	521

# FORMat[:DATA] <Format>[, <BitLength>]

This command selects the data format that is used for transmission of trace data from the R&S FSWP to the controlling computer.

Note that the command has no effect for data that you send to the R&S FSWP. The R&S FSWP automatically recognizes the data it receives, regardless of the format.

For details on data formats see Chapter 15.7.3.5, "Formats for Returned Values: ASCII Format and Binary Format", on page 524.

#### **Parameters:**

<format></format>	ASCii ASCii format, separated by commas. This format is almost always suitable, regardless of the actual data format. However, the data is not as compact as other for- mats may be.
	REAL Floating-point numbers (according to IEEE 754) in the "definite length block format". The format setting REAL is used for the binary transmission of trace data.
<bitlength></bitlength>	Length in bits for floating-point results <b>16</b> 16-bit floating-point numbers. Compared to REAL, 32 format, half as many numbers are returned. <b>32</b> 32-bit floating-point numbers For I/Q data, 8 bytes per sample are returned for this format set- ting. <b>64</b> 64-bit floating-point numbers Compared to REAL, 32 format, twice as many numbers are returned.
Example:	FORM REAL, 32

# FORMat:DEXPort:CSEParator <Separator>

This command selects the column separator for exported trace data.

The selected value is not affected by a preset. The command therefore has no reset value.

**Parameters:** <Separator>

COMMa Selects a comma as a separator. **SEMicolon** Selects a semicolon as a separator.

	<b>TAB</b> Selects a ta	ibulator as a separator.
	*RST:	n/a
Example:		umn separator P:CSEP TAB
Manual operation:	See "Colum	nn Separator" on page 212

# FORMat:DEXPort:DSEParator <Separator>

This command selects the decimal separator for data exported in ASCII format.

Parameters:			
<separator></separator>	POINt   COMMa		
	СОММа		
	Uses a comma as decimal separator, e.g. 4,05.		
	POINt		
	Uses a point as decimal separator, e.g. 4.05.		
	*RST:	*RST has no effect on the decimal separator. Default is POINt.	
Example:	FORM:DEXP:DSEP POIN		
	Sets the de	cimal point as separator.	
Manual operation:	See " Decimal Separator " on page 212		

#### FORMat:DEXPort:FORMat <FileFormat>

Determines the format of the ASCII file to be imported or exported. Depending on the external program in which the data file was created or will be evaluated, a comma-separated list (CSV) or a plain data format (DAT) file may be required.

<pre>Parameters: <fileformat></fileformat></pre>	CSV   DAT	
	*RST:	DAT
Example:	FORM:DEXE	FORM CSV
Manual operation:	See " File T	ype " on page 212

# FORMat:DEXPort:HEADer <State>

If enabled, additional instrument and measurement settings are included in the header of the export file for result data. If disabled, only the pure result data from the selected traces and tables is exported.

#### **Parameters:**

<state></state>	ON   OFF	0 1
	*RST:	1

Manual operation: See " Include Instrument & Measurement Settings " on page 210

#### FORMat:DEXPort:TRACes <Selection>

This command selects the data to be included in a data export file (see MMEMory: STORe<n>:TRACe on page 576).

# **Parameters:**

<Selection>

SINGle | ALL

# SINGle

Only a single trace is selected for export, namely the one specified by the MMEMory: STORe<n>: TRACe command.

# ALL

Selects all active traces and result tables (e.g. Result Summary, marker peak list etc.) in the current application for export to an ASCII file.

The <trace> parameter for the MMEMory: STORe<n>: TRACe command is ignored.

\*RST: SINGle

Manual operation: See "Export all Traces and all Table Results " on page 210

MMEMory:LOAD<n>:TRACe <FileName>[, <Window>, <Trace>, <Trace>]

This commans imports a previously recorded trace.

# Secure User Mode

In secure user mode, settings that are stored on the instrument are stored to volatile memory, which is restricted to 256 MB. Thus, a "memory limit reached" error can occur although the hard disk indicates that storage space is still available.

To store data permanently, select an external storage location such as a USB memory device.

For details, see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

#### Suffix:

ounix.	
<n></n>	1n
	Destination Window
Parameters:	
<filename></filename>	String that contains the location of the ASCII file you want to import.
	Supported file types are .dat and .csv.
<window></window>	<numeric value=""> (integer only)</numeric>
	Optional.
	Selects the source window of the trace that you want to import. Because the ASCII file can contain trace information for several result windows, you can select a specfic result window whose trace(s) are imported.

	The selected window must be compatible to the destination win- dows selected by the suffix at the LOAD <n> syntax element. For example if you want to import the data of a phase noise trace, a phase noise diagram must be active. If you omit the source window, the R&amp;S FSWP checks if the import data is compatible to the diagram that you have selected. If not, the command throws an error and the data is not impor- ted. Range: 1 to 16</n>
<trace></trace>	<numeric value=""> (integer only)</numeric>
	Optional. Selects the number of the source trace. The source trace is the trace you want to import. Range: 1 to 6
<trace></trace>	<numeric value=""> (integer only)</numeric>
	Optional. Selects the number of the destination trace. The destination trace is the trace you want to write the imported trace to. Range: 1 to 6
Example:	//Import all compatible traces from an ASCII file into window 2 MMEM:LOAD2:TRAC 'c:\trace.dat'
Example:	<pre>//Import all traces stored as window 1 into window 2 MMEM:LOAD2:TRAC 'c:\trace.dat',1</pre>
Example:	<pre>//Import a single trace from ASCII file MMEM:LOAD:TRAC 'c:\trace.dat',2,1,5</pre>
Manual operation:	See "Select ASCII File" on page 212 See "Source Window / Source Trace" on page 213 See "Destination Trace" on page 213 See "Import" on page 213

# 15.7.3.4 Trace Mathematics

CALCulate <n>:MATH:STATe</n>	22
CALCulate <n>:MATH[:EXPRession][:DEFine]5</n>	23

# CALCulate<n>:MATH:STATe <State>

This command turns trace mathematics on and off.

Suffix:	
<n></n>	1n
	Window
Parameters:	
<state></state>	ON   1
	Turns trace mathematics on and selects the operation that has
	been selected last (or (TRACE1-TRACE3) if you have not yet
	selected one).
	OFF   0
	Turns trace mathematics off.
	*RST: OFF
Example:	//Turn on trace 3, subtract it from trace 2 and write the result to
	trace 2
	DISP:TRAC3:MODE WRIT
	CALC:MATH (TRACE2-TRACE3)
	//Turn off trace mathematics
	CALC:MATH:STAT OFF
	//Turn them on again and selects the operation (TRACE2-
	TRACE3). CALC:MATH:STAT ON
	CALC:MAIN:STAT UN
Manual operation:	See "Selecting the math operation" on page 214

# CALCulate<n>:MATH[:EXPRession][:DEFine] <Operation>

This command selects the operation for trace mathematics.

Suffix:			
<n></n>	1n Window		
Setting parameters:	3:		
<operation></operation>	Depending on the operation you select, one trace is subtracted from another. The result is written to the first trace indicated in the operation.		
	An operation is only available if both traces are actually turned on.		
	(TRACE1-TRACE3)		
	(TRACE2-TRACE3)		
	(TRACE4-TRACE6)		
	(TRACE5-TRACE6)		
	*RST: Trace mathematics are off.		
Example:	//Subtract trace 2 from trace 1 and write the result to trace 1 CALC:MATH (TRACE1-TRACE2)		
Manual operation:	See "Selecting the math operation" on page 214		

# 15.7.3.5 Formats for Returned Values: ASCII Format and Binary Format

When trace data is retrieved using the TRAC: DATA or TRAC: IQ: DATA command, the data is returned in the format defined using the FORMat [:DATA] on page 519. The possible formats are described here.

- ASCII Format (FORMat ASCII): The data is stored as a list of comma-separated values (CSV) of the measured values in floating point format.
- Binary Format (FORMat REAL, 16/32/64): The data is stored as binary data (definite length block data according to IEEE 488.2), each measurement value being formatted in 16-bit/32-bit/64-bit IEEE 754 floating-point-format.

The schema of the result string is as follows:

#41024<value1><value2>...<value n> with:

#4	Number of digits (= 4 in the example) of the following number of data bytes
1024	Number of following data bytes (= 1024 in the example)
<value></value>	2-byte/4-byte/8-byte floating point value



Reading out data in binary format is quicker than in ASCII format. Thus, binary format is recommended for large amounts of data.

# 15.7.4 Marker

Individual Marker Setup	. 524
Marker Search	
	Individual Marker Setup General Marker Settings Marker Search Positioning Markers. Retrieving Marker Positions

# 15.7.4.1 Individual Marker Setup

CALCulate <n>:DELTamarker<m>:AOFF</m></n>	
CALCulate <n>:DELTamarker<m>:LINK</m></n>	
CALCulate <n>:DELTamarker<ms>:LINK:TO:MARKer<md></md></ms></n>	
CALCulate <n>:DELTamarker<m>:MODE</m></n>	526
CALCulate <n>:DELTamarker<m>:MREFerence</m></n>	
CALCulate <n>:DELTamarker<m>[:STATe]</m></n>	
CALCulate <n>:DELTamarker<m>:TRACe</m></n>	
CALCulate <n>:DELTamarker<m>:X</m></n>	
CALCulate <n>:MARKer<m>:AOFF</m></n>	
CALCulate <n>:MARKer<ms>:LINK:TO:MARKer<md></md></ms></n>	
CALCulate <n>:MARKer<m>[:STATe]</m></n>	528
CALCulate <n>:MARKer<m>:TRACe</m></n>	
CALCulate <n>:MARKer<m>:X</m></n>	529

#### CALCulate<n>:DELTamarker<m>:AOFF

This command turns off *all* delta markers.

Suffix:	
<n></n>	Window
<m></m>	irrelevant
Example:	CALC:DELT:AOFF Turns off all delta markers.

#### CALCulate<n>:DELTamarker<m>:LINK <State>

This command links delta marker <m> to marker 1.

If you change the horizontal position (x-value) of marker 1, delta marker <m> changes its horizontal position to the same value.

Suffix: <n></n>	Window
<m></m>	Marker
Parameters: <state></state>	ON   OFF   0   1 <b>OFF   0</b> Switches the function off <b>ON   1</b> Switches the function on
Example:	CALC:DELT2:LINK ON
Manual operation:	See " Linking to Another Marker " on page 227

# CALCulate<n>:DELTamarker<ms>:LINK:TO:MARKer<md> <State>

This command links delta marker <m1> to any active normal marker <m2>.

If you change the horizontal position of marker <m2>, delta marker <m1> changes its horizontal position to the same value.

Suffix: <n></n>	Window
<ms></ms>	source marker, see Marker
<md></md>	destination marker, see Marker
Parameters: <state></state>	ON   OFF   0   1
	<b>OFF   0</b> Switches the function off
	<b>ON   1</b> Switches the function on

Example:	CALC:DELT4:LINK:TO:MARK2 ON
	Links the delta marker 4 to the marker 2.
Manual operation:	See " Linking to Another Marker " on page 227

# CALCulate<n>:DELTamarker<m>:MODE <Mode>

This command defines whether the position of a delta marker is provided as an absolute value or relative to a reference marker.

Note that when the position of a delta marker is *queried*, the result is always an absolute value (see CALCulate<n>:DELTamarker<m>:X on page 527)!

#### Suffix:

<n></n>	Window
<m></m>	irrelevant
Parameters: <mode></mode>	ABSolute Delta marker position in absolute terms. RELative Delta marker position in relation to a reference marker. *RST: RELative
Example:	CALC:DELT:MODE ABS Absolute delta marker position.

# CALCulate<n>:DELTamarker<m>:MREFerence <Reference>

This command selects a reference marker for a delta marker other than marker 1.

Suffix: <n></n>	Window
<m></m>	Marker
Parameters: <pre><reference></reference></pre>	
Example:	CALC: DELT3:MREF 2 Specifies that the values of delta marker 3 are relative to marker 2.
Manual operation:	See " Reference Marker " on page 227

# CALCulate<n>:DELTamarker<m>[:STATe] <State>

This command turns delta markers on and off.

If necessary, the command activates the delta marker first.

No suffix at DELTamarker turns on delta marker 1.

Suffix: <n></n>	Window
<m></m>	Marker
Parameters: <state></state>	ON   OFF   0   1 OFF   0 Switches the function off ON   1 Switches the function on
Example:	CALC:DELT2 ON Turns on delta marker 2.
Manual operation:	See " Marker State " on page 226 See " Marker Type " on page 227 See " Select Marker " on page 228

# CALCulate<n>:DELTamarker<m>:TRACe <Trace>

This command selects the trace a delta marker is positioned on.

Note that the corresponding trace must have a trace mode other than "Blank".

If necessary, the command activates the marker first.

Suffix:	
<n></n>	Window
<m></m>	Marker
Parameters: <trace></trace>	Trace number the marker is assigned to.
Example:	CALC: DELT2: TRAC 2 Positions delta marker 2 on trace 2.

# CALCulate<n>:DELTamarker<m>:X <Position>

This command moves a delta marker to a particular coordinate on the x-axis.

If necessary, the command activates the delta marker and positions a reference marker to the peak power.

Suffix:		
<n></n>	Window	
<m></m>	Marker	
Parameters: <position></position>	Numeric value that defines the marker position on the x-axis.	
	Range:	The value range and unit depend on the measure- ment and scale of the x-axis.

Example:	CALC:DELT:X?
	Outputs the absolute x-value of delta marker 1.
Manual operation:	See "Marker Position X-value " on page 227

# CALCulate<n>:MARKer<m>:AOFF

This command turns off all markers.

Suffix:	
<n></n>	Window
<m></m>	Marker
Example:	CALC:MARK:AOFF Switches off all markers.
Manual operation:	See " All Markers Off " on page 228

# CALCulate<n>:MARKer<ms>:LINK:TO:MARKer<md> <State>

This command links normal marker <m1> to any active normal marker <m2>.

If you change the horizontal position of marker <m2>, marker <m1> changes its horizontal position to the same value.

<n></n>	Window
<ms></ms>	source marker, see Marker
<md></md>	destination marker, see Marker
Parameters: <state></state>	ON   OFF   0   1 <b>OFF   0</b> Switches the function off <b>ON   1</b> Switches the function on
Example:	CALC:MARK4:LINK:TO:MARK2 ON Links marker 4 to marker 2.
Manual operation:	See " Linking to Another Marker " on page 227

# CALCulate<n>:MARKer<m>[:STATe] <State>

Window

This command turns markers on and off. If the corresponding marker number is currently active as a delta marker, it is turned into a normal marker.

Suffix: <n>

Suffix

<m></m>	Marker	
Parameters: <state></state>	ON   OFF   0   1 <b>OFF   0</b> Switches the function off	
	<b>ON   1</b> Switches the function on	
Example:	CALC:MARK3 ON Switches on marker 3.	
Manual operation:	See " Marker State " on page 226 See " Marker Type " on page 227 See " Select Marker " on page 228	

#### CALCulate<n>:MARKer<m>:TRACe <Trace>

This command selects the trace the marker is positioned on.

Note that the corresponding trace must have a trace mode other than "Blank".

If necessary, the command activates the marker first.

Suffix: <n></n>	Window
<m></m>	Marker
Parameters: <trace></trace>	
Example:	//Assign marker to trace 1 CALC:MARK3:TRAC 2
Manual operation:	See " Assigning the Marker to a Trace " on page 228

#### CALCulate<n>:MARKer<m>:X <Position>

This command moves a marker to a specific coordinate on the x-axis.

If necessary, the command activates the marker.

If the marker has been used as a delta marker, the command turns it into a normal marker.

# Suffix:

<n>

Window

<m> Marker

# Parameters: <Position>

Numeric value that defines the marker position on the x-axis. The unit depends on the result display. Range: The range depends on the current x-axis range. Default unit: Hz

Example:	CALC:MARK2:X 1.7MHz Positions marker 2 to frequency 1.7 MHz.
Manual operation:	See "Marker Table " on page 121 See "Marker Position X-value " on page 227

# 15.7.4.2 General Marker Settings

DISPlay[:WINDow <n>]:MTABle</n>	30
CALCulate <n>:MARKer<m>:LINK</m></n>	80

# DISPlay[:WINDow<n>]:MTABle <DisplayMode>

This command turns the marker table on and off.

Suffix: <n></n>	irrelevant	
Parameters: <displaymode></displaymode>	<b>ON   1</b> Turns on the	e marker table.
	OFF   0 Turns off the *RST:	e marker table. AUTO
Example:	DISP:MTAB Activates the	ON e marker table.
Manual operation:	See " Marke	r Table Display " on page 229

# CALCulate<n>:MARKer<m>:LINK <State>

This command defines whether all markers within the selected result display are linked. If enabled, and you move one marker along the x-axis, all other markers in the display are moved to the same x-axis position.

Suffix: <m></m>	irrelevant	
<n></n>	Window	
Parameters: <state></state>	ON   OFF   1   0 *RST: 0	
Example:	CALC2:MARK:LINK ON	
Manual operation:	See "Linked Markers" on page 229	

# 15.7.4.3 Marker Search

0.0

CALCulate <n>:MARKer<m>:PEXCursion</m></n>	531
CALCulate <n>:MARKer<m>:FUNCtion:SPTRacking:RANGe</m></n>	531
CALCulate <n>:MARKer<m>:FUNCtion:SPTRacking[:STATe]</m></n>	532

#### CALCulate<n>:MARKer<m>:PEXCursion < Excursion>

This command defines the peak excursion (for all markers).

The peak excursion sets the requirements for a peak to be detected during a peak search.

The unit depends on the measurement.

Suffix:	
<n></n>	Window
<m></m>	irrelevant
Example:	CALC:MARK:PEXC 10dB Defines peak excursion as 10 dB.
Manual operation:	See " Peak Excursion " on page 230

# CALCulate<n>:MARKer<m>:FUNCtion:SPTRacking:RANGe <Range>

This command defines the frequency range in which spur tracking takes place.

Prerequisites for this command

 Turn on spur tracking (CALCulate<n>:MARKer<m>:FUNCtion:SPTRacking[: STATe]).

#### Suffix:

<n></n>	1n irrelevant	
<m></m>	1n irrelevant	
<b>Parameters:</b> <range></range>	<numeric value=""></numeric>	
	Number without unit that defines the frequency range as a function of the resolution bandwidth. Tracking range = $x * RBW$	
	*RST: 1.0	
Example:	<pre>//Turn on spur tracking and define a tracking range of 2 x RBW CALC:MARK:FUNC:SPTR ON CALC:MARK:FUNC:SPTR:RANG 2</pre>	
Manual operation:	See "Spurious Tracking" on page 230	

# CALCulate<n>:MARKer<m>:FUNCtion:SPTRacking[:STATe] <State>

This command turns spurious tracking on and off.

Suffix:	
<n></n>	1n irrelevant
<m></m>	1n irrelevant
Parameters:	
<state></state>	ON   OFF   1   0
	*RST: OFF
Example:	//Turn on spur tracking CALC:MARK:FUNC:SPTR ON
Manual operation:	See "Spurious Tracking" on page 230

# 15.7.4.4 Positioning Markers

CALCulate <n>:DELTamarker<m>:MAXimum:LEFT</m></n>	532
CALCulate <n>:DELTamarker<m>:MAXimum:NEXT</m></n>	533
CALCulate <n>:DELTamarker<m>:MAXimum:RIGHt</m></n>	533
CALCulate <n>:DELTamarker<m>:MAXimum[:PEAK]</m></n>	533
CALCulate <n>:DELTamarker<m>:MINimum:LEFT</m></n>	533
CALCulate <n>:DELTamarker<m>:MINimum:NEXT</m></n>	
CALCulate <n>:DELTamarker<m>:MINimum:RIGHt</m></n>	534
CALCulate <n>:DELTamarker<m>:MINimum[:PEAK]</m></n>	534
CALCulate <n>:MARKer<m>:MAXimum:LEFT</m></n>	534
CALCulate <n>:MARKer<m>:MAXimum:NEXT</m></n>	534
CALCulate <n>:MARKer<m>:MAXimum:RIGHt</m></n>	535
CALCulate <n>:MARKer<m>:MAXimum[:PEAK]</m></n>	535
CALCulate <n>:MARKer<m>:MINimum:LEFT</m></n>	535
CALCulate <n>:MARKer<m>:MINimum:NEXT</m></n>	
CALCulate <n>:MARKer<m>:MINimum:RIGHt</m></n>	
CALCulate <n>:MARKer<m>:MINimum[:PEAK]</m></n>	536

#### CALCulate<n>:DELTamarker<m>:MAXimum:LEFT

This command moves a delta marker to the next higher value.

The search includes only measurement values to the left of the current marker position.

# Suffix: <n> Window <m> Marker Manual operation: See " Search Next Peak " on page 231

#### CALCulate<n>:DELTamarker<m>:MAXimum:NEXT

This command moves a marker to the next higher value.

Suffix:	
<n></n>	1n Window
<m></m>	1n Marker
Manual operation:	See " Search Next Peak " on page 231

#### CALCulate<n>:DELTamarker<m>:MAXimum:RIGHt

This command moves a delta marker to the next higher value.

The search includes only measurement values to the right of the current marker position.

Suffix:	
<n></n>	Window
<m></m>	Marker
Manual operation:	See " Search Next Peak " on page 231

#### CALCulate<n>:DELTamarker<m>:MAXimum[:PEAK]

This command moves a delta marker to the highest level.

If the marker is not yet active, the command first activates the marker.

Suffix: <n></n>	Window
<m></m>	Marker
Manual operation:	See " Peak Search " on page 231

#### CALCulate<n>:DELTamarker<m>:MINimum:LEFT

This command moves a delta marker to the next higher minimum value.

The search includes only measurement values to the right of the current marker position.

Suffix:	
<n></n>	Window
<m></m>	Marker
Manual operation:	See " Search Next Minimum " on page 232

# CALCulate<n>:DELTamarker<m>:MINimum:NEXT

This command moves a marker to the next higher minimum value.

Suffix:	
<n></n>	Window
<m></m>	Marker
Manual operation:	See " Search Next Minimum " on page 232

#### CALCulate<n>:DELTamarker<m>:MINimum:RIGHt

This command moves a delta marker to the next higher minimum value.

The search includes only measurement values to the right of the current marker position.

Suffix:	
<n></n>	Window
<m></m>	Marker
Manual operation:	See " Search Next Minimum " on page 232

#### CALCulate<n>:DELTamarker<m>:MINimum[:PEAK]

This command moves a delta marker to the minimum level.

If the marker is not yet active, the command first activates the marker.

Suffix:	
<n></n>	Window
<m></m>	Marker
Manual operation:	See " Search Minimum " on page 231

# CALCulate<n>:MARKer<m>:MAXimum:LEFT

This command moves a marker to the next lower peak.

The search includes only measurement values to the left of the current marker position.

Window
Marker
See " Search Next Peak " on page 231

#### CALCulate<n>:MARKer<m>:MAXimum:NEXT

This command moves a marker to the next lower peak.

Suffix

Suffix:	
<n></n>	Window
<m></m>	Marker
Manual operation:	See " Search Next Peak " on page 231

# CALCulate<n>:MARKer<m>:MAXimum:RIGHt

This command moves a marker to the next lower peak.

The search includes only measurement values to the right of the current marker position.

Suffix: <n></n>	Window
<m></m>	Marker
Manual operation:	See " Search Next Peak " on page 231

#### CALCulate<n>:MARKer<m>:MAXimum[:PEAK]

This command moves a marker to the highest level.

If the marker is not yet active, the command first activates the marker.

Suffix:	
<n></n>	Window
<m></m>	Marker
Manual operation:	See " Peak Search " on page 231

#### CALCulate<n>:MARKer<m>:MINimum:LEFT

This command moves a marker to the next minimum value.

The search includes only measurement values to the right of the current marker position.

#### Suffix:

Manual operation:	See " Search Next Minimum " on page 232
<m></m>	Marker
<n></n>	Window

#### CALCulate<n>:MARKer<m>:MINimum:NEXT

This command moves a marker to the next minimum value.

Suffix: <n> Window <m>

Marker

Manual operation: See " Search Next Minimum " on page 232

#### CALCulate<n>:MARKer<m>:MINimum:RIGHt

This command moves a marker to the next minimum value.

The search includes only measurement values to the right of the current marker position.

Suffix:	
<n></n>	Window
<m></m>	Marker
Manual operation:	See " Search Next Minimum " on page 232

# CALCulate<n>:MARKer<m>:MINimum[:PEAK]

This command moves a marker to the minimum level.

If the marker is not yet active, the command first activates the marker.

Suffix:	
<n></n>	Window
<m></m>	Marker
Manual operation:	See " Search Minimum " on page 231

# 15.7.4.5 Retrieving Marker Positions

Commands useful to retrieve marker positions described elsewhere:

- CALCulate<n>:DELTamarker<m>:X
- CALCulate<n>:MARKer<m>:X

CALCulate <n>:DELTamarker<m>:X:RELative?</m></n>	. 536
CALCulate <n>:DELTamarker<m>:Y?</m></n>	. 537
CALCulate <n>:MARKer<m>:Y?</m></n>	.537

#### CALCulate<n>:DELTamarker<m>:X:RELative?

This command queries the relative position of a delta marker on the x-axis.

If necessary, the command activates the delta marker first.

Suffix:	Minday
<n></n>	Window
<m></m>	Marker
<b>Return values:</b> <position></position>	Position of the delta marker in relation to the reference marker.

Example:	CALC:DELT3:X:REL? Outputs the frequency of delta marker 3 relative to marker 1 or relative to the reference position.
Usage:	Query only

# CALCulate<n>:DELTamarker<m>:Y?

Queries the result at the position of the specified delta marker.

Suffix: <n></n>	1n
<m></m>	1n
<b>Return values:</b> <result></result>	Result at the position of the delta marker. The unit is variable and depends on the one you have currently set. Default unit: DBM
Usage:	Query only

# CALCulate<n>:MARKer<m>:Y?

Queries the result at the position of the specified marker.

Suffix:	
<n></n>	1n
<m></m>	1n
Return values:	
<result></result>	Default unit: DBM
Usage:	Query only

# 15.7.5 Limit Lines

•	Managing Limit Lines	. 537
•	Designing Limit Lines	.542
	Reading out the Results of a Limit Check	
•	Programming Example: Using Limit Lines	. 548

# 15.7.5.1 Managing Limit Lines

CALCulate <n>:LIMit<li>:ACTive?</li></n>	538
CALCulate <n>:LIMit<k>:COMPatible?</k></n>	538
CALCulate <n>:LIMit<li>:COPY</li></n>	538
CALCulate <n>:LIMit<li>:DELete</li></n>	
CALCulate <n>:LIMit<li>:LOWer:OFFSet</li></n>	539
CALCulate <n>:LIMit<li>:LOWer:STATe</li></n>	539

CALCulate <n>:LIMit<li>:STATe</li></n>	.540
CALCulate <n>:LIMit<li>:TRACe<t></t></li></n>	540
CALCulate <n>:LIMit<li>:TRACe<t>:CHECk</t></li></n>	. 541
CALCulate <n>:LIMit<li>:UPPer:STATe</li></n>	. 541

# CALCulate<n>:LIMit:ACTive?

This command queries the names of all active limit lines.

Suffix: <n></n>	irrelevant
< i>	irrelevant
<b>Return values:</b> <limitlines></limitlines>	String containing the names of all active limit lines in alphabeti- cal order.
Example:	CALC:LIM:ACT? Queries the names of all active limit lines.
Usage:	Query only
Manual operation:	See " Visibility " on page 237

#### CALCulate<n>:LIMit<k>:COMPatible?

This command queries if the currently selected limit line is compatible to the current measurement configuration.

C	ı ıff	iv.
J	un	I <b>A</b> .

<n></n>	1n irrelevant
<k></k>	1n Limit line
<b>Return values:</b> <mkrindex></mkrindex>	<ul> <li>1</li> <li>Limit line is compatible to the current measurement settings.</li> <li>0</li> <li>Limit line is not compatible to the current measurement settings.</li> </ul>
Example:	<pre>//Query limit line compatibility CALC:LIM:NAME 'Limit' CALC:LIM:COMP?</pre>
Usage:	Query only

#### CALCulate<n>:LIMit:COPY <Line>

This command copies a limit line.

Suffix:

<n>

Window

<li></li>	Limit line
Parameters: <line></line>	1 to 8 number of the new limit line
	<name> String containing the name of the limit line.</name>
Example:	CALC:LIM1:COPY 2 Copies limit line 1 to line 2. CALC:LIM1:COPY 'FM2' Copies limit line 1 to a new line named FM2.
Manual operation:	See " Copy Line " on page 238

# CALCulate<n>:LIMit:DELete

This command deletes a limit line.

- ----

Suffix:		
<n></n>	Window	
< i>	Limit line	
Manual operation:	See " Delete Line " on page 238	

# CALCulate<n>:LIMit:LOWer:OFFSet <Offset>

This command defines an offset for a complete lower limit line.

Compared to shifting the limit line, an offset does not actually change the limit line definition points.

Suffix: <n> <li></li></n>	Window Limit line
Parameters: <offset></offset>	Numeric value. *RST: 0 Default unit: dB

# CALCulate<n>:LIMit:LOWer:STATe <State>

This command turns a lower limit line on and off.

Before you can use the command, you have to select a limit line with CALCulate<n>: LIMit:NAME on page 546.

Suffix: <n>

irrelevant

< i>	Limit line
Parameters:	
<state> ON   OFF   0   1</state>	
	OFF   0
	Switches the function off
	ON   1
	Switches the function on
Manual operation:	See " Visibility " on page 237

# CALCulate<n>:LIMit:STATe <State>

This command turns the limit check for a specific limit line on and off.

To query the limit check result, use CALCulate<n>:LIMit:FAIL?.

Note that a new command exists to activate the limit check and define the trace to be checked in one step (see CALCulate<n>:LIMit:TRACe<t>:CHECk on page 541).

Suffix:	
<n></n>	irrelevant
< i>	Limit line
Parameters:	
<state></state>	ON   OFF   0   1
	OFF   0
	Switches the function off
	ON   1
	Switches the function on
Example:	CALC:LIM:STAT ON
·	Switches on the limit check for limit line 1.
Manual operation: See " Disable All Lines " on page 238	

#### CALCulate<n>:LIMit:TRACe<t> <TraceNumber>

This command links a limit line to one or more traces.

Note that this command is maintained for compatibility reasons only. Limit lines no longer need to be assigned to a trace explicitly. The trace to be checked can be defined directly (as a suffix) in the new command to activate the limit check (see CALCulate<n>:LIMit:TRACe<t>:CHECk on page 541).

#### Suffix:

<n></n>	Window
< i>	Limit line
<t></t>	irrelevant

Example:

CALC:LIM2:TRAC 3 Assigns limit line 2 to trace 3.

#### CALCulate<n>:LIMit:TRACe<t>:CHECk <State>

This command turns the limit check for a specific trace on and off.

To query the limit check result, use CALCulate<n>:LIMit:FAIL?.

Note that this command replaces the two commands from previous signal and spectrum analyzers (which are still supported, however):

- CALCulate<n>:LIMit:TRACe<t> on page 540
- CALCulate<n>:LIMit:STATe on page 540

## Suffix:

<n></n>	Window
< i>	Limit line
<t></t>	Trace
Parameters: <state></state>	ON   OFF   0   1 <b>OFF   0</b> Switches the function off <b>ON   1</b> Switches the function on
Example:	CALC:LIM3:TRAC2:CHEC ON Switches on the limit check for limit line 3 on trace 2.
Manual operation:	See " Traces to be Checked " on page 237

#### CALCulate<n>:LIMit:UPPer:STATe <State>

This command turns an upper limit line on and off.

Before you can use the command, you have to select a limit line with CALCulate<n>: LIMit: NAME on page 546.

Suffix: <n></n>	irrelevant
< j>	Limit line
Parameters: <state></state>	ON   OFF   0   1 <b>OFF   0</b> Switches the function off
	<b>ON   1</b> Switches the function on
Manual operation:	See " Visibility " on page 237

0.0

## 15.7.5.2 Designing Limit Lines

CALCulate <n>:LIMit<li>:COMMent CALCulate<n>:LIMit<li>:CONTrol[:DATA] CALCulate<n>:LIMit<li>:CONTrol:DOMain</li></n></li></n></li></n>	542
CALCulate <n>:LIMit<li>:CONTrol:MODE</li></n>	543
CALCulate <n>:LIMit<li>:CONTrol:SHIFt CALCulate<n>:LIMit<li>:CONTrol:SPACing</li></n></li></n>	544
CALCulate <n>:LIMit<li>:LOWer[:DATA] CALCulate<n>:LIMit<li>:LOWer:MODE</li></n></li></n>	
CALCulate <n>:LIMit<li>:LOWer:SHIFt CALCulate<n>:LIMit<li>:LOWer:SPACing</li></n></li></n>	
CALCulate <n>:LIMit<li>:NAME CALCulate<n>:LIMit<li>:UNIT</li></n></li></n>	546
CALCulate <n>:LIMit<li>:UPPer[:DATA]</li></n>	546
CALCulate <n>:LIMit<li>:UPPer:MODE CALCulate<n>:LIMit<li>:UPPer:SHIFt</li></n></li></n>	
CALCulate <n>:LIMit<li>:UPPer:SPACing</li></n>	547

#### CALCulate<n>:LIMit:COMMent <Comment>

This command defines a comment for a limit line. Suffix: <n> irrelevant <|j> Limit line **Parameters:** <Comment> String containing the description of the limit line.

Manual operation: See " Comment " on page 238

## CALCulate<n>:LIMit:CONTrol[:DATA] <LimitLinePoints>

This command defines the horizontal definition points of a limit line.

Suffix: <n> <li></li></n>	irrelevant Limit line
<b>Parameters:</b> <limitlinepoints></limitlinepoints>	Variable number of x-axis values. Note that the number of horizontal values has to be the same as the number of vertical values set with CALCulate <n>: LIMit<li>:LOWer[:DATA] OF CALCulate<n>:LIMit<li>: UPPer[:DATA]. If not, the R&amp;S FSWP either adds missing val- ues or ignores surplus values. *RST: - Default unit: HZ</li></n></li></n>
Manual operation:	See " Data Points " on page 239

CALCulate <n>:LIMit<li>:CONTrol:DOMain <spansetting></spansetting></li></n>	
This command selec	ts the domain of the limit line.
Suffix: <n></n>	irrelevant
< i>	Limit line
Parameters: <spansetting></spansetting>	FREQuency   TIME FREQuency For limit lines that apply to a range of frequencies. TIME For limit lines that apply to a period of time. CURRent For limit lines that apply to a range of currents. VOLTage For limit lines that apply to a range of voltages. *RST: FREQuency
Example:	CALC:LIM:CONT:DOM FREQ Select a limit line in the frequency domain.
Manual operation:	See " X-Axis " on page 239

## CALCulate<n>:LIMit:CONTrol:MODE <Mode>

This command selects the horizontal limit line scaling.

Suffix: <n></n>	irrelevant
< i>	Limit line
Parameters: <mode></mode>	ABSolute Limit line is defined by absolute physical values (Hz or s). RELative
Limit line is defined by relative values related to the center quency (frequency domain) or the left diagram border (tir domain).	
	*RST: ABSolute

#### CALCulate<n>:LIMit:CONTrol:SHIFt <Distance>

This command moves a complete limit line horizontally.

Compared to defining an offset, this command actually changes the limit line definition points by the value you define.

Suffix:	
<n></n>	irrelevant
< i>	Limit line
Parameters: <distance></distance>	Numeric value.
	The unit depends on the scale of the x-axis.
	Default unit: HZ
Manual operation:	See " Shift x " on page 240

#### CALCulate<n>:LIMit:CONTrol:SPACing <InterpolMode>

This command selects linear or logarithmic interpolation for the calculation of limit lines from one horizontal point to the next.

Suffix: <n></n>	Window
< i>	Limit line
Parameters: <interpolmode></interpolmode>	LINear   LOGarithmic *RST: LIN
Example:	CALC:LIM:CONT:SPAC LIN
Manual operation:	See " X-Axis " on page 239

## CALCulate<n>:LIMit:LOWer[:DATA] <LimitLinePoints>

This command defines the vertical definition points of a lower limit line.

Suffix: <n></n>	irrelevant
< i>	Limit line
Parameters: <limitlinepoints></limitlinepoints>	Variable number of level values. Note that the number of vertical values has to be the same as the number of horizontal values set with CALCulate <n>: LIMit<li>:CONTrol[:DATA]. If not, the R&amp;S FSWP either adds missing values or ignores surplus values. *RST: Limit line state is OFF Default unit: DBM</li></n>
Manual operation:	See " Data Points " on page 239

## CALCulate<n>:LIMit:LOWer:MODE <Mode>

This command selects the vertical limit line scaling.

Suffix: <n></n>	Window	
< i>	Limit line	
Parameters: <mode></mode>	<b>ABSolute</b> Limit line is defined by absolute physical values. The unit is variable.	
	RELative         Limit line is defined by relative values related to the reference         level (dB).         *RST:       ABSolute	
Manual operation:	See " X-Axis " on page 239	

#### CALCulate<n>:LIMit:LOWer:SHIFt <Distance>

This command moves a complete lower limit line vertically.

Compared to defining an offset, this command actually changes the limit line definition points by the value you define.

Su	ffix:

<n></n>	Window
< i>	Limit line
Parameters: <distance></distance>	Defines the distance that the limit line moves. Default unit: DB
Manual operation:	See " Shift y " on page 240

## CALCulate<n>:LIMit:LOWer:SPACing <InterpolType>

This command selects linear or logarithmic interpolation for the calculation of a lower limit line from one horizontal point to the next.

<n></n>	Window	
< i>	Limit line	
Parameters: <interpoltype></interpoltype>	LINear   LOGarithmic *RST: LIN	
Manual an avation		<u>م</u>

Manual operation: See "Y-Axis " on page 239

#### CALCulate<n>:LIMit:NAME <Name>

This command selects a limit line that already exists or defines a name for a new limit line.

Suffix:		
<n></n>	Window	
< i>	Limit line	
Parameters: <name></name>	String cont	aining the limit line name.
	*RST:	REM1 to REM8 for lines 1 to 8
Manual operation:	See " Name	e " on page 238

## CALCulate<n>:LIMit:UNIT <Unit>

This command defines the unit of a limit line.

Suffix: <n></n>	irrelevant
< i>	Limit line
<b>Parameters:</b> <unit></unit>	If you select dB as the limit line unit, the command automatically turns the limit line into a relative limit line. *RST: DBM
Manual operation:	See "Y-Axis " on page 239

## CALCulate<n>:LIMit:UPPer[:DATA] <LimitLinePoints>

This command defines the vertical definition points of an upper limit line.

C	five	
3	ипти	

<n></n>	irrelevant

Limit line

#### **Parameters:**

<limitlinepoints></limitlinepoints>	Variable number of level values.
	Note that the number of vertical values has to be the same as
	the number of horizontal values set with CALCulate <n>:</n>
	LIMit <li>:CONTrol[:DATA]. If not, the R&amp;S FSWP either</li>
	adds missing values or ignores surplus values.
	*RST: Limit line state is OFF
	Default unit: DBM
	One II Date Daiste II en name 200

Manual operation: See " Data Points " on page 239

CALCulate <n>:LIMit<li>:UPPer:MODE <mode></mode></li></n>		
This command select	s the vertical limit line scaling.	
Suffix: <n> <li></li></n>	Window Limit line	
Parameters: <mode></mode>	<b>ABSolute</b> Limit line is defined by absolute physical values. The unit is variable.	
	<b>RELative</b> Limit line is defined by relative values related to the referencelevel (dB).*RST:ABSolute	
Manual operation:	See " X-Axis " on page 239	

## CALCulate<n>:LIMit:UPPer:SHIFt <Distance>

This command moves a complete upper limit line vertically.

Compared to defining an offset, this command actually changes the limit line definition points by the value you define.

Suffix: <n></n>	irrelevant
< i>	Limit line
<b>Parameters:</b> <distance></distance>	Defines the distance that the limit line moves.
Manual operation:	See " Shift y " on page 240

#### CALCulate<n>:LIMit:UPPer:SPACing <InterpolType>

This command selects linear or logarithmic interpolation for the calculation of an upper limit line from one horizontal point to the next.

Suffix:	
<n></n>	Window
< i>	Limit line
Parameters: <interpoltype></interpoltype>	LINear   LOGarithmic *RST: LIN
Manual operation:	See " Y-Axis " on page 239

## 15.7.5.3 Reading out the Results of a Limit Check

CALCulate <n>:LIMit<li>:CLEar[:IMMediate]</li></n>	548
CALCulate <n>:LIMit<li>:FAIL?</li></n>	548

## CALCulate<n>:LIMit:CLEar[:IMMediate]

This command deletes the result of the current limit check.

The command works on *all* limit lines in *all* measurement windows at the same time.

Suffix:	
<n></n>	Window
< i>	irrelevant
Example:	CALC:LIM:CLE
	Deletes the result of the limit check.

#### CALCulate<n>:LIMit:FAIL?

- ---

This command queries the result of a limit check in the specified window.

To get a valid result, you have to perform a complete measurement with synchronization to the end of the measurement before reading out the result. This is only possible for single measurement mode.

Suffix: <n></n>	Window
< i>	Limit line
<b>Return values:</b> <result></result>	0 PASS 1 FAIL
Example:	INIT; *WAI Starts a new sweep and waits for its end. CALC2:LIM3:FAIL? Queries the result of the check for limit line 3 in window 2.
Usage:	Query only

#### 15.7.5.4 Programming Example: Using Limit Lines

```
//----- Creating and editing limit lines ------ //Select or create a limit line with index '1'
CALC:LIM1:NAME 'FM1'
```

```
//Define 5 horizontal definition points for limit line 1
calc:lim:cont 100hz,1khz,10khz,100khz,100khz
//Select an absolute vertical scale for limit line 1
```

```
CALC:LIM1:UPP:MODE ABS
//Select the unit dBc Hz for limit line 1
CALC:LIM1:UNIT DBC HZ
//Define 5 vertical definition points for limit line 1
CALC:LIM1:UPP -60, -80, -90, -100, -110
//Shift the limit line 1 by -10 dB
CALC:LIM1:UPP:SHIF -10DB
//----- Configuring a limit check ------
//Activate upper limit FM1 as line 1
CALC:LIM1:UPP:STAT ON
//Activate the limit to be checked against trace 1 and 2
CALC:LIM1:TRAC1:CHEC ON
CALC:LIM1:TRAC2:CHEC ON
//Query the names of all active limit lines
CALC:LIM:ACT?
//Result: 'FM1'
//Clear the previous limit check results
CALC:LIM:CLE
//---- Performing the measurement-----
//Initiate a new measurement and wait until the last sweep has finished
INIT;*WAI
//----- Retrieving limit check results-----
//Query the result of the limit line check
```

```
CALC:LIM1:FAIL?
```


## 15.7.6 Examples: Configuring the Result Display

The following example demonstrates how to configure result displays in a remote environment.

#### 15.7.6.1 Example 1: Adding and Arranging Windows

Starting from the default initial display in the Spectrum application (Frequency Sweep), we will configure the following result displays:

1 Frequency Sweep		3 Marker Table	
	2 Spectrogram	4 Marker Peak List	



//-----Resetting the instrument -----\*RST
//----- Adding new windows -----//Add a Spectrogram window beneath the Frequency Sweep window
LAY:ADD? '1',BEL,SGR
//Result: window number: '2'
//Add a Marker Table window to the right of the Frequency Sweep window
LAY:ADD? '1',RIGH,MTAB
//Result: window number: '3'
//Add a Marker Peak List window to the right of the Spectrogram window
LAY:WIND2:ADD? RIGH,PEAK
//Result: window number: '4'

//----- Changing the size of individual windows -----//Move the splitter between the Frequency Sweep window and the Marker Table
//window to enlarge the spectrum display to 60% of the entire width.
LAY:SPL 1,3,60
//Move the splitter between the Spectrogram window and the Marker Peak List
//window to enlarge the Spectrogram display to 60% of the entire width.
LAY:SPL 2,4,60

```
//----- Querying all displayed windows ------
//Query the name and number of all displayed windows
//(from top left to bottom right)
LAY:CAT?
//Result : '1',1,'2',2,'3',3,'4',4
```


//----- Maximizing a Window -----//Maximize the window "2 Spectrogram"
DISP:WIND2:SIZE LARG

```
//-----Restore multiple window display ------
DISP:WIND2:SIZE SMAL
```

## 15.7.6.2 Example 2: Replacing and Removing Windows

Starting from the display configured in Example 1: Adding and Arranging Windows, we will remove and replace result displays to obtain the following configuration:





//---- Preparing the configuration from example 1 -----

```
LAY:ADD? '1',BEL,SGR
LAY:ADD? '1',RIGH,MTAB
LAY:WIND2:ADD? RIGH,PEAK
LAY:CAT?
//Result : '1',1,'2',2,'3',3,'4',4
//Remove Spectrogram
LAY:WIND2:REM //Remove Marker Table window
LAY:REM '3'
//Replace Marker Peak List window by Marker Table
LAY:REPL '4',MTAB
//------ Querying all displayed windows ------
//Query the name and number of all displayed windows (from top left to bottom right)
LAY:CAT?
//Result : '1',1,'4',4
```

\*RST

```
//----- Changing the size of individual windows ------
//Move the splitter between the Frequency Sweep window and the Marker Table window
//to enlarge the spectrum display to 80% of the entire height.
LAY:SPL 1,4,80
```

# 15.8 Managing Settings and Results

The commands required to store and load instrument settings and import and export measurement results in a remote environment are described here. The tasks for manual operation are described in Chapter 12, "Data Management", on page 244.

#### Addressing drives

The various drives can be addressed via the "mass storage instrument specifier" <msis> using the conventional Windows syntax. The internal hard disk is addressed by "C:". For details on storage locations refer to Chapter 12.3.2.2, "Storage Location and Filename", on page 252.

The file names (<FileName> parameter) are given as string parameters enclosed in quotation marks. They also comply with Windows conventions. Windows file names do not distinguish between uppercase and lowercase notation.

#### Wildcards

The two characters "\*" and "?" can be used as "wildcards". Wildcards are variables for a selection of several files. The question mark "?" replaces exactly one character, the asterisk replaces any of the remaining characters in the file name. "\*.\*" thus means all files in a directory.

#### Path names

Storage locations can be specified either as absolute (including the entire path) or relative paths (including only subfolders of the current folder). Use the MMEM:CDIR? query to determine the current folder.

# (j

## Secure user mode

In secure user mode, settings that are to be stored on the instrument are stored to volatile memory, which is restricted to 256 MHz. Thus, a "Memory full" error may occur although the hard disk indicates that storage space is still available.

553
558
561
565
576
576

# 15.8.1 Managing Files

Commands to manage files described elsewhere:

- FORMat[:DATA]
- FORMat:DEXPort:DSEParator

MMEMory:CATalog	
MMEMory:CATalog:LONG	
MMEMory:CDIRectory	
MMEMory:COMMent	
MMEMory:COPY	554
MMEMory:DATA	
MMEMory:DELete:IMMediate	
MMEMory:MDIRectory	
MMEMory:MOVE	
MMEMory:MSIS	
MMEMory:NAME	
MMEMory:NETWork:DISConnect	
MMEMory:NETWork:MAP	
MMEMory:NETWork:UNUSeddrives?	
MMEMory:NETWork:USEDdrives MMEMory:RDIRectory	558

## MMEMory:CATalog <FileName>

This command returns the contents of a particular directory.

## **Parameters:**

<filename></filename>	String containing the path and directory If you leave out the path, the command returns the contents of the directory selected with MMEMory:CDIRectory on page 554. The path may be relative or absolute. Using wildcards ('*') is possible to query a certain type of files only. If you use a specific file as a parameter, the command returns the name of the file if the file is found in the specified directory, or an error if the file is not found ("-256, "File name not found").
Example:	MMEM:CAT? 'C:\Data\SPOOL?.PNG' Returns all files in C:\Data\ whose names start with SPOOL, have 6 characters and the extension .PNG, e.g.: SPOOL1.PNG, SPOOL2.PNG, SPOOL3.PNG
Example:	<pre>MMEM:CAT? 'C:\Data\SPOOL6.PNG' Query whether the file 'SPOOL6.PNG' also exists in the directory Result: -256,"File name not found;:MMEMory:CATalog? 'C:\Data\SPOOL6.PNG'</pre>

Manual operation: See "Selecting Storage Location - Drive/ Path/ Files" on page 253

#### MMEMory:CATalog:LONG <Directory>

This command returns the contents of a particular directory with additional information about the files.

#### **Parameters:**

<directory></directory>	String containing the path and directory.
	If you leave out the path, the command returns the contents of
	the directory selected with MMEMory: CDIRectory
	on page 554.
	The path may be relative or absolute. Using wildcards ('*') is
	possible to query a certain type of files only.

#### MMEMory:CDIRectory <Directory>

This command changes the current directory.

#### **Parameters:**

<directory></directory>	String containing the path to another directory.
	The path may be relative or absolute.

#### MMEMory:COMMent <Comment>

This command defines a comment for the stored settings.

Parameters: <comment></comment>	String containing the comment.	
Example:	<pre>MMEMory:COMMent "ACP measurement with Standard Tetra from 23.05." MMEMory::MMEMory:STORe1:STATe 1, "ACP_T" As a result, in the selection list for recall settings, the comment "ACP measurement with Standard Tetra from 23.05." is added to the ACP entry.</pre>	
Manual operation:	See " Comment " on page 254	

#### MMEMory:COPY <FileName>, <FileName>

This command copies one or more files to another directory.

## Parameters:

<FileName> String containing the path and file name of the source file.
Special behavior if optional external mixer is active and the destination is C:\R\_S\INSTR\USER\cv1\: the contents of the
entire folder are copied. For details, see "Conversion Loss
Tables" on page 131.

<FileName> String containing the path and name of the target file. The path may be relative or absolute.

MMEMory:DATA <FileName>[, <Data>] MMEMory:DATA? <FileName>

This command writes block data into a file. The delimiter must be set to EOI to obtain error-free data transfer.

When you query the contents of a file, you can save them in a file on the remote control computer.

The command is useful for reading stored settings files or trace data from the instrument or for transferring them to the instrument

#### **Parameters:**

<Data>

<block\_data><block with the following structure.<br/>
#<br/>
Hash sign.<br/>
<number><br/>
Length of the length information.<br/>
<number><br/>
Length information of the binary data (number of bytes).<br/>
<data><br/>
Binary data with the indicated <number> of bytes.

## Parameters for setting and query:

<FileName>

Example: MMEM:NAME '\Public\User\Testfile.txt'
Creates a new file called 'testfile.txt'.
MMEM:DATA 'Testfile.txt', #220Contents of the
file
The parameter means:
#2: hash sign and length of the length information (20 bytes = 2
digits)
20: indicates the number of subsequent binary data bytes.
Contents of the file: store 20 binary bytes (characters) to the file.
MMEM:DATA? 'Testfile.txt'
Returns the contents of the file.

## MMEMory:DELete:IMMediate <FileName>

This command deletes a file.

## Parameters:

<FileName>

String containing the path and file name of the file to delete. The path may be relative or absolute.

#### MMEMory:MDIRectory <Directory>

This command creates a new directory.

#### **Parameters:**

<Directory> String containing the path and new directory name The path may be relative or absolute.

#### **MMEMory:MOVE** <FileName>, <FileName>

This command moves a file to another directory.

The command also renames the file if you define a new name in the target directory.

If you do not include a path for <NewFileName>, the command just renames the file.

<pre>Parameters: <filename></filename></pre>	String containing the path and file name of the source file.
<filename></filename>	String containing the path and name of the target file.
Example:	MMEM:MOVE 'C:\TEST01.CFG', 'SETUP.CFG' Renames TEST01.CFG in SETUP.CFG in directory C:\.

#### MMEMory:MSIS <Device>

This command selects the default storage device used by all MMEMory commands.

#### Parameters:

<device></device>	'A:'   'C:'	.   'Z:'
	String conta	aining the device drive name
	*RST:	n.a.

#### MMEMory:NAME <FileName>

This command has several purposes, depending on the context it is used in.

- It creates a new and empty file.
- It defines the file name for screenshots taken with HCOPy[:IMMediate<1|2>]. Note that you have to route the printer output to a file.

## Parameters:

<filename></filename>	String containing the path and name of the target file.	
Example:	MMEM:NAME 'C:\Data\PRINT1.BMP'	
	Selects the file name.	

# MMEMory:NETWork:DISConnect <Drive>[, <State>]

This command disconnects a network drive.

Parameters: <drive></drive>	String containing the drive name.
<state></state>	1   0   ON   OFF
	Optional: determines whether disconnection is forced or not
	1   ON Disconnection is forced.
	0   OFF
	Disconnect only if not in use.
	*RST: 0

MMEMory:NETWork:MAP <FilePath>, <IP>[, <UserName>, <Password>, <State>]

This command maps a drive to a server or server directory of the network.

Note that you have to allow sharing for a server or folder in Microsoft networks first.

<b>Parameters:</b> <filepath></filepath>	String containing the drive name or path of the directory you want to map.
<ip></ip>	String containing the host name of the computer or the IP address and the share name of the drive. '<\host name or IP address\share name>'
<username></username>	String containing a user name in the network. The user name is optional.
<password></password>	String containing the password corresponding to the <user- Name&gt;. The password is optional.</user- 
<state></state>	ON   OFF   1   0 ON   1 Reconnects at logon with the same user name. OFF   0 Does not reconnect at logon.

## MMEMory:NETWork:UNUSeddrives?

This command returns a list of unused network drives.

Return values:	
<drivename></drivename>	List of network drives in alphabetically descending order, e.g. 'W:,V:,U:,'
Usage:	Query only

#### MMEMory:NETWork:USEDdrives [<State>]

This command returns a list of all network drives in use.

## Parameters:

<State> You do not have to use the parameter. If you do not include the parameter, the command returns a list of all drives in use. This is the same behavior as if you were using the parameter OFF. **ON | 1** Returns a list of all drives in use including the folder information. **OFF | 0** Returns a list of all drives in use.

#### MMEMory:RDIRectory <arg0>

This command deletes the indicated directory.

Parameters:

<arg0> String containing the path of the directory to delete. Note that the directory you want to remove must be empty.

## 15.8.2 Selecting Items to Store

The following commands select the items to be included in the configuration file.

Depending on the used command, either the items from the entire instrument (MMEMory:SELect[:ITEM]...), or only those from the currently selected channel (MMEM:SELect:CHANnel[:ITEM]...) are stored.

MMEMory:SELect:CHANnel[:ITEM]:ALL	559
MMEMory:SELect[:ITEM]:ALL.	
MMEMory:SELect:CHANnel[:ITEM]:DEFault	
MMEMory:SELect[:ITEM]:DEFault	
MMEMory:SELect:CHANnel[:ITEM]:HWSettings	
MMEMory:SELect[:ITEM]:HWSettings	559
MMEMory:SELect:CHANnel[:ITEM]:LINes:ALL	560
MMEMory:SELect[:ITEM]:LINes:ALL	560
MMEMory:SELect:CHANnel[:ITEM]:NONE	560
MMEMory:SELect[:ITEM]:NONE	
MMEMory:SELect:CHANnel[:ITEM]:SGRam	560
MMEMory:SELect[:ITEM]:SGRam	560
MMEMory:SELect:CHANnel[:ITEM]:TRACe[:ACTive]	560
MMEMory:SELect[:ITEM]:TRACe<13>[:ACTive]	560
MMEMory:SELect:CHANnel[:ITEM]:TRANsducer:ALL	561
MMEMory:SELect[:ITEM]:TRANsducer:ALL	561
MMEMory:SELect:CHANnel[:ITEM]:WEIGhting	561
MMEMory:SELect[:ITEM]:WEIGhting	561

## MMEMory:SELect:CHANnel[:ITEM]:ALL MMEMory:SELect[:ITEM]:ALL

This command includes all items when storing or loading a configuration file.

The items are:

- Hardware configuration: MMEMory: SELect [:ITEM]: HWSettings on page 559
- Limit lines: MMEMory: SELect [:ITEM]:LINes:ALL on page 560
- Spectrogram data: MMEMory:SELect[:ITEM]:SGRam on page 560
- Trace data: MMEMory:SELect[:ITEM]:TRACe<1...3>[:ACTive] on page 560

**Example:** MMEM:SEL:ALL

Manual operation: See " Items: " on page 254

## MMEMory:SELect:CHANnel[:ITEM]:DEFault MMEMory:SELect[:ITEM]:DEFault

This command selects the current settings as the only item to store to and load from a configuration file.

Manual operation: See " Items: " on page 254

## MMEMory:SELect:CHANnel[:ITEM]:HWSettings <State> MMEMory:SELect[:ITEM]:HWSettings <State>

This command includes or excludes measurement (hardware) settings when storing or loading a configuration file.

Measurement settings include:

- general channel configuration
- measurement hardware configuration including markers
- limit lines

Note that a configuration may include no more than 8 limit lines. This number includes active limit lines as well as inactive limit lines that were used last. Therefore the combination of inactivate limit lines depends on the sequence of use with MMEMory:LOAD:STATe on page 562.

- color settings
- configuration for the hardcopy output

#### **Parameters:**

<state></state>	ON   OFF   0   1
	*RST: 1
Example:	MMEM:SEL:HWS ON
Manual operation:	See " Items: " on page 254

## MMEMory:SELect:CHANnel[:ITEM]:LINes:ALL <State> MMEMory:SELect[:ITEM]:LINes:ALL <State>

This command includes or excludes all limit lines (active and inactive) when storing or loading a configuration file.

**Parameters:** 

	 <b>O</b>	~ = 4
Example:	MMEM:SEL:LIN:ALL (	ON
	*RST: 0	
<state></state>	ON   OFF   1   0	

Manual operation: See " Items: " on page 254

## MMEMory:SELect:CHANnel[:ITEM]:NONE MMEMory:SELect[:ITEM]:NONE

This command does not include any of the following items when storing or loading a configuration file.

- Hardware configuration: MMEMory:SELect[:ITEM]:HWSettings on page 559
- Limit lines: MMEMory: SELect[:ITEM]:LINes:ALL on page 560
- Spectrogram data: MMEMory: SELect [:ITEM]: SGRam on page 560
- Trace data: MMEMory:SELect[:ITEM]:TRACe<1...3>[:ACTive] on page 560

**Example:** MMEM:SEL:NONE

Manual operation: See " Items: " on page 254

## MMEMory:SELect:CHANnel[:ITEM]:SGRam <State> MMEMory:SELect[:ITEM]:SGRam <State>

This command includes or excludes spectrogram data when storing or loading a configuration file.

#### Parameters:

<state></state>	ON   OFF   1   0 *RST: 0
Example:	MMEM: SEL: SGR ON Adds the spectrogram data to the list of data subsets.
Manual operation:	See " Items: " on page 254

## MMEMory:SELect:CHANnel[:ITEM]:TRACe[:ACTive] <State> MMEMory:SELect[:ITEM]:TRACe<1...3>[:ACTive] <State>

This command includes or excludes trace data when storing or loading a configuration file.

Suffix:

<1...3>

irrelevant

Parameters: <state></state>	ON   OFF	1   0
	*RST:	0, i.e. no traces are stored
Example:	MMEM:SEL:	TRAC ON
Manual operation:	See " Items	: " on page 254

## MMEMory:SELect:CHANnel[:ITEM]:TRANsducer:ALL <State> MMEMory:SELect[:ITEM]:TRANsducer:ALL <State>

This command includes or excludes transducer factors when storing or loading a configuration file.

The command is available in the optional Spectrum application.

#### Parameters:

Manual operation:	See " Items: " on page 254
Example:	MMEM:SEL:TRAN:ALL ON
	*RST: 0
<state></state>	ON   OFF   1   0

```
MMEMory:SELect:CHANnel[:ITEM]:WEIGhting <State>
MMEMory:SELect[:ITEM]:WEIGhting <State>
Parameters:
<State>
```

## 15.8.3 Saving and Loading Instrument Settings

MMEMory:CLEar:ALL	561
MMEMory:CLEar:STATe	
MMEMory:LOAD:AUTO	
MMEMory:LOAD:STATe	562
MMEMory:STORe<1 2>:STATe	563
MMEMory:STORe<1 2>:STATe:NEXT	
MMEMory:STORe<1 2>:TYPE	
SYSTem:PRESet	
SYSTem:PRESet:CHANnel[:EXEC]	

#### MMEMory:CLEar:ALL

This command deletes all instrument configuration files in the current directory.

You can select the directory with MMEMory: CDIRectory on page 554.

**Example:** MMEM:CLE:ALL

#### MMEMory:CLEar:STATe <1>, <FileName>

This command deletes an instrument configuration file.

Parameters:

<1>

<filename></filename>	String containing the path and name of the file to delete. The string may or may not contain the file's extension.
Example:	MMEM:CLE:STAT 1, 'TEST'

## MMEMory:LOAD:AUTO <1>, <FileName>

This command restores an instrument configuration and defines that configuration as the default state.

The default state is restored after a preset (\*RST) or after you turn on the R&S FSWP.

#### Parameters:

<1>

<filename></filename>	<pre>'Factory' Restores the factory settings as the default state. '<file_name></file_name></pre>	
	String containing the path and name of the configuration file. Note that only <i>instrument</i> settings files can be selected for the startup recall function; channel files cause an error.	
Example:	MMEM:LOAD:AUTO 1,'C:\R_S\INSTR\USER\TEST'	
Manual operation:	See " Startup Recall " on page 255	

#### MMEMory:LOAD:STATe <1>, <FileName>

This command restores and activates the instrument configuration stored in a \*.dfl file.

Note that files with other formats cannot be loaded with this command.

The contents that are reloaded from the file are defined by the last selection made either in the "Save/Recall" dialogs (manual operation) or through the MMEMory:SELect[:ITEM] commands (remote operation; the settings are identical in both cases).

By default, the selection is limited to the user settings ("User Settings" selection in the dialogs, HWSettings in SCPI). The selection is not reset by [Preset] or \*RST.

As a consequence, the results of a SCPI script using the MMEMory: LOAD: STATe command without a previous MMEMory: SELect [:ITEM] command may vary, depending on previous actions in the GUI or in previous scripts, even if the script starts with the \*RST command.

It is therefore recommended that you use the appropriate MMEMory:SELect[:ITEM] command before using MMEMory:LOAD:STATe.

Parameters: <1>	
<filename></filename>	String containing the path and name of the file to load. The string may or may not include the file's extension.
Example:	<pre>MMEM: SEL: ALL //Save all items (User Settings, All Traces, All Limit Lines) from the R&amp;S FSWP. MMEM: LOAD: STAT 1, 'C:\R_S\INSTR\USER\TEST01' //Reloads all items In the "Recall" dialog, select only "User Settings" and "All Limit Lines". MMEM: LOAD: STAT 1, 'C:\R_S\INSTR\USER\TEST01' //Reloads user settings and all limit lines. *RST //Reset instrument. MMEM: LOAD: STAT 1, 'C:\R_S\INSTR\USER\TEST01' //Selected items are retained. Reloads user settings and all limit lines. Restart the instrument. (Switch the [ON/OFF] key off and on). MMEM: LOAD: STAT 1, 'C:\R_S\INSTR\USER\TEST01' // Selected items are set to default. Reloads only the user set- tings.</pre>
Manual operation:	See " Recall " on page 251 See " Recall in New Channel / Recall in Current Channel " on page 255

## MMEMory:STORe<1|2>:STATe <1>, <FileName>

This command saves the current instrument configuration in a \*.dfl file.

<b>Suffix:</b> <1 2>	irrelevant
Parameters: <1>	
<filename></filename>	String containing the path and name of the target file. The file extension is .dfl.
Example:	MMEM:STOR:STAT 1, 'Save' Saves the current instrument settings in the file Save.dfl.
Manual operation:	See " Save File " on page 254

## MMEMory:STORe<1|2>:STATe:NEXT

This command saves the current instrument configuration in a \*.dfl file.

The file name depends on the one you have set with MMEMory: STORe<1 | 2>: STATe on page 563. This command adds a consecutive number to the file name.

<b>Suffix:</b> <1 2>	irrelevant
Example:	<pre>MMEM:STOR:STAT 1, 'Save' Saves the current instrument settings in the file Save.dfl. MMEM:STOR:STAT:NEXT Saves the current instrument settings in the file Save_001.dfl MMEM:STOR:STAT:NEXT Saves the current instrument settings in the file Save_002.dfl</pre>
Manual operation:	See " Save File " on page 254

## MMEMory:STORe<1|2>:TYPE <Type>

This command defines whether the data from the entire instrument or only from the current channel is stored with the subsequent MMEM: STOR... command.

<b>Suffix:</b> <1 2>	irrelevant	
<b>Parameters:</b> <type></type>	<b>CHANnel</b> Stores data fr	rom the entire instrument. rom an individual channel.
Example:	INST:SEL ' Selects chann MMEM:STOR:	nel'SPECTRUM2'.

#### SYSTem:PRESet

This command presets the R&S FSWP. It is identical to \*RST.

Example:	SYST:PRES
Usage:	Event

## SYSTem:PRESet:CHANnel[:EXEC]

This command restores the default instrument settings in the current channel.

Use INST: SEL to select the channel.

Example:	INST:SEL 'Spectrum2' Selects the channel for "Spectrum2". SYST:PRES:CHAN:EXEC Restores the factory default settings to the "Spectrum2"channel.
Usage:	Event
Manual operation:	See "Preset Channel" on page 125

# 15.8.4 Storing and Printing Screenshots

Useful commands to perform measurements described elsewhere:

• MMEMory:NAME

	<b>F0 -</b>
DISPlay:LOGO	
HCOPy:ABORt	
HCOPy:CMAP <it>:DEFault<ci></ci></it>	
HCOPy:CMAP <it>:HSL</it>	566
HCOPy:CMAP <it>:PDEFined</it>	567
HCOPy:CONTent	567
HCOPy:DESTination<1 2>	568
HCOPy:DEVice:COLor	569
HCOPy:DEVice:LANGuage<1 2>	569
HCOPy[:IMMediate<1 2>]	570
HCOPy[:IMMediate<1 2>]:NEXT	570
HCOPy:ITEM:WINDow<1 2>:TEXT	570
HCOPy:PAGE:COUNt:STATe	
HCOPy:PAGE:MARGin<1 2>:BOTTom	
HCOPy:PAGE:MARGin<1 2>:LEFT	571
HCOPy:PAGE:MARGin<1 2>:RIGHt	571
HCOPy:PAGE:MARGin<1 2>:TOP	572
HCOPy:PAGE:MARGin<1 2>:UNIT	572
HCOPy:PAGE:ORIentation<1 2>	572
HCOPy:PAGE:WINDow<1 2>:CHANnel:STATe	573
HCOPy:PAGE:WINDow<1 2>:COUNt	
HCOPy:PAGE:WINDow<1 2>:SCALe	
HCOPy:PAGE:WINDow<1 2>:STATe	
HCOPy:TDSTamp:STATe<1 2>	
SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt	
SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]	
SYSTem:COMMunicate:PRINter:SELect<1/2>	

## DISPlay:LOGO <State>

Activates/deactivates the printout of the Rohde & Schwarz company logo at the top of each page.

## Parameters:

<State>

1 | 0 | ON | OFF

	<b>1   ON</b> Logo is printed.
	<b>0   OFF</b> Logo is not printed. *RST: 1
Example:	DISP:LOGO OFF
Manual operation:	See " Print Logo " on page 262

## HCOPy:ABORt

This command aborts a running hardcopy output.

Example: HCOP:ABOR

## HCOPy:CMAP<it>:DEFault<ci>

This command defines the color scheme for print jobs.

For details see " Print Colors " on page 287.

Suffix: <it></it>	Selects the item for which the color scheme is to be defined. For more information see Chapter 15.9.4.3, "CMAP Suffix Assignment", on page 594.
<ci></ci>	See table below
Example:	HCOP: CMAP: DEF2 Selects the optimized color set for the color settings of a print- out.

#### Manual operation: See " Print Colors " on page 287

Gui setting	Description	Remote command
"Screen Colors (Print)"	Selects the current screen colors for the printout. The background is always printed in white and the grid in black.	HCOP:CMAP:DEF1
"Optimized Colors"	Selects an optimized color setting for the printout to improve the visibility of the colors (default setting). Trace 1 is blue, trace 2 black, trace 3 green, and the markers are turquoise. The background is always printed in white and the grid in black.	HCOP:CMAP:DEF2
"User Defined Colors"	Selects the user-defined color setting.	HCOP:CMAP:DEF3
"Screen Colors (Screenshot)"	Selects the current screen colors without any changes for a screenshot.	HCOP:CMAP:DEF4

HCOPy:CMAP<it>:HSL <hue>, <sat>, <lum>

This command selects the color for various screen elements in print jobs.

Suffix:	
<it></it>	Selects the item for which the color scheme is to be defined. For more information see Chapter 15.9.4.3, "CMAP Suffix Assignment", on page 594.
Parameters:	
<hue></hue>	hue tint Range: 0 to 1
<sat></sat>	sat saturation Range: 0 to 1
<lum></lum>	lum brightness Range: 0 to 1
Example:	HCOP:CMAP2:HSL 0.3,0.8,1.0 Changes the grid color
Manual operation:	See "Defining User-specific Colors" on page 289

## HCOPy:CMAP<it>:PDEFined <Color>

This command selects a predefined color for various screen elements in print jobs.

Suffix: <it></it>	1n Selects the item for which the color scheme is to be defined. For more information see Chapter 15.9.4.3, "CMAP Suffix Assignment", on page 594.
Parameters: <color></color>	BLACk   BLUE   BROWn   GREen   CYAN   RED   MAGenta   YELLow   WHITe   DGRay   LGRay   LBLue   LGReen   LCYan   LRED   LMAGenta
Example: Manual operation:	HCOP:CMAP2:PDEF GRE See "Predefined Colors " on page 289

## HCOPy:CONTent <arg0>

This command determines the type of content included in the printout.

This setting is independent of the printing device.

#### Parameters:

<arg0> WINDows | HCOPy

#### **WINDows**

Includes only the selected windows in the printout. All currently active windows for the current channel (or "MultiView") are available for selection. How many windows are printed on a each page of the printout is defined by HCOPy: PAGE:WINDow<1|2>: COUNt on page 573.

This option is not available when copying to the clipboard (HCOP:DEST 'SYST:COMM:CLIP' or an image file (see HCOPy:DEVice:LANGuage<1|2> on page 569).

If the destination is currently set to an image file or the clipboard, it is automatically changed to be a PDF file for the currently selected printing device.

## **HCOPy**

Selects all measurement results displayed on the screen for the current channel (or "MultiView"): diagrams, traces, markers, marker lists, limit lines, etc., including the channel bar and status bar, for printout on a single page. Displayed items belonging to the software user interface (e.g. softkeys) are not included. The size and position of the elements in the printout is identical to the screen display.

\*RST: HCOPy

Example:	<pre>HCOP:DEST1 'SYST:COMM:CLIP' HCOP:CONT WIND HCOP:DEST1? //Result: 'MMEM' HCOP:DEV:LANG1? //Result: 'PDF' "Print to clipboard" is automatically switched to "print to PDF file" when the contents are switched to "multiple windows".</pre>
Manual operation:	See " Print Screenshot " on page 262 See " Print Multiple Windows " on page 262

#### HCOPy:DESTination<1|2> <arg0>

This command selects the destination of a print job.

**Suffix:** <1|2>

|2> Printing device.

## Parameters:

<arg0>

#### 'MMEM'

Sends the hardcopy to a file. You can select the file name with MMEMory:NAME. You can select the file format with HCOPy:DEVice: LANGuage<1 | 2>.

## 'SYST:COMM:PRIN'

Sends the hardcopy to a printer. You can select the printer with SYSTem:COMMunicate: PRINter:SELect<1|2>.

**'SYST:COMM:CLIP'** Sends the hardcopy to the clipboard. The format should be WEMF. \*RST: 'SYST:COMM:CLIP'

Manual operation: See " Destination " on page 266

## HCOPy:DEVice:COLor <State>

This command turns color printing on and off.

## Parameters:

<State>

ON | OFF | 0 | 1 ON | 1 Color printing OFF | 0 Black and white printing \*RST: 1

Example:

HCOP:DEV:COL ON

#### HCOPy:DEVice:LANGuage<1|2> <arg0>

This command selects the file format for a print job.

<b>Suffix:</b> <1 2>	1 2 Printing device.
Parameters:	
<arg0></arg0>	WMF   GDI   EWMF   BMP   PNG   JPEG   JPG   PDF   SVG   DOC   RTF
	GDI Crashiga Daviga Interface
	Graphics Device Interface Default format for output to a printer configured under Windows. Must be selected for output to the printer interface. Can be used for output to a file. The printer driver configured under Windows is used to generate a printer-specific file format.
	BMP   JPG   PNG   PDF   SVG Data format for output to files
Example:	HCOP:DEV:LANG1 PNG
Manual operation:	See " Destination " on page 266

#### HCOPy[:IMMediate<1|2>]

This command initiates a print job.

If you are printing to a file, the file name depends on MMEMory: NAME.

**Suffix:** <1|2>

Printing device.

Manual operation: See " Print " on page 264

## HCOPy[:IMMediate<1|2>]:NEXT

This command initiates a print job.

If you are printing to a file, the file name depends on MMEMory: NAME. This command adds a consecutive number to the file name.

Suffix:

- ----

<1|2> Printing device.

Manual operation: See " Print " on page 264

## HCOPy:ITEM:WINDow<1|2>:TEXT <arg0>

This command defines a comment to be added to the printout.

<b>Suffix:</b> <1 2>	1 2
Parameters: <arg0></arg0>	String containing the comment.
Manual operation:	See " Comment " on page 262

#### HCOPy:PAGE:COUNt:STATe <arg0>

This command includes or excludes the page number for printouts consisting of multiple pages (HCOPy:CONTent on page 567).

#### Parameters:

<arg0></arg0>	1   0   ON   OFF
	<b>1   ON</b> The page number is printed.
	0   OFF
	The page number is not printed. *RST: 1
Example:	HCOP:PAGE:COUN:STAT ON
Manual operation:	See " Print Page Count " on page 262

#### HCOPy:PAGE:MARGin<1|2>:BOTTom <arg0>

112

This command defines the margin at the bottom of the printout page on which no elements are printed. The margins are defined according to HCOPy: PAGE: MARGin<1 | 2>: UNIT on page 572.

**Suffix:** <1|2>

· 1—	Printing dev	vice.
Parameters: <arg0></arg0>	*RST:	4.23 mm
Example:	HCOP:PAGE	E:MARG2:BOTT 2
Manual operation:	See " Margi	ins " on page 268

#### HCOPy:PAGE:MARGin<1|2>:LEFT <arg0>

This command defines the margin at the left side of the printout page on which no elements are printed. The margins are defined according to HCOPy: PAGE: MARGin<1 | 2>: UNIT on page 572.

<b>Suffix:</b> <1 2>	1 2 Printing dev	ice.
Parameters: <arg0></arg0>	*RST:	4.23 mm
Example:	HCOP:PAGE	:MARG2:LEFT 2
Manual operation:	See " Margi	ns " on page 268

## HCOPy:PAGE:MARGin<1|2>:RIGHt <arg0>

This command defines the margin at the right side of the printout page on which no elements are printed. The margins are defined according to HCOPy: PAGE: MARGin<1 | 2>: UNIT on page 572.

## Suffix:

<1 2>	1 2 Printing dev	vice.
Parameters: <arg0></arg0>	*RST:	4.23 mm
Example:	HCOP:PAGE	E:MARG2:RIGH 2
Manual operation:	See " Marg	ins " on page 268

## HCOPy:PAGE:MARGin<1|2>:TOP <arg0>

This command defines the margin at the top of the printout page on which no elements are printed. The margins are defined according to HCOPy: PAGE:MARGin<1|2>:UNIT on page 572.

 Suffix:
 1|2

 <1|2>
 1|2

 Printing device.

 Parameters:

 <arg0>
 \*RST:

 4.23 mm

 Example:

 HCOP:PAGE:MARG2:TOP 2

 Manual operation:

 See "Margins " on page 268

#### HCOPy:PAGE:MARGin<1|2>:UNIT <arg0>

This command defines the unit in which the margins for the printout page are configured.

2

Suffix: <1 2>	1 2 Printing dev	vice.
Parameters: <arg0></arg0>	MM   IN MM millimeters IN inches *RST:	ММ
Example:	HCOP:PAGE	E:MARG2:BOTT 2
Manual operation:	See " Margi	ns " on page 268

## HCOPy:PAGE:ORlentation<1|2> <arg0>

The command selects the page orientation of the printout.

The command is only available if the output device is a printer or a PDF file.

Suffix:			
<1 2>	1 2		
	Printing o	levice.	
Parameters:			
<arg0></arg0>	LANDsca	pe   PORTrait	
	*RST:	PORTrait	
Example:	HCOP:DE	CV:LANG1 PDF	
	HCOP:PA	GE:ORI2 LAND	

## Manual operation: See " Orientation " on page 268

#### HCOPy:PAGE:WINDow<1|2>:CHANnel:STATe <arg0>, <arg1>

This command selects all windows of the specified channel to be included in the printout for HCOPy:CONTent on page 567.

<b>Suffix:</b> <1 2>	irrelevant
Parameters: <arg0></arg0>	String containing the name of the channel.
	For a list of available channel types use INSTrument:LIST? on page 391.
<arg1></arg1>	1   0   ON   OFF <b>1   ON</b> The charged windows are included in the printent.
	The channel windows are included in the printout. <b>0   OFF</b>
	The channel windows are not included in the printout.
	*RST: 1
Example:	HCOP:CONT WIND HCOP:PAGE:WIND2:CHAN 'IQ Analyzer',0 HCOP:PAGE:WIND2:STAT 'IQ Analyzer','1',1 Prints only window 1 in the IQ Analyzer channel.
Manual operation:	See " Print Multiple Windows " on page 262

## HCOPy:PAGE:WINDow<1|2>:COUNt <arg0>

This command defines how many windows are displayed on a single page of the printout for HCOPy:CONTent on page 567.

<b>Suffix:</b> <1 2>	irrelevant	
Parameters: <arg0></arg0>	integer *RST:	1
Example:	HCOP:PAGE	:WIND2:COUN 2
Manual operation:	See " Windo	ows Per Page " on page 268

## HCOPy:PAGE:WINDow<1|2>:SCALe <arg0>

This command determines the scaling of the windows in the printout for HCOPY: CONTent on page 567.

<b>Suffix:</b> <1 2>	irrelevant
Parameters: <arg0></arg0>	<pre>1   0   ON   OFF 1   ON Each window is scaled to fit the page size optimally, not regard- ing the aspect ratio of the original display. If more than one win- dow is printed on one page (see HCOPy: PAGE: WINDow&lt;1   2&gt;: COUNt on page 573), each window is printed in equal size. ("Size to fit") 0   OFF Each window is printed as large as possible while maintaining the aspect ratio of the original display. ("Maintain aspect ratio") *RST: 1</pre>
Example:	HCOP:PAGE:WIND2:SCAL 0
Manual operation:	See " Scaling " on page 268

## HCOPy:PAGE:WINDow<1|2>:STATe <arg0>, <arg1>, <arg2>

This command selects the windows to be included in the printout for HCOPy:CONTent on page 567.

1.0	
<b>Suffix:</b> <1 2>	irrelevant
Parameters: <arg0></arg0>	String containing the name of the channel. For a list of available channel types use INSTrument:LIST? on page 391.
<arg1></arg1>	String containing the name of the existing window. By default, the name of a window is the same as its index. To determine the name and index of all active windows in the active channel, use the LAYout:CATalog[:WINDow]? query.
<arg2></arg2>	1   0   ON   OFF <b>1   ON</b> The window is included in the printout. <b>0   OFF</b> The window is not included in the printout. *RST: 1
Example:	HCOP:PAGE:WIND2:STAT 'IQ Analyzer','1',1
Manual operation:	See " Print Multiple Windows " on page 262

#### HCOPy:TDSTamp:STATe<1|2> <arg0>

This command includes or excludes the time and date in the printout.

<b>Suffix:</b> <1 2>	1 2 Printing device.
Parameters:	
<arg0></arg0>	1   0   ON   OFF
	1   ON
	The time and date are printed.
	0   OFF
	The time and date are not printed.
	*RST: 1
Manual operation:	See " Print Date and Time " on page 263

## SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt

This command queries the name of the first available printer.

To query the name of other installed printers, use SYSTem:COMMunicate:PRINter: ENUMerate[:NEXT] on page 575.

Manual operation: See " Printer Name " on page 266

#### SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]

This command queries the name of available printers.

You have to use SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt on page 575 for this command to work properly.

Manual operation: See " Printer Name " on page 266

#### SYSTem:COMMunicate:PRINter:SELect<1|2> <arg0>

This command selects the printer that processes jobs sent by the R&S FSWP.

Use HCOPy: DESTination<1 | 2> to select another output destination.

**Suffix:** <1|2>

1|2 Printing device.

Parameters: <arg0>

String containing the printer name. Use •SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt on page 575and R&S<sup>®</sup>FSWP

**Remote Control** 

•SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT] on page 575 to query all available printers. \*RST: NONE Manual operation: See " Printer Name " on page 266

## 15.8.5 Saving Measurement Results

Useful commands to store measurement results described elsewhere:

• FORMat[:DATA]

#### MMEMory:STORe<n>:TRACe <Trace>, <FileName>

This command exports trace data from the specified window to an ASCII file.

For details on the file format see Chapter 11.3.8.1, "Reference: ASCII File Export Format", on page 216.

## Secure User Mode

In secure user mode, settings that are stored on the instrument are stored to volatile memory, which is restricted to 256 MB. Thus, a "memory limit reached" error can occur although the hard disk indicates that storage space is still available.

To store data permanently, select an external storage location such as a USB memory device.

For details, see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

Suffix: <n></n>	Window
Parameters: <trace></trace>	Number of the trace to be stored
<filename></filename>	String containing the path and name of the target file.
Example:	MMEM:STOR1:TRAC 1, 'C:\TEST.ASC' Stores trace 1 from window 1 in the file TEST.ASC.
Manual operation:	See " Export Trace to ASCII File " on page 211

## 15.8.6 Examples: Managing Data

•	Storing Data	577
•	Loading Data	577
•	Storing Instrument Settings	578

## Managing Settings and Results

٠	Loading Instrument Settings	578
•	Printing to a File	578
•	Printing on a Printer	579

## 15.8.6.1 Storing Data

```
MMEM:MSIS 'C:'
//Selects drive C: as the default storage device.
-----Connecting a network drive-----
MMEM:NETW:USED?
//Returns a list of all drives in use in the network.
MMEM:NETW:UNUS?
//Returns a list of free drive names in the network.
MMEM:NETW:MAP 'T:', 'Server\ACLRTest'
//Maps drive T: to the directory 'Server\ACLRTest'
-----Saving data on the instrument-----
MMEM:MDIR 'C:\R S\INST\USER\ACLRTest'
//Creates a directory called 'ACLRTest' on drive C:
MMEM:NAME 'C:\R S\INST\USER\Test001.txt'
//Creates a file called 'Test001.txt'
MMEM:COMM 'ACLR test results'
//Creates a comment for the file.
MMEM:DATA 'Test001.txt',#212FileContents
//Writes 12 characters to the file 'Test001.txt'
-----Copying the data to another location---
MMEM:COPY 'C:\R S\INST\USER\Results\Test001.txt','T:'
//Copies the specified file to network drive T:.
MMEM:DEL 'C:\R S\INST\USER\Results\Test001.txt'
//Deletes the specified file from the instrument hard disk.
//or
MMEM:MOVE 'C:\R_S\INST\USER\Results\Test001.xml','D:\TestResults.txt'//
//Moves the file 'Test001.txt' to drive T:, renames it to 'Testresults.txt'
//and removes it from the instrument hard disk.
MMEM:RDIR 'C:\R S\INST\USER\Results'
//Deletes the directory called 'Results' from drive C:, unless it still contains any content.
----Disconnecting the network drive---
MMEM:NETW:DISC 'T:'
//Disconnect drive T:.
```

## 15.8.6.2 Loading Data

```
MMEM:CDIR?
//Returns the path of the current directory.
//e.g.
C:\R_S\Instr\user\
MMEM:CDIR 'C:\R_S\INST\USER\Results'
//Changes the current directory.
MMEM:CAT? 'C:\R_S\INST\USER\Results\*.xml'
//or
```

```
MMEM:CAT? '*.xml'
//Returns a list of all xml files in the directory 'C:\R_S\INST\USER\Results'.
MMEM:CAT:LONG? '*.xml'
//Returns additional information about the xml files in the directory 'C:\R_S\INST\USER\Resul
```

## 15.8.6.3 Storing Instrument Settings

#### In this example we will store the instrument settings for the "Spectrum" channel.

```
INST:SEL 'SPECTRUM'
//Selects measurement channel 'SPECTRUM'.
MEMM:STOR:TYPE CHAN
//Specifies that channel-specific data is to be stored.
MMEM:STOR:STAT 1, 'C:\R_S\Instr\user\Spectrum'
//Stores the channel settings from the 'Spectrum' channel
// to the file 'Spectrum.dfl'.
```

## 15.8.6.4 Loading Instrument Settings

In this example we will load the hardware settings from the configuration file Spectrum.dfl to a new "Spectrum2" channel.

```
MEMM:LOAD:TYPE NEW
//Specifies that settings will be loaded to a new channel besides the existing
//'Spectrum' channel.
MMEM:SEL:CHAN:HWS ON
//Selects only hardware settings to be loaded.
MMEM:LOAD:STAT 1, 'C:\R_S\Instr\user\Spectrum'
//Loads the channel-specific settings from the file 'C:\R_S\Instr\user\Spectrum.dfl'
//to a new channel. The new channel is named 'Spectrum2' to avoid a naming conflict
//with the existing 'Spectrum' channel.
INST:REN 'Spectrum2', 'Spectrum3'
//Renames the loaded channel to 'Spectrum3'.
```

## 15.8.6.5 Printing to a File

```
HCOP:DEST 'MMEM'
//Prints the data to a file.
HCOP:DEV:LANG BMP
//Selects bmp as the file format.
MMEM:NAME 'C:\R_S\INST\USER\Screenshot.bmp'
//Selects the file name for the printout.
HCOP:ITEM:ALL
//Prints all screen elements
HCOP:ITEM:WIND:TEXT 'ACLRResults'
//Adds a comment to the printout.
HCOP
//Stores the printout in a file called 'Screenshot.bmp'.
```

HCOP:NEXT
//Stores the printout in a file called 'Screenshot\_001.bmp'.

## 15.8.6.6 Printing on a Printer

```
HCOP:DEST2 'SYST:COMM:PRIN'
//Prints the data on a printer.
SYST:COMM:PRIN:ENUM:FIRS?
SYST:COMM:PRIN:ENUM?
//Returns the available printers, e.g.
'LASER on LPT1'
. .
//\ensuremath{\mathsf{Means}} that one printer is available.
SYST:COMM:PRIN:SEL2 'LASER on LPT1'
//Selects the printer for the print job on device 2.
HCOP:PAGE:ORI2 LAND
//\ensuremath{\mathsf{Selects}} the landscape format for the printout.
HCOP:TDST:STAT2 ON
//Includes date and time on the printout.
HCOP:ITEM:ALL
//Prints all screen elements
HCOP
//Initiates the printout.
```

## 15.9 Configuring the R&S FSWP

•	Basic Instrument Setup	579
	Configuring the Reference Frequency	
•	Calibrating the R&S FSWP and Checking Temperature	585
•	Customizing the Screen Layout	589
	Configuring Network and Remote Control	
•	Checking the System Configuration	600
•	Using Service Functions	606
•	Reference: Command Set of 5052 Emulation	608
•	Reference: Command Set of Emulated PSA Models	610

## 15.9.1 Basic Instrument Setup

SYSTem:CLOGging	580
SYSTem:REBoot	580
SYSTem:SHUTdown	580
SYSTem:DATE	580
SYSTem:TIME	580

## SYSTem:CLOGging <State>

This command turns logging of remote commands on and off.

## **Parameters:**

<state></state>	ON   OFF   1   0
	ON   1
	Writes all remote commands that have been sent to a file. The destination is C:\R_S\INSTR\ScpiLogging\
	ScpiLog. <no.>.</no.>
	where <no.> is a sequential number</no.>
	A new log file is started each time logging was stopped and is restarted.
	OFF   0
	*RST: 0
Manual operation:	See "I/O Logging" on page 356

## SYSTem:REBoot

This command reboots the instrument, including the operating system.

## SYSTem:SHUTdown

This command shuts down the instrument.

#### SYSTem:DATE <Year>, <Month>, <Day>

Configures the date on the instrument.

 Parameters:

 <Year>

 <Month>

 <Day>

 Example:
 SYST:DATE 2020,04,23

 Manual operation:
 See " Set Date and Time " on page 282

SYSTem:TIME <Year>, <Month>, <Day>

Configures the time on the internal real-time clock on the instrument.

<hour></hour>	Range:	0 to 23
<minutes></minutes>	Range:	0 to 59
<seconds></seconds>	Range:	0 to 59
Example:	SYST:TIME	10,52,33

Manual operation: See " Set Date and Time " on page 282

## **15.9.2** Configuring the Reference Frequency

[SENSe:]ROSCillator:COUPling:BANDwidth	
[SENSe:]ROSCillator:COUPling:BANDwidth:MODE	581
[SENSe:]ROSCillator:COUPling:MODE	
[SENSe:]ROSCillator:LBWidth	582
[SENSe:]ROSCillator:O640	
SOURce <si>:EXTernal<ext>:ROSCillator:EXTernal:FREQuency</ext></si>	583
[SENSe:]ROSCillator:OSYNc	
[SENSe:]ROSCillator:SOURce	
[SENSe:]ROSCillator:SOURce:EAUTo?	584
[SENSe:]ROSCillator:TRANge	585

## [SENSe:]ROSCillator:COUPling:BANDwidth < Bandwidth>

This command defines coupling bandwidth for the internal reference frequency.

Prerequisites for this command

- Options R&S FSWP-B60 or -B61 must be available.
- Select manual bandwidth mode ([SENSe:]ROSCillator:COUPling: BANDwidth:MODE)

## Parameters:

<bandwidth></bandwidth>	<numeric value=""></numeric>
	Bandwidths 20 mHz, 1 Hz and 100 kHz are supported.
	Default unit: Hz
Example:	//Define coupling bandwidth
	ROSC:COUP:BAND:MODE MAN
	ROSC:COUP:BAND 1HZ

Manual operation: See "Advanced reference frequency configuration" on page 295

## [SENSe:]ROSCillator:COUPling:BANDwidth:MODE <Mode>

This command selects coupling bandwidth mode for the internal reference frequency.

Prerequisites for this command

• Options R&S FSWP-B60 or -B61 must be available.

#### **Parameters:**

<Mode>

### AUTO

Automatically selects an appropriate coupling bandwidth.

MANual

Manual selection of coupling bandwidth. You can select the bandwidth with [SENSe:]ROSCillator:COUPling: BANDwidth.

## \*RST: AUTO

Example: //Select coupling bandwidth mode ROSC:COUP:BAND:MODE AUTO

Manual operation: See "Advanced reference frequency configuration" on page 295

## [SENSe:]ROSCillator:COUPling:MODE <State>

This command turns the coupling of the internal reference frequency on and off.

Prerequisites for this command

• Options R&S FSWP-B60 or -B61 must be available.

## Parameters:

<state></state>	<b>AUTO</b> Automatically turns the coupling on and off, depending on the current measurement scenario.
	OFF
	Decouples the reference frequencies.
	ON Couples the reference frequencies. *RST: AUTO
Example:	//Synchronize reference frequencies ROSC:COUP:MODE ON
Manual operation:	See "Advanced reference frequency configuration" on page 295

### [SENSe:]ROSCillator:LBWidth <Bandwidth>

Defines the loop bandwidth, that is, the speed of internal synchronization with the reference frequency. The setting requires a compromise between performance and increasing phase noise.

For a variable external reference frequency with a narrow tuning range (+/- 0.5 ppm), the loop bandwidth is fixed to 0.1 Hz and cannot be changed.

## **Parameters:**

<bandwidth></bandwidth>	0.1 Hz   1 Hz   3 Hz   10 Hz   30 Hz   100 Hz   300 Hz The possible values depend on the reference source and tuning range (see Table 13-1). Default unit: Hz
Example:	ROSC:LBW 3
Manual operation:	See "Loop Bandwidth" on page 294

## [SENSe:]ROSCillator:O640 <State>

This command turns the output of a reference signal on the corresponding connector ("Ref Output") on and off.

[SENSe:]ROSCillator:0100: Provides a 100 MHz reference signal on corresponding connector.

[SENSe:]ROSCillator:0640: Provides a 640 MHz reference signal on corresponding connector.

 Parameters:

 <State>

 ON | OFF | 1 | 0

 OFF | 0

 Switches the reference off.

 ON | 1

 Switches the reference on

 //Output reference signal of 100 MHz.

 ROSC:0100 ON

 Manual operation:

## SOURce<si>:EXTernal<ext>:ROSCillator:EXTernal:FREQuency <Frequency>

This command defines the frequency of the external reference oscillator.

If the external reference oscillator is selected, the reference signal must be connected to the rear panel of the instrument.

Suffix:	
<si></si>	1n
<ext></ext>	1n
Parameters: <frequency></frequency>	Range: 1 MHz to 50 MHz Default unit: HZ
Example:	ROSC:EXT:FREQ 13MHZ Sets the frequency to 13 MHz. SOUR:EXT:ROSC:EXT:FREQ 13MHZ
Manual operation:	See "Reference Frequency Input" on page 293

## [SENSe:]ROSCillator:OSYNc <State>

If enabled, a 100 MHz reference signal is provided to the "SYNC TRIGGER OUTPUT" connector.

## Parameters:

C.........

<state></state>	ON   OFF   1   0	
	*RST: 0	
Example:	ROSC:OSYN ON	
Manual operation:	See "Reference Frequency Output" on page 295	

#### [SENSe:]ROSCillator:SOURce <Source>

This command selects the reference oscillator.

If you want to select the external reference, it must be connected to the R&S FSWP.

## Parameters:

<Source>

## INTernal

The internal reference is used (10 MHz)

#### EXTernal | EXTernal1 | EXT1

The external reference from the "REF INPUT 10 MHZ" connector is used; if none is available, an error flag is displayed in the status bar

## E10

The external reference from "REF INPUT 1..50 MHZ" connector is used with a fixed 10 MHZ frequency; if none is available, an error flag is displayed in the status bar

## E100

The external reference from the "REF INPUT 100 MHZ / 1 GHz" connector is used with a fixed 100 MHZ frequency; if none is available, an error flag is displayed in the status bar

## E1000

The external reference from "REF INPUT 100 MHZ / 1 GHz" connector is used with a fixed 1 GHZ frequency; if none is available, an error flag is displayed in the status bar

## EAUTo

The external reference is used as long as it is available, then the instrument switches to the internal reference

#### SYNC

The external reference is used; if none is available, an error flag is displayed in the status bar

Example: ROSC:SOUR EXT

Manual operation: See "Reference Frequency Input" on page 293 See "Behavior in case of missing external reference" on page 294

## [SENSe:]ROSCillator:SOURce:EAUTo?

This command queries the current reference type in case you have activated an automatic switch to the internal reference if the external reference is missing.

## Return values:

<Reference>

INT | EXT INT internal reference EXT external reference

Example:	SENS: ROSC: SOUR: EAUT? Queries the currently available reference type.
Usage:	Query only
Manual operation:	See "Behavior in case of missing external reference" on page 294

### [SENSe:]ROSCillator:TRANge <Range>

Defines the tuning range. The tuning range is only available for the variable external reference frequency. It determines how far the frequency may deviate from the defined level in parts per million (10<sup>-6</sup>).

## Parameters:

<Range>

WIDE | SMALI

The possible values depend on the reference source (see Table 13-1).

### SMALI

With this smaller deviation (+/- 0.5 ppm) a very narrow fixed loop bandwidth of 0.1 Hz is realized. With this setting the instrument can synchronize to an external reference signal with a very precise frequency. Due to the very narrow loop bandwidth, unwanted noise or spurious components on the external reference input signal are strongly attenuated. Furthermore, the loop requires about 30 seconds to reach a locked state. During this locking process, "NO REF" is displayed in the status bar.

## WIDE

The larger deviation (+/- 6 ppm) allows the instrument to synchronize to less precise external reference input signals.

Example: ROSC:TRAN WIDE

Manual operation: See "Tuning Range" on page 294

## 15.9.3 Calibrating the R&S FSWP and Checking Temperature

CALibration[:ALL]?	
CALibration:RESult?	586
DIAGnostic:SERVice:INPut:MC[:DISTance]	587
DIAGnostic:SERVice:INPut:PULSed:CFRequency	587
DIAGnostic:SERVice:INPut:RF[:SPECtrum]	
DIAGnostic:SERVice:INPut[:SELect]	
DIAGnostic:SERVice:INPut:SYNThtwo[:FREQuency]	588
DIAGnostic:SERVice:STESt:RESult?	
SOURce <si>:TEMPerature:FRONtend</si>	588

## CALibration[:ALL]?

This command initiates a calibration (self-alignment) routine and queries if calibration was successful.

During the acquisition of correction data the instrument does not accept any remote control commands.

**Note:** If you start a self-alignment remotely, then select the "Local" softkey while the alignment is still running, the instrument only returns to the manual operation state after the alignment is completed.

In order to recognize when the acquisition of correction data is completed, the MAV bit in the status byte can be used. If the associated bit is set in the Service Request Enable (SRE) register, the instrument generates a service request after the acquisition of correction data has been completed.

## Return values:

<calibrationfailed></calibrationfailed>	ON   OFF   0   1
	OFF   0
	Calibration was successful.
	ON   1
	Calibration was not successful.
Example:	*CLS
	Resets the status management.
	*SRE 16
	Enables MAV bit in the Service Request Enable register. *CAL?
	Starts the correction data recording, and then a service request
	is generated.
Usage:	Query only
Manual operation:	See " Start Self Alignment " on page 278

## CALibration:RESult?

This command returns the results collected during calibration.

String containing the calibration data.
CAL:RES? would return, e.g. Total Calibration Status: PASSED, Date (dd/mm/yyyy): 12/07/2004, Time: 16:24:54,Runtime: 00.06
Query only
See " Alignment Results: " on page 280

#### DIAGnostic:SERVice:INPut:MC[:DISTance] <Bandwidth>

This command selects the distance of the peaks of the microwave calibration signal for calibration of the YIG filter.

# Parameters: <Bandwidth>

WIDE | SMALI **SMALI** Small offset of combline frequencies. **WIDE** Wide offset of combline frequencies.

Manual operation: See " Calibration Frequency MW " on page 307

## DIAGnostic:SERVice:INPut:PULSed:CFRequency <Frequency>

This command defines the frequency of the calibration signal.

Before you can use the command, you have to feed in a calibration signal with DIAGnostic:SERVice:INPut[:SELect] on page 587.

Manual operation: See " Calibration Frequency RF " on page 306

## DIAGnostic:SERVice:INPut:RF[:SPECtrum] <Bandwidth>

This command selects the bandwidth of the calibration signal.

## Parameters:

<Bandwidth> NARRowband | BROadband NARRowband Narrowband signal for power calibration of the frontend. BROadband Broadband signal for calibration of the IF filter. Manual operation: See " Spectrum " on page 306

## DIAGnostic:SERVice:INPut[:SELect] <Signal>

This command activates or deactivates the use of an internal calibration signal as input for the R&S FSWP.

## Parameters:

<Signal>

#### CALibration

Uses the calibration signal as RF input.

#### **MCALibration**

Uses the calibration signal for the microwave range as RF input.

## RF

Uses the signal from the RF input.

## **SYNTtwo**

Uses the calibration signal to check the phase noise of the two synthesizers. A second synthesizer is available as an hardware option.

\*RST: RF

 Example:
 DIAG: SERV: INP\_CAL

 Uses the calibration signal as RF input.

 Manual operation:
 See " NONE " on page 306

 See " Calibration Frequency RF " on page 306

 See " Calibration Frequency MW " on page 307

 See " Calibration Synthesizer 2 " on page 307

## DIAGnostic:SERVice:INPut:SYNThtwo[:FREQuency] <Frequency>

This command selects the frequency which the synthesizers are calibrated for.

The command is available when you select the synthesizer as the calibration source with DIAGnostic:SERVice:INPut[:SELect] on page 587.

Parameters: <frequency></frequency>	Default unit: Hz
Example:	DIAG:SERV:INP:SEL SYNT DIAG:SERV:INP:SYNT 10MHZ
Manual operation:	See " Calibration Synthesizer 2 " on page 307

## DIAGnostic:SERVice:STESt:RESult?

This command queries the self-test results.

<b>Return values:</b> <results></results>	String of data containing the results. The rows of the self-test result table are separated by commas.
Example:	DIAG:SERV:STES:RES? would return, e.g. "Total Selftest Status: PASSED", "Date (dd/mm/yyyy): 09/07/2004 TIME: 16:24:54", "Runtime: 00:06", "
Usage:	Query only

## SOURce<si>:TEMPerature:FRONtend

This command queries the current frontend temperature of the R&S FSWP.

During self-alignment, the instrument's (frontend) temperature is also measured (as soon as the instrument has warmed up completely). This temperature is used as a reference for a continuous temperature check during operation. If the current temperature deviates from the stored self-alignment temperature by a certain degree, a warning is displayed in the status bar indicating the resulting deviation in the measured power levels. A status bit in the STATUs:QUEStionable:TEMPerature register indicates a possible deviation.

(This feature is available in the optional Spectrum and Signal Analyzer application.)

Suffix: < <sub>Si</sub> >	irrelevant
<b>Return values:</b> <temperature></temperature>	Temperature in degrees Celsius.
Example:	SOUR: TEMP: FRON? Queries the temperature of the frontend sensor.

## 15.9.4 Customizing the Screen Layout

•	Configuring Screen Elements	589
•	Selecting Colors and Schemes	592

## 15.9.4.1 Configuring Screen Elements

Useful commands to configure screen elements described elsewhere:

- DISPlay[:WINDow<n>]:MTABle
- DISPlay:FORMat

DISPlay:ANNotation:CBAR	
DISPlay:ANNotation:FREQuency	
DISPlay:SBAR[:STATe]	
DISPlay:SKEYs[:STATe]	590
DISPlay:TBAR[:STATe]	
DISPlay:TOUChscreen[:STATe]	
DISPlay[:WINDow <n>]:TIME</n>	
DISPlay[:WINDow <n>]:TIME:FORMat</n>	591
SYSTem:DISPlay:FPANel[:STATe]	

## DISPlay:ANNotation:CBAR <State>

This command hides or displays the channel bar information.

Parameters:		
<state></state>	ON   OFF   0   1	
	*RST: 1	
Example:	DISP:ANN:CBAR OFF	
Manual operation:	See " Channel Bar " on page 284	

\_

#### DISPlay:ANNotation:FREQuency <State>

This command turns the label of the x-axis on and off.

Parameters:

<State>

Example:

ON   OFF   0	) 1	
*RST:	1	
DISP:ANN:	FREQ	OFF

Manual operation: See " Diagram Footer (Annotation) " on page 284

#### DISPlay:SBAR[:STATe] <State>

This command turns the status bar on and off.

Parameters:

<State>

**Example:** 

ON   OFF   0   1 *RST: 1
DISP:SBAR:OFF

Manual operation: See " Status Bar " on page 284

#### DISPlay:SKEYs[:STATe] <State>

This command turns the softkey bar on and off.

#### Parameters:

<state></state>	ON   OFF   0   1	
	*RST: 1	
Example:	DISP:SKEY:OFF	
Manual operation:	See " Softkey Bar " on page 284	

## DISPlay:TBAR[:STATe] <State>

This command turns the toolbar on or off.

## Parameters:

<State>

ON   OFF   1	0
*RST:	0
DISP:TBAR	ON

**Example:** DISP:TE

Manual operation: See "Toolbar " on page 283

## DISPlay:TOUChscreen[:STATe] <State>

This command controls the touch screen functionality.

# Parameters: <State>

ON | FRAMe | OFF

	ON   1 Touch screen is active for entire screen
	<b>OFF   0</b> Touch screen is inactivate for entire screen
	FRAMeTouch screen is inactivate for the diagram area of the screen, but active for softkeys, toolbars and menus.*RST:1
Example:	DISP:TOUC:STAT ON
Manual operation:	See " Deactivating and Activating the Touchscreen " on page 282

## DISPlay[:WINDow<n>]:TIME <State>

This command adds or removes the date and time from the display.

Suffix: <n></n>	irrelevant
Parameters: <state></state>	ON   OFF   1   0 *RST: 0
Example:	DISP:TIME ON
Manual operation:	See " Date and Time " on page 284

## DISPlay[:WINDow<n>]:TIME:FORMat <Format>

This command selects the time and date format.

Suffix:	
<n></n>	irrelevant
Parameters:	
<format></format>	US   DE
	DE
	dd.mm.yyyy hh:mm:ss
	24 hour format.
	US
	mm/dd/yyyy hh:mm:ss
	12 hour format.
	*RST: DE
Example:	DISP:TIME ON
	Switches the screen display of date and time on.
	DISP:TIME:FORM US
	Switches the date and time format to US.
Manual operation:	See " Date and Time Format " on page 283

## SYSTem:DISPlay:FPANel[:STATe] <State>

This command includes or excludes the front panel keys when working with the remote desktop.

Parameters:

<state></state>	ON   OFF   0   1
	*RST: 1
Manual operation:	See " Front Panel " on page 284 See " Mini Front Panel " on page 285

## 15.9.4.2 Selecting Colors and Schemes

Useful commands to select colors and schemes described elsewhere:

- HCOPy:CMAP<it>:DEFault<ci>
- HCOPy:CMAP<it>:HSL
- HCOPy:CMAP<it>:PDEFined

DISPlay:CMAP <it>:DEFault<ci></ci></it>	592
DISPlay:CMAP <it>:HSL</it>	593
DISPlay:CMAP <it>:PDEFined</it>	
DISPlay:THEMe:CATalog?	
DISPlay:THEMe:SELect	

## DISPlay:CMAP<it>:DEFault<ci>

This command resets the color scheme for the display. The query returns the default color scheme.

## Suffix:

<it></it>	Selects the item for which the color scheme is to be defined. For more information see Chapter 15.9.4.3, "CMAP Suffix Assignment", on page 594.
<ci></ci>	1 Current colors with a white background and a black grid. 2 Optimized colors. 3 Customized colors. 4 Current screen colors (setting for hardcopies). Suffix irrelevant for query
Return values:	
<defscheme></defscheme>	1   2   3   4
	The default color scheme for the selected item, as specified by the <ci> suffix.</ci>

Example:	DISP:CMAP:DEF2
	Selects default setting 2 for setting the colors.
	DISP:CMAP:DEF?
	//Result: 2

Manual operation: See " Screen Colors " on page 287

## DISPlay:CMAP<it>:HSL <hue>, <sat>, <lum>

This command selects the color for various screen elements in the display.

Suffix:		
<it></it>	For more in	item for which the color scheme is to be defined. formation see Chapter 15.9.4.3, "CMAP Suffix t", on page 594.
Parameters:		
<hue></hue>	tint	
	Range:	0 to 1
<sat></sat>	saturation	
	Range:	0 to 1
<lum></lum>	brightness	
	Range:	0 to 1
Example:		P2:HSL 0.3,0.8,1.0 ne grid color.

## DISPlay:CMAP<it>:PDEFined <Color>

This command selects a predefined color for various screen elements.

Suffix:	
<it></it>	1n Selects the item for which the color scheme is to be defined. For more information see Chapter 15.9.4.3, "CMAP Suffix Assignment", on page 594.
Parameters:	
<color></color>	BLACk   BLUE   BROWn   GREen   CYAN   RED   MAGenta   YELLow   WHITe   DGRay   LGRay   LBLue   LGReen   LCYan   LRED   LMAGenta
Example:	DISP:CMAP2:PDEF GRE
Manual operation:	See "Restoring the User Settings to Default Colors" on page 289

## DISPlay:THEMe:CATalog?

This command queries all available display themes.

Return values: <themes></themes>	String containing all available display themes.
Example:	DISP:THEMe:CAT?
Usage:	Query only

## DISPlay:THEMe:SELect <Theme>

This command selects the display theme.

Parameters: <theme></theme>	String containing the name of the theme.
	*RST: SPL
Example:	DISP:THEM:SEL "BlueOcean"
Manual operation:	See " Theme " on page 287

## 15.9.4.3 CMAP Suffix Assignment

Several commands to change the color settings of individual items of the display or printout are available. Which item is to be configured is defined using a <CMAP> suffix. The following assignment applies:

Suffix	Description
CMAP1	Background
CMAP2	Grid
CMAP3 *)	Common Text
CMAP4 *)	Check Status OK
CMAP5 *)	Check Status Error
CMAP6 *)	Text Special 1
CMAP7 *)	Text Special 2
CMAP8	Trace 1
CMAP9	Trace 2
CMAP10	Trace 3
CMAP11	Marker Info Text
CMAP12	Limit Lines
CMAP13	Limit and Margin Check – "Pass"
CMAP14	Limit and Margin Check – "Fail"
CMAP15 *)	Softkey Text
CMAP16 *)	Softkey Background
CMAP17 *)	Selected Field Text

Configuring the R&S FSWP

Suffix	Description
CMAP18 *)	Selected Field Background
CMAP19 *)	Softkey 3D Bright Part
CMAP20 *)	Softkey 3D Dark Part
CMAP21 *)	Softkey State "On"
CMAP22 *)	Softkey State "Dialog open"
CMAP23 *)	Softkey Text Disabled
CMAP24	Logo
CMAP25	Trace 4
CMAP26	Grid – Minorlines
CMAP27	Marker
CMAP28	Display Lines
CMAP29 *)	Sweepcount – Text
CMAP30	Limit and Margin Check – Text
CMAP31	Limit and Margin Check – \"Margin\"
CMAP32 *)	Table Overall – Title Text
CMAP33 *)	Table Overall – Title Background
CMAP34 *)	Table Overall – Text
CMAP35 *)	Table Overall – Background
CMAP36 *)	Table Value – Title Text
CMAP37 *)	Table Value – Title Background
CMAP38 *)	Table Value – Text
CMAP39 *)	Table Value – Background
CMAP40	Trace 5
CMAP41	Trace 6
*) these settings can only be defined via the theme (DISPlay: THEMe: SELect) and are thus ignored in the SCPI command	

## 15.9.5 Configuring Network and Remote Control

SYSTem:COMMunicate:GPIB[:SELF]:ADDRess	596
SYSTem:COMMunicate:GPIB[:SELF]:RTERminator	
SYSTem:DISPlay:LOCK.	
SYSTem:DISPlay:UPDate	
SYSTem:ERRor:CLEar:REMote	
SYSTem:ERRor:DISPlay	597
SYSTem:IDENtify:FACTory	

## Configuring the R&S FSWP

SYSTem:IDENtify[:STRing]	
SYSTem:KLOCk.	598
SYSTem:LANGuage	
SYSTem:LXI:LANReset	
SYSTem:LXI:MDEScription	
SYSTem:LXI:PASSword	
SYSTem:PSA:WIDeband	
SYSTem:SHIMmediate:STATe	
SYSTem:SHIMmediate ONCE	600

## SYSTem:COMMunicate:GPIB[:SELF]:ADDRess <Address>

This command sets the GPIB address of the R&S FSWP.

## Parameters:

<address></address>	Range: *RST:	0 to 30 (no influence on this parameter, factory default 20)
Example:	SYST:COMM:GPIB:ADDR 18	
Manual operation:	See "GPIB Address" on page 355	

## SYSTem:COMMunicate:GPIB[:SELF]:RTERminator < Terminator>

This command selects the GPIB receive terminator.

Output of binary data from the instrument to the control computer does not require such a terminator change.

<terminator></terminator>	LFEOI   EOI	
	LFEOI	
	According to the standard, the terminator in ASCII is <lf> and/or <eoi>.</eoi></lf>	
	EOI	
	For binary data transfers (e.g. trace data) from the control com- puter to the instrument, the binary code used for <lf> might be included in the binary data block, and therefore should not be interpreted as a terminator in this particular case. This can be avoided by using only the receive terminator EOI. *RST: LFEOI</lf>	
Example:	SYST:COMM:GPIB:RTER EOI	
Manual operation:	See "GPIB Terminator" on page 356	

#### SYSTem:DISPlay:LOCK <State>

Defines whether the "Display Update" function remains available in remote operation or not.

## **Parameters:**

<State>

ON | OFF | 0 | 1 **OFF | 0** The function remains available. **ON | 1** The function is not available and the display is not updated during remote operation. \*RST: 0

## SYSTem:DISPlay:UPDate <State>

This command turns the display during remote operation on and off.

If on, the R&S FSWP updates the diagrams, traces and display fields only.

The best performance is obtained if the display is off during remote control operation.

## Parameters:

<state></state>	ON   OFF   1   0	
	*RST: 0	
Example:	SYST:DISP:UPD ON	
Manual operation:	See "Remote Display Update" on page 356	

## SYSTem:ERRor:CLEar:REMote

This command deletes all contents of the "Remote Errors" table.

Note: The remote error list is automatically cleared when the R&S FSWP is shut down.

**Example:** SYST:ERR:CLE:REM

Manual operation: See "Display Remote Errors" on page 357 See "Clear Error List" on page 361

## SYSTem:ERRor:DISPlay <State>

This command the error display during remote operation on and off.

If activated, the R&S FSWP displays a message box at the bottom of the screen that contains the most recent type of error and the command that caused the error.

<state></state>	ON   OFF   1   0		
	*RST:	0	
Example:	SYST:ER	R:DISP	ON

Manual operation: See "Display Remote Errors" on page 357

## SYSTem:IDENtify:FACTory

This command resets the query to **\*IDN**? to its default value.

Manual operation: See "Reset to Factory String" on page 355

## SYSTem:IDENtify[:STRing] <String>

This command defines the response to **\*IDN**?.

**Parameters:** 

<string></string>	String containing the description of the instrument.
Manual operation:	See "Identification String" on page 355

## SYSTem:KLOCk <State>

This command activates the local lockout (remote control) or returns to the local mode.

Parameters: <state></state>	<b>ON</b> LLO (local lockout)
	<b>OFF</b> GTL (go to local) *RST: OFF
Example:	SYST:KLOC ON Activates LLO (remote control)
Manual operation:	See "Local" on page 361

## SYSTem:LANGuage <Language>

This command selects the system language.

<language></language>	String containing the name of the language.	
	'SCPI'	
	SCPI language.	
	'PSA'	
	PSA emulation.	
	For a list of supported commands, see Chapter 15.9.9, "Refer-	
	ence: Command Set of Emulated PSA Models", on page 610.	
	*RST: SCPI	
Example:	SYST:LANG 'PSA'	
	Emulates the PSA.	
Manual operation:	See "Language" on page 358	

#### SYSTem:LXI:LANReset

This command resets the LAN configuration, as well as the "LAN" password and instrument description.

Manual operation: See " LAN Reset" on page 360

#### SYSTem:LXI:MDEScription < Description>

This command defines the "LAN" instrument description.

#### **Parameters:**

<Description> String containing the instrument description.

#### SYSTem:LXI:PASSword < Password>

This command defines the "LAN" password.

 Parameters:

 <Password>

 String containing the password.

 Manual operation:

 See "LAN Password" on page 360

#### SYSTem:PSA:WIDeband <State>

This command defines which option is returned when the \*OPT? query is executed, depending on the state of the wideband option.

It is only available for PSA89600 emulation.

## Parameters:

<state></state>	ON   OFF   HIGH
	OFF
	The option is indicated as "B7J"
	ON
	The 40 MHz wideband is used.
	The option is indicated as "B7J, 140".
	HIGH
	The 80 MHz wideband is used.
	The option is indicated as "B7J, 122".
	*RST: OFF
Manual operation:	See "Wideband" on page 358

#### SYSTem:SHIMmediate:STATe <State>

Determines when the remote commands that change hardware settings on the R&S FSWP are executed.

Regardless of this setting, the firmware automatically sets the hardware when a sweep is started.

This setting is not changed by the preset function.

Parameters:			
<state></state>	ON   OFF   0   1		
	OFF   0		
	Remote commands that cause changes to the hardware are		
	only executed when the SYSTem:SHIMmediate ONCE com-		
	mand is executed.		
	ON   1		
	Remote commands are always executed immediately when they are received by the instrument.		
	*RST: 1		
Example:	SYST:SHIM:STAT ON		
	SYST:SHIM ONCE		
Manual operation:	See "Set Hardware Immediately" on page 357		

## SYSTem:SHIMmediate ONCE

Executes any received remote commands that cause changes to the hardware and have not been executed yet due to a SYST: SHIM: STAT OFF command.

Manual operation:	See "Set Hardware Immediately" on page 357
Usage:	Event
	 SYST:SHIM ONCE
Example:	SYST:SHIM:STAT ON

## 15.9.6 Checking the System Configuration

Useful commands to check the system configuration described elsewhere:

• DIAGnostic:SERVice:SINFo?

DIAGnostic:INFO:CCOunt? DIAGnostic:SERVice:BIOSinfo?	
DIAGnostic:SERVice:HWINfo?	
DIAGnostic:SERVice:VERSinfo?	602
SYSTem:ERRor:CLEar:ALL	603
SYSTem:ERRor:EXTended?	603
SYSTem:ERRor:LIST?	603
SYSTem:ERRor[:NEXT]?	604
SYSTem:FIRMware:UPDate	
SYSTem:FORMat:IDENt	604
SYSTem:PRESet:COMPatible	605
SYSTem:PRESet:FILTer	605
SYSTem:SECurity[:STATe]	605

## DIAGnostic:INFO:CCOunt? <Relay>

This command queries how many switching cycles the individual relays have performed since they were installed.

## Query parameters:

<relay></relay>	ACDC		
	Mechanical Attenuation Coupling		
	ATT5		
	Mechanical Attenuation 05 DB		
	ATT10		
	Mechanical Attenuation 10 DB		
	ATT20		
	Mechanical Attenuation 20 DB		
	ATT40		
	Mechanical Attenuation 40 DB		
	CAL		
	Mechanical Calibration Source		
	EATT		
	Electrical Attenuation Bypass		
	PREamp		
	Preamplifier Bypass		
	SATT10   SATT20   SATT40		
	Mechanical attenuation (10, 20 and 40 dB) for the optional Signal Source hardware.		
	SCAL		
	DUT bypass (available with the optional Signal Source hard- ware).		
Return values:			
<cycles></cycles>	Number of switching cycles.		
Example:	DIAG:INFO:CCO? CAL		
Usage:	Query only		
Manual operation:	See " Relays Cycle Counter " on page 310		

## DIAGnostic:SERVice:BIOSinfo?

This command queries the BIOS version of the CPU board.

Return values: <biosinformation></biosinformation>	String containing the BIOS version.
Example:	DIAG:SERV:BIOS? Returns the BIOS version.
Usage:	Query only

## DIAGnostic:SERVice:HWINfo?

This command queries hardware information.

## **Return values:**

<hardware></hardware>	String containing the following information for every hardware component. <component>: name of the hardware component <serial#>: serial number of the component <order#>: order number of the component <model>: model of the component <code>: code of the component <revision>: revision of the component <subrevision>: subrevision of the component</subrevision></revision></code></model></order#></serial#></component>	
Example:	DIAG:SERV:HWIN? Queries the hardware information. "FRONTEND 100001/003 1300.3009 03 01 00 00", "MOTHERBOARD 123456/002 1300.3080 02 00 00 00", 	
Usage:	Query only	

## DIAGnostic:SERVice:VERSinfo?

This command queries information about the hardware and software components.

## Return values:

Return values.			
<information></information>	String containing the version of hardware and software compo- nents including the types of licenses for installed options.		
Example:	DIAG:SERV:VERS?		
-	Queries the version information.		
	Response:		
	Instrument Firmware  1.10,		
	BIOS  R&S ANALYZER BIOS V1.80-5-07-1 IPC11,		
	Image Version  1.6.0,		
	Device Installation Version  1.0.0,		
	PCIE-FPGA  13.06,		
	SA-FPGA  6.46,		
	MB-FPGA  2.1.3.0,		
	SYNTH-18G-FPGA  4.8.0.0,		
	SYNTH-18G-FPGA 2  4.8.0.0,		
	REF-FPGA  3.4.0.0,		
	MWC-FPGA  3.4.0.0,		
	PNDIGIT-FPGA  0.46,		
	Data Sheet Version  01.00,		
	Time Control Management   active,		
	Cross Correlation Measurements B60  ,		
	Signal Source B64  ,		

Usage:

Query only

## SYSTem:ERRor:CLEar:ALL

This command deletes all contents of the "System Messages" table.

**Example:** SYST:ERR:CLE:ALL

## SYSTem:ERRor:EXTended? < MessageType>[, < ChannelName>]

This command queries all system messages, or all messages of a defined type, displayed in the status bar for a specific channel (application).

**Note:** This command queries the strings displayed for manual operation. For remote programs, do not define processing steps depending on these results. Instead, query the results of the STATUS:QUEStionable:EXTended:INFO status register, which indicates whether messages of a certain type have occurred (see "STATUS:QUEStionable:EXTended:INFO Register" on page 341).

Para	meters:
------	---------

<messagetype></messagetype>	ALL   INFO   WARNing   FATal   ERRor   MESSage
<channelname></channelname>	String containing the name of the channel. The parameter is optional. If you omit it, the command works for the currently active channel.
Return values: <messages></messages>	String containing all messages of the selected type for the speci- fied channel. Each message is separated by a comma and inserted in parentheses. If no messages are available, empty parentheses are returned.
Example:	SYST: ERR: EXT? ALL Returns all messages for the currently active application, e.g. "Message 1", "Message 2".
Example:	SYST: ERR: EXT? FAT, 'Spectrum2' Queries fatal errors in the 'Spectrum2' application. If none have occurred, the result is: " ".
Usage:	Query only

#### SYSTem:ERRor:LIST? [<MessType>]

This command queries the error messages that occur during R&S FSWP operation.

#### **Query parameters:**

<MessType> SMSG | REMote SMSG (default) Queries the system messages which occurred during manual operation.

	<b>REMote</b> Queries the error messages that occurred during remote opera- tion. Note: The remote error list is automatically cleared when the R&S FSWP is shut down.	
Return values: <systemmessages></systemmessages>	String containing all messages in the "System Messages" table.	
<remoteerrors></remoteerrors>	<pre><error_no>   <description>   <command/>   <date>   <time> Comma-separated list of errors from the "Remote Errors" table, where: <error_no>: device-specific error code <description>: brief description of the error <command/>: remote command causing the error <date> <time>: date and time the error occurred</time></date></description></error_no></time></date></description></error_no></pre>	
Usage:	Query only	

## SYSTem:ERRor[:NEXT]?

This command queries the most recent error queue entry and deletes it.

Positive error numbers indicate device-specific errors, negative error numbers are error messages defined by SCPI. If the error queue is empty, the error number 0, "No error", is returned.

For details on error queues see Chapter 14.1.7, "Status Reporting System", on page 332.

Usage: Query only

## SYSTem:FIRMware:UPDate < Directory>

This command starts a firmware update using the \*.msi files in the selected directory. The default path is D:\FW\_UPDATE. The path is changed via the MMEMory:COMMent command. To store the update files the MMEMory:DATA command is used.

Only user accounts with administrator rights can perform a firmware update.

#### Setting parameters:

<Directory>

Example: SYST:FIRM:UPD 'D:\FW\_UPDATE' Starts the firmware update from directory "D:\FW\_UPDATE".

## SYSTem:FORMat:IDENt <IDNFormat>

This command selects the response format to the **\*IDN**? query.

LEGacy

## **Parameters:**

<IDNFormat>

Format is compatible to R&S FSP/FSU/FSQ/FSG family.

	NEW   FSL R&S FSWP format Format is also compatible to the R&S FSL and R&S FSV family *RST: not reset!	
Example:		IIDEN LEG return value of *IDN? to the R&S FSP/FSU/FSQ fam-
Manual operation:	See "*IDN F	Format" on page 356

## SYSTem:PRESet:COMPatible <OpMode>

This command defines the operating mode that is activated when you switch on the R&S FSWP or press the [PRESET] key.

#### **Parameters:**

<opmode></opmode>	<b>SANalyzer</b> Defines Signal and Spectrum Analyzer operating mode as the presetting.	
	<b>OFF</b> Selects the phase noise application as the default application (default value).	
Manual operation:	See " Preset Mode " on page 302	

## SYSTem:PRESet:FILTer <FilterType>

This command selects the resolution filter type that is selected after a preset in the Spectrum application.

## **Parameters:**

<filtertype></filtertype>	NORMal Selects 3 dB	3 filter.
	NOISe Selects 3 dB (NORMal an	filter. Id NOISe have the same effect.)
	PULSe Selects 6 dB *RST:	3 filter. NORMal
Example:	//Select the	6 dB filters as the default filter type FILT PULS

## SYSTem:SECurity[:STATe] <State>

Activates or queries secure user mode.

**Note:** Before you activate secure user mode, store any instrument settings that are required beyond the current session, such as predefined instrument settings, transducer files, or self-alignment data.

**Note:** Initially after installation of the R&S FSWP-K33 option, secure user mode must be enabled manually once before remote control is possible. This is necessary to prompt for a change of passwords.

For details on the secure user mode see Chapter 4.7, "Protecting Data Using the Secure User Mode", on page 31.

## Parameters:

<State>

ON | OFF | 0 | 1

## ON | 1

The R&S FSWP automatically reboots and starts in secure user mode. In secure user mode, no data is written to the instrument's internal solid-state drive. Data that the R&S FSWP normally stores on the solid-state drive is redirected to SDRAM.

### OFF | 0

The R&S FSWP is set to normal instrument mode. Data is stored to the internal solid-state drive. Note: this parameter is for query only. Secure user mode cannot be deactivated via remote operation.

\*RST:

Manual operation: See "SecureUser Mode " on page 302

0

## 15.9.7 Using Service Functions

DIAGnostic:SERVice:SFUNction	606
DIAGnostic:SERVice:SFUNction:LASTresult?	607
DIAGnostic:SERVice:SFUNction:RESults:DELete	607
DIAGnostic:SERVice:SFUNction:RESults:SAVE	607
DIAGnostic:SERVice:SINFo?	
SYSTem:PASSword:RESet.	608
SYSTem:PASSword[:CENable]	

### DIAGnostic:SERVice:SFUNction <ServiceFunction>

This command starts a service function.

The service functions are available after you have entered the level 1 or level 2 system password.

## Parameters for setting and query:

<ServiceFunction> String containing the ID of the service function.

The ID of the service function is made up out of five numbers, separated by a point.

- function group number
- board number
- function number
- parameter 1 (see the Service Manual)
- parameter 2 (see the Service Manual)

Example:	DIAG:SERV:SFUN 'Function1' DIAG:SERV:SFUN? 'Function2'
Manual operation:	See " Service Function " on page 308 See " Send " on page 308

## DIAGnostic:SERVice:SFUNction:LASTresult?

This command queries the results of the most recent service function you have used.

Return values: <Result>

Usage: Query only

## DIAGnostic:SERVice:SFUNction:RESults:DELete

This command deletes the results of the most recent service function you have used.

Usage:EventManual operation:See " Clear Results " on page 309

## DIAGnostic:SERVice:SFUNction:RESults:SAVE [<FileName>]

This command saves the results of the most recent service function you have used.

Parameters: <FileName> String cont

Name> String containing the file name.

Manual operation: See "Save Results " on page 309

## DIAGnostic:SERVice:SINFo?

This command creates a \*.zip file with important support information. The \*.zip file contains the system configuration information ("device footprint"), the current eeprom data and a screenshot of the screen display (if available).

This data is stored to the C:\R S\INSTR\USER directory on the instrument.

As a result of this command, the created file name (including the drive and path) is returned.

You can use the resulting file name information as a parameter for the MMEM: COPY command to store the file on the controller PC.

If you contact the Rohde&Schwarz support to get help for a certain problem, send this file to the support in order to identify and solve the problem faster.

#### Return values:

<FileName>

C:\R\_S\INSTR\USER \<R&S Device ID>\_<CurrentDate>\_<CurrentTime>

	String containing the drive, path and file name of the created support file, where the file name consists of the following ele- ments: <b><r&s device="" id=""></r&s></b> : The unique R&S device ID indicated in the "Versions + Options" information <b><currentdate></currentdate></b> : The date on which the file is created ( <yyyymmdd>) <b><currenttime></currenttime></b>: The time at which the file is created (<hhmmss>)</hhmmss></yyyymmdd>
Example:	DIAG:SERV:SINF? <b>Result:</b> "c:\R&S\instr\user\FSWP-26_1322.8003K26-100005-xx_20130116_165858.zip"
	<pre>MMEM:COPY "c:\R&amp;S\instr\user\FSWP-26_ 1322.8003K26-100005-xx_20130116_165858.zip", "S:\Debug\FSWP-26_1322.8003K26-100005-xx_ 20130116_165858.zip"</pre>
Usage:	Query only
Manual operation:	See " Create R&S Support Information " on page 304

## SYSTem:PASSword:RESet

Clears any previously provided password and returns to the most restrictive service level.

Manual operation: See " Password " on page 309

## SYSTem:PASSword[:CENable] <arg0>

Provides a password for subsequent service functions.

Parameters: <arg0></arg0>	string	
Example:	SYST:PASS:CEN	'894129'
Manual operation:	See " Password " o	on page 309

## 15.9.8 Reference: Command Set of 5052 Emulation

CALCulate:PN{xch}:DATA:CARRier
CALCulate:PN{xch}:TRACe{trc}:BDMarker:X:STARt
CALCulate:PN{xch}:TRACe{trc}:BDMarker:X:STATe
CALCulate:PN{xch}:TRACe{trc}:BDMarker:X:STOP
CALCulate:PN{xch}:TRACe{trc}:FUNCtion:INTegral:DATA
CALCulate:PN{xch}:TRACe{trc}:FUNCtion:DOMain:X

CALCulate:PN{xch}:TRACe{trc}:FUNCtion:DOMain:Y
CALCulate:PN{xch}:TRACe{trc}:FUNCtion:TYPE
CALCulate:PN{xch}:TRACe{trc}:LIMit:FAIL
CALCulate:PN{xch}:TRACe{trc}:LIMit:LOWer:SEGMent:CLEar
CALCulate:PN{xch}:TRACe{trc}:LIMit:LOWer:SEGMent:COUNt
CALCulate:PN{xch}:TRACe{trc}:LIMit:LOWer:SEGMent:DATA
CALCulate:PN{xch}:TRACe{trc}:LIMit:STATe
CALCulate:PN{xch}:TRACe{trc}:LIMit:UPPer:SEGMent:CLEar
CALCulate:PN{xch}:TRACe{trc}:LIMit:UPPer:SEGMent:COUNt
CALCulate:PN{xch}:TRACe{trc}:LIMit:UPPer:SEGMent:DATA
CALCulate:PN{xch}:TRACe{trc}:MARKer{mk}:SEARch:EXECute:LPEak
CALCulate:PN{xch}:TRACe{trc}:MARKer{mk}:SEARch:EXECute:MAXimum
CALCulate:PN{xch}:TRACe{trc}:MARKer{mk}:SEARch:EXECute:MINimum
CALCulate:PN{xch}:TRACe{trc}:MARKer{mk}:SEARch:EXECute:PEAK
CALCulate:PN{xch}:TRACe{trc}:MARKer{mk}:SEARch:EXECute:RPEak
CALCulate:PN{xch}:TRACe{trc}:MARKer{mk}:SEARch:PEAK:EXCursion
CALCulate:PN{xch}:TRACe{trc}:MARKer{mk}:STATe
CALCulate:PN{xch}:TRACe{trc}:MARKer{mk}:X
CALCulate:PN{xch}:TRACe{trc}:MARKer{mk}:Y
CALCulate:PN{xch}:TRACe{trc}:SMOothing:APERture
CALCulate:PN{xch}:TRACe{trc}:SMOothing:STATe
CALCulate:PN{xch}:TRACe{trc}:SPURious:OMISsion
CALCulate:PN{xch}:TRACe{trc}:SPURious:POWer
DISPlay:MAXimize
DISPlay:PN{xch}:MAXimize
DISPlay:PN{xch}:STATe
DISPlay:WINDow:ACTive
INITiate:PN{xch}:CONTinuous
INITiate:PN{xch}:IMMediate
[SENSe]:ATTenuation:LEVel
[SENSe]:PN{xch}:ASET
[SENSe]:PN{xch}:AVERage:CLEar
[SENSe]:PN{xch}:AVERage:STATe
[SENSe]:PN{xch}:AVERage:COUNt

[SENSe]:PN{xch}:CORRelation:COUNt
[SENSe]:PN{xch}:CRANge
[SENSe]:PN{xch}:FBANd
[SENSe]:PN{xch}:FREQuency:STARt
[SENSe]:PN{xch}:FREQuency:STOP
[SENSe]:PN{xch}:IFGain
[SENSe]:PN{xch}:LOBandwidth
[SENSe]:PN{xch}:ROSCillator:BANDwidth
[SENSe]:PN{xch}:ROSCillator:REFerence{ref}:SOURce
[SENSe]:PN{xch}:SEGTable:MEASurement:QUALity
[SENSe]:PN{xch}:SWEep:POINts
TRIGger:AVERage
TRIGger:MODE
TRIGger:PN:SOURce
TRIGger:SOPC

## 15.9.9 Reference: Command Set of Emulated PSA Models

The R&S FSWP analyzer family supports a subset of the GPIB commands of PSA89600 instruments.

Despite the differences in system architecture and device features, the supported commands have been implemented in a way to ensure a sufficiently high degree of correspondence with the original.

In many cases the selection of commands supported by the R&S FSWP is sufficient to run an existing GPIB program without adaptation.

Supported 89600 commands
*CAL?
*CLS
*ESE
*ESR?
*IDN?
*IST?
*OPC
*OPT?
*PCB

Configuring the R&S FSWP

Supported 89600 commands	
PRE	
PSC	
RST	
SRE	
STB?	
TRG	
TST?	
'WAI	
CALibration:AUTO OFF ON ALERt	
CALibration:TCORrections AUTO ON OFF	
CONFigure:WAVeform	
DIAGnostic:EABY ON OFF	
DIAGnostic:LATCh:VALue <numeric></numeric>	
DIAGnostic:LATCh:SELect <string></string>	
DISPlay:ANNotation:TITLe:DATA <string></string>	
DISPlay:ENABle OFF ON	
DISPlay:WINDow:TRACe:Y:[SCALe]:PDIVision <numeric></numeric>	
DISPlay:WINDow:TRACe:Y:[SCALe]:RLEVel <numeric></numeric>	
DISPlay:WINDow:TRACe:Y:[SCALe]:RLEVel:OFFSet <numeric></numeric>	
FORMat:BORDer NORMal SWAPped	
FORMat[:DATA] ASCii REAL UINT MATLAB, <numeric></numeric>	
INITiate:CONTinuous OFF ON	
INITiate[:IMMediate]	
INSTrument:CATalog?	
INSTrument:NSELect <numeric></numeric>	
MMEMory:CATalog? <dir_name></dir_name>	
MMEMory:COPY <'file_name1'>,<'file_name2'>	
MMEMory:DATA <'file_name'>, <definite_length_block></definite_length_block>	
MMEMory:DELete <'file_name'>	
MMEMory:LOAD:STATe 1,<'file_name'>	
MMEMory:LOAD:TRACe 1,<'file_name'>	
MMEMory:MDIRectory <'dir_name'>	
MMEMory:MOVE <'file_name1'>,<'file_name2'>	

## Configuring the R&S FSWP

Supported 89600 commands
:MMEMory:STORe:STATe 1,<'file_name'>
:MMEMory:STORe:TRACe <numeric>,&lt;'file_name'&gt;</numeric>
:READ:WAVform?
[:SENSe]:FREQuency:CENTer <numeric></numeric>
[:SENSe]:FREQuency:STARt <numeric></numeric>
[:SENSe]:FREQuency:STOP <numeric></numeric>
[:SENSe]:FREQuency:SPAN <numeric></numeric>
[:SENSe]:POWer:ATTenuation <numeric></numeric>
[:SENSe]:ROSCillator:EXTernal:FREQuency <numeric></numeric>
[:SENSe]:ROSCillator:OUTPut OFF ON
[:SENSe]:ROSCillator:SOURce INTernal EXTernal EAUTo
[:SENSe]:SPECtrum:TRIGger:SOURce EXTernal<1 2> IF IMMediate
[:SENSe]:WAVeform:ADC:RANGe P6
[:SENSe]:WAVeform:APER?
[:SENSe]:WAVeform:AVERage:TACount <numeric></numeric>
[:SENSe]:WAVeform:BWIDth:ACTive?
[:SENSe]:WAVeform:BWIDth:TYPE FLAT GAUSsian
[:SENSe]:WAVeform:IFGain <numeric></numeric>
[:SENSe]:WAVeform:IFPath NARRow WIDE
[:SENSe]:WAVeform:NCPTrace ON OFF
[:SENSe]:WAVeform:PDIT ON OFF
[:SENSe]:WAVeform:SRATe <numeric></numeric>
[:SENSe]:WAVeform:SWEep:TIME <numeric></numeric>
[:SENSe]:WAVeform:TRIGger:EOFFset?
[:SENSe]:WAVeform:TRIGger:INTerpolation ON OFF
[:SENSe]:WAVeform:TRIGger:SOURce EXTernal<1 2> IF IMMediate
:STATus:QUEStionable:CONDition?
:STATus:QUEStionable:ENABle <number></number>
:STATus:QUEStionable:NTRansition <number></number>
:STATus:QUEStionable:PTRansition <number></number>
:STATus:QUEStionable[:EVENt]?
:STATus:QUEStionable:CALibration:CONDition?
:STATus:QUEStionable:CALibration:ENABle <number></number>

# Configuring the R&S FSWP

Supported 89600 commands
:STATus:QUEStionable:CALibration:NTRansition <number></number>
:STATus:QUEStionable:CALibration:PTRansition <number></number>
:STATus:QUEStionable:CALibration[:EVENt]?
:STATus:QUEStionable:FREQuency:CONDition?
:STATus:QUEStionable:FREQuency:ENABle <number></number>
:STATus:QUEStionable:FREQuency:NTRansition <number></number>
:STATus:QUEStionable:FREQuency:PTRansition <number></number>
:STATus:QUEStionable:FREQuency[:EVENt]?
:STATus:QUEStionable:INTegrity:CONDition?
:STATus:QUEStionable:INTegrity:ENABle <number></number>
:STATus:QUEStionable:INTegrity:NTRansition <number></number>
:STATus:QUEStionable:INTegrity:PTRansition <number></number>
:STATus:QUEStionable:INTegrity[:EVENt]?
:STATus:OPERation:CONDition?
:STATus:OPERation:ENABle <integer></integer>
:STATus:OPERation:NTRansition <integer></integer>
:STATus:OPERation:PTRansition <integer></integer>
:STATus:OPERation[:EVENt]?
:SYSTem:COMMunicate:GPIB[:SELF]:ADDRess <integer></integer>
:SYSTem:DATE <year>,<month>,<day></day></month></year>
:SYSTem:ERRor[:NEXT]?
:SYSTem:KLOCK?
:SYSTem:MESSage <string></string>
:SYSTem:PRESet
:SYSTem:TIME <hour>,<minute>,<second></second></minute></hour>
:SYSTem:VERSion?
:TRACe:COPY <src_trace>,<dest_trace></dest_trace></src_trace>
:TRACe[:DATA] TRACE1   TRACE2   TRACE3   TRACE4   TRACE5   TRACE6, <definite_length_block>   <comma_separated_ascii_data></comma_separated_ascii_data></definite_length_block>
:TRACe:MODE WRITe MAXHold MINHold VIEW BLANk
:TRIGger[:SEQuence]:DELay <numeric></numeric>
:TRIGger[:SEQuence]:DELay:STATe OFF ON 0 1
:TRIGger[:SEQuence]:EXTermal:DELay <numeric></numeric>
:TRIGger[:SEQuence]:EXTermal:LEVel <numeric></numeric>

:TRIGger[:SEQuence]:EXTermal:SLOPe POSitive NEGative
:TRIGger[:SEQuence]:HOLDoff <numeric></numeric>
:TRIGger[:SEQuence]:IF:DELay <numeric></numeric>
:TRIGger[:SEQuence]:IF:LEVel <numeric></numeric>
:TRIGger[:SEQuence]:IF:SLOPe POSitive NEGative
:TRIGger[:SEQuence]:SLOPe POSitive NEGative
:TRIGger[:SEQuence]:SOURce IMMediate VIDeo EXTernal<1 2>
:TRIGger[:SEQuence]:VIDeo:LEVel <numeric></numeric>
:TRIGger[:SEQuence]:VIDeo:LEVel:FREQuency <freq></freq>

## 15.10 Using the Status Register

For more information on the contents of the status registers see:

- "STATus:OPERation Register" on page 338
- "STATus:QUEStionable:ACPLimit Register" on page 340
- "STATus:QUEStionable:EXTended Register" on page 341
- "STATus:QUEStionable:FREQuency Register" on page 342
- "STATus:QUEStionable:LIMit Register" on page 342
- "STATus:QUEStionable:LMARgin Register" on page 343
- "STATus:QUEStionable:POWer Register" on page 344
- "STATus:QUEStionable:TEMPerature Register" on page 345
- "STATus:QUEStionable:TIMe Register" on page 346

•	General Status Register Commands	614
	Reading Out the CONDition Part	
•	Reading Out the EVENt Part	.616
•	Controlling the ENABle Part	.616
	Controlling the Negative Transition Part	
	Controlling the Positive Transition Part	

## 15.10.1 General Status Register Commands

GTATus:PRESet6	15
TATus:QUEue[:NEXT]?6	15

### STATus:PRESet

This command resets the edge detectors and ENABle parts of all registers to a defined value. All PTRansition parts are set to FFFFh, i.e. all transitions from 0 to 1 are detected. All NTRansition parts are set to 0, i.e. a transition from 1 to 0 in a CONDition bit is not detected. The ENABle part of the STATus:OPERation and STATus:QUEStionable registers are set to 0, i.e. all events in these registers are not passed on.

Usage: Event

### STATus:QUEue[:NEXT]?

This command queries the most recent error queue entry and deletes it.

Positive error numbers indicate device-specific errors, negative error numbers are error messages defined by SCPI. If the error queue is empty, the error number 0, "No error", is returned.

This command is identical to the SYSTem: ERRor [:NEXT]? command.

Usage: Query only

### 15.10.2 Reading Out the CONDition Part

For more information on the condition part see Chapter 14.1.7.2, "Structure of a SCPI Status Register", on page 334.

STATus:OPERation:CONDition? STATus:QUEStionable:CONDition? STATus:QUEStionable:ACPLimit:CONDition? <ChannelName> STATus:QUEStionable:EXTended:CONDition? <ChannelName> STATus:QUEStionable:EXTended:INFO:CONDition? <ChannelName> STATus:QUEStionable:FREQuency:CONDition? <ChannelName> STATus:QUEStionable:LIMit<n>:CONDition? <ChannelName> STATus:QUEStionable:LIMit<n>:CONDition? <ChannelName> STATus:QUEStionable:LMARgin<n>:CONDition? <ChannelName> STATus:QUEStionable:PNOise:CONDition? <ChannelName> STATus:QUEStionable:PNOise:CONDition? <ChannelName> STATus:QUEStionable:POWer:CONDition? <ChannelName> STATus:QUEStionable:POWer:DCPNoise:CONDition? <ChannelName> STATus:QUEStionable:TEMPerature:CONDition? <ChannelName> STATus:QUEStionable:TEMPerature:CONDition? <ChannelName>

These commands read out the CONDition section of the status register.

The commands do not delete the contents of the CONDition section.

Suffix: <n>

Window

Query parameters: <channelname></channelname>	String containing the name of the channel. The parameter is optional. If you omit it, the command works for the currently active channel.
Usage:	Query only

## 15.10.3 Reading Out the EVENt Part

For more information on the event part see Chapter 14.1.7.2, "Structure of a SCPI Status Register", on page 334.

```
STATus:OPERation[:EVENt]?
STATus:QUEStionable[:EVENt]?
STATus:QUEStionable:ACPLimit[:EVENt]? <ChannelName>
STATus:QUEStionable:EXTended[:EVENt]? <ChannelName>
STATus:QUEStionable:EXTended:INFO[:EVENt]? <ChannelName>
STATus:QUEStionable:FREQuency[:EVENt]? <ChannelName>
STATus:QUEStionable:LIMit<n>[:EVENt]? <ChannelName>
STATus:QUEStionable:LMARgin<n>[:EVENt]? <ChannelName>
STATus:QUEStionable:PNOise[:EVENt]? <ChannelName>
STATus:QUEStionable:PNOise[:EVENt]? <ChannelName>
STATus:QUEStionable:POWer[:EVENt]? <ChannelName>
STATus:QUEStionable:POWer[:EVENt]? <ChannelName>
STATus:QUEStionable:POWer[:EVENt]? <ChannelName>
STATus:QUEStionable:POWer:DCPNoise[:EVENt]? <ChannelName>
STATus:QUEStionable:TEMPerature[:EVENt]? <ChannelName>
```

These commands read out the EVENt section of the status register.

At the same time, the commands delete the contents of the EVENt section.

<pre>suffix: <n></n></pre>	Window
Query parameters: <channelname></channelname>	String containing the name of the channel. The parameter is optional. If you omit it, the command works for the currently active channel.
Usage:	Query only

### 15.10.4 Controlling the ENABle Part

o .....

For more information on the enable part see Chapter 14.1.7.2, "Structure of a SCPI Status Register", on page 334.

STATus:OPERation:ENABle <SumBit> STATus:QUEStionable:ENABle <SumBit> STATus:QUEStionable:ACPLimit:ENABle <SumBit>,<ChannelName> STATus:QUEStionable:EXTended:ENABle <SumBit>,<ChannelName> STATus:QUEStionable:EXTended:INFO:ENABle <SumBit>,<ChannelName> STATus:QUEStionable:FREQuency:ENABle <SumBit>,<ChannelName> STATus:QUEStionable:LIMit<n>:ENABle <SumBit>,<ChannelName> STATus:QUEStionable:LMARgin<n>:ENABle <SumBit>,<ChannelName> STATus:QUEStionable:PNOise:ENABle <SumBit>,<ChannelName> STATus:QUEStionable:POWer:ENABle <SumBit>,<ChannelName> STATus:QUEStionable:POWer:DCPNoise:ENABle <SumBit>,<ChannelName> STATus:QUEStionable:TEMPerature:ENABle <SumBit>,<ChannelName> STATus:QUEStionable:TEMPerature:ENABle <SumBit>,<ChannelName> STATus:QUEStionable:TEMPerature:ENABle <SumBit>,<ChannelName>

These commands control the ENABle part of a register.

The ENABle part allows true conditions in the EVENt part of the status register to bereported in the summary bit. If a bit is 1 in the enable register and its associated event bit transitions to true, a positive transition will occur in the summary bit reported to the next higher level.

### Suffix:

<n></n>	Window
<b>Parameters:</b> <sumbit></sumbit>	Range: 0 to 65535
<channelname></channelname>	String containing the name of the channel. The parameter is optional. If you omit it, the command works for the currently active channel.

### 15.10.5 Controlling the Negative Transition Part

For more information on the positive transition part see Chapter 14.1.7.2, "Structure of a SCPI Status Register", on page 334.

STATus:OPERation:NTRansition <SumBit> STATus:QUEStionable:NTRansition <SumBit> STATus:QUEStionable:ACPLimit:NTRansition <SumBit>,<ChannelName> STATus:QUEStionable:EXTended:NTRansition <SumBit>,<ChannelName> STATus:QUEStionable:FREQuency:NTRansition <SumBit>,<ChannelName> STATus:QUEStionable:IMit<n>:NTRansition <SumBit>,<ChannelName> STATus:QUEStionable:LIMit<n>:NTRansition <SumBit>,<ChannelName> STATus:QUEStionable:LIMit<n>:NTRansition <SumBit>,<ChannelName> STATus:QUEStionable:LIMit<n>:NTRansition <SumBit>,<ChannelName> STATus:QUEStionable:PNOise:NTRansition <SumBit>,<ChannelName> STATus:QUEStionable:POWer:NTRansition <SumBit>,<ChannelName> STATus:QUEStionable:POWer:NTRansition <SumBit>,<ChannelName> STATus:QUEStionable:POWer:DCPNoise:NTRansition <SumBit>,<ChannelName> STATus:QUEStionable:TEMPerature:NTRansition <SumBit>,<ChannelName> STATus:QUEStionable:TEMPerature:NTRansition <SumBit>,<ChannelName>

These commands control the Negative TRansition part of a register.

Setting a bit causes a 1 to 0 transition in the corresponding bit of the associated register. The transition also writes a 1 into the associated bit of the corresponding EVENt register.

#### Suffix:

<n>

Window

<b>Parameters:</b> <sumbit></sumbit>	Range: 0 to 65535
<channelname></channelname>	String containing the name of the channel. The parameter is optional. If you omit it, the command works for the currently active channel.

## 15.10.6 Controlling the Positive Transition Part

For more information on the negative transition part see Chapter 14.1.7.2, "Structure of a SCPI Status Register", on page 334.

STATus:OPERation:PTRansition <SumBit>

STATus:QUEStionable:PTRansition <SumBit> STATus:QUEStionable:ACPLimit:PTRansition <SumBit>,<ChannelName> STATus:QUEStionable:EXTended:PTRansition <SumBit>,<ChannelName> STATus:QUEStionable:EXTended:INFO:PTRansition <SumBit>,<ChannelName> STATus:QUEStionable:FREQuency:PTRansition <SumBit>,<ChannelName> STATus:QUEStionable:LIMit<n>:PTRansition <SumBit>,<ChannelName> STATus:QUEStionable:LMARgin<n>:PTRansition <SumBit>,<ChannelName> STATus:QUEStionable:PNOise:PTRansition <SumBit>,<ChannelName> STATus:QUEStionable:PNOise:PTRansition <SumBit>,<ChannelName> STATus:QUEStionable:POWer:PTRansition <SumBit>,<ChannelName> STATus:QUEStionable:POWer:PTRansition <SumBit>,<ChannelName> STATus:QUEStionable:POWer:DCPNoise:PTRansition <SumBit>,<ChannelName> STATus:QUEStionable:TEMPerature:PTRansition <SumBit>,<ChannelName> STATus:QUEStionable:TEMPerature:PTRansition <SumBit>,<ChannelName>

These commands control the Positive TRansition part of a register.

Setting a bit causes a 0 to 1 transition in the corresponding bit of the associated register. The transition also writes a 1 into the associated bit of the corresponding EVENt register.

### Suffix:

<n></n>	Window
<b>Parameters:</b> <sumbit></sumbit>	Range: 0 to 65535
<channelname></channelname>	String containing the name of the channel. The parameter is optional. If you omit it, the command works for the currently active channel.

## **15.11 Programming Examples**

Some advanced programming examples for complex measurement tasks are provided here.

Service Request......619

## **15.11.1 Service Request**

The service request routine requires an extended initialization of the instrument in which the relevant bits of the transition and enable registers are set. In addition the service request event must be enabled in the VISA session.

### 15.11.1.1 Initiate Service Request

```
REM ---- Example of initialization of the SRQ in the case
' of errors -----
PUBLIC SUB SetupSRQ()
CALL InstrWrite (analyzer, "*CLS") 'Reset status reporting system
CALL InstrWrite (analyzer, "*SRE 168") 'Enable service request for
'STAT:OPER, STAT:QUES and ESR
'register
CALL InstrWrite (analyzer, "*ESE 60") 'Set event enable bit for
'command, execution, device-
'dependent and query error
CALL InstrWrite (analyzer, "STAT:OPER:ENAB 32767")
'Set OPERation enable bit for
'all events
CALL InstrWrite (analyzer, "STAT:OPER:PTR 32767")
'Set appropriate OPERation
'Ptransition bits
CALL InstrWrite (analyzer, "STAT:QUES:ENAB 32767")
'Set questionable enable bits
'for all events
CALL InstrWrite (analyzer, "STAT:QUES:PTR 32767")
'Set appropriate questionable
'Ptransition bits
CALL viEnableEvent(analyzer, VI_EVENT_SERVICE_REQ, VI_QUEUE, 0)
'Enable the event for service
'request
Status = viWaitOnEvent(analyzer, VI EVENT SERVICE REQ, SRQWaitTimeout, VI NULL,
VI NULL)
IF (status = VI SUCCESS) THEN CALL Srq
'If SRQ is recognized =>
'subroutine for evaluation
END SUB
Private mbSession As MessageBasedSession
Sub Main()
   Console.WriteLine("Example of initialization
              of the SRQ in the case of errors.")
   Dim SRQWaitTimeout = 4000 ' Timeout As Integer for WaitOnEvent
    'Opening session
   Trv
       'Analyzer is alias, instead of using resource string.
```

### **Programming Examples**

```
'For example on TCP use TCPIP0::192.168.1.2::inst0::INSTR
   mbSession = CType(ResourceManager.GetLocalManager().Open("Analyzer"),
                                MessageBasedSession)
   mbSession.TerminationCharacterEnabled = True
   Try
       mbSession.Write("*CLS") 'Reset status reporting system
       mbSession.Write("*SRE 168") 'Enable service request for
       'STAT:OPER, STAT:OUES and ESR register
       mbSession.Write("*ESE 60") 'Set event enable bit for
       'command, execution, device-dependent and query error
       mbSession.Write("STAT:OPER:ENAB 32767")
       'Set OPERation enable bit for all events
       mbSession.Write("STAT:OPER:PTR 32767")
       'Set appropriate OPERation Ptransition bits
       mbSession.Write("STAT:QUES:ENAB 32767")
       'Set questionable enable bits for all events
       mbSession.Write("STAT:QUES:PTR 32767")
       'Set appropriate questionable Ptransition bits
       Console.WriteLine("Wait on event - Blocking")
       mbSession.EnableEvent(MessageBasedSessionEventType.ServiceRequest,
                                         EventMechanism.Queue)
       'Enable the event for service request
        ۱_____
        ' Your command plase use here
        ' mbSession.Write("Your command")
        ۱_____
       Dim Status = mbSession.WaitOnEvent(
                          MessageBasedSessionEventType.ServiceRequest, SRQWaitTimeout)
       If (Status.EventType() = _
                          MessageBasedSessionEventType.ServiceRequest) Then
           Console.WriteLine("SRQ is recognized")
           'If SRQ is recognized => subroutine for evaluation
           Srq()
       End If
   Catch exp As Exception
       Console.WriteLine(exp.Message)
   End Try
Catch exp As InvalidCastException
   Console.WriteLine("Resource selected must be a message-based session")
Catch exp As Exception
   Console.WriteLine(exp.Message)
End Try
' Close session
mbSession.Dispose()
' Wait for end
Console.WriteLine("Press any key to end")
```

```
Console.ReadKey()
End Sub
```

### 15.11.1.2 Waiting for the Arrival of a Service Request

There are basically two methods of waiting for the arrival of a service request:

### Blocking (user inputs not possible):

This method is appropriate if the waiting time until the event to be signaled by an SRQ is short (shorter than the selected timeout), if no response to user inputs is required during the waiting time, and if – as the main criterion – the event is absolutely certain to occur.

Reason:

From the time the viWaitOnEvent() function is called until the occurrence of the expected event, it does not allow the program to respond to mouse clicks or key entries during the waiting time. Moreover, it returns an error if the SRQ event does not occur within the predefined timeout period.

The method is, therefore, in many cases not suitable for waiting for measurement results, especially when using triggered measurements.

The following function calls are required:

```
Status = viWaitOnEvent(analyzer, VI EVENT SERVICE REQ, SRQWaitTimeout, VI NULL,
VI NULL)
'Wait for service request user
'inputs are not possible during
'the waiting time!
IF (status = VI SUCCESS) THEN CALL Srq
'If SRQ is recognized =>
'subroutine for evaluation
'----- Sweep in first Spectrum Tab and query marker -----
MessageBasedSessionEventType.ServiceRequest, SRQWaitTimeout)
'Wait for service request user inputs are not possible
'during the waiting time!
If (Status.EventType() = MessageBasedSessionEventType.ServiceRequest) Then
'If SRQ is recognized => subroutine for evaluation
   Srq()
```

End If

### Non-blocking (user inputs possible):

This method is recommended if the waiting time until the event to be signaled by an SRQ is long (longer than the selected timeout), and user inputs should be possible during the waiting time, or if the event is not certain to occur. This method is, therefore, the preferable choice for waiting for the end of measurements, i.e. the output of results, especially in the case of triggered measurements.

The method necessitates a waiting loop that checks the status of the SRQ line at regular intervals and returns control to the operating system during the time the expected event has not yet occurred. In this way, the system can respond to user inputs (mouse clicks, key entries) during the waiting time.

It is advisable to employ the Hold() auxiliary function, which returns control to the operating system for a selectable waiting time (see section Waiting Without Blocking the Keyboard and Mouse), so enabling user inputs during the waiting time.

```
result = 0
For i = 1 To 10 'Abort after max. 10 loop
'iterations
Status = viWaitOnEvent(analyzer, VI_EVENT_SERVICE_REQ, VI_TMO_IMMEDIATE, VI_NULL,
VI NULL)
'Check event queue
If (status = VI SUCCESS) Then
result = 1
CALL Srg 'If SRQ is recognized =>
'subroutine for evaluation
Else
CALL Hold(20) 'Call hold function with
'20 ms 'waiting time. User inputs
'are possible.
Endif
Next i
If result \approx 0 Then
Debug.Print "Timeout Error; Program aborted"'Output error message
STOP 'Stop software
Endif
```

### 15.11.1.3 Waiting Without Blocking the Keyboard and Mouse

A frequent problem with remote control programs using Visual Basic is to insert waiting times without blocking the keyboard and the mouse.

If the program is to respond to user inputs also during a waiting time, control over the program events during this time must be returned to the operating system. In Visual Basic, this is done by calling the DoEvents function. This function causes keyboard-or mouse-triggered events to be executed by the associated elements. For example, it allows the operation of buttons and input fields while the user waits for an instrument setting to be completed.

The following programming example describes the Hold() function, which returns control to the operating system for the period of the waiting time selectable in milliseconds.

The waiting procedure is activated simply by calling Hold (<Waiting time in milliseconds>).

### 15.11.1.4 Service Request Routine

A service request is processed in the service request routine.



The variables userN% and userM% must be pre-assigned usefully!

```
REM ----- Service request routine -----
Public SUB Srq()
ON ERROR GOTO noDevice 'No user existing
CALL viReadSTB(analyzer, STB%) 'Serial poll, read status byte
IF STB% > 0 THEN 'This instrument has bits set in
'the STB
SRQFOUND\% = 1
IF (STB% AND 16) > 0 THEN CALL Outputqueue
IF (STB% AND 4) > 0 THEN CALL ErrorQueueHandler
IF (STB% AND 8) > 0 THEN CALL Questionablestatus
IF (STB% AND 128) > 0 THEN CALL Operationstatus
IF (STB% AND 32) > 0 THEN CALL Esrread
END IF
noDevice:
END SUB 'End of SRO routine
REM ------ Subroutine for evaluation Service Request Routine ------
Public Sub Srq()
   Try
       Dim mySTB As Short = mbSession.ReadStatusByte()
                            'Serial poll, read status byte
       Console.WriteLine("Reading Service Request Routine:" + mySTB.ToString())
       If mySTB > 0 Then 'This instrument has bits set in the STB
          If (mySTB And 16) > 0 Then Call Outputqueue()
          If (mySTB And 4) > 0 Then Call ErrorQueueHandler()
```

```
If (mySTB And 8) > 0 Then Call Questionablestatus()
If (mySTB And 128) > 0 Then Call Operationstatus()
If (mySTB And 32) > 0 Then Call Esrread()
End If
Catch exp As Exception
Console.WriteLine(exp.Message)
End Try
End Sub 'End of SRQ routine
```

Reading out the status event registers, the output buffer and the error/event queue is effected in subroutines.

### 15.11.1.5 Reading Out the Output Buffer

```
REM ------ Subroutine for the individual STB bits ------
Public SUB Outputqueue() 'Reading the output buffer
result$ = SPACE$(100) 'Make space for response
CALL InstrRead(analyzer, result$)
Debug.Print "Contents of Output Queue:"; result$
END SUB
REM ------ Subroutine for the output queue -----
Public Sub Outputqueue() 'Reading the output buffer
  Try
      Dim result As String = mbSession.ReadString()
      Console.WriteLine("Contents of Output Queue:" + result)
   Catch exp As Exception
      Console.WriteLine(exp.Message)
   End Try
End Sub
```

### 15.11.1.6 Reading Error Messages

### 15.11.1.7 Evaluation of SCPI Status Registers

```
REM ----- Subroutine for evaluating Questionable Status Register ------
Public SUB Questionablestatus()
Ques = SPACE$ (20)
'Preallocate blanks to text
'variable
CALL InstrWrite (analyzer, "STATus:QUEStionable:EVENt?")
CALL InstrRead(analyzer, Ques$)
Debug.Print "Questionable Status:"; Ques$
END SUB
REM ----- Subroutine for evaluating Operation Status Register ------
Public SUB Operationstatus()
Oper$ = SPACE$(20) 'Preallocate blanks to text
'variable
CALL InstrWrite (analyzer, "STATus:OPERation:EVENt?")
CALL InstrRead(analyzer, Oper$)
Debug.Print "Operation Status:"; Oper$
END SUB
REM ----- Subroutine for evaluating Questionable Status Register ------
Public Sub Questionablestatus()
   Dim myQSR As String = Nothing
   Trv
      myQSR = mbSession.Query("STATus:QUEStionable:EVENt?") 'Read QSR
      Console.WriteLine("Questionable Status:" + myQSR)
   Catch exp As Exception
      Console.WriteLine(exp.Message)
   End Try
End Sub
REM ----- Subroutine for evaluating Operation Status Register ------
Public Sub Operationstatus()
   Dim myOSR As String = Nothing
   Try
       myOSR = mbSession.Query("STATus:OPERation:EVENt?") 'Read OSR
       Console.WriteLine("Operation Status:" + myOSR)
   Catch exp As Exception
```

```
Console.WriteLine(exp.Message)
End Try
End Sub
```

### 15.11.1.8 Evaluation of Event Status Register

```
REM ----- Subroutine for evaluating the Event Status Register ------
Public SUB Esrread()
Esr$ = SPACE$(20) 'Preallocate blanks to text
'variable
CALL InstrWrite (analyzer, "*ESR?") 'Read ESR
CALL InstrRead(analyzer, Esr$)
IF (VAL(Esr$) AND 1) > 0 THEN Debug.Print "Operation complete"
IF (VAL(Esr$) AND 2) > 0 THEN Debug.Print "Request Control"
IF (VAL(Esr$) AND 4) > 0
THEN Debug.Print "Query Error"
IF (VAL(Esr$) AND 8) > 0
THEN Debug.Print "Device dependent error"
IF (VAL(Esr$) AND 16) > 0
THEN Debug.Print "Execution Error; Program aborted" 'Output error message
STOP 'Stop software
END IF
IF (VAL(Esr$) AND 32) > 0
THEN Debug.Print "Command Error; Program aborted" 'Output error message
STOP 'Stop software
END IF
IF (VAL(Esr$) AND 64) > 0 THEN Debug.Print "User request"
IF (VAL(Esr$) AND 128) > 0 THEN Debug.Print "Power on"END SUB
REM ----- Subroutine for evaluating the Event Status Register -------
Public Sub Esrread()
   Try
       Dim myESR As Short = mbSession.Query("*ESR?") 'Read ESR
       If (myESR And 1) > 0 Then Console.WriteLine("Operation complete")
       If (myESR And 2) > 0 Then Console.WriteLine("Request Control")
       If (myESR And 4) > 0 Then Console.WriteLine("Query Error")
       If (myESR And 8) > 0 Then Console.WriteLine("Device dependent error")
       If (myESR And 16) > 0 Then
           Console.WriteLine("Execution Error; Program aborted") 'Output error message
           Stop 'Stop software
       End If
       If (myESR And 32) > 0 Then
           Console.WriteLine("Command Error; Program aborted") 'Output error message
           Stop 'Stop software
       End If
       If (myESR And 64) > 0 Then Console.WriteLine("User request")
       If (myESR And 128) > 0 Then Console.WriteLine("Power on")
    Catch exp As Exception
       Console.WriteLine(exp.Message)
```

Programming Examples

End Try End Sub

# 16 Maintenance

The R&S FSWP does not require regular maintenance. Maintenance is essentially restricted to cleaning the R&S FSWP. It is, however, recommended that you check the nominal data from time to time.

The data sheet specifies the storage temperature range for the R&S FSWP. Protect the instrument against dust if it is to be stored for a long period.

# 16.1 Cleaning

## **WARNING**

### **Risk of electric shock**

If moisture enters the casing, for example if you clean the instrument using a moist cloth, contact with the instrument can lead to electric shock. Before cleaning the instrument other than with a dry cloth, make sure that the instrument is switched off and disconnected from all power supplies.

## NOTICE

### Instrument damage caused by cleaning agents

Cleaning agents contain substances such as solvents (thinners, acetone, etc.), acids, bases, or other substances. Solvents can damage the front panel labeling, plastic parts, or screens, for example.

Never use cleaning agents to clean the outside of the instrument. Use a soft, dry, lintfree dust cloth instead.

# NOTICE

### Risk of instrument damage due to obstructed fans

If the instrument is operated in dusty areas, the fans become obstructed by dust or other particles over time. Check and clean the fans regularly to ensure that they always operate properly. If the instrument is run with obstructed fans for a longer period, the instrument overheats, which can disturb the operation and even cause damage.

- 1. Clean the outside of the instrument using a soft, dry, lint-free dust cloth.
- 2. Check and clean the fans regularly to ensure that they always operate properly.
- 3. Clean the touchscreen as follows:
  - a) Apply a small amount of standard screen cleaner to a soft cloth.
  - b) Wipe the screen gently with the moist, but not wet, cloth.

c) If necessary, remove any excess moisture with a dry, soft cloth.

# 17 Troubleshooting

If the results do not meet your expectations, the following sections may contain helpful hints and information.

•	Error Information	630
	Error Messages in Remote Control Mode	
	Troubleshooting Remote Operation	
	Miscellaneous Troubleshooting Hints	
	System Recovery	
•	Collecting Information for Support	635
•	Contacting Customer Support	637

# **17.1 Error Information**

If errors or irregularities are detected, a keyword and an error message, if available, are displayed in the status bar.

Depending on the type of message, the status message is indicated in varying colors.

Color	Туре	Description
Red	Error	An error occurred at the start or during a measurement, e.g. due to missing data or wrong settings, so that the measurement cannot be started or completed correctly.
Orange	Warning	An irregular situation occurred during measurement, e.g. the settings no lon- ger match the displayed results, or the connection to an external device was interrupted temporarily.
Gray	Information	Information on the status of individual processing steps.
No color	No errors	No message displayed - normal operation.
Green	Measurement successful	Some applications visualize that the measurement was successful by show- ing a message.

Table 17-1: Status bar information - color coding

If any error information is available for a channel, an exclamation mark is displayed next to the channel name (I). This is particularly useful when the MultiView tab is displayed, as the status bar in the MultiView tab always displays the information for the currently selected measurement only.

Furthermore, a status bit is set in the STATUS:QUEStionable:EXTended:INFO register for the application concerned. Messages of a specific type can be queried using the SYSTem:ERRor:EXTended? command. For more information, see the R&S FSWP User Manual.

### Error Messages in Remote Control Mode

"INPUT OVLD"	The signal level at the RF input connector exceeds the maximum.
	The RF input is disconnected from the input mixer to protect the device. To re-enable measurement, decrease the level at the RF input connector and reconnect the RF input to the mixer input.
"RF OVLD"	<ul> <li>Overload of the input mixer or of the analog IF path.</li> <li>Increase the RF attenuation (for RF input).</li> <li>Reduce the input level (for digital input)</li> </ul>
"LO UNL"	Error in the instrument's frequency processing hardware was detected.
"NO REF"	Instrument was set to an external reference but no signal was detected on the reference input.
"OVENCOLD"	The optional OCXO reference frequency has not yet reached its operating tempera- ture. The message usually disappears a few minutes after power has been switched on.
"UNCAL"	<ul> <li>One of the following conditions applies:</li> <li>Correction data has been switched off.</li> <li>No correction values are available, for example after a firmware update.</li> <li>Record the correction data by performing a self alignment</li> </ul>
"OLD CAL"	Calibration data outdated. Perform a new self-alignment. Also displayed if Reuse Old Alignment Data is enabled.
"WRONG_FW"	The firmware version is out-of-date and does not support the currently installed hard- ware. Until the firmware version is updated, this error message is displayed and self- alignment fails.

### Table 17-2: List of keywords

## 17.2 Error Messages in Remote Control Mode

In remote control mode error messages are entered in the error/event queue of the status reporting system and can be queried with the command SYSTem:ERRor?. The answer format of R&S FSWP to the command is as follows:

```
<error code>, "<error text with queue query>; <remote control
command concerned>"
```

The indication of the remote control command with prefixed semicolon is optional.

### Example:

The command TEST: COMMAND generates the following answer to the query SYSTem: ERRor?

-113, "Undefined header; TEST: COMMAND"

There are two types of error messages:

- Error messages defined by SCPI are marked by negative error codes. These messages are defined and described in the SCPI standard and not listed here.
- Device-specific error messages use positive error codes. These messages are described below.

Error code	Error text in the case of queue poll Error explanation
1052	Frontend LO is Unlocked
	This message is displayed when the phase regulation of the local oscillator fails in the RF front-end.
1060	Trigger-Block Gate Delay Error- gate length < Gate Delay
	This message is displayed when the gate signal length is not sufficient for the pull-in delay with a predefined gate delay.
1064	Tracking LO is Unlocked
	This message is displayed when the phase regulation of the local oscillator fails on the external generator module.
2028	Hardcopy not possible during measurement sequence
	<ul> <li>This message is displayed when a printout is started during scan sequences that cannot be interrupted. Such sequences are for example:</li> <li>Recording the system error correction data (alignment)</li> <li>Instrument self-test</li> </ul>
	In such cases synchronization to the end of the scan sequence should be performed prior to starting the printout.
2033	Printer Not Available
	This message is displayed when the selected printer is not included in the list of available output devices. A possible cause is that the required printer driver is missing or incorrectly installed.
2034	CPU Temperature is too high
	This message is displayed when the temperature of the processor exceeds 70 $^\circ\text{C}.$

### Table 17-3: Device-specific error messages

#### Table 17-4: Power Sensor errors

Status bar message	Description
Zeroing could not be per- formed	Zeroing could not be performed because the RF power applied is too high.
Power sensor zero failed	

## 17.3 Troubleshooting Remote Operation

If problems arise during measurement in remote operation, try the following methods to solve them.

### Incompleted sequential commands - blocked remote channels

If a sequential command cannot be completed, for example because a triggered sweep never receives a trigger, the remote control program will never finish and the remote channel to the R&S FSWP is blocked for further commands. In this case, you must interrupt processing on the remote channel in order to abort the measurement.

### To regain control over a blocked remote channel

Usually, if you wait a minute for the VISA connection to detect the lost connection and clear the control channel by itself, you can then re-establish the connection again. If this fails, try the following:

- Press "Local" on the front panel of the R&S FSWP to return to manual operation (if not disabled). Then re-establish the connection.
- Send a "Device Clear" command from the control instrument to the R&S FSWP to clear all currently active remote channels. Depending on the used interface and protocol, send the following commands:
  - Visa: viClear()
  - **GPIB**: ibclr()
  - **RSIB**: RSDLLibclr()

The remote channel currently processing the incompleted command is then ready to receive further commands again.

- 3. On the remote channel performing the measurement, send the SCPI command ABORt to abort the current measurement and reset the trigger system.
- If the R&S FSWP still does not react to the remote commands, switch it off and back on.

### Ignored commands

When a remote command attempts to define incompatible settings, the command is ignored and the instrument status remains unchanged, i.e. other settings are not automatically adapted. Therefore, control programs should always define an initial instrument status (e.g. using the \*RST command) and then implement the required settings.

#### Detecting false commands - log file

If a remote program does not provide the expected results and you are using a GPIB connection, you can log the commands and any errors that may occur. To activate the SCPI error log function, in the "Network + Remote" dialog box, in the "GPIB" tab, select "I/O Logging".

All remote control commands received by the R&S FSWP are recorded in log files with the following syntax:

```
C:\Program Files
(x86)\Rohde-Schwarz\FSWP\<version>\ScpiLogging\ScpiLog.<xx>
```

where <xx> is a consecutive number, starting with 00;

A new file is created each time you stop and restart the logging function. The lowest available number is used for the <xx> extension.

Logging the commands may be extremely useful for debug purposes, e.g. in order to find misspelled keywords in control programs. However, remember to turn off the logging function after debugging to avoid unnecessary access to the hard drive and use of storage space.

## **17.4 Miscellaneous Troubleshooting Hints**

Power levels for low frequency signals not correct	634
Invalid trace display	
Data capturing takes too long	
Multiple user access to one instrument	
Web browser access to instrument fails	

### Power levels for low frequency signals not correct

By default, the R&S FSWP uses AC coupling for RF input. For very low frequencies, the input signal may be distorted with this setting. In this case, use DC coupling instead. To change the setting, select "INPUT/OUPUT" > "Input Source Config > Radio Frequency > Input Coupling > DC".

### Invalid trace display

If output to the "IF 2 GHz OUT" connector is activated, the measured values are no longer sent to the display; thus, the trace data currently displayed on the R&S FSWP becomes invalid. A message in the status bar indicates this situation.

# Data capturing takes too long Spectrum application only.

Particularly for FFT sweeps, the time required to process the data may be considerably longer than the time required to capture the data. Thus, if you only consider the defined sweep time, you may assume an error has occurred if the measurement takes longer than expected.

However, while the sweep time only defines the time in which data is actually captured, the total sweep *duration* includes the time required for capturing *and processing* the data. Thus, for FFT sweeps in the Spectrum application, the sweep duration is now also indicated in the channel bar, behind the sweep time. In remote operation, the estimated sweep duration can be queried for all sweep modes (also zero span and frequency sweeps).

**Tip:** To determine the necessary timeout for data capturing in a remote control program, double the estimated time and add 1 second.

Remote command: [SENSe:]SWEep:DURation

### Multiple user access to one instrument

Using the R&S FSWP's web browser interface, several users can access *and operate* the same instrument simultaneously. This is useful for troubleshooting or training purposes.

Type the instrument's host name or IP address in the address field of the browser on your PC, for example "http://10.113.10.203". The instrument home page (welcome page) opens.

**Note:** This function can be deactivated for the instrument. After a firmware update, it is automatically activated again.

### Web browser access to instrument fails

If an error message ("Failed to connect to server (code. 1006)") is displayed in the web browser instead of the instrument's user interface then the LAN web browser interface was probably deactivated.

## 17.5 System Recovery

**For instruments running Windows 10**, the system drive is delivered with a recovery partition that allows you to restore the original operating system image and firmware.

### To restore the original operating system image and firmware

- 1. Open the Windows control panel.
- 2. Select "Update & Security" > "Recovery" > "Restart Now".

The "R&S Recovery Environment" starts.

3. In the "R&S Recovery Environment", select "Factory Default Restore".

The default image is restored.

4. Reboot the instrument.

After the default image is restored, upgrade to the desired firmware version (see Chapter 13.4.4, "Firmware Updates", on page 299).

## 17.6 Collecting Information for Support

If problems occur, the instrument generates error messages which in most cases will be sufficient for you to detect the cause of an error and find a remedy.

In addition, our customer support centers are there to assist you in solving any problems that you may encounter with your R&S FSWP. We will find solutions more quickly and efficiently if you provide us with the information listed below.

Windows Event Log Files

Windows records important actions of applications and the operating system in event logs. You can create event log files to summarize and save the existing event logs (see "To create Windows event log files" on page 636).

- System Configuration: The "System Configuration" dialog box (in the "Setup" menu) provides information on:
  - Hardware Info: hardware assemblies
  - Versions and Options: the status of all software and hardware options installed on your instrument
  - System Messages: messages on any errors that may have occurred

An .xml file with information on the system configuration ("Device Footprint") can be created automatically (using the DIAGnostic:SERVice:SINFo command or as described in "To collect the support information" on page 636).

• Error Log: The RSError.log file (in the

C:\Program Files (x86)\Rohde-Schwarz\FSWP\<version>\log directory) contains a chronological record of errors.

 Support file: a \*.zip file with important support information can be created automatically (in the

C:\Program Files (x86)\Rohde-Schwarz\FSWP\<version>\user directory). The \*.zip file contains the system configuration information ( "Device Footprint" ), the current eeprom data and a screenshot of the screen display.

See also the R&S FSWP User Manual, chapter "Service Functions".

### To collect the support information

- 1. Press the [Setup] key.
- 2. Select "Service" > "R&S Support" and then "Create R&S Support Information" .

```
The file is stored as
C:\Program Files (x86)\Rohde-Schwarz\FSWP\<version>\user\
<inst_model>_<serial-no>_<date_and_time>.zip
The file is stored as
C:\Program Files (x86)\Rohde-Schwarz\FSWP\<version>\user\
FSWP_*.zip.
```

### To create Windows event log files

- 1. Select the "Windows Start Button" in the bottom left corner.
- 2. Enter Event Viewer and select "Enter".
- 3. Select and expand "Windows Logs" in the "Console Tree".
- Right-click on each subsection and select "Save All Events As...".

🛃 Event Viewer	
File Action Vi	ew Help
< 🔶 🗖 🛛	
<ul> <li>Event Viewer (L</li> <li>Custom Vie</li> <li>Custom Vie</li> <li>Custom Vie</li> </ul>	ogs Overview
😭 Applica 😭 Security	Overview
Setur € Syste Forw ▲ Applicati	Open Saved Log e Create Custom View r Import Custom View
🛃 Subscrip	Clear Log Filter Current Log Properties
	Find
	Save All Events As
	Attach a Task To this Log
	Help > -

Figure 17-1: Event Viewer

5. Enter a file name and select "Save"

Collect the error information and attach it to an email in which you describe the problem. Send the email to the customer support address for your region as listed in Chapter 17.7, "Contacting Customer Support", on page 637.



### Packing and transporting the instrument

If the instrument needs to be transported or shipped, observe the notes described in Chapter 4.1.1, "Unpacking and Checking the Instrument", on page 21.

## 17.7 Contacting Customer Support

### Technical support - where and when you need it

For quick, expert help with any Rohde & Schwarz product, contact our customer support center. A team of highly qualified engineers provides support and works with you to find a solution to your query on any aspect of the operation, programming or applications of Rohde & Schwarz products.

### **Contact information**

Contact our customer support center at www.rohde-schwarz.com/support, or follow this QR code:

Contacting Customer Support



Figure 17-2: QR code to the Rohde & Schwarz support page

# List of commands

[SENSe:]ADJust:CONFigure:FREQuency:AUTosearch[:STATe]	
[SENSe:]ADJust:CONFigure:FREQuency:COUNt	
[SENSe:]ADJust:CONFigure:FREQuency:LIMit:HIGH	450
[SENSe:]ADJust:CONFigure:FREQuency:LIMit:LOW	450
[SENSe:]ADJust:CONFigure:LEVel:THReshold	
[SENSe:]AVERage <n>:COUNt</n>	
[SENSe:]BWIDth:MEASurement?	408
[SENSe:]BWIDth:VIDeo	
[SENSe:]BWIDth:VIDeo:AUTO	
[SENSe:]CORRection:CVL:BAND	
[SENSe:]CORRection:CVL:BIAS	
[SENSe:]CORRection:CVL:CATalog?	
[SENSe:]CORRection:CVL:CLEar	
[SENSe:]CORRection:CVL:COMMent	
[SENSe:]CORRection:CVL:DATA	
[SENSe:]CORRection:CVL:HARMonic	
[SENSe:]CORRection:CVL:MIXer	
[SENSe:]CORRection:CVL:PORTs	
[SENSe:]CORRection:CVL:SELect	427
[SENSe:]CORRection:CVL:SNUMber	
[SENSe:]CORRection:WEIGhting:COMMent	
[SENSe:]CORRection:WEIGhting:DATA	
[SENSe:]CORRection:WEIGhting:DELete	464
[SENSe:]CORRection:WEIGhting:NAME	
[SENSe:]CORRection:WEIGhting:SELect	
[SENSe:]FILTer:LPASs:FREQuency:MANual	
[SENSe:]FILTer:LPASs[:STATe]	
[SENSe:]FREQuency:CENTer	
[SENSe:]FREQuency:CENTer:STEP	
[SENSe:]FREQuency:CENTer:STEP:LINK	
[SENSe:]FREQuency:CENTer:STEP:LINK:FACTor	
[SENSe:]FREQuency:SPAN	
[SENSe:]FREQuency:STARt	
[SENSe:]FREQuency:STOP	
[SENSe:]LIST:BWIDth[:RESolution]:RATio	
[SENSe:]LIST:BWIDth[:RESolution]:USMall	
[SENSe:]LIST:RANGe <r>:BWIDth[:RESolution]</r>	
[SENSe:]LIST:RANGe <r>:FREQuency:STARt?</r>	
[SENSe:]LIST:RANGe <r>:FREQuency:STOP?</r>	
[SENSe:]LIST:RANGe <r>:XCOunt</r>	
[SENSe:]MIXer <x>:BIAS:HIGH</x>	
[SENSe:]MIXer <x>:BIAS[:LOW]</x>	
[SENSe:]MIXer <x>:FREQuency:HANDover</x>	
[SENSe:]MIXer <x>:FREQuency:STARt</x>	
[SENSe:]MIXer <x>:FREQuency:STOP</x>	
[SENSe:]MIXer <x>:HARMonic:BAND</x>	
[SENSe:]MIXer <x>:HARMonic:BAND:PRESet</x>	418

[SENSe:]MIXer <x>:HARMonic:HIGH:STATe</x>	
[SENSe:]MIXer <x>:HARMonic:HIGH[:VALue]</x>	418
[SENSe:]MIXer <x>:HARMonic:TYPE</x>	419
[SENSe:]MIXer <x>:HARMonic[:LOW]</x>	
[SENSe:]MIXer <x>:LOPower</x>	
[SENSe:]MIXer <x>:LOSS:HIGH</x>	419
[SENSe:]MIXer <x>:LOSS:TABLe:HIGH</x>	
[SENSe:]MIXer <x>:LOSS:TABLe[:LOW]</x>	
[SENSe:]MIXer <x>:LOSS[:LOW]</x>	
[SENSe:]MIXer <x>:PORTs</x>	
[SENSe:]MIXer <x>:RFOVerrange[:STATe]</x>	
[SENSe:]MIXer <x>:XCORr</x>	421
[SENSe:]MIXer <x>[:STATe]</x>	
[SENSe:]POWer:RLEVel:MODE	454
[SENSe:]POWer:RLEVel:OFFSet	448
[SENSe:]POWer:RLEVel?	
[SENSe:]ROSCillator:COUPling:BANDwidth	
[SENSe:]ROSCillator:COUPling:BANDwidth:MODE	
[SENSe:]ROSCillator:COUPling:MODE	
[SENSe:]ROSCillator:LBWidth	
[SENSe:]ROSCillator:0640	
[SENSe:]ROSCillator:OSYNc	
[SENSe:]ROSCillator:SOURce	
[SENSe:]ROSCillator:SOURce:EAUTo?	
[SENSe:]ROSCillator:TRANge	
[SENSe:]SMOothing:APERture	
[SENSe:]SMOothing[:STATe]	
[SENSe:]SPURs:COLor	473
[SENSe:]SPURs:FILTer:CLEar	
[SENSe:]SPURs:FILTer:HARMonics	
[SENSe:]SPURs:FILTer:LOAD	
[SENSe:]SPURs:FILTer:MODE	471
[SENSe:]SPURs:FILTer:NAME?	
[SENSe:]SPURs:FILTer:OFFSet	472
[SENSe:]SPURs:FILTer:RANGe	
[SENSe:]SPURs:FILTer:SAVE	
[SENSe:]SPURs:SORT	
[SENSe:]SPURs:SUPPress	
[SENSe:]SPURs:THReshold	
[SENSe:]SPURs:WEIGhting	
[SENSe:]SWEep:CAPTure:RANGe	
[SENSe:]SWEep:COUNt	
[SENSe:]SWEep:EGATe:HOLDoff	
[SENSe:]SWEep:EGATe:LENGth	
[SENSe:]SWEep:EGATe:LEVel	
[SENSe:]SWEep:EGATe:TYPE	
[SENSe:]SWEep:FORWard	
[SENSe:]SWEep:FSEGment	
[SENSe:]SWEep:MODE	
[SENSe:]SWEep:PULSe:DETection	

[SENSe:]SWEep:PULSe:GATE	
[SENSe:]SWEep:PULSe:PRI	476
[SENSe:]SWEep:TIME	459
[SENSe:]SWEep:XFACtor	
[SENSe:]SWEep:XOPTimize:THReshold	
[SENSe:]SWEep:XOPTimize[:STATe]	
[SENSe:]TIME:STARt	
*CAL?	
*CLS	
*ESE	
*ESR?	
*IDN?	
*IST?	
*OPC	
*OPT?	
*PCB	
*PRE	
*PSC	
*RST	
*SRE	
*STB?	
*TRG	
*TST?	
*WAI	
ABORt	
CALCulate <n>:DELTamarker<m>:AOFF</m></n>	
CALCulate <n>:DELTamarker<m>:LINK</m></n>	
CALCulate <n>:DELTamarker<m>:MAXimum:LEFT</m></n>	
CALCulate <n>:DELTamarker<m>:MAXimum:NEXT</m></n>	
CALCulate <n>:DELTamarker<m>:MAXimum:RIGHt</m></n>	
CALCulate <n>:DELTamarker<m>:MAXimum[:PEAK]</m></n>	
CALCulate <n>:DELTamarker<m>:MINimum:LEFT</m></n>	
CALCulate <n>:DELTamarker<m>:MINimum:NEXT</m></n>	
CALCulate <n>:DELTamarker<m>:MINimum:RIGHt</m></n>	
CALCulate <n>:DELTamarker<m>:MINimum[:PEAK]</m></n>	
CALCulate <n>:DELTamarker<m>:MODE</m></n>	
CALCulate <n>:DELTamarker<m>:MREFerence</m></n>	
CALCulate <n>:DELTamarker<m>:TRACe</m></n>	
CALCulate <n>:DELTamarker<m>:X</m></n>	
CALCulate <n>:DELTamarker<m>:X:RELative?</m></n>	
CALCulate <n>:DELTamarker<m>:Y?</m></n>	
CALCulate <n>:DELTamarker<m>[:STATe]</m></n>	
CALCulate <n>:DELTamarker<ms>:LINK:TO:MARKer<md></md></ms></n>	
CALCulate <n>:FREQuency:DEViation:DIAGram</n>	
CALCulate <n>:FREQuency:DEViation:REGRession:POINts?</n>	
CALCulate <n>:FREQuency:DEViation:REGRession?</n>	
CALCulate <n>:FREQuency:DEViation:SLOPe?</n>	
CALCulate <n>:FREQuency:DEViation:STARt</n>	
CALCulate <n>:FREQuency:DEViation:STATe</n>	
•	

CALCulate <n>:FREQuency:DEViation:STOP</n>	
CALCulate <n>:FREQuency:DEViation:TRACe</n>	
CALCulate <n>:LIMit<k>:COMPatible?</k></n>	
CALCulate <n>:LIMit<li>:ACTive?</li></n>	
CALCulate <n>:LIMit<li>:CLEar[:IMMediate]</li></n>	548
CALCulate <n>:LIMit<li>:COMMent</li></n>	
CALCulate <n>:LIMit<li>:CONTrol:DOMain</li></n>	543
CALCulate <n>:LIMit<li>:CONTrol:MODE</li></n>	
CALCulate <n>:LIMit<li>:CONTrol:SHIFt</li></n>	543
CALCulate <n>:LIMit<li>:CONTrol:SPACing</li></n>	
CALCulate <n>:LIMit<li>:CONTrol[:DATA]</li></n>	542
CALCulate <n>:LIMit<li>:COPY</li></n>	538
CALCulate <n>:LIMit<li>:DELete</li></n>	539
CALCulate <n>:LIMit<li>:FAIL?</li></n>	
CALCulate <n>:LIMit<li>:LOWer:MODE</li></n>	
CALCulate <n>:LIMit<li>:LOWer:OFFSet</li></n>	539
CALCulate <n>:LIMit<li>:LOWer:SHIFt</li></n>	
CALCulate <n>:LIMit<li>:LOWer:SPACing</li></n>	
CALCulate <n>:LIMit<li>:LOWer:STATe</li></n>	
CALCulate <n>:LIMit<li>:LOWer[:DATA]</li></n>	544
CALCulate <n>:LIMit<li>:NAME</li></n>	546
CALCulate <n>:LIMit<li>:STATe</li></n>	540
CALCulate <n>:LIMit<li>:TRACe<t></t></li></n>	540
CALCulate <n>:LIMit<li>:TRACe<t>:CHECk</t></li></n>	541
CALCulate <n>:LIMit<li>:UNIT</li></n>	546
CALCulate <n>:LIMit<li>:UPPer:MODE</li></n>	
CALCulate <n>:LIMit<li>:UPPer:SHIFt</li></n>	
CALCulate <n>:LIMit<li>:UPPer:SPACing</li></n>	
CALCulate <n>:LIMit<li>:UPPer:STATe</li></n>	
CALCulate <n>:LIMit<li>:UPPer[:DATA]</li></n>	
CALCulate <n>:MARKer<m>:AOFF</m></n>	
CALCulate <n>:MARKer<m>:FUNCtion:SPTRacking:RANGe</m></n>	
CALCulate <n>:MARKer<m>:FUNCtion:SPTRacking[:STATe]</m></n>	532
CALCulate <n>:MARKer<m>:LINK</m></n>	
CALCulate <n>:MARKer<m>:MAXimum:LEFT</m></n>	
CALCulate <n>:MARKer<m>:MAXimum:NEXT</m></n>	
CALCulate <n>:MARKer<m>:MAXimum:RIGHt</m></n>	
CALCulate <n>:MARKer<m>:MAXimum[:PEAK]</m></n>	
CALCulate <n>:MARKer<m>:MINimum:LEFT</m></n>	
CALCulate <n>:MARKer<m>:MINimum:NEXT</m></n>	
CALCulate <n>:MARKer<m>:MINimum:RIGHt</m></n>	
CALCulate <n>:MARKer<m>:MINimum[:PEAK]</m></n>	
CALCulate <n>:MARKer<m>:PEXCursion</m></n>	
CALCulate <n>:MARKer<m>:TRACe</m></n>	
CALCulate <n>:MARKer<m>:X</m></n>	
CALCulate <n>:MARKer<m>:Y?</m></n>	
CALCulate <n>:MARKer<m>[:STATe]</m></n>	
CALCulate <n>:MARKer<ms>:LINK:TO:MARKer<md></md></ms></n>	
CALCulate <n>:MATH:STATe</n>	
CALCulate <n>:MATH[:EXPRession][:DEFine]</n>	

CALCulate <n>:SETTling:TIME:DIAGram</n>	
CALCulate <n>:SETTling:TIME:FREQuency:LIMit:LOWer</n>	
CALCulate <n>:SETTling:TIME:FREQuency:LIMit:UPPer</n>	
CALCulate <n>:SETTling:TIME:RESult?</n>	
CALCulate <n>:SETTling:TIME:STATe</n>	
CALCulate <n>:SETTling:TIME:TRACe</n>	
CALCulate <n>:SNOise<s>:AOFF</s></n>	
CALCulate <n>:SNOise<s>:STATe</s></n>	
CALCulate <n>:SNOise<s>:X</s></n>	
CALCulate <n>:SNOise<s>[:TRACe<t>]:DECades:X?</t></s></n>	
CALCulate <n>:SNOise<s>[:TRACe<t>]:DECades:Y?</t></s></n>	
CALCulate <n>:SNOise<s>[:TRACe<t>]:DECades[:STATe]</t></s></n>	
CALCulate <n>:SNOise<s>[:TRACe<t>]:USERdefined[:STATe]</t></s></n>	
CALCulate <n>:SNOise<s>[:TRACe<t>]:Y?</t></s></n>	
CALCulate <n>[:RANGe<j>]:EVALuation:STARt</j></n>	
CALCulate <n>[:RANGe<j>]:EVALuation:STOP</j></n>	
CALCulate <n>[:RANGe<j>]:EVALuation:TRACe</j></n>	
CALCulate <n>[:RANGe<j>]:EVALuation:WEIGhting</j></n>	
CALCulate <n>[:RANGe<j>]:EVALuation[:STATe]</j></n>	
CALibration:RESult?	
CALibration[:ALL]?	
CONFigure:PNOise:MEASurement	
CONFigure:SNTune:MEASurement[:STATe]	
CONFigure:SNTune:SWEep:DELay:INITial	
CONFigure:SNTune:SWEep:DELay[:POINt]	
CONFigure:SNTune:SWEep:POINts	
CONFigure:SNTune:SWEep:SOURce	
CONFigure:SNTune:SWEep:STARt	
CONFigure:SNTune:SWEep:STOP	
CONFigure:TRANsient:MEASurement[:STATe]	
CONFigure:TRANsient:MODE	
CONFigure:TRANsient[:WINDow <n>]:AF:COUPling</n>	
CONFigure:TRANsient[:WINDow <n>]:AF:COUPling:RPOint:MODE</n>	
CONFigure:TRANsient[:WINDow <n>]:AF:COUPling:RPOint[:X]</n>	
CONFigure:VCO:FIX:SOURce	
CONFigure:VCO:MEASurement[:STATe]	
CONFigure:VCO:SWEep:DELay:INITial	
CONFigure:VCO:SWEep:DELay[:POINt]	
CONFigure:VCO:SWEep:FCOunter:RESolution	
CONFigure:VCO:SWEep:POINts	
CONFigure:VCO:SWEep:SOURce	
CONFigure:VCO:SWEep:STARt	
CONFigure:VCO:SWEep:STOP	
DIAGnostic:INFO:CCOunt?	
DIAGnostic:SERVice:BIOSinfo?	
DIAGnostic:SERVice:HWINfo?	
DIAGnostic:SERVice:INPut:MC[:DISTance]	
DIAGnostic:SERVice:INPut:PULSed:CFRequency	
DIAGnostic:SERVice:INPut:RF[:SPECtrum]	
DIAGnostic:SERVice:INPut:SYNThtwo[:FREQuency]	
· · · · · · · · · · · · · · · · · · ·	

DIAGnostic:SERVice:INPut[:SELect]	
DIAGnostic:SERVice:NSOurce	441
DIAGnostic:SERVice:SFUNction	
DIAGnostic:SERVice:SFUNction:LASTresult?	
DIAGnostic:SERVice:SFUNction:RESults:DELete	
DIAGnostic:SERVice:SFUNction:RESults:SAVE	607
DIAGnostic:SERVice:SINFo?	607
DIAGnostic:SERVice:STESt:RESult?	
DIAGnostic:SERVice:VERSinfo?	602
DISPlay:ANNotation:CBAR	589
DISPlay:ANNotation:FREQuency	
DISPlay:ATAB	
DISPlay:CMAP <it>:DEFault<ci></ci></it>	592
DISPlay:CMAP <it>:HSL</it>	593
DISPlay:CMAP <it>:PDEFined</it>	
DISPlay:FORMat	500
DISPlay:LOGO	565
DISPlay:SBAR[:STATe]	
DISPlay:SKEYs[:STATe]	590
DISPlay:SNINfo:TRACe	469
DISPlay:SNINfo[:STATe]	
DISPlay:TBAR[:STATe]	
DISPlay:THEMe:CATalog?	593
DISPlay:THEMe:SELect	
DISPlay:TOUChscreen[:STATe]	590
DISPlay:WSELect?	
DISPlay:XGINdicator[:STATe]	
DISPlay[:WINDow <n>]:MTABle</n>	
DISPlay[:WINDow <n>]:SIZE</n>	501
DISPlay[:WINDow <n>]:TIME</n>	
DISPlay[:WINDow <n>]:TIME:FORMat</n>	591
DISPlay[:WINDow <n>]:TRACe<t>:LABel:TEXT</t></n>	514
DISPlay[:WINDow <n>]:TRACe<t>:LABel[:STATe]</t></n>	513
DISPlay[:WINDow <n>]:TRACe<t>:MODE</t></n>	512
DISPlay[:WINDow <n>]:TRACe<t>:PERSistence:DECay</t></n>	514
DISPlay[:WINDow <n>]:TRACe<t>:PERSistence[:STATe]</t></n>	
DISPlay[:WINDow <n>]:TRACe<t>:RESult[:TYPE]</t></n>	515
DISPlay[:WINDow <n>]:TRACe<t>:SMOothing:APERture</t></n>	517
DISPlay[:WINDow <n>]:TRACe<t>:SMOothing[:STATe]</t></n>	517
DISPlay[:WINDow <n>]:TRACe<t>:SPURs:SUPPress</t></n>	
DISPlay[:WINDow <n>]:TRACe<t>:SPURs:THReshold</t></n>	470
DISPlay[:WINDow <n>]:TRACe<t>:X:SPACing?</t></n>	444
DISPlay[:WINDow <n>]:TRACe<t>:X[:SCALe]</t></n>	443
DISPlay[:WINDow <n>]:TRACe<t>:X[:SCALe]:AUTO</t></n>	444
DISPlay[:WINDow <n>]:TRACe<t>:Y:UNIT</t></n>	
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]</t></n>	445
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:AUTO</t></n>	445
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:MODE</t></n>	
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:PDIVision</t></n>	
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:RLEVel</t></n>	

DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:RLEVel:LOWer</t></n>	446
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:RLEVel:OFFSet</t></n>	
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:RLEVel:OFFSet:STATe</t></n>	
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:RPOSition</t></n>	
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:RVALue</t></n>	
DISPlay[:WINDow <n>]:TRACe<t>:Y[:SCALe]:UNIT</t></n>	
DISPlay[:WINDow <n>][:SUBWindow<w>]:SELect</w></n>	
DISPlay[:WINDow <n>][:SUBWindow<w>]:TRACe<t>[:STATe]</t></w></n>	
DISPlay[:WINDow <n>]:SUBWindow<w>]:ZOOM:AREA</w></n>	
DISPlay[:WINDow <n>]:SUBWindow<w>]:ZOOM:MULTiple<zn>:AREA</zn></w></n>	
DISPlay[:WINDow <n>]:SUBWindow<w>]:ZOOM:MULTiple<zn>[:STATe]</zn></w></n>	
DISPlay[:WINDow <n>][:SUBWindow<w>]:ZOOM[:STATe]</w></n>	
FETCh <n>:PNOise<t>:SPURs:COUNt?</t></n>	
FETCh <n>:PNOise<t>:SPURs:DISCrete?</t></n>	
FETCh <n>:PNOise<t>:SPURs:JITTer?</t></n>	
FETCh <n>:PNOise<t>:SPURs:RANDom?</t></n>	
FETCh <n>:PNOise<t>:SPURs?</t></n>	
FETCh <n>[:RANGe<j>]:PNOise<t>:DUT:GAIN?</t></j></n>	
FETCh <n>[:RANGe<j>]:PNOise<t>:IPN?</t></j></n>	
FETCh <n>[:RANGe<j>]:PNOise<t>:RAM?</t></j></n>	
FETCh <n>[:RANGe<j>]:PNOise<t>:RFM?</t></j></n>	
FETCh <n>[:RANGe<j>]:PNOise<t>:RMS?</t></j></n>	
FETCh <n>[:RANGe<j>]:PNOise<t>:RPM?</t></j></n>	
FORMat:DEXPort:CSEParator	
FORMat:DEXPort:DSEParator	
FORMat:DEXPort:FORMat	
FORMat:DEXPort:HEADer	
FORMat:DEXPort:TRACes	
FORMat[:DATA]	
HCOPy:ABORt	
HCOPy:CMAP <it>:DEFault<ci></ci></it>	
HCOPy:CMAP <it>:HSL</it>	
HCOPy:CMAP <it>:PDEFined</it>	
HCOPy:CONTent	
HCOPy:DESTination<1 2>	
HCOPy:DEVice:COLor	
HCOPy:DEVice:LANGuage<1 2>	
HCOPy:ITEM:WINDow<1 2>:TEXT	
HCOPy:PAGE:COUNt:STATe	
HCOPy:PAGE:MARGin<1 2>:BOTTom	
HCOPy:PAGE:MARGin<1 2>:LEFT	
HCOPy:PAGE:MARGin<1 2>:RIGHt	
HCOPy:PAGE:MARGin<1 2>:TOP	
HCOPy:PAGE:MARGin<1 2>:UNIT	
HCOPy:PAGE:ORIentation<1 2>	.572
HCOPy:PAGE:WINDow<1 2>:CHANnel:STATe	
HCOPy:PAGE:WINDow<1 2>:COUNt	573
HCOPy:PAGE:WINDow<1 2>:SCALe	573
HCOPy:PAGE:WINDow<1 2>:STATe	574
HCOPy:TDSTamp:STATe<1 2>	575

HCOPy[:IMMediate<1 2>]	
HCOPy[:IMMediate<1 2>]:NEXT	
INITiate:SEQuencer:ABORt	
INITiate:SEQuencer:IMMediate	
INITiate:SEQuencer:MODE	
INITiate <n>:CONMeas</n>	400
INITiate <n>:CONTinuous</n>	401
INITiate <n>[:IMMediate]</n>	402
INPut<1 2>:ATTenuation	
INPut<1 2>:ATTenuation:AUTO	
INPut<1 2>:CONNector	
INPut<1 2>:LOSCillator:SOURce	
INPut<1 2>:LOSCillator:SOURce:EXTernal:LEVel	
INPut<1 2>:RLEVel	
INPut <ip>:COUPling</ip>	413
INPut <ip>:SELect</ip>	
INPut <ip>:UPORt:STATe</ip>	
INPut <ip>:UPORt[:VALue]</ip>	
INSTrument:CREate:DUPLicate	
INSTrument:CREate:REPLace	
INSTrument:CREate[:NEW]	
INSTrument:DELete	
INSTrument:LIST?	
INSTrument:REName	
INSTrument[:SELect]	
LAYout:ADD[:WINDow]?	501
LAYout:CATalog[:WINDow]?	
LAYout:IDENtify[:WINDow]?	503
LAYout:MOVE[:WINDow]	504
LAYout:REMove[:WINDow]	
LAYout:REPLace[:WINDow]	505
LAYout:SPLitter	505
LAYout:WINDow <n>:ADD?</n>	
LAYout:WINDow <n>:IDENtify?</n>	
LAYout:WINDow <n>:REMove</n>	
LAYout:WINDow <n>:REPLace</n>	
MMEMory:CATalog	
MMEMory:CATalog:LONG	554
MMEMory:CDIRectory	554
MMEMory:CLEar:ALL	561
MMEMory:CLEar:STATe	
MMEMory:COMMent	
MMEMory:COPY	554
MMEMory:DATA	555
MMEMory:DELete:IMMediate	555
MMEMory:LOAD:AUTO	
MMEMory:LOAD:STATe	562
MMEMory:LOAD <n>:TRACe</n>	
MMEMory:MDIRectory	556
MMEMory:MOVE	

MMEMory:MSIS	
MMEMory:NAME	
MMEMory:NETWork:DISConnect	556
MMEMory:NETWork:MAP	
MMEMory:NETWork:UNUSeddrives?	
MMEMory:NETWork:USEDdrives	558
MMEMory:RDIRectory	558
MMEMory:SELect:CHANnel[:ITEM]:ALL	559
MMEMory:SELect:CHANnel[:ITEM]:DEFault	559
MMEMory:SELect:CHANnel[:ITEM]:HWSettings	559
MMEMory:SELect:CHANnel[:ITEM]:LINes:ALL	560
MMEMory:SELect:CHANnel[:ITEM]:NONE	
MMEMory:SELect:CHANnel[:ITEM]:SGRam	
MMEMory:SELect:CHANnel[:ITEM]:TRACe[:ACTive]	
MMEMory:SELect:CHANnel[:ITEM]:TRANsducer:ALL	561
MMEMory:SELect:CHANnel[:ITEM]:WEIGhting	
MMEMory:SELect[:ITEM]:ALL	559
MMEMory:SELect[:ITEM]:DEFault	559
MMEMory:SELect[:ITEM]:HWSettings	559
MMEMory:SELect[:ITEM]:LINes:ALL	
MMEMory:SELect[:ITEM]:NONE	
MMEMory:SELect[:ITEM]:SGRam	
MMEMory:SELect[:ITEM]:TRACe<13>[:ACTive]	
MMEMory:SELect[:ITEM]:TRANsducer:ALL	
MMEMory:SELect[:ITEM]:WEIGhting	
MMEMory:STORe<1 2>:STATe	
MMEMory:STORe<1 2>:STATe:NEXT	
MMEMory:STORe<1 2>:TYPE	
MMEMory:STORe <n>:SPURs</n>	
MMEMory:STORe <n>:TRACe</n>	
OUTPut <up>:UPORt:STATe</up>	
OUTPut <up>:UPORt[:VALue]</up>	
SOURce:CURRent:AUX:LIMit:HIGH?	
SOURce:CURRent:CONTrol <i>:LIMit:HIGH?</i>	
SOURce:CURRent:POWer <i>:LIMit:HIGH</i>	
SOURce:CURRent:SEQuence:RESult?	
SOURce:GENerator:CHANnel:COUPling	
SOURce:GENerator:DUTBypass	
SOURce:GENerator:FREQuency	
SOURce:GENerator:FREQuency:STEP	
SOURce:GENerator:LEVel	
SOURce:GENerator:MODulation	
SOURce:GENerator:PULSe:PERiod	
SOURce:GENerator:PULSe:TRIGger:OUTPut	
SOURce:GENerator:PULSe:WIDTh	
SOURce:GENerator[:STATe]	
SOURce:POWer:SEQuence:RESult?	
SOURce:VOLTage:AUX:LEVel:AMPLitude	
SOURce:VOLTage:AUX:LEVel:LIMit:HIGH	
SOURce:VOLTage:AUX:LEVel:LIMit:LOW	
-	

SOURce:VOLTage:AUX:LEVel[:STATe]	431
SOURce:VOLTage:CHANnel:COUPling	431
SOURce:VOLTage:CONTrol <i>:LEVel:AMPLitude</i>	
SOURce:VOLTage:CONTrol <i>:LEVel:LIMit:HIGH</i>	432
SOURce:VOLTage:CONTrol <i>:LEVel:LIMit:LOW</i>	
SOURce:VOLTage:CONTrol <i>:LEVel[:STATe]</i>	
SOURce:VOLTage:POWer <i>:LEVel:AMPLitude</i>	
SOURce:VOLTage:POWer <i>:LEVel:LIMit:HIGH</i>	
SOURce:VOLTage:POWer <i>:LEVel:LIMit:LOW</i>	
SOURce:VOLTage:POWer <i>:LEVel:MODE</i>	
SOURce:VOLTage:POWer <i>:LEVel[:STATe]</i>	
SOURce:VOLTage:POWer <i>:LIMit:HIGH</i>	
SOURce:VOLTage:SEQuence:RESult?	
SOURce:VOLTage[:STATe]	
SOURce <si>:EXTernal<ext>:ROSCillator:EXTernal:FREQuency</ext></si>	
SOURce <si>:TEMPerature:FRONtend</si>	
STATus:OPERation:CONDition?	
STATus:OPERation:ENABle	
STATus:OPERation:NTRansition	
STATus:OPERation:PTRansition	
STATus:OPERation[:EVENt]?	
STATus:PRESet	
STATus:QUEStionable:ACPLimit:CONDition?	615
STATus:QUEStionable:ACPLimit:ENABle	
STATus:QUEStionable:ACPLimit:NTRansition	
STATus:QUEStionable:ACPLimit:PTRansition	
STATus:QUEStionable:ACPLimit[:EVENt]?	
STATus:QUEStionable:CONDition?	
STATus:QUEStionable:ENABle	
STATus:QUEStionable:EXTended:CONDition?	
STATus:QUEStionable:EXTended:ENABle	
STATus:QUEStionable:EXTended:INFO:CONDition?	
STATus:QUEStionable:EXTended:INFO:ENABle	
STATus:QUEStionable:EXTended:INFO:NTRansition	
STATus:QUEStionable:EXTended:INFO:PTRansition	
STATus:QUEStionable:EXTended:INFO[:EVENt]?	
STATus:QUEStionable:EXTended:NTRansition	
STATus:QUEStionable:EXTended:PTRansition	
STATus:QUEStionable:EXTended[:EVENt]?	
STATus:QUEStionable:FREQuency:CONDition?	
STATus:QUEStionable:FREQuency:ENABle	
STATus:QUEStionable:FREQuency:NTRansition	
STATus:QUEStionable:FREQuency:PTRansition	
STATus:QUEStionable:FREQuency[:EVENt]?	
STATus:QUEStionable:LIMit <n>:CONDition?</n>	
STATus:QUEStionable:LIMit <n>:ENABle</n>	
STATus:QUEStionable:LIMit <n>:NTRansition</n>	
STATus:QUEStionable:LIMit <n>:PTRansition</n>	
STATus:QUEStionable:LIMit <n>[:EVENt]?</n>	
STATus:QUEStionable:LMARgin <n>:CONDition?</n>	

STATus:QUEStionable:LMARgin-rp-PTRansition       618         STATus:QUEStionable:IMARgin-rp-[EVENt]?       616         STATus:QUEStionable:PNCise_CONDition?       615         STATus:QUEStionable:PNCise_ENABle       617         STATus:QUEStionable:PNCise_ENABle       617         STATus:QUEStionable:PNCise_PTRansition       618         STATus:QUEStionable:PNCise_PTRansition       618         STATus:QUEStionable:PNCise_PTRansition       616         STATus:QUEStionable:PNCise_PTRansition       616         STATus:QUEStionable:PNCise_PTRansition       616         STATus:QUEStionable:PNCise_PTRansition       616         STATus:QUEStionable:POWer-DCPNoise_CONDition?       615         STATus:QUEStionable:POWer-DCPNoise_CONDition?       616         STATus:QUEStionable:POWer-DCPNoise_ENTRansition       617         STATus:QUEStionable:POWer-DCPNoise[EVENt]?       616         STATus:QUEStionable:POWer-PTRansition       618         STATus:QUEStionable:POWer-PTRansition       618         STATus:QUEStionable:POWer-PTRansition       616         STATus:QUEStionable:POWer-PTRansition       616         STATus:QUEStionable:TEMPerature:ENABle       617         STATus:QUEStionable:TEMPerature:ENABle       617         STATus:QUEStionable:TEMPerature:ENABle       617		
STATus:QUEStionable:NTRansition       617         STATus:QUEStionable:PNOise:CNNBile.       617         STATus:QUEStionable:PNOise:TRansition       617         STATus:QUEStionable:PNOise:TRansition       617         STATus:QUEStionable:PNOise:TRansition       618         STATus:QUEStionable:PNOise:TRansition       616         STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:DCPNoise:ENABle       617         STATus:QUEStionable:POWer:DCPNoise:ENABle       617         STATus:QUEStionable:POWer:DCPNoise:EVENI?       616         STATus:QUEStionable:POWer:DCPNoise:EVENI?       616         STATus:QUEStionable:POWer:DCPNoise:EVENI?       616         STATus:QUEStionable:POWer:PTRansition       617         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer:PTRansition       616         STATus:QUEStionable:TEMPerature:PTRansition       617         STATus:QUEStionable:TEMPerature:PTRansition       618         STATus:QUEStionable:TEMPerature:PTRansition       618         STATus:QUEStionable:TEMPerature:PTRansition       616	STATus:QUEStionable:LMARgin <n>:ENABle</n>	617
STATus:QUEStionable:/LMARgin=n>[EVENI]?       616         STATus:QUEStionable:/NRansition       617         STATus:QUEStionable:PNOise:CONDition?       615         STATus:QUEStionable:PNOise:TRansition       617         STATus:QUEStionable:PNOise:TRansition       617         STATus:QUEStionable:PNOise:TRansition       618         STATus:QUEStionable:PNOise:CONDition?       616         STATus:QUEStionable:POWer:CONDition?       616         STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:DCPNoise:CONDition?       616         STATus:QUEStionable:POWer:DCPNoise:CONDItion?       616         STATus:QUEStionable:POWer:DCPNoise:TRABILE       617         STATus:QUEStionable:POWer:DCPNoise:PTRansition       618         STATus:QUEStionable:POWer:DCPNoise:EVENI?       616         STATus:QUEStionable:POWer:PCPNOSe:EVENI?       616         STATus:QUEStionable:POWer:PRansition       617         STATus:QUEStionable:POWer:PRansition       618         STATus:QUEStionable:POWer:PRansition       616         STATus:QUEStionable:TEMPerature:CNDItion?       616         STATus:QUEStionable:TEMPerature:TNRansition       617         STATus:QUEStionable:TEMPerature:TNRansition       616         STATus:QUEStionable:TEMPerature:TNRansition       6	STATus:QUEStionable:LMARgin <n>:NTRansition</n>	617
STATus:QUEStionable:NTRansition       617         STATus:QUEStionable:PNOise:CNNBile.       617         STATus:QUEStionable:PNOise:TRansition       617         STATus:QUEStionable:PNOise:TRansition       617         STATus:QUEStionable:PNOise:TRansition       618         STATus:QUEStionable:PNOise:TRansition       616         STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:DCPNoise:ENABle       617         STATus:QUEStionable:POWer:DCPNoise:ENABle       617         STATus:QUEStionable:POWer:DCPNoise:EVENI?       616         STATus:QUEStionable:POWer:DCPNoise:EVENI?       616         STATus:QUEStionable:POWer:DCPNoise:EVENI?       616         STATus:QUEStionable:POWer:PTRansition       617         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer:PTRansition       616         STATus:QUEStionable:TEMPerature:PTRansition       617         STATus:QUEStionable:TEMPerature:PTRansition       618         STATus:QUEStionable:TEMPerature:PTRansition       618         STATus:QUEStionable:TEMPerature:PTRansition       616	STATus:QUEStionable:LMARgin <n>:PTRansition</n>	618
STATus:QUEStionable:PNOise:CONDition?       615         STATus:QUEStionable:PNOise:TRAnsition       617         STATus:QUEStionable:PNOise:TRAnsition       618         STATus:QUEStionable:PNOise;TVENI?       616         STATus:QUEStionable:PNOise;TVENI?       616         STATus:QUEStionable:PNOise;TCPNoise:CONDition?       615         STATus:QUEStionable:POWer.DCPNoise:CONDition?       615         STATus:QUEStionable:POWer.DCPNoise:CONDition?       616         STATus:QUEStionable:POWer.DCPNoise:CONDition?       616         STATus:QUEStionable:POWer.DCPNoise:CONDition?       616         STATus:QUEStionable:POWer.DCPNoise:PTRAnsition       617         STATus:QUEStionable:POWer.DCPNoise:EVENI?       616         STATus:QUEStionable:POWer.DCPNoise:EVENI?       616         STATus:QUEStionable:POWer.PTRansition       617         STATus:QUEStionable:POWer.PTRansition       618         STATus:QUEStionable:TEMPerature:CONDition?       616         STATus:QUEStionable:TEMPerature:PTRansition       617         STATus:QUEStionable:TEMPerature:PTRansition       618         STATus:QUEStionable:TEMPerature:PTRansition       618         STATus:QUEStionable:TEMPerature:PTRansition       616         STATus:QUEStionable:TEMPerature:PTRansition       616         STATus:QUEStionable	STATus:QUEStionable:LMARgin <n>[:EVENt]?</n>	616
STATus:QUEStionable:PNOise:ENABle.       617         STATus:QUEStionable:PNOise:TRansition.       618         STATus:QUEStionable:PNOise[EVENI]?       616         STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:DCPNoise:ENABle.       617         STATus:QUEStionable:POWer:DCPNoise:ENABle.       617         STATus:QUEStionable:POWer:DCPNoise:ENABle.       617         STATus:QUEStionable:POWer:DCPNoise:ENABle.       617         STATus:QUEStionable:POWer:DCPNoise:ENABle.       617         STATus:QUEStionable:POWer:DCPNoise!TRansition.       618         STATus:QUEStionable:POWer:DCPNoise!TRansition.       616         STATus:QUEStionable:POWer:NTRansition.       616         STATus:QUEStionable:POWer:NTRansition.       617         STATus:QUEStionable:POWer:PTRansition.       618         STATus:QUEStionable:POWer!TRansition.       616         STATus:QUEStionable:POWer!TRansition.       616         STATus:QUEStionable:POWer!TRansition.       617         STATus:QUEStionable:POWer!TRansition.       616         STATus:QUEStionable:TEMPerature:NTRansition.       617         STATus:QUEStionable:TEMPerature:NTRansition.       617         STATus:QUEStionable:TEMPerature:NTRansition.       616         STATus:QUEStionable:TIME:PTRansition.	STATus:QUEStionable:NTRansition	617
STATus:QUEStionable:PNOise:ENABle.       617         STATus:QUEStionable:PNOise:TRansition.       618         STATus:QUEStionable:PNOise[EVENI]?       616         STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:DCPNoise:ENABle.       617         STATus:QUEStionable:POWer:DCPNoise:ENABle.       617         STATus:QUEStionable:POWer:DCPNoise:ENABle.       617         STATus:QUEStionable:POWer:DCPNoise:ENABle.       617         STATus:QUEStionable:POWer:DCPNoise:ENABle.       617         STATus:QUEStionable:POWer:DCPNoise!TRansition.       618         STATus:QUEStionable:POWer:DCPNoise!TRansition.       616         STATus:QUEStionable:POWer:NTRansition.       616         STATus:QUEStionable:POWer:NTRansition.       617         STATus:QUEStionable:POWer:PTRansition.       618         STATus:QUEStionable:POWer!TRansition.       616         STATus:QUEStionable:POWer!TRansition.       616         STATus:QUEStionable:POWer!TRansition.       617         STATus:QUEStionable:POWer!TRansition.       616         STATus:QUEStionable:TEMPerature:NTRansition.       617         STATus:QUEStionable:TEMPerature:NTRansition.       617         STATus:QUEStionable:TEMPerature:NTRansition.       616         STATus:QUEStionable:TIME:PTRansition.	STATus:QUEStionable:PNOise:CONDition?	
STATus:QUEStionable:PN0ise[FVRansition.       618         STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:DCPNoise:CNDition?       615         STATus:QUEStionable:POWer:DCPNoise:ENABle       617         STATus:QUEStionable:POWer:DCPNoise:ENABle       617         STATus:QUEStionable:POWer:DCPNoise:PTRansition       618         STATus:QUEStionable:POWer:DCPNoise;PTRansition       618         STATus:QUEStionable:POWer:DCPNoise;PTRansition       617         STATus:QUEStionable:POWer:DCPNoise;PTRansition       616         STATus:QUEStionable:POWer:PTRansition       617         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer:PTRansition       616         STATus:QUEStionable:POWer:PTRansition       616         STATus:QUEStionable:TEMPerature:CONDition?       616         STATus:QUEStionable:TEMPerature:PTRansition       617         STATus:QUEStionable:TEMPerature:PTRansition       617         STATus:QUEStionable:TEMPerature:PTRansition       616         STATus:QUEStionable:TEMPerature:PTRansition       616         STATus:QUEStionable:TEMPerature:PTRansition       616         STATus:QUEStionable:TIME:ENABle       617         STATus:QUEStionable:TIME		
STATus:QUEStionable:PN0ise[FVRansition.       618         STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:DCPNoise:CNDition?       615         STATus:QUEStionable:POWer:DCPNoise:ENABle       617         STATus:QUEStionable:POWer:DCPNoise:ENABle       617         STATus:QUEStionable:POWer:DCPNoise:PTRansition       618         STATus:QUEStionable:POWer:DCPNoise;PTRansition       618         STATus:QUEStionable:POWer:DCPNoise;PTRansition       617         STATus:QUEStionable:POWer:DCPNoise;PTRansition       616         STATus:QUEStionable:POWer:PTRansition       617         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer:PTRansition       616         STATus:QUEStionable:POWer:PTRansition       616         STATus:QUEStionable:TEMPerature:CONDition?       616         STATus:QUEStionable:TEMPerature:PTRansition       617         STATus:QUEStionable:TEMPerature:PTRansition       617         STATus:QUEStionable:TEMPerature:PTRansition       616         STATus:QUEStionable:TEMPerature:PTRansition       616         STATus:QUEStionable:TEMPerature:PTRansition       616         STATus:QUEStionable:TIME:ENABle       617         STATus:QUEStionable:TIME	STATus:QUEStionable:PNOise:NTRansition	617
STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:DCPNoise:CONDition?       615         STATus:QUEStionable:POWer:DCPNoise:ENABle.       617         STATus:QUEStionable:POWer:DCPNoise:PTRansition       618         STATus:QUEStionable:POWer:DCPNoise:PTRansition       616         STATus:QUEStionable:POWer:DCPNoise:PTRansition       616         STATus:QUEStionable:POWer:ENABle.       617         STATus:QUEStionable:POWer:INTRansition.       618         STATus:QUEStionable:POWer:INTRansition.       616         STATus:QUEStionable:POWer:PTRansition.       616         STATus:QUEStionable:POWer:INTRAnsition.       617         STATus:QUEStionable:PTRAnsition.       616         STATus:QUEStionable:TEMPerature:CONDition?       616         STATus:QUEStionable:TEMPerature:CONDition?       616         STATus:QUEStionable:TEMPerature:PTRansition.       617         STATus:QUEStionable:TEMPerature:PTRansition.       617         STATus:QUEStionable:TEMPerature:PTRansition.       618         STATus:QUEStionable:TEMPerature:PEVAII?       616         STATus:QUEStionable:TEMPerature:PTRansition.       617         STATus:QUEStionable:TEMPerature:PTRansition.       617         STATus:QUEStionable:TME:PTRansition.       616         STATus:QUEStionable:T	STATus:QUEStionable:PNOise:PTRansition	618
STATus:QUEStionable:POWer:CONDition?       615         STATus:QUEStionable:POWer:DCPNoise:CONDition?       615         STATus:QUEStionable:POWer:DCPNoise:ENABle.       617         STATus:QUEStionable:POWer:DCPNoise:PTRansition       618         STATus:QUEStionable:POWer:DCPNoise:PTRansition       616         STATus:QUEStionable:POWer:DCPNoise:PTRansition       616         STATus:QUEStionable:POWer:ENABle.       617         STATus:QUEStionable:POWer:INTRansition.       618         STATus:QUEStionable:POWer:INTRansition.       616         STATus:QUEStionable:POWer:PTRansition.       616         STATus:QUEStionable:POWer:INTRAnsition.       617         STATus:QUEStionable:PTRAnsition.       616         STATus:QUEStionable:TEMPerature:CONDition?       616         STATus:QUEStionable:TEMPerature:CONDition?       616         STATus:QUEStionable:TEMPerature:PTRansition.       617         STATus:QUEStionable:TEMPerature:PTRansition.       617         STATus:QUEStionable:TEMPerature:PTRansition.       618         STATus:QUEStionable:TEMPerature:PEVAII?       616         STATus:QUEStionable:TEMPerature:PTRansition.       617         STATus:QUEStionable:TEMPerature:PTRansition.       617         STATus:QUEStionable:TME:PTRansition.       616         STATus:QUEStionable:T	STATus:QUEStionable:PNOise[:EVENt]?	616
STATus:QUEStionable:POWer:DCPNoise:NTRansition       617         STATus:QUEStionable:POWer:DCPNoise:PTRansition       618         STATus:QUEStionable:POWer:DCPNoise:PTRansition       618         STATus:QUEStionable:POWer:DCPNoise[:EVENI]?       616         STATus:QUEStionable:POWer:NTRansition       617         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:PTRansition       618         STATus:QUEStionable:PTRansition       618         STATus:QUEStionable:PTRansition       618         STATus:QUEStionable:TEMPerature:ENABle       617         STATus:QUEStionable:TEMPerature:ENABle       617         STATus:QUEStionable:TEMPerature:ENABle       617         STATus:QUEStionable:TEMPerature:PTRansition       618         STATus:QUEStionable:TEMPerature:PTRansition       616         STATus:QUEStionable:TIME:PNABle       617         STATus:QUEStionable:TIME:PNBLE       616         STATus:QUEStionable:TIME:PNBLE       616         STATus:QUEStionable:TIME:PNBLE       616         STATus:QUEStionable:TIME:PTRansition       616         STATus:QUEStionable:TIME:PTRansition       616         STATus:QUESt	STATus:QUEStionable:POWer:CONDition?	615
STATus:QUEStionable:POWer:DCPNoise:NTRansition       617         STATus:QUEStionable:POWer:DCPNoise:PTRansition       618         STATus:QUEStionable:POWer:DCPNoise[EVENI]?       616         STATus:QUEStionable:POWer:NTRansition       617         STATus:QUEStionable:POWer:PTRansition       617         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer[EVENI]?       616         STATus:QUEStionable:PTRansition       618         STATus:QUEStionable:TEMPerature:CONDition?       616         STATus:QUEStionable:TEMPerature:CONDition?       616         STATus:QUEStionable:TEMPerature:NTRansition       617         STATus:QUEStionable:TEMPerature:PTRansition       618         STATus:QUEStionable:TEMPerature:PTRansition       617         STATus:QUEStionable:TEMPerature:PTRansition       616         STATus:QUEStionable:TIME:CONDition?       616         STATus:QUEStionable:TIME:PTRansition       617         STATus:QUEStionable:TIME:PTRansition       618         STATus:QUEStionable:TIME:PTRansition       616         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:PTRAnsition       617         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:PTRANSiton       617     <	STATus:QUEStionable:POWer:DCPNoise:CONDition?	615
STATus:QUEStionable:POWer:DCPNoise:PTRansition       618         STATus:QUEStionable:POWer:DCPNoise[:EVENt]?       616         STATus:QUEStionable:POWer:ENABle.       617         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer:EVENt]?       616         STATus:QUEStionable:TEMPerature:CONDition?       615         STATus:QUEStionable:TEMPerature:ENABle       617         STATus:QUEStionable:TEMPerature:ENABle       617         STATus:QUEStionable:TEMPerature:ENABle       617         STATus:QUEStionable:TEMPerature:PTRansition       618         STATus:QUEStionable:TEMPerature:PTRansition       617         STATus:QUEStionable:TEMPerature:PTRansition       616         STATus:QUEStionable:TIME:ENABle.       617         STATus:QUEStionable:TIME:PTRansition       618         STATus:QUEStionable:TIME:PTRansition       617         STATus:QUEStionable:TIME:PTRansition       617         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:PTRANSiton       616	STATus:QUEStionable:POWer:DCPNoise:ENABle	617
STATus:QUEStionable:POWer:DCPNoise:PTRansition       618         STATus:QUEStionable:POWer:DCPNoise[:EVENt]?       616         STATus:QUEStionable:POWer:ENABle.       617         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer:EVENt]?       616         STATus:QUEStionable:TEMPerature:CONDition?       615         STATus:QUEStionable:TEMPerature:ENABle       617         STATus:QUEStionable:TEMPerature:ENABle       617         STATus:QUEStionable:TEMPerature:ENABle       617         STATus:QUEStionable:TEMPerature:PTRansition       618         STATus:QUEStionable:TEMPerature:PTRansition       617         STATus:QUEStionable:TEMPerature:PTRansition       616         STATus:QUEStionable:TIME:ENABle.       617         STATus:QUEStionable:TIME:PTRansition       618         STATus:QUEStionable:TIME:PTRansition       617         STATus:QUEStionable:TIME:PTRansition       617         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:PTRANSiton       616	STATus:QUEStionable:POWer:DCPNoise:NTRansition	
STATus:QUEStionable:POWer:DCPNoise[:EVENt]?       616         STATus:QUEStionable:POWer:ENABle       617         STATus:QUEStionable:POWer:TRansition       618         STATus:QUEStionable:POWer:PTRansition       618         STATus:QUEStionable:POWer!EVENt]?       616         STATus:QUEStionable:PTRansition       618         STATus:QUEStionable:TEMPerature:CONDition?       615         STATus:QUEStionable:TEMPerature:ENABle       617         STATus:QUEStionable:TEMPerature:PTRansition       618         STATus:QUEStionable:TEMPerature:PTRansition       617         STATus:QUEStionable:TEMPerature:EVENt]?       616         STATus:QUEStionable:TEMPerature:EVENt]?       616         STATus:QUEStionable:TEMPerature:EVENt]?       616         STATus:QUEStionable:TEMPerature:EVENt]?       616         STATus:QUEStionable:TIME:CONDition?       615         STATus:QUEStionable:TIME:PTRansition       617         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:PTRANSition       616         STATus		
STATus:QUEStionable:POWer:ENABle       617         STATus:QUEStionable:POWer:NTRansition       618         STATus:QUEStionable:PTRansition       618         STATus:QUEStionable:PTRansition       618         STATus:QUEStionable:PTRansition       618         STATus:QUEStionable:PTRAnsition       618         STATus:QUEStionable:TEMPerature:CONDition?       615         STATus:QUEStionable:TEMPerature:CONDition?       615         STATus:QUEStionable:TEMPerature:ENABle       617         STATus:QUEStionable:TEMPerature:ENABle       617         STATus:QUEStionable:TEMPerature:ENABle       616         STATus:QUEStionable:TEMPerature:EVENIJ?       616         STATus:QUEStionable:TEMPerature:EVENIJ?       616         STATus:QUEStionable:TIME:CONDition?       615         STATus:QUEStionable:TIME:TMRansition       617         STATus:QUEStionable:TIME:TMEnsition       616         STATus:QUEStionable:TIME:TMENsition       617         STATus:QUEStionable:TIME:TMENsition       617         STATus:QUEStionable:TIME:TMENtionalition       617         STATus:QUEStionable:TIME:TMENtionalition       616         STATus:QUEStionable:TIME:TMENTIME:TMENTIME       616         STATus:QUEStionable:TIME:TMENTIME:TMENTIME:TMENTIME       616         STATus:QU		
STATus:QUEStionable:POWer/EVENtj?       618         STATus:QUEStionable:POWer/EVENtj?       616         STATus:QUEStionable:TEMPerature:CONDition?       615         STATus:QUEStionable:TEMPerature:CONDition?       615         STATus:QUEStionable:TEMPerature:CONDition?       616         STATus:QUEStionable:TEMPerature:NABle.       617         STATus:QUEStionable:TEMPerature:PTRansition       618         STATus:QUEStionable:TEMPerature:PTRansition       616         STATus:QUEStionable:TEMPerature:PTRansition       617         STATus:QUEStionable:TIME:CONDition?       615         STATus:QUEStionable:TIME:CONDition?       616         STATus:QUEStionable:TIME:PTRansition       617         STATus:QUEStionable:TIME:PTRAnsition       617         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:EVENt]?       616         STATus:QUEStionable:TIME:EVENt]?       616         STATus:QUEStionable:TIME:EVENT?       616         STATus:QUEStionable:TIME:EVENT?       616         STATus:QUEStionable:TIME:EVENT?       616         STATus:QUEStionable:TIME:EVENT?       616         SYSTEm:COMMunicate:GPIB[:SELF]:ADDRess       596         SYSTEm:COMMunicate:GPIB[:SELF]:ADDRess       596         SYSTEm:COMMunicate:PRINter		
STATus:QUEStionable:POWer/EVENtj?       618         STATus:QUEStionable:POWer/EVENtj?       616         STATus:QUEStionable:TEMPerature:CONDition?       615         STATus:QUEStionable:TEMPerature:CONDition?       615         STATus:QUEStionable:TEMPerature:CONDition?       616         STATus:QUEStionable:TEMPerature:NABle.       617         STATus:QUEStionable:TEMPerature:PTRansition       618         STATus:QUEStionable:TEMPerature:PTRansition       616         STATus:QUEStionable:TEMPerature:PTRansition       617         STATus:QUEStionable:TIME:CONDition?       615         STATus:QUEStionable:TIME:CONDition?       616         STATus:QUEStionable:TIME:PTRansition       617         STATus:QUEStionable:TIME:PTRAnsition       617         STATus:QUEStionable:TIME:PTRAnsition       616         STATus:QUEStionable:TIME:EVENt]?       616         STATus:QUEStionable:TIME:EVENt]?       616         STATus:QUEStionable:TIME:EVENT?       616         STATus:QUEStionable:TIME:EVENT?       616         STATus:QUEStionable:TIME:EVENT?       616         STATus:QUEStionable:TIME:EVENT?       616         SYSTEm:COMMunicate:GPIB[:SELF]:ADDRess       596         SYSTEm:COMMunicate:GPIB[:SELF]:ADDRess       596         SYSTEm:COMMunicate:PRINter	STATus:QUEStionable:POWer:NTRansition	
STATus:QUEStionable:POWer[:EVENI]?		
STATus:QUEStionable:PTRansition618STATus:QUEStionable:TEMPerature:CONDition?615STATus:QUEStionable:TEMPerature:ENABle617STATus:QUEStionable:TEMPerature:PTRansition617STATus:QUEStionable:TEMPerature:PTRansition618STATus:QUEStionable:TEMPerature:PTRansition618STATus:QUEStionable:TEMPerature:PTRansition618STATus:QUEStionable:TIME:CONDition?615STATus:QUEStionable:TIME:CONDition?615STATus:QUEStionable:TIME:ENABle617STATus:QUEStionable:TIME:PTRansition617STATus:QUEStionable:TIME:PTRansition618STATus:QUEStionable:TIME:PTRansition616STATus:QUEStionable:TIME:PTRansition616STATus:QUEStionable:TIME:PTRansition616STATus:QUEStionable:EVENtj?616STATus:QUEStionable:EVENtj?616STATus:QUEStionable:EVENtj?616STATus:QUEStionable:EVENtj?616STATus:QUEStionable:EVENtj?616STATus:QUEStionable:EVENtj?616SYSTem:COMMunicate:GPIB[:SELF]:ADDRess596SYSTem:COMMunicate:GPIB[:SELF]:ADDRess596SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt575SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt575SYSTem:COMMunicate:PRINter:SELect<1 2>597SYSTem:DISPlay:UDDate597SYSTem:ERRor:CLEar:REMote597SYSTem:ERRor:CLEar:REMote597SYSTem:ERRor:CLEar:REMote597SYSTem:ERRor:CLEar:REMote597SYSTem:ERRor:DISPlay.603SYST		
STATus:QUEStionable:TEMPerature:CONDition?615STATus:QUEStionable:TEMPerature:NTRansition617STATus:QUEStionable:TEMPerature:PTRansition618STATus:QUEStionable:TEMPerature:PTRansition618STATus:QUEStionable:TEMPerature:EVENI]?616STATus:QUEStionable:TIME:CONDition?615STATus:QUEStionable:TIME:EVENI]?616STATus:QUEStionable:TIME:ENABle617STATus:QUEStionable:TIME:ENABle617STATus:QUEStionable:TIME:PTRansition618STATus:QUEStionable:TIME:PTRansition618STATus:QUEStionable:TIME:PTRansition616STATus:QUEStionable:TIME:EVENI]?616STATus:QUEStionable:TIME:EVENI]?616STATus:QUEStionable:EVENI]?616STATus:QUEStionable:EVENI]?616STATus:QUEStionable:EVENI]?616STATus:QUEStionable:EVENI]?616STATus:QUEUe[:NEXT]?616SYSTem:COMMunicate:GPIB[:SELF]:ADDRess596SYSTem:COMMunicate:GPIB[:SELF]:ADDRess596SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt575SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt575SYSTem:COMMunicate:PRINter:SELect<1 2>592SYSTem:DISPlay:UPDate597SYSTem:ERRor:CLEar:ALL603SYSTem:ERRor:CLEar:ALL603SYSTem:ERRor:CLEar:REMote597SYSTem:ERRor:CLEar:REMote597SYSTem:ERRor:CLEar:REMote597SYSTem:ERRor:CLEar:REMote597SYSTem:ERRor:CLEar:REMote597SYSTem:ERRor:CLEar:REMote597<		
STATus:QUEStionable:TEMPerature:ENABle.617STATus:QUEStionable:TEMPerature:NTRansition.617STATus:QUEStionable:TEMPerature:PTRansition.618STATus:QUEStionable:TEMPerature:EVENt]?616STATus:QUEStionable:TIME:CONDition?615STATus:QUEStionable:TIME:ENABle.617STATus:QUEStionable:TIME:PTRansition.617STATus:QUEStionable:TIME:PTRansition.617STATus:QUEStionable:TIME:PTRansition.618STATus:QUEStionable:TIME:PTRansition.616STATus:QUEStionable:TIME:EVENt]?616STATus:QUEStionable:TIME:EVENt]?616STATus:QUEStionable:TIME:EVENt]?616STATus:QUEStionable:TIME:EVENt]?616STATus:QUEStionable:TIME:EVENt]?616STATus:QUEStionable:TIME:EVENt]?616STATus:QUEStionable:TIME:EVENt]?616SYSTem:CLOGging.580SYSTem:COMMunicate:GPIB:SELF]:ADDRess.596SYSTem:COMMunicate:GPIB:SELF]:ADDRess.596SYSTem:COMMunicate:PRINter:ENUMerate:IREXT]575SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]575SYSTem:DISPlay:Honel:STATe]592SYSTem:DISPlay:Honel:STATe]592SYSTem:DISPlay:UPDate.597SYSTem:ERRor:CLEar:ALL603SYSTem:ERRor:CLEar:ALL603SYSTem:ERRor:EXEnded?603SYSTem:ERRor:EXEnded?603SYSTem:ERRor:EXTended?603SYSTem:ERRor:EXTended?603SYSTem:ERRor:EXTended?603SYSTem:ERRor:EXTended?603SYSTem:		
STATus:QUEStionable:TEMPerature:NTRansition617STATus:QUEStionable:TEMPerature:PTRansition618STATus:QUEStionable:TEMPerature:EVENt]?616STATus:QUEStionable:TIME:CONDition?615STATus:QUEStionable:TIME:ENABle617STATus:QUEStionable:TIME:NTRansition617STATus:QUEStionable:TIME:PTRansition618STATus:QUEStionable:TIME:PTRansition616STATus:QUEStionable:TIME:PTRansition616STATus:QUEStionable:TIME:EVENt]?616STATus:QUEStionable:TIME:EVENt]?616STATus:QUEUeq:NEXT]?616SYSTem:CLOGging580SYSTem:COMMunicate:GPIB[:SELF]:ADDRess.596SYSTem:COMMunicate:GPIB[:SELF]:RTERminator596SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt575SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]575SYSTem:DISPlay:FPANel[:STATe]580SYSTem:DISPlay:UPDate597SYSTem:ERRor:CLEar:ALL603SYSTem:ERRor:CLEar:ALL603SYSTem:ERRor:CLEar:REMote597SYSTem:ERRor:LIST?603SYSTem:ERRor:LIST?603SYSTem:ERRor:LIST?603SYSTem:ERRor:EXTended?603SYSTem:ERRor:EXTended?603SYSTem:ERRor:EXTended?603SYSTem:ERRor:EXTended?603SYSTem:ERRor:EXTended?603SYSTem:ERRor:EXTended?603SYSTem:ERRor:EXTended?603SYSTem:ERRor:EXTended?603SYSTem:ERRor:EXTended?603SYSTem:ERRor:EXTended?603		
STATus:QUEStionable:TEMPerature[:EVENt]?616STATus:QUEStionable:TIME:CONDition?615STATus:QUEStionable:TIME:ENABle617STATus:QUEStionable:TIME:NTRansition617STATus:QUEStionable:TIME:PTRansition618STATus:QUEStionable:TIME:PTRansition616STATus:QUEStionable:TIME:PTRansition616STATus:QUEStionable:TIME:EVENt]?616STATus:QUEStionable:EVENt]?616STATus:QUEStionable[:EVENt]?616SYStem:CLOGging580SYSTem:COMMunicate:GPIB[:SELF]:ADDRess.596SYSTem:COMMunicate:GPIB[:SELF]:RTERminator596SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt575SYSTem:COMMunicate:PRINter:SELect<1 2>575SYSTem:COMMunicate:PRINter:SELect<1 2>575SYSTem:DISPlay:FPANel[:STATe]592SYSTem:DISPlay:IDSPlay:UPDate597SYSTem:DISPlay:UPDate597SYSTem:ERRor:CLEar:ALL603SYSTem:ERRor:CLEar:REMote597SYSTem:ERRor:LER:Mote597SYSTem:ERRor:LER:Mote597SYSTem:ERRor:LIST?603SYSTem:ERRor:LIST?603SYSTem:ERRor:LIST?603SYSTem:ERRor[:NEXT]?603SYSTem:ERRor[:NEXT]?603SYSTem:ERRor[:NEXT]?604		
STATus:QUEStionable:TEMPerature[:EVENt]?616STATus:QUEStionable:TIME:CONDition?615STATus:QUEStionable:TIME:ENABle617STATus:QUEStionable:TIME:NTRansition617STATus:QUEStionable:TIME:PTRansition618STATus:QUEStionable:TIME:PTRansition616STATus:QUEStionable:TIME:PTRansition616STATus:QUEStionable:TIME:EVENt]?616STATus:QUEStionable:EVENt]?616STATus:QUEStionable[:EVENt]?616SYStem:CLOGging580SYSTem:COMMunicate:GPIB[:SELF]:ADDRess.596SYSTem:COMMunicate:GPIB[:SELF]:RTERminator596SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt575SYSTem:COMMunicate:PRINter:SELect<1 2>575SYSTem:COMMunicate:PRINter:SELect<1 2>575SYSTem:DISPlay:FPANel[:STATe]592SYSTem:DISPlay:IDSPlay:UPDate597SYSTem:DISPlay:UPDate597SYSTem:ERRor:CLEar:ALL603SYSTem:ERRor:CLEar:REMote597SYSTem:ERRor:LER:Mote597SYSTem:ERRor:LER:Mote597SYSTem:ERRor:LIST?603SYSTem:ERRor:LIST?603SYSTem:ERRor:LIST?603SYSTem:ERRor[:NEXT]?603SYSTem:ERRor[:NEXT]?603SYSTem:ERRor[:NEXT]?604	STATus:QUEStionable:TEMPerature:PTRansition	
STATus:QUEStionable:TIME:CONDition?615STATus:QUEStionable:TIME:ENABle.617STATus:QUEStionable:TIME:NTRansition617STATus:QUEStionable:TIME:PTRansition618STATus:QUEStionable:TIME:PTRansition616STATus:QUEStionable:TIME[:EVENt]?616STATus:QUEStionable[:EVENt]?616STATus:QUEStionable[:EVENt]?616STATus:QUEStionable[:EVENt]?616SYStem:CLOGging580SYStem:COMMunicate:GPIB[:SELF]:ADDRess.596SYSTem:COMMunicate:GPIB[:SELF]:RTERminator.596SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt.575SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]575SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]575SYSTem:DISPlay:FPANel[:STATe]592SYSTem:DISPlay:FPANel[:STATe]597SYSTem:DISPlay:COK597SYSTem:ERRor:CLEar:ALL603SYSTem:ERRor:CLEar:REMote597SYSTem:ERRor:DISPlay597SYSTem:ERRor:LIST?603SYSTem:ERRor:LIST?603SYSTem:ERRor:LIST?603SYSTem:ERRor:LIST?603SYSTem:ERRor:INERT]?603SYSTem:ERRor:INERT]?603SYSTem:ERRor:INERT]?603SYSTem:ERRor:INERT]?603SYSTem:ERRor:INERT]?603SYSTem:ERRor:INERT]?603SYSTem:ERRor:INERT]?603SYSTem:ERRor:INERT]?603SYSTem:ERRor:INERT]?603	STATus:QUEStionable:TEMPerature[:EVENt]?	616
STATus:QUEStionable:TIME:ENABle.       617         STATus:QUEStionable:TIME:NTRansition       617         STATus:QUEStionable:TIME:PTRansition       618         STATus:QUEStionable:TIME:EVENt]?       616         STATus:QUEStionable[:EVENt]?       616         STATus:QUEStionable[:EVENt]?       616         STATus:QUEstionable[:EVENt]?       616         STATus:QUEue[:NEXT]?       615         SYSTem:CLOGging       580         SYSTem:COMMunicate:GPIB[:SELF]:ADDRess       596         SYSTem:COMMunicate:GPIB[:SELF]:RTERminator       596         SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt       575         SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]       575         SYSTem:DISPlay:FPANel[:STATe]       592         SYSTem:DISPlay:FPANel[:STATe]       597         SYSTem:DISPlay:FPANel[:STATe]       597         SYSTem:DISPlay:UPDate       597         SYSTem:ERRor:CLEar:REMote       597         SYSTem:ERRor:DISPlay       597         SYSTem:ERRor:CLEar:REMote       597         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603		
STATus:QUEStionable:TIME:PTRansition.       618         STATus:QUEStionable:TIME[:EVENt]?       616         STATus:QUEStionable[:EVENt]?       616         STATus:QUEStionable[:EVENt]?       616         STATus:QUEue[:NEXT]?       615         SYSTem:CLOGging.       580         SYSTem:COMMunicate:GPIB[:SELF]:ADDRess.       596         SYSTem:COMMunicate:GPIB[:SELF]:RTERminator.       596         SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt.       575         SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt.       575         SYSTem:COMMunicate:PRINter:SELect<1/td>       575         SYSTem:COMMunicate:PRINter:SELect<1/td>       575         SYSTem:DATE       580         SYSTem:DISPlay:FPANel[:STATe]       592         SYSTem:DISPlay:UPDate       597         SYSTem:ERRor:CLEar:ALL       603         SYSTem:ERRor:DISPlay       597         SYSTem:ERRor:DISPlay       597         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603		
STATus:QUEStionable:TIME:PTRansition.       618         STATus:QUEStionable:TIME[:EVENt]?       616         STATus:QUEStionable[:EVENt]?       616         STATus:QUEStionable[:EVENt]?       616         STATus:QUEue[:NEXT]?       615         SYSTem:CLOGging.       580         SYSTem:COMMunicate:GPIB[:SELF]:ADDRess.       596         SYSTem:COMMunicate:GPIB[:SELF]:RTERminator.       596         SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt.       575         SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt.       575         SYSTem:COMMunicate:PRINter:SELect<1/td>       575         SYSTem:COMMunicate:PRINter:SELect<1/td>       575         SYSTem:DATE       580         SYSTem:DISPlay:FPANel[:STATe]       592         SYSTem:DISPlay:UPDate       597         SYSTem:ERRor:CLEar:ALL       603         SYSTem:ERRor:DISPlay       597         SYSTem:ERRor:DISPlay       597         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603	STATus:QUEStionable:TIME:NTRansition	
STATus:QUEStionable:TIME[:EVENt]?       616         STATus:QUEStionable[:EVENt]?       616         STATus:QUEue[:NEXT]?       615         SYSTem:CLOGging       580         SYSTem:COMMunicate:GPIB[:SELF]:ADDRess       596         SYSTem:COMMunicate:GPIB[:SELF]:RTERminator       596         SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt       575         SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]       575         SYSTem:COMMunicate:PRINter:SELect<1 2>       575         SYSTem:DATE       580         SYSTem:DISPlay:FPANel[:STATe]       592         SYSTem:DISPlay:UPDate       597         SYSTem:ERRor:CLEar:REMote       597         SYSTem:ERRor:CLEar:REMote       597         SYSTem:ERRor:LIST?       603		
STATus:QUEStionable[:EVENt]?       616         STATus:QUEue[:NEXT]?       615         SYSTem:CLOGging       580         SYSTem:COMMunicate:GPIB[:SELF]:ADDRess       596         SYSTem:COMMunicate:GPIB[:SELF]:RTERminator       596         SYSTem:COMMunicate:GPIB[:SELF]:RTERminator       596         SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt       575         SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]       575         SYSTem:COMMunicate:PRINter:SELect<1 2>       575         SYSTem:DISPlay:FPANel[:STATe]       592         SYSTem:DISPlay:FPANel[:STATe]       597         SYSTem:DISPlay:UPDate       597         SYSTem:ERRor:CLEar:ALL       603         SYSTem:ERRor:DISPlay       597         SYSTem:ERRor:DISPlay       597         SYSTem:ERRor:CLEar:REMote       597         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor[:NEXT]?       604		
STATus:QUEue[:NEXT]?       615         SYSTem:CLOGging       580         SYSTem:COMMunicate:GPIB[:SELF]:ADDRess       596         SYSTem:COMMunicate:GPIB[:SELF]:RTERminator       596         SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt       575         SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]       575         SYSTem:COMMunicate:PRINter:SELect<1 2>       575         SYSTem:DISPlay:FPANel[:STATe]       580         SYSTem:DISPlay:FPANel[:STATe]       592         SYSTem:DISPlay:UPDate       597         SYSTem:ERRor:CLEar:ALL       603         SYSTem:ERRor:DISPlay.       597         SYSTem:ERRor:DISPlay.       597         SYSTem:ERRor:CLEar:REMote       597         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor[:NEXT]?       604		
SYSTem:CLOGging.       580         SYSTem:COMMunicate:GPIB[:SELF]:ADDRess.       596         SYSTem:COMMunicate:GPIB[:SELF]:RTERminator.       596         SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt.       575         SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]       575         SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]       575         SYSTem:COMMunicate:PRINter:ELect<1 2>.       575         SYSTem:DATE.       580         SYSTem:DISPlay:FPANel[:STATe]       592         SYSTem:DISPlay:POAte       597         SYSTem:DISPlay:UPDate       597         SYSTem:ERRor:CLEar:ALL       603         SYSTem:ERRor:DISPlay       597         SYSTem:ERRor:LEar:REMote       597         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor[:NEXT]?       604		
SYSTem:COMMunicate:GPIB[:SELF]:ADDRess.596SYSTem:COMMunicate:GPIB[:SELF]:RTERminator.596SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt.575SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]575SYSTem:COMMunicate:PRINter:SELect<1 2>.575SYSTem:DATE580SYSTem:DISPlay:FPANel[:STATe]592SYSTem:DISPlay:UPDate597SYSTem:ERRor:CLEar:ALL603SYSTem:ERRor:DISPlay597SYSTem:ERRor:DISPlay597SYSTem:ERRor:LEar:REMote597SYSTem:ERRor:LIST?603SYSTem:ERRor:LIST?603SYSTem:ERRor:LIST?603SYSTem:ERRor:LIST?604		
SYSTem:COMMunicate:GPIB[:SELF]:RTERminator.596SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt.575SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]575SYSTem:COMMunicate:PRINter:SELect<1 2>575SYSTem:DATE.580SYSTem:DISPlay:FPANel[:STATe]592SYSTem:DISPlay:LOCK.597SYSTem:DISPlay:UPDate.597SYSTem:ERRor:CLEar:ALL603SYSTem:ERRor:CLEar:REMote.597SYSTem:ERRor:DISPlay.597SYSTem:ERRor:LIST?603SYSTem:ERRor:LIST?603SYSTem:ERRor:LIST?603SYSTem:ERRor[:NEXT]?604		
SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt.       575         SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]       575         SYSTem:COMMunicate:PRINter:SELect<1 2>       575         SYSTem:DATE       580         SYSTem:DISPlay:FPANel[:STATe]       592         SYSTem:DISPlay:IPDate       597         SYSTem:DISPlay:UPDate       597         SYSTem:ERRor:CLEar:ALL       603         SYSTem:ERRor:DISPlay       597         SYSTem:ERRor:DISPlay       597         SYSTem:ERRor:DISPlay       597         SYSTem:ERRor:CLEar:ALL       603         SYSTem:ERRor:DISPlay       597         SYSTem:ERRor:DISPlay       597         SYSTem:ERRor:DISPlay       597         SYSTem:ERRor:DISPlay       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor[:NEXT]?       604		
SYSTem:COMMunicate:PRINter:ENUMerate[:NEXT]       575         SYSTem:COMMunicate:PRINter:SELect<1 2>       575         SYSTem:DATE       580         SYSTem:DISPlay:FPANel[:STATe]       592         SYSTem:DISPlay:LOCK       597         SYSTem:ERRor:CLEar:ALL       603         SYSTem:ERRor:CLEar:REMote       597         SYSTem:ERRor:LISPlay       597         SYSTem:ERRor:LIST?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor[:NEXT]?       604		
SYSTem:COMMunicate:PRINter:SELect<1 2>		
SYSTem:DATE		
SYSTem:DISPlay:LOCK		
SYSTem:DISPlay:LOCK	SYSTem:DISPlay:FPANel[:STATe]	
SYSTem:DISPlay:UPDate		
SYSTem:ERRor:CLEar:ALL.       603         SYSTem:ERRor:CLEar:REMote.       597         SYSTem:ERRor:DISPlay.       597         SYSTem:ERRor:EXTended?       603         SYSTem:ERRor:LIST?       603         SYSTem:ERRor[:NEXT]?       604		
SYSTem:ERRor:CLEar:REMote		
SYSTem:ERRor:DISPlay		
SYSTem:ERRor:EXTended?		
SYSTem:ERRor:LIST?         603           SYSTem:ERRor[:NEXT]?         604	-	
SYSTem:ERRor[:NEXT]?604		
	SYSTem:FIRMware:UPDate	

SYSTem:FORMat:IDENt	
SYSTem:IDENtify:FACTory	
SYSTem:IDENtify[:STRing]	
SYSTem:KLOCk	598
SYSTem:LANGuage	
SYSTem:LXI:LANReset	
SYSTem:LXI:MDEScription	
SYSTem:LXI:PASSword	
SYSTem:PASSword:RESet	608
SYSTem:PASSword[:CENable]	608
SYSTem:PRESet	
SYSTem:PRESet:CHANnel[:EXEC]	564
SYSTem:PRESet:COMPatible	605
SYSTem:PRESet:FILTer	605
SYSTem:PSA:WIDeband	599
SYSTem:REBoot	
SYSTem:SECurity[:STATe]	605
SYSTem:SEQuencer	394
SYSTem:SHIMmediate ONCE	600
SYSTem:SHIMmediate:STATe	
SYSTem:SHUTdown	
SYSTem:TIME	580
TRACe <n>:COPY</n>	518
TRACe <n>:POINts?</n>	410
TRACe <n>[:DATA]:LINear?</n>	
TRACe <n>[:DATA]:X:POINts?</n>	411
TRACe <n>[:DATA]:X?</n>	411
TRACe <n>[:DATA]:Y:POINts?</n>	
TRACe <n>[:DATA]:Y?</n>	411
TRACe <n>[:DATA]?</n>	408
TRIGger[:SEQuence]:DTIMe	
TRIGger[:SEQuence]:FREQuency	
TRIGger[:SEQuence]:FREQuency:HYSTeresis	
TRIGger[:SEQuence]:HOLDoff[:TIME]	
TRIGger[:SEQuence]:IFPower:HOLDoff	
TRIGger[:SEQuence]:LEVel[:EXTernal<1 2>]	
TRIGger[:SEQuence]:SLOPe	
TRIGger[:SEQuence]:SOURce	

# Index

### Symbols

*IDN	
Format	356
*OPC	
*OPC?	
*RST	
*WAI	
9.91E37	
Remote control	329

### Α

Aborting		
Sweep	109, 1 <sup>,</sup>	10
AC/DC coupling	12	26
Alignment		
Basics	27	75
Performing	280, 28	81
Results	277, 28	80
Settings	27	77
touchscreen	276, 28	80
Touchscreen	27	77
Alphanumeric keys		39
Alphanumeric parameters	8	87
AM (trace information)		77
Analog Modulation Analysis		
Application	10	00
Annotations		
Hiding/restoring		84
Application cards	····· ′	19
Application notes	····· ′	19
Applications		
Analog Modulation Analysis	1(	00
I/Q Analyzer	10	00
Noise Figure	1(	00
Phase Noise	9	99
Pulse	1(	01
Spectrum	10	00
Spectrum Monitor	9	99
Spurious Measurements	1(	01
Transient Analysis		
Vector Signal Analysis (VSA)	1(	01
Arranging		
Windows	94, 19	97
ASCII trace export	2 <sup>,</sup>	16
Att (channel bar)		76
Autologin mechanism		
Activating/Deactivating	37	70
AUX PORT		
Connector		
Average count		
AVG (trace information)		77

### В

Band	
Conversion loss table	140
External Mixer	134, 135
External Mixer (remote)	418
Baseband input	43

Bias	
Conversion loss table	137, 140
External Mixer	130, 137
External Mixer (remote)	422
Block data	327
Boolean parameters	326
Brackets	327
Brochures	19

### С

Calibration	
Frequency	305
Frequency MW	
Frequency RF	306
Remote	385
Remote control	
Results (remote control)	586
RF	306
Settings	
Signal	
Capture Range149,	
Case-sensitivity	
SCPI	323
Channel	
Creating (remote)	392
Deleting (remote)	
Duplicating (remote)	
Querying (remote)	
Renaming (remote)	
Replacing (remote)	
Selecting (remote)	
Channel bar	552
Hiding/restoring	201
Information	
channel settings	
Presetting	245
Channel settings	240
Display	75
	75
Channels	400
Duplicating	
New	
Replacing	
see also Measurement channels	
Sequential operation	
Switching	
Cleaning	628
Clear status	
Remote	385
Closing	
Channels	
Channels (remote)	
Windows	
Windows (remote)	
CLRW (trace information)	
Colon	327
Colors	
Assigning to object	288
Configuring 288,	290
Display	
Editing	286
Predefined	
Print	

Drinting	200
Printing	
Restoring	
Screen	
User-defined	
User-specific	
Comma	
Command sequence	
Recommendation	349
Remote	
Commands	
Brackets	
Colon	
Comma	
Command line structure	
Common	
Double dagger	
GBIP, addressed	
GBIP, universal	
Instrument control	
Overlapping	
Question mark	
Quotation mark	
SCPI confirmed	
Sequential	
Syntax elements	
Tracking	
Vertical stroke	
White space	
Comment	
Limit lines	238
Screenshots	
Softkey	
Common commands	
Syntax	
Syntax Compatibility	
Compatibility	
Compatibility Limit lines	
Compatibility Limit lines Computer name	
Compatibility Limit lines Computer name CONDition	
Compatibility Limit lines Computer name CONDition Connector	
Compatibility Limit lines Computer name CONDition Connector AC power supply	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT Baseband Input	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT Baseband Input	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT Baseband Input Display Port DVI	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT Baseband Input Display Port DVI GPIB interface	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT Baseband Input Display Port DVI GPIB interface IF/VIDEO/DEMOD	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT Baseband Input Display Port DVI GPIB interface IF/VIDEO/DEMOD LAN	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT Baseband Input Display Port DVI GPIB interface IF/VIDEO/DEMOD LAN Noise source	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT Baseband Input Display Port DVI GPIB interface IF/VIDEO/DEMOD LAN Noise source Power sensor	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT Baseband Input Display Port DVI GPIB interface IF/VIDEO/DEMOD LAN Noise source	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT Baseband Input Display Port DVI GPIB interface IF/VIDEO/DEMOD LAN Noise source Power sensor	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT Baseband Input Display Port DVI GPIB interface IF/VIDEO/DEMOD LAN Noise source Power sensor Probe power REF INPUT	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT Baseband Input Display Port DVI GPIB interface IF/VIDEO/DEMOD LAN Noise source Power sensor Probe power REF INPUT USB	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT Baseband Input Display Port DVI GPIB interface IF/VIDEO/DEMOD LAN Noise source Power sensor Probe power REF INPUT USB Connectors	
Compatibility Limit lines Computer name CONDition Connector AC power supply AUX PORT Baseband Input Display Port DVI GPIB interface IF/VIDEO/DEMOD LAN Noise source Power sensor Probe power REF INPUT USB Connectors EXT REF	232, 237 353 334 46 47 43 43 46 46 46 48 48 47 47 43 42 42 42 42 42 42 42 42 49 46
Compatibility Limit lines Computer name	
Compatibility Limit lines Computer name	232, 237 353 334 46 47 43 43 46 46 48 47 46 48 47 47 43 42 42 42 42 42 42 42 42 42 42 42 42 42
Compatibility Limit lines Computer name	
Compatibility Limit lines Computer name	
Compatibility Limit lines Computer name	
Compatibility Limit lines Computer name	232, 237 353 334 46 47 47 43 46 46 48 48 47 46 48 48 47 47 46 48 48 47 47 46 48 43 42 42 42 42 42 42 42 42 42 42 42 42 42
Compatibility Limit lines Computer name CONDition Connector AC power supply Baseband Input Display Port DVI GPIB interface IF/VIDEO/DEMOD LAN Noise source Power sensor Probe power REF INPUT USB Connectors EXT REF External generators for External Mixer OCXO Probe Power REF OUTPUT REF INPUT	
Compatibility Limit lines Computer name	
Compatibility Limit lines Computer name CONDition Connector AC power supply Baseband Input Display Port DVI GPIB interface IF/VIDEO/DEMOD LAN Noise source Power sensor Probe power REF INPUT USB Connectors EXT REF External generators for External Mixer OCXO Probe Power REF OUTPUT REF INPUT Signal source output SYNC TRIGGER	232, 237 353 334 46 47 43 43 46 46 48 48 47 47 46 48 48 47 47 46 48 48 47 42 42 42 42 42 42 42 42 42 42 42 42 42
Compatibility Limit lines Computer name	232, 237 353 334 46 47 43 43 46 46 48 48 47 47 46 48 48 47 47 46 48 49 49 46 48 43 42 42 42 42 42 42 42 42 42 42 42 42 42
Compatibility Limit lines Computer name	
Compatibility Limit lines Computer name	
Compatibility Limit lines Computer name	

Continue single sweep		
Softkey	. 108,	110
Continuous Sequencer		
Softkey		105
Continuous sweep		
Softkey	. 108,	110
Conventions		
SCPI commands		383
Conversion loss		
External Mixer (remote)	. 419,	420
Conversion loss tables		
Available (remote)		.424
Band (remote)		424
Bias (remote)		424
Configuring		
Deleting (remote)		425
External Mixer	. 131,	136
External Mixer (remote)		420
Harmonic order (remote)		426
Importing (External Mixer)		139
Mixer type (remote)		426
Saving (External Mixer)		142
Selecting (remote)		427
Shifting values (External Mixer)		142
Values (External Mixer)		
Copying		
Channel (remote)		389
Traces		214
Count (channel bar)		76
Cross-correlation		
Cursor keys		40
Customer support		

### D

ASCII       524         Binary       524         Remote       520, 521         Data sheets       19         Date       283         Format       283         Instrument setting       284         Instrument setting       282         Setting       31         Date and Time       263         Printing       263         DC connectors       165         DC power       165         DC source       178         Fix       178         Sweep       178         Tuning       178         DCL       319         Debugging       633         Decimal separator       212         DEF       325         Default       Restoring settings       244         Default       244
Remote       520, 521         Data sheets       19         Date       283         Format       283         Hiding/restoring       284         Instrument setting       282         Setting       31         Date and Time       263         Printing       263         DC connectors       165         DC power       165         DC source       178         Fix       178         Sweep       178         DCL       319         Debugging       633         Decimal separator       172         Trace export       212         DEF       325         Default       Restoring settings       244
Data sheets19DateFormat283Hiding/restoring284Instrument setting282Setting31Date and Time263Printing263DC connectors165DC power165DC source165Fix178Sweep178Tuning178DCL319Debugging633Decimal separator212DEF325Default244
DateFormat283Hiding/restoring284Instrument setting282Setting31Date and Time263Printing263DC connectors165DC power165DC source165Fix178Sweep178Tuning178DCL319Debugging633Decimal separator212DEF325Default25Default244
Format283Hiding/restoring284Instrument setting282Setting31Date and Time263DC connectors165DC power165DC source165Fix178Sweep178Tuning178DCL319Debugging633Decimal separator212DEF325Default325Default244
Hiding/restoring284Instrument setting282Setting31Date and Time263Printing263DC connectors165DC power165DC source165Fix178Tuning178DCL319Debugging633Decimal separator712Trace export212DEF325Default244
Instrument setting282Setting31Date and Time263Printing263DC connectors165DC power165DC source165Fix178Tuning178DCL319Debugging633Decimal separator712Trace export212DEF325Default224
Instrument setting282Setting31Date and Time263Printing263DC connectors165DC power165DC source165Fix178Tuning178DCL319Debugging633Decimal separator712Trace export212DEF325Default224
Date and Time         263           DC connectors         165           DC power         165           DC source         178           Fix         178           Tuning         178           DCL         319           Debugging         633           Remote control programs         633           Decimal separator         172           Trace export         212           DEF         325           Default         244
Date and Time         263           DC connectors         165           DC power         165           DC source         178           Fix         178           Tuning         178           DCL         319           Debugging         633           Remote control programs         633           Decimal separator         172           Trace export         212           DEF         325           Default         244
DC connectors         165           DC power         165           DC source         178           Fix         178           Sweep         178           Tuning         178           DCL         319           Debugging         633           Remote control programs         633           Decimal separator         212           DEF         325           Default         244
DC connectors         165           DC power         165           DC source         178           Fix         178           Sweep         178           Tuning         178           DCL         319           Debugging         633           Remote control programs         633           Decimal separator         212           DEF         325           Default         244
DC power       165         DC source       Fix         Fix       178         Sweep       178         Tuning       178         DCL       319         Debugging       633         Decimal separator       212         DEF       325         Default       244
Fix       178         Sweep       178         Tuning       178         DCL       319         Debugging       633         Decimal separator       633         Trace export       212         DEF       325         Default       Restoring settings         244
Sweep178Tuning178DCL319Debugging633Decimal separator7Trace export212DEF325DefaultRestoring settings244
Sweep178Tuning178DCL319Debugging633Decimal separator7Trace export212DEF325DefaultRestoring settings244
Tuning178DCL319Debugging833Remote control programs633Decimal separator71Trace export212DEF325Default825Restoring settings244
DCL
Debugging Remote control programs
Remote control programs       633         Decimal separator       7         Trace export       212         DEF       325         Default       244
Decimal separator Trace export
Trace export
DEF
Default Restoring settings
Restoring settings
5 5
Remote
Deleting
Limit line values
Delta markers
Defining

Device	
Softkey	268
Device ID	305
Device-specific commands	321
DHCP	
Diagnostics	
Hardware	309
Diagram area	
Status display	80
Trace information	
Diagram footer	
Hiding/restoring	
Diagram scale	
Dialog boxes	145
5	96
Slider	
Transparency	80
Dialogs	
Printing2	
Suppressing file selection	266
Display	
Colors	
Config (Softkey) 1	
Evaluation bar93, 1	196
Evaluation methods 1	93
Information	.74
Settings2	281
SmartGrid 90, 1	193
Theme	286
Update (remote)	356
Update rate	
Display Port	
Connector	46
Displayed items	
Touchscreen	283
DNS server	
IP Address	365
Double dagger	
DOWN	
Duplicating	,20
Channel (remote)	280
DVI	109
Connector	16
	40

### Е

RF OVLD			
UNCAL			
UNLD			
WRONG_FW 82,			
ESD			
ESE (event status enable register )			
ESR (event status register)			337
Evaluation			
Modes			
Modes, adding		93,	196
Evaluation bar			
Using		93,	196
Evaluation methods			
Remote			501
EVENt			
Event status enable register (ESE)			
Remote			385
Event status register (ESR)		.333,	337
Remote			
Export format			
Traces			216
Exporting			
Data			259
Functions			252
I/Q data			
Measurement settings			
Softkey			
Trace data			
Traces			
EXREF (status display)			
EXT REF			
Status message			80
External generators			48
External Mixer			
Activating (remote)		0,	423
Band			
Bias current			
Conversion loss			136
Conversion loss tables			
Frequency range	. 101,	129	134
General information		. 120,	120
Handover frequency			
Harmonic Order			
Harmonic Type			
Name			
Range			
Restoring bands			
RF overrange RF Start/RF Stop			
•			
Serial number			
Type		141,	421
External monitor			40
Connectors			. 40
External reference			~~ 4
Frequency			
Input			
Loop bandwidth			
Missing			
Output			
Settings			
Status message			
Tuning range			294

### F

File format	
Export Files	216
Trace export	
File type	
Storage settings	254
filename	
Data files	252
Settings25	4, 256
Firmware	
Updating	299
Firmware Update	
Remote control	604
Firmware updates	
see User Manual	20
Focus	
Changing	86
Format	
Data	524
Data (remote)52	0, 521
Date and time	283
see also File format	216
Frequency	
External reference	294
Offset	149
Reference	
Frequency (channel bar)	76
Frequency range	
Extending	
External Mixer	129
Frequency response	
Frequency search	148
Front panel	
Hiding/restoring	284
Frontend	
Temperature	
Temperature (remote)	
Temperature, status bit	
Full screen mode	37
Function keys	
Details - see user manual	
Overview	38

### G

GET	
Getting started	
GPIB	
Address	355, 368
Characteristics	
interface messages	
Language (remote control)	598
Settings	354
Terminator	356
GPIB bus control	
Remote	
GPIB interface	
Configuring - see User Manual	48
Connector	48
Remote control	96
GTL	319

### Н

External Mixer	124
External Mixer (remote)	
Hard drive	40
Hardware	000
Check	
Diagnostics	
Information	
Supported	. 299
Harmonics	
Conversion loss table	. 140
External Mixer (remote)	. 419
LO	. 129
Order (External Mixer)	. 136
Type (External Mixer)	
Hiding/restoring	
Display items	283
HiSLIP	
Protocol	
Resource string	
Resource string	. 515
1	
1	
	356
I/O Logging	. 356
I/Q Analyzer	
I/Q Analyzer Application	
I/Q Analyzer Application I/Q data	. 100
I/Q Analyzer Application I/Q data Exporting	. 100
I/Q Analyzer Application I/Q data Exporting Identification	. 100 . 259
I/Q Analyzer Application I/Q data Exporting Identification Remote	. 100 .259 . 386
I/Q Analyzer Application I/Q data Exporting Identification Remote String, R&S FSWP	. 100 . 259 . 386 . 355
I/Q Analyzer Application I/Q data Exporting Identification Remote String, R&S FSWP String, resetting (R&S FSWP)	. 100 . 259 . 386 . 355
I/Q Analyzer Application I/Q data Exporting Identification Remote String, R&S FSWP String, resetting (R&S FSWP) IEC/IEEE bus	. 100 . 259 . 386 . 355 . 355
I/Q Analyzer Application I/Q data Exporting Identification Remote String, R&S FSWP String, resetting (R&S FSWP)	. 100 . 259 . 386 . 355 . 355
I/Q Analyzer Application I/Q data Exporting Identification Remote String, R&S FSWP String, resetting (R&S FSWP) IEC/IEEE bus	. 100 . 259 . 386 . 355 . 355 . 312
I/Q Analyzer Application I/Q data Exporting Identification Remote String, R&S FSWP String, resetting (R&S FSWP) IEC/IEEE bus see GPIB IECWIN IF OVLD	. 100 . 259 . 386 . 355 . 355 . 312 . 350
I/Q Analyzer Application I/Q data Exporting Identification Remote String, R&S FSWP String, resetting (R&S FSWP) IEC/IEEE bus see GPIB IECWIN	. 100 . 259 . 386 . 355 . 355 . 312 . 350
I/Q Analyzer Application I/Q data Exporting Identification Remote String, R&S FSWP String, resetting (R&S FSWP) IEC/IEEE bus see GPIB IECWIN IF OVLD	. 100 . 259 . 386 . 355 . 355 . 312 . 350
I/Q Analyzer Application I/Q data Exporting Identification Remote String, R&S FSWP String, resetting (R&S FSWP) IEC/IEEE bus see GPIB IECWIN IF OVLD Error	. 100 . 259 . 386 . 355 . 355 . 312 . 350 , 631
I/Q Analyzer Application I/Q data Exporting Identification Remote String, R&S FSWP String, resetting (R&S FSWP) IEC/IEEE bus see GPIB IECWIN IF OVLD Error	. 100 . 259 . 386 . 355 . 355 . 312 . 350 , 631 47
I/Q Analyzer Application I/Q data Exporting Identification Remote String, R&S FSWP String, resetting (R&S FSWP) IEC/IEEE bus see GPIB IECWIN IF OVLD Error	. 100 . 259 . 386 . 355 . 355 . 312 . 350 , 631 47
I/Q Analyzer Application	. 100 . 259 . 386 . 355 . 355 . 312 . 350 , 631 47 . 319
I/Q Analyzer Application I/Q data Exporting Identification Remote String, R&S FSWP String, resetting (R&S FSWP) IEC/IEEE bus see GPIB IECWIN IF OVLD Error	. 100 . 259 . 386 . 355 . 312 . 350 . 631 47 . 319 . 252

Information

INPUT OVLD

Inserting

Installing

Instrument name

Instrument settings

Input

Integrated Measurements	158
Remote Configuration	462
Intended use	17
Interface messages	321
Interfaces	
GPIB	317
LAN	312
USB	319
Interrupt	346
Invalid results	
Remote control	329
IP address	313
Assigning	364
Network	354
IP Address	
DNS server	365
IP configuration	
LAN	368
IST	
IST flag	337
Remote	386
Items	
Saving	251
Settings	254

### Κ

Кеу	
Power	
Redo	41
Undo	41
Keyboard	
On-screen	85
Keypad	87
Key layout	
Overview	
Keys	
MKR	
MKR ->	229
MKR →	231
Peak Search	
PRESET	244
RUN CONT	108, 110
RUN SINGLE	108, 109, 110
Keywords	
see Mnemonics	

### L

LAN

# Configuration359Configuration - see user Manual20Configuring366Connector46Interface312IP address313LAN configuration368Password360Ping368Remote control interface311Reset360Settings358VISA313VXI protocol314Web browser interface366Legacy format366

Level (channel bar) Level offset	76
Level search	
LEVELSEAICH	
GPIB terminator	356
Limit check	000
Activating/Deactivating	240
Results	
Limit lines	
Activating/Deactivating	
Comment	
Compatibility	
Compatible	
Copying	
Creating	
Data points	
Deactivating	
Defining	
Deleting	
Deleting values	
Details	
Editing	
Inserting values	
Managing	
Name	
Offsets	
Recalling	
Saving	
Shifting	
Storing2	
Threshold	
Traces	
View filter	
Violation	
Visibility	
X-axis	
Y-axis	239
Lines	
Configuration	
Limit, see Limit lines 2	236
Linking	
Markers	
LLO	319
LO	
Harmonics	
Level (External Mixer)	137
Error	
LO UNL (status display)6	531
Loading	
Functions2	
Instrument settings	
Settings	248
Logging	
Remote control programs6	633
Login	
Network	369
Logo	
Printing	262
Loop bandwidth	
External reference 2	294
LOUNL	
Error	82
M	
Maintenance6	528

Violation
Marker
Information
Marker table
Evaluation method
Information
Marker to Trace
Markers
Assigned trace
Basic settings226
Configuration 226, 228
Deactivating
Delta markers
Linked
Linking
Minimum
Next minimum
Peak
Position
Positioning
State
Table
Table (evaluation method) 121
Tips
Туре 227
X-value
MAX
MAX (trace information)
Maximize
Window
Maximizing
Windows (remote)501
Meas Time (channel bar)
Measurement
Measurement Continuous
Measurement Continuous
Measurement Continuous
Measurement Continuous
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       89
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       89
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurement time       153         Measurements       153
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurement time       153         Measurements       193
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurement time       153         Measurements       193         Evaluation methods       193
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurement time       153         Measurements       193         Menus       60         Context-sensitive       85
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurement time       153         Measurements       193         Evaluation methods       193         Menus       85         Messages       85
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurement time       153         Measurements       193         Evaluation methods       193         Menus       85         Context-sensitive       85         Messages       201         Commands       321
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurement time       153         Measurements       193         Evaluation methods       193         Menus       85         Context-sensitive       85         Messages       321         Instrument       321
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurements       153         Evaluation methods       193         Menus       20         Context-sensitive       85         Messages       321         Instrument       321         Instrument responses       322
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurements       153         Measurements       193         Menus       20         Context-sensitive       85         Messages       321         Instrument       321         Instrument responses       322         Interface       321
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurements       153         Evaluation methods       193         Menus       20         Context-sensitive       85         Messages       321         Instrument       321         Instrument responses       322         Interface       321         Microsoft Windows       321
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurements       153         Measurements       193         Menus       20         Context-sensitive       85         Messages       321         Instrument       321         Instrument responses       322         Interface       321         Microsoft Windows       26
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurement time       153         Measurements       193         Evaluation methods       193         Menus       201         Context-sensitive       85         Messages       321         Instrument       321         Instrument responses       322         Interface       321         Microsoft Windows       26         Access       26
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurement time       153         Measurements       193         Evaluation methods       193         Menus       201         Context-sensitive       85         Messages       321         Instrument responses       322         Interface       321         Microsoft Windows       26         Access       26         MIN       325         MIN (trace information)       77
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurement time       153         Measurements       193         Evaluation methods       193         Menus       201         Context-sensitive       85         Messages       321         Instrument responses       322         Interface       321         Microsoft Windows       26         Access       26         MIN       325         MIN (trace information)       77         Mini front panel       77
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurement time       153         Measurements       193         Evaluation methods       193         Menus       201         Context-sensitive       85         Messages       321         Instrument responses       322         Interface       321         Microsoft Windows       26         Access       26         MIN       325         MIN (trace information)       77
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurement sequence       153         Measurements       193         Evaluation methods       193         Menus       201         Context-sensitive       85         Messages       321         Instrument responses       322         Interface       321         Microsoft Windows       26         Access       26         MIN       325         MIN (trace information)       77         Mini front panel       Hiding/restoring         Hiding/restoring       285
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurements       153         Evaluation methods       193         Menus       193         Context-sensitive       85         Messages       20         Commands       321         Instrument       322         Interface       321         Microsoft Windows       226         MIN       325         MIN (trace information)       77         Mini front panel       11         Hiding/restoring       285         Key combination       286         Using       292         Minimum       231
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurements       153         Evaluation methods       193         Menus       201         Context-sensitive       85         Messages       221         Instrument       321         Instrument responses       322         Interface       321         Microsoft Windows       24         Access       26         MIN       325         MIN (trace information)       77         Mini front panel       101         Hiding/restoring       285         Key combination       286         Using       292
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurements       153         Evaluation methods       193         Menus       193         Context-sensitive       85         Messages       20         Commands       321         Instrument       322         Interface       321         Microsoft Windows       226         MIN       325         MIN (trace information)       77         Mini front panel       11         Hiding/restoring       285         Key combination       286         Using       292         Minimum       231
Measurement       108         Continuous       108         Performing       108         Single       108         Measurement channels       108         Activating       89         Closing       90         Measurement range       149         Measurement sequence       157         Measurement time       153         Measurements       193         Evaluation methods       193         Menus       201         Context-sensitive       85         Messages       221         Instrument       321         Instrument responses       322         Interface       321         Microsoft Windows       226         MIN       325         MIN (trace information)       77         Mini front panel       141         Hiding/restoring       285         Key combination       286         Using       292         Minimum       231

MKR ->	
Key	
MKR →	
Key	231
Mnemonics	
Optional	
Monitor	
External	
Settings	
Multiple zoom	
MultiView	
Status display	80
Tab	

### Ν

Name	
Limit lines	238
NAN	325
NAN (not a number)	
Remote control	. 329
Navigation control	40
NCor (enhancement label)	77
Network	
Auto-login	370
Changing user passwords	. 370
Configuration (dialog box)	354
Configuring	, 363
Connecting the instrument	
Creating users	
DNS server	. 365
Login	. 369
Operating the instrument	. 369
Setting up	362
Settings	
Sharing directories	372
Next Minimum	. 232
Marker positioning	. 232
Next Peak	231
Marker positioning	. 231
NINF	325
NO REF	
Error82	, 631
Noise	
Saving settings	. 251
Source	. 172
Noise Figure	
Application	. 100
Noise source	
Connector	43
NTRansition	. 334
Numeric parameters	, 325
Numeric values	
Special	. 325

### 

OCXO	
Offset	
level	144
Limit lines	
Offset frequency	
On-screen keyboard	
Online keyboard	
Operating mode	
Presetting	
Operating temperature	

Operation complete	
Remote	386
Options	
Identification (remote)	386
Information	
Installing	297, 298
Secure user mode (K33)	
Orientation	
Screenshot	
Output	172
Buffer	333
External reference	295
Noise source	172
Signal source (optional)	168
OVEN	
Error	631
OVEN (status display)	82
OVENCOLD	
Error	631
OVENCOLD (status display)	631
Overlapping commands	330
Preventing	331

### Ρ

Parallel poll register enable	
Remote	387
Parameters	
Block data	327
Boolean	.326
Entering 80	ð, 87
Numeric values	
SCPI	324
Special numeric values	325
String	
Text	
Password	
Secure user mode	302
Passwords	
Changing	370
Secure user mode	
Service functions	309
Peak excursion	.230
Peak list	
Peak excursion	230
Peak search	
Key	.231
Mode	
Peaks	
Marker positioning	231
Next	
Softkey	
Phase Noise	
Application	99
Phase response	
Ping	
PN (trace information)	
PN + AM (trace information)	
PN Transient analysis	
Ports	
External Mixer (remote)	421
User	442
Position	
Limit line values	239
Power key	37
Power seonsors	

Power supply	
Connector	. 46
PPC	
PPE register	337
PPU	319
Preset	
Bands (External Mixer, remote)	418
channel settings	245
External Mixer	135
Key	244
Recalling settings	
Presetting	
Channels	125
Pretrigger	
Print Screen	
Softkey	264
Printer	
Selecting	266
Printer configuration	
see user Manual	. 20
Printers	
Installing	267
Printing	
Colors	290
Medium	
Screenshots	
Probe power	
Product IDs	
Programming examples	020
Sequencer	395
Service request	
Protocol	010
VXI	314
PSA emulation	
PSA89600	010
Wideband	358
PTRansition	
Pulse	554
Application	101
Pushing measurements	
	100

### Q

Queries	
Status	
Question mark	
Quick recall	
Settings	
Quick save	
Secure user mode	249, 250
Settings	
Quotation mark	

### R

R&S FSP	00
Emulating (remote) 5 R&S FSQ	90
Emulating (remote)	98
R&S FSU	
Emulating (remote)5	98
R&S FSV	
Emulating (remote)5	98
R&S Support	04
Rackmounting	24
RBW	54
RBW (channel bar)	76

Ready for trigger Status register
Rebooting Remote control
Recalling Settings
Settings for preset
Softkey
Remote control programming
REF INPUT Connector
Reference External
Frequency
Internal
Softkey
Reference frequency
Default
Input
Output
Reference level
External Mixer 133
Reference marker 227
Registers
Relay Cycle Counter 310
Release notes
Remote control
Blocked
Errors
Ignored commands
Interfaces
Protocols
Sequential commands
Remote Desktop
Client
Ending session
Setting up a connection
Setting up controller
Setting up instrument
Remote display
Update 356
Remote operation
Configuring
Dedotiveling the instrument
GPIB address
see also Remote control
Setting up
Settings
Starting
Stopping
Removable hard drive
Reset values
Remote
Residual effects
Remote Configuration
Resolution bandwidth
Restoring
Channel settings
Restricted operation Secure user mode
Restrictions
Storage space
J

Result displays	
Marker table	121
Programming example	
Results	
Data format (remote) 520,	521
Displaying	88
Exporting	
Managing	244
RF input	
RF overrange	
External Mixer	421
RF OVLD	
Error	631
RF OVLD (status display) 82,	631
Rotary knob	40
RUNCONT	
Key	110
RUN SINGLE	
Key 108, 109,	110

### S

Safety information		17
Safety instructions		19
Save/Recall Mode		
Settings		254
Savesets		
Settings		250
Saving		
Classified data	31	245
Data types		
Functions		
Instrument settings		
Limit lines		
Screenshots		
Settings		
Softkey	• • • • • • • • •	252
Scale		
Y-axis		145
SCPI		~~ 4
Parameters		
Syntax		
version		
SCPI confirmed commands		321
Screen		
See Touchscreen		287
Screenshots		
Printing	264,	269
Saving	264,	269
SDC		319
Search		
Frequency		148
Level		144
Searching		
Configuration		229
Secure user mode		
Activating		302
Activating/deactivating		
Background information		
Instrument settings		
Passwords		
Quick save		
Redirecting storage		
Redifecting storage		
Restricted operation		
Self-alignment	351,	352

Self-alignment data			
Storage location			
SecureUser			
Select Marker			
Self-alignment			
Aborting			
Secure user mode 32, 246, 278, 297,			
Starting			278
Self-test			
Performing			
Remote			
Results			
Settings			
Temperature			
Sequencer			
Aborted			
Activating (remote)			
Channels			
Example			
Mode			
Programming example			
Remote			
Run Single			
Setting up Single Sweep			
Softkey			
•			
State			105
Sequences Aborting (remote)			303
Mode (remote)			
Sequential commands			
Errors			
Service functions			
	505,		000
Numeric mode			
Numeric mode Passwords			308
Passwords		·····	308 309
Passwords Results			308 309 309
Passwords Results Service manual			308 309 309 . 18
Passwords Results Service manual Service request (SRQ)	333,	336,	308 309 309 . 18 346
Passwords Results Service manual Service request (SRQ)	333,	 336, 333,	308 309 309 . 18 346 336
Passwords Results Service manual Service request (SRQ)	333,	336, 333,	308 309 309 . 18 346 336 387
Passwords Results Service manual Service request (SRQ)	333,	336, 333,	308 309 309 . 18 346 336 387
Passwords Results Service manual Service request (SRQ)	333,	336, 333,	308 309 309 . 18 346 336 387 321
Passwords Results Service manual Service request (SRQ)	333,	336, 333, 254,	308 309 309 . 18 346 336 387 321 256
Passwords Results Service manual Service request (SRQ)	333,	336, 333, 254,	308 309 309 . 18 346 336 387 321 256 256
Passwords Results Service manual Service request (SRQ)	333,	336, 333, 254,	308 309 309 . 18 346 336 387 321 256 256 244
Passwords Results Service manual Service request (SRQ)	333,	336, 333, 254, 247,	308 309 309 346 336 387 321 256 256 244 248
Passwords Results	333,	336, 333, 254, 247,	308 309 309 . 18 346 336 387 321 256 256 244 248 247
Passwords Results Service manual Service request (SRQ)	333,	336, 333, 254, 247, 247,	308 309 309 . 18 346 336 387 321 256 256 244 248 247 256
Passwords Results Service manual Service request (SRQ)	333,	336, 333, 254, 247, 251, 253,	308 309 309 . 18 346 336 387 321 256 244 248 247 256 256
Passwords Results	333,	336, 333, 254, 247, 251, 255, 247,	308 309 309 . 18 346 336 337 321 256 244 248 247 256 256 256 248
Passwords Results	333,	254, 2254, 2251, 251, 253, 247,	308 309 309 . 18 346 336 321 256 244 248 247 256 248 247 256 248 76
PasswordsResults	333,	254, 2254, 2251, 251, 253, 247,	308 309 309 . 18 346 336 321 256 244 248 247 256 248 247 256 248 76
Passwords Results	333,	254, 2254, 2251, 251, 253, 247,	308 309 309 . 18 346 336 321 256 244 248 247 256 248 247 256 248 76
Passwords Results	333,	336, 333, 254, 247, 251, 253, 247,	308 309 . 18 346 336 321 256 256 244 248 247 256 248 247 256 248 76 240
Passwords	333,	254, 247, 251, 253, 247,	308 309 309 . 18 346 336 256 244 256 244 247 256 248 247 256 248 76 240 240
Passwords	333,	254, 247, 251, 253, 247,	308 309 309 . 18 346 336 256 244 256 244 247 256 248 247 256 248 76 240 240
Passwords	333,	254, 247, 251, 253, 247,	308 309 309 . 18 346 336 321 256 256 244 248 247 256 256 248 76 240 240 234
Passwords	333,	254, 247, 251, 247, 251, 247,	308 309 309 . 18 346 336 321 256 254 244 248 256 256 248 2.76 240 240 240 240 234 279
Passwords	333,	336, 333, 254, 247, 251, 253, 247,	308 309 309 . 18 346 336 256 256 244 248 247 256 256 248 247 256 256 248 247 240 240 240 240 240 240
Passwords	333,	336, 333, 254, 247, 251, 253, 247,	308 309 309 . 18 336 337 321 256 256 244 248 247 256 248 247 256 248 76 240 234 234 279 580 148
Passwords	333,	254, 2254, 2251, 2551, 2251, 247,	308 309 309 . 18 336 337 321 256 256 256 256 256 244 248 247 256 256 248 76 240 234 234 279 580 148 76
Passwords	333,	336, 333, 254, 247, 251, 253, 247,	308 309 309 . 18 336 337 321 256 256 244 248 247 256 248 247 256 248 76 240 234 279 580 148 76
Passwords	333,	254, 2254, 2251, 2551, 2251, 247,	308 309 309 . 18 336 337 321 256 256 244 248 247 256 248 247 256 248 76 240 234 279 580 148 76 144 76
Passwords	333,	336, 333, 254, 247, 251, 253, 247,	308 309 309 . 18 346 336 256 2248 247 256 248 247 256 248 247 256 248 76 240 234 279 580 148 76 144 76

Single Sequencer	
Softkey	105
Single sweep Softkey	100
•	
Single zoom 198, SmartGrid	199
Activating	106
Activating	
Display	
Evaluation bar	
Features	
Mode	
Programming example	
Smoothing	
Traces	
Soft front panels	204
Using	291
Softkey bar	201
Hiding/restoring	284
Softkeys	204
Clear All Messages (remote control)	604
Comment	
Continue single sweep	
Continue Single Sweep	
Continuous Sequencer	
Continuous sweep	
Continuous Sweep	
Device	
Display Config	
Export	
Export config	
I/Q Export	
Import	
Install Printer	
Line Config	
Marker Config 226	
Marker Config	228
Marker to Trace	228 228
Marker to Trace	228 228 231
Marker to Trace Min Next Min	228 228 231 232
Marker to Trace Min Next Min Next Peak	228 228 231 232 231
Marker to Trace Min Next Min Next Peak Norm/Delta	228 228 231 232 231 231 .227
Marker to Trace Min Next Min Next Peak Norm/Delta Peak	228 228 231 232 231 231 227 .227
Marker to Trace Min Next Min Next Peak Norm/Delta Peak Print Screen	228 228 231 232 231 227 .227 .231 264
Marker to Trace Min Next Min Next Peak Norm/Delta Peak Print Screen R&S Support	228 228 231 232 231 227 231 264 304
Marker to Trace Min Next Min Next Peak Norm/Delta Peak Print Screen	228 228 231 232 231 227 231 264 304 252
Marker to Trace Min Next Min Next Peak Norm/Delta Peak Print Screen R&S Support Recall Recall File	228 228 231 232 231 227 231 264 304 252
Marker to Trace Min Next Min Next Peak Norm/Delta Peak Print Screen R&S Support Recall Recall File	228 231 232 231 227 231 264 304 252 255 292
Marker to Trace Min Next Min Next Peak Norm/Delta Peak Print Screen R&S Support Recall Recall File	228 231 232 231 227 231 264 304 252 255 292 255
Marker to Trace Min Next Min Next Peak Norm/Delta Peak Print Screen R&S Support Recall Recall File	228 231 232 231 227 231 264 304 252 255 292 255 292 252 254
Marker to Trace           Min           Next Min           Next Peak           Norm/Delta           Peak           Print Screen           R&S Support           Recall           Reference           Save           Save File	228 231 232 231 227 231 264 304 252 255 292 255 292 252 252 254 229
Marker to Trace	228 231 232 231 227 231 264 304 252 255 292 255 292 255 292 254 229 228
Marker to Trace	228 228 231 232 231 227 231 264 304 252 255 292 252 252 254 229 228 105
Marker to Trace	228 228 231 227 231 264 304 252 255 292 255 292 254 229 2254 229 228 105
Marker to Trace	228 228 231 232 231 264 304 252 255 292 255 292 252 254 229 228 105 105 108
Marker to Trace	228 228 231 232 231 264 304 252 255 292 252 254 229 225 254 229 228 105 105 108 109 255
Marker to Trace         Min         Next Min         Next Peak         Norm/Delta         Peak         Print Screen         R&S Support         Recall         Recall File         Save         Save File         Search Config         Select Marker         Sequencer         Single Sequencer         Single Sweep         Startup Recall (On/Off)	228 228 231 232 231 264 304 255 255 255 252 255 105 108 109 255 255
Marker to Trace	228 228 231 232 231 264 304 255 255 255 252 255 105 108 109 255 255
Marker to Trace	228 228 231 232 231 264 304 252 255 252 252 252 252 254 229 228 105 105 108 109 255 255 84 157
Marker to Trace         Min         Next Min         Next Peak         Norm/Delta         Peak         Print Screen         R&S Support         Recall         Recall File         Save         Save File         Search Config         Select Marker         Sequencer         Single Sequencer         Single Sequencer         Single Sweep         Startup Recall (On/Off)         Status         Sweep Count         System Messages (remote control)	228 228 231 232 231 264 304 252 255 252 252 252 254 229 228 105 105 108 109 255 255 84 157 604
Marker to Trace	228 228 231 232 231 227 231 264 252 255 252 255 255 205 255 205 255 255
Marker to Trace	228 228 231 232 231 264 252 255 252 252 252 252 252 255 105 105 108 109 255 255 255 255 255 255 255 255 255 25
Marker to Trace	228 228 231 232 231 264 252 255 252 252 254 229 228 105 108 109 255 255 255 255 255 255 255 255 255 25
Marker to Trace	228 228 231 232 231 264 252 255 252 252 255 255 105 105 105 105 105 105 105 105 105 1
Marker to Trace	228 228 231 232 231 264 252 255 252 252 254 229 228 105 108 109 255 255 255 255 255 255 255 255 255 25

Specifics for	
Configuration	125
Spectrum	
Application	100
Spectrum Monitor	
Application	99
Split	~ -
Window	
Split screen mode	. 37
Splitters	~ .
Window size	
Spot noise	
Spur Color	
Spur removal	
Spurious Color	163
Spurious Measurements	404
Application	
SRE (service request enable register)	336
SRQ (service request)	346
Start frequency	149
Startup recall	
Remote	562
Startup Recall	~
Softkey	255
Status	~
Queries	348
Status bar	~~~
Color coding81,	
Error messages	630
Hiding/restoring	
Secure user mode	246
Status byte	~~~
Remote	
Status byte (STB)	336
Status byte register (STB)	
Status display	
Status registers	
CONDition	
ENABle	
EVENt	
model	
NTRansition	
parts	
PTRansition	
STATus:OPERation	
STATus:QUEStionable	
STATus:QUEStionable:ACPLimit	
STATus:QUEStionable:EXTended	
STATus:QUEStionable:EXTended:INFO	
STATus:QUEStionable:FREQuency	342
STATus:QUEStionable:LIMit	
STATus:QUEStionable:LMARgin	
STATus:QUEStionable:POWer	
STATus:QUEStionable:POWer:DCPNoise	344
STATus:QUEStionable:POWer:PNOise	
STATUS:QUEStionable:TEMPerature	
STATUS:QUEStionable:TEMPerature	
STATus:QUEStionable:TIMe	
Status reporting system	
Application	
Stop frequency	149
Storage location	050
Data files	
Secure user mode	200
Settings	
-	
Storage settings File type	256

In	d	ex
		-

Storing	
Settings	
String in remote commands	326
Subnet Mask	354
Suffixes	323
Common	384
Supply voltage	165
Support	635
Information	304
Suppressing	
File name dialog	266
Sweep	
Aborting	109, 110
Mode	108
Sweep Count	157
Sweep direction	157
Sweep range	178
Sweep status	
Status register	338
Sweep voltage	178
SYNC TRIGGER	
Connector	47
Syntax elements	
SCPI	327
System	
Configuration	296
Messages	298
Preset operating mode	302
System keys	
т	

Table		
Half decades		157
Tabs		
All		89
MultiTab		. 75
MultiView		
Switching		. 75
Technical support		
Temperature		
Check		276
Check (remote)		
Frontend		
Frontend (remote)		
Frontend, status bit		
Self-alignment		
Self-alignment (remote)		
Status register		
Test setup		
Text paramters in remote commands		
Theme		520
Display	200	207
Threshold	200,	201
		000
Limit lines Time		233
		000
Format		
Hiding/restoring		
Instrument setting		
Setting		31
Toolbar		
Hiding/restoring		
Overview		83
touchscreen		
Alignment	276,	280

Touchscreen
Alignment277, 281
Colors
De-/Activating
Displayed items
Overview
Settings
Theme
Trace information
Trace number
Window title bar
Trace labels
Trace math
Settings
Trace mode
Trace offset
Trace smoothing
Traces
Configuration (Softkey)
Copying214
Copying (remote control) 518
Export format 212
Exporting210, 211, 215
Mode
Mode (remote) 512
Saving251
Traces to be Checked
Limit lines
Transducers
Recalling
Saving
Transient analysis
Transient Analysis
Application
Trigger
Event (remote)
External, errors
Holdoff
Input
Offset
Output
01.1
Status register
Troubleshooting
Troubleshooting File name error
Troubleshooting562File name error562Hardware309Low frequencies634Remote control programs356, 633Timeout for data capture634
Troubleshooting       562         File name error       562         Hardware       309         Low frequencies       634         Remote control programs       356, 633         Timeout for data capture       634         Trace display       634
Troubleshooting562File name error562Hardware309Low frequencies634Remote control programs356, 633Timeout for data capture634
Troubleshooting       562         File name error       562         Hardware       309         Low frequencies       634         Remote control programs       356, 633         Timeout for data capture       634         Trace display       634
Troubleshooting562File name error562Hardware309Low frequencies634Remote control programs356, 633Timeout for data capture634Trace display634Tuning176, 180
Troubleshooting562File name error562Hardware309Low frequencies634Remote control programs356, 633Timeout for data capture634Trace display634Tuning176, 180Tuning range178

### U

Ultra-Small RBWs	154
Error	82, 631
UNCAL (status display)	631
Undo	40, 41
UP	325
Update Path	
Remote control	604
Update rate	
Display	

Updating	
Firmware	
USB	
Address	
Connector	46
Interfaces	
USB port	
User ports	
Remote control	442
Users	
Network	
Password	370

### V

VCO measurements	
Vendor ID	,
Rohde & Schwarz	
Version information	297
Vertical stroke	
VIEW (trace information)	
View filter	
Limit lines	
VISA	
Libraries	
Resource string	
Visible	
Limit lines	
Volatile memory	
Secure user mode	
Voltage supply	
VSA (Vector Signal Analysis)	
Application	101
VXI protocol	

### W

Wait		
Remote		388
Waiting for trigger		
Status register		. 338
Warmup time		
Web browser		
Configuration interface		. 366
White papers		
White space		
Wideband		
PSA89600		. 358
Window title bar		77
Windows		
Adding		196
Adding (remote)		501
Arranging		197
Closing		
Closing (remote)		508
Configuring		
Dialog boxes		
Layout (remote)		505
Maximizing (remote)		
Querying (remote)		
Replacing (remote)		505
Size		94
Splitting (remote)		501
Types (remote)		
WRH (trace information)		
WRONG_FW		
Error	82, 275, 299,	631

### Χ

X-axis	
Limit lines	
X-value	
Marker	
XCORR	155
XCORR Factor (channel bar)	76

### Υ

Y-axis	
Limit lines	239
Scale	

## Ζ

Zooming	198,	200
Activating (remote)		511
Area (Multiple mode, remote)		510
Area (remote)		509
Deactivating		200
Multiple mode	198,	199
Multiple mode (remote)		511
Restoring original display		200
Single mode		