

R&S®SMA100B

RF Signal Generator

User Manual



1178383402
Version 10

ROHDE & SCHWARZ
Make ideas real



This document describes the R&S®SMA100B models, stock no. 1419.8888.02 and its options:

- R&S®SMAB-B1H
- R&S®SMAB-B28
- R&S®SMAB-B29
- R&S®SMAB-B32/-B34/-B35/-B36S/-B37/-B39
- R&S®SMAB-B80/-B85
- R&S®SMAB-B81/-B82
- R&S®SMAB-B86
- R&S®SMAB-B92/-B93
- R&S®SMAB-B103/-B106/-B112/-B120/-B131/-B140(N)/-B150(N)/-B167(N)
- R&S®SMAB-B709/-B710(N)/-B711(N)
- R&S®SMAB-K22/-K23/-K24/-K27
- R&S®SMAB-K25
- R&S®SMAB-K28
- R&S®SMAB-K31/-K33
- R&S®SMAB-K33/-K36/-K38/-K40
- R&S®SMAB-K40
- R&S®SMAB-K703
- R&S®SMAB-K704
- R&S®SMAB-K720/-K721
- R&S®SMAB-K722
- R&S®SMAB-K723
- R&S®SMAB-K724
- R&S®SMAB-K725
- R&S®SMAB-K726
- R&S®SMAB-K980

This manual describes firmware version FW 5.10.121.xx and later of the R&S®SMA100B.

© 2023 Rohde & Schwarz GmbH & Co. KG
Muehldorfstr. 15, 81671 Muenchen, Germany
Phone: +49 89 41 29 - 0
Email: info@rohde-schwarz.com
Internet: www.rohde-schwarz.com

Subject to change – data without tolerance limits is not binding.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG.

All other trademarks are the properties of their respective owners.

1178.3834.02 | Version 10 | R&S®SMA100B

Throughout this manual, products from Rohde & Schwarz are indicated without the ® symbol , e.g. R&S®SMA100B is indicated as R&S SMAB. Linux® is abbreviated as Linux.

Contents

1	Safety and regulatory information.....	15
1.1	Safety instructions.....	15
1.2	Labels on R&S SMA100B.....	18
1.3	Warning messages in the documentation.....	18
1.4	Where to find key documents on Rohde & Schwarz.....	18
1.5	Korea certification class A.....	19
2	Welcome.....	20
2.1	Key features.....	20
2.2	What's new.....	20
2.3	Documentation overview.....	20
2.3.1	Getting started manual.....	21
2.3.2	User manuals and help.....	21
2.3.3	Service manual.....	21
2.3.4	Instrument security procedures.....	21
2.3.5	Printed safety instructions.....	21
2.3.6	Data sheets and brochures.....	21
2.3.7	Release notes and open source acknowledgment (OSA).....	22
2.3.8	Application notes, application cards, white papers, etc.....	22
2.3.9	Videos.....	22
3	Getting started.....	23
3.1	Preparing for use.....	23
3.1.1	Lifting and carrying.....	23
3.1.2	Unpacking and checking.....	23
3.1.3	Choosing the operating site.....	23
3.1.4	Setting up the R&S SMA100B.....	24
3.1.5	Considerations for test setup.....	26
3.1.6	Connecting to power.....	27
3.1.7	Connecting to LAN.....	27
3.1.8	Connecting USB devices.....	28
3.1.9	Connecting to RF coaxial connectors.....	29
3.1.10	Connecting to RF 50 Ω.....	30

3.1.11	Connecting to Ref In/Ref Out.....	31
3.1.12	Switching on or off.....	31
3.2	Instrument tour.....	32
3.2.1	Front panel tour.....	32
3.2.2	Rear panel tour.....	40
3.3	Trying out the instrument.....	43
3.3.1	Generating an unmodulated carrier.....	44
3.3.2	Generating an RF frequency sweep signal.....	46
3.3.3	Saving and recalling settings.....	48
3.4	Instrument control.....	51
3.4.1	Possible ways to operate the instrument.....	52
3.4.2	Means of manual interaction.....	52
3.4.3	Understanding the display information.....	53
3.4.4	Accessing the functionality.....	56
3.4.5	Entering data.....	57
3.4.6	Getting information and help.....	59
3.4.7	Remote control.....	60
3.4.8	Remote operation over VNC.....	61
4	RF signal configuration.....	62
4.1	Activating RF signal output.....	63
4.2	How to set the frequency and level.....	63
4.3	Phase continuous frequency.....	65
4.3.1	How to generate a phase continuous RF signal.....	65
4.4	RF connector settings.....	66
4.5	RF frequency settings.....	69
4.6	RF level settings.....	72
4.7	RF phase settings.....	76
5	Analog modulations.....	79
5.1	Required options.....	79
5.2	Modulation types and signal sources.....	79
5.3	Activating analog modulations.....	82
5.4	Modulation settings.....	82
5.4.1	Pulse modulation settings.....	82

5.4.2	FM, PhiM and AM modulation settings.....	84
5.4.3	Chirp modulation.....	91
5.4.4	Pulse generator.....	96
5.4.5	Pulse graph.....	109
5.4.6	Pulse external / trigger settings.....	110
5.4.7	FM, PhiM and AM modulation sources.....	111
5.4.8	LF signal output settings.....	118
5.4.9	Overview.....	120
5.5	How to generate an amplitude modulated signal.....	122
5.6	How to generate a pulse modulated signal.....	122
5.7	How to generate a pulse train modulated signal.....	123
6	Avionic standards.....	125
6.1	Required options.....	125
6.2	About avionics.....	125
6.3	Generating VOR signals.....	125
6.3.1	About VOR.....	126
6.3.2	VOR configuration and settings.....	127
6.4	Generating ILS signals.....	136
6.4.1	About ILS.....	136
6.4.2	ILS configuration and settings.....	139
6.5	Generating ADF signals.....	162
6.5.1	About ADF.....	162
6.5.2	ADF configuration and settings.....	163
7	List and sweep mode.....	168
7.1	Signal generation and triggering in the sweep and list modes.....	170
7.2	About sweep mode.....	177
7.2.1	Correlating parameters in sweep mode.....	178
7.2.2	Sweep signal shapes.....	180
7.3	About list mode.....	181
7.4	Significant parameters and functions.....	182
7.5	Sweep mode settings.....	184
7.5.1	General sweep settings.....	184
7.5.2	Frequency range settings.....	191

7.5.3	Level range settings.....	193
7.5.4	Output settings.....	195
7.5.5	Edit marker settings.....	196
7.6	List mode settings.....	198
7.6.1	General settings.....	199
7.6.2	List mode data settings.....	201
7.6.3	Import/export settings.....	202
7.7	List editor.....	204
7.8	How to generate a signal in list or sweep mode.....	208
8	Improving level performance.....	210
8.1	Attenuator.....	210
8.1.1	Attenuator settings.....	211
8.1.2	Reverse power protection.....	213
8.2	Automatic level control (ALC).....	213
8.2.1	ALC settings.....	215
8.2.2	How to set up an external ALC.....	217
8.3	User correction.....	218
8.3.1	User correction settings.....	220
8.3.2	List editor.....	222
8.3.3	Fill with sensor.....	226
8.3.4	Import/export list files.....	227
8.4	Using power sensors.....	230
8.4.1	Connecting R&S NRP power sensors to the R&S SMA100B.....	230
8.4.2	NRP sensor mapping.....	231
8.4.3	NRP power viewer.....	234
8.4.4	NRP-Z power analysis.....	242
8.5	How to calibrate the power level with an R&S NRP power sensor.....	287
9	Reference oscillator.....	291
9.1	Required options.....	291
9.2	Reference frequency settings.....	291
9.3	Reference output settings.....	295
9.4	Adjustment settings.....	296
9.5	Using the reference frequency for instruments synchronization.....	297

10	Clock synthesis.....	301
11	File and data management.....	305
11.1	About the file system.....	305
11.2	Restoring the (default) instrument configuration.....	308
11.2.1	Preset, set to default and factory preset settings.....	310
11.2.2	How to identify parameters which are not in a preset state.....	311
11.2.3	How to recall user settings automatically after preset.....	312
11.2.4	Reference.....	312
11.3	Protecting data.....	313
11.4	Saving and recalling instrument settings.....	314
11.4.1	Save/recall settings.....	315
11.4.2	How to save and recall instrument settings.....	317
11.5	Accessing files with user data.....	318
11.5.1	File select settings.....	318
11.6	Exporting and importing remote command lists.....	320
11.7	Loading, importing and exporting lists.....	321
11.8	Using the file manager.....	321
11.8.1	File manager settings.....	322
11.8.2	Map network share settings.....	323
11.8.3	How to display all saved files.....	325
11.8.4	How to map a network folder.....	325
11.9	How to transfer files from and to the instrument.....	327
11.9.1	Removing file system protection.....	328
11.9.2	Accessing the file system of the R&S SMA100B over FTP.....	329
11.9.3	Accessing the R&S SMA100B file system using SMB (Samba).....	330
11.9.4	Using a USB storage device for file transfer.....	332
11.9.5	Using a file server for test files exchange.....	332
11.10	Creating screenshots of current settings.....	333
11.10.1	Hardcopy settings.....	333
11.10.2	How to save a hardcopy of the display.....	337
12	General instrument functions.....	339
12.1	Customizing the user interface.....	339
12.1.1	Display and keyboard settings.....	340

12.1.2	Display update settings.....	341
12.1.3	Defining the RF signal state on power on.....	342
12.1.4	How to set the initial instrument settings.....	343
12.2	Organizing frequently used settings as favorites.....	344
12.2.1	User menu settings.....	345
12.2.2	How to use the user menu for fast adjustments.....	346
12.2.3	Define user key actions settings.....	348
12.2.4	How to assign actions to the [★ (User)] key.....	350
12.3	Managing licenses and license keys.....	351
12.3.1	Manage license keys settings.....	351
12.3.2	Using the license server.....	354
12.3.3	How to move a portable license.....	358
12.4	Using the security settings.....	360
12.4.1	Protection level settings.....	361
12.4.2	Setting security parameters.....	362
12.4.3	Configuring LAN services.....	367
12.4.4	Password management.....	370
12.4.5	How to prevent unauthorized access.....	372
12.5	Undoing or restoring actions.....	375
12.6	Shutting down and rebooting the instrument.....	377
13	Network operation and remote control.....	378
13.1	Overview of remote access modes.....	379
13.2	Remote control interfaces and protocols.....	380
13.2.1	LAN interface.....	381
13.2.2	USB interface.....	383
13.2.3	GPIB interface (IEC/IEEE bus interface).....	384
13.2.4	LXI browser interface.....	385
13.3	Remote control programs and libraries.....	385
13.4	Status reporting system.....	388
13.4.1	Hierarchy of the status registers.....	388
13.4.2	Structure of a SCPI status register.....	390
13.4.3	Status byte (STB) and service request enable register (SRE).....	392
13.4.4	Event status register (ESR) and event status enable register (ESE).....	393

13.4.5	Questionable status register (STATus:QUEStionable).....	393
13.4.6	Operation status register (STATus:OPERation).....	394
13.4.7	Application of the status reporting system.....	394
13.4.8	Reset values of the status reporting system.....	396
13.5	Remote access settings.....	396
13.5.1	Network settings.....	398
13.5.2	VISA resource strings.....	402
13.5.3	GPIO address settings.....	403
13.5.4	RS232 settings.....	404
13.5.5	Instrument emulations settings.....	405
13.5.6	Remote connections settings.....	406
13.5.7	HUMS settings.....	408
13.5.8	HUMS enhanced settings.....	410
13.5.9	QR code.....	418
13.6	LXI settings.....	419
13.6.1	LXI status settings.....	419
13.6.2	LXI browser settings.....	420
13.7	To configure the instrument for remote access.....	426
13.7.1	To find the VISA resource string.....	427
13.7.2	To configure the acces over LAN.....	427
13.7.3	To configure the access over GPIO.....	431
13.8	To establish a remote control session over LAN.....	431
13.8.1	To establish the connection with the LXI web browser.....	432
13.8.2	To establish the connection using VXI-11 protocol.....	433
13.8.3	To establish the connection using socket communication.....	438
13.9	To establish a remote control session over GPIO.....	440
13.10	To establish a remote control session over USB.....	440
13.11	To trace messages with the LXI web browser interface.....	441
13.12	To return to manual operation.....	442
13.13	To automate tasks with remote command scripts.....	442
13.13.1	Show SCPI command.....	445
13.13.2	Displaying an SCPI list.....	445
13.13.3	SCPI recording export settings.....	446

13.13.4	How to record / create SCPI lists.....	447
13.13.5	How to convert and save SCPI lists.....	450
13.13.6	How to find out the SCPI commands for GUI functions.....	451
13.14	To operate the instrument using VNC.....	452
13.14.1	How to enable the VNC service.....	452
13.14.2	How to set up remote operation from a desktop system.....	453
13.14.3	How to set up remote operation from a smart device.....	455
13.15	References.....	458
13.15.1	LXI functionality.....	458
13.15.2	Code generator templates.....	458
13.15.3	Remote control states.....	460
14	Remote control commands.....	462
14.1	Conventions used in SCPI command descriptions.....	462
14.2	Programming examples.....	463
14.3	Common commands.....	463
14.4	Preset commands.....	468
14.5	MMEMory subsystem.....	469
14.5.1	File naming conventions.....	470
14.5.2	Accessing files in the default or in a specified directory.....	471
14.5.3	Programming examples.....	472
14.5.4	Remote control commands.....	474
14.6	CALibration subsystem.....	479
14.7	CSYNthesis subsystem.....	483
14.8	DIAGnostic subsystem.....	488
14.9	HUMS remote control commands.....	491
14.10	DISPlay subsystem.....	499
14.11	FORMat subsystem.....	503
14.12	HCOPy subsystem.....	505
14.12.1	Hard copy settings.....	506
14.12.2	Automatic naming.....	507
14.13	KBOard subsystem.....	510
14.14	OUTPut subsystem.....	510
14.15	Power sensor measurement subsystems.....	514

14.15.1	CALCulate subsystem.....	515
14.15.2	DISPlay subsystem.....	522
14.15.3	INITiate command.....	523
14.15.4	READ subsystem.....	523
14.15.5	SENSe SWEep subsystem.....	524
14.15.6	TRACe subsystem.....	556
14.16	SENSe, READ, INITiate and SLISt subsystems.....	568
14.17	SOURce subsystem.....	582
14.17.1	Analog modulation subsystems.....	583
14.17.2	Avionic standards subsystems.....	614
14.17.3	SOURce:CORRection subsystem.....	656
14.17.4	SOURce:FREQuency subsystem.....	664
14.17.5	SOURce:INPut subsystem.....	673
14.17.6	SOURce:LFOutput subsystem.....	674
14.17.7	SOURce:LIST subsystem.....	687
14.17.8	SOURce:NOISe subsystem.....	699
14.17.9	SOURce:PGEN subsystem.....	701
14.17.10	SOURce:PHASe subsystem.....	703
14.17.11	SOURce:POWer subsystem.....	704
14.17.12	SOURce:ROSCillator subsystem.....	714
14.17.13	SOURce:SWEep subsystem.....	720
14.18	SYSTem subsystem.....	735
14.19	STATus subsystem.....	761
14.20	TEST subsystem.....	765
14.21	TRIGger subsystem.....	765
14.22	UNIT subsystem.....	769
15	Troubleshooting and notifications.....	770
15.1	Notifications.....	770
15.1.1	Volatile notifications.....	770
15.1.2	Permanent notifications.....	771
15.2	SCPI notifications.....	771
15.3	Device-specific notifications.....	771
15.4	Querying notifications.....	773

15.5	Resolving network connection failures.....	775
15.6	Measuring USB cable quality.....	776
15.7	Requesting instrument configuration and specifications.....	776
15.7.1	Hardware configuration settings.....	776
15.7.2	Versions/options settings.....	778
15.7.3	How to query instrument configuration.....	779
15.7.4	How to request the data sheet.....	781
15.8	Collecting information for technical support.....	781
15.9	Contacting customer support.....	782
16	Transporting.....	784
17	Maintenance, storage and disposal.....	785
17.1	Cleaning.....	785
17.2	Storage.....	785
17.3	Performing maintenance tasks.....	785
17.3.1	Internal adjustments.....	785
17.3.2	Date and time.....	791
17.3.3	Check front panel.....	794
17.3.4	FPGA/uC update settings.....	797
17.3.5	Delete temporary files.....	799
17.4	Disposal.....	800
	Annex.....	801
A	Reference information for remote control.....	801
A.1	Telnet program examples.....	801
A.2	Hardware interfaces.....	806
A.2.1	GPIB-Bus interface.....	806
B	Extensions for user files.....	808
C	Unit shortcuts.....	809
D	Morse code settings.....	811

Glossary: List of the often used terms and abbreviations.....	812
List of Commands.....	816
Index.....	833

1 Safety and regulatory information

The product documentation helps you use the product safely and efficiently. Follow the instructions provided here and in the following chapters.

Intended use

The product generates radio frequency (RF) signals for the development, production and verification of electronic components, modules or devices. The product is intended for industrial use, for example for production and conformance testing, maintenance and engineering laboratories.

Use the product only for its designated purpose. Any other use is considered improper use. Observe the operating conditions and performance limits stated in the data sheet.

Target audience

This document targets at all users, including technicians, operators, administrators and maintenance personnel. The required skills and experience of the users depend on the test setup and application of the product.

Where do I find safety information?

Safety information is part of the product documentation. It warns you of potential dangers and gives instructions on how to prevent personal injury or damage caused by dangerous situations. Safety information is provided as follows:

- In [Chapter 1.1, "Safety instructions"](#), on page 15. The same information is provided in many languages as printed "Safety Instructions". The printed "Safety Instructions" are delivered with the product.
- Throughout the documentation, safety instructions are provided when you need to take care during setup or operation.

1.1 Safety instructions

Products from the Rohde & Schwarz group of companies are manufactured according to the highest technical standards. To use the products safely, follow the instructions provided here and in the product documentation. Keep the product documentation nearby and offer it to other users.

Use the product only for its intended use and within its performance limits. Intended use and limits are described in the product documentation such as the data sheet, manuals and the printed "Safety Instructions". If you are unsure about the appropriate use, contact Rohde & Schwarz customer service.

Using the product requires specialists or specially trained personnel. These users also need sound knowledge of at least one of the languages in which the user interfaces and the product documentation are available.

Reconfigure or adjust the product only as described in the product documentation or the data sheet. Any other modifications can affect safety and are not permitted.

Never open the casing of the product. Only service personnel authorized by Rohde & Schwarz are allowed to repair the product. If any part of the product is damaged or broken, stop using the product. Contact Rohde & Schwarz customer service at <https://www.rohde-schwarz.com/support>.

Lifting and carrying the product

The product is heavy. Do not move or carry the product by yourself. A single person can only carry a maximum of 18 kg safely depending on age, gender and physical condition. Look up the maximum weight in the data sheet. Use the product handles to move or carry the product. Do not lift by the accessories mounted on the product. Accessories are not designed to carry the weight of the product.

To move the product safely, you can use lifting or transporting equipment such as lift trucks and forklifts. Follow the instructions provided by the equipment manufacturer.

Choosing the operating site

Only use the product indoors. The product casing is not waterproof. Water that enters can electrically connect the casing with live parts, which can lead to electric shock, serious personal injury or death if you touch the casing. If Rohde & Schwarz provides accessories designed for your product, e.g. a carrying bag, you can use the product outdoors.

Unless otherwise specified, you can operate the product up to an altitude of 2000 m above sea level. The product is suitable for pollution degree 2 environments where nonconductive contamination can occur. For more information on environmental conditions such as ambient temperature and humidity, see the data sheet.

Setting up the product

Always place the product on a stable, flat and level surface with the bottom of the product facing down. If the product is designed for different positions, secure the product so that it cannot fall over.

If the product has foldable feet, always fold the feet completely in or out to ensure stability. The feet can collapse if they are not folded out completely or if the product is moved without lifting it. The foldable feet are designed to carry the weight of the product, but not an extra load.

If stacking is possible, keep in mind that a stack of products can fall over and cause injury.

If you mount products in a rack, ensure that the rack has sufficient load capacity and stability. Observe the specifications of the rack manufacturer. Always install the products from the bottom shelf to the top shelf so that the rack stands securely. Secure the product so that it cannot fall off the rack.

Connecting to power

The product is an overvoltage category II product. Connect the product to a fixed installation used to supply energy-consuming equipment such as household appliances and similar loads. Keep in mind that electrically powered products have risks, such

as electric shock, fire, personal injury or even death. Replace parts that are relevant to safety only by original parts, e.g. power cables or fuses.

Take the following measures for your safety:






- Before switching on the product, ensure that the voltage and frequency indicated on the product match the available power source. If the power adapter does not adjust automatically, set the correct value and check the rating of the fuse.
- Only use the power cable delivered with the product. It complies with country-specific safety requirements. Only insert the plug into an outlet with protective conductor terminal.
- Only use intact cables and route them carefully so that they cannot be damaged. Check the power cables regularly to ensure that they are undamaged. Also ensure that nobody can trip over loose cables.
- If you connect the product to an external power supply, use the one delivered with the product or recommended in the product documentation. The external power supply must conform to the country-specific regulations.
- Only connect the product to a power source with a fuse protection of maximum 20 A.
- Ensure that you can disconnect the product from the power source at any time. Pull the power plug to disconnect the product. The power plug must be easily accessible. If the product is integrated into a system that does not meet these requirements, provide an easily accessible circuit breaker at the system level.

Cleaning the product

Use a dry, lint-free cloth to clean the product. When cleaning, keep in mind that the casing is not waterproof. Do not use liquid cleaning agents.

Meaning of safety labels

Safety labels on the product warn against potential hazards.

	Potential hazard Read the product documentation to avoid personal injury or product damage.
	Heavy product Be careful when lifting, moving or carrying the product. Carrying the product requires a sufficient number of persons or transport equipment.
	Electrical hazard Indicates live parts. Risk of electric shock, fire, personal injury or even death.
	Hot surface Do not touch. Risk of skin burns. Risk of fire.
	Protective conductor terminal Connect this terminal to a grounded external conductor or to protective ground. This connection protects you against electric shock if an electric problem occurs.

1.2 Labels on R&S SMA100B

Labels on the casing inform about:

- Personal safety, see ["Connecting to power"](#) on page 16.
- Product and environment safety, see [Table 1-1](#).
- Identification of the product, see the serial number on the [rear panel](#).

Table 1-1: Labels regarding R&S SMA100B and environment safety



Labeling in line with EN 50419 for disposal of electrical and electronic equipment after the product has come to the end of its service life. For more information, see [Chapter 17.4, "Disposal"](#), on page 800.

1.3 Warning messages in the documentation

A warning message points out a risk or danger that you need to be aware of. The signal word indicates the severity of the safety hazard and how likely it will occur if you do not follow the safety precautions.

WARNING

Potentially hazardous situation. Could result in death or serious injury if not avoided.

CAUTION

Potentially hazardous situation. Could result in minor or moderate injury if not avoided.

NOTICE

Potential risks of damage. Could result in damage to the supported product or to other property.

1.4 Where to find key documents on Rohde & Schwarz

Certificates issued to Rohde & Schwarz that are relevant for your country are provided at www.rohde-schwarz.com/key-documents, e.g. concerning:

- Quality management
- Environmental management
- Information security management
- Accreditations

1.5 Korea certification class A



이 기기는 업무용(A급) 전자파 적합기기로서 판매자 또는 사용자는 이 점을 주의하시기
바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

2 Welcome

The R&S SMA100B is a new high-performance signal generator developed to meet demanding customer requirements. Offering excellent signal characteristic and straightforward and intuitive operation, the signal generator makes signal generation fast and easy.

2.1 Key features

Outstanding key features of the R&S SMA100B are:

- Frequency range from 8 kHz to up to 20 GHz (overrange 72 GHz)
- Excellent signal quality
- Excellent single sideband (SSB) phase noise
- Nearly no wideband noise
- Very high output power
- Low harmonics
- Unique pulse train generation
- High-stability reference oscillator
- Intuitive operation via touchscreen with the tile diagram as key element

For more information, see data sheet.

2.2 What's new

This manual describes firmware version FW 5.10.121.xx and later of the R&S®SMA100B.

Compared to the previous version, it provides the new features listed below:

- HUMS settings including device tags and enhanced protocol settings, see [Chapter 13.5.7, "HUMS settings"](#), on page 408 and [Chapter 13.5.8, "HUMS enhanced settings"](#), on page 410.
- Delayed internal adjustment settings to start the internal adjustments at at a specified time and automatic shut down of the instrument when completed, see [Chapter 17.3.1.2, "Delayed adjustment settings"](#), on page 788.

2.3 Documentation overview

This section provides an overview of the R&S SMA100B user documentation. Unless specified otherwise, you find the documents at:

www.rohde-schwarz.com/manual/sma100b

2.3.1 Getting started manual

Introduces the R&S SMA100B and describes how to set up and start working with the product. Includes basic operations, typical measurement examples, and general information, e.g. safety instructions, etc. A printed version is delivered with the instrument.

2.3.2 User manuals and help

Contains the description of all instrument modes and functions. It also provides an introduction to remote control, a complete description of the remote control commands with programming examples, and information on maintenance, instrument interfaces and error messages. Includes the contents of the getting started manual.

The contents of the user manuals are available as help in the R&S SMA100B. The help offers quick, context-sensitive access to the complete information.

All user manuals are also available for download or for immediate display on the Internet.

2.3.3 Service manual

Describes the performance test for checking compliance with rated specifications, firmware update, troubleshooting, adjustments, installing options and maintenance.

The service manual is available for registered users on the global Rohde & Schwarz information system (GLORIS):

<https://gloris.rohde-schwarz.com>

2.3.4 Instrument security procedures

Deals with security issues when working with the R&S SMA100B in secure areas. It is available for download on the internet.

2.3.5 Printed safety instructions

Provides safety information in many languages. The printed document is delivered with the product.

2.3.6 Data sheets and brochures

The data sheet contains the technical specifications of the R&S SMA100B. It also lists the options and their order numbers and optional accessories.

The brochure provides an overview of the instrument and deals with the specific characteristics.

See www.rohde-schwarz.com/brochure-datasheet/sma100b

2.3.7 Release notes and open source acknowledgment (OSA)

The release notes list new features, improvements and known issues of the current firmware version, and describe the firmware installation.

The software makes use of several valuable open source software packages. An open-source acknowledgment document provides verbatim license texts of the used open source software.

See www.rohde-schwarz.com/firmware/sma100b

2.3.8 Application notes, application cards, white papers, etc.

These documents deal with special applications or background information on particular topics.

See www.rohde-schwarz.com/application/sma100b

2.3.9 Videos

Find various videos on Rohde & Schwarz products and test and measurement topics on YouTube: <https://www.youtube.com/@RohdeundSchwarz>



On the menu bar, search for your product to find related videos.

HOME VIDEOS SHORTS PLAYLISTS COMMUNITY CHANNELS ABOUT



Figure 2-1: Product search on YouTube

3 Getting started

3.1 Preparing for use

Here, you can find basic information about setting up the product for the first time.

3.1.1 Lifting and carrying

Use the handles at the side, for lifting and carrying the R&S SMA100B, see ["Lifting and carrying the product"](#) on page 16. Use the handles at the front, for mounting the R&S SMA100B in a rack.




Figure 3-1: Instrument side view with front handles (1) and side handles (2)

3.1.2 Unpacking and checking

1. Unpack the R&S SMA100B carefully.
2. Retain the original packing material. Use it to protect the control elements and connectors when transporting or shipping the R&S SMA100B later.
See also [Chapter 16, "Transporting"](#), on page 784.
3. Using the delivery notes, check the equipment for completeness.
4. Check the equipment for damage.

If the delivery is incomplete or equipment is damaged, contact Rohde & Schwarz.

3.1.3 Choosing the operating site

Specific operating conditions ensure proper operation and avoid damage to the product and connected devices. For information on environmental conditions such as ambient temperature and humidity, see the data sheet.

See also ["Choosing the operating site"](#) on page 16.

Electromagnetic compatibility classes

The electromagnetic compatibility (EMC) class indicates where you can operate the product. The EMC class of the product is given in the data sheet.

- Class B equipment is suitable for use in:
 - Residential environments
 - Environments that are directly connected to a low-voltage supply network that supplies residential buildings
- Class A equipment is intended for use in industrial environments. It can cause radio disturbances in residential environments due to possible conducted and radiated disturbances. It is therefore not suitable for class B environments. If class A equipment causes radio disturbances, take appropriate measures to eliminate them.

3.1.4 Setting up the R&S SMA100B


See also:

- ["Setting up the product"](#) on page 16
- ["Intended use"](#) on page 15

3.1.4.1 Placing the R&S SMA100B on a bench top

To place the product on a bench top

1. Place the product on a stable, flat and level surface. Ensure that the surface can support the weight of the product. For information on the weight, see the data sheet.
2. **CAUTION!** Foldable feet can collapse. See ["Setting up the product"](#) on page 16. Always fold the feet completely in or out. With folded-out feet, do not place anything on top or underneath the product.
3. **WARNING!** A stack of products can fall over and cause injury. Never stack more than three products on top of each other. Instead, mount them in a rack.
Stack as follows:
 - If the products have foldable feet, fold them in completely.
 - It is best if all products have the same dimensions (width and length). If the products have different dimensions, stack according to size and place the smallest product on top.
 - Do not exceed the permissible total load placed on the product at the bottom of the stack:
 - 50 kg when stacking products of identical dimensions (left figure).
 - 25 kg when stacking smaller products on top (middle figure).



Left = Stacked correctly, same dimensions
 Middle = Stacked correctly, different dimensions
 Right = Stacked incorrectly, too many products

4. **NOTICE!** Overheating can damage the product.

Prevent overheating as follows:

- Keep a minimum distance of 10 cm between the fan openings of the product and any object in the vicinity to provide sufficient airflow and ventilation.
- Do not place the product next to heat-generating equipment such as radiators or other products.

3.1.4.2 Mounting the R&S SMA100B in a rack

To prepare the rack

1. Observe the requirements and instructions in "[Setting up the product](#)" on page 16.
2. **NOTICE!** Insufficient airflow can cause overheating and damage the product.
Design and implement an efficient ventilation concept for the rack.

To mount the R&S SMA100B in a rack

1. Use an adapter kit that fits the dimensions of the R&S SMA100B to prepare the instrument for rack mounting.
 - a) Order the rack adapter kit designed for the R&S SMA100B. For the order number, see the data sheet.
 - b) Mount the adapter kit. Follow the assembly instructions provided with the adapter kit.
2. **WARNING!** The R&S SMA100B is heavy. Lift the R&S SMA100B with a lifting equipment, see "[Lifting and carrying the product](#)" on page 16.
Lift the R&S SMA100B to shelf height.
3. Grab the handles at the front.
4. Push the R&S SMA100B onto the shelf until the rack brackets fit closely to the rack.

5. Tighten all screws at the rack brackets with a tightening torque of 1.2 Nm to secure the R&S SMA100B in the rack.

To unmount the R&S SMA100B from a rack

1. Loosen the screws at the rack brackets.
2. **WARNING!** The R&S SMA100B is heavy. Lift the R&S SMA100B with a lifting equipment, see ["Lifting and carrying the product"](#) on page 16.
Bring the lifting equipment to shelf height.
3. Remove the R&S SMA100B from the rack.
4. If placing the R&S SMA100B on a bench top again, unmount the adapter kit from the R&S SMA100B. Follow the instructions provided with the adapter kit.

3.1.5 Considerations for test setup

Cable selection and electromagnetic interference (EMI)

Electromagnetic interference (EMI) can affect the measurement results.

To suppress electromagnetic radiation during operation:

- Use high-quality shielded cables, especially for the following connector types:
 - BNC
Double-shielded BNC cables.
How to: ["To connect to pluggable connectors"](#) on page 30
 - SMA
Double-shielded SMA cables.
How to: ["To connect to screwable connectors"](#) on page 29
 - USB
Double-shielded USB cables.
How to: [Chapter 3.1.8, "Connecting USB devices"](#), on page 28.
 - LAN
At least CAT6 STP cables.
How to: [Chapter 3.1.7, "Connecting to LAN"](#), on page 27
- Always terminate open cable ends.
- Ensure that connected external devices comply with EMC regulations.

Signal input and output levels

Information on signal levels is provided in the data sheet. Keep the signal levels within the specified ranges to avoid damage to the R&S SMA100B and connected devices.

Preventing electrostatic discharge (ESD)

Electrostatic discharge is most likely to occur when you connect or disconnect a DUT.

- **NOTICE!** Electrostatic discharge can damage the electronic components of the product and the device under test (DUT).

Ground yourself to prevent electrostatic discharge damage:

- a) Use a wrist strap and cord to connect yourself to ground.
- b) Use a conductive floor mat and heel strap combination.

3.1.6 Connecting to power

For safety information, see ["Connecting to power"](#) on page 16.

1. Plug the AC power cable into the AC power connector on the rear panel. Only use the AC power cable delivered with the R&S SMA100B.
2. Plug the AC power cable into a power outlet with ground contact.

The required ratings are listed next to the AC power connector and in the data sheet.

3.1.7 Connecting to LAN

Network environment

Before connecting the product to a local area network (LAN), consider the following:


- Install the latest firmware to reduce security risks.
- For internet or remote access, use secured connections if applicable.
- Ensure that the network settings comply with the security policies of your company. Contact your local system administrator or IT department before connecting your product to your company LAN.
- When connected to the LAN, the product may potentially be accessed from the internet, which may be a security risk. For example, attackers might misuse or damage the product.

To connect to LAN

- Connect the LAN socket on the rear panel via an RJ-45 cable to the LAN.

Using DHCP (dynamic host configuration protocol), the R&S SMA100B assigns the IP address automatically.

If connected to the LAN, the R&S SMA100B displays the IP address and the host-name at the left bottom of the home screen.



- 1 = Hostname
- 2 = IP address

If disconnected from the LAN, the R&S SMA100B displays the IP address *0.0.0.0*.

See also [Chapter 13.7, "To configure the instrument for remote access"](#), on page 426.

3.1.8 Connecting USB devices

You can connect or disconnect all USB devices from the R&S SMA100B during operation.

To connect USB storage devices

USB storage devices, such as memory sticks, allow data transfer from or to the R&S SMA100B. You can also use them for firmware updates.

- Connect the USB storage device to any of the USB connectors.

To connect USB devices with external power supply

1. **NOTICE!** Connected devices with external power supply can feed back current into the 5 V power supply of the USB interface and thus damage the R&S SMA100B.
Ensure that there is no connection between the positive pole of the power supply and the +5 V power pin of the USB interface (VBUS).
2. Connect the USB storage device to any of the USB connectors on the front panel or rear panel.

To connect a keyboard

- Connect the keyboard to any of the USB connectors on the front panel or rear panel.

When connected, the R&S SMA100B detects the keyboard automatically. A detected keyboard has the default layout English – US.

To connect a mouse

- Connect the mouse to any of the USB connectors.

When connected, the R&S SMA100B detects the mouse automatically.

To connect power sensors

You can connect power sensors of the R&S NRP families to any of the USB connectors on the front panel or rear panel.

See [Chapter 8.4, "Using power sensors"](#), on page 230.

3.1.9 Connecting to RF coaxial connectors

Here, you find information on how to prepare and to connect to RF coaxial connectors of the R&S SMA100B. Use these RF connectors, for example, for output of the RF signal or for input of an external reference signal.

To prepare for connecting

1. **NOTICE!** Damaged or not clean connections can lead to RF insertion loss and mismatch, and even premature wear of the connectors.
Before connecting to the port, inspect the RF connector visually. Check that it is clean, undamaged and mechanically compatible.
2. **NOTICE!** DC voltage at the RF connector can damage the instrument. Never apply DC voltage to the RF input connectors.
Make sure that the values are within the DC limits given in the data sheet.
3. If your test setup has a DC component at the RF input, insert a DC blocker.
4. Use a high-quality RF cable that matches the RF connector type.
See ["Cable selection and electromagnetic interference \(EMI\)"](#) on page 26.
5. You can connect to two kinds of connectors:
 - ["To connect to screwable connectors"](#) on page 29
 - ["To connect to pluggable connectors"](#) on page 30

To connect to screwable connectors

The R&S SMA100B provides screwable RF connectors as in [Table 3-1](#).

- **NOTICE!** Excessive tightening can damage the connectors.

To connect the cable with the connector, proceed as follows:

- a) Carefully align the connector of the cable and the connector along a common axis.
- b) Mate the connectors along the common axis until the male pin of the inner connector engages with the female socket of the outer connector.
- c) Turn the nut of the outer connector until the connectors are firmly coupled.
- d) Using a calibrated torque wrench torque the nut to the limit as in the table below. Hold the opposite connector part stationary with a spanner.

Table 3-1: Connector name, type, size, torque limit and nut opening

Connector		Torque limit		Nut opening	
Type	Name	lb-Inch	Nm	Inch	mm
N	RF 50 Ω *)	13.3	1.5	3/4	20
SMA	Clk Syn Clk Syn N Ref In 1 GHz Ref Out 1 GHz	5	0.56	5/16	8

Connector		Torque limit		Nut opening	
2.92 mm	RF 50 Ω ^{*)}	8	0.9	5/16	8
1.85 mm	RF 50 Ω ^{*)}	8	0.9	5/16	8

^{*)} maximum frequency f_{\max} depends on the connector type: $f_{\max}(N) \leq 7$ GHz,
 $f_{\max}(2.92 \text{ mm}) \leq 40$ GHz, $f_{\max}(1.85 \text{ mm}) \leq 67$ GHz

To connect to pluggable connectors

The R&S SMA100B provides pluggable Bayonet Neill-Concelman (BNC) connectors.

- To connect the RF cable with the BNC connector, proceed as follows:
 - a) Carefully align the connector of the cable and the BNC connector along a common axis.
 - b) Mate the connectors along the common axis until the male pin of the connector of the cable engages with the female socket of the BNC connector.

For information on how to handle and maintain the RF port, to minimize measurement deviations and ensure its longevity, see the application note [1MA99](#).

If you want to mount test port adapters to your RF connector, see the application note [1MA100](#).

3.1.10 Connecting to RF 50 Ω

To connect to "RF 50 Ω"

1. Before connecting to the "RF 50 Ω" connector on the front panel, proceed as follows:
 - a) Prepare the "RF 50 Ω" connector. See ["To prepare for connecting"](#) on page 29.
 - b) If activated, deactivate the RF output. In the home screen, select the block "Level" > "RF On > Off".

If equipped with an option for rear panel connectors, prepare the "RF 50 Ω" connector on the rear panel.

2. Connect to the "RF 50 Ω" connector. See ["To connect to screwable connectors"](#) on page 29.

To prevent RF output switch-off

- **NOTICE!** If you set a too high output level without a load connected to the instrument, the reverse power can exceed a limit forcing the R&S SMA100B to switch off the RF output.

Connect a load with sufficient return loss as given in the data sheet.

3.1.11 Connecting to Ref In/Ref Out

To connect to "Ref In"/"Ref Out"




For connection, the R&S SMA100B provides BNC connectors (reference signal frequency $f_{\text{ref}} < 1$ GHz) or SMA connectors ($f_{\text{ref}} = 1$ GHz).

1. Before connecting, prepare the Ref In/Ref Out connectors on the rear panel. See ["To prepare for connecting"](#) on page 29.
2. Connect to the "Ref In"/"Ref Out" connectors:
 - $f_{\text{ref}} < 1$ GHz: ["To connect to pluggable connectors"](#) on page 30
 - $f_{\text{ref}} = 1$ GHz: ["To connect to screwable connectors"](#) on page 29

3.1.12 Switching on or off

The following table provides an overview of power states, LEDs and positions of the power switch.

Table 3-2: Overview of power states

State	LED	Position of power switch
Off	 gray	[0]
Standby	 orange	[I]
Ready	 green	[I]

To switch on the R&S SMA100B

The R&S SMA100B is off but connected to power. See [Chapter 3.1.6, "Connecting to power"](#), on page 27.

1. Set the switch on the power supply to position [I] on the rear panel.
The LED of the [On/Standby] key on the front panel is orange.
2. Press the [On/Standby] key on the front panel.
The LED changes to green. The R&S SMA100B boots.
After booting, the R&S SMA100B starts up displaying the home screen on the screen on the front panel.

To check start-up functions

When starting for the first time, the R&S SMA100B starts with the default settings. When restarting, the R&S SMA100B recalls the instrument configuration before shut-down.

See [Chapter 11.4, "Saving and recalling instrument settings"](#), on page 314.

When switched on, the R&S SMW automatically monitors main functions. You can query erroneous functions. In addition to automatic monitoring, you can perform maintenance tasks. See the following:

- [Chapter 15.4, "Querying notifications"](#), on page 773
- [Chapter 17.3, "Performing maintenance tasks"](#), on page 785

To shut down the product

The product is in the ready state.

- Press the [On/Standby] key.

The operating system shuts down. The LED changes to orange.

In the standby state, the power switch circuits are active. To deactivate them, disconnect the instrument from the power supply.

To disconnect from power

The R&S SMA100B is in the standby state.

1. **NOTICE!** Risk of data loss. If you disconnect the product from power when it is in the ready state, you can lose settings and data. Shut it down first.
Set the toggle switch on the power supply to position [0].
The LED of the [On/Standby] key is switched off.
2. Disconnect the R&S SMA100B from the power source.

3.2 Instrument tour

This chapter explains the control elements and the connectors of the R&S SMA100B. The views of the front panel and the rear panel help you to get familiar with the instrument and to perform first steps. For specifications of the interfaces, see the data sheet.

The meanings of the labels on the R&S SMA100B are described in [Chapter 1.2, "Labels on R&S SMA100B"](#), on page 18.

3.2.1 Front panel tour

This section provides an overview of the control elements at the front panel of the R&S SMA100B. Most of the connectors are at the rear panel and are described in [Chapter 3.2.2, "Rear panel tour"](#), on page 40.



Figure 3-2: Front panel view of the R&S SMA100B RF Signal Generator with height unit 2HU (option R&S SMAB-B92)

- 1 = Utility keys
- 2 = Touchscreen
- 3 = Function keys
- 4 = Navigation controls
- 5 = Display keys
- 6 = SD card slot
- 7 = USB connector
- 8 = RF 50 Ω
- 9 = Sensor
- 10 = Keypad
- 11 = On/Standby




Figure 3-3: Front panel view of the R&S SMA100B RF Signal Generator with height unit 3HU (option R&S SMAB-B93)

- 1 = On/Standby
- 2 = Utility keys
- 3 = Touchscreen
- 4 = Keypad
- 5 = Function keys
- 6 = Navigation controls
- 7 = Display keys
- 8 = SD card slot

- 9 = USB connector
- 10 = Sensor
- 11 = RF 50 Ω
- 12 = Pulse signal connectors
- 13 = LF
- 14 = Ext 1/2
- 15 = Clock synthesizer connectors

3.2.1.1 Touchscreen

The screen at the front panel is the graphical user interface. It shows the settings dialogs and parameters, and the current configuration at a glance, see [Chapter 3.4.3, "Understanding the display information"](#), on page 53.




Figure 3-4: Touchscreen

The touch-sensitive panel provides an alternative means of user interaction for quick and easy handling of the instrument, see [Chapter 3.4.2, "Means of manual interaction"](#), on page 52.

See also:

- [Chapter 3.4, "Instrument control"](#), on page 51, for operating the touchscreen.
- [Chapter 17.1, "Cleaning"](#), on page 785, for instructions on cleaning the product.

3.2.1.2 Utility keys

The utility keys set the R&S SMA100B to a defined state, and provide access to basic settings and information on assistance.

Table 3-3: Utility keys

Utility Key	Assigned functions
[Preset]	Sets the instrument to a defined state
[Local]	Switches from remote control to local (manual) control
[Setup]	Accesses the general instrument settings
[Help]	Displays context-sensitive help text

3.2.1.3 On/Standby

The [On/Standby] key switches the instrument from the standby to the ready state or vice versa.

The LED above the [On/Standby] key indicates the instrument state, see [Chapter 3.1.12, "Switching on or off"](#), on page 31.

3.2.1.4 Function keys

Function keys provide access to the most common generator settings and functions. You can find a detailed description of the corresponding functions in the user manual.

Table 3-4: Function keys

Function key	Assigned functions
[Freq]	Activates frequency entry.
[Level]	Activates level entry.
[Mod on/off]	Switches the modulation on and off.
[RF on/off]	Switches the RF output on and off.

3.2.1.5 Keypad

The keypad enables you to enter alphanumeric parameters, including the corresponding units. It contains the following keys:

Table 3-5: Keys on the keypad

Type of key	Description
Alphanumeric keys	Enter numbers and (special) characters in edit dialog boxes.
Decimal point	Inserts a decimal point "." at the cursor position.
Sign key	Changes the sign of a numeric parameter. For an alphanumeric parameter, inserts a "-" at the cursor position.
Unit keys (G/n dBμV, M/μ μV, k/m mV and x1 dB(m))	These keys add the selected unit to the entered numeric value and complete the entry. For level entries (e.g. in dB) or dimensionless values, all units have the value "1" as multiplying factor. Thus, they have the same function as an [Enter] key.

3.2.1.6 Navigation controls

The navigation controls include a rotary knob, navigation keys, and the display keys. They allow you to navigate within the display or within dialog boxes.

Rotary knob

The rotary knob has several functions:

- Increments (clockwise direction) or decrements (counterclockwise direction) numeric instrument parameters at a defined step width.
- Moves the selection, e.g. to a function block in the block diagram
- Shifts the selection bar within focused areas (e.g. lists).
- Acts like the [Enter] key, when it is pressed.
- Opens a context-sensitive menu, when it is pressed and held.

Editing keys

Editing keys enable you to confirm an entry, delete individual characters, or exit the current operation.

Table 3-6: Editing keys

Type of key	Description
[Esc] key	<p>Closes all kinds of dialog boxes, if the edit mode is not active. Quits the edit mode, if the edit mode is active. Equals selecting the "Cancel" button in dialogs, if provided.</p> <p>For "Edit" dialog boxes, the following applies:</p> <ul style="list-style-type: none"> • If data entry has been started, it retains the original value and closes the dialog box. • If data entry has not been started or has been completed, it closes the dialog box.
[Enter] key	<p>Has the same effect as pressing the rotary knob.</p> <ul style="list-style-type: none"> • Concludes the entry of dimensionless entries. The new value is accepted. • With other entries, this key can be used instead of the default unit key. • In a dialog box, selects the default or focused element. • Calls the next dialog level. • Confirms and closes open input windows.
[Backspace] key	Deletes the character to the left of the cursor in editing mode.

Navigation keys

As an alternative to the rotary knob or the touchscreen, you can use the navigation keys to navigate through dialog boxes, diagrams, or tables.

Table 3-7: Navigation keys

Type of key	Description
[Up/Down] Key	<p>The [Up] and the [Down] key does the following:</p> <ul style="list-style-type: none"> • In a numeric edit dialog box, increase or decrease the instrument parameter. • In a list, scroll forward and backward through the list entries. • In a table, move the selection bar vertically. • In windows or dialog boxes with vertical scrollbar, move the scrollbar.
[Left/Right] Key	<p>The [Left] and the [Right] key does the following:</p> <ul style="list-style-type: none"> • In an alphanumeric edit dialog box, move the cursor. • In a list, scroll forward and backward through the list entries. • In a table, move the selection bar horizontally. • In windows or dialog boxes with horizontal scrollbar, move the scrollbar.

3.2.1.7 Display keys

The display keys arrange different windows on the display.

Table 3-8: Display keys

Display key	Assigned functions
[Home]	Returns to the initial feature screen.
[Next window]	Toggles between the entry fields in the taskbar.
[On/Off]	<ul style="list-style-type: none"> • Switches highlighted elements or a function block on and off. • Switches between two or more settings, e.g. items of selection lists. At the end of a list, the cursor is set on the first entry again.
[Undo]	Reverts the last operation.
[★ (User)]	Adds a parameter to the user menu for quick access.

3.2.1.8 SD card slot

Option: R&S SMAB-B85

Slot for removable mass storage.

To prevent from unauthorized removal, the SD card holder includes wholes that provide the opportunity of sealing the SD card. We recommend that you seal the SD card crosswise.

3.2.1.9 USB connector

Female USB type A connector, to connect devices like a keyboard, a mouse, a memory stick, or the R&S NRP-Z3/Z4 cable for the R&S NRP power sensors.

How to: [Chapter 3.1.8, "Connecting USB devices"](#), on page 28

3.2.1.10 Sensor

Connector for R&S NRP sensors.

A power sensor is connected to the R&S SMA100B by inserting the male connector. To disconnect, pull the connector by its sleeve. You cannot disconnect the sensor simply by pulling at the cable or the rear part of the connector.

The R&S SMA100B supports the use of R&S NRP power sensors in various ways including the use as a power viewer.



The female connector allows the mechanical connection of 6-pole and 8-pole male connectors.

It mates with the interface cables R&S NRP-ZK8 and R&S NRP-ZK6, used for connecting R&S NRPxx power sensors, and also with the six-pole push-pull plugs of the R&S NRP-Zxx series.

However, the signal pair of the common time base clock assigned to the two pins in the center of the male connectors is not available. These pins are used by Rohde & Schwarz power meters to synchronize several power sensors.

Further information on connecting and using power sensors, see [Chapter 8.4.1, "Connecting R&S NRP power sensors to the R&S SMA100B"](#), on page 230, [Chapter 8.4.4, "NRP-Z power analysis"](#), on page 242, [Chapter 8.4.2, "NRP sensor mapping"](#), on page 231, [Chapter 8.4.4, "NRP-Z power analysis"](#), on page 242 and [Chapter 8.3, "User correction"](#), on page 218.

3.2.1.11 RF 50 Ω

Output of the RF signal.

The connector type depends on the installed frequency option.

Table 3-9: RF connector types of the frequency options

Installed RF frequency option	Connector type	Frequency range
R&S SMAB-B103	N female	$f_{\max} \leq 6 \text{ GHz}$
R&S SMAB-B106		
R&S SMAB-B112	PC 2.92 mm female Instrument equipped with interchangeable PC 2.92 mm test port adapter.	$f_{\max} \leq 40 \text{ GHz}$
R&S SMAB-B120		
R&S SMAB-B131		
R&S SMAB-B140(N)		
R&S SMAB-B150(N)	PC 1.85 mm female Instrument equipped with PC 1.85 mm inter- changeable female/female wear and tear adapter.	$f_{\max} \leq 67 \text{ GHz}$
R&S SMAB-B167(N)		



The PC 1.85 mm male connector for up to 67 GHz comes with a protective 1.85 mm female adapter to prevent the sensitive connector from damage.

It is available as a spare part, and can be replaced if damaged. Contact your Rohde & Schwarz support center or www.rohde-schwarz.com/support for information.

How to: [Chapter 3.1.10, "Connecting to RF 50 Ω"](#), on page 30

3.2.1.12 Pulse signal connectors

Pulse Sync

BNC connector for output of a signal to synchronize the pulse generator signal. The synchronization signal is generated at the beginning of each pulse. For double-pulse generation, the synchronization signal is generated at the beginning of the first pulse.

Pulse Video

BNC connector for output of the internal pulse generator signal or the looped through pulse signal from Pulse Ext connector (video signal).

See [Chapter 5.4.1, "Pulse modulation settings"](#), on page 82.

Pulse Ext

BNC connector for input of an external pulse modulation signal or an external trigger/gate signal for the pulse generator.

3.2.1.13 LF modulation connectors

LF

BNC connector for output of the internal LF generator signal.

See the data sheet and in the user manual, section [Chapter 5, "Analog modulations"](#), on page 79.

Ext

BNC connector for input of external analog modulation signals.

See [Chapter 5, "Analog modulations"](#), on page 79.

3.2.1.14 Clock synthesizer connectors

Clk Syn/Clk Syn N

SMA connectors for output of the clock synthesizer signal, or the inverted signal.

3.2.2 Rear panel tour

This section provides an overview of the connectors at the rear panel of the instrument. For technical data of the connectors, refer to the data sheet.




Figure 3-5: R&S SMA100B rear panel with height unit 2HU (option R&S SMAB-B92)

- 1 = Serial number (six digits in the string 1419.8888.02-<serial number>-<checksum>)
- 2 = IEC 625/IEEE 488
- 3, 5 = USB/USB In
- 4 = LAN
- 6, 7 = Ref In/Ref Out
- 8 = V/GHz X-Axis and Z-Axis
- 9 = Stop
- 10 = EFC
- 11 = Marker User1
- 12 = Inst Trig
- 13 = Signal Valid
- 14 = Clk Syn/Clk Syn N
- 15 = Pulse Sync, Pulse Video and Pulse Ext
- 16 = LF
- 17 = Ext 1/2
- 18 = AC power supply connector and switch
- 19 = RF 50 Ω




Figure 3-6: Rear panel view of the R&S SMA100B RF Signal Generator with height unit 3HU (option R&S SMAB-B93)

- 1 = Serial number (six digits in the string 1419.8888.02-<serial number>-<checksum>)
- 2 = IEC 625/IEEE 488
- 3, 5 = USB/USB In
- 4 = LAN
- 6, 7 = Ref In/Ref Out

- 8 = V/GHz X-Axis and Z-Axis
- 9 = Stop
- 10 = EFC
- 11 = Marker User1
- 12 = Inst Trig
- 13 = Signal Valid
- 14 = Clk Syn/Clk Syn N
- 15 = Pulse Sync, Pulse Video and Pulse Ext
- 16 = LF
- 17 = Ext 1/2
- 18 = AC power supply connector and switch
- 19 = RF 50 Ω

3.2.2.1 Connectors

IEC 625/IEEE 488

Option: R&S SMAB-B86

General purpose interface bus (GPIB) interface for remote control of the instrument. The interface is in compliance with the standards IEC 625, IEEE 488 and SCPI.

Use this interface to connect a computer for remote control of the R&S SMA100B. To set up the connection, use high-quality shielded cables. See ["Cable selection and electromagnetic interference \(EMI\)"](#) on page 26.

See also [Chapter A.2.1, "GPIB-Bus interface"](#), on page 806 and [Chapter 13, "Network operation and remote control"](#), on page 378.

USB/USB In

- Female USB (universal serial bus) 2.0 connector of type A (host USB), to connect devices like a keyboard, a mouse, a memory stick, or the R&S NRP-Z3/Z4 cable for the R&S NRP power sensors
- Option: R&S SMAB-B86
Female USB 3.0 connector of type Micro-B (USB In), for example, for remote control.

How to: [Chapter 3.1.8, "Connecting USB devices"](#), on page 28

LAN

RJ-45 connector to connect the R&S SMA100B to a LAN for remote control, remote operation, and data transfer.

How to: [Chapter 3.1.7, "Connecting to LAN"](#), on page 27

Ref In/Ref Out

Input/output for external reference signal.

BNC connectors for reference signals from 1 MHz to 100 MHz.

SMA connectors for 1 GHz reference signals.

How to: [Chapter 3.1.11, "Connecting to Ref In/Ref Out"](#), on page 31

V/GHz X-Axis

BNC connectors for output of a voltage ramp signal:

- "V / GHz": the voltage is proportional to the frequency.
- "X-Axis": output of a voltage ramp for the X deflection of an oscilloscope or an XY recorder.

Z-Axis

BNC connector for output of a voltage pulse signal, e.g. for the combined blanking and marker generation of network analyzers.

Stop

BNC connector for input and output signals to stop a sweep in all modes.

This connector is bidirectional. Used as:

- "Input": enables you to stop a sweep triggered by an external network analyzer.
- "Output": enables the R&S SMA100B to stop the sweep of an external network analyzer.

EFC

BNC connector for input of an EFC (external frequency control) signal for electronic tuning of the internal reference frequency.

See [Chapter 9, "Reference oscillator"](#), on page 291.

Marker User1

BNC connector for output of a marker or trigger signal.

Inst Trig

BNC connector for input of external trigger signals. The signals trigger sweeps and list mode.

See [Chapter 7.1, "Signal generation and triggering in the sweep and list modes"](#), on page 170.

Signal Valid

BNC connector for output of a signal that determines the valid signal times (valid level and frequency) for all analog modulations.

Clk Syn/Clk Syn N

SMA connectors for output of the clock synthesizer signal, or the inverted signal.

Pulse Ext

BNC connector for input of an external pulse modulation signal or an external trigger/gate signal for the pulse generator.

Pulse Video

BNC connector for output of the internal pulse generator signal or the looped through pulse signal from Pulse Ext connector (video signal).

See [Chapter 5.4.1, "Pulse modulation settings"](#), on page 82.

Pulse Sync

BNC connector for output of a signal to synchronize the pulse generator signal. The synchronization signal is generated at the beginning of each pulse. For double-pulse generation, the synchronization signal is generated at the beginning of the first pulse.

LF

BNC connector for output of the internal LF generator signal.

See the data sheet and in the user manual, section [Chapter 5, "Analog modulations"](#), on page 79.

Ext 1/2

BNC connectors for input of external analog modulation signals.

See [Chapter 5, "Analog modulations"](#), on page 79.

AC power supply connector and switch

Mains power switch for performing the following tasks:

- Connecting the internal power supply to the power source
- Disconnecting the internal power supply from the power source

How to: [Chapter 3.1.6, "Connecting to power"](#), on page 27.

RF 50 Ω

Rear panel connector for the RF signal. This connector is for use of the instrument in a 19" rack.

How to:

- [Chapter 3.1.4.2, "Mounting the R&S SMA100B in a rack"](#), on page 25
- [Chapter 3.1.10, "Connecting to RF 50 \$\Omega\$ "](#), on page 30

3.3 Trying out the instrument

This chapter introduces the first steps with the R&S SMA100B. It shows how to operate and configure the instrument using simple examples. The complete description of the functionality and its usage is given in the R&S SMA100B user manual. Basic instrument operation is described in [Chapter 3.4, "Instrument control"](#), on page 51.

Prerequisites

The instrument is set up, connected to the power supply, and started up as described in [Chapter 3.1, "Preparing for use"](#), on page 23.

The first signal generation tasks explain how to generate an unmodulated signal, to configure the RF signal output, and how you can vary the RF frequency and level in sweep mode.


The instrument is manually operated via the touchscreen. Try out the following:

- [Generating an unmodulated carrier](#)..... 44
- [Generating an RF frequency sweep signal](#).....46
- [Saving and recalling settings](#)..... 48

3.3.1 Generating an unmodulated carrier

We start to generate a simple unmodulated signal. In this example, the R&S SMA100B can be in its minimal configuration.

1. On the R&S SMA100B front panel, press the [Preset] key to set a defined initial instrument state.
2. Set the frequency:
 - a) In the "Status Bar", tap the "Frequency" field.
 - b) On the on-screen keypad, enter "6" and press the "GHz" key.



The on-screen key pad closes and the frequency value is displayed.

3. To set the signal level, tap the "Level" field and enter the level in the same way.
4. To activate RF signal output, select "Level" > "RF On" in the tile diagram.

Frequency 6.000 000 000 000 GHz		Level -25.00 dBm
Modulation <i>configure AM, FM, Phase and Pulse Modulation</i> Mod Off	Frequency Ref Out: 10 MHz Int Ref	Level Limit: 30.00 dBm Level <input checked="" type="checkbox"/> RF ON
System Config IP: 10.124.0.207 GPIB Address: 28 FW: 4.15.148	Sweep <i>configure RF-, LF-, Level Sweep and List Mode</i>	Level... Attenuator... Automatic Level Control...

The blue colored "RF On" icon indicates that the RF output is activated.

The R&S SMA100B provides the 6 GHz signal at the RF A connector at the front panel.


Frequency 6.000 000 000 000 GHz		Level -25.00 dBm
Modulation <i>configure AM, FM, Phase and Pulse Modulation</i> Mod Off	Frequency Ref Out: 10 MHz Int Ref	Level Limit: 30.00 dBm RF On
System Config IP: 10.124.0.207 GPIB Address: 28 FW: 4.15.148	Sweep <i>configure RF-, LF-, Level Sweep and List Mode</i> 	Clk Syn / Pow Sens <i>configure Clock Synthesis and Power Sensor Applications</i> Clock Syn Off

Figure 3-7: Generating an unmodulated signal

Alternative ways to access the instrument functions

To fulfill the same task, you can also use the front panel keys or the setting parameters provided in the frequency and level dialogs.

Try out the settings dialogs

1. In the "Frequency" tile, select "Frequency...".
 - a) In the "RF Frequency" tab, tap the "Frequency" field.
 - b) Set the frequency via the on-screen keypad.
2. Access the "RF Level" dialog via the "Level" tile.
 - a) In the "RF Level" tab, select "Amplitude".
 - b) Set the amplitude (level) via the on-screen keypad.
3. Select "RF State > On" to activate the RF signal generation.

See [Chapter 4, "RF signal configuration"](#), on page 62.

Try out the front panel keys

- Use the [Freq], [Level], and [RF on/off] key on the front panel.



Connect RF 50 Ω of the R&S SMA100B to a signal analyzer, for example R&S®FSW, to display the generated signal.

For the required settings of the signal analyzer, refer to its user manual or its online help.


3.3.2 Generating an RF frequency sweep signal

The "Sweep" operating mode allows you to generate an RF signal with periodically varying frequencies or amplitudes.


This example deals with an RF signal with varying frequency and constant level. To configure the sweep, you need to determine a defined start and end frequency with constant time intervals between the frequency steps.

The sweep function does not require specific options.

1. On the front panel, press the [Preset] key to set a defined initial instrument state.
2. Set the signal output level, if required, e.g. set "Level > -25 dBm".
3. In the tile diagram, select "Sweep" > "Frequency Sweep".
4. In the "General" tab:



- a) Select "Mode > Auto" to run the sweep continuously.
 - b) Select "Shape > Sawtooth" to set the waveform shape of the sweep signal.
 - c) Select "Spacing > Linear", to determine the calculation method for the frequency shift of a step.
 - d) Set "Dwell Time > 15.0 ms", to determine the time interval of the sweep steps.
5. Select the "Frequency Range" tab.



- a) Set "Start Freq > 200 MHz" and "Stop Freq > 600 MHz" to determine the frequency sweep range.
 - b) Set the step width "Step Lin > 10.0 MHz" to determine the width for a frequency step.
6. In the "General" tab, activate the frequency sweep with "State > On".
 7. Close the sweep dialog.
(Alternatively, tap the "Home" button to minimize the dialog. The R&S SMA100B indicates the "Sweep" dialog as active dialog in the task bar.)

8. To activate the RF signal output, select "Level" > "RF On".




Figure 3-8: Generating a frequency sweep signal

The frequency field in the status bar indicates the continuously changing frequency, i.e. the running sweep.


3.3.3 Saving and recalling settings

To restore the results of our measurements later, we save the instrument settings in a file.

To save the instrument settings in a file

We assume, a test configuration as described in [Chapter 3.3.2, "Generating an RF frequency sweep signal"](#), on page 46.

1. Press the [Setup] key on the front panel.
2. In the "Setup" menu, select "Settings > Save/Recall".
3. In the "Save/Recall" dialog, select "Operation Mode > Save".




4. Tap the "Filename", use the on-screen keyboard, and enter *MyTestSignal*.
5. Tap the "Save" button.

The file `MyTestSignal.savrc1.txt` is stored in the default directory `/var/user/`.

To load saved instrument settings

You can restore the settings to the instrument at any time using the settings file.

1. Press the [Preset] button to restore the default instrument settings so you can check that the stored user settings are restored afterwards.
2. Press the [Setup] key on the front panel.
3. In the "Setup" menu, select "Settings > Save/Recall".
4. In the "Save/Recall" dialog, select "Operation Mode > Recall".
Navigate to the directory the file is saved in and select the `MyTestSignal` file.



5. Tap the "Recall" button.

All instrument settings are restored and the display resembles [Chapter 3.3.2, "Generating an RF frequency sweep signal"](#), on page 46, which shows the instrument display right before the settings were saved.










How to display all parameters with values different to their preset values


When you load a file to your instrument, you do not have enough information on the changed settings. In such case, it is useful to visualize all parameters that have been changed from their default state.

Try out the following:

- Touch and hold a spot in the tile diagram for at least 1 second to access the context-sensitive menu.
- Select "Mark All Parameters Changed from Preset".

	Mark All Parameters Changed from Preset
	Start SCPI Recording
	Add to User Menu
	Undo
	Redo
	Help ...
	Key Emulation ...

- All changed parameters are highlighted.



See also [Chapter 11, "File and data management"](#), on page 305.

3.4 Instrument control

This chapter provides an overview on how to work with the R&S SMA100B.

It covers the following topics:

- [Possible ways to operate the instrument](#)..... 52
- [Means of manual interaction](#)..... 52
- [Understanding the display information](#)..... 53
- [Accessing the functionality](#)..... 56
- [Entering data](#)..... 57

• Getting information and help	59
• Remote control	60
• Remote operation over VNC	61

3.4.1 Possible ways to operate the instrument

There are three ways to operate the R&S SMA100B:

- **Manual operation:**
Use the touchscreen, hard keys and rotary knob, or an optional mouse and/or keyboard.
- **Remote control:**
Create programs to automatize repeating settings, tests and measurements. The instrument is connected to a computer running the program.
This way of operation is described in [Chapter 13, "Network operation and remote control"](#), on page 378.
- **Remote operation from a computer:**
Remote monitoring and control of the instrument from a connected computer is based on the common cross-platform technology VNC (Virtual Network Computing). On the remote computer, any standard web browser (supporting Java) or a dedicated VNC client (like Ultr@VNC) can be used. See also [Chapter 3.4.8, "Remote operation over VNC"](#), on page 61.

The following sections show how to operate the instrument manually.

3.4.2 Means of manual interaction

For the manual interaction with the R&S SMA100B, you have several methods that you can use as an alternative to perform a task:

- **Touchscreen:**
Touchscreen operation is the most direct way to interact. Almost all control elements and actions on the screen are based on the standard operating system concept. You can tap any user interface element to set parameters in dialog boxes, enter data, scroll within a dialog etc., as if you work with a mouse pointer.
Tapping the screen works like clicking mouse buttons:
 - Touch quickly = click: Selects a parameter or provokes an action.
 - Touch and hold = right-click: Opens a context-sensitive menu.
 - Touch and swipe = drag: Scrolls through the contents of a display element larger than the screen, e.g. a list or a table.
- **Function keys and rotary knob:**
The front panel provides nearly all functions and controls to operate the instrument in the classic way, without touchscreen.
- **Optional mouse and/or keyboard:**
These devices work like known from PCs. The navigation keys on the front panel correspond to the keys on the keyboard.

This manual describes the manual interaction with the instrument via the touchscreen. It mentions the alternative methods using the keys on the instrument or the on-screen keypads if it deviates from the standard operating procedures. The usage of the touchscreen and navigation keys is described in [Chapter 3.4.4, "Accessing the functionality"](#), on page 56.

Throughout the manual, the term "select" refers to any of the following methods:

- Using a finger on the touchscreen
- Using a mouse pointer in the display
- Using a key on the instrument or on a keyboard

3.4.3 Understanding the display information

The home screen of the R&S SMA100B displays all main settings and generator states, divided into three main operation areas.




Figure 3-9: Home screen

- 1 = Taskbar/softkey bar with "Home" and "System Config" key
- 2 = Status bar
- 3 = Tile diagram

• Status bar	54
• Tile diagram	54
• Taskbar	54
• Additional display characteristics	55

3.4.3.1 Status bar

The status bar at the top of the screen indicates the RF frequency and the level of the output signal provided to the DUT. You can set both parameters directly here.

3.4.3.2 Tile diagram

The tile diagram is the main entry to the settings of the R&S SMA100B.

Tile	Access to:
"Modulation"	<ul style="list-style-type: none"> Analog and stereo¹⁾, and pulse¹⁾ modulation settings Built in LF generator
"System Config"	<ul style="list-style-type: none"> "Save/Recall": settings for saving and loading instrument configurations "Remote access": Network and emulation settings. "Setup": general system configuration
"Sweep"	<ul style="list-style-type: none"> Frequency and level sweeps List mode
"Frequency"	<ul style="list-style-type: none"> RF frequency and phase Reference frequency
"Level"	<ul style="list-style-type: none"> RF level Attenuator Automatic level control User correction
"Clk Syn / Pow Sens"	<ul style="list-style-type: none"> Clock synthesis¹⁾ Power sensors
¹⁾ requires additional options	

3.4.3.3 Taskbar

The "Taskbar" shows a home and an info button, and assigns a labeled button whenever you open a dialog. If more dialogs are open than the taskbar can display, touch and swipe the taskbar to scroll up and down.

The buttons shown in the following example represent the variants.


Table 3-10: Example of buttons in the taskbar




"Home" button
Returns to the home screen.



"Busy" indicator
Indicates a running process.



"User Menu"
Lists parameters that can be defined for quick access.

SCPI, VNC, SMB	Shows the current remote access connections when the instrument is remotely controlled. Tip: An indicator in the "System Config" tile shows the current remote control status.
-67.74 dBm 1: NRP18S	R&S NRP power sensors Shows a connected external power sensor. The button displays the current readings when the sensor is active.
RF Level/EMF ALC/UCOR Pulse Modulation	Active dialogs Indicates the dialog name of each active dialog in a separate button.
 Info	"Info" key Provides access to status and error messages. Note: The warning symbol signifies a permanent error message.

3.4.3.4 Additional display characteristics

The following section provides a short insight on the indication of the screen in general, and significant elements that you see under specific operating modes, in dialogs or settings.

- **Appearance of active elements**
 - *Active* elements like On/Off switches, state buttons have a **blue** background.
 - *Selected* elements are framed or highlighted **orange**.
 - *Inactive* elements are **gray**.
- **On-Screen keypads**
As additional means of interacting with the instrument without having to connect an external keyboard, either a numerical or alphanumerical on-screen keypad appears when you activate an entry field (see [Chapter 3.4.5, "Entering data"](#), on page 57).
- **Info line**
The "Info line" shows brief status information and error messages. It appears when an event generates a message. If selected, the R&S SMA100B shows information on static errors and the error history.




- **Key parameters indicated in tab labels**
Most dialogs are divided into tabs with logically grouped parameters. The tab label expresses the content and can also contain status indicators or the set value of a key parameter.
- **Scroll bar handle**
An arrow icon that appears when you touch a scroll bar helps you to scroll in a dialog or list.
If no scrollbar handle appears, you can touch and swipe an element to scroll up and down.

- **Progress indicators**

A busy icon indicates a currently running process. If a process takes some time, a progress bar shows the current state.

- **Context-sensitive menus**

Within the entire screen display, including single parameters, you can access context-sensitive menus that provide some additional functions.



3.4.4 Accessing the functionality

All functionalities are provided in dialog boxes as known from computer programs. You can control the instrument intuitively with the touchscreen. This section provides an overview of the accessing methods.

The instrument's functions and settings can be accessed by selecting one of the following elements:

- System and function keys on the front panel of the instrument
- Taskbar/softkeys on the touchscreen
- Context-sensitive menus for specific elements on the touchscreen, or with the rotary knob (press and hold).
- Elements on the status bar in the touchscreen
- Displayed setting on the touchscreen that means block diagram and all settings available in dialogs.

To open a dialog box

- ▶ Perform one of the following actions:

- Tap the required tile, and then the menu entry.
- Tap the minimized view (button) on the taskbar.

Some of the utility keys access a dedicated dialog, too.

To minimize a dialog box

1. To return to the home screen, tap the "Home" button.
2. To switch to another dialog, press the [Next Window] button.

To close a dialog box

To close a dialog box, you have the same controls as you know from computers or devices with touchscreen.

- ▶ Perform one of the following actions:
 - Tap the "Close" icon in the upper right corner.
 - Press the [Esc] key on the front panel.
 - Drag and drop a minimized dialog from the taskbar to the tile diagram.

To select an option in a dialog box

- ▶ Tap the required option.

3.4.5 Entering data

Some parameters have their own key on the front panel.

For data input in dialog boxes, the instrument provides on-screen keypads for entering numeric and alphanumeric values. Thus, you can always set the parameters via the touchscreen, the front panel, or an external keyboard.

To correct an entry

1. Using the arrow keys, move the cursor to the right of the entry you want to delete.
2. Press the [Backspace] key.
3. Deletes the entry to the left of the cursor.
4. Enter your correction.

To complete the entry

- ▶ Press the [Enter] key or the rotary knob.

To abort the entry

- ▶ Press the [Esc] key.
The dialog box closes without changing the settings.

3.4.5.1 Entering numeric parameters

To enter values with the on-screen keypad

For numeric settings, the instrument displays the numeric keypad. The units specified correspond to the units of the parameter.

1. Enter the numeric value.

Tip: For quick entry, you can enter a value in exponential representation, e.g. $1e7$ for 10000000 .

2. Tap the unit button to complete the entry.

The unit is added to the entry.

Tip: For quick unit change, you can enter shortcuts, e.g. for a frequency value $1e8h$ for 100 MHz .

For an overview of shortcuts supported by the R&S SMA100B, see [Chapter C, "Unit shortcuts"](#), on page 809.

3. If the parameter does not require a unit, confirm the entered value by pressing "Enter".

To enter values by using the front panel controls

1. Change the currently used parameter value by using the rotary knob or the [Up/Down] keys.
2. If the parameter does not require a unit, confirm the entered value by pressing the [Enter] key or any of the unit keys.
The instrument highlights the editing line to confirm the entry.


If you edit numeric data in tables, the entry field must be in edit mode: Press [Enter], or the rotary knob to activate the edit mode.

3.4.5.2 Entering alphanumeric parameters

If a field requires alphanumeric input, you can use the on-screen keyboard to enter letters and (special) characters.

3.4.5.3 Undo and redo actions

Accessed via the context-sensitive menus, "Undo" allows you to restore one or more actions on the instrument. Depending on the available memory, the "Undo" steps can restore all actions.



"Redo" restores a previously undone action.

3.4.6 Getting information and help

In some dialog boxes, graphics are included to explain the way a setting works.


For further information, you can use the following sources:

- Tooltips give the value range of the parameter.
- The context help provides functional description on a setting.
- The general help explains a dialog box, provides instructions, and general information.

To display context help

- ▶ To access a help topic, perform one of the following:
 - a) Tap and hold the parameter for which you need information and tap "Help" in the context menu.
 - b) Tap the parameter and press the [Help] key.

The "Help" dialog opens. You can browse the help for further information.



Contents of the help dialog box

The help dialog box covers two main areas:

- "Contents" - contains a table of help contents
- "Topic" - contains a specific help topic

The help system also provides an "Index" and a "Find" area, and "Zoom" functions that are accessed via the corresponding buttons.

To open general help

- ▶ Press the yellow [Help] key on the front panel.

If a dialog box is opened, the help topic for the current tab is shown. Otherwise the "Contents" page appears.

Navigating in the table of contents and in the help topics

1. To move through the displayed contents entries, tap on an entry and scroll or use a connected mouse or the [Up/Down] keys.
Entries with a plus sign contain further entries.
2. To display a help topic, tap on the topic name or double-click the topic name or press the [Enter] key.
3. To follow a cross-reference, tap on the link text.
4. To return to the previous page, select "Back".
This function scrolls back all steps you have performed before.
5. Use the "scroll bars" to shift the visible section of content shown.
6. To maximize the "Topics" area, tap the "Hide Contents Tree" button to hide the contents tree.

Using the index

1. Select the "Index" button.
2. Enter the first characters of the topic you are interested in.
The entries starting with these characters are displayed.
3. Tap on the index entry.
The corresponding help topic is displayed.

3.4.7 Remote control

In addition to working with the R&S SMA100B interactively, located directly at the instrument, it is also possible to operate and control it from a remote PC.

The R&S SMA100B supports various methods for remote control:

- Connecting the instrument to a LAN (see [Chapter 3.1.7, "Connecting to LAN"](#), on page 27)
- Using the LXI browser interface in a LAN
- Connecting a PC via the IEC-bus (IEEE 488) interface
- Remote control via the USB interface



For remote control over LAN or USB, you can use the R&S VISA (Virtual Instrument Software Architecture) library provided for download at the Rohde & Schwarz website <http://www.rohde-schwarz.com/rsvisa>.

How to configure the remote control interfaces is described in [Chapter 13, "Network operation and remote control"](#), on page 378.

3.4.8 Remote operation over VNC

The VNC is an application which can be used to access and control the instrument from a remote computer through a LAN connection. While the instrument is in operation, the instrument screen contents are displayed on the remote computer, and VNC provides access to all applications, files, and network resources of the instrument. Thus, remote operation of the instrument is possible.



Instrument control from a remote computer

To access the basic utility functions of the R&S SMA100B, perform a right mouse click the block diagram and select "Key Emulation".

A key panel to the right of the block diagram gives access to the utility functions provided by the front panel keys.

The VNC is an add-on program, included in operating system Linux/Unix, and available as a free-of-charge download on the internet.

See also [Chapter 13.14, "To operate the instrument using VNC"](#), on page 452.

4 RF signal configuration

The R&S SMA100B signal generator generates RF signals with outstanding spectral purity within the frequency range from 8 kHz up to 20 GHz and with adjustable signal level over a wide range.

In addition to these real-time CW signals, you can generate RF signals from predefined lists and sweep signals that vary according to the frequency or amplitude curves.

You can also apply versatile analog modulation types with definable characteristics.

The variably adjustable output level due to the built-in attenuator, allows you to vary the RF signal level over the full level range. Several methods enable you to improve the signal performance and to optimize the signal quality for the particular application, or to increase the accuracy and reliability of the generated RF signal.

The R&S SMA100B supports R&S NRP power sensors, e.g. to monitor the output level of the generator or to determine the level correction values for user correction lists.

Signal modes and characteristics

The R&S SMA100B generates unmodulated or analog modulated RF signals. You can output the signal in fixed mode or as a signal with periodically varying frequencies or amplitudes.

Signal modes for RF signal generation:

- Unmodulated signal
Generates an unmodulated continuous wave (CW) of constant frequency and amplitude.
For information on the signal frequency and level settings and an example on how to configure a simple CW signal, see:
 - [Chapter 4.5, "RF frequency settings"](#), on page 69
 - [Chapter 4.6, "RF level settings"](#), on page 72
 - [Chapter 3.3.1, "Generating an unmodulated carrier"](#), on page 44
- Analog modulated signal
Modulates the signal with an analog signal and generates amplitude, phase, frequency and pulse modulation.
See [Chapter 5, "Analog modulations"](#), on page 79.

The R&S SMA100B allows you to provide the RF signal with constant or varying frequencies and/or amplitudes at the output:

- Constant frequency and level (CW/Fixed mode)
The RF output signal has the set frequency and level.
- Varying frequency and/or level
 - Sweep mode
An RF or LF frequency and RF level sweep signal, processed continuously, step-by-step or individually and with selectable trigger modes. You can only run one sweep at a time.
 - List mode

The RF signal is based on a list of predefined frequency and level values pairs and step widths.

See [Chapter 7, "List and sweep mode"](#), on page 168.

4.1 Activating RF signal output

By default, the RF output signal is deactivated.

To activate the RF output signal

1. Configure the RF signal as required.
Set, for example, the frequency and level values.
2. Activate the RF output in one of the following ways:
 - a) Select "Level" > "RF ON" > "On"
 - b) Press the [RF on/off] key at the front panel.

When activated, the "RF On" icon in the "Level" tile turns blue.

RF State/RF ON	63
RF output impedance	63

RF State/RF ON

Activates or deactivates the RF output.

Acts as the [RF on/off] key.

Remote command:

[:OUTPut<hw>\[:STATe\]](#) on page 511

RF output impedance

You can query the impedance of the RF output.

Remote command:

[:OUTPut<hw>:IMPedance?](#) on page 512

4.2 How to set the frequency and level

The simplest form of the RF signal is a continuous wave (CW) of constant frequency and amplitude. The RF signal is defined by its frequency, level and phase.

To configure the RF signal.

1. Use one of the following:

- a) In the home screen select:
 - "Frequency" and "Level" in the status bar
 - "Frequency" in the "Frequency" tile
 - "Level" in the "Level" tile
 - "Phase" in the "Frequency" tile
- b) On the front panel:
 - Press the [Freq] key
 - Press the [Level] key

2. Enter the values as required.

The R&S SMA100B indicates the frequency and level settings in the status bar of the home screen, and shows active functions and parameters of the RF signal in the "Frequency" and "Level" tiles.

See ["RF frequency and level display with a downstream instrument"](#) on page 64.

RF frequency and level display with a downstream instrument

If your test setup includes a downstream instrument, you can enter the parameter of the downstream instrument in the frequency or level settings dialog of the R&S SMA100B. Examples of downstream instruments are mixers, frequency multipliers, amplifiers or attenuators and of their corresponding major parameters offset, multiplier, amplitude. The R&S SMA100B generates the signal without the downstream parameters, but considers all additional parameters concerning the frequency and level.

Example parameters that affect the frequency and level:

- Frequency offset
- Multiplication factor
- User correction

Any of these cases are indicated by a dedicated icon, displayed in the "Frequency" or "Level" tile, depending on the affected parameter.

[Figure 4-1](#) illustrates the calculation of the "Frequency" and "Level" values, displayed in the status bar.




Figure 4-1: Frequency and Level display vs frequency and level at the RF output

f_{RF} , $Level_{RF}$	= Frequency and level ("Status bar > Frequency and Level") at the output of the downstream instrument, see also Calculation of f_{RF} and $Level_{RF}$)
$f_{RF\ Out}$, $Level_{RF\ Out}$	= Frequency and level at the output connector [RF 50 Ω] ("RF > RF Frequency > Frequency" and "RF > RF Level > Amplitude")
$n*f$	= Multiplication factor ("RF > RF Frequency > Multiplier")
Δf	= Frequency offset ("RF > RF Frequency > Offset")
$\Delta Level$	= Power offset ("RF > RF Level > Offset")

Calculation of f_{RF} and $Level_{RF}$

- $f_{RF} = n * f_{RF\ Out} + \Delta f$
- $Level_{RF} = Level_{RF\ Out} + \Delta Level$

4.3 Phase continuous frequency

The R&S SMA100B enables you to generate a phase continuous RF signal over a certain frequency range. In this mode, the output sine wave signal shows no phase discontinuity or glitch when changing the frequency, e.g. in sweep mode.

At frequency changes, the switching transitions (intermediate frequencies) cause spurs. The spurs are due to adjustments in the synthesizer, e.g. adjusting the settings of dividers, filters, phase detectors can lead to phase discontinuities.

The phase continuous mode freezes the settings of the synthesizer components which can generate phase discontinuities when adjusted. The R&S SMA100B performs the frequency changes with the fine resolution synthesizer. The result is a phase continuous change from one frequency to another without transients.

The available frequency range for continuous-phase signal generation is determined by the fine resolution synthesizer used. The frequency range varies according to the RF frequency set at the time you activate phase continuous mode.

Equipped with the ultra low phase noise option (R&S SMAB-B711), the R&S SMA100B enables you to select between two frequency ranges, either to achieve a higher signal quality or an especially wide frequency range.

4.3.1 How to generate a phase continuous RF signal

To achieve an output sine wave signal with no phase discontinuity or glitch when changing the frequency, e.g. in RF frequency sweep mode, you can use the phase continuous mode provided by the instrument.



Activating frequency or phase modulation deactivates phase continuous mode and vice versa.

To select the phase continuous frequency mode

The following example requires, that the instrument is equipped with the option R&S SMAB-B711.



Before setting the parameters and activating the phase continuous mode, turn off active sweeps.

1. If the "RF Frequency Sweep" is running, select "Sweep" > "RF Frequency Sweep".
2. Turn off "State".
3. On the home screen, select "Frequency" > "Phase".
4. Turn off "Phase Continuous Active", if enabled.
5. Select "Frequency Range" > "Narrow".
6. Check if the range displayed in "Frequency Range From" and "To", corresponds to your range selection.
7. IF the displayed frequency range does not correspond to the selection, select "Frequency Range > Wide" (requires option R&S SMAB-B711).
8. If the displayed range corresponds to the selection, enable "Phase Continuous Active".
9. In the "RF Frequency Sweep" dialog
 - a) Modify the "Start Freq" and "Stop Freq" or "Center Frequency" and "Span" as needed.
 - b) Set the RF frequency sweep state to "ON".







To set a phase continuous frequency sweep

1. On the home screen, select "Sweep" > "RF Frequency Sweep" > "Frequency Range".
2. Set the "Start Frequency" and "Stop Frequency" or "Center Frequency" and "Span" for the sweep range.
3. In the "General" tab, configure the sweep parameters as required.
4. Turn on "State" to start the sweep signal generation.

4.4 RF connector settings


Access:

1. Select "Frequency" > "RF Connectors".

RF Connectors			
Signal	Connector	Show	
Instr. Trigger ...		 ...	
External Mod. ...	EXT 1	 ...	
External Mod. ...	EXT 2	 ...	
LF Output ...	LF Out	 ...	
Ref. Freq. Input ...	Ref In	 ...	
Ref. Freq. Output ...	Ref Out	 ...	
Signal Valid	Signal Valid		
Pulse In ...	Pulse Ext		
Pulse Video ...	Pulse Video		

The "RF Connectors" dialog shows the assignment of the logical signals to the connectors. The connectors displayed depend on the options installed.

2. Select a "Signal" to access the corresponding settings dialog or directly set signal characteristics.
3. Use the built-in [Show Connector](#) function to display the physical location of the selected connector.

The eye icon  in the tab header indicates the panel (front, rear or both) the selected connector is at.

**Settings:**

Signal.....	68
Connector.....	69
Show Connector.....	69

Signal

Displays the signal that is assigned to the connector.

Selecting a signal accesses the settings dialog for configuring the signal, or setting signal characteristics directly.

For additional information on the connectors, see:

- [Chapter 3.2.2.1, "Connectors"](#), on page 41
- ["Signal output"](#) on page 80 for the assignment of the input and output connectors used for analog modulation signals.

"Instr. Trigger"	Input of an external trigger signal for sweep and list modes, see Chapter 7.1, "Signal generation and triggering in the sweep and list modes" , on page 170.
"External Mod..."	Input of an external modulation signal, see "Signal sources" on page 79.
"LF Output"	Output of the internal LF generator signal, Chapter 5.4.8, "LF signal output settings" , on page 118.
"Ref. Freq. Input"	Input of an external reference signal, see Chapter 9.2, "Reference frequency settings" , on page 291.

"Ref. Freq. Output"

Output of the internal reference signal, see [Chapter 9.3, "Reference output settings"](#), on page 295 .

"Signal Valid" / "Signal Valid Neg."

Automatically generated output signal that identifies a valid signal time (level and frequency) for all analog modulation signals.
For "Signal Valid Neg." (inverted), the output signal is low during the valid signal time.

"Pulse In"

Input of an external pulse signal or input of external trigger/gate signal for the internal pulse generator (see [Chapter 5.4.4, "Pulse generator"](#), on page 96).

"Pulse Video"

Output of the internal pulse generator signal or the looped through "Pulse Ext" pulse signal (video signal), see [Chapter 5.4.1, "Pulse modulation settings"](#), on page 82.

Connector

Displays the assigned connector.

**Show Connector**

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.


4.5 RF frequency settings

Access:

1. Select "Frequency" > "RF Frequency".

RF Frequency	Phase	Output		✕
Frequency	1.000 000 000 000 GHz		Main PLL Bandwidth	Narrow
Offset	10.000 000 000 MHz		Multiplier	1.000
User Variation				
Variation Active	<input type="checkbox"/>		Variation Step	1.000 000 000 MHz

2. Observe the information on the home screen, "Frequency" tile.



The "Frequency" tile indicates the reference frequency, current frequency offset and multiplier values, and phase offset value.

In the "RF Frequency" dialog, you can configure:

- RF frequency, incl. an offset or multiplication factor of a downstream instrument
- The step size for varying the frequency with the rotary knob.

The remote commands required to define the settings are described in [Chapter 14.17.4, "SOURce:FREQuency subsystem"](#), on page 664.

Settings

Frequency.....	70
Main PLL Bandwidth.....	71
Offset.....	71
Multiplier.....	71
User Variation.....	71
L Variation Active.....	71
L Variation Step.....	71

Frequency

Sets the RF frequency.

This frequency is output at the RF 50 Ω connector. It does not consider an [Offset](#) or multiplication factor ([Multiplier](#)).

See ["RF frequency and level display with a downstream instrument"](#) on page 64.

Note: Suppressed values in the status bar

For security concerns or certain operating modes, you can hide the frequency and level display in the status bar.

- *********

The display has been disabled for security reasons.

See:

- [Annotation Frequency](#)
- [Annotation Amplitude](#)

- 

The display is disabled when list mode is running, see [Chapter 7, "List and sweep mode"](#), on page 168.

Remote command:

`[:SOURce<hw>] :FREQuency [:CW | FIXed]` on page 666

Main PLL Bandwidth

Selects the PLL (Phase Locked Loop) bandwidth of the **main synthesizer**.

"Normal" Default main PLL bandwidth.
The instrument provides the maximum modulation bandwidth and FM/PhiM deviation.

"Narrow" Sets the narrow PLL bandwidth.

Remote command:

[\[:SOURce<hw>\]:FREQuency:PLL:MODE](#) on page 671

Offset

Sets the frequency offset.

This value represents the frequency shift of a downstream instrument, like for example a mixer.

The "Frequency" value displayed in the status bar is the resulting frequency, as it is at the output of the downstream instrument. The frequency at the R&S SMA100B RF output is not changed.

See ["RF frequency and level display with a downstream instrument"](#) on page 64.

Remote command:

[\[:SOURce<hw>\]:FREQuency:OFFSet](#) on page 668

Multiplier

Sets the multiplication factor for the RF frequency.

This value represents the multiplication factor of a downstream instrument, as for example a multiplier. You can also assign a negative multiplication factor, for example -1.0 to support frequency converters working in the reverse frequency position.

The "Frequency" value displayed in the status bar is the resulting frequency, as it is at the output of the downstream instrument. The frequency at the R&S SMA100B RF output is not changed.

See ["RF frequency and level display with a downstream instrument"](#) on page 64.

Remote command:

[\[:SOURce<hw>\]:FREQuency:MULTiplier](#) on page 668

User Variation

Defines and activates a user-defined step width for varying the RF frequency or RF level with the rotary knob.

If disabled, the step width varies in steps of one unit at the cursor position.

Variation Active ← User Variation

Activates the set user-defined step width.

Remote command:

[\[:SOURce<hw>\]:FREQuency:STEP:MODE](#) on page 670

[\[:SOURce<hw>\]:POWer:STEP:MODE](#) on page 711

Variation Step ← User Variation

Sets the user-defined step width.

Remote command:


[:SOURce<hw>] :FREQuency:STEP [:INCRe ment] on page 671

[:SOURce<hw>] :POWer:STEP [:INCRe ment] on page 711

4.6 RF level settings


Access:

1. Select "Level" > "RF Level".




In the "RF Level" dialog, you can configure the offset-free level, the level limit, and the step width for varying the level with the rotary knob.

2. Select "User Variation" to set the step width to be used when setting the RF level using the rotary knob.



3. Observe the information on the home screen, "Level" tile.



The "Level" tile indicates the level limit, the user correction status and current correction value, current setting characteristics incl. mode.

The remote commands required to define the settings are described in [Chapter 14.17.11, "SOURce:POWer subsystem"](#), on page 704.

Settings

RF State/RF ON.....	73
Amplitude.....	73
Limit.....	74
Offset.....	74
Setting Characteristics.....	74
Harmonic Filter.....	75
Level Range.....	75
Readjust.....	76
User Variation.....	76
L Variation Active.....	76
L Variation Step.....	76

RF State/RF ON

Activates or deactivates the RF output.

Acts as the [RF on/off] key.

Remote command:

:OUTPut<hw> [:STATe] on page 511

Amplitude

Sets the level of the RF signal.

The value is offset-free and corresponds to the level at the RF 50 Ω connector.

See ["RF frequency and level display with a downstream instrument"](#) on page 64.

Note: Suppressed values in the status bar

For security concerns or certain operating modes, you can hide the frequency and level display in the status bar.

- *****

The display has been disabled for security reasons.

See:

- [Annotation Frequency](#)
- [Annotation Amplitude](#)



The display is disabled when list mode is running, see [Chapter 7, "List and sweep mode"](#), on page 168.

Remote command:

[\[:SOURce<hw>\]:POWer:POWer](#) on page 710

Note: The SCPI command [\[:SOURce<hw>\]:POWer\[:LEVel\]\[:IMMediate\]\[:AMPLitude\]](#) sets the level of the "Level" display.

This means, the level containing offset.

Limit

Sets an upper limit for the RF output power.

You can use this value to protect your DUT from damage due to high input power. If you enter an RF level above this value, the instrument limits the output power to this specified value, and generates the warning message:

"Pep value greater than the defined limit." However, the level indication in the status bar is not affected.

The setting is not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. It is reset only by factory preset.

Remote command:

[\[:SOURce<hw>\]:POWer:LIMit\[:AMPLitude\]](#) on page 708

Offset

Sets a level offset.

This value represents the level shift of a downstream instrument, like, for example, an attenuator or an amplifier.

The "Level" value displayed in the status bar is the resulting level, as it is at the output of the downstream instrument. The level at the R&S SMA100B RF output is not changed.

See ["RF frequency and level display with a downstream instrument"](#) on page 64.

Remote command:

[\[:SOURce<hw>\]:POWer\[:LEVel\]\[:IMMediate\]:OFFSet](#) on page 711

Setting Characteristics

Selects additional quality characteristics to optimize the behavior of the RF signal level for the specific application.

"Auto"	<p>Sets the RF output level automatically according to the selected mode.</p> <p>In this mode, the instrument provides the highest dynamic range and fastest setting times, as specified in the data sheet.</p> <p>The RF signal is shortly blanked when the step attenuator is switching.</p>
--------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

"Uninterrupted"

Suppresses blanking at level transitions. Frequency transitions can lead to an RF level blanking due to hardware specific switching points.

This mode reduces the dynamic range of the instrument. The step attenuator is fixed.

"Strictly Monotone"

Executes signal level changes monotonically increasing or decreasing.

The setting makes sure that increasing the level value exclusively results in an increased output level, and vice versa.

All electronic switches, which might affect the monotonicity are fixed. The operation mode is useful for applications using level searching algorithms which rely on a strictly monotonous behavior.

"Constant-VSWR"

Suppresses output impedance variations at the RF 50 Ω output connector, due to changed level settings.

"High Dyn. Uninterrupted"

R&S SMAB-K724

Provides a linear output power that is uninterrupted over a wide dynamic range.

Note: The R&S SMA100B supports this characteristic at frequencies above 52 MHz. If you select the setting at lower frequencies (≤ 52 MHz), the instrument reports a settings conflict.

"User"

Indicates that a setting has been modified in the expert mode. The expert mode is a protected function, that requires protection level 2 password.

Remote command:

`[:SOURce<hw>] :POWer:LBEHaviour` on page 708

Harmonic Filter

Activates low harmonic filter or enables its automatic switching.

"On"

Ensures best low harmonics performance but decreases the level range.

"Auto"

Applies an automatically selected harmonic filter that fits to the current level setting.

Remote command:

`:OUTPut<hw>:FILTer:MODE` on page 512

Level Range

Shows the interruption-free range of the level that you can use in the currently selected mode.

Remote command:

`[:SOURce<hw>] :POWer:RANGe:LOWer?` on page 713

`[:SOURce<hw>] :POWer:RANGe:UPPer?` on page 713

Readjust

Recalculates and adjusts the internal switch positions of the RF chain according to the current level.

In "External ALC" mode, "Readjust" triggers the detector offset zeroing, see [Chapter 8.2.2, "How to set up an external ALC"](#), on page 217.

Remote command:

`[:SOURce<hw>] :POWer:ALC:SONCe` on page 707

User Variation

Defines and activates a user-defined step width for varying the RF frequency or RF level with the rotary knob.

If disabled, the step width varies in steps of one unit at the cursor position.

Variation Active ← User Variation

Activates the set user-defined step width.

Remote command:

`[:SOURce<hw>] :FREQuency:STEP:MODE` on page 670

`[:SOURce<hw>] :POWer:STEP:MODE` on page 711

Variation Step ← User Variation

Sets the user-defined step width.

Remote command:

`[:SOURce<hw>] :FREQuency:STEP [:INCRement]` on page 671

`[:SOURce<hw>] :POWer:STEP [:INCRement]` on page 711

4.7 RF phase settings

The phase in sinusoidal signals defines the initial angle at its origin.

Access:

1. Select "Frequency" > "Phase".

In the "Phase" tab, you can activate the phase continuous mode, set the delta phase parameter and reset the phase to this reference.

2. Switch to the home screen, "Frequency" tile.

The R&S SMA100B indicates the configured settings.

The remote commands required to define the settings are described in [Chapter 14.17.10, "SOURCE:PHASe subsystem"](#), on page 703.

Settings

Phase Continuous Active	77
Frequency Range	78
Frequency Range From / To	78
Delta Phase	78
Reset Delta Phase Display	78

Phase Continuous Active

Activates generation of a phase continuous frequency signal.

The R&S SMA100B generates a phase continuous output sinewave, i.e. without phase discontinuity or glitch when changing the frequency.

For a given RF frequency, the frequency range is limited.

Remote command:

[\[:SOURCE<hw>\]:FREQUENCY:PHASe:CONTinuous:STATe](#) on page 673

Frequency Range

Selects the mode that determines the frequency range for the phase continuity of the RF signal.

The available frequency range depends on the selected mode and is limited by the resolution of the used synthesizer. It varies depending on the frequency, and is set when you activate the phase continuous settings.

"Narrow" Sets a small frequency range, asymmetrically around the RF frequency.

"Wide" Option: R&S SMAB-B711
Sets a large frequency range, symmetrically around the RF frequency.

Remote command:

[\[:SOURce<hw>\]:FREQuency:PHASe:CONTinuous:MODE](#) on page 672

Frequency Range From / To

Displays the frequency range for phase continuous settings.

The value range depends on the mode selected with [Frequency Range](#).

Remote command:

[\[:SOURce<hw>\]:FREQuency:PHASe:CONTinuous:LOW?](#) on page 672

[\[:SOURce<hw>\]:FREQuency:PHASe:CONTinuous:HIGH?](#) on page 671

Delta Phase

Sets the phase of the RF signal.

The current phase of the signal is used as the reference.

Remote command:

[\[:SOURce<hw>\]:PHASe](#) on page 703

Reset Delta Phase Display

Adopts the selected "Delta Phase" value as the current value, and resets delta phase to 0 degrees.

Remote command:

[\[:SOURce<hw>\]:PHASe:REFeRence](#) on page 703

5 Analog modulations

The R&S SMA100B supports AM (amplitude modulation), FM (frequency modulation), Φ M (phase modulation (PhiM)), and also PULM (pulse modulation). It generates low frequency signals (LF) as sine, triangle, trapezoidal or square (pulse) waveform, that can be output and further processed by a downstream instrument.

Option: R&S SMAB-K22, enables generation of chirp modulated RF signals.

5.1 Required options

R&S SMA100B base unit equipped with the following options:

- Option frequency (R&S SMAB-B10x)
- Option pulse modulator (R&S SMAB-K22)
- Option pulse generator (R&S SMAB-K23)
(supports generation of single and double pulse signals)
- Option multi-function generator (R&S SMAB-K24)
- Option pulse train generator (R&S SMAB-K27)
(requires R&S SMAB-K23)
- Option AM/FM/PhiM (R&S SMAB-K720)
- Option Scan AM (R&S SMAB-K720 and R&S SMAB-K721)
- Option Chirp Signal Generation (R&S SMAB-K725)
(requires R&S SMAB-K22
R&S SMAB-K23, providing extended ranges for resolution, pulse width and pulse period
R&S SMAB-K720)

For more information, see data sheet.

5.2 Modulation types and signal sources

Radio transmitters do not transmit an audio signal directly. Instead, they modulate the audio signal onto a continuous wave (CW) carrier with much higher frequency.

A CW carrier has a sinusoidal waveform with constant amplitude and constant frequency. Modulating a signal onto the carrier means varying a property of the carrier according to the modulating signal. The three basic modulation types FM, AM and PhiM for example, vary one property of the carrier proportional to the instantaneous amplitude of the modulating signal.

Signal sources

If fully equipped, the R&S SMA100B modulates signals from the following sources:

- **Internal modulation source**

- *Two LF generators*
Each of the LF generators provides a modulation signal with sine, pulse, triangle or trapezoid shape.
- *Noise generator*
The noise generator supplies white noise with selectable bandwidth and distribution.
- *High-performance pulse generator*
Generates single and double pulse, or pulse train signals.
- **External modulation source**
 - Amplitude, frequency or phase modulation signals are input at the Ext connector.
 - Pulse modulation signals, at the Pulse Ext connector.

Signal output

You can perform AM, FM and PhiM with the signal of any of the provided sources. Moreover, you can combine two modulation signals and generate a two-tone signal. Regardless of the signal source, the generated signal can be output for further processing in a downstream instrument.

Current configuration is indicated in the "Analog Modulations > Overview" dialog; the output signal routing can be changed, too.

Input and output connectors

Direction	Modulation	Connector	Required option
Output	Pulse modulation from internal signal Loop through of pulse signal from Pulse Ext	Pulse Video	R&S SMAB-K22/-K23
	All analog modulations Marks the valid level and frequency Inverted version; the output signal is low during the valid signal times.	Signal Valid Signal Valid Neg.	
	Chirp Modulation	Pulse Video Pulse Sync	R&S SMAB-K22/-K23
	Pulse generator	Pulse Sync	
	LF generator	LF	
Input	AM, FM, PhiM	Ext **)	R&S SMAB-K720
	Pulse modulation from external source*) Or External trigger or gate signal*)	Pulse Ext**)	R&S SMAB-K22

- *) External trigger signal and external signal for the pulse modulation cannot be used simultaneously, because these signals are expected at the same connector Pulse Ext. Signal polarity and impedance are the same for both signals.

- **) The external modulation signal must have a voltage of $U_S = 1 \text{ V}$ ($U_{EFF} = 0.707 \text{ V}$) to achieve the displayed modulation depth and range.
Note that the input voltage does not exceed 1 V, otherwise modulation distortions can occur.

For more information, see data sheet.

Interactions and characteristics

- FM and PhiM modulations exclude each other and cannot be performed simultaneously.
- In sweep mode, LF frequency sweep is possible.
- The settings of the modulation signal affect all analog modulations that use an internal modulation source.
- You can feed an external LF signal in each of the two paths.
- Considerations to AM when using an external modulation signal:
If external modulation is enabled, the RF output amplitude follows the external modulation signal with a scaling factor defined by the modulation sensitivity setting.

With **Coupling (AC/DC) > DC**, the RF output signal behaves according to:

- input signal = 0 V: the RF output amplitude corresponds to the level value set in the R&S SMA100B
- input signal = +1 V: the output level increases up to the maximum value given by the set modulation sensitivity
- input signal = -1 V: the output level decreases down to the minimum value given by the set modulation sensitivity

With **Coupling (AC/DC) > AC**, the modulation input signal is internally highpass filtered. Therefore, the DC content of the input signal is removed before it reaches the amplitude modulator.

- Using exponential amplitude modulation with an external source, sets the coupling of the corresponding input automatically to DC.
See also [Chapter 5.4.7.2, "Source > external settings"](#), on page 115.
- Scan AM
 - Scan AM provides the scan mode, i.e. an amplitude modulation depth with an extended dynamic range that automatically uses the exponential amplitude modulation type.
 - If you use Scan AM with an external modulation input signal, the voltage range is adjusted to $\pm 6 \text{ V}$ (usually $\pm 1 \text{ V}$). Therefore, we recommend that you do not use the external modulation signal for FM or PhiM in parallel, since the voltage affects the modulations.
- The amplitude modulation types linear and exponential derive the carrier signal either linear in percent / volt, or as complex exponential in dB / volt.
- For pulse modulated signals, you can select between fast or smoothed transitions, see ["Transition Type"](#) on page 84.
This setting is available over the entire frequency range for all instruments with frequency options up to 6 GHz. For higher frequency options, the frequency range for the smoothed setting is limited.
- Chirp modulation

- excludes PhiM, avionics and pulse modulation
- disables automatic level control (ALC)
- can not be operated with an external modulation signal

For more information, see data sheet.

5.3 Activating analog modulations

- ▶ Use one of the following:
 - Select "Modulation > Amplitude Modulation/Frequency Modulation/Phase Modulation > State > ON".
 - Select "Modulation > MOD ON".
 - Press the [Mod on/off] key.

[Mod on/off]

Activate one or more analog modulations and press the [Mod on/off] key to toggle the state of them all.

Pressing the key again restores the status that was active before the last switch-off.

Remote command:

`[:SOURce<hw>] :MODulation [:ALL] [:STATe]` on page 583

5.4 Modulation settings

Access:

- ▶ Select "Modulation" > "Modulation Sources".

The "Modulation" dialog contains all functions and settings to configure the analog modulations, the LF signal sources for performing a modulation, and the LF signal output.

The remote commands required to define these settings are described in:


- [Chapter 14.17.1.2, "SOURce:AM subsystem"](#), on page 584
- [Chapter 14.17.1.4, "SOURce:FM subsystem"](#), on page 594
- [Chapter 14.17.1.5, "SOURce:PM subsystem"](#), on page 599
- [Chapter 14.17.1.6, "SOURce:PULM subsystem"](#), on page 603
- [Chapter 14.17.1.3, "SOURce:CHIRp subsystem"](#), on page 590
- [Chapter 14.17.6, "SOURce:LFOutput subsystem"](#), on page 674

5.4.1 Pulse modulation settings

Option: see [Chapter 5.1, "Required options"](#), on page 79.

Access:

- Select "Modulation" > "Pulse Modulation".



The "Pulse Modulation" dialog contains all parameters required to configure the pulse modulator and the pulse generator. It also displays the pulse signal graphically.

For an overview of the supported signals sources and related connectors, see [Chapter 5.2, "Modulation types and signal sources"](#), on page 79.

The remote commands required to define these settings are described in [Chapter 14.17.1.6, "SOURce:PULM subsystem"](#), on page 603.

Settings:

State.....	83
Source.....	83
Transition Type.....	84

State

Activates pulse modulation and triggers the following automatic settings:

- Pulse generator is activated.
The signal is output at the Pulse Video connector.
To deactivate the signal output, set "Pulse Generator" > [Pulse Output State](#) > "Off".

Remote command:

[\[:SOURce<hw>\]:PULM:STATe](#) on page 607

Source

Selects between the internal "Pulse Generator" or an "External" pulse signal for the modulation.

"Pulse Generator"

Selects the internal generator.

See [Pulse generator](#).

"External"

Modulation source is fed to the input connector.

See ["Signal sources"](#) on page 79.

Remote command:

[:SOURce<hw>] :PULM:SOURce on page 607

Transition Type

Selects between "Fast" or "Smoothed" slew rate (slope).

"Fast" Enables fast transitions with shortest rise and fall times.

"Smoothed" Flattens the slew rate, resulting in longer rise / fall times. Use this mode if you are working with devices that are sensitive to steep slopes.

Note: The R&S SMA100B supports this functionality up to a certain frequency, depending on the installed frequency options, see also ["Interactions and characteristics"](#) on page 81.

For more information, see data sheet.

Remote command:

[:SOURce<hw>] :PULM:TTYPe on page 607

5.4.2 FM, PhiM and AM modulation settings

Option: R&S SMAB-K720

Access:

- Select "Modulation" > "Amplitude Modulation/Frequency Modulation/Phase Modulation".

Path 1		Path 2	
State	<input checked="" type="checkbox"/>	State	<input checked="" type="checkbox"/>
Source	LF Generator 1	Source	External 1
Deviation	1.000 00 kHz	Deviation	1.000 00 kHz
Deviation Mode	Fixed Ratio	Ratio Path 2 / Path 1	100.00 %
Mode	High Bandwidth		

The "FM", "ΦM" and "AM" tabs contain the parameters per modulation type.

Source

State.....	85
Source.....	85
FM settings.....	86
L Deviation.....	86
L Deviation Mode.....	86
L Total Deviation.....	86
L Ratio Path2/Path1.....	86
L Mode.....	87
PhiM settings.....	87
L Deviation.....	87
L Deviation Mode.....	87
L Total Deviation.....	88
L Ratio Path2/Path1.....	88
L Mode.....	88
AM settings.....	88
L Mode.....	89
L Type.....	89
L Depth.....	90
L Sensitivity.....	90
L Deviation Mode.....	90
L Total Depth.....	90
L Ratio Path2/Path1.....	91

State

Activates a modulation.

Note: Some modulations exclude each other and cannot be performed simultaneously. For more information, see data sheet.

Remote command:

[:SOURce<hw>] :AM<ch> :STATe on page 586

[:SOURce<hw>] :FM<ch> :STATe on page 596

[:SOURce<hw>] :PM<ch> :STATe on page 600

Source

Selects the LF signal source.

You can vary the signal sources for each of the modulations.

"LF Generator 1/2"

Selects one or both of the internally generated LF signals.

See [Chapter 5.4.7.1, "Source > LF generator settings"](#), on page 111.

"External 1/2" Selects an externally supplied LF signal.

"Noise Generator"

Selects the internally generated noise signal.

See [Chapter 5.4.7.3, "Source > noise generator settings"](#), on page 117.

Remote command:

[:SOURce<hw>] :AM<ch> :SOURce on page 587

[:SOURce<hw>] :FM<ch> :SOURce on page 596

[:SOURce<hw>] :PM<ch> :SOURce on page 601

FM settings

The following settings are dedicated to FM.

Deviation ← FM settings

Sets the frequency modulation deviation in Hz.

The maximal deviation depends on the RF frequency and the selected modulation mode (see data sheet).

Maximal possible deviation is selected automatically, if one of the following applies:

- The selected deviation is too high for the particular frequency
- The selected frequency is outside of the range where deviation is possible.

A warning message indicates this situation, too.

Remote command:

[:SOURce<hw>] :FM<ch> [:DEViation] on page 596

Deviation Mode ← FM settings

Enables you to couple the LF signal of both paths and determines the mode for fixing the total deviation.

The total deviation is the sum of both paths. When the sum is exceeded, the R&S SMA100B reports a settings conflict, but does not change the settings.

- | | |
|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| "Uncoupled" | Enables you to adjust the deviation for each path independently. |
| "Fixed Total" | Couples the deviation of both paths in per Hz. If you change the deviation of any path, the R&S SMA100B automatically adjusts the value of the other path. The sum always results in the set Total Deviation . |
| "Fixed Ratio" | Couples the deviation ratio of both paths. If you change the deviation of any path, the R&S SMA100B adjusts the value of the other path. |

Remote command:

[:SOURce<hw>] :FM:DEViation:MODE on page 597

Total Deviation ← FM settings

Sets the sum of the signal deviation for path 1 and path 2 in Hz when using combined sources in [Deviation Mode > Fixed Total](#).

[Deviation](#) of both paths always sum up to the value of the total deviation.

Behavior when changing any depth settings:

- Changing the total deviation adjusts the deviation of both paths proportionally.
- Changing the deviation of one path adjusts the deviation of the other path. The sum always results in the set total deviation.

Remote command:

[:SOURce<hw>] :FM:DEViation:SUM on page 597

Ratio Path2/Path1 ← FM settings

Sets the deviation ratio (path2 to path1) in percent.

Example:

If the deviation in path1 is 10 kHz and the ratio is 50%, the deviation in path 2 is automatically set to 5 kHz.

Remote command:

`[:SOURce<hw>] :FM:RATio` on page 598

Mode ← FM settings

Selects the mode of the frequency modulation.

"High Bandwidth"

The maximum range for modulation bandwidth is available.

"Low Noise"

Phase modulation with phase noise and spurious characteristics close to CW mode. The range for modulation bandwidth and FM deviation is reduced (see data sheet).

To reduce the phase noise further, set the [Main PLL Bandwidth](#) = "Narrow"

Remote command:

`[:SOURce<hw>] :FM:MODE` on page 598

PhiM settings

The following settings are dedicated to PhiM.

Deviation ← PhiM settings

Sets the phase modulation deviation in radians or degrees.

The maximal deviation depends on the RF frequency and the selected modulation mode (see data sheet).

Maximal possible deviation is selected automatically, if one of the following applies:

- The selected deviation is too high for the particular frequency
- The selected frequency is outside of the range where deviation is possible.

A warning message indicates this situation, too.

Remote command:

`[:SOURce] :PM<ch> [:DEViation]` on page 603

Deviation Mode ← PhiM settings

Enables you to couple the LF signal of both paths and determines the mode for fixing the total deviation.

The deviation sum 2 rad at a maximum. When the sum is exceeded, the R&S SMA100B adjusts the settings automatically.

"Uncoupled" Enables you to adjust the deviation for each path independently.

"Fixed Total" Couples the deviation of both paths. If you change the deviation of any path, the R&S SMA100B automatically adjusts the value of the other path. The sum always results in the set [Total Deviation](#).

"Fixed Ratio" Couples the deviation ratio of both paths. If you change the deviation of any path, the R&S SMA100B adjusts the value of the other path.

Remote command:

`[:SOURce<hw>] :PM:DEViation:MODE` on page 602

Total Deviation ← PhiM settings

In **Deviation Mode = Fixed Total**, sets the sum of the signal deviation for path 1 and path 2.

Deviation of both paths always sum up to the value of the total deviation.

Behavior when changing any depth settings:

- Changing the total deviation adjusts the deviations of both paths proportionally.
- Changing the deviation of one path adjusts the deviation of the other path. The sum always results in the set total deviation.

Remote command:

`[:SOURce<hw>] :PM:DEVIation:SUM` on page 602

Ratio Path2/Path1 ← PhiM settings

Sets the deviation ratio (path2 to path1) in per cent.

Example:

If the deviation in path1 is 10 rad and the ratio is 50%, the deviation in path 2 is automatically set to 5 rad.

Remote command:

`[:SOURce<hw>] :PM:RATio` on page 602

Mode ← PhiM settings

Selects the mode of the phase modulation.

"High Bandwidth"

The maximum range for modulation bandwidth and PhiM deviation is available.

However, phase noise increases at low frequencies, and the range of PhiM deviation is limited. This mode is suitable if you process high frequencies.

"High Deviation"

The maximum range for PhiM deviation is available.

Phase noise is improved for low frequencies compared to the default mode. The range for modulation frequency is limited (see data sheet). This mode is suitable for low modulation frequencies and/or high PhiM deviation.

"Low Noise"

Frequency modulation with phase noise and spurious characteristics close to CW mode. The range for modulation bandwidth and FM deviation is reduced (see data sheet).

Remote command:

`[:SOURce<hw>] :PM:MODE` on page 601

AM settings

The following settings are dedicated to AM.

Sources	<input checked="" type="radio"/> FM	<input type="radio"/> Φ M	<input checked="" type="radio"/> AM	<input type="radio"/> Output	Overview	X
Mode		Type				
Normal		Linear				
Path 1			Path 2			
State		State				
<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>				
Source		Source				
LF Generator 1		External 1				
Depth		Sensitivity				
30.00 %		30.0 %/V				
Deviation Mode		Ratio Path 2 / Path 1				
Fixed Ratio		100.00 %				

Mode ← AM settings

Selects the mode to derive the carrier signal for amplitude modulation.

- "Normal" Performs the standard amplitude modulation with a single sinusoidal carrier signal.
- "Scan" (Option: R&S SMAB-K721)
Performs amplitude modulation with a higher dynamic range. The R&S SMA100B provides a special exponential amplitude modulation system optimized for highest dynamic range. You can use the scan mode to emulate level behaviors of transmitter/receiver systems with rotating antennas. Selecting "Mode > Scan" sets the modulation type to "Exponential".
Note: Using exponential AM with an external source affects other operating modes as described in ["Interactions and characteristics"](#) on page 81.

Remote command:

[:SOURce<hw>] :AM:MODE on page 588

Type ← AM settings

Selects the type of the amplitude modulation for both paths.

Using exponential AM with an external source affects the coupling mode and the external modulation input, see ["Interactions and characteristics"](#) on page 81.

- "Linear" Sets linear amplitude modulation with depths specified in percent / volt.
- "Exponential" Sets the exponential AM type with depths in dB / volt.

Remote command:

`[:SOURce<hw>] :AM:TYPE` on page 590

Depth ← AM settings

Determines the depth of the modulation signal in percent.

For "Type = Exponential", the unit of "AM Depth" changes to dB.

The depth is limited by the maximum peak envelope power (PEP).

Remote command:

`[:SOURce<hw>] :AM<ch>:DEPTH:LINear` on page 587

`[:SOURce<hw>] :AM<ch>:DEPTH:EXponential` on page 588

Sensitivity ← AM settings

Sets the input sensitivity of the external modulation signal.

Remote command:

`[:SOURce<hw>] :AM<ch>:SENSitivity[:LINear]` on page 590

`[:SOURce<hw>] :AM<ch>:SENSitivity:EXponential` on page 589

Deviation Mode ← AM settings

Enables you to couple the LF signal of both paths and determines the mode for fixing the total deviation.

The deviation sum of both paths is 100% in total. When the sum is exceeded, the R&S SMA100B reports a settings conflict, but does not change the settings.

- | | |
|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| "Uncoupled" | Enables you to adjust the deviation depth for each path independently. |
| "Fixed Total" | Couples the deviation depth of both paths in per cent. If you change the depth of any path, the R&S SMA100B automatically adjusts the value of the other path. The sum always results in the set Total Depth . |
| "Fixed Ratio" | Couples the deviation ratio of both paths. If you change the depth of any path, the R&S SMA100B adjusts the value of the other path. |

Remote command:

`[:SOURce<hw>] :AM:DEVIation:MODE` on page 589

Total Depth ← AM settings

Sets the sum of the signal [Depth](#) for path 1 and path 2 in per cent when using combined sources and [Deviation Mode > Fixed Total](#).

Using external LF signals, the R&S SMA100B indicates the [Sensitivity](#) per Volts for the input signal.

Provided both signal paths are turned on, the depth of both paths always sum up to the value of the total depth.

Behavior when changing any depth settings:

- Changing the total depth adjusts the depths of both paths proportionally.
- Changing the depth of one path adjusts the depth of the other path. The sum always results in the set total depth.

Remote command:

[:SOURce<hw>] :AM:DEPTh:SUM on page 588

Ratio Path2/Path1 ← AM settings

Sets the deviation ratio of the signal depth for path 2 to path 1 in per cent when using combined sources.

Using external LF signals, the R&S SMA100B indicates the [Sensitivity](#) per Volts for the input signal.

In conjunction with the deviation mode, you can set the depth of both paths independently or coupled.

- [Deviation Mode > Uncoupled](#)
Enables you to set the [Depth](#) or [Sensitivity](#) of both paths independently.
- [Deviation Mode > Fixed Ratio](#)
Couples the ratio of the two paths as follows.
 - Changing the ratio path2/path1 adjusts the depth of both path2. The depth of path1 remains the same
 - Changing the depth of one path adjusts the depth of the other accordingly. The ratio path2/path1 remains the same.

Remote command:

[:SOURce<hw>] :AM:RATio on page 589

5.4.3 Chirp modulation


Option: see [Chapter 5.1, "Required options"](#), on page 79.

About chirp modulation

Chirp modulation is used in radar technique to achieve pulse compression. Pulse compression increases the sensitivity and resolution of radar systems by modifying transmitted pulses to improve their auto-correlation properties. To chirp the radar signal is one way of accomplishing pulse compression. A chirp is a signal with increasing or decreasing frequency over time.

The R&S SMA100B always couples the chirp modulation with the pulse modulation. It generates the modulation signals for FM and pulse modulator, and synchronizes the signals internally. The internal pulse generator signal is the modulation source for the pulse modulator, and the internal LF generator signal is the signal source for the frequency modulation. Normal FM mode is used. Using an external modulation signals is not possible for chirp modulation.

The following graph shows the FM demodulated signal of chirped pulses with a chirp bandwidth of 80 MHz and a pulse width of 80 µs. Chirp direction is up.



The nominal level is used for typically 3 ms to 5 ms after level or frequency setting, if:

- No attenuator is fitted.
- "High Power" mode is enabled.
- "Auto" mode is enabled, and if the level is in the range of the high power, i.e. the mechanical relay bypass is switched.

For more information, see data sheet.


5.4.3.1 Chirp modulation settings

Option: see [Chapter 5.1, "Required options"](#), on page 79.

- [Chirp modulation](#)..... 93
- [Pulse external / trigger](#)..... 95

Chirp modulation

- Access:
- Select "Modulation" > "Chirp Modulation".



The "Chirp Modulation" dialog contains the parameters for configuring the modulation and trigger settings.

State.....	93
Direction.....	93
Pulse Period.....	94
Bandwidth.....	94
Trigger Mode.....	95
Pulse Width.....	95
Compression Ratio.....	95
Show Connector.....	95
Execute Single Trigger.....	95

State
Activates chirp modulation.


Note: Some modulations exclude each other and cannot be performed simultaneously. For more information, see data sheet.

Remote command:
[:SOURce<hw>] :CHIRp:STATe on page 593

Direction
Selects the direction of the chirp modulation.

"Up"


The chirp starts with the lower frequency.



Display: 10.000, 20000, 500.00 x 100

"Down"

The chirp starts with the higher frequency.



Display: 10.000, 20000, 500.00 x 100

Remote command:

[\[:SOURce<hw>\]:CHIRp:DIRection](#) on page 592

Pulse Period

Sets the period of the generated chirp. Option: R&S SMAB-K23 provides higher resolution.

For more information, see data sheet.

Remote command:

[\[:SOURce<hw>\]:CHIRp:PULSe:PERiod](#) on page 592

Bandwidth

Sets the modulation bandwidth in Hz.

The modulation bandwidth is the difference between the maximum and minimum frequency. E.g. a bandwidth of 10 MHz at a center frequency of 1 GHz leads to a frequency modulation between 995 MHz and 1005 MHz.

The maximum bandwidth depends on the installed frequency option and the RF frequency. If the bandwidth exceeds the RF frequency, or the frequency is out of the bandwidth range, the R&S SMA100B sets the maximum bandwidth and generates an error message.

For more information, see data sheet.

Remote command:

[\[:SOURce<hw>\]:CHIRp:BANDwidth](#) on page 592

Trigger Mode

Selects the trigger mode for chirp modulation signals.

To supply the external trigger signal, use the Pulse Ext connector.

"Auto"	Generates the chirp modulation signal continuously.
"Single"	Generates the chirp modulation signal once, triggered internally with "Execute Single Trigger" on page 95.
"Ext Single"	Generates a single chirp pulse, triggered by an external signal.
"Ext Triggered"	Generates the chirp pulse each time an external trigger event occurs.
"Extern Gated"	Generates the chirp pulse signal triggered by an external gate signal.

Remote command:

[\[:SOURce<hw>\]:CHIRp:TRIGger:MODE](#) on page 593

Pulse Width

Sets the width of the generated pulse. The pulse width must be at least 1 us less than the set pulse period. Option R&S SMA100B-K23 provides a higher resolution.

For more information, see data sheet.

Remote command:

[\[:SOURce<hw>\]:CHIRp:PULSe:WIDTh](#) on page 593

Compression Ratio

Indicates the pulse compression ratio, i.e. the product of the pulse width in (s) and the bandwidth (Hz). Pulse compression increases the range resolution and the signal to noise ratio of pulsed signals.

Remote command:

[\[:SOURce<hw>\]:CHIRp:COMPression:RATio?](#) on page 592



Show Connector

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

Execute Single Trigger

If [\[:SOURce<hw>\]:CHIRp:TRIGger:MODE > SINGLE](#) "Trigger Mode = Single", initiates a single pulse sequence manually.

Remote command:


[\[:SOURce<hw>\]:CHIRp:TRIGger:IMMediate](#) on page 593

Pulse external / trigger

Access:

1. Select "Modulation" > "Chirp Modulation".

2. Select "Pulse External / Trigger".



The "Pulse External / Trigger" dialog contains the parameters for configuring the externally applied pulse and trigger signals.

Show Connector.....96




Show Connector
Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

5.4.4 Pulse generator

Option: see Chapter 5.1, "Required options", on page 79.

Access:

- Select "Modulation" > "Pulse Modulation > Pulse Generator".



The "Pulse Generator" tab contains the settings for creating the pulse modulation signal internally.

- [Pulse generator > general settings](#)..... 97
- [Pulse generator > pulse train settings](#)..... 102
- [Import/export list files](#)..... 106

5.4.4.1 Pulse generator > general settings

Access:

- Select "Modulation" > "Pulse Modulation > Pulse Generator".

Settings


- [Pulse Mode](#)..... 98
- [Trigger Mode](#)..... 99
- [Pulse Period](#)..... 101
- [Pulse Width](#)..... 101
- [Double Pulse Width](#)..... 102
- [Pulse Delay](#)..... 102
- [Double Pulse Delay](#)..... 102
- [Pulse Repetition Frequency](#)..... 102
- [Pulse Output State](#)..... 102
- [Show Connector](#)..... 102
- [Pulse Output Polarity](#)..... 102
- [Execute Single Trigger](#)..... 102

Pulse Mode

Sets the operating mode of the pulse generator. Depending on the selection, the instrument displays the associated parameters.

"Single"


Generates a single pulse in one pulse period.



- 1 = Pulse delay
- 2 = Pulse width
- 3 = Pulse period

"Double"

Generates two pulses in one pulse period.




- 1 = Pulse width
- 2 = Double pulse delay
- 3 = Double pulse width
- 4 = Pulse period

"Train"

Option: R&S SMAB-K27

Generates a user-defined pulse train.



1 = 1st pulse: On-time

2 = 1st pulse: Off-time

3 = 1st pulse: pulse period

4 = 2nd pulse: repeated 3 times

5 = 3rd pulse

6 = 4th pulse

See [Chapter 5.4.4.2, "Pulse generator > pulse train settings"](#), on page 102.

Remote command:

[:SOURce<hw>] :PULM:MODE on page 605

Trigger Mode

Selects between continuous triggering or triggering initiated by a trigger event from an external signal.

See also ["Input and output connectors"](#) on page 80.

"Auto" Generates the internal modulation signal continuously.


"Single" The pulse generator is triggered by an internal trigger event, initiated with [Execute Single Trigger](#).

The pulse signal is generated once.

"Ext Single" Generates a single pulse signal, triggered by an external signal.


"Ext Triggered" Generates the pulse signal each time an external trigger event occurs.

Example: Generation of single pulse signal ("Pulse Mode = Single") using "Trigger Mode = Ext Triggered"



- 1 = External trigger signal input with "Trigger Input Polarity = Normal" (the positive slope is active)
- 2 = Sync signal
- 3 = Pulse signal
- Δt = Trigger delay between the trigger and the sync signal start; see data sheet
- delay = "Pulse Delay = 100 ns"
- PW = "Pulse Width = 100 ns"

Example: Generation of double pulse signal ("Pulse Mode = Double") using "Trigger Mode = Ext Triggered"




- 1 = External trigger signal input with "Trigger Input Polarity = Normal" (the positive slope is active)
- 2 = Sync signal

- 3 = Pulse signal
- a = Trigger signal during double pulse generation is without effect
- Δt = Trigger delay between the trigger and the sync signal start; see data sheet
- delay = "Double Pulse Delay = 200 ns"; the first pulse starts without a delay
- PW = "Double Pulse Width = 100 ns"

"Ext Gated"

Generates the signal triggered by an external gate signal.

Example: Generation of single pulse signal ("Pulse Mode = Single") using "Trigger Mode = Ext Gated"



- 1 = External trigger signal input with "Trigger Input Polarity = Normal" (the positive slope is active)
- 2 = Sync signal
- 3 = Pulse signal
- Δt = Trigger delay between the trigger and the sync signal start; see data sheet
- delay = "Pulse Delay = 100 ns"
- PW = "Pulse Width = 100 ns"
- period = "Pulse Period = 300 ns" (time between the pulse start of two consecutive pulses)
- a = Gate active duration (pulses are generated during the gate active part)

Remote command:

[\[:SOURce<hw>\]:PULM:TRIGger:MODE](#) on page 605

Pulse Period

Sets the repetition rate of the generated pulse signal.

Remote command:

[\[:SOURce<hw>\]:PULM:PERiod](#) on page 605

Pulse Width

Sets the pulse duration of the generated pulse signal.

Note: The pulse width must be at least 20 ns less than the set pulse period.

Remote command:

[\[:SOURce<hw>\]:PULM:WIDTh](#) on page 606

Double Pulse Width

Sets the width of the second pulse.

Remote command:

[\[:SOURce<hw>\]:PULM:DOUBle:WIDTh](#) on page 607

Pulse Delay

Sets the pulse delay. The pulse delay determines the time that elapses after a trigger event before pulse modulation starts. The pulse delay is not effective for double pulse generation.

Remote command:

[\[:SOURce<hw>\]:PULM:DELaY](#) on page 606

Double Pulse Delay

Sets the delay from the start of the first pulse to the start of the second pulse.

Remote command:

[\[:SOURce<hw>\]:PULM:DOUBle:DELaY](#) on page 606

Pulse Repetition Frequency

Indicates the number of pulses of the repeating signal in a specific time unit.

The parameter is commonly expressed in Hz or in pulses per second (pps).

Remote command:

n.a.

Pulse Output State

Activates the output of the pulse modulation signal.

Remote command:

[\[:SOURce<hw>\]:PGENerator:OUTPut\[:STATe\]](#) on page 702

**Show Connector**

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

Pulse Output Polarity

Sets the polarity of the pulse output signal.

Remote command:

[\[:SOURce<hw>\]:PGENerator:OUTPut:POLarity](#) on page 702

Execute Single Trigger

If "Trigger Mode = Single", initiates a single pulse sequence manually.

Remote command:


[\[:SOURce\]:PULM\[:INTernal\]\[:TRAIIn\]:TRIGger:IMMediate](#) on page 605

5.4.4.2 Pulse generator > pulse train settings

Option: see [Chapter 5.1, "Required options"](#), on page 79.

Access:

1. Select "Modulation" > "Pulse Modulation > Pulse Generator" > **"Pulse Mode = Train"**.



2. Select "Pulse Train Data".
3. Select an existing file or select "New" to create one.
4. Define the filename.
Select "Edit Pulse Train Data", if the file is empty or to control and change the values.
5. In the "Edit Pulse Train Data" dialog, enter the pulse on/off times and pulse repetition values.
6. Select "Save".

A pulse train is a sequence of pulses with user-defined repetition, and pulse on and off times. Once defined, pulse train settings can be saved in a file. The filename is user-definable; the file extension (*.pulstrn) is assigned automatically. When a file is selected, the filename is indicated.

Possible ways to configure a pulse train

You can configure a pulse train in the following ways:

- **Internally**
 - Use the built-in editor table editor, see in the "Pulse Generator > Pulse Train" dialog.
Once defined, pulse train settings can be saved in a file. For example, to exchange configuration between instruments or to modify the file content with an external program and reload them again.
The filename is user-definable; the file extension is *.pulstrn.
 - Using the corresponding remote-control commands.

Note that you have to create a pulse train file first.

- **Externally**

Create a pulse train sequence as a CSV file with Microsoft Excel, with a Notepad or a similar tool, save it with the predefined extension. Transfer the file to and load it into the instrument.

Pulse train ASCII file format

Files describing pulse trains are simple files in text or comma-separated value (CSV) file format. The filename is user-definable; the file extension is `*.csv` or `*.txt`.

The file contains a list of pulse definition values, one row per pulse; a new line indicator separates the pulses. Pulses are defined with their pulse on time, pulse off time given in us and number of repetitions.

Example: Pulse train file content (*.txt file)

```
0.0001,0.0005,2
0.00025,0.0005,1
0.0001,0.0003,3
```

For file handling, use the standard functions in the "File Manager", see [Chapter 11.8, "Using the file manager"](#), on page 321.

Settings

Pulse Train Data.....	104
Edit Pulse Train Data.....	105
Data handling keys.....	105
L Go To.....	105
L Edit.....	105
L Save As/Save.....	105
Fill.....	105

Pulse Train Data

Accesses the standard "File Select" function of the instrument. The provided navigation possibilities in the dialog are self-explanatory.

Pulse train files are files with predefined file extension `*.pulstrn`. When a file is selected, the dialog indicates the filename.

You can create the file internally in the table editor or externally.

- To select an existing file, select "Select List > navigate to the file *.pulstrn > Select"
- Use the general editor function to create internally new file or to edit an existing one.
- Use the standard file manager function to load externally created files to the instrument.

Remote command:

`[:SOURce<hw>] :PULM:TRAI:n:CATalog?` on page 610

`[:SOURce<hw>] :PULM:TRAI:n:SElect` on page 611

`[:SOURce<hw>] :PULM:TRAI:n:DElete` on page 610

Edit Pulse Train Data

Accesses the build-in table editor to define a new pulse train file or edit an existing one.

"On-Time, μ s/Off-Time, μ s"

Sets the pulse on and pulse off time.

"Count"

Sets the number of repetitions of an "On-/ Off-Time" value pair.

Pulses with "Count = 0" are ignored.

Use this method to skip value pairs temporarily, without deleting them from the table.

Remote command:

[:SOURce<hw>] :PULM:TRAI:n:ONTime on page 610

[:SOURce<hw>] :PULM:TRAI:n:OFFTime on page 610

[:SOURce<hw>] :PULM:TRAI:n:REPetition on page 611

[:SOURce<hw>] :PULM:TRAI:n:DElete on page 610

Data handling keys

Standard functions for file and data handling.



Note: Save a list only after filling both columns (frequency and level), otherwise the entries are lost.

Go To ← Data handling keys

Selects a row for editing.

Edit ← Data handling keys

Enables you to insert, or delete a row or ranges within a list, and provides access to a dialog for automatic filling.

See "Fill..." on page 105.

Save As/Save ← Data handling keys

Saves the list in a file with user-defined name and predefined file extension. To save a copy or create a file, use the "Save as" function.

Fill...

Provides parameters for filling a table automatically with user-defined values.

From 0	Range 4
Column To Fill Frequency /Hz	
Start Value 2.000 000 000 000 GHz	End Value 2.600 000 000 000 GHz
Increment Value 200.000 000 000 MHz	
<input checked="" type="checkbox"/> Fill	

To fill the table, select "Fill".

Note: Once you enter a value or fill a column, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows will be lost when saving. You can simply override these values.

"From / Range"

Defines the start line and number of lines to be filled.

"Column To Fill"

Selects, if the column is filled up with frequencies in Hz, levels in dBm or dwell times in s.

"Start Value / End Value"

Sets the start value for frequency, level or dwell time. The end value is read only and depends on the increment value and the range.

"Increment Value"

Determines the step size.

"Fill"

Fills the column specified in "Column To fill".

5.4.4.3 Import/export list files

Access:

1. Select one of the following:

- "Sweep" > "List mode".
- "Level" > "User Correction".
- "Modulation > Pulse Modulation > Pulse Generator > Pulse Mode = Train".

2. Select "Import/Export".




Figure 5-1: Im-/Export dialog (example with UCOR settings)

The "Import/Export" dialog contains all functions and settings to import externally created list data or to export it accordingly. You can process and store a list in the formats `*.txt` (ASCII), or `*.csv` (plain text with identical sequence of fields). The table separators and the decimal floating point numbers are customizable.

Settings

Mode.....	107
ASCII File Settings.....	107
Select (ASCII) Source/Select (ASCII) Destination.....	108
Select Source/Select ASCII Destination.....	108
Import / Export.....	108

Mode

Selects import or export of a data list file. The provided parameters vary according to the selected mode.

Remote command:

`[:SOURCE<hw>] :LIST:DEXChange:MODE` on page 699

`[:SOURCE<hw>] :CORRection:DEXChange:MODE` on page 664

`[:SOURCE<hw>] :PULM:TRAIIn:DEXChange:MODE` on page 612

ASCII File Settings

Defines the format and the separators of the associated data file.

"Extension" Selects `*.csv` or `*.txt` format.

"Decimal Point" Sets "Point" (dot) or "Comma" as the decimal separator used in the ASCII data with floating-point numerals.

"Column Separator" Sets the separator between the columns in an ASCII table.
Available are: "Tab", "Semicolon", "Comma" or "Space".

Remote command:

`[:SOURCE<hw>] :LIST:DEXChange:AFIle:EXTeNsion` on page 698

`[:SOURCE<hw>] :LIST:DEXChange:AFIle:SEParator:DECimal` on page 699

[\[:SOURce<hw>\]:LIST:DEXChange:AFILe:SEParator:COLumn](#) on page 698

[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:EXTension](#) on page 662

[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:SEParator:DECimal](#)

on page 663

[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:SEParator:COLumn](#)

on page 663

[\[:SOURce<hw>\]:PULM:TRAIIn:DEXChange:AFILe:EXTension](#) on page 612

[\[:SOURce<hw>\]:PULM:TRAIIn:DEXChange:AFILe:SEParator:DECimal](#)

on page 613

[\[:SOURce<hw>\]:PULM:TRAIIn:DEXChange:AFILe:SEParator:COLumn](#)

on page 613

Select (ASCII) Source/Select (ASCII) Destination

In "Mode > Import", access the file select dialog that provides standard file handling functions.

Where:

- "Select ASCII Source": defines the file to be loaded (imported)
- "Select ASCII Destination": selects the filename under that the loaded file is saved

Remote command:

[\[:SOURce<hw>\]:LIST:DEXChange:AFILe:CATalog?](#) on page 697

[\[:SOURce<hw>\]:LIST:DEXChange:AFILe:SElect](#) on page 698

[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:CATalog?](#) on page 662

[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:SElect](#) on page 663

[\[:SOURce<hw>\]:PULM:TRAIIn:DEXChange:AFILe:CATalog?](#) on page 613

[\[:SOURce<hw>\]:PULM:TRAIIn:DEXChange:AFILe:SElect](#) on page 613

Select Source/Select ASCII Destination

In "Mode > Export", access the file select dialog that provides standard file handling functions.

Where:

- "Select Source": selects the file to be exported
- "Select ASCII Destination": defines the filename and the file path for the exported file

Remote command:

[\[:SOURce<hw>\]:LIST:DEXChange:SElect](#) on page 699

[\[:SOURce<hw>\]:CORRection:DEXChange:SElect](#) on page 664

[\[:SOURce<hw>\]:PULM:TRAIIn:DEXChange:SElect](#) on page 614

Import / Export

Imports or exports the selected data list file, depending on the current mode.

Remote command:

[\[:SOURce<hw>\]:LIST:DEXChange:EXECute](#) on page 698

[\[:SOURce<hw>\]:CORRection:DEXChange:EXECute](#) on page 663

[\[:SOURce<hw>\]:PULM:TRAIIn:DEXChange:EXECute](#) on page 614


5.4.5 Pulse graph

Option: see [Chapter 5.1, "Required options"](#), on page 79.

Access:

- Select "Modulation" > "Pulse Modulation > Pulse Graph".

The pulse graph is the graphical representation of the current pulse signal.



The height of the bars corresponds to the selected amplitude of the pulse signal.

File Name

Indicates the name of the pulse train data file.

To create or select a file, see ["Pulse Train Data"](#) on page 104.

Remote command:

`[:SOURce<hw>] :PULM:TRain:SElect` on page 611

Zooming

You can zoom into the diagram to visualize the graph in more detail:

- "Zoom Position": Sets the focus on the time axis where to enlarge the graph.
- "Zoom In": Enlarges the graph at the selected position.
- "Zoom Out" for the reverse operation.

5.4.6 Pulse external / trigger settings

- Access:
- ▶ Select "Modulation" > "Pulse Modulation > Pulse External / Trigger".

Pulse GeneratorPulse GraphPulse ModulationPulse External / Trigger

Pulse Ext Connector

Polarity

Normal

Impedance

10 kΩ

Threshold

1.0 V

Show Connector ...

The dialog specifies some characteristics of the Pulse Ext connector.
This connector is common for the pulse generator and the pulse modulator. For an overview, see ["Input and output connectors"](#) on page 80.

Settings	
Polarity.....	110
Impedance.....	110
Threshold.....	110
Show Connector.....	111

Polarity
Sets the polarity of the active slope of a pulse input signal, that is the external pulse modulation signal.

Remote command:
[\[:SOURce<hw>\]:PULM:POLarity](#) on page 608

Impedance
Sets the input impedance.
Remote command:
[\[:SOURce<hw>\]:PULM:IMPedance](#) on page 608

Threshold
Sets the high/low threshold in volts for the signal at the [Pulse Ext] connector.
Remote command:
[\[:SOURce<hw>\]:PULM:THReshold](#) on page 608

**Show Connector**

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

5.4.7 FM, PhiM and AM modulation sources

Access:

- Select "Modulation > Modulation Sources".

In the "Sources" tab, you can configure an LF modulation signal for performing analog modulations. It includes the setting parameters of the internal LF-and multi-function generators, the noise generator, and an external signal source.

- [Source > LF generator settings](#)..... 111
- [Source > external settings](#)..... 115
- [Source > noise generator settings](#)..... 117

5.4.7.1 Source > LF generator settings

Access:

- Select "Modulation" > "Modulation Sources > LF Generator".

Sources		FM	ΦM	AM	Output	Overview	X
LF Generator 1		LF Generator 2		LF Generator			
LF Frequency Sweep State				External			
Off				Noise Generator			
Shape		Shape					
Sine		Pulse					
Frequency		Pulse Period					
1.000 00 kHz		1.000 00 ms					
Period		Pulse Width					
1.000 00 ms		500.00 μs					
		Pulse Duty Cycle					
		50.000 000 %					

The internal LF signal can be the modulation signal source for any of the analog modulations. The LF signal applies to all modulations which use the internal modulation signal. Therefore, any modification of the LF signal immediately affects all currently active modulations.

Settings

State (LF frequency sweep).....	112
Shape.....	112
Frequency.....	114
Period.....	114
Pulse Width.....	114
Pulse Duty Cycle.....	114
Triangle Rise.....	115
Trapezoid Rise / Fall.....	115
Trapezoid High.....	115

State (LF frequency sweep)

Status of the LF frequency sweep signal.

You find this parameter in two dialogs:

- "LF Frequency Sweep" turns on/off the signal generation.
See [Sweep mode settings](#) for access.
- "Analog Modulation Sources" displays the current state (read-only). If it is turned on, this dialog provides the varying sweep frequency, see [Current Frequency](#).

Note: Active RF frequency, RF level or RF combined sweep modes deactivate the LF sweep or List mode and vice versa.

Remote command:


[\[:SOURce<hw>\]:LFOutput:FREQuency:MODE](#) on page 678

Shape

Selects the waveform shape of the LF generator signal.


The "Triangle" and "Trapezoid" waveforms require option R&S SMAB-K24.

"Sine"




1 = Period

"Square"





1 = Period

"Pulse"

1 = Pulse width
2 = Pulse period

"Triangle"

1 = Triangle rise
2 = Triangle period



Remote command:

[\[:SOURce<hw>\]:LFOutput<ch>:SHAPE](#) on page 681

Frequency

Sets the frequency of the LF generator for sine signals.

Set the signal shape with the parameter [Shape](#).

Remote command:

[\[:SOURce\]:LFOutput<ch>:FREQuency](#) on page 677

Period

Sets the repetition rate of the generated LF signal for triangle, trapezoid or pulse shapes, see [Shape](#).

The period of sine signals is calculated from the selected [Frequency](#)

Remote command:

[\[:SOURce<hw>\]:LFOutput<ch>:SHAPE:TRAPeZe:PERiod](#) on page 682

[\[:SOURce<hw>\]:LFOutput<ch>:SHAPE:TRIangle:PERiod](#) on page 683

[\[:SOURce<hw>\]:LFOutput<ch>:SHAPE:PULSe:PERiod](#) on page 681

Pulse Width

Sets the pulse duration of the generated pulse signal.

Remote command:

[\[:SOURce<hw>\]:LFOutput<ch>:SHAPE:PULSe:WIDTh](#) on page 682

Pulse Duty Cycle

Sets the ratio between the pulse duration and the pulse period in percent.

Remote command:

[\[:SOURce<hw>\]:LFOutput<ch>:SHAPE:PULSe:DCYClE](#) on page 681

Triangle Rise

Sets the time required for the triangle signal to change from low level to high level.

Remote command:

[\[:SOURce<hw>\]:LFOutput<ch>:SHAPE:TRIangle:RISE](#) on page 683

Trapezoid Rise / Fall

Sets the time required for the trapezoid signal to change from low level to high level, and vice versa.

Remote command:

[\[:SOURce<hw>\]:LFOutput<ch>:SHAPE:TRAPeZe:RISE](#) on page 683

[\[:SOURce<hw>\]:LFOutput<ch>:SHAPE:TRAPeZe:FALL](#) on page 682

Trapezoid High

Sets how long the trapezoid signal is at high level.


Remote command:

[\[:SOURce<hw>\]:LFOutput<ch>:SHAPE:TRAPeZe:HIGH](#) on page 682

5.4.7.2 Source > external settings

Access:

- Select "Modulation" > "Modulation Sources > External".



The "External" settings section contains all parameters required to configure the signal of an externally supplied LF signal.

Settings

Coupling (AC/DC).....	116
Impedance.....	116
Bandwidth.....	116
Show Connector.....	116

Coupling (AC/DC)

Selects the coupling mode (AC or DC) for the external signal.

- "AC" Disconnects the DC voltage component and uses only the AC component of the modulation signal.
- "DC" Uses the modulation signal with both components, AC and DC. For active external exponential AM, sets the coupling of the corresponding input automatically to DC.

Remote command:

[\[:SOURce<hw>\]:INPut:MODext:COUPling<ch>](#) on page 673

Impedance

Sets the impedance for the externally supplied signal.

Remote command:

[\[:SOURce<hw>\]:INPut:MODext:IMPedance<ch>](#) on page 674

Bandwidth

Displays the maximum bandwidth of the external LF signal.

Remote command:


[\[:SOURce\]:LFOutput<ch>:BANDwidth?](#) on page 677

**Show Connector**

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

5.4.7.3 Source > noise generator settings

- Access:
- Select "Modulation" > "Modulation Sources > Noise Generator".



The "Noise Generator" settings contain all parameters to configure the signal of the internal noise generator.

Settings

Distribution.....	117
Bandwidth.....	117

Distribution

- Selects the distribution of the noise power density.
- "Gauss" Generates the noise power according to a Gaussian distribution.
 - "Equal" Generates an evenly distributed noise.

Remote command:
`[:SOURce<hw>] :NOISe:DISTriBution` on page 701

Bandwidth


- Sets the noise bandwidth as distinct value.
- You can set the bandwidth between 100 kHz and 10 MHz in 100 KHz steps.

Remote command:
`[:SOURce<hw>] :NOISe:BANDwidth|BWIDth` on page 700
`[:SOURce<hw>] :NOISe:BWIDth:STATe` on page 700

5.4.8 LF signal output settings

Access:

- Select "Modulation" > "LF Output".



In the "LF Output" tab, you can configure the signal at the LF outputs, determine the output voltage or add a DC offset. Activate both paths to output the sum signal of the two sources.

Settings:

State.....	118
Source.....	119
Show Connector.....	119
Output Voltage.....	119
DC-Offset.....	119
Load Impedance.....	119
Noise Level.....	120
L Noise Density.....	120
L Noise Level.....	120

State

Activates the output of the LF signal.

Remote command:

[:SOURce] :LFOutput<ch> [:STATe] on page 679

Source

Select the sources for the signal output at the LF connector. If you activate path 1 *and* 2, those sources are added.

Use the "Show Connector" function to find out where this connector is located.

"LF Generator 1/2"

Selects one of internally generated LF signals.

"AM"

Option: R&S SMAB-K720

Selects the AM signal.

"FM/PhiM"

Option: R&S SMAB-K720

Selects the signal also used by the frequency or phase modulations.

"Noise Generator"

Selects the internally generated noise signal.

"External 1/2"

Selects one of the externally supplied LF signals.

Remote command:

[\[:SOURce\]:LFOutput<ch>:SOURce](#) on page 680

**Show Connector**

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

Output Voltage

Sets the peak to peak voltage of the selected LF output source.

This value, e.g. +1 V to -1 V refers to 50 Ohm at the RF output with high termination impedance at the LF output.

Remote command:

[\[:SOURce\]:LFOutput<ch>:INTernal:VOLTage](#) on page 679

DC-Offset

Adds a DC offset to the LF output signal.

Remote command:

[\[:SOURce\]:LFOutput:OFFSet](#) on page 680

Load Impedance

Sets the specification of the load impedance interconnected to the LF generator output.

This parameter is available in case of activated R&S SML0x emulations only, see "Remote Access Settings" > "Instrument Emulations" > ["Language"](#) on page 405.

These signal generators come with an LF generator source impedance of 10 Ohm which is not available with the R&S SMA100B.

The set LF generator load impedance enables the R&S SMA100B to emulate the 10 Ohm LF generator source impedance of these generators by a corresponding increase of the open circuit LF generator output voltage.


The load impedance setting is not affected by an instrument preset ([Preset] key or *RST), restart or the "Save/Recall" function. It is reset to the default value of 1 MOhm by a factory preset only.

Remote command:
n.a.

Noise Level

Access:

- Select "Modulation" > "Output > Noise Level".



Noise Density ← Noise Level

Indicates the level of the noise signal for a bandwidth of 1 Hz (relative).

Remote command:

`[:SOURce<hw>] :NOISe:LEVel:RELative?` on page 701

Noise Level ← Noise Level

Indicates the level of the noise signal per Hz within the total bandwidth (absolute).

Remote command:


`[:SOURce<hw>] :NOISe:LEVel [:ABSolute]?` on page 701

5.4.9 Overview

Option: AM and FM/PM require R&S SMAB-K720

Access:

- Select "Modulation" > "Modulation Sources > Overview".



Blue color = Active output signal (AM and FM)
 Gray color = Inactive output signal (LF Out)
 Miniature graph = Indicates an active source
 Connectors = Indicate a connector (e.g. external signal) is involved in the path of the signal

The "Overview" tab is an interactive diagram that indicates the active modulations and the signal being output.

Here you can:

- Select the output signal ("LF Out") in one or two paths; the setting acts as the parameter "LF Output Source"
 - Select the source for each modulation and modulation path; the setting acts as the parameter "Source"
 - Activate modulation in one or two paths; the setting acts as the parameter "State"
- To generate a two-tone signal composed from the two paths of the same modulation type, activate both paths.
- The "FM" box allows switching to "PhiM", but those modulations are mutually exclusive.

LFOut

Label for the LF output settings in the overview.

Remote command:

n.a.

AM

Label for the amplitude modulation settings in the overview.

Remote command:

n.a.

FM/PhiM

Selects the modulation signal to be assigned to the output. You can assign the frequency or phase modulated signal.

Remote command:

n.a.

5.5 How to generate an amplitude modulated signal

The following examples use the internal LF generator.

To set the frequency and level of the RF signal

1. Press [Preset] to start from a defined state.
2. In the status bar, set "Frequency = 2 GHz".
3. Set "Level = -20 dBm".

To configure the modulation signal (LF generator)

1. Select "Modulation" > "Modulation Source".
2. In the "Sources" tab, select "Shape > Sine".
3. Set "Frequency = 20 kHz".

The period is calculated automatically and indicates "Period = 50.00 µs".

To configure the amplitude modulation settings

1. In "Modulation" dialog, select the "AM" tab.
2. Set "Source = LF Generator1"
3. Set "Depth = 30%"
4. Select "State = I" to activate the modulation.
5. Set "Level > RF ON" to enable signal output.

5.6 How to generate a pulse modulated signal

The following example uses the internal pulse generator.

To set the frequency and level of the RF signal

1. Press [Preset].
2. In the status bar, set "Frequency = 4 GHz".
3. Set "Level = -25 dBm".

To configure the pulse generator

1. Select "Modulation" > "Pulse Generator".
2. Select "Pulse Mode = Double".
3. Set "Pulse Period = 10 us".
4. Set "Pulse Width = 2 us".
5. Set "Double Pulse Width = 1.2 us".
6. Set "Double Pulse Delay = 4.5 us".
7. Activate "Pulse Output State".
8. Set "Trigger Mode = Auto".

In the "Pulse Graph" tab, you can view the generated pulse signal graphically.

To enable pulse modulation

1. Select the "Pulse Modulation" tab.
2. Set "State = I" to activate pulse modulation.
3. Set "Level > RF ON" to enable signal output.

5.7 How to generate a pulse train modulated signal

The following example uses the internal pulse generator.

To set the frequency and level of the RF signal

1. Press [Preset].
2. In the status bar, set "Frequency = 6 GHz".
3. Set "Level = -25 dBm".

To configure the pulse generator

1. Select "Modulation" > "Pulse Generator".
2. Select "Pulse Mode = Train".
3. Select "Pulse Train Data".
Accesses the standard function for file handling.

4. Select an existing file or select "New" to create one.
5. Define the filename.
Select "Edit Pulse Train Data", if the file is empty or to control and change the values.
6. In the "Edit Pulse Train Data" dialog, enter the pulse on/off times and pulse repetition values.
For example:
 - "On-Time = 500 us", "OFF-Time = 2 ms", "Count = 2"
 - "On-Time = 100 us", "OFF-Time = 2.5 ms", "Count = 1"
 - "On-Time = 10 us", "OFF-Time = 50 us", "Count = 10"
7. "Save" the file and close the dialog.
The instrument returns to the /var/user/ where it has saved the file.
8. Select the file in the directory.
9. Confirm with "Select".
10. In the "Pulse Generator" dialog, select "Pulse Output State = On".
11. Set "Trigger Mode = Auto".

In the "Pulse Graph" tab, you can view the generated pulse signal graphically.

To enable pulse train modulation

1. Select the "Pulse Modulation" tab.
2. Set "State = I".
3. Set "Level > RF ON" to enable signal output.

6 Avionic standards

The R&S SMA100B supports avionic standards VOR, ILS and ADF.

Contents

• Required options	125
• About avionics	125
• Generating VOR signals	125
• Generating ILS signals	136
• Generating ADF signals	162

6.1 Required options

The R&S SMA100B base unit equipped with the following options:

- Signal generation for VOR, ILS and ADF (R&S SMAB-K25)

6.2 About avionics

This chapter summarizes information on avionics standards supported at the R&S SMA100B. Also, it links detailed information on the avionic standard supported at the R&S SMA100B.

Overview of avionics standards

- **Landing systems:** ILS (Instrument Landing System)
Landing systems are ground-based approach systems that provide precision guidance to aircraft approaching and landing on a runway.
For more information, see [Chapter 6.4, "Generating ILS signals"](#), on page 136.
- **Radio/Flight navigation systems:** VOR (VHF Omnidirectional Radio), ADF (Automatic Direction Finder)
The radio navigation systems are aircraft systems that support the pilots to determine the aircraft positions and stay on course.
For more information, see [Chapter 6.3, "Generating VOR signals"](#), on page 125 and [Chapter 6.5, "Generating ADF signals"](#), on page 162.

6.3 Generating VOR signals

This chapter provides information on very high frequency (VHF) omnidirectional radio range (VOR) signal generation with the R&S SMA100B. This information includes

required options, background information on VOR, generation of VOR signals, configuration and settings.

- [About VOR](#)..... 126
- [VOR configuration and settings](#)..... 127

6.3.1 About VOR

Very high frequency (VHF) omnidirectional radio range (VOR) is used for radio navigation and helps the aircraft to determine its position and stay on course.

A VOR system consists of a ground transmission station and a VOR receiver on the board of the aircraft.

The transmitter stations operate at VHF frequencies of 108 MHz to 118 MHz (see [Table 6-1](#)), with the code identification (COM/ID) transmitting on a modulation tone of 1.020 kHz. It emits two types of signals:

- An omnidirectional reference signal (REF) that can consist of two parts:
 - 30 Hz frequency modulated (FM) sine wave on subcarrier 9.96 kHz from amplitude modulation (AM) carrier
 - 1020 Hz AM modulated sine wave morse code
- A directional positioning signal, variable (VAR): 30 Hz AM modulated sine waves with variable phase shift.

The position of the aircraft is determined by measuring azimuth as the difference in phase of those two signals. The magnetic north is defined as the reference point, for which both signals are exactly in phase.

Related settings

For VOR settings at the R&S SMA100B, see [Chapter 6.3, "Generating VOR signals"](#), on page 125.

Channel frequencies

The column notations in the table below are as follows:

- **Channel** = ICAO channel number
- **Frequency** = VOR Interrogation frequency (MHz)

Table 6-1: VOR ICAO channels and frequencies (MHz)

Channel	Frequency	Channel	Frequency	Channel	Frequency	Channel	Frequency
17X	108.00	57X	112.00	87Y	114.00	107X	116.00
17Y	108.05	57Y	112.05	87Y	114.05	107Y	116.05
19X	108.20	58X	112.10	88X	114.10	108X	116.10
19Y	108.25	58Y	112.15	88Y	114.15	108Y	116.15
21X	108.40	59X	112.20	89X	114.20	109X	116.20
21Y	108.45	59Y	112.25	89Y	114.25	109Y	116.25

Channel	Frequency	Channel	Frequency	Channel	Frequency	Channel	Frequency
23X	108.60	70X	112.30	90X	114.30	110X	116.30
23Y	108.65	70Y	112.35	90Y	114.35	110Y	116.35
25X	108.80	71X	112.40	91X	114.40	111X	116.40
25Y	108.85	71Y	112.45	91Y	114.45	111Y	116.45
27X	109.00	72X	112.50	92X	114.50	112X	116.50
27Y	109.05	72Y	112.55	92Y	114.55	112Y	116.55
29X	109.20	73X	112.60	93X	114.60	113X	116.60
29Y	109.25	73Y	112.65	93Y	114.65	113Y	116.65
31X	109.40	74X	112.70	94X	114.70	114X	116.75
31Y	109.45	74Y	112.75	94Y	114.75	114Y	116.75
33X	109.60	75X	112.80	95X	114.80	115X	116.80
33Y	109.65	75Y	112.85	95Y	114.85	115Y	116.85
35X	109.80	76X	112.90	96X	114.90	116X	116.90
35Y	109.85	76Y	112.95	96Y	114.95	116Y	116.95
37X	110.00	77X	113.00	97X	115.00	117X	117.00
37Y	110.05	77Y	113.05	97Y	115.05	117Y	117.05
39X	110.20	78X	113.10	98X	115.10	118X	117.10
39Y	110.25	78Y	113.15	98Y	115.15	118Y	117.15
41X	110.40	79X	113.20	99X	115.20	119X	117.20
41Y	110.45	79Y	113.25	99Y	115.25	119Y	117.25
43X	110.60	80X	113.30	100X	115.30	120X	117.30
43Y	110.65	80Y	113.35	100Y	115.35	120Y	117.35
45X	110.80	81X	113.40	101X	115.40	121X	117.40
45Y	110.85	81Y	113.45	101Y	115.45	121Y	117.45
47X	111.00	82X	113.50	102X	115.50	122X	117.50
47Y	111.05	82Y	113.55	102Y	115.55	122Y	117.55
49X	111.20	83X	113.60	103X	115.60	123X	117.60
49Y	111.25	83Y	113.65	103Y	115.65	123Y	117.65
51X	111.40	84X	113.70	104X	115.70	124X	117.70
51Y	111.45	84Y	113.75	104Y	115.75	124Y	117.75
53X	111.60	85X	113.80	105X	115.80	125X	117.80
53Y	111.65	85Y	113.85	105Y	115.85	125Y	117.85
55X	111.80	86X	113.90	106X	115.90	126X	117.90
55Y	111.85	86Y	113.95	106Y	115.95	126Y	117.95

6.3.2 VOR configuration and settings

Option: R&S SMAB-K25

Access:

- Select "Modulation" > "Avionic Standards" > "VOR".

The remote commands required to define VOR settings are described in [Chapter 14.17.2.5, "SOURCE:VOR subsystem"](#), on page 647.


Settings

- [General settings](#)..... 128
- [Signal settings](#)..... 131
- [Position settings](#)..... 133
- [COM/ID settings](#)..... 134

6.3.2.1 General settings

Access:

- Select "VOR" > "General".



This dialog provides general settings of the VOR standard, the default and the "Save/Recall" settings.

By default, a VOR modulation signal is set on an RF carrier with a frequency of 108 MHz or ICAO channel 17X. The 9.96 kHz subcarrier signal is frequency modulated with a 30.00 Hz reference signal. The COM/ID signal has 1.02 kHz frequency, the variable phase signal 30.00 Hz frequency.

If enabled, the avionic standard modulation is displayed in the "Modulation" tile as follows:

- "Avionic: VOR" for enabled VOR modulation
- "Avionic ILS: Glide Slope/Localizer/Marker Bcn" for enabled ILS glide slope/localizer/marker beacons modulation
- "Avionic: ADF" for enabled ADF modulation

Settings

State.....	129
Set To Default.....	129
Save/Recall.....	129
Carrier Frequency Mode.....	130
Carrier Frequency.....	130
ICAO Channel.....	130
EXT AM.....	130

State

Activates the avionic standard.

Activation of the standard deactivates a previously active avionic standard. The "VOR/ILS > Carrier Frequency" setting is applied automatically to the RF [Frequency](#) and displayed in the status bar.

Remote command:

[<subsystem>:STATe](#) on page 621

Set To Default

Calls the default settings. The values of the main parameters are listed in the following table.

Standard	Parameter	Value
VOR/ILS/ADF	State	Not affected by "Set to default"
VOR	Carrier Frequency Mode	User Defined
	Carrier Frequency	108.000000 MHz
ILS	ILS Component	Glide Slope (GS)
	ILS GS > Carrier Frequency Mode	User Defined
	ILS GS > Carrier Frequency	334.700000 MHz
ADF	Carrier Frequency	190.000 kHz

Remote command:

[<subsystem>:PRESet](#) on page 620

Save/Recall

Accesses the "Save/Recall" dialog, that is the standard instrument function for saving and recalling the complete dialog-related settings in a file. The provided navigation possibilities in the dialog are self-explanatory.

The settings are saved in a file with predefined extension. You can define the filename and the directory, in that you want to save the file.

Remote command:

[<subsystem>:SETTing:CATalog](#) on page 620

[<subsystem>:SETTing:DELeTe](#) on page 620

[<subsystem>:SETTing:LOAD](#) on page 620

[<subsystem>:SETTing:STORe](#) on page 621

Carrier Frequency Mode

Sets the mode for the carrier frequency of the signal.

"User Defined" Activates user-defined setting of the carrier frequency.

"ICAO" Activates ICAO-conform setting of the carrier frequency via the "ICAO Channel". For standard VOR transmitting frequencies, see [Table 6-1](#).

Remote command:

[:SOURce<hw>] :VOR:FREQuency:MODE on page 653

Carrier Frequency

Requires "Carrier Frequency Mode > User Defined".

Sets the carrier frequency of the signal.

Remote command:

[:SOURce<hw>] :VOR:FREQuency on page 652

ICAO Channel

Requires "Carrier Frequency Mode" > "ICAO".

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

For an overview of the VOR ICAO channels and frequencies, see [Table 6-1](#).

Remote command:

[:SOURce<hw>] :VOR:ICAO:CHANnel on page 653

EXT AM

Enables additional modulation from an external source. The external signal is input via the Ext connector.

"Off" Selects the internal modulation source for the avionic standard modulation.

"EXT (MOD AM)"

Selects the external source. The external signal is added to the internal signal. Switching off the internal source is not possible. The external signal is input via the Ext connector. The sensitivity is 10 mV per percent modulation depth.

Note: There can be an overmodulation as a function of the level of the external signal without a corresponding caution message being generated. To avoid an overmodulation, the peak value of the external signal is to be delimited corresponding to the sum of the modulation depths of the remaining VOR signal components.

Remote command:

[:SOURce<hw>] :VOR:SOURce on page 648

6.3.2.2 Signal settings

Access:

- Select "VOR" > "Signal".

VOR		ILS <i>Glide Slope</i>	ADF	
Operating Mode Norm				General
VAR/REF Frequency 30.00 Hz		VAR Depth 30.0 %		Signal
Subcarrier Frequency 9.960 00 kHz		Subcarrier Depth 30.0 %		Position
REF Deviation 480 Hz				COM I/D

This dialog provides signal settings of the VOR modulation signal.

Settings

Mode.....	131
VAR/REF Frequency.....	132
VAR Depth.....	132
Subcarrier Frequency.....	132
Subcarrier Depth.....	132
REF Deviation.....	132

Mode

Selects the operating mode for the VOR modulation signal.

"Norm"	VOR modulation is active.
"Var"	Amplitude modulation of the output signal with the VAR signal component (30Hz signal content) of the VOR signal. The modulation depth corresponds to the value set under VAR Depth .
"Subcarrier"	Amplitude modulation of the output signal with the unmodulated FM carrier (9960Hz) of the VOR signal. The modulation depth corresponds to the value set under Subcarrier Depth .
"Subcarrier + FM"	Amplitude modulation of the output signal with the frequency-modulated FM carrier (9960Hz) of the VOR signal. The frequency deviation corresponds to the value set under REF Deviation , the modulation depth corresponds to the value set under "Subcarrier Depth".

Remote command:

[:SOURCE<hw>] :VOR:MODE on page 654

VAR/REF Frequency

Sets the frequency of the VAR signal and the REF signal. As the two signals must have the same frequency, the setting is valid for both signals.

Remote command:

[\[:SOURce<hw>\]:VOR:VAR:FREQuency](#) on page 656

VAR Depth

Sets the AM modulation depth of the 30 Hz VAR signal.

Note: The sum of "Subcarrier Depth", "VAR Depth" and COM/ID "Depth" must be smaller than 100 %.

Remote command:

[\[:SOURce<hw>\]:VOR:VAR\[:DEPTh\]](#) on page 656

Subcarrier Frequency

Sets the frequency of the FM carrier.

Remote command:

[\[:SOURce<hw>\]:VOR:SUBCarrier\[:FREQuency\]](#) on page 655

Subcarrier Depth

Sets the AM modulation depth of the FM carrier.

Note: The sum of "Subcarrier Depth", "VAR Depth" and COM/ID "Depth" must be smaller than 100 %.

Remote command:

[\[:SOURce<hw>\]:VOR:SUBCarrier:DEPTh](#) on page 655

REF Deviation

Sets the frequency deviation of the reference signal on the FM carrier.


Remote command:

[\[:SOURce<hw>\]:VOR:REFerence\[:DEViation\]](#) on page 655

6.3.2.3 Position settings

Access:

► Select "VOR" > "Position".



This dialog provides position settings related to the VOR modulation signal.

Settings

Bearing Angle.....	133
Direction.....	133

Bearing Angle

Sets the phase angle between the 30 Hz VAR signal and the 30 Hz reference signal.
The orientation of the angle depends on the set [Direction](#).

Remote command:
`[:SOURCE<hw>] :VOR [:BANGLE]` on page 648

Direction

Sets the reference position of the phase information.
The angle set under "Bearing Angle" corresponds to the angle between the geographic north and the connection line from beacon to airplane.

- "From" Selection of the beacon as a reference position.
- "To" Selection of the airplane position as a reference position.

Remote command:
`[:SOURCE<hw>] :VOR [:BANGLE] :DIRection` on page 649

6.3.2.4 COM/ID settings

Access:

- Select "VOR" > "COM/ID".

VOR		ILS <i>Glide Slope</i>	ADF	
COM/ID State <input checked="" type="checkbox"/>				General
Code MUC		Period 9.000 s		Signal
Frequency 1.020 00 kHz		Depth 10.0 %		Position
Time Schema Standard				COM I/D
Dot Length 100.0 ms				

This dialog provides COM/ID signal settings related to the VOR signal.

Settings

COM/ID State.....	134
Code.....	134
Period.....	135
Frequency.....	135
Depth.....	135
Time Schema.....	135
Dot Length.....	135
Dash Length.....	135
Symbol Space.....	136
Letter Space.....	136

COM/ID State

Enables/disables the COM/ID signal.

See also [Chapter D, "Morse code settings"](#), on page 811.

Remote command:

`[:SOURce<hw>] :VOR:COMid [:STATe]` on page 652

Code

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse code settings"](#), on page 811.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:CODE](#) on page 649

Period

Sets the period of the COM/ID signal.

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:PERiod](#) on page 651

Frequency

Sets the frequency of the COM/ID signal.

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:FREQuency](#) on page 650

Depth

Sets the AM modulation depth of the COM/ID signal.

Note: The sum of [Subcarrier Depth](#), [VAR Depth](#) and COM/ID > [Depth](#) must be smaller than 100 %.

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:DEPTH](#) on page 650

Time Schema

Sets the time schema of the Morse code for the COM/ID signal.

"Standard" The set dot length determines the length of the dash, the symbol space and letter space of the Morse code.

"User" You can set each length value separately.

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:TSCHEMA](#) on page 652

Dot Length

Sets the length of a Morse code dot.

If "Time Schema" > "Standard", the dot length value determines also the length of the dash (= 3 times the dot length), symbol space (= dot length) and letter space (= 3 times the dot length).

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:DOT](#) on page 650

Dash Length

Requires "Time Schema" > "User".

Sets the length of a Morse code dash.

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:DASH](#) on page 650

Symbol Space

Requires "Time Schema" > "User".

Sets the length of the Morse code symbol space.

Remote command:

`[:SOURce<hw>] :VOR:COMid:SYMBol` on page 651

Letter Space

Requires "Time Schema" > "User".

Sets the length of a Morse code letter space.

Remote command:

`[:SOURce<hw>] :VOR:COMid:LETTer` on page 651

6.4 Generating ILS signals

This chapter provides information on instrument landing system (ILS) signal generation with the R&S SMA100B. This information includes required options, background information on ILS, generation of ILS signals, configuration and settings.

- [About ILS](#)..... 136
- [ILS configuration and settings](#)..... 139

6.4.1 About ILS

During the landing approach, the aircraft uses the instrument landing system (ILS) to monitor the correct approach path to the runway.




Figure 6-1: Approach navigation using instrument landing system (ILS) [1MA193]

An ILS consists of three independent subsystems:

- A glide slope for vertical guidance
- A localizer for horizontal guidance
- Optionally, marker beacons

Glide slope


The glide slope transmitter is located near the end of the runway (nearest to the start of the aircraft approach).

Typically, vertically aligned antennas transmit two intersecting main beams on top of one another at carrier frequencies between 329 MHz and 335 MHz (see [Table 6-2](#)). The top beam is usually modulated at 90 Hz and the beam below at 150 Hz [1MA193].

The information on position is provided after demodulation of the beam signals by evaluating the difference in depth of modulation (DDM). The following scenarios are possible:

- Predominance of the 90 Hz beam: the aircraft is too high and must descend
- Predominance of the 150 Hz beam: the aircraft is too low and needs to climb
- The signal strength from both beams is equal: the aircraft is in the center, on the right course.

If there is a predominance of the 90 Hz beam, then the aircraft is too high and must descend. A predominant 150 Hz means that the aircraft is too low and needs to climb.




Localizer

The localizer transmitter is located near the end of the runway (nearest to the start of the aircraft approach). Typically, horizontally aligned antennas transmit two intersecting main beams beside one another at carrier frequencies between 108 MHz and 112 MHz (see [Table 6-2](#)). As seen from the approaching aircraft coming in for a landing, the left beam is usually modulated at 90 Hz and the right beam at 150 Hz [1MA193].

The information on position is provided after demodulation of the beam signals by evaluating the difference in depth of modulation (DDM). The following scenarios are possible:

- Predominance of the 90 Hz beam: the aircraft is too far to the left and must turn to the right
- Predominance of the 150 Hz beam: the aircraft is too far to the right and must turn to the left
- The signal strength from both beams is equal: the aircraft is in the center, on the right course.



Marker beacons

Marker beacon receivers are used for a rough distance measurement. They are available only for some ILS installations [1MA193].




Figure 6-2: Marker beacon placement and distance to runway

Marker beacon receivers decode audio and provide signaling output to identify one of three marker beacons installed near the runway. They transmit a narrow beam width at 75 MHz carrier frequency in a vertical direction. Each of them has a different distinct modulation code to allow the receiver to identify which one it is flying over [1MA193].

Both visual (color of the marker beacon) and audio tone identification is supported for determining which marker has been flown over. The audio/visual pairing of marker beacons is as follows:

- Outer marker flashes BLUE in the cockpit at 400 Hz (“relaxed” tone).
- Middle marker flashes AMBER in the cockpit at 1300 Hz (“hurried” tone).
- Inner marker flashes WHITE in the cockpit at 3000 Hz (“urgent” tone).

Related Settings

For ILS settings at the R&S SMA100B, see the following sections:

- [Chapter 6.4.2.2, "ILS glide slope settings"](#), on page 142
- [Chapter 6.4.2.3, "ILS localizer settings"](#), on page 148
- [Chapter 6.4.2.4, "ILS marker beacons settings"](#), on page 157

Channel frequencies

The column notations in the table below are as follows:

- **Chan.** = ICAO channel number
- **LOC freq.** = ILS localizer frequency (MHz)
- **GS freq.** = ILS glide slope frequency (MHz)

Table 6-2: ILS ICAO channels and frequencies (MHz)

Chan.	LOC freq.	GS freq.	Chan.	LOC freq.	GS freq.	Chan.	LOC freq.	GS freq.
18X	108.10	334.70	32X	109.50	332.60	46X	110.90	330.80
18Y	108.15	334.55	32Y	109.55	332.45	46Y	110.95	330.65
20X	108.30	334.10	34X	109.70	333.20	48X	111.10	331.70
20Y	108.35	333.95	34Y	109.75	333.05	48Y	111.15	331.55
22X	108.50	329.90	36X	109.90	333.80	50X	111.30	332.30
22Y	108.55	329.75	36Y	109.95	333.65	50Y	111.35	332.15
24X	108.70	330.50	38X	110.10	334.40	52X	111.50	332.90
24Y	108.75	330.35	38Y	110.15	334.25	52Y	111.55	332.75
26X	108.90	329.30	40X	110.30	335.00	54X	111.70	333.50
26Y	108.95	329.15	40Y	110.35	334.85	54Y	111.75	333.35
28X	109.10	331.40	42X	110.50	329.60	56X	111.90	331.10
28Y	109.15	331.25	42Y	110.55	329.45	56Y	111.95	330.95
30X	109.30	332.00	44X	110.70	330.20			
30Y	109.35	331.85	44Y	110.75	330.05			

6.4.2 ILS configuration and settings

Option: R&S SMAB-K25

Access:

- Select "Modulation" > "Avionic Standards" > "ILS".

The remote commands required to define ILS settings are described in [Chapter 14.17.2.4, "SOURCE:ILS subsystem"](#), on page 625.

Settings


- [General settings](#)..... 140
- [ILS glide slope settings](#)..... 142
- [ILS localizer settings](#)..... 148
- [ILS marker beacons settings](#)..... 157

6.4.2.1 General settings

This chapter provides settings to configure general ILS components.

Access:

- Select "ILS" > "General".



This dialog comprises general settings of the ILS standard, the default and the "Save/Recall" settings.

By default, an ILS glide slope modulation signal on an RF carrier with a frequency of 344.7 MHz or ICAO channel 18X. The dual-tone LF signal with frequencies 90 Hz and 150 Hz and a balanced modulation at SDM of 80 %.

If enabled, the avionic standard modulation is displayed in the "Modulation" tile as follows:

- "Avionic: VOR" for enabled VOR modulation
- "Avionic ILS: Glide Slope/Localizer/Marker Bcn" for enabled ILS glide slope/localizer/marker beacons modulation
- "Avionic: ADF" for enabled ADF modulation

Settings

State.....	141
Set To Default.....	141
Save/Recall.....	141
ILS Component.....	141

State

Activates the avionic standard.

Activation of the standard deactivates a previously active avionic standard. The "VOR/ILS > Carrier Frequency" setting is applied automatically to the RF [Frequency](#) and displayed in the status bar.

Remote command:

[<subsystem>:STAt](#) on page 621

Set To Default

Calls the default settings. The values of the main parameters are listed in the following table.

Standard	Parameter	Value
VOR/ILS/ADF	State	Not affected by "Set to default"
VOR	Carrier Frequency Mode	User Defined
	Carrier Frequency	108.000000 MHz
ILS	ILS Component	Glide Slope (GS)
	ILS GS > Carrier Frequency Mode	User Defined
	ILS GS > Carrier Frequency	334.700000 MHz
ADF	Carrier Frequency	190.000 kHz

Remote command:

[<subsystem>:PRESet](#) on page 620

Save/Recall

Accesses the "Save/Recall" dialog, that is the standard instrument function for saving and recalling the complete dialog-related settings in a file. The provided navigation possibilities in the dialog are self-explanatory.

The settings are saved in a file with predefined extension. You can define the filename and the directory, in that you want to save the file.

Remote command:

[<subsystem>:SETTing:CATalog](#) on page 620

[<subsystem>:SETTing:DELeTe](#) on page 620

[<subsystem>:SETTing:LOAD](#) on page 620

[<subsystem>:SETTing:STORe](#) on page 621

ILS Component

Sets the ILS component.

- "Glide slope" Enables the glide slope.
 "Localizer" Enables the localizer.
 "Marker Beacons" Enables the marker beacons.

Remote command:

[:SOURce<hw>] : ILS : TYPE on page 626

6.4.2.2 ILS glide slope settings

Access:

1. Select "ILS" > "General".
2. Select "ILS Component" > "Glide Slope".

Settings

- [General settings](#)..... 142
- [Signal settings](#)..... 144
- [Amplitude settings](#)..... 146

General settings

Access:

- Select "ILS" > "General".



This dialog provides carrier frequency settings related to the ILS glide slope component of the ILS signal.

Settings

Carrier Frequency Mode.....	143
Carrier Frequency.....	143
ICAO Channel.....	143
Sync with Glide Slope/ Sync with Localizer.....	143
EXT AM.....	144

Carrier Frequency Mode

Sets the mode for the carrier frequency of the signal.

Select "Carrier Frequency Mode > ICAO" to set a standard ILS frequency channel. If you want to couple carrier frequencies of ILS glide slope and localizer components, enable [Sync with Glide Slope/ Sync with Localizer](#).

"User Defined" Activates user-defined variation of the carrier frequency.

"ICAO" Activates variation in predefined steps according to standard ILS transmitting frequencies (see [Table 6-2](#)).

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:FREQuency:MODE](#) on page 630

Carrier Frequency

Requires "Carrier Frequency Mode" > "User Defined".

Sets the carrier frequency of the signal.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:FREQuency](#) on page 629

ICAO Channel

Requires "Carrier Frequency Mode" > "ICAO".

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

For an overview of the ILS ICAO channel frequencies, see [Table 6-2](#).

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:ICAO:CHANnel](#) on page 630

Sync with Glide Slope/ Sync with Localizer

Activates synchronization of the ILS glide slope with the ILS localizer carrier frequency or vice versa.

If "Carrier Frequency Mode" > "User", the ILS glide slope carrier frequency is applied to the ILS localizer carrier frequency or vice versa.

If "Carrier Frequency Mode" > "ICAO", the ILS glide slope ICAO channel is applied to the ILS localizer ICAO channel or vice versa. The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Remote command:

[<subsystem>:FREQuency:SYNChronize:STATe](#) on page 621

EXT AM

Activates additional modulation from an external source. The input of the external signal is at the connector Ext.

"Off" Selects the internal modulation source for the avionic standard modulation.

"EXT (MOD AM)"

Selects the external source. The external signal is added to the internal signal. Switching off the internal source is not possible. The external signal is input via the Ext connector. The sensitivity is 10 mV per percent modulation depth.

Note: There can be an overmodulation as a function of the level of the external signal without a corresponding caution message being generated. To avoid an overmodulation, the peak value of the external signal is to be delimited corresponding to the sum of the modulation depths of the remaining VOR signal components.

Remote command:

[:SOURce<hw>] : ILS [:GS | GSLope] : SOURce on page 632

Signal settings

Access:

1. Select "ILS Component" > "Glide Slope". See [Chapter 6.4.2.2, "ILS glide slope settings"](#), on page 142.
2. Select "ILS" > "Signal".

VOR		ILS Glide Slope		ADF		X	
Operating Mode		DDM Polarity		General			
Norm		90 Hz - 150 Hz					
Up Frequency		Down Frequency		Signal			
90.00 Hz		150.00 Hz					
Up/Down Phase				Amplitude			
0.00 deg							

This dialog provides modulation signal settings related to the ILS glide slope component of the ILS signal.

Settings

Operating Mode	145
DDM Polarity	145
Up Frequency	145
Down Frequency	145
Up/Down Phase	145

Operating Mode

Selects the operating mode for the ILS glide slope modulation signal.

"Norm"	ILS glide slope modulation is active.
"90 Hz"	<p>Amplitude modulation of the output signal with the upper lobe signal component (90 Hz signal content) of the ILS glide slope signal.</p> <p>The modulation depth of the 90 Hz signal results from the settings of the parameters Sum of Depth and DDM Depth according to:</p> <ul style="list-style-type: none"> "Fly > Down" $\text{AM (90 Hz)} = 0.5 \times (\text{SDM} + \text{DDM} \times 100 \%)$ "Fly > Up" $\text{AM (90 Hz)} = 0.5 \times (\text{SDM} - \text{DDM} \times 100 \%)$
"150 Hz"	<p>Amplitude modulation of the output signal with the lower lobe signal component (150 Hz signal content) of the ILS glide slope signal.</p> <p>The modulation depth of the 150 Hz signal results from the settings of parameters Sum of Depth and DDM Depth according to:</p> <ul style="list-style-type: none"> "Fly > Down" $\text{AM (150 Hz)} = 0.5 \times (\text{SDM} + \text{DDM} \times 100 \%)$ "Fly > Up" $\text{AM (150 Hz)} = 0.5 \times (\text{SDM} - \text{DDM} \times 100 \%)$

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:MODE](#) on page 631

DDM Polarity

Defines the polarity for DDM calculation, see ["DDM Depth"](#) on page 147.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:DDM:POLarity](#) on page 628

Up Frequency

Sets the modulation frequency of the upper antenna lobe.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:ULObE\[:FREQuency\]](#) on page 633

Down Frequency

Sets the modulation frequency of the lower antenna lobe.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:LLObE\[:FREQuency\]](#) on page 631

Up/Down Phase

Sets the phase between the modulation signals of the upper and lower antenna lobe.

The zero crossing of the lower lobe (150Hz) signal serves as a reference. The angle refers to the period of the signal of the lower antenna lobe.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:PHASe](#) on page 631

Amplitude settings

Access:

1. Select "ILS Component" > "Glide Slope". See [Chapter 6.4.2.2, "ILS glide slope settings"](#), on page 142.
2. Select "ILS" > "Amplitude".

VOR		ILS Glide Slope		ADF		X	
Fly Mode				Up		General	
Sum of Depth				80.0 %		DDM - SDM Coupling	
						Fixed DDM	
DDM Step				Decimal		Signal	
DDM Current				0.0 µA		DDM Depth	
						0.000 0	
DDM Logarithmic				0.000 0 dB		DDM Percent	
						0.00 %	

This dialog provides amplitude settings related to the ILS glide slope component of the ILS signal.

Settings

Sum of Depth.....	146
Fly Mode.....	147
DDM Step.....	147
DDM Current.....	147
DDM Depth.....	147
DDM Logarithmic.....	147
DDM Percent.....	148
DDM - SDM Coupling.....	148

Sum of Depth

Sets the arithmetic sum of the modulation depths of the upper lobe (90 Hz) and lower lobe (150 Hz) ILS glide slope signal contents.

The RMS modulation depth of the sum signal depends on the phase setting of both modulation tones.

Remote command:

[:SOURce<hw>] : ILS [:GS | GSlope] : SDM on page 632

Fly Mode

Selects the simulation mode for the ILS glide slope modulation signal. A change of the setting automatically changes the sign of the DDM value.

This setting simulates the direction in which the pilot has to correct the course.

"Up"	The 150 Hz modulation signal is predominant, the DDM value is negative (the airplane is too low, it must climb).
"Down"	The 90 Hz modulation signal is predominant, the DDM value is positive (the airplane is too high, it must descend).

Remote command:

`[:SOURce<hw>] : ILS [:GS | GSLope] : DDM : DIRection` on page 627

DDM Step

Selects the variation of the DDM values.

"Decimal"	Decimal variation according to the current cursor position.
"Predifined"	Variation in predefined steps according to the standardized DDM values.

Remote command:

`[:SOURce<hw>] : ILS [:GS | GSLope] : DDM : STEP` on page 629

DDM Current

Sets the current of the ILS indicating the instrument corresponding to the DDM value. The instrument current is calculated according to:

$$\text{DDM Current } \mu\text{A} = \text{DDM Depth } [\%] \times 857,125 \mu\text{A}$$

A variation of the instrument current automatically leads to a variation of the DDM value and the DDM value in dB.

Remote command:

`[:SOURce<hw>] : ILS [:GS | GSLope] : DDM : CURRent` on page 627

DDM Depth

Sets the difference in depth of modulation between the upper lobe (90 Hz) and the lower lobe (150 Hz) tone of the ILS glide slope modulation signal.

The DDM value is calculated with the formula:

- "DDM Polarity" > "90 Hz - 150 Hz":
DDM = [AM (90 Hz) - AM (150 Hz)] / 100%
- "DDM Polarity" > "150 Hz - 90 Hz":
DDM = [AM (150 Hz) - AM (90 Hz)] / 100%

A variation of the DDM value automatically leads to a variation of the value of the instrument current and the DDM value in dB.

Remote command:

`[:SOURce<hw>] : ILS [:GS | GSLope] : DDM [: DEPT h]` on page 629

DDM Logarithmic

Sets the DDM value in dB. The dB value is calculated according to:

$$\text{DDM dB} = 20 \times \text{LOG} [(SDM + DDM \times 100\%) / (SDM - DDM \times 100\%)]$$

A variation of the value automatically leads to a variation of the DDM value and the instrument current.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:DDM:LOGarithmic](#) on page 628

DDM Percent

Sets the difference in depth of modulation between the upper lobe (90 Hz) and the lower lobe (150 Hz) tone of the ILS glide slope modulation signal.

The DDM value in percent is calculated as follows:

- "DDM Polarity" > "90 Hz - 150 Hz":
DDM = [AM (90 Hz) - AM (150 Hz)]
- "DDM Polarity" > "150 Hz - 90 Hz":
DDM = [AM (150 Hz) - AM (90 Hz)]

A variation of the DDM value automatically leads to a variation of the value of the instrument current and the DDM value in dB.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:DDM:PCT](#) on page 628

DDM - SDM Coupling

Selects if the DDM value is fixed or is changed with a change of sum of modulation depths (SDM, see below).

"Fixed DDM" The absolute DDM value stays constant, if the SDM is changed.

"Coupled to SDM"

The absolute DDM value changes, if the SDM is changed. The DDM value expressed in dB stays constant.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:DDM:COUpling](#) on page 627

6.4.2.3 ILS localizer settings

Access:


1. Select "ILS" > "General".
2. Select "ILS Component" > "Localizer".

Settings

• General settings	149
• Signal settings	151
• Amplitude settings	152
• COM/ID settings	155

General settings

- Access:
- Select "ILS > General".



This dialog provides carrier frequency settings of the ILS localizer component of the ILS signal.

Settings

Carrier Frequency Mode.....	149
Carrier Frequency.....	149
ICAO Channel.....	150
Sync with Glide Slope/ Sync with Localizer.....	150
EXT AM.....	150

Carrier Frequency Mode

Sets the mode for the carrier frequency of the signal.

- "User Defined" Activates user-defined variation of the carrier frequency.
- "ICAO" Activates variation in predefined steps according to standard ILS transmitting frequencies (see [Table 6-2](#)).
Select the [ICAO Channel](#) to set a standard ILS frequency channel. If you want to couple carrier frequencies of ILS glide slope and localizer components, enable [General settings](#).

Remote command:
`[:SOURce<hw>] :ILS:LOCalizer:FREquency:MODE` on page 639

Carrier Frequency

Requires "Carrier Frequency Mode" > "User Defined".
Sets the carrier frequency of the signal.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:FREQuency` on page 639

ICAO Channel

Requires "Carrier Frequency Mode > ICAO".

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

For an overview of the ILS ICAO channel frequencies, see [Table 6-2](#).

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:ICAO:CHANnel` on page 640

Sync with Glide Slope/ Sync with Localizer

Activates synchronization of the ILS glide slope with the ILS localizer carrier frequency or vice versa.

If "Carrier Frequency Mode" > "User", the ILS glide slope carrier frequency is applied to the ILS localizer carrier frequency or vice versa.

If "Carrier Frequency Mode" > "ICAO", the ILS glide slope ICAO channel is applied to the ILS localizer ICAO channel or vice versa. The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Remote command:

`<subsystem>:FREQuency:SYNChronize:STATe` on page 621

EXT AM

Activates additional modulation from an external source. The input of the external signal is at the connector Ext.

"Off" Selects the internal modulation source for the avionic standard modulation.

"EXT (MOD AM)"

Selects the external source. The external signal is added to the internal signal. Switching off the internal source is not possible. The external signal is input via the Ext connector. The sensitivity is 10 mV per percent modulation depth.

Note: There can be an overmodulation as a function of the level of the external signal without a corresponding caution message being generated. To avoid an overmodulation, the peak value of the external signal is to be delimited corresponding to the sum of the modulation depths of the remaining VOR signal components.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:SOURce` on page 642

Signal settings

Access:

1. Select "ILS Component" > "Localizer". See [Chapter 6.4.2.3, "ILS localizer settings"](#), on page 148.
2. Select "ILS" > "Signal".

VOR

ILS
Localizer

ADF

✕

Operating Mode	DDM Polarity	General
Norm	90 Hz - 150 Hz	
Left Frequency	Right Frequency	
90.00 Hz	150.00 Hz	Signal
Left/Right Phase		Amplitude
0.00 deg		COM I/D

This dialog provides audio signal and modulation settings related to the ILS localizer component of the ILS signal.

Settings

Operating Mode	151
DDM polarity	152
Left Frequency	152
Right Frequency	152
Left/Right Phase	152

Operating Mode

Selects the operating mode for the ILS localizer modulation signal.

- "Norm" ILS localizer modulation is active.
- "90 Hz"

Amplitude modulation of the output signal with the left lobe (90 Hz) signal component of the ILS localizer signal.

The modulation depth of the 90 Hz signal results from the settings of parameters [Sum of Depth](#) and [DDM Depth](#) according to:

 - "Fly > Right"

$$AM\ (90\ Hz) = 0.5 \times (SDM + DDM \times 100\ \%)$$
 - "Fly > Left"

$$AM\ (90\ Hz) = 0.5 \times (SDM - DDM \times 100\ \%)$$

"150 Hz"

Amplitude modulation of the output signal with the right lobe (150 Hz) signal component of the ILS localizer signal.

The modulation depth of the 150 Hz signal results from the settings of parameters [Sum of Depth](#) and [DDM Depth](#) according to:

- "Fly" = "Right"

$$\text{AM (150 Hz)} = 0.5 \times (\text{SDM} + \text{DDM} \times 100 \%)$$
- "Fly" = "Left"

$$\text{AM (150 Hz)} = 0.5 \times (\text{SDM} - \text{DDM} \times 100 \%)$$

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:MODE](#) on page 641

DDM polarity

Defines the polarity for DDM calculation, see ["DDM Depth"](#) on page 154.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:DDM:POLarity](#) on page 638

Left Frequency

Sets the modulation frequency of the antenna lobe arranged at the left viewed from the air plane.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:LLOBe\[:FREQuency\]](#) on page 640

Right Frequency

Sets the modulation frequency of the antenna lobe arranged at the right viewed from the air plane.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:RLOBe\[:FREQuency\]](#) on page 642

Left/Right Phase

Sets the phase between the modulation signals of the left and right antenna lobe. The zero crossing of the right lobe (150 Hz) signal serves as a reference. The angle refers to the period of the signal of the right antenna lobe.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:PHASe](#) on page 641

Amplitude settings

Access:

1. Select "ILS Component" > "Localizer". See [Chapter 6.4.2.3, "ILS localizer settings"](#), on page 148.

2. Select "ILS" > "Amplitude".

VOR		ILS Localizer		ADF		X	
Fly Mode						General	
Left							
Sum of Depth				DDM - SDM Coupling		Signal	
40.0 %				Fixed DDM			
DDM Step						Amplitude	
Decimal							
DDM Current				DDM Depth		COM I/D	
0.0 µA				0.000 0			
DDM Logarithmic				DDM Percent			
0.000 0 dB				0.00 %			

This dialog provides amplitude settings related to the ILS localizer component of the ILS signal.

Settings

Fly Mode.....	153
Sum of Depth.....	153
DDM - SDM Coupling.....	154
DDM Step.....	154
DDM Current.....	154
DDM Depth.....	154
DDM Logarithmic.....	155
DDM Percent.....	155

Fly Mode

Selects the simulation mode for the ILS localizer modulation signal. A change of the setting automatically changes the sign of the DDM value.

This setting simulates the direction in which the pilot has to correct the course.

"Left"	The 150 Hz modulation signal is predominant, the DDM value is negative (the airplane is too far to the right, it must turn to the left).
"Right"	The 90 Hz modulation signal is predominant, the DDM value is positive (the airplane is too far to the left, it must turn to the right).

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:DDM:DIRection` on page 637

Sum of Depth

Sets the arithmetic sum of the modulation depths of the left lobe (90 Hz) and right lobe (150 Hz) ILS localizer signal contents.

The RMS modulation depth of the sum signal depends on the phase setting of both modulation tones.

The "Sum of Depth" and "COM/ID > Depth" must be smaller than 100 %.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:SDM` on page 642

DDM - SDM Coupling

Selects if the DDM value is fixed or is changed with a change of sum of modulation depths (SDM, see below).

"Fixed DDM" The absolute DDM value stays constant, if the SDM is changed.

"Coupled to SDM" The absolute DDM value changes, if the SDM is changed. The DDM value expressed in dB stays constant.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:DDM:COUPling` on page 636

DDM Step

Selects the variation step of the DDM values.

"Decimal" Decimal variation according to the current cursor position.

"Predifined" Variation in predefined steps according to the standardized DDM values.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:DDM:STEP` on page 638

DDM Current

Sets the current of the ILS indicating instrument corresponding to the DDM value. The instrument current is calculated according to:

$$\text{DDM } \mu\text{A} = \text{DDM} \times 967.75 \mu\text{A}$$

A variation of the instrument current automatically leads to a variation of the DDM value and the DDM value in dB.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:DDM:CURRent` on page 636

DDM Depth

Sets the difference in depth of modulation (DDM) between the signal of the left lobe (90 Hz) and the right lobe (150 Hz) of the ILS localizer modulation signal.

The DDM value in percent is calculated as follows:

- "DDM Polarity > 90 Hz - 150 Hz" (default setting):

$$\text{DDM} = [\text{AM} (90 \text{ Hz}) - \text{AM} (150 \text{ Hz})] / 100 \%$$
- "DDM Polarity > 150 Hz - 90 Hz":

$$\text{DDM} = [\text{AM} (150 \text{ Hz}) - \text{AM} (90 \text{ Hz})] / 100 \%$$

A variation of the DDM value automatically leads to a variation of the DDM value in dB and the value of the instrument current.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:DDM[:DEPTh]` on page 639

DDM Logarithmic

Sets the DDM value in dB. The dB value is calculated according to:

$$\text{DDM dB} = 20 \times \text{LOG} [(\text{SDM} + \text{DDM} \times 100 \%) / (\text{SDM} - \text{DDM} \times 100 \%)]$$

A variation of the value automatically leads to a variation of the DDM value and the instrument current.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:DDM:LOGarithmic` on page 637

DDM Percent

Sets the difference in depth of modulation between the signal of the left lobe (90 Hz) and the right lobe (150 Hz).

The DDM value in percent is calculated by the following formulas:

- "DDM Polarity > 90 Hz - 150 Hz" (default setting):

$$\text{DDM} = [\text{AM} (90 \text{ Hz}) - \text{AM} (150 \text{ Hz})]$$

- "DDM Polarity > 150 Hz - 90 Hz":

$$\text{DDM} = [\text{AM}(150 \text{ Hz}) - \text{AM} (90 \text{ Hz})]$$

A variation of the DDM value automatically leads to a variation of the DDM value in dB and the value of the instrument current.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:DDM:PCT` on page 638

COM/ID settings

Access:

1. Select "ILS Component" > "Localizer". See [Chapter 6.4.2.3, "ILS localizer settings"](#), on page 148.
2. Select "ILS" > "COM/ID".

COM/ID State <input checked="" type="checkbox"/>		General
Code	MUC	Period
		9.000 s
Frequency	1.020 00 kHz	Depth
		10.0 %
Time Schema	Standard	COM I/D
Dot Length	100.0 ms	

This dialog provides COM/ID settings related to the ILS localizer component of the ILS signal.

Settings

COM/ID State.....	156
Code.....	156
Frequency.....	156
Period.....	156
Depth.....	156
Time Schema.....	157
Dot Length.....	157
Dash Length.....	157
Symbol Space.....	157
Letter Space.....	157

COM/ID State

Enables/disables the COM/ID signal.

See also [Chapter D, "Morse code settings"](#), on page 811.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:COMid[:STATe]` on page 636

Code

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse code settings"](#), on page 811.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:COMid:CODE` on page 633

Frequency

Sets the frequency of the COM/ID signal.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:COMid:FREQuency` on page 634

Period

Sets the period of the COM/ID signal.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:COMid:PERiod` on page 635

Depth

Sets the AM modulation depth of the COM/ID signal.

Note: The sum of [Sum of Depth](#) and $\text{COM/ID} > \text{Depth}$ must be smaller than 100 %.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:COMid:DEPTh` on page 634

Time Schema

Sets the time schema of the Morse code for the COM/ID signal.

"Standard" The set dot length determines the length of the dash, the symbol space and letter space of the Morse code.

"User" You can set each length value separately.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:COMid:TSCHEMA](#) on page 635

Dot Length

Sets the length of a Morse code dot.

If "Time Schema" > "Standard", the dot length value determines also the length of the dash (= 3 times the dot length), symbol space (= dot length) and letter space (= 3 times the dot length).

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:COMid:DOT](#) on page 634

Dash Length

Requires "Time Schema" > "User".

Sets the length of a Morse code dash.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:COMid:DASH](#) on page 633

Symbol Space

Requires "Time Schema" > "User".

Sets the length of the Morse code symbol space.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:COMid:SYMBOL](#) on page 635

Letter Space

Requires "Time Schema" > "User".

Sets the length of a Morse code letter space.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:COMid:LETTER](#) on page 635

6.4.2.4 ILS marker beacons settings

Access:

1. Select "ILS > General".
2. Select "ILS Component > Marker Beacons".


Settings

- [General settings](#)..... 158
- [Signal settings](#)..... 159
- [COM/ID settings](#)..... 160

General settings

Access:

- 1. Select "ILS Component > Marker Beacons".
See [Chapter 6.4.2.4, "ILS marker beacons settings"](#), on page 157.
- 2. Select "ILS > General".



This dialog provides carrier frequency and signal settings related to the ILS marker beacons component of the ILS signal.

Settings

- [Carrier Frequency Mode](#)..... 158
- [Carrier Frequency](#)..... 158

Carrier Frequency Mode

Sets the mode for the carrier frequency of the signal.

- "User Defined" Activates user-defined variation of the carrier frequency.
- "Predefined" Activates variation of the carrier frequency by integer 25 kHz steps.

Remote command:

[\[:SOURCE<hw>\] \[:ILS\] :MBEacon:FREQUENCY:MODE](#) on page 646

Carrier Frequency

Requires "Carrier Frequency Mode > User Defined".

Sets the carrier frequency of the signal.

Remote command:

[\[:SOURCE<hw>\] \[:ILS\] :MBEacon:FREQUENCY](#) on page 646

Signal settings

Access:

1. Select "ILS Component" > "Marker Beacons". See [Chapter 6.4.2.4, "ILS marker beacons settings"](#), on page 157.
2. Select "ILS" > "Signal".

This dialog provides signal settings related to the ILS marker beacons component of the ILS signal.

Settings

Marker Frequency	159
Marker Depth	159
Pulsed Marker	159

Marker Frequency

Sets the modulation frequency of the marker signal.

Remote command:

[\[:SOURce<hw>\] \[:ILS\] :MBEacon:MARKer:FREQuency](#) on page 646

Marker Depth

Sets the modulation depth of the marker signal.

Remote command:

[\[:SOURce<hw>\] \[:ILS\] :MBEacon\[:MARKer\]:DEPTh](#) on page 647

Pulsed Marker

Activates the modulation of a pulsed marker signal (morse coding).

"On"

Modulation of pulsed marker signals (morse coding). The duty cycle, the marker on- and off-times depend on the frequency of the marker signal ([Table 6-3](#)).

Table 6-3: ILS marker beacons marker signals and morse coding

Signal	Freq.	On	Off	Morse rate	Duty cycle
Outer marker	400 Hz	375 ms	125 ms	2 dots/s	75 %
Middle marker	1300 Hz	1 st : 375 ms 2 nd : 83 ms	1 st : 125 ms 2 nd : 83 ms	1.5 dots/s	68.8 %
Inner marker	3000 Hz	83 ms	83 ms	6 dots/s	50 %

"Off"

Modulation of a continuous non-coded marker signal.

Remote command:

[:SOURce<hw>] [:ILS] :MBEacon [:MARKer] :PULSed on page 647

COM/ID settings

Access:

1. Select "ILS Component" > "Marker Beacons". See [Chapter 6.4.2.4, "ILS marker beacons settings"](#), on page 157.
2. Select "ILS" > "COM/ID".

The screenshot shows the 'ILS Marker Beacons' settings window. The 'COM/ID State' checkbox is checked. The 'Code' is 'MUC', 'Period' is '9.000 s', 'Frequency' is '1.020 00 kHz', 'Depth' is '5.0 %', 'Time Schema' is 'Standard', and 'Dot Length' is '100.0 ms'. The 'COM I/D' tab is selected in the right sidebar.

This dialog provides COM/ID settings of the marker beacons component of the ILS signal.

Settings

COM/ID State.....	161
Code.....	161
Period.....	161
Frequency.....	161
Depth.....	161
Time Schema.....	161
Dot Length.....	162
Dash Length.....	162
Symbol Space.....	162
Letter Space.....	162

COM/ID State

Enables/disables the COM/ID signal.

See also [Chapter D, "Morse code settings"](#), on page 811.

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid[:STATe]` on page 646

Code

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse code settings"](#), on page 811.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid:CODE` on page 643

Period

Sets the period of the COM/ID signal.

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid:PERiod` on page 645

Frequency

Sets the frequency of the COM/ID signal.

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid:FREQuency` on page 644

Depth

Sets the AM modulation depth of the COM/ID signal.

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid:DEPT h` on page 643

Time Schema

Sets the time schema of the Morse code for the COM/ID signal.

"Standard" The set dot length determines the length of the dash, the symbol space and letter space of the Morse code.

"User" You can set each length value separately.

Remote command:

[\[:SOURce<hw>\] \[:ILS\] :MBEacon:COMid:TSCHEMA](#) on page 645

Dot Length

Sets the length of a Morse code dot.

If "Time Schema" > "Standard", the dot length value determines also the length of the dash (= 3 times the dot length), symbol space (= dot length) and letter space (= 3 times the dot length).

Remote command:

[\[:SOURce<hw>\] \[:ILS\] :MBEacon:COMid:DOT](#) on page 644

Dash Length

Requires "Time Schema" > "User".

Sets the length of a Morse code dash.

Remote command:

[\[:SOURce<hw>\] \[:ILS\] :MBEacon:COMid:DASH](#) on page 643

Symbol Space

Requires "Time Schema" > "User".

Sets the length of the Morse code symbol space.

Remote command:

[\[:SOURce<hw>\] \[:ILS\] :MBEacon:COMid:SYMBOL](#) on page 645

Letter Space

Requires "Time Schema" > "User".

Sets the length of a Morse code letter space.

Remote command:

[\[:SOURce<hw>\] \[:ILS\] :MBEacon:COMid:LETTER](#) on page 644

6.5 Generating ADF signals

This chapter provides information on distance measurement equipment (DME) signal generation with the R&S SMA100B. This information includes required options, background information on DME, generation of DME signals, configuration and settings.

- [About ADF](#) 162
- [ADF configuration and settings](#) 163

6.5.1 About ADF

Automatic direction finder (ADF) receivers provide the relative bearing of a basic ground-based non-directional beacon (NDB) to the fore axis or aft axis of the aircraft. The beacon signal is generated by a directional antenna assembly in the aircraft.

The ADF determines the direction to the NDB station relative to the aircraft and is used for instrument approaches (autopilot). It provides additional information to other navigation equipment, e.g. VOR.

Related Settings

For ADF settings at the R&S SMA100B, see [Chapter 6.5.2, "ADF configuration and settings"](#), on page 163.

6.5.2 ADF configuration and settings

Option: R&S SMAB-K25

Access:

- ▶ Select "Modulation" > "Avionic Standards" > "ADF".

The remote commands required to define ADF settings are described in [Chapter 14.17.2.3, "SOURCE:ADF subsystem"](#), on page 622.


Settings

- [General settings](#)..... 163
- [COM/ID settings](#)..... 165

6.5.2.1 General settings

Access:

- ▶ Select "ADF" > "General".



This dialog provides general settings of the ADF standard, the default and the "Save/Recall" settings.

By default, an ADF signal modulation is set on an RF carrier with a frequency of 190 kHz. The COM/ID signal has 1.02 kHz frequency.

If enabled, the avionic standard modulation is displayed in the "Modulation" tile as follows:

- "Avionic: VOR" for enabled VOR modulation

- "Avionic ILS: Glide Slope/Localizer/Marker Bcn" for enabled ILS glide slope/localizer/marker beacons modulation
- "Avionic: ADF" for enabled ADF modulation

ADF state and carrier frequency range

If the R&S SMA100B carrier frequency is outside the specified ADF frequency range from 190 kHz to 1750 kHz, a settings conflict is displayed. Activating ADF is not possible.

Change the carrier frequency to a value within the specified frequency range.

Settings

State.....	164
Set To Default.....	164
Save/Recall.....	164

State

Activates the avionic standard.

Activation of the standard deactivates a previously active avionic standard. The "VOR/ILS > Carrier Frequency" setting is applied automatically to the RF [Frequency](#) and displayed in the status bar.

Remote command:

[<subsystem>:STAt](#) on page 621

Set To Default

Calls the default settings. The values of the main parameters are listed in the following table.

Standard	Parameter	Value
VOR/ILS/ADF	State	Not affected by "Set to default"
VOR	Carrier Frequency Mode	User Defined
	Carrier Frequency	108.000000 MHz
ILS	ILS Component	Glide Slope (GS)
	ILS GS > Carrier Frequency Mode	User Defined
	ILS GS > Carrier Frequency	334.700000 MHz
ADF	Carrier Frequency	190.000 kHz

Remote command:

[<subsystem>:PRESet](#) on page 620

Save/Recall

Accesses the "Save/Recall" dialog, that is the standard instrument function for saving and recalling the complete dialog-related settings in a file. The provided navigation possibilities in the dialog are self-explanatory.


The settings are saved in a file with predefined extension. You can define the filename and the directory, in that you want to save the file.

Remote command:

```
<subsystem>:SETTing:CATalog on page 620
<subsystem>:SETTing:DELeTe on page 620
<subsystem>:SETTing:LOAD on page 620
<subsystem>:SETTing:STORe on page 621
```

6.5.2.2 COM/ID settings

- Access:
- Select "ADF" > "COM/ID".



This dialog provides COM/ID signal settings related to the ADF signal.

Settings

COM/ID State.....	166
Code.....	166
Period.....	166
Frequency.....	166
Depth.....	166
Time Schema.....	166
Dot Length.....	166
Dash Length.....	167
Symbol Space.....	167
Letter Space.....	167

COM/ID State

Enables/disables the COM/ID signal.

Remote command:

`[:SOURCE<hw>] :ADF:COMid[:STATe]` on page 625

Code

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse code settings"](#), on page 811.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Remote command:

`[:SOURCE<hw>] :ADF:COMid:CODE` on page 622

Period

Sets the period of the COM/ID signal.

Remote command:

`[:SOURCE<hw>] :ADF:COMid:PERiod` on page 624

Frequency

Sets the frequency of the COM/ID signal.

Remote command:

`[:SOURCE<hw>] :ADF:COMid:FREQuency` on page 623

Depth

Sets the AM modulation depth of the COM/ID signal.

Remote command:

`[:SOURCE<hw>] :ADF:COMid:DEPTh` on page 623

Time Schema

Sets the time schema of the Morse code for the COM/ID signal.

"Standard" The set dot length determines the length of the dash, the symbol space and letter space of the Morse code.

"User" You can set each length value separately.

Remote command:

`[:SOURCE<hw>] :ADF:COMid:TSCHEMA` on page 624

Dot Length

Sets the length of a Morse code dot.

If "Time Schema" > "Standard", the dot length value determines also the length of the dash (= 3 times the dot length), symbol space (= dot length) and letter space (= 3 times the dot length).

Remote command:

`[:SOURCE<hw>] :ADF:COMid:DOT` on page 623

Dash Length

Requires "Time Schema" > "User".

Sets the length of a Morse code dash.

Remote command:

[\[:SOURCE<hw>\]:ADF:COMid:DASH](#) on page 622

Symbol Space

Requires "Time Schema" > "User".

Sets the length of the Morse code symbol space.

Remote command:

[\[:SOURCE<hw>\]:ADF:COMid:SYMBOL](#) on page 624

Letter Space

Requires "Time Schema" > "User".

Sets the length of a Morse code letter space.

Remote command:

[\[:SOURCE<hw>\]:ADF:COMid:LETTER](#) on page 623

7 List and sweep mode

The operating modes "List" and "Sweep" allow you to generate an RF signal having periodically varying frequencies or amplitudes.

A signal generated with varying parameters scans a certain range of varying values of a parameter, with defined start and end points, and can be repeated cyclically.

The R&S SMA100B supports two basic methods:

- **Sweep** mode

The instrument generates an RF signal which varies its frequency or level values in discrete steps between the start and end values. The values change according to a specific shape like sawtooth or triangle. The spacing is linear or logarithmic.




Figure 7-1: Schematic representation of a signal generated in sweep mode

The main application field of the "Sweep" mode is to determine the frequency response of a DUT.

- **List** mode

The instrument generates a varying output signal, based on a previously saved list with frequency, amplitude and step width values. While in sweep mode the frequency **or** the level values change, in list mode you can vary **both parameters simultaneously**. The frequency and level values do not need to have ascending or descending order, they can vary arbitrarily.

You can use a global dwell time, which means that the time interval is constant for all steps of the list, or different dwell times for each value pair.

[Figure 7-2](#) represents the frequency and power value pairs, in this case with the dwell time set the same for all steps (global dwell time).




Figure 7-2: Schematic representation of a signal generated in list mode (global dwell time)

The list mode is especially useful in high-speed measurements with fast changing frequency and level settings.



Note that the shown diagrams represent the behaviour in theory. In real signal generation, the instruments usually have a blank time when the frequency or level changes.

Interactions and characteristics of list and sweep mode

- Activating the list mode automatically deactivates all RF and LF sweeps and vice versa.
- In list processing mode, the frequency and level display in the status bar is disabled.



- The sweep modes only work with a *global* dwell time, that means the time intervals are constant during signal generation.
- If you want to hold a running sweep at a specific frequency or level value, enter the value in the status bar. The sweep stops immediately.
- We recommend that you switch off the display update for optimum sweep performance, especially with short dwell times
See [Chapter 12.1.2, "Display update settings"](#), on page 341.

7.1 Signal generation and triggering in the sweep and list modes

In both operating modes "List" and "Sweep", triggering and signal generation follow the same principle. The instrument generates the signal continuously (that means triggered automatically) or in individual steps (controlled manually by an internal or external trigger signal).

The instrument expects the trigger signal at the Inst Trig connector.



If the dwell time in sweep or list mode is too short or external trigger signals come too fast, the signal generation delays. As the delay increases, the R&S SMA100B signals an overrun, or even stops sweep or list mode signal generation, if the delay gets too long.

The instrument displays corresponding error messages.

The figures in this section give an overview on the signal generation in the sweep and list modes and the appropriate triggering. The figures show the signal state after activating the mode and the generation of the signal when a trigger event occurs. For each mode, the relevant parameters and settings are briefly explained.

Each "Sweep" and "List" mode dialog provides also a "Reset" function that sets the signal to the initial value or the beginning of the list. Depending on the selected trigger mode, the signal generation proceeds accordingly.



The naming of the selection parameters in manual control (GUI) sometimes deviates from the naming in the remote-control commands. In addition, the value names of the selection parameters used in the signal generator partly differ from the SCPI syntax. The instrument accepts all value names.

The correlation between the manual control and the corresponding remote control commands, including the SCPI conform syntax are explained for each mode (see the cross-reference tables).

See also the following programming examples on the sweep and list modes in remote control:

- [Example "Setup an RF frequency or power sweep"](#) on page 720
- [Example "Setup an LF sweep"](#) on page 674
- [Example "Create an RF list and activate the list mode"](#) on page 687

Signal generation and triggering in the sweep and list modes

Auto mode (Sweep/List)





Figure 7-3: Auto mode (Sweep/List)

- The instrument generates the signal continuously.
- Trigger mode "Auto" is prerequisite (default). It causes the continuous generation of the sweep signal.
- Starts signal generation immediately with "State = On".
- Switches automatically to the next step when the **Dwell time** has elapsed.
- Stops signal generation with "State = Off".

Table 7-1: Cross-reference between manual and remote control in Auto mode (Sweep/List)

Manual control mode: "Auto"	Remote commands Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:TRIGger<hw>:FSWEEP:SOURce AUTO [IMMediate] :SOURce<hw>:SWEep:FREQuency:MODE AUTO
RF level sweep	:TRIGger<hw>:PSWEEP:SOURce AUTO [IMMediate] :SOURce<hw>:SWEep:POWer:MODE AUTO
LF frequency sweep	:TRIGger<hw>:LFFSWEEP:SOURce AUTO [IMMediate] :SOURce<hw>:LFOutput<ch>:SWEep:FREQuency:MODE AUTO
List	:SOURce<hw>:LIST:MODE AUTO :SOURce<hw>:LIST:TRIGger:SOURce AUTO

Single / Extern Single mode (Sweep/List)**Figure 7-4: Single / Extern Single mode (sweep / list)**

In single mode, you can specify, that the signal returns to the start value when a sweep cycle has been completed.

See ["The Retrace function"](#) on page 177 for details.

- The instrument generates a single sweep cycle.
- Trigger mode "Manual". A trigger event initiates one sweep from the start value to the end value.
- "State = On" sets the signal to the start value: the sweep start frequency, the sweep start power or the frequency-power value pair of the selected index in the list.
- Starts signal generation with a trigger event.
- Switches automatically to the next step when the [Dwell time](#) has elapsed.
- Stops signal generation at the set end value and waits for the subsequent trigger event.
- Trigger sources:
 - The "Execute Single Sweep" function.
 - The corresponding remote control command.
 - An externally applied trigger signal.
- "State = Off" stops the signal generation in sweep or list mode.

Table 7-2: Cross-reference between manual and remote control in Single / Extern Single modes (Sweep/List)

Manual control mode: "Single / Extern Single"	Remote commands Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:TRIGger<hw>:FSWEEP:SOURce SINGLE [BUS] "Single" or :TRIGger<hw>:FSWEEP:SOURce EXTERNAL [EXTERNAL] "Extern Single" :SOURce<hw>:SWEep:FREQuency:MODE AUTO
RF level sweep	:TRIGger<hw>:PSWEEP:SOURce SINGLE [BUS] for "Single" or :TRIGger<hw>:PSWEEP:SOURce EXTERNAL [EXTERNAL] for "Extern Single" :SOURce<hw>:SWEep:POWer:MODE AUTO
LF frequency sweep	:TRIGger<hw>:LFFSWEEP:SOURce SINGLE [BUS] "Single" or :TRIGger<hw>:LFFSWEEP:SOURce EXTERNAL [EXTERNAL] "Extern Single" :SOURce<hw>:LFOutput<ch>:SWEep:FREQuency:MODE AUTO
List	:SOURce<hw>:LIST:TRIGger:SOURce SINGLE "Single" or :SOURce<hw>:LIST:TRIGger:SOURce EXTERNAL "Extern Single" :SOURce<hw>:LIST:MODE AUTO

Step / Extern Step mode (Sweep/List)




Figure 7-5: Step / Extern Step mode (sweep / list)

- The instrument generates the signal step-by-step.
- Starts signal generation with "State = On".
- Switches to the next step with a manual action.
If the end value is reached, signal generation starts again from the beginning.
- Stops signal generation with "State = Off".

Signal generation and triggering in the sweep and list modes

- Trigger sources:
 - The rotary knob at the front panel.
 - The [Arrow] keys at the front panel.
 - The corresponding remote control commands.
 - An externally applied trigger signal.

To step through the sweep frequencies or levels:


- In manual mode:
 - Set the **Current Frequency** or **Current Level** values
 - Use the [Up] and [Down] keys or the rotary knob
- In remote control mode:
 - Use the commands `[:SOURce<hw>] :FREQuency:MANual` or `[:SOURce<hw>] :POWer:MANual` with the UP or DOWN parameter



Steps that would exceed the sweep range are ignored.

Table 7-3: Cross-reference between manual and remote control in Step / Extern Step modes (Sweep/List)

Manual control mode: "Step / Extern Step"	Remote commands Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:TRIGger<hw>:FSweep:SOURce SINGLE [BUS] "Step" or :TRIGger<hw>:FSweep:SOURce EXTernal [EXTernal] for "Extern Step" :SOURce<hw>:SWEep:FREQuency:MODE STEP
RF level sweep	:TRIGger<hw>:PSweep:SOURce SINGLE [BUS] "Step" or :TRIGger<hw>:PSweep:SOURce EXTernal [EXTenal] "Extern Step" :SOURce<hw>:SWEep:POWer:MODE STEP
LF frequency sweep	:TRIGger<hw>:LFFSweep:SOURce SINGLE [BUS] "Step" or :TRIGger<hw>:LFFSweep:SOURce EXTernal [EXTenal] "Extern Step" :SOURce<hw>:LFOutput<ch>:SWEep:FREQuency:MODE STEP
List	:SOURce<hw>:LIST:TRIGger:SOURce SINGLE "Step" or :SOURce<hw>:LIST:TRIGger:SOURce EXTernal "Extern Step" :SOURce<hw>:LIST:MODE STEP

Extern Start/Stop mode (sweep)**Figure 7-6: Extern Start/Stop mode (sweep)**

- The instrument generates the signal continuously.
- Trigger mode "Auto" and "Sweep > State = On" are prerequisite.
- State "On" sets the signal to the start value, that is one of the following:
 - Sweep start frequency
 - Sweep start power
 - Frequency-power value pair of the selected index in the list
- Starts signal generation with a trigger event.
- Switches automatically to the next sweep step when the **Dwell time** has elapsed. If the end value is reached, signal generation continues with the next sweep cycle.
- Stops signal generation with the next external trigger event.
- Starts the signal generation again with the next trigger event, beginning at the start value.
- "State = Off" stops the signal generation in sweep or list mode.
- Trigger source: An externally applied trigger signal.

Table 7-4: Cross-reference between manual and remote control in Extern Start/Stop modes (sweep)

Manual control mode: "Extern Start/Stop"	Remote commands Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:TRIGger<hw>:FSweep:SOURce EAUTO [-] :SOURce<hw>:SWEep:FREQuency:MODE AUTO
RF level sweep	:TRIGger<hw>:PSweep:SOURce EAUTO [-] :SOURce<hw>:SWEep:POWer:MODE AUTO
LF frequency sweep	:TRIGger<hw>:LFFSweep:SOURce EAUTO [-] :SOURce<hw>:LFOutput<ch>:SWEep:FREQuency:MODE AUTO

Manual mode (Sweep/List)



The **manual** mode only applies to remote control. It is not visible in the graphical user interface of the instrument and is described here for completeness.





Figure 7-7: Manual mode in remote control (sweep / list)

- The instrument generates the signal in steps.
- Starts signal generation with "State = On".
- Switches to the next step with a user defined setting via remote control. You can arbitrarily select a value within the range of the start and stop values by setting the frequency, power or index using the corresponding remote control command. There is no ascending or descending order.
- Stops signal generation with "State = Off".

Table 7-5: Remote control commands in manual mode (Sweep/List)

Remote control mode:	Remote commands
Manual	Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:SOURce<hw>:FREQuency:MANUal <Manual>
RF level sweep	:SOURce<hw>:POWEr:MANUal <Manual>
LF frequency sweep	:SOURce<hw>:LFOUtpuT:FREQuency:MANUal <Manual>
List	:SOURce<hw>:LIST:INDex <Index>

The Retrace function



Retrace is a function especially designed for "Single" sweep modes, when the sweep signal follows a sawtooth shape. Working in this mode, the instrument performs a single sweep cycle when a trigger event occurs. The signal generation stops at the set end point (stop frequency or stop level), and waits for the next trigger event.

In this state, the upper value of the signal remains at the output until the next cycle starts. In particular, if you generate a level sweep signal, the high amplitude of the signal is output for a certain time. To protect the DUT from overload, the retrace function immediately resets the signal value to the start value at the end of a sweep cycle. It returns to the start level or start frequency until the next trigger is applied.

You can use the "Retrace" function if "Sweep > Mode = Single/External Single" and "Shape = Sawtooth", see:

- ["Shape"](#) on page 188
- ["Mode"](#) on page 186

7.2 About sweep mode

In sweep mode, the signal generator scans the sweep range gradually from one point to another, using a defined step size and following a triangle or sawtooth shape. This mode also enables you to change direction, that means, it is possible to step backwards.

See [Chapter 7.2.2, "Sweep signal shapes"](#), on page 180.

Configuration and operation of sweep mode signals

- The R&S SMA100B generates a sweep signal by varying the following parameters: either the *RF frequency*, the *RF level* or both, the *RF frequency* and the *RF level* in combined RF sweep mode, or the *LF frequency*.
- In all sweep modes, you can perform a complete sweep cycle once, repeat the cycle continuously or step through it gradually.
- The instrument generates the sweep signal according to the sweep settings.
- The "Reset Sweep" function, provided in the sweep settings dialogs enables you to reset the sweep to its initial value and restart it.



Impact of changing the sweep mode during performance

If you change the sweep mode during the execution, the signal generator stops the sweep and starts with the next trigger event at the initial value.

Combined RF frequency / level sweep processing mode

The combined RF sweep functionality processes the signal similar to the Live list mode. The R&S SMA100B sets the frequency and level values simultaneously in the hardware. The difference to the list mode is that the values are not taken from a previously created list, but are calculated using the selected frequency and level ranges, the dwell time and the number of steps.

7.2.1 Correlating parameters in sweep mode

A sweep signal is a periodic signal that changes its frequency or level, or both, from a starting value to an ending value in a defined time.

The R&S SMA100B provides various possibilities to configure a sweep signal. For example, you can determine the sweep range by the start and end values, or based on the start value and span. In any case, related parameters are adjusted accordingly.

The formulas below show how the sweep parameters correlate and the corresponding calculation basis, by the frequency and offset settings. Apart from "Center Frequency", "Span" and "Step_lin", the values apply accordingly to the level settings.

Table 7-6: Variables that are used in the following formulas

Variable	Description
Sweep range	Defined frequency or level value range
f_{CENTer}	Defined center frequency
f_{SPAN}	Defined extend of the sweep range
f_{OFFSet}	Frequency offset
f_{START}	Start frequency of the sweep range
f_{STOP}	End frequency of the sweep range
f_1	Current sweep frequency

Variable	Description
f_2	Next, subsequent sweep frequency
step_lin	Step size in linear scaling
step_log	Step size in logarithmic scaling
POINts	Number of steps within the sweep range

Sweep range

The sweep range is defined by a start and an end value. How the remaining parameters correlate is shown below.

Offset = 0

Sweep Range = f_{START} to f_{STOP}

$$f_{\text{CENTer}} = (f_{\text{START}} + f_{\text{STOP}})/2$$

$$f_{\text{SPAN}} = (f_{\text{STOP}} - f_{\text{START}})$$

Where:

$$f_{\text{START}} = f_{\text{CENTer}} - (f_{\text{SPAN}}/2)$$

$$f_{\text{STOP}} = f_{\text{CENTer}} + (f_{\text{SPAN}}/2)$$

Offset≠0

A defined offset also affects the sweep range and the center frequency. Therefore, the set frequencies are only absolute values, if the Offset = 0. Offset ≠ 0 shifts the frequencies with the offset value:

Sweep Range = $f_{\text{START}} + f_{\text{OFFSet}}$ to $f_{\text{STOP}} + f_{\text{OFFSet}}$

$$f_{\text{CENTer}} = f_{\text{CENTer}} + f_{\text{OFFSet}}$$

$$f_{\text{SPAN}} = f_{\text{SPAN}} + f_{\text{OFFSet}}$$

The value range of the instrument is calculated as follows:

$$RF_{\text{min}} + f_{\text{OFFSet}} \text{ to } RF_{\text{max}} + f_{\text{OFFSet}}$$



It is possible to set $f_{\text{START}} > f_{\text{STOP}}$ and $f_{\text{START}} < f_{\text{STOP}}$, so that even a negative value is permitted for the "Span".

If you change the start and/or stop frequency, the span and center frequency change accordingly, and vice versa.

Sweep steps

In the following, you see how the sweep steps are calculated depending on the defined spacing mode. The formulas show a frequency sweep, but apply to the level settings in the same way.

The step size is added to the current value, to get the subsequent sweep step.

With **linear** scaling, the next frequency is calculated according to:

$$f_2 = f_1 + \text{step_lin}$$

In the **logarithmic** scaling, the step size is determined in per cent, as a constant fraction of the current frequency.

Successive frequencies are calculated as follows:

- For $f_{\text{START}} < f_{\text{STOP}}$
 $f_2 = f_1 * (1 + \text{step_log}/100)$
 If $f_2 > f_{\text{STOP}}$, then $f_2 = f_{\text{STOP}}$
- For $f_{\text{START}} > f_{\text{STOP}}$
 $f_2 = f_1 / (1 + \text{step_log}/100)$
 If $f_2 < f_{\text{STOP}}$, then $f_2 = f_{\text{STOP}}$

With "Shape = Triangle", the frequency values on the slope from f_{STOP} to f_{START} are the same as on the slope from f_{START} to f_{STOP} .

If you specify the number of steps within the sweep range, the step size is adjusted according to the following correlation:

- For **linear** sweeps and $f_{\text{START}} < f_{\text{STOP}}$
 $\text{POINTS}_{\text{frequency}} = ((f_{\text{START}} - f_{\text{STOP}})/\text{step_lin}) + 1 = (f_{\text{SPAN}}/\text{step_lin}) + 1$
- For **logarithmic** sweeps and $f_{\text{START}} < f_{\text{STOP}}$
 $\text{POINTS}_{\text{frequency}} = ((\log f_{\text{STOP}} - \log f_{\text{START}})/\log \text{step_log}) + 1$

If step_log changes, the value of POINTs is adjusted. The f_{START} and f_{STOP} values are retained.

7.2.2 Sweep signal shapes

The R&S SMA100B supports the following sweep shapes:

- Sawtooth
 The sweep sequence resembles a sawtooth. One sweep runs from start to stop frequency, or level value respectively. Each subsequent sweep starts again at the start value.




Figure 7-8: Sweep signal sawtooth shape

1 = Start value
2 = Stop value
3 = Step size

- Triangle
The sweep sequence resembles a triangle. One sweep runs from start to stop value frequency and back. Each subsequent sweep starts at the start value.




Figure 7-9: Sweep signal triangle shape

1 = Start value
2 = Stop value
3 = Step size

The current frequency or level of an RF frequency, level or LF frequency sweep is determined by the shape (e.g. sawtooth or triangle) and the spacing (linear or logarithmic), and the step size.

7.3 About list mode

The list mode is used to generate the RF signal based on a set of predefined frequency and amplitude value pairs, with individual step times. You can define the values

arbitrarily, in any order and varying step sizes, within the entire configurable value range of the instrument.

Configuration and operation of list mode signals

The parameters configuring the RF signal are defined in a list (table) and stored in a file.

Creating and handling lists

List files can be created in the following ways:

- **Internally**
Use the build-in table editor with columns for the frequency-level values pairs and the dwell time.
Define the values manually (row by row) or automatically, based on value range and step size.
(See [Chapter 7.7, "List editor"](#), on page 204)
Lists are saved as files with user-definable filename and the predefined file extension *.lsw. To load a saved file, use the "File Manager".
(See [Chapter 11.8, "Using the file manager"](#), on page 321)
- Lists can be exported, too. For example, to exchange configuration between instruments or to modify the file content with an external program and reload them again.
- **Externally**
Create a list file as a CSV file with Microsoft Excel, with a Notepad or a similar tool and save it with the predefined extension. Transfer the file to and load it into the instrument.

Dwell time mode

You can choose whether you want to use different dwell times or a fixed value for all steps in the list mode:

- "From List"
This mode uses the values from the data table.
See [Edit List Mode Data](#)
- "Global"
This mode processes the list with a fixed time interval you can set with [Global Dwell Time](#).

List processing mode

See:

- ["Live list processing mode"](#) on page 184

7.4 Significant parameters and functions

This section provides some basic parameters, settings and functions that affect the operating modes CW, list and sweep, that means at all frequency and level transitions of the RF signal.

Dwell time

Dwell time is the length of time that elapses from the beginning until the end of a step in list or sweep mode.




Figure 7-10: Dwell Time vs. settling time

- 1 = "Dwell Time" (as set with the parameter)
- 2 = Settling time
- 3 = Dwell time (effective)

However, the time the instrument requires for the signal to settle reduces the set dwell time:

$$t_{\text{dwell(effective)}} = t_{\text{dwell}} - t_{\text{settling}}$$



If the dwell time in sweep or list mode is too short or external trigger signals come too fast, the signal generation delays. As the delay increases, the R&S SMA100B signals an overrun, or even stops sweep or list mode signal generation, if the delay gets too long.

The instrument displays corresponding error messages.

Hardware adjustments

The first time a list (new or modified) is processed, the instrument automatically calculates the necessary hardware settings. It can be performed during list processing, but delays the first cycle, especially with short dwell times.

With long dwell times, you can perform this calculation while the list is being processed; the entered dwell times are observed. With short dwell times, calculation of the hardware settings increases the dwell time for the initial processing cycle; the entered value is only observed from the second processing cycle onwards. In this case, a message indicates that there is a deviation between the current and set dwell times. After the first cycle, you do not need to perform additional calculations. The current dwell times do not deviate from the set dwell times.

Blanking

The instrument applies *blanking*, which temporarily turns off the RF signal when the frequency or level changes, until the signal has settled to a stable state.

Temporary blanking applies to all operating modes.

Live list processing mode

The R&S SMA100B generates the signal directly from the value pairs in the database, and adjusts the hardware settings accordingly. The current instrument state and thus any change during the signal generation directly affects the RF signal. The temporary memory is not used.

You can conveniently modify parameters like modulation settings during run-time. Learning list mode data is not required. Impacts like temperature drift are also considered immediately.

This mode is optimized for **maximum signal quality**, and is useful if dwell times higher than 2 ms are sufficient.

7.5 Sweep mode settings

This section lists the settings of **all** available sweep modes.

Access:

1. Select "Sweep" > "RF Frequency Sweep"
2. Select "Sweep" > "RF Level Sweep"
3. Select "Sweep" > "RF Combined Sweep"
4. Select "Sweep" > "LF Frequency Sweep"

The remote commands required to define these settings are described in:

- [Chapter 14.17.13, "SOURce:SWEep subsystem"](#), on page 720
- [Chapter 14.17.4, "SOURce:FREQuency subsystem"](#), on page 664
- [Chapter 14.17.11, "SOURce:POWEr subsystem"](#), on page 704
- [Chapter 14.17.6, "SOURce:LFOutput subsystem"](#), on page 674

Settings

• General sweep settings	184
• Frequency range settings	191
• Level range settings	193
• Output settings	195
• Edit marker settings	196

7.5.1 General sweep settings

Access:

- Select for example "Sweep" > "RF Frequency Sweep".

Table 7-7: General settings dialog: Examples of RF Frequency and RF Combined Sweep dialogs

> "RF Frequency Sweep"	> "RF Combined Sweep"

Settings

Sweep Type	185
State (RF frequency sweep)	185
State (RF level sweep)	186
State (RF frequency / level sweep)	186
State (LF frequency sweep)	186
Current Frequency	186
Current Level	186
Mode	186
Retrace	187
Shape	188
Spacing	189
Sweep Time	189
Dwell Time	189
Trigger Slope	190
Show Connector	190
Reset Sweep	190
Execute Single Sweep	190

Sweep Type

Selects the kind of the frequency sweep.

- "Step" Increases or decreases the frequency at each step.
To determine the frequency intervals, see [Spacing](#).
- "Ramp" Provides a synthesized continuous analog frequency sweep with the set [Sweep Time](#).

Remote command:

[\[:SOURce<hw>\]:SWEep:GENeration](#) on page 724

State (RF frequency sweep)

Activates RF frequency sweep signal generation.

Note: Active RF frequency, RF level or RF combined sweep modes deactivate the LF sweep or List mode and vice versa.

Remote command:

[:SOURce<hw>] :FREQuency:MODE on page 665

State (RF level sweep)

Activates RF level sweep signal generation.

Note: Active RF frequency, RF level or RF combined sweep modes deactivate the LF sweep or List mode and vice versa.

Remote command:

[:SOURce<hw>] :POWer:MODE on page 709

State (RF frequency / level sweep)

Activates the RF frequency / level sweep signal generation.

Note: Active RF frequency, RF level or RF combined sweep modes deactivate the LF sweep or List mode and vice versa.

Remote command:

[:SOURce<hw>] :FREQuency:MODE on page 665

[:SOURce<hw>] :POWer:MODE on page 709

State (LF frequency sweep)

Status of the LF frequency sweep signal.

You find this parameter in two dialogs:

- "LF Frequency Sweep" turns on/off the signal generation.
See [Sweep mode settings](#) for access.
- "Analog Modulation Sources" displays the current state (read-only). If it is turned on, this dialog provides the varying sweep frequency, see [Current Frequency](#).

Note: Active RF frequency, RF level or RF combined sweep modes deactivate the LF sweep or List mode and vice versa.

Remote command:

[:SOURce<hw>] :LFOutput:FREQuency:MODE on page 678

Current Frequency

Displays the current frequency sweep value for all sweep [Modes](#), except of [Mode > Step](#). In this mode, you can enter the next frequency setting manually.

Remote command:

[:SOURce<hw>] :FREQuency:MANual on page 668

[:SOURce<hw>] :LFOutput:FREQuency:MANual on page 678

Current Level

Displays the current level sweep value for all sweep [Modes](#), except of [Mode > Step](#). In this mode, you can enter the next level setting manually.

Remote command:

[:SOURce<hw>] :POWer:MANual on page 709

Mode

Selects the sweep mode.

See [Chapter 7.1, "Signal generation and triggering in the sweep and list modes"](#), on page 170.

- "Auto" Generates a continuously repeating sweep signal directly after activating the sweep mode.
The sweep steps are performed automatically, controlled by the dwell time.
- "Single / Extern Single" Generates a single sweep cycle after a trigger event.
The sweep steps within the cycle are performed automatically, controlled by the dwell time. If one cycle is completed, the instrument waits for the next trigger event.
- "Step / Extern Step" Generates the sweep signal step-by-step, manually triggered.
- "Extern Start/Stop" Generates a continuously repeating sweep signal that is started, stopped, and restarted by subsequent external trigger events.
The sweep steps are performed automatically, controlled by the dwell time.

Remote command:

RF frequency sweep:

[\[:SOURce<hw>\]:SWEep\[:FREQuency\]:MODE](#) on page 726
[:TRIGger<hw>:FSWEEP:SOURce](#) on page 766

RF level sweep:

[\[:SOURce<hw>\]:SWEep:POWer:MODE](#) on page 724
[:TRIGger<hw>:PSWEEP:SOURce](#) on page 766

RF combined sweep:

[\[:SOURce<hw>\]:SWEep:COMBined:MODE](#) on page 732
[:TRIGger<hw>:FPSWEEP:SOURce](#) on page 767

LF frequency sweep:

[\[:SOURce<hw>\]:LFOutput:SWEep\[:FREQuency\]:MODE](#) on page 684
[:TRIGger<hw>:LFFSWEEP:SOURce](#) on page 766

Retrace

For "Shape = Sawtooth" and "Mode = Single/External Single", enables changing the signal to the start value while it is waiting for the next trigger event. It returns to the start level or start frequency until the next trigger is applied.

Remote command:

RF frequency sweep:

[\[:SOURce<hw>\]:SWEep\[:FREQuency\]:RETRace](#) on page 728

RF level sweep:

[\[:SOURce<hw>\]:SWEep:POWer:RETRace](#) on page 728

RF combined sweep:

[\[:SOURce<hw>\]:SWEep:COMBined:RETRace](#) on page 732

LF frequency sweep:

[\[:SOURce<hw>\]:LFOutput:SWEep\[:FREQuency\]:RETRace](#) on page 685

Shape

Selects the waveform shape of the sweep signal.

"Sawtooth"

The sweep runs from start to stop frequency. The subsequent sweep starts at the start value, i.e. the shape of the sweep sequence resembles a sawtooth.




Figure 7-11: Sweep signal sawtooth shape

1 = Start value
2 = Stop value
3 = Step width

"Triangle"

The sweep runs from start to stop value and back, i.e. the shape of the sweep resembles a triangle. Each subsequent sweep starts at the start frequency.

The triangle shape is only available for [Sweep Type > Step](#).




Figure 7-12: Sweep signal triangle shape

1 = Start value
2 = Stop value
3 = Step width

Remote command:

RF frequency sweep:

[\[:SOURCE<hw>\]:SWEep\[:FREQuency\]:SHApe](#) on page 728

RF level sweep:

[:SOURce<hw>] :SWEep:POWer:SHApe on page 728

RF combined sweep:

[:SOURce<hw>] :SWEep:COMBined:SHApe on page 733

LF frequency sweep:

[:SOURce<hw>] :LFOutput:SWEep [:FREQuency] :SHApe on page 686

Spacing

In "RF and LF Frequency Sweep" mode, "Spacing " selects the mode for calculating the frequency interval, which increases or decreases the current frequency at each step.

In "RF Frequency Sweep" mode and [Sweep Type > Ramp](#), the parameter automatically distributes the step intervals linearly.

To determine the step size, select the parameter [Step Linear/Step Logarithmic](#).

In "RF Combined Sweep" mode, the parameter indicates that the step intervals are linearly (straight proportional) distributed, i.e. the intervals have the same size. The frequency / level range and the [Dwell Time](#) time determine the calculated step size.

- | | |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| "Linear" | <p>The spacing depends on the selected sweep type.</p> <ul style="list-style-type: none"> • Sweep Type > Step
Takes the frequency value entered as absolute value in Hz. • Option: R&S SMAB-B28
Sweep Type > Ramp
Generates a synthesized continuous analog frequency sweep for the duration set with the parameter Sweep Time. |
| "Logarithmic" | <p>(Sweep Type > Step only)
Takes the value entered as a logarithmic value, i.e. as a constant fraction of the current frequency in %.</p> |

Remote command:

RF frequency sweep:

[:SOURce<hw>] :SWEep [:FREQuency] :SPACing on page 727

RF combined sweep: n.a.

LF frequency sweep:

[:SOURce<hw>] :LFOutput:SWEep [:FREQuency] :SPACing on page 686

Sweep Time

Option: R&S SMAB-B28

For "RF Frequency Sweep" with [Sweep Type > Ramp](#), the parameter sets the duration of a ramp sweep step.

Remote command:

[:SOURce<hw>] :SWEep [:FREQuency] :TIME on page 733

Dwell Time

Defines the duration of the individual sweep steps.

Note: In case of considerable overrun conditions, the R&S SMA100B turns off the sweep mode.

See also [Chapter 7.4, "Significant parameters and functions"](#), on page 182.

Remote command:

RF frequency sweep:

`[:SOURce<hw>] :SWEep [:FREQuency] :DWELl` on page 726

RF level sweep:

`[:SOURce<hw>] :SWEep:POWer:DWELl` on page 724

RF combined sweep:

`[:SOURce<hw>] :SWEep:COMBined:DWELl` on page 731

LF frequency sweep:

`[:SOURce<hw>] :LFOutput:SWEep [:FREQuency] :DWELl` on page 684

Trigger Slope

For "Mode = Extern Step/Single", selects the polarity of the active slope of an applied instrument trigger.

Trigger signal is expected at the Inst Trig connector.

"Positive" The rising edge of the trigger signal triggers the instrument.

"Negative" The falling edge of the trigger signal triggers the instrument.

Remote command:

`[:SOURce] :INPut:TRIGger:SLOPe` on page 674



Show Connector

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

Reset Sweep

Resets a sweep.

With the next trigger event, the sweep starts at the initial value.

Remote command:

`[:SOURce<hw>] :SWEep:RESet [:ALL]` on page 733

Execute Single Sweep

In "Mode = Single", starts a sweep manually.

Remote command:

RF frequency sweep:

`[:SOURce<hw>] :SWEep [:FREQuency] :EXECute` on page 728

`:TRIGger<hw>:FSWep [:IMMediate]` on page 768

RF level sweep:

`[:SOURce<hw>] :SWEep:POWer:EXECute` on page 728

`:TRIGger<hw>:PSWep [:IMMediate]` on page 768

RF combined sweep:

`[:SOURce<hw>] :SWEep:COMBined:EXECute` on page 731

LF frequency sweep:

`[:SOURce<hw>] :LFOutput:SWEep [:FREQuency] :EXECute` on page 684

`:TRIGger<hw>:LFFSweep:IMMediate` on page 768

General:

`:TRIGger<hw> [:SWEep] [:IMMediate]` on page 768

7.5.2 Frequency range settings

Access:

1. Select for example "Sweep" > "RF Frequency Sweep"
2. Select for example "Frequency Range".

Table 7-8: Range settings dialog: Examples of RF Frequency and RF Combined Sweep dialogs

> "Frequency Range"					> "Frequency / Level Range"				
<div><div>General</div><div>Single</div></div> <div>Frequency Range</div> <div>Output</div> <div>Edit Marker</div> <div></div> <div>X</div>					<div><div>General</div><div>Auto</div></div> <div>Frequency Level Range</div> <div>Output</div> <div>Edit Marker</div> <div></div> <div>X</div>				
Start Frequency			100.000 000 000 MHz		Stop Frequency			500.000 000 000 MHz	
Center Frequency			300.000 000 000 MHz		Span			400.000 000 000 MHz	
Spacing			Linear		Step Linear			1.000 000 000 MHz	

Start Frequency			100.000 000 000 MHz		Stop Frequency			500.000 000 000 MHz	
Start Level			-30.00 dBm		Stop Level			-10.00 dBm	
Step Count			501						

Settings

Start Frequency/Stop Frequency.....	191
Center Frequency.....	191
Span.....	192
Spacing.....	192
Step Linear/Step Logarithmic.....	192

Start Frequency/Stop Frequency

Defines the frequency sweep range by setting the start and end values.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Remote command:

RF frequency sweep:

[:SOURce<hw>] :FREQuency:START on page 669

[:SOURce<hw>] :FREQuency:STOP on page 670

RF combined sweep:

[:SOURce<hw>] :COMBined:FREQuency:START on page 730

[:SOURce<hw>] :COMBined:FREQuency:STOP on page 730

LF frequency sweep:

[:SOURce<hw>] :LFOutput:FREQuency:START on page 679

[:SOURce<hw>] :LFOutput:FREQuency:STOP on page 679

Center Frequency

In "RF Frequency Sweep" mode, sets the RF center frequency.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Remote command:

[:SOURce<hw>] :FREQuency:CENTer on page 669

Span

In "RF Frequency Sweep" mode, sets the span of the frequency sweep range.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Remote command:

[\[:SOURce<hw>\]:FREQuency:SPAN](#) on page 669

Spacing

In "RF and LF Frequency Sweep" mode, "Spacing " selects the mode for calculating the frequency interval, which increases or decreases the current frequency at each step.

In "RF Frequency Sweep" mode and [Sweep Type > Ramp](#), the parameter automatically distributes the step intervals linearly.

To determine the step size, select the parameter [Step Linear/Step Logarithmic](#).

In "RF Combined Sweep" mode, the parameter indicates that the step intervals are linearly (straight proportional) distributed, i.e. the intervals have the same size. The frequency / level range and the [Dwell Time](#) time determine the calculated step size.

- | | |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| "Linear" | <p>The spacing depends on the selected sweep type.</p> <ul style="list-style-type: none"> • Sweep Type > Step
Takes the frequency value entered as absolute value in Hz. • Option: R&S SMAB-B28
Sweep Type > Ramp
Generates a synthesized continuous analog frequency sweep for the duration set with the parameter Sweep Time. |
| "Logarithmic" | <p>(Sweep Type > Step only)
Takes the value entered as a logarithmic value, i.e. as a constant fraction of the current frequency in %.</p> |

Remote command:

RF frequency sweep:

[\[:SOURce<hw>\]:SWEep\[:FREQuency\]:SPACing](#) on page 727

RF combined sweep: n.a.

LF frequency sweep:

[\[:SOURce<hw>\]:LFOutput:SWEep\[:FREQuency\]:SPACing](#) on page 686

Step Linear/Step Logarithmic

In "RF/LF Frequency Sweep" mode, sets the step width for the individual frequency sweep steps. The value is added at each sweep step to the current frequency.

Depending on the current [Spacing](#), you can enter either an absolute or logarithmic step width.

This parameter is only available for [Sweep Type > Step](#).

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

"Step Linear" The step width is a constant value in Hz.

"Step Logarithmic"

The step width is determined logarithmically in %, i.e. as a constant fraction of the current frequency.

Remote command:

`[:SOURce<hw>] :SWEep [:FREQuency] :STEP [:LINear]`

on page 729

`[:SOURce<hw>] :SWEep [:FREQuency] :STEP:LOGarithmic`

on page 729

`[:SOURce<hw>] :LFOutput:SWEep [:FREQuency] :STEP [:LINear]` on page 687



`[:SOURce<hw>] :LFOutput:SWEep [:FREQuency] :STEP:LOGarithmic` on page 686

7.5.3 Level range settings

Access:

1. Select "Sweep" > "RF Level Sweep"
2. Select for example "Level Range".

Table 7-9: Range settings dialog: Examples of RF Level and RF Combined Sweep dialogs

> "Level Range"	> "Frequency / Level Range"
	

Settings

Start Level / Stop Level.....	193
Step Count.....	194
Spacing.....	194
Step.....	194
Setting Characteristics.....	194
Sweep Level Range.....	195

Start Level / Stop Level

Defines the RF level sweep range by setting the start and end values.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Remote command:

RF level sweep:

`[:SOURce<hw>] :POWer:START` on page 710

`[:SOURce<hw>] :POWer:STOP` on page 710

RF combined sweep:

`[:SOURce<hw>] :COMBined:POWer:START` on page 730

`[:SOURce<hw>] :COMBined:POWer:STOP` on page 731

Step Count

In "RF Combined Mode", defines the number of sweeps to be executed in [Mode > Single](#).

To start the sweep cycles, select [Execute Single](#).

Remote command:

`[:SOURce<hw>] :SWEep:COMBined:COUNt` on page 731

Spacing

Indicates that the instrument distributes the level steps linearly (straight proportional), i.e. the level steps have the same size.

To determine the step size, use the parameter [Step](#).

Remote command:

n.a.

Step

Sets the step width for the RF level sweep in dB.

The "RF level sweep" mode increases or decreases the level value linearly by the set value.

Remote command:

`[:SOURce<hw>] :SWEep:POWer:STEP[:LOGarithmic]` on page 725

Setting Characteristics

Selects additional quality characteristics to optimize the behavior of the RF signal level for the specific application.

"Auto"	<p>Sets the RF output level automatically according to the selected mode.</p> <p>In this mode, the instrument provides the highest dynamic range and fastest setting times, as specified in the data sheet.</p> <p>The RF signal is shortly blanked when the step attenuator is switching.</p>
"Uninterrupted"	<p>Suppresses blanking at level transitions. Frequency transitions can lead to an RF level blanking due to hardware specific switching points.</p> <p>This mode reduces the dynamic range of the instrument. The step attenuator is fixed.</p>

"Strictly Monotone"

Executes signal level changes monotonically increasing or decreasing.

The setting makes sure that increasing the level value exclusively results in an increased output level, and vice versa.

All electronic switches, which might affect the monotonicity are fixed. The operation mode is useful for applications using level searching algorithms which rely on a strictly monotonous behavior.

"Constant-VSWR"

Suppresses output impedance variations at the RF 50 Ω output connector, due to changed level settings.

"High Dyn. Uninterrupted"

R&S SMAB-K724

Provides a linear output power that is uninterrupted over a wide dynamic range.

Note: The R&S SMA100B supports this characteristic at frequencies above 52 MHz. If you select the setting at lower frequencies (≤ 52 MHz), the instrument reports a settings conflict.

"User"

Indicates that a setting has been modified in the expert mode. The expert mode is a protected function, that requires protection level 2 password.

Remote command:

`[:SOURce<hw>] :POWer:LBEHaviour` on page 708

Sweep Level Range

Displays the RF level sweep range.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Remote command:

`[:SOURce<hw>] :POWer:RANGe:MIN?` on page 714


`[:SOURce<hw>] :POWer:RANGe:MAX?` on page 714

7.5.4 Output settings

Option: R&S SMAB-B28

Access:

1. Select "Sweep" > "RF Frequency Sweep".
2. Select "Output".



Settings

V/GHz / X-Axis	196
Marker / User	196

V/GHz / X-Axis

Option: R&S SMAB-B28

Selects the mode the voltage is supplied depending on the frequency.

The R&S SMA100B supplies the signal at the V/GHz X-Axis connector.

"0,25 V/GHz" / "0,5 V/GHz" / "1 V/GHz" Supplies the voltage proportional to the set frequency, derived from the selected setting.

"X-Axis" Supplies a voltage range from 0 V to 10 V proportional to the frequency sweep range, set with [Start Frequency/Stop Frequency](#).

Remote command:
[:OUTPut:FPRoportional:SCALe](#) on page 513

Marker / User

Option: R&S SMAB-B28

Selects the signal to be supplied at the Marker User1 connector.

"Marker" Assigns a marker signal to the output.
 To configure and assign the marker signals, see [Chapter 7.5.5, "Edit marker settings"](#), on page 196.

"User" Intended for future use.

Remote command:
[:OUTPut:USER:MARKer](#) on page 513

7.5.5 Edit marker settings

Option: R&S SMAB-B28

Access:

1. Select "Sweep" > "RF Frequency Sweep"
2. Select "Edit Marker".

General Single	Frequency Range	Output	Edit Marker	X
Frequency 1 1.000 000 000 000 GHz	<input checked="" type="checkbox"/>	Frequency 6 3.000 000 000 000 GHz	<input checked="" type="checkbox"/>	
Frequency 2 4.500 000 000 000 GHz	<input checked="" type="checkbox"/>	Frequency 7 1.000 000 000 000 GHz	<input type="checkbox"/>	
Frequency 3 2.100 000 000 000 GHz	<input type="checkbox"/>	Frequency 8 1.000 000 000 000 GHz	<input type="checkbox"/>	
Frequency 4 1.000 000 000 000 GHz	<input type="checkbox"/>	Frequency 9 1.000 000 000 000 GHz	<input type="checkbox"/>	
Frequency 5 1.000 000 000 000 GHz	<input type="checkbox"/>	Frequency 10 1.000 000 000 000 GHz	<input type="checkbox"/>	
Marker Polarity Normal		Active Marker 3 - 2100000000.00 Hz		

You can define up to 10 markers, and assign one of them to the output at a time. When the sweep run has reached the marker frequency, the R&S SMA100B activates the marker signal and supplies it at the Marker User1 connector. The duration of the active signal corresponds to the dwell time of a step.

Settings

Frequency x.....	197
State.....	197
Marker Polarity.....	198
Active Marker.....	198

Frequency x

Sets the frequency that the selected marker indicates.

When the specified value is used, the polarity of the marker signal changes, as selected with the parameter .

Remote command:

[:SOURce<hw>] :SWEep [:FREQuency] :MARKer<ch>:FREQuency on page 734

State

Enables the selected marker.

A marker signal at the output connector marks the moment the specified frequency values is used.

Remote command:

[:SOURce<hw>] :SWEep [:FREQuency] :MARKer<ch>:FState on page 734

Marker Polarity

Sets the polarity of the marker signal.

The duration of the active signal is equal to the dwell time of a step.

Remote command:

[\[:SOURce<hw>\]:SWEep:MARKer:OUTPut:POLarity](#) on page 733

Active Marker

Boosts a specific marker signal so that it is output with higher voltage than all other markers.

Remote command:

[\[:SOURce<hw>\]:SWEep\[:FREQuency\]:MARKer:ACTive](#) on page 734

7.6 List mode settings

The "List Mode" dialog contains all the functions and settings for creating and handling lists with RF frequency/level pairs including the corresponding dwell times for generating the RF signal based on these values.

Access:

- Select "Sweep" > "List mode".

The dialog contains parameters for configuring the list mode processing, entering list mode data and transferring data files from or to the instrument.

The remote commands required to define these settings are described in [Chapter 14.17.7, "SOURce:LIST subsystem"](#), on page 687.

- [General settings](#)..... 199
- [List mode data settings](#)..... 201
- [Import/export settings](#)..... 202

7.6.1 General settings

Access:

- Select "Sweep" > "List mode".

The screenshot shows a software interface for configuring list mode settings. The 'General' tab is active, displaying the following parameters:

- State:** A numeric field set to 0.
- Mode:** A dropdown menu set to 'Auto'.
- Dwell Time Mode:** A dropdown menu set to 'Global'.
- Global Dwell Time:** A text field set to '10.000 ms'.
- Reset:** A button with a circular arrow icon.

In the "General" tab, you can configure the trigger and dwell time modes for list processing and activate signal generation.

Settings

State.....	199
Current Index.....	199
Mode.....	200
Dwell Time Mode.....	200
Global Dwell Time.....	200
Trigger Slope.....	200
Reset.....	201
Execute Single.....	201

State

Activates the list mode and processes the currently selected list.

Note: Active RF frequency, RF level or RF combined sweep modes deactivate the LF sweep or List mode and vice versa.

Remote command:

[:SOURce<hw>] :FREQuency:MODE on page 665

Current Index

Sets the list index for list processing in "Step" mode. In the other modes, the index indicates the current step.

Remote command:

[:SOURce<hw>] :LIST:INDEX on page 692

Mode

Selects the mode for list processing.

See [Chapter 7.1, "Signal generation and triggering in the sweep and list modes"](#), on page 170.

"Auto" Generates the signal by processing the frequency/level value pairs of the list from the beginning to the end.
The list steps are performed automatically, controlled by the dwell time. If you switch from any mode to "Auto", signal generation always starts at the top of the list.

"Single / Extern Single"

Generates the signal by processing the frequency/level value pairs of the list once from the beginning to the end after a trigger event.
The list steps are performed automatically, controlled by the dwell time. If one cycle is completed, the instrument waits for the next trigger event.

"Step / Extern Step"

Generates the signal by processing the frequency/level value pairs of the list step-by-step, manually triggered.

Remote command:

`[:SOURce<hw>] :LIST:TRIGger:SOURce` on page 694

`[:SOURce<hw>] :LIST:MODE` on page 693

Dwell Time Mode

Selects either variable dwell times or a fixed dwell time to perform signal generation in list mode.

"Global" Uses the same dwell time for all lists steps, set with [Global Dwell Time](#).

"From List" Uses the dwell times from the list.
You can define the dwell time for each frequency/level value pair individually, see [Chapter 7.7, "List editor"](#), on page 204.

Remote command:

`[:SOURce<hw>] :LIST:DWELL:MODE` on page 690

Global Dwell Time

Sets the dwell time for [Dwell Time Mode](#) > "Global".

Note: In case of considerable overrun conditions, the R&S SMA100B turns off the list mode.

See also ["Dwell time"](#) on page 183.

Remote command:

`[:SOURce<hw>] :LIST:DWELL` on page 690

Trigger Slope

For "Mode = Extern Step/Single", selects the polarity of the active slope of an applied instrument trigger.

Trigger signal is expected at the Inst Trig connector.

"Positive" The rising edge of the trigger signal triggers the instrument.


"Negative" The falling edge of the trigger signal triggers the instrument.
 Remote command:
[\[:SOURce\]:INPut:TRIGger:SLOPe](#) on page 674

Reset
 Resets the list to the starting point.
 Remote command:
[\[:SOURce<hw>\]:LIST:RESet](#) on page 697

Execute Single
 Manually starts list processing in "Single" mode.
 Remote command:
[\[:SOURce<hw>\]:LIST:TRIGger:EXECute](#) on page 694

7.6.2 List mode data settings

- Access:
1. Select "Sweep" > "List mode".
 2. Select "List Mode Data".



This dialog contains the parameters required for creating and editing lists, activating the learning function and selecting the list processing mode.

Settings	
List Mode Data	201
Edit List Mode Data	202
List Range from/to	202

List Mode Data
 Accesses the standard "Select List" dialog for selecting, creating and editing a list file. The currently loaded file is indicated.
 You can create data lists with the internal editor or import externally created files, see ["Creating and handling lists"](#) on page 182.
 Remote command:
[\[:SOURce<hw>\]:LIST:CATalog?](#) on page 695
[\[:SOURce<hw>\]:LIST:SElect](#) on page 697
[\[:SOURce<hw>\]:LIST:DELeTe](#) on page 695
[\[:SOURce<hw>\]:LIST:DELeTe:ALL](#) on page 696

Edit List Mode Data

Opens the editor to insert and save data lists with RF frequency, power and dwell time values, see [Chapter 7.7, "List editor"](#), on page 204.

You find this function also in standard file select dialog, accessed via [List Mode Data](#).

List Range from/to

Defines an index range in the current list by setting the start and stop index.

The instrument generates the signal with the values of the selected index range and ignores all other list entries.

Remote command:


`[:SOURce<hw>] :LIST:INDEX:START` on page 692

`[:SOURce<hw>] :LIST:INDEX:STOP` on page 692

7.6.3 Import/export settings

Access:

1. Select "Sweep" > "List Mode".
2. Select "List Mode Data" > "Im-/Export".



The "Im-/Export" dialog provides the parameters for importing or exporting files with user data in standard ASCII *.txt or *.csv file format.

The table separators and the decimal floating point numbers are customizable.

Settings

Mode.....	203
ASCII File Settings.....	203
Select (ASCII) Source/Select (ASCII) Destination.....	203
Select Source/Select ASCII Destination.....	204
Import / Export.....	204

Mode

Selects import or export of a data list file. The provided parameters vary according to the selected mode.

Remote command:

[:SOURce<hw>] :LIST:DEXChange:MODE on page 699
 [:SOURce<hw>] :CORRection:DEXChange:MODE on page 664
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:MODE on page 612

ASCII File Settings

Defines the format and the separators of the associated data file.

"Extension" Selects *.csv or *.txt format.
 "Decimal Sets "Point" (dot) or "Comma" as the decimal separator used in the
 Point" ASCII data with floating-point numerals.
 "Column Separator" Sets the separator between the columns in an ASCII table.
 Available are: "Tab", "Semicolon", "Comma" or "Space".

Remote command:

[:SOURce<hw>] :LIST:DEXChange:AFILe:EXTension on page 698
 [:SOURce<hw>] :LIST:DEXChange:AFILe:SEParator:DECimal on page 699
 [:SOURce<hw>] :LIST:DEXChange:AFILe:SEParator:COLumn on page 698
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:EXTension on page 662
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:SEParator:DECimal
 on page 663
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:SEParator:COLumn
 on page 663
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:EXTension on page 612
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:SEParator:DECimal
 on page 613
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:SEParator:COLumn
 on page 613

Select (ASCII) Source/Select (ASCII) Destination

In "Mode > Import", access the file select dialog that provides standard file handling functions.

Where:

- "Select ASCII Source": defines the file to be loaded (imported)
- "Select ASCII Destination": selects the filename under that the loaded file is saved

Remote command:

[:SOURce<hw>] :LIST:DEXChange:AFILe:CATalog? on page 697
 [:SOURce<hw>] :LIST:DEXChange:AFILe:SElect on page 698
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:CATalog? on page 662
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:SElect on page 663
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:CATalog? on page 613
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:SElect on page 613

Select Source/Select ASCII Destination

In "Mode > Export", access the file select dialog that provides standard file handling functions.

Where:

- "Select Source": selects the file to be exported
- "Select ASCII Destination": defines the filename and the file path for the exported file

Remote command:

[:SOURce<hw>] :LIST:DEXChange:SElect on page 699
 [:SOURce<hw>] :CORRection:DEXChange:SElect on page 664
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:SElect on page 614

Import / Export

Imports or exports the selected data list file, depending on the current mode.

Remote command:

[:SOURce<hw>] :LIST:DEXChange:EXECute on page 698
 [:SOURce<hw>] :CORRection:DEXChange:EXECute on page 663
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:EXECute on page 614

7.7 List editor

The "User Correction" and "List Mode" dialogs provide a build-in list editor for defining the corresponding value pairs.

The table and navigation functions of the UCOR and list mode editors have the same structure and are therefore summarized below. The access is specified for both modes, the fields and functions are explained using the example of the list mode.

Access to "Edit List Mode Data":

- "Sweep" > "List Mode" > "List Mode Data" > "Edit List Mode Data"

The editor for list mode provides a table with RF frequency and power values, an extra column for defining variable dwell times, and standard navigation functions.

Edit List Mode Data: rf_list			
	Frequency /Hz	Power /dBm	Dwell Time /s
0	1 000 000 000.000	-20.00	0.001 000
1	540 000 000.000	-5.00	0.015 000
2	4 800 000 000.000	10.00	0.002 000
3	4 200 000 000.000	25.00	0.020 000
4	4 200 000 000.000	25.00	1.000 000
5	3 600 000 000.000	-15.00	0.500 000
6			

Go To Edit Save As ... Save

The remote commands required to define the list mode data are described in [Chapter 14.17.7, "SOURCE:LIST subsystem"](#), on page 687.

Access to "Edit User Correction Data":

- "Level" > "User Correction" > "Edit User Cor. Data"

Edit User Correction Data : ucor		
	Frequency /Hz	Correction Value /dB
0	1 560 000 000.00	11.51
1	1 561 000 000.00	11.03
2	1 562 000 000.00	10.55
3	1 563 000 000.00	10.07
4	1 564 000 000.00	9.59
5	1 565 000 000.00	9.11
6		

Go To Edit Fill with Sensor ... Save As ... Save

The editor for user correction data provides a table with RF frequency and power values and standard navigation functions.

The remote commands required to define the user correction data are described in [Chapter 14.17.3, "SOURCE:CORRection subsystem"](#), on page 656.



All columns in a row must contain values. Cells with missing values are therefore filled automatically, using the value of the previous row.

If you use **global dwell time in list mode**, consider also that the instrument uses the value set with [Global Dwell Time](#) for all list steps and not the values from the list.

Since the table and navigation functions can be assumed to be known, the following description contains a brief overview, shown by the example of the "Edit List Mode Data" dialog. If a function relates to a particular dialog, it is explicitly stated.

Settings

Edit List Mode Data.....	206
Data handling keys.....	206
L Go To.....	206
L Edit.....	207
L Fill with Sensor.....	207
L Save As/Save.....	207
Fill.....	207

Edit List Mode Data

Table with values for list or user correction processing.

Note: Once you enter a value, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows are lost when saving. You can simply override these values.

"Frequency /Hz"

Sets the frequency values.

Remote command:

[\[:SOURce<hw>\]:LIST:FREQuency](#) on page 691

[\[:SOURce<hw>\]:CORRection:CSET:DATA:FREQuency](#)
on page 659

"Power /dBm" (list mode data table)

Sets the level values.

Remote command:

[\[:SOURce<hw>\]:LIST:POWer](#) on page 693

"Correction Value /dBm" (user correction data table)

Sets the level values.

Remote command:

[\[:SOURce<hw>\]:CORRection:CSET:DATA:POWer](#) on page 659

"Dwell /s"

In list mode, sets the dwell time values.

Remote command:

[\[:SOURce<hw>\]:LIST:DWELl:LIST](#) on page 691

Data handling keys

Standard functions for file and data handling.



Go To ← Data handling keys

Selects a row for editing.

Edit ← Data handling keys

Enables you to insert, or delete a row or ranges within a list, and provides access to a dialog for automatic filling, see "Fill..." on page 105.

Fill with Sensor ← Data handling keys

Opens a dialog to configure the automatic filling of user correction data with an R&S NRP power sensor. Available in UCOR mode only.

See [Chapter 8.3.3, "Fill with sensor"](#), on page 226

Save As/Save ← Data handling keys

Stores the list in a file with user-defined name and predefined file extension. To save a copy or create a file, use the "Save as" function.

Fill...

Provides parameters for filling a table automatically with user-defined values.

From 0	Range 4
Column To Fill Frequency /Hz	
Start Value 2.000 000 000 000 GHz	End Value 2.600 000 000 000 GHz
Increment Value 200.000 000 000 MHz	
<input checked="" type="checkbox"/> Fill	

To fill the table, select "Fill".

Note: Once you enter a value or fill a column, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows will be lost when saving. You can simply override these values.

"From / Range"

Defines the start line and number of lines to be filled.

"Column To Fill"

Selects, if the column is filled up with frequencies in Hz, levels in dBm or dwell times in s.

"Start Value / End Value"

Sets the start value for frequency, level or dwell time. The end value is read only and depends on the increment value and the range.

"Increment Value"

Determines the step size.

"Fill"

Fills the column specified in "Column To fill".

7.8 How to generate a signal in list or sweep mode

This section shows you how to configure a varying RF output signal for both, the list and sweep modes.

To configure the frequency sweep signal

- For a step-by-step description, see [Chapter 3.3.2, "Generating an RF frequency sweep signal"](#), on page 46.

Example: Fast changing frequency and level settings in list mode

The following example shows you how to generate an amplitude modulated RF signal based on list mode data.

General workflow

Since any change of the hardware settings or list entries can affect the RF signal characteristics directly, we recommend that you proceed as follows:

1. Configure the modulation settings.
Activate the RF signal.
2. Wait until the hardware settings have settled.
3. Create a list file.
4. Configure the list mode.
5. Activate list mode.

To configure amplitude modulation and switch RF on

1. Press [Preset] to start from an initial state.
2. Select "Modulation" > "Amplitude Modulation > On".
3. Select "Level" > "RF ON" to activate RF signal generation.

To create list mode data

1. Select "Sweep" > "List Mode".
2. In the "List Mode Data" tab, select "List Mode Data > New"
3. Enter the filename `ListMode_Test` for the data list and confirm with "Ok".
The instrument creates a file and stores it in the `/var/user/` directory.
4. Select "Edit List Mode Data".
5. Enter the first values "Frequency > 2", "Power > 0" and "Dwell > 2".
6. Enter further frequency, power and dwell time values in the same way.
7. Select "Save" and close the dialog.

To configure the list mode and start signal generation

1. In the "General" tab, select "List Mode > Auto".
2. Select "Dwell Time Mode > From List".
3. Switch state to "On".
4. Select "General > State > On".

The instrument continuously generates an amplitude-modulated RF signal whose frequency and level values change according to the dwell times, as defined in the list.

With active list mode, the generator displays no frequency and level values in the status bar, but you can check the following parameters.

- In the list mode dialog, the current index indicates the steps of the signal generation.
- In remote control mode, you can query:
 - The current state with `[:SOURce<hw>] :LIST:RUNNing?`
 - Current parameters with the commands `FREQ?`, `POW?` and `LIST:DWEL?`.

8 Improving level performance

To adjust the RF output signal to specific needs in your application, the R&S SMA100B offers different functions:

- **Attenuator**

The R&S SMA100B is equipped with a step attenuator that enables you to vary the amplitude of the RF signal in a wide range. It is characterized by low VSWR (voltage standing wave ratio) over the full level and frequency range, and provides highest level accuracy and noise suppression.

See ["About the attenuator"](#) on page 210.

- **Automatic Level Control (ALC)**

The automatic level control system provides stable RF signals with highest absolute level accuracy over temperature and time.

See ["About ALC"](#) on page 213.

- **User correction (UCOR)**

The user correction function allows you to compensate frequency responses of external setups (e.g. losses of cables) and achieve a stable input signal over frequency directly at the DUT.

See ["About UCOR"](#) on page 218.

- **Power sensors**

The R&S SMA100B has excellent absolute level accuracy. Since a DUT is rarely connected directly to the generator, but with cables or other components, the reference level shifts from the RF output to the DUT. To calibrate this level with high accuracy, i.e. in the tenth dB range, you can connect an R&S NRP power sensor to the generator. The power sensor transmits its readings to the generator, which indicates these measurement results in the display. Thus you can adjust the RF output power of the generator until you reach the target level at the DUT.

See [Chapter 8.4, "Using power sensors"](#), on page 230

8.1 Attenuator

About the attenuator

The step attenuator is either an electronic or a mechanical device. Instruments with frequency options up to 20 GHz use an electronic step attenuator, providing fast and wear free level settings. Instruments capable to generate higher frequency signals use mechanical step attenuators. Depending on the frequency range and the installed high-power option, both types of step attenuators can be built in, and you can select the type to be used below 20 GHz.

To achieve a consistent level setting behavior for all frequencies, the mechanical step attenuator is used even for lower frequencies while the electronic one is disregarded. Especially in frequency ramp sweep mode, which requires a consistent level adjustment behavior, the R&S SMA100B automatically activates the mechanical step attenuator and disables the selection of the electronic step attenuator.



However, option R&S SMAB-B36S does not support using the mechanical attenuator below 20 GHz.

According to the requirements of your application, you can select different attenuator characteristics.


The following are examples of test requirements and the corresponding configuration:

- Automatic configuration
Select standard operation mode ("Auto"), in which the generator adjusts the attenuation of the RF output signal automatically.
- DUT tests under low signal to noise conditions
Low output power is suitable to test the behavior of a DUT under low signal to noise conditions.
- Uninterrupted level settings with constant VSWR
A fix attenuation value is required for obtaining uninterrupted level settings with constant VSWR.
The configuration "RF Off Mode > Unchanged" ensures that constant VSWR is maintained if you turn the signal off and on again.
- Noise sensitive applications
The parameter "RF OFF Mode > Full Attenuation" sets maximum attenuation and thus suppresses noise when you turn off the RF signal.

8.1.1 Attenuator settings

Access:

- Select "Level" > "Level > Attenuator".



In the "Attenuator" dialog, you can select the operating mode of the electronic step attenuator.

The remote commands required to define these settings are described in [Chapter 14.14, "OUTPut subsystem"](#), on page 510 and [Chapter 14.17.11, "SOURce:POWer subsystem"](#), on page 704.

Settings

Mode.....	212
Step Attenuator below 20 GHz.....	212
Level Range.....	212
RF OFF Mode.....	212

Mode

Determines the operating mode of the step attenuator.

- "Auto" Adjusts the attenuator settings automatically.
- "Fixed" Fixes the attenuator and amplifier paths for the current RF level and provides signal output with constant output VSWR. The resulting level range is indicated under ["Level Range"](#) on page 212.

Remote command:

[:OUTPut<hw>:AMODE](#) on page 512

Step Attenuator below 20 GHz

Without option R&S SMAB-B36S only

Selects the type of the step attenuator for frequencies up to 20 GHz.

This setting depends on the frequency range and the installed high power options, see ["About the attenuator"](#) on page 210.

- "Mechanical" Selects that the R&S SMA100B uses the mechanical step attenuator over the whole frequency range.
The mechanical attenuator is used even for lower frequencies, to achieve a consistent level setting behavior for all frequencies. The electronic step attenuator is disregarded.
[Sweep Type > Ramp](#) also requires a consistent level adjustment behavior. Therefore, the R&S SMA100B automatically activates the mechanical step attenuator and disables the selection of the electronic step attenuator.
- "Electronic" Selects that the R&S SMA100B uses the electronic attenuator as long as the frequency is below 20 GHz, providing benefits regarding setting time and wear.

Remote command:

[\[:SOURce<hw>\]:POWer:ATTenuation:PATTenuator](#) on page 707

Level Range

Shows the interruption-free range of the level that you can use in the selected mode.

Remote command:

[:OUTPut<hw>:AFIXed:RANGe:LOWer?](#) on page 513

[:OUTPut<hw>:AFIXed:RANGe:UPPer?](#) on page 513

RF OFF Mode

Determines the state of the step attenuator, when the RF signal is switched off.

The setting is not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. It is reset only by factory preset.

"Unchanged" Freezes the setting of the step attenuator.
Use this mode if a constant VSWR (Voltage Standing Wave Ratio) is required.

"Full Attenuation"
Switches to the maximum attenuation.
Use this mode for applications that require a high level of noise suppression.

Remote command:

`[:SOURce<hw>] :POWer:ATTenuation:RFOff:MODE` on page 707

8.1.2 Reverse power protection

The R&S SMA100B is equipped with a reverse power protection circuit.

The reverse power protection is tripped when the power of signals reflected from the load or external signals applied to the RF output get too high. A relay opens and interrupts the internal connection to the RF output. This condition is indicated in the status bar by the "Overload" status message.

Overload

If an "Overload" status message is indicated in the status bar, perform the following:

- Remove the cause for the overload
- Press the [RF on/off] key to reset the overload protection

The RF input is activated when the overload protection is reset.

Remote command:

`:OUTPut<hw>:PROtection:TRIPped?` on page 514

`:OUTPut<hw>:PROtection:CLEar` on page 514

8.2 Automatic level control (ALC)

The R&S SMA100B is equipped with an automatic level control (ALC) unit to obtain best RF level accuracy.

About ALC

ALC is an adaptive control system to stabilize the RF output level. It continuously monitors the current level and adjusts it to keep a steady state over temperature and time.

ALC is active in almost all applications by default. However, when **pulse modulation** with short pulses is used, the ALC uses table-based level settings with table values depending on the pulse width.

Also note that ALC can detect incorrect values in **multi-transmitter** test setups. If multiple generators are coupled, reverse power can affect the ALC readings, which leads to an incorrect RF output power.

ALC states and their effects

The following description basically explains the ALC states and their principle of operation:

- "Auto"
Adjusts the output level to the operating conditions automatically. ALC is active in almost all operating modes.
- "On"
Activates the internal level control permanently, regardless of the operating conditions.
Note: This mode is not useful for pulse modulation with narrow pulses and low repetition rates, since the automatic level control cannot settle in time. Set ALC "Table & On" instead.
- "Off (Table)"
Deactivates internal level control loop. The instrument calculates every level setting using the attenuation values from the internal (ALC) table. Level attenuation between two table values is done with linear interpolation. This mode enables you to perform a fast and strictly monotonic, but not quite as precise level adjustment.
- "Table & On"
Starts with the associated value of the internal level table and then activates the automatic level control. This mode achieves maximum level accuracy and fast setting times.
If pulse modulation is applied, this mode ensures fast level settings even with narrow pulses at low repetition rate.
- "External ALC"
Activates the external ALC detector mode.
This setting enables you to control the RF signal level at a specific point in the signal chain following the signal generator output with high accuracy.

The R&S SMA100B displays the level control setting as a status message in the info line.

About external ALC

Some applications require precise control of the RF signal level at a specific point in the signal chain following the signal generator output.

For this purpose, the "External ALC" function of the R&S SMA100B enables you to close the level control loop of the instrument using an external level detector diode with negative polarity and a coupler device.

The diode rectifies the signal received from the coupler and loops it back to the R&S SMA100B to control the ALC system.

As shown in [Figure 8-1](#), you must apply the feed back signal at the modulation input connector Ext1.




Figure 8-1: External ALC setup


- 1 = RF 50 Ω output connector
- 2 = Leveled output
- 3 = Negative polarity detector diode
- 4 = Ext1 input connector

How to: see [Chapter 8.2.2, "How to set up an external ALC"](#), on page 217.

8.2.1 ALC settings

Access:

- Select "Level" > "Automatic Level Control".



In the "ALC" dialog, you can configure the settings for the automatic level control of the RF signal to achieve optimal accuracy.

The remote commands required to define these settings are described in [Chapter 14.17.11, "SOURce:POWer subsystem"](#), on page 704.

Settings

State.....	216
Detector Sensitivity.....	216
Detector Coupling Factor.....	216
Required Generator Level.....	216

State

Selects the internal level control mode.

"Auto"	Selects the most appropriate ALC mode automatically.
"On"	Activates ALC permanently.
"Off (Table)"	Controls the level using the attenuation values of the internal ALC table.
"Table & On"	Starts with the attenuation setting from the internal ALC table and continues with automatic level control.

"External ALC" Activates the external detector ALC mode.

For further details on the individual settings, an overview of the functionality and details on what is to be considered, see ["ALC states and their effects"](#) on page 214.

Remote command:

[\[:SOURce<hw>\]:POWer:ALC\[:STATe\]](#) on page 705

Detector Sensitivity

Determines the path of the internal level detector.

The level detector of the ALC has multiple paths distinguished by their sensitivity.

"Auto"	Selects the detector path automatically, according to the given level. This mode is the recommended operation mode.
"Fix"	Fixes the last set sensitivity setting.

Remote command:

[\[:SOURce<hw>\]:POWer:ALC:DSENSitivity](#) on page 706

Detector Coupling Factor

Option: R&S SMAB-K726

Sets the attenuation value for the external RF coupler of the external ALC.

See [Chapter 8.2.2, "How to set up an external ALC"](#), on page 217

Remote command:

[\[:SOURce<hw>\]:POWer:ALC:EDETector:FACTor](#) on page 706

Required Generator Level

Option: R&S SMAB-K726

Sets the maximum power level at the RF output required to compensate external coupler and cable losses of the external ALC.

See [Chapter 8.2.2, "How to set up an external ALC"](#), on page 217

Remote command:

[:SOURce<hw>] :POWer:ALC:EDeTector:LEVel on page 707

8.2.2 How to set up an external ALC

Prerequisites

- R&S SMAB-K726
- Negative polarity RF detector diode with adequate frequency range
- RF coupler with adequate frequency range

Setting up an external ALC control loop


To set up an external ALC control loop, connect the detector diode and coupler as follows, see also "About external ALC" on page 214:

1. Connect the coupled output to the detector RF input.
2. Connect the detector output to the R&S SMA100B modulation input connector Ext1.

Setting the external ALC parameters

To configure the external ALC settings:

1. Select "Level" > "Automatic Level Control" > "ALC".
2. Select "State" > "External ALC" to activate the external detector ALC mode.



The R&S SMA100B displays the parameters required for the settings in the dialog.

3. Set "Detector Coupling Factor", e.g. "16 dB", to determine the attenuation value of the RF coupler.

4. Set "Required Generator Level", e.g. "20 dBm" to configure the maximum power level at the RF output.

This value corresponds to the losses of cabling and coupler to compensate.

5. In the "RF Level" tab, select "Readjust " to execute the instrument detector offset compensation.

This function recalculates and compensates the internally detected offset voltages.

6. Set "RF" > "State" > "On".

After turning on the RF output, the system levels the coupler output power to the value set in the instrument level display

8.3 User correction

The R&S SMA100B supports a correction function to compensate external losses, caused, for example, by the RF cable, to achieve a precise target input level at the DUT.

The signal at the RF outputs of the R&S SMA100B is flat. However, the DUT is usually not connected directly to the outputs of the instrument but rather via connecting cables. Components like cables, power combiners, switches or mixers can affect the signal flatness at the DUT input.




Figure 8-2: Effect of external losses on the signal flatness at the DUT input

DUT = Device under test

Components = Designation of all components between the measurement equipment and the DUT, e.g. cables

1 = Flat signal at the outputs of the R&S SMA100B

2 = Signal received at the DUT, incl. the external losses

About UCOR

User correction (UCOR) is a method that determines the external level loss over a frequency range in advance, see [Figure 8-3](#).

The difference between the generator output level and the level at the DUT determines the correction value at the respective frequency. Alternatively, the attenuation characteristics over a certain frequency range of, for example, RF cables are also specified in the associated data sheet.




Figure 8-3: Understanding the principle of user correction

- | | |
|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DUT | = Device under test |
| Compo-
nents | = Designation of all components between the measurement equipment and the DUT, e.g. cables |
| PS | = Power sensor, e.g. R&S NRP, connected at the DUT's input and the USB connector of the R&S SMA100B |
| 1 | = Power sensor measures the level over a frequency range, where the collected values correspond to the losses caused by the components between the R&S SMA100B and the DUT |
| 2 | = Obtain the correction data by inverting the collected data; load the correction parameters in the R&S SMA100B |
| 3 | = In the R&S SMA100B, the RF signal is pre-processed with the correction values so that the signal at the outputs is the inverted version of the external losses |
| 4 | = Received at the DUT input, the pre-processed signal is flat |

With active **UCOR**, the generator adds the correction value internally and thus increases the output level by exactly the amount of the loss between its output and the DUT. For frequencies which are not contained in the list, the level correction is calculated by interpolation of the closest correction values.

Possible ways for configuring the user correction values

You can configure correction values in the following ways:

- **Internally**

- Use the built-in table editor in the "UCOR > Edit User Correction Data" dialog. Once defined, user correction values can be saved in a file. Files with correction data can be exported, for example, to exchange configuration between instruments or to modify the file content with an external program and reload them again.
- Using the corresponding remote-control commands. Note that you have to create a user correction file first.

- **Externally**

Create a file with correction values as a CSV file with Microsoft Excel, with a Notepad or a similar tool and save it with the predefined extension. Transfer the file to and load it into the instrument.

UCOR file format

Files containing correction data are simple files in text or comma-separated value (CSV) file format. The filename is user-definable; the file extension is *.ucor.

The file contains a list of correction values, one row per frequency and correction value pair; a new line indicator separates the correction values.

For file handling, use the standard functions in the "File Manager", see [Chapter 11.8, "Using the file manager"](#), on page 321.

Collecting correction data

To fill the frequency and power values in the correction table, use one of the following options:

- **Manually**, row by row.
- Fill the table **automatically** with linearly interpolated values, calculated from value range and step size.
- Acquire the real frequency response characteristics of the used component with the **R&S NRP power sensor**, see [Understanding the principle of user correction](#).

Using a power sensor for frequency response measurements

Consider the following when using R&S NRP power sensors to measure the correction values:

- Measure the level directly at the input of the DUT.
- Use the internal correction functions of an R&S NRP power sensor to increase the measurement accuracy.
- Use S-parameter to consider the impact of any two-port device like an adapter between the signal generator and the sensor input.



Interactions and characteristics

Activated user correction is effective in all operating modes.

The RF output level (Level_{RF}) is the sum of the level value and the correction for the particular frequency:

$$\text{Level}_{\text{RF}} = \text{"Status bar > Level"} + \text{"UCOR"}$$


Activated user correction is indicated by the status indication "Lev Ucor" in the "Level" tile.

8.3.1 User correction settings

Access:

1. Select "Level" > "User Correction".
2. If you already have created a file with user correction data:
 - a) Select "UCOR Data > navigate to the file *.uco > Select".

- b) Proceed with [step 4](#).
3. If you need to create a file:
 - a) Select "UCOR Data > New".
 - b) Enter the filename `UCOR_Data` and confirm with "Ok".
 - c) Choose the file and confirm with "Select".
 - d) Select "Edit UCOR Data".
 - e) To fill the user correction data table, proceed as described in [Chapter 7.7, "List editor"](#), on page 204.
4. Select "RF Level > RF State > On".
5. Select "User Cor. Data > State > On".



The "UCOR" dialog contains all settings for creating and handling files with user-defined level correction values.

The remote commands required to define these settings are described in [Chapter 14.17.3, "SOURCE:CORRection subsystem"](#), on page 656.

Settings

State	221
User Correction	221
UCOR Data	222
Edit UCOR Data	222
UCOR Info	222

State

Activates user correction.

The R&S SMA100B displays the status icon "Lev Ucor" in the "Level" panel.

Remote command:

`[:SOURCE<hw>] :CORRection [:STATe]` on page 661

User Correction

Indicates the corrected level value for a specific frequency point.

Remote command:

[\[:SOURce<hw>\]:CORRection:VALue?](#) on page 660

UCOR Data

Accesses the standard "File Select" function of the instrument. The provided navigation possibilities in the dialog are self-explanatory.

Files with user correction values are files with predefined file extension *.uco. When a file is selected, the dialog indicates the filename.

You can create the file internally in the table editor or externally.

- To select an existing file, select "Select List > navigate to the file *.uco > Select"
- Use the general editor function to create internally new file or to edit an existing one.
- Use the standard file manager function to load externally created files to the instrument.

Remote command:

[\[:SOURce\]:CORRection:CSET:CATalog?](#) on page 661

[\[:SOURce<hw>\]:CORRection:CSET\[:SElect\]](#) on page 660

[\[:SOURce\]:CORRection:CSET:DELeTe](#) on page 662

Edit UCOR Data

Opens the build-in table editor to define a new correction table or edit an existing one.

See also:

- [Chapter 7.7, "List editor"](#), on page 204
- ["Fill..."](#) on page 105
- [Chapter 8.3.3, "Fill with sensor"](#), on page 226

UCOR Info ...

Opens a window information on the user correction file.

The window shows the metadata of the file and the output level parameters that are relevant for user correction.

Remote command:

n.a.

8.3.2 List editor

The "User Correction" and "List Mode" dialogs provide a build-in list editor for defining the corresponding value pairs.

The table and navigation functions of the UCOR and list mode editors have the same structure and are therefore summarized below. The access is specified for both modes, the fields and functions are explained using the example of the list mode.

Access to "Edit List Mode Data":

- ▶ "Sweep" > "List Mode" > "List Mode Data" > "Edit List Mode Data"

The editor for list mode provides a table with RF frequency and power values, an extra column for defining variable dwell times, and standard navigation functions.




	Frequency /Hz	Power /dBm	Dwell Time /s
0	1 000 000 000.000	-20.00	0.001 000
1	540 000 000.000	-5.00	0.015 000
2	4 800 000 000.000	10.00	0.002 000
3	4 200 000 000.000	25.00	0.020 000
4	4 200 000 000.000	25.00	1.000 000
5	3 600 000 000.000	-15.00	0.500 000
6			

The remote commands required to define the list mode data are described in [Chapter 14.17.7, "SOURCE:LIST subsystem"](#), on page 687.

Access to "Edit User Correction Data":

- "Level" > "User Correction" > "Edit User Cor. Data"



	Frequency /Hz	Correction Value /dB
0	1 560 000 000.00	11.51
1	1 561 000 000.00	11.03
2	1 562 000 000.00	10.55
3	1 563 000 000.00	10.07
4	1 564 000 000.00	9.59
5	1 565 000 000.00	9.11
6		

The editor for user correction data provides a table with RF frequency and power values and standard navigation functions.

The remote commands required to define the user correction data are described in [Chapter 14.17.3, "SOURCE:CORRection subsystem"](#), on page 656.



All columns in a row must contain values. Cells with missing values are therefore filled automatically, using the value of the previous row.

If you use **global dwell time in list mode**, consider also that the instrument uses the value set with [Global Dwell Time](#) for all list steps and not the values from the list.

Since the table and navigation functions can be assumed to be known, the following description contains a brief overview, shown by the example of the "Edit List Mode Data" dialog. If a function relates to a particular dialog, it is explicitly stated.

Settings

Edit List Mode Data.....	224
Data handling keys.....	224
L Go To.....	224
L Edit.....	225
L Fill with Sensor.....	225
L Save As/Save.....	225
Fill.....	225

Edit List Mode Data

Table with values for list or user correction processing.

Note: Once you enter a value, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows are lost when saving. You can simply override these values.

"Frequency /Hz"

Sets the frequency values.

Remote command:

[\[:SOURce<hw>\]:LIST:FREQuency](#) on page 691

[\[:SOURce<hw>\]:CORRection:CSET:DATA:FREQuency](#)
on page 659

"Power /dBm" (list mode data table)

Sets the level values.

Remote command:

[\[:SOURce<hw>\]:LIST:POWer](#) on page 693

"Correction Value /dBm" (user correction data table)

Sets the level values.

Remote command:

[\[:SOURce<hw>\]:CORRection:CSET:DATA:POWer](#) on page 659

"Dwell /s"

In list mode, sets the dwell time values.

Remote command:

[\[:SOURce<hw>\]:LIST:DWELl:LIST](#) on page 691

Data handling keys

Standard functions for file and data handling.



Go To ← Data handling keys

Selects a row for editing.

Edit ← Data handling keys

Enables you to insert, or delete a row or ranges within a list, and provides access to a dialog for automatic filling, see "Fill..." on page 105.

Fill with Sensor ← Data handling keys

Opens a dialog to configure the automatic filling of user correction data with an R&S NRP power sensor. Available in UCOR mode only.

See [Chapter 8.3.3, "Fill with sensor"](#), on page 226

Save As/Save ← Data handling keys

Stores the list in a file with user-defined name and predefined file extension. To save a copy or create a file, use the "Save as" function.

Fill...

Provides parameters for filling a table automatically with user-defined values.

From	0	Range	4
Column To Fill	Frequency /Hz		
Start Value	2.000 000 000 000 GHz	End Value	2.600 000 000 000 GHz
Increment Value	200.000 000 000 MHz		
<input checked="" type="checkbox"/> Fill			

To fill the table, select "Fill".

Note: Once you enter a value or fill a column, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows will be lost when saving. You can simply override these values.

"From / Range"

Defines the start line and number of lines to be filled.

"Column To Fill"

Selects, if the column is filled up with frequencies in Hz, levels in dBm or dwell times in s.

"Start Value / End Value"

Sets the start value for frequency, level or dwell time. The end value is read only and depends on the increment value and the range.

"Increment Value"


Determines the step size.

"Fill"

Fills the column specified in "Column To fill".

8.3.3 Fill with sensor

- Access:
- 1. Select "Level" > "User Correction".
 - 2. Select "UCOR Data > navigate to the file *.ucor > Select".
 - 3. Select "Edit UCOR Data > Fill With Sensor...".



This dialog contains parameters for filling a table automatically with sensor readings.

To fill the table, select "Execute".

For information on power sensors and how to use them, see [Chapter 8.5, "How to calibrate the power level with an R&S NRP power sensor"](#), on page 287.

Settings:

Fill User Correction Data with Sensor	226
Used SMAB Settings For Measurement	227

Fill User Correction Data with Sensor

- "Sensor"
Displays connected sensors for selection.
- "List To Fill"
Indicates the used list.
- "S-Parameter"

- Indicates whether S-Parameter correction in the R&S NRP power sensor is used.
- "Include Zeroing"
Performs a zeroing procedure before acquiring the user correction data to improve precision.
No signal is applied to the sensor during zeroing. RF output is temporarily switched off during that time.
When unchecked, the zeroing procedure is skipped. However, the RF signal level can be blanked shortly. This setting is useful if blanking of RF is undesirable or the absence of power at the sensor cannot be guaranteed.
- "Execute"

The "Execute" button is only enabled if a sensor is detected and the user correction list contains at least one frequency value.

Remote command:

`[:SOURce<hw>] :CORRection:ZERoing:STATe` on page 661

`[:SOURce<hw>] :CORRection:CSET:DATA [:SENSor<ch>] [:POWer] :SONCe`
on page 660

Used SMAB Settings For Measurement

Displays the settings relevant for the measurement.

"Modulation" Indicates the modulation state

"Amplitude" Displays the currently set level.

Remote command:

`[:SOURce<hw>] :POWer:POWer` on page 710

"Offset" Displays the level offset, set with "Offset" on page 74.

Remote command:

`[:SOURce<hw>] :POWer [:LEVel] [:IMMediate] :OFFSet`
on page 711

"UCOR Reference Level" Displays the reference value for user correction.
The user correction reference level is the set [Amplitude](#) plus the set [Offset](#).

Remote command:

`[:SOURce<hw>] :POWer [:LEVel] [:IMMediate] :REFLevel`
on page 713

8.3.4 Import/export list files

Access:

1. Select one of the following:
 - "Sweep" > "List mode".
 - "Level" > "User Correction".
 - "Modulation > Pulse Modulation > Pulse Generator > Pulse Mode = Train".

2. Select "Import/Export".




Figure 8-4: Im-/Export dialog (example with UCOR settings)

The "Import/Export" dialog contains all functions and settings to import externally created list data or to export it accordingly. You can process and store a list in the formats *.txt (ASCII), or *.csv (plain text with identical sequence of fields). The table separators and the decimal floating point numbers are customizable.

Settings

Mode.....	228
ASCII File Settings.....	228
Select (ASCII) Source/Select (ASCII) Destination.....	229
Select Source/Select ASCII Destination.....	229
Import / Export.....	229

Mode

Selects import or export of a data list file. The provided parameters vary according to the selected mode.

Remote command:

```
[ :SOURce<hw> ] :LIST:DEXChange:MODE on page 699
[ :SOURce<hw> ] :CORRection:DEXChange:MODE on page 664
[ :SOURce<hw> ] :PULM:TRAIin:DEXChange:MODE on page 612
```

ASCII File Settings

Defines the format and the separators of the associated data file.

- "Extension" Selects *.csv or *.txt format.
- "Decimal Point" Sets "Point" (dot) or "Comma" as the decimal separator used in the ASCII data with floating-point numerals.
- "Column Separator" Sets the separator between the columns in an ASCII table. Available are: "Tab", "Semicolon", "Comma" or "Space".

Remote command:

```
[ :SOURce<hw> ] :LIST:DEXChange:AFIle:EXTeNsion on page 698
[ :SOURce<hw> ] :LIST:DEXChange:AFIle:SEParaTor:DECimal on page 699
```

[\[:SOURCE<hw>\]:LIST:DEXChange:AFILe:SEParator:COLumn](#) on page 698

[\[:SOURCE<hw>\]:CORRection:DEXChange:AFILe:EXTension](#) on page 662

[\[:SOURCE<hw>\]:CORRection:DEXChange:AFILe:SEParator:DECimal](#)

on page 663

[\[:SOURCE<hw>\]:CORRection:DEXChange:AFILe:SEParator:COLumn](#)

on page 663

[\[:SOURCE<hw>\]:PULM:TRAIIn:DEXChange:AFILe:EXTension](#) on page 612

[\[:SOURCE<hw>\]:PULM:TRAIIn:DEXChange:AFILe:SEParator:DECimal](#)

on page 613

[\[:SOURCE<hw>\]:PULM:TRAIIn:DEXChange:AFILe:SEParator:COLumn](#)

on page 613

Select (ASCII) Source/Select (ASCII) Destination

In "Mode > Import", access the file select dialog that provides standard file handling functions.

Where:

- "Select ASCII Source": defines the file to be loaded (imported)
- "Select ASCII Destination": selects the filename under that the loaded file is saved

Remote command:

[\[:SOURCE<hw>\]:LIST:DEXChange:AFILe:CATalog?](#) on page 697

[\[:SOURCE<hw>\]:LIST:DEXChange:AFILe:SElect](#) on page 698

[\[:SOURCE<hw>\]:CORRection:DEXChange:AFILe:CATalog?](#) on page 662

[\[:SOURCE<hw>\]:CORRection:DEXChange:AFILe:SElect](#) on page 663

[\[:SOURCE<hw>\]:PULM:TRAIIn:DEXChange:AFILe:CATalog?](#) on page 613

[\[:SOURCE<hw>\]:PULM:TRAIIn:DEXChange:AFILe:SElect](#) on page 613

Select Source/Select ASCII Destination

In "Mode > Export", access the file select dialog that provides standard file handling functions.

Where:

- "Select Source": selects the file to be exported
- "Select ASCII Destination": defines the filename and the file path for the exported file

Remote command:

[\[:SOURCE<hw>\]:LIST:DEXChange:SElect](#) on page 699

[\[:SOURCE<hw>\]:CORRection:DEXChange:SElect](#) on page 664

[\[:SOURCE<hw>\]:PULM:TRAIIn:DEXChange:SElect](#) on page 614

Import / Export

Imports or exports the selected data list file, depending on the current mode.

Remote command:

[\[:SOURCE<hw>\]:LIST:DEXChange:EXECute](#) on page 698

[\[:SOURCE<hw>\]:CORRection:DEXChange:EXECute](#) on page 663

[\[:SOURCE<hw>\]:PULM:TRAIIn:DEXChange:EXECute](#) on page 614

8.4 Using power sensors

The R&S SMA100B works with most of the R&S NRP power sensors and thus supports various application tasks. Using power sensors, you can for example determine attenuation characteristics of downstream equipment or cables. You can use the measured values to compensate the losses with internal control functions or with an external control circuit in real time.

R&S NRP power sensors are highly accurate standalone measuring devices, suitable for a wide range of applications. The power sensors communicate directly with the signal generator, calculate the average or peak power internally, include S-parameter correction and return the measurement results to the generator.

The R&S SMA100B works with any sensor of the R&S NRP series and can perform up to four power measurements simultaneously.

Only for the NRP-Z power analysis function, you have to use R&S NRP power sensors that support power analysis in frequency, power and time domain, see [Chapter 8.4.4.1, "Required options"](#), on page 242.



Check the firmware version of the R&S NRP sensors regularly. Update the firmware, if necessary.

For updates, see the Rohde & Schwarz website <http://www.rohde-schwarz.com> in section "Power Meters & Voltmeters".

• Connecting R&S NRP power sensors to the R&S SMA100B	230
• NRP sensor mapping	231
• NRP power viewer	234
• NRP-Z power analysis	242

8.4.1 Connecting R&S NRP power sensors to the R&S SMA100B

R&S NRP sensors are connected to the R&S SMA100B in the following ways:

- Connection to the Sensor connector
 - R&S NRP-ZK8 (eight-pole interface cable) for R&S NRPxx power sensors
 - R&S NRP-ZK6 (six-pole interface cable) for R&S NRPxx power sensors
 - No additional cable for R&S NRP-Zxx power sensors (cable is fixed on the sensor)
- Connection to the USB connector

Requires the following cables, depending on the used sensor type:

 - R&S NRP-ZKU (USB interface cable) for R&S NRPxx power sensors
 - R&S NRP-Z3 or R&S NRP-Z4 (USB adapter cables) for sensors of the R&S NRP-Zxx family
- Connection via R&S NRP-Z5 sensor hub

The R&S NRP-Z5 USB sensor hub (high-speed USB 2.0) can host up to 4 R&S NRP sensors. It provides simultaneous internal and external triggering of all connected sensors.

Requires additional cables, depending on the used output connector of the hub. Choose one of the following:

- Short extension cable R&S NRP-Z2 for connection to the sensor connector. This six-pole connection provides the external trigger capability.
- Standard USB cable (USB type A to USB type B) to any USB type A connector of the R&S SMA100B. This connection does not support external triggering.
- Connection via USB hub with external power supply unit
Requires the following cables, depending on the used sensor type:
 - R&S NRP-ZKU (USB interface cable) for R&S NRPxx power sensors
 - R&S NRP-Z3 or R&S NRP-Z4 (USB adapter cables) for sensors of the R&S NRP-Zxx family
- Connection via LAN for R&S NRPxxxSN/xxxTN/xxxAN power sensors
Using the Ethernet interface requires PoE (Power over Ethernet) to provide the electrical power.
To establish the connection, you can use:
 - A PoE Ethernet switch, e.g. R&S NRP-ZAP1 and an RJ-45 Ethernet cable.
 - A PoE injector and an RJ-45 Ethernet cable.

For details, see the description R&S®NRP®Series Power Sensors Getting Started.

Detection and mapping

The R&S SMA100B automatically detects a connected R&S NRP power sensor and indicates it in the "NRP Power Viewer" and "NRP Sensor Mapping" dialogs.

By default, detected sensors are indicated as follows:

- A sensor connected at the Sensor socket is assigned as "Sensor 1".
If no sensor is connected to this socket, channel 1 remains unassigned.
- Sensors 2 to 4 are assigned to the sensors at the USB connectors, according to their sequence of connection.

You can change the default mapping in the [NRP sensor mapping](#) dialog.



On connection, the R&S SMA100B immediately starts the measurement of a detected R&S NRP power sensor. If you perform an instrument preset ([Preset] key or *RST), the R&S SMA100B stops the measurements. The connection and the mapping of the power sensors remain, the measurements must be restarted.

8.4.2 NRP sensor mapping


The "NRP Sensor Mapping" lists all R&S NRP sensors detected by the instrument.



Any R&S NRP sensor that supports the USB legacy protocol and is connected to one of the USB interfaces, is detected automatically and added to the list. Vice versa, the R&S SMA100B removes a sensor from the list, when it is disconnected.

R&S NRP sensors that are connected via LAN or use the USBTMC protocol are not automatically detected. They are detected by the scan search function.

Access:

- Select "Clk Syn/Power Sens" > "NRP Sensor Mapping".



Sensor	Peak	K28 Support	Revision	Protocol	Connector	Mapping
NRP40TN-100999	No	No	16.05.11.02	Visa		2
NRQ6-900037	No	No	04.03.02.01	Visa		1

Buttons: Scan, Start, Clear, Hide 'Add Sensor'

Add Sensor

IP Address or Host Name: NRQ6-900037 Add LAN Sensor

Device ID or Sensor Name: NRQ6 Serial Number: 900037 Add USBTMC Sensor

The dialog lists all detected R&S NRP sensors for selection and mapping. You can also browse the network for sensors.

The detected sensors are characterized by the used protocol and the corresponding connector icon. In the "Mapping" column, you can assign the sensor to one of the available sensor channels. The list can contain several entries but the R&S SMA100B can only use up to four sensors simultaneously.

The remote commands required to define these settings are described in [Chapter 14.16, "SENSe, READ, INITiate and SLISt subsystems"](#), on page 568.

Settings

Sensor Mapping List	232
Scan	233
Clear	233
Add Sensor/Hide 'Add Sensor'	233
Add Sensor settings	233
L Add LAN Sensor settings	233
L Add USB Sensor settings	233

Sensor Mapping List

Shows the sensors that are connected to the R&S SMA100B.

The table informs on the sensor type, specific features and the installed sensor firmware. It also shows the interface the sensor is connected to, including the communication protocol and the assigned channel.

Remote command:

`:SLIST[:LIST]?` on page 572

`:SLIST:ELEMent<ch>:MAPPING` on page 574

`:SLIST:SENSor:MAP` on page 574

Scan

Scans the network and the USB connections for sensors connected using the VISA communication protocol, i.e. sensors that are addressed over LAN or USBTMC.

The instrument detects sensors communicating over the USB legacy protocol automatically.

Remote command:

`:SLIST:SCAN[:STATe]` on page 572

Clear

Removes the selected sensor from the sensor mapping list.

Remote command:

`:SLIST:CLEar:LAN` on page 573

`:SLIST:CLEar:USB` on page 573

`:SLIST:CLEar[:ALL]` on page 574

Add Sensor/Hide 'Add Sensor'

Shows or hides the "Add Sensor" settings.

Add Sensor settings

Configures settings to add sensors connected to the R&S SMA100B via USB or LAN.

Add LAN Sensor settings ← Add Sensor settings

Configures settings to add sensors connected to the R&S SMA100B via LAN.

"IP Address or Host Name"

Displays the host name or the IP address of a R&S NRP power sensor.

If the R&S SMA100B does not detect a connected R&S NRP sensor, you can assign the address information manually.

"Add LAN Sensor"

Adds a detected R&S NRP sensor connected in the LAN to the list of sensors, including its device ID or name and its serial number.

Remote command:

`:SLIST:SCAN:LSensor` on page 572

Add USB Sensor settings ← Add Sensor settings

Configures settings to add sensors connected to the R&S SMA100B via USB.

"Device ID or Sensor Name"

Displays the device identifier or the name of the R&S NRP power sensor.

If the R&S SMA100B does not detect a connected R&S NRP sensor, you can assign the ID or name manually.

"Serial Number"

Displays the serial number of the R&S NRP power sensor.

If the R&S SMA100B does not detect a connected R&S NRP sensor, you can assign the serial number manually.

"Add USBTMC Sensor"

Adds a detected R&S NRP sensor connected at the USB interface to the list of sensors, including its device ID or name and its serial number.

Remote command:

:SLIST:SCAN:USENsor on page 573

8.4.3 NRP power viewer

The R&S SMA100B features the power viewer function for measuring or monitoring signals with R&S NRP power sensors.

8.4.3.1 About

The R&S SMA100B can perform up to four power measurements simultaneously.

Depending on the signal characteristic (CW, AM, pulsed, etc.) or the parameter to be measured (average, peak, etc.) a suitable R&S power sensor must be used.

About the measuring principle, averaging filter, filter length, and achieving stable results

A sensor measures the average or peak RF power of the source continuously. The measurement results are displayed in the "NRP Power Viewer" dialog.

The power viewer function uses **averaging filters** for getting a stable readout.

Measurement results could be interfered, for instance, by too much noise in your setup, by a bad suppression of harmonics or non-harmonics or when you reach the sensitivity level of your power sensor.

Measurements are continuously repeated in a predefined time window. The measurement result is obtained by averaging the measured values for the last 2N time windows. This approach is referred as a **two-step averaging process**.

The factor of 2 in the formula arises because the output signals from the microwave detector are chopped at the same rate as the time windows to suppress low-frequency noise. An independent measured value can only be obtained from two consecutive values.

The variable N in the formula indicates the **filter length**. The filter length then directly influences the measurement time. The filter length can be selected automatically or it can be manually set to a fixed value.

Depending on the R&S NRP power sensor type, the manual setting of the filter length varies in resolution:

- Resolution = 1 for the R&S NR Px power sensor family

- Resolution = 2^n for R&S NRP-Zxx power sensors, with $n = 1$ to 16

Follow the following general recommendation to find out the **optimum filter length**:

- Always start a measurement in auto mode ("Filter > Auto").
Check if the measurement results are sufficient.
- If the power is not constant, select the filter length manually ("Filter > User").
Trigger the "Auto Once" function to search for the optimum filter length for the current measurement conditions.
The estimated value is indicated as filter length.
- If the target measurement accuracy value is known, select "Filter > Fixed Noise".
The averaging factor is selected automatically and so that the sensor's intrinsic noise (two standard deviations) does not exceed the specified noise content.
- Different sensor types achieve the same filtering result with different filter and time window lengths.

The time window length depends on the sensor type:

- For most sensors, it is fixed to 20 ms.
- For the R&S NRP-Z81 sensor, it is 10 μ s.
The R&S NRP-Z81 uses filter length that is 1000 times larger than the filter length for other sensors.

About zeroing

Activates the auto zero function.

Zeroing calibrates the external power sensor by adjusting its reading at zero signal power. For this purpose, the RF power source must be switched off or disconnected from the sensor. If a Rohde & Schwarz power sensor receives an input power during the zeroing process, it aborts zeroing and generates an error message. Zeroing takes a few seconds, depending on the sensor model. Refer to the documentation of your power sensor for more information.

Tips for zeroing

When to perform zeroing:

- During warm up after switching on or connecting the instrument
- After a substantial change of the ambient temperature
- After fastening the power sensor module to an RF connector at high temperature
- After several hours of operation
- When low-power signals are to be measured, e.g. less than 10 dB above the lower measurement limit.
- Switch off the RF power source for zeroing, but do not disconnect it from the power sensor. This proceeding keeps the thermal equilibrium, and the zeroing process also compensates the noise that superimposes the measured signal (e.g. from a broadband amplifier).

Related settings and functions

- Measurements-related settings, like results, filter, filter length:
[Chapter 8.4.3.2, "NRP power viewer settings"](#), on page 236

- Software version of the connected power sensor:
`:SENSe<ch>[:POWER]:TYPE?` on page 582
- Acquisition of level correction data:
Chapter 8.3, "User correction", on page 218

Additional information


See Rohde & Schwarz website <http://www.rohde-schwarz.com> in section "Power Meters & Voltmeters" for:

- R&S NRP power sensor manual.
- Information on the R&S NRP-Z5 sensor hub and the available accessories.
- Sensor software updates.


8.4.3.2 NRP power viewer settings

Access:

- Select "Clk Syn/Power Sens" > "NRP Power Viewer".



The "Overview" tab shows the list of detected sensors, and provides a separate tab per sensor.



A sensor tab contains all parameters for configuring the sensor settings, like average or peak display, reference source, filter and level offset.

The remote commands required to define these settings are described in [Chapter 14.16, "SENSe, READ, INITiate and SLISt subsystems"](#), on page 568, including the triggering of the measurement and the retrieval of measurement results.

See also [Chapter 8.5, "How to calibrate the power level with an R&S NRP power sensor"](#), on page 287.

Settings

Sensor type and serial number.....	238
Level (Peak) / Level (Average).....	238
Sensor Mapping.....	238
Sensor settings.....	238
L State.....	238
L Zero.....	238

L Display.....	239
L Permanent.....	239
L Display.....	239
L Use Frequency Of.....	239
L Frequency.....	239
L Level Offset State,Level Offset.....	239
L Filter.....	240
L Filter Length.....	240
L Noise/Signal Ratio.....	240
L Auto Once.....	240
L Timeout.....	241
L Default Aperture Time.....	241
L Aperture Time.....	241
L S-Parameter.....	241
L Enable Logging.....	241

Sensor type and serial number

Indicates the type and the serial number of a selected R&S NRP power sensor, and the channel the sensor is assigned to.

The displayed **Level (Peak) / Level (Average)** values correspond to the particular sensor.

Remote command:

`:SENSe<ch>[:POWER]:TYPE?` on page 582

`:SENSe<ch>[:POWER]:SNUMber?` on page 580

Level (Peak) / Level (Average)

Indicates the measured peak or average level value.

You can also change the unit for the results display: Watt, dBm or dBμV.

Note: Peak level measurements are provided if the power sensor supports this feature.

Remote command:

`:READ<ch>[:POWER]?` on page 523

`:SENSe<ch>:UNIT[:POWER]` on page 574

Sensor Mapping

Accesses the **NRP sensor mapping** dialog.

Sensor settings

One tab per sensor provides the corresponding settings.

State ← Sensor settings

Activates level measurement.

Remote command:

`:INITiate<hw>[:POWER]:CONTinuous` on page 523

To query the availability of a sensor at a given connector, use the command :

`SENSe<ch>[:POWER]:STATus[:DEVICE]?` on page 581.

Zero ← Sensor settings

Activates the auto zeroing.

For details, see ["About zeroing"](#) on page 235.

Remote command:

`:SENSe<ch>[:POWER]:ZERO` on page 582

Display ← Sensor settings

Sets the display mode for power readings.

Permanent ← Display ← Sensor settings

Activates the indication of the power sensor measurement in the status bar of the home screen.

You can activate the permanent display for several sensors.

Remote command:

`:SENSe<ch>[:POWER]:DISPlay:PERManent:STATe` on page 576

Display ← Display ← Sensor settings

Sets the display of results on mean or peak power.

Remote command:

`:SENSe<ch>[:POWER]:DISPlay:PERManent:PRIority` on page 576

Use Frequency Of ← Sensor settings

Selects the source for measurement.

- | | |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| "RF" | The R&S SMA100B transfers the RF frequency and level settings to the R&S power sensor automatically. Thus you achieve power readings of high accuracy, irrespective from the connected sensor type. |
| "User" | Sets a user defined frequency. |

Example:

If you have a frequency converting device between the generator and the DUT. If the frequency converter doubles the frequency, you can set twice the frequency in the R&S SMA100B. The R&S power sensor considers this RF frequency setting.

Set the parameter [Frequency](#) to the measurement's frequency.

Remote command:

`:SENSe<ch>[:POWER]:SOURce` on page 581

Frequency ← Sensor settings

Defines the frequency value if "Source > User" is used.

Remote command:

`:SENSe<ch>[:POWER]:FREQuency` on page 579

Level Offset State,Level Offset ← Sensor settings

Activates and defines a level offset which is considered in the power measurement result. The level offset value is always expressed in dB, irrespective of the display of the measurement result.

This function allows you to consider, for example, an attenuator in the signal path.

Remote command:

`:SENSe<ch>[:POWER]:OFFSet` on page 580

`:SENSe<ch>[:POWER]:OFFSet:STATE` on page 580

Filter ← Sensor settings

Selects the way the length of the used filter is defined.

See also "About the measuring principle, averaging filter, filter length, and achieving stable results" on page 234.

"Auto"	<p>Selects the filter length automatically and adjusts it to the measured value. The value is indicated with the parameter Filter Length.</p> <p>When high output power is applied, the filter length and therefore the measurement time can be short.</p> <p>When low output power is applied, the filter length and therefore the measurement time is increased which reduces the considered noise content in your measurement.</p>
"User"	<p>The filter length is defined manually, with the parameter Filter Length.</p> <p>As the filter length works as a multiplier for the time window, constant filter length results in a constant measurement time.</p> <p>Values 1 and 2N are allowed.</p>
"Fixed Noise"	<p>The averaging factor is taken automatically in accordance to the value Noise/Signal Ratio. Thus, the sensor's intrinsic noise (2 standard deviations) does not exceed the specified noise content.</p> <p>To avoid long measurement times when the power is too low, set a Timeout.</p> <p>Timeout is the maximum acceptable measurement time which limits the averaging factor and therefore leads to a more unstable readout.</p>

Remote command:

`:SENSe<ch>[:POWER]:FILTer:TYPE` on page 579

Filter Length ← Sensor settings

Sets or indicates the filter length, depending on the selected filter mode.

- "Filter > Auto" indicates the automatically adjusted filter length.
- "Filter > User" enables you to set the filter length manually.
- "Filter > Fixed Noise" hides the setting parameter.

Remote command:

`:SENSe<ch>[:POWER]:FILTer:LENGth:AUTO?` on page 577

`:SENSe<ch>[:POWER]:FILTer:LENGth[:USER]` on page 577

Noise/Signal Ratio ← Sensor settings

For [Filter > Fixed Noise](#), sets the noise content.

Remote command:

`:SENSe<ch>[:POWER]:FILTer:NSRatio` on page 578

Auto Once ← Sensor settings

Searches the optimum filter length for the current measurement conditions. The result is indicated with the parameter [Filter Length](#).

See also "About the measuring principle, averaging filter, filter length, and achieving stable results" on page 234.

Remote command:

`:SENSe<ch>[:POWer]:FILTer:SONCe` on page 578

Timeout ← Sensor settings

For "Filter > Fixed Noise", sets a time limit for the averaging process.

Remote command:

`:SENSe<ch>[:POWer]:FILTer:NSRatio:MTIME` on page 578

Default Aperture Time ← Sensor settings

The sensor default setting is sufficient. Disable this parameter to specify a user-defined aperture time per sensor, if, for example, the readings vary.

To obtain stable readings, set the [Aperture Time](#) exactly to one modulation period.

Remote command:

`:SENSe<ch>[:POWer]:APERTure:DEFAult:STATe` on page 575

Aperture Time ← Sensor settings

If "Use Default Aperture Time > Off", defines the acquisition time per sensor.

For example, to obtain a sufficient low average value, set the aperture time exactly to one modulation period.

Remote command:

`:SENSe<ch>[:POWer]:APERTure:TIME` on page 575

S-Parameter ← Sensor settings

Lists the S-Parameter correction data files retrieved for the connected power sensor.

To activate the correction data, select the corresponding file.

S-Parameter correction is used to mathematically shift the reference plane to the DUT by considering the S-parameters for any components connected upstream of the sensor.

The S-Parameter table can be changed with the S-Parameters tool, provided as part of the free R&S NRP Toolkit software. For more information, refer to the manual of the connected R&S NRP power sensor.

Remote command:

`:SENSe<ch>[:POWer]:CORRection:SPDevice:STATe` on page 576

`:SENSe<ch>[:POWer]:CORRection:SPDevice:LIST?` on page 576

`:SENSe<ch>[:POWer]:CORRection:SPDevice:SElect` on page 575

Enable Logging ← Sensor settings

Activates recording of R&S NRP power sensor readings in a log file.

There is 1 log file per sensor. The log files are created automatically and filled in continuously. They are text files with predefined filename `SensLog<n>.txt`, where `<n>` indicates the connected sensor. Log files are stored on the internal memory, in the directory `/var/user/SensorLogging`.

Each log file contains the measured value (2 readings when you work with peak sensors), the sensor type, and the measurement time (timestamp). Logged data is not overwritten. When a new measurement is started, the collected logging data is appended in the log file.

Check the used disc space regularly and remove log files to maintain storage capacity.

Note: The logging function is intended for measurements with long time intervals. It is suitable source for data reconstructions if the connection to the sensor was interrupted.

Remote command:

`:SENSe<ch>[:POWER]:LOGGing:STATe` on page 580

8.4.4 NRP-Z power analysis

The NRP-Z power analysis functionality enables you to analyze the measured power of a DUT in frequency, power or time domain. The instrument provides marker, graphic and reference value functions.

8.4.4.1 Required options

The NRP-Z power analysis function requires the power analysis option installed on your instrument, and a sensor that supports power analysis.

R&S SMA100B base unit equipped with the following option:

- Power Analysis (R&S SMAB-K28)

R&S NRP power sensors:

- R&S NRP-Z8x, referred to in the following description
- R&S NRP-Z91
- R&S NRP-Z211

For more information, see data sheet.

8.4.4.2 About

Characteristics and features of the NRP-Z power analysis function

The NRP-Z power analysis displays the measurement data graphically. The measurement diagram covers up to four traces you can manually or automatically assign to one or more connected power sensors. For evaluation of the readings, you can save a defined reference trace or even freeze a reading temporarily on the screen. Markers and mathematic functions enable you to compare particular values.

The NRP-Z power analysis supports three measurement modes:

- Power versus frequency (frequency response).
For this mode, all required generator settings are automatically configured except for the power level. The power level setting of the generator is used for the frequency sweep measurements.

The frequency sweep settings are transferred to the sensor to automatically calculate the correct measurement value for each frequency point.


- **Power versus power (power sweep, AM/AM)**
Power sweep measurements are executed using the frequency settings of the generator. Alternatively, the sensor can be adjusted to a frequency different from the generator, see [Use Separate Frequency- Power Analysis](#). This frequency is transmitted to the sensor to automatically calculate the correct measurement value.
- **Power versus time (power measurement in the time domain, e.g. R&S NRP-Z8x trace mode).**
In the time mode, you can analyze the signal of the generator but also externally supplied signals. This mode requires an additional trigger event, with selectable level, hysteresis and drop time. Provided the sensor used supports the power measurement of pulse signals, you can also analyze pulse data in time domain.

Characteristics of pulse data



For R&S NRP-Z8x power sensors that support time domain analysis and automatic pulse analysis.

The power sensors enable pulse data analysis in measurement mode time. All important pulse parameters are measured after setting the threshold levels. The following graph shows most of these parameters:



The sensor calculates the pulse parameters from each measurement and delivers the results to the R&S SMA100B.

The indication state of the parameters also affects the save function. Storing the measurement diagram as hardcopy includes the parameters selected in this dialog.



A total of 6 parameters can be indicated at one time. Structured hierarchically, trace 1 features top priority and trace 4 is addressed with the lowest weighting. This means that only the first 6 checked parameters are indicated, starting with the settings of trace 1.

The pulse data is only visible for certain zoom levels of the diagram.

8.4.4.3 Accessing the NRP-Z Power Analysis functionality

Access:

- Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".




Figure 8-5: Power analysis window

- 1 = Softkeys for accessing the "NRP-Z" the sensor settings dialogs
- 2 = Power analysis diagram
- 3 = Reference curve, indicated when active
- 4 = Progress bar indicated during measurement
- 5 = "Start Continuous / Stop" softkey to trigger the measurement
- 6 = Softkey for accessing the measurement settings dialogs
- 7,8,9 = Softkeys for accessing the trace and marker settings dialogs

The start screen of the NRP-Z power analysis contains the measurement diagram and labelled softkeys indicating connected power sensors. These softkeys and a configuration softkey lead you to the dialogs for setting up the measurement and sensor parameters, and for configuring the trace display in the diagram. You can start or stop your measurement directly. During the measurement, the R&S SMA100B shows the progress of the measurement in the progress bar at the bottom of the diagram.

Context-sensitive menu

A context-sensitive menu also provides access to the configuration dialogs and some additional functions.

Access:

- ▶ Touch and hold a spot in the power analysis diagram for at least 1 second to access the context-sensitive menu.




Figure 8-6: Power analysis context-sensitive menu

In the context-sensitive menu you can access:

- "Start Continuous/Stop": Triggers / stops the power analysis measurement
Note: During a measurement in the frequency domain, or the power domain respectively, the displayed frequency/power value in the status bar (home screen) does not correspond to the value applied at the output. Therefore, the R&S SMA100B displays asterisks instead of the frequency or power value during the measurement and indicates the original value again when the measurement is completed or aborted.
- "Next Window (Hardkey)": Switches between the measurement views that are enabled in the following order:
 - "Standard View"
 - "Marker View"
 - "Pulse Data View"
 - "Full Screen"

At least one viewing mode has to be selected. For details on the different view modes, see ["Next window list"](#) on page 273.
- "Configure...": opens a dialog for configuring the power analysis measurement. See [Chapter 8.4.4.6, "NRP-Z configure settings"](#), on page 252.
- "Trace/Markers...": opens a dialog for configuring the traces/marker. See [Chapter 8.4.4.5, "NRP-Z traces/markers settings"](#), on page 246.
- "Save...(Power Analysis)": opens a dialog to save a hardcopy of the measurement. See [Chapter 8.4.4.7, "Creating screenshots of power analysis settings"](#), on page 277.

Power Analysis Diagram

Indicates the measurement results graphically, including configured markers, functions, etc.

Off / NRP-Zxx

Accesses the dialogs for configuring the traces and markers, see [Chapter 8.4.4.5, "NRP-Z traces/markers settings"](#), on page 246

Configure...

Accesses the dialog for configuring the power analysis measurement, see [Chapter 8.4.4.6, "NRP-Z configure settings"](#), on page 252.

Start Continuous / Stop

Starts and stops the power analysis measurement. Depending on the selected measurement mode, the label varies.

8.4.4.4 Test setup example

As a power meter has no built-in selection, it is measuring all signal components from nearly DC to 40 GHz and higher. Therefore, the DUT's signal must be rather pure or subjected to external filtering (harmonics, spurious) before measured.

The test setup for the power analysis in the power versus frequency or power versus power is as follows:



Figure 8-7:

DUT = Device under test

PS = Power sensor, e.g. R&S NRP-Z8x, connected at the DUT's input and the USB connector of the R&S SMA100B

1. Connect the DUT RF input to the RF output of the instrument.
2. Connect the DUT RF output to the power sensor.
3. Connect the power sensor to the signal generator.
4. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
5. Select "Configure" to open a dialog for setting up the measurement.
6. Select the power sensor, indicated at the bottom of the dialog to set the trace.
7. Select "Start Cont." to trigger the measurement.

8.4.4.5 NRP-Z traces/markers settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".

2. Select power sensor indication located at the bottom of the dialog.
3. To access the trace settings, select the respective "Trace x" tab.

Trace 1	Trace 2	Trace 3	Trace 4	Markers		✕
Indication 2 - NRP-Z81		Color Yellow				
Save To Ref		Define Reference ...				
Mathematics Off		T1=		T1(Ind.)		T1

The measurement data can be current (sensor trace) or stored trace data. You can store data either in a file (reference trace) or in a temporary memory (hold trace). Up to four traces can be indicated at one time. On connection, the sensors are automatically detected and assigned to a trace. By default, connected sensors are assigned to the traces in ascending order, that means sensor 1 to trace 1, sensor 2 to trace 2, etc. If the default trace is already used, the sensor has to be assigned manually in the trace dialog.

Using the reference and hold traces, you can compare traces. Assign a reference curve to one trace and your measured values to a second one, and switch on the display. With this feature you can compare results directly in the graph, or show the deviations in a graph by using the ["Mathematics - Trace Power Analysis"](#) on page 248 function.

Example

The current single measurement of sensor 2 which is assigned to trace 2 is used as reference trace.

1. Select "Trace 2" with "Indication" = "2 - NRP-Z81".
2. Select "Save To Ref".
3. Select "Trace 1" > "Indication > Ref".
4. Select "Diagram".

The R&S SMA100B indicates two identical traces.

5. Select "Start single".

Triggers a new measurement cycle with sensor 2. You can compare the resulting measurement trace with the former measurement, which is displayed as reference trace.

Trace settings

Indication - Trace Power Analysis

Selects the source for the trace data.

The softkey label in the measurement diagram indicates the current selection.

"Off"	No source is selected, the trace is not indicated.
"2 - NRP-Zxx"	The current measurement results of the selected power sensor are the source for the trace data. The index at the beginning of the sensor name indicates the used connector, for example "2" indicates that the sensor is connected via a USB interface. The data is either continuously updated (continuous measurement) or represents a single measurement cycle (single measurement).
"Ref"	Selects the reference trace. The reference trace is a static trace that was stored in a file and can be recalled. It is possible to store one reference trace at a time.
"Hold"	Freezes the current trace data. The hold trace is a temporary trace that is available until the power analysis is finished. Freezing the trace of a sensor in one trace and displaying the measurement values of the same sensor in another trace allows fast comparison between measurements.

Remote command:

:TRACe<ch>:FREQ:SWEep:SRC on page 558
 :TRACe<ch>:POW:SWEep:SRC on page 558
 :TRACe<ch>:TIME:SWEep:SRC on page 559
 :TRACe<ch>[:POWer]:SWEep:STATe on page 566
 :TRACe<ch>[:POWer]:SWEep:FEED on page 561

Color - Trace Power Analysis

Selects the color of the trace.

Remote command:

:TRACe<ch>[:POWer]:SWEep:COLor on page 559

Save to Ref - Trace Power Analysis

Saves the selected trace as reference trace. Only one reference trace is available at a time.

Remote command:

:TRACe<ch>[:POWer]:SWEep:COPY on page 560

Define Reference - Trace Power Analysis

Opens a dialog for defining a linear reference curve, see ["Define reference NRP-Z analysis settings"](#) on page 249.

Mathematics - Trace Power Analysis

Activates the mathematic function.

The function enables you to determine the deviation of two test series, either of measurement traces, or also of traces that contain math results or stored reference curves. That means you can also assign a math result to an operand for further calculation. Various nested computation steps are possible.

The math operation follows the formula:

$$T<ch>_{\text{result}} = T<ch>_{\text{Operand1}} - T<ch>_{\text{Operand2}}$$

How to proceed:

Determine $T<ch>_{\text{Operand1}}$ in the entry field next to "Tx", and then select $T<ch>_{\text{Operand2}}$ in the second entry field right to it.

The result (" $T<ch>_{\text{result}}$ ") is assigned to the above selected "Trace". If switched on, the graph shows the resulting curve.

Note:

Depending on the type of trace, the instrument automatically sets the appropriate unit on the y-axis:

- "dBm" if it shows only measurement traces.
- "dB" for purely mathematical curves.
- "dB/dBm" ratio scale for mixed display, that means measurements and mathematical curves.

Example:

Example of a nested calculation.

- T1 shows the result of the subtraction of the trace ("Trace 1"), and the reference curve.
- Trace2 subtracts Ref from T1.

That illustrates the nested calculation, since T1 covers already a math operation.

Note: "(Ind.)" denotes the currently selected trace.

Remote command:

`:CALCulate[:POWER]:SWEep:FREQuency:MATH<ch>:STATe` on page 516

`:CALCulate[:POWER]:SWEep:FREQuency:MATH<ch>:SUBTract` on page 516

`:CALCulate[:POWER]:SWEep:POWER:MATH<ch>:STATe` on page 517

`:CALCulate[:POWER]:SWEep:POWER:MATH<ch>:SUBTract` on page 518

`:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:STATe` on page 521

`:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:SUBTract` on page 521

Define reference NRP-Z analysis settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select a power sensor at the bottom of the power analysis main screen.
The traces dialog opens.
3. Select a "Trace" tab.

4. Select "Define Reference".

Point A	
Frequency (X)	Pow (Y)
8.000 kHz	-40.000 0 dBm

Point B	
Frequency (X)	Pow (Y)
40.000 000 000 GHz	-40.000 0 dBm

Save To Ref

Figure 8-8: Defining the reference curve, e.g. in frequency mode

In this dialog, you can specify a linear reference curve for the measurement of the corresponding trace. The measurement mode, selected with [Configure measurement settings](#), determines the parameters assigned to the x-axis and the y-axis in the diagram.

The remote commands required to define these settings are described in [Chapter 14.16, "SENSe, READ, INITiate and SLISt subsystems"](#), on page 568.

Freq (X)

For [Configure measurement settings](#) > "Frequency", sets the frequency values for points A and B of the reference curve.

Remote command:

[:SENSe\[:POWER\]:SWEep:FREQuency:REference:DATA:XVALues](#) on page 535

[:CALCulate\[:POWER\]:SWEep:FREQuency:MATH<ch>:XVAL](#) on page 517

POW (Y)

For [Configure measurement settings](#) > "Frequency", sets the power values for points A and B of the reference curve.

Remote command:

[:SENSe\[:POWER\]:SWEep:FREQuency:REference:DATA:YVALues](#) on page 535

[:CALCulate\[:POWER\]:SWEep:FREQuency:MATH<ch>:YVAL](#) on page 517

Pow (X)

For [Configure measurement settings](#) > "Power", sets the power values for points A and B of the reference curve on the x-axis.

Remote command:

[:SENSe\[:POWER\]:SWEep:POWer:REference:DATA:XVALues](#) on page 547

[:CALCulate\[:POWER\]:SWEep:POWer:MATH<ch>:XVAL](#) on page 518

Pow (Y)

For [Configure measurement settings](#) > "Power", sets the power values for points A and B of the reference curve on the x-axis.

Remote command:

[:SENSe\[:POWER\]:SWEep:POWer:REFeRence:DATA:YVALues](#) on page 548

[:CALCulate\[:POWER\]:SWEep:POWer:MATH<ch>:YVAL](#) on page 518

Time (X)

For [Configure measurement settings](#) > "Time", sets the time values for points A and B of the reference curve on the x-axis.

Remote command:

[:SENSe\[:POWER\]:SWEep:TIME:REFeRence:DATA:XVALues](#) on page 552

[:CALCulate\[:POWER\]:SWEep:TIME:MATH<ch>:XVAL](#) on page 521

Pow (Y)

For [Configure measurement settings](#) > "Time", sets the power values for points A and B of the reference curve on the y-axis.

Remote command:

[:SENSe\[:POWER\]:SWEep:TIME:REFeRence:DATA:YVALues](#) on page 553

[:CALCulate\[:POWER\]:SWEep:TIME:MATH<ch>:YVAL](#) on page 522

Save To Ref

Saves the selected trace as reference trace. One reference trace is available at a time.

Remote command:

[:SENSe\[:POWER\]:SWEep:FREQuency:REFeRence:DATA:COpy](#) on page 534

[:SENSe\[:POWER\]:SWEep:POWer:REFeRence:DATA:COpy](#) on page 547

[:SENSe\[:POWER\]:SWEep:TIME:REFeRence:DATA:COpy](#) on page 552

Marker settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select a power sensor button at the bottom power analysis main screen.

The traces dialog opens.

3. Select the "Markers" tab.

Trace 1	Trace 2	Trace 3	Trace 4	Markers	
Trace				Marker 1 Visible	<input checked="" type="checkbox"/>
Trace				Marker 2 Visible	<input checked="" type="checkbox"/>
Trace				Marker 3 Visible	<input type="checkbox"/>
Trace				Marker 4 Visible	<input type="checkbox"/>

In this dialog, you can assign markers to the corresponding traces and activate them for display.

Trace - Power Analysis

Selects the trace the marker is assigned to.

Remote command:

n.a.

Marker x Visible - Power Analysis

Selects if the respective marker and the marker list are shown in the diagram.

Remote command:

n.a.

8.4.4.6 NRP-Z configure settings

The "Configure" dialog allows you to set measurement and sensor parameters.

- [Configure measurement settings](#).....252
- [Configure sensors settings](#).....256
- [Configure diagram](#).....260
- [Configure time mode settings](#).....261
- [Trace settings](#).....262
- [Pulse data notifications settings](#).....264
- [Trigger settings](#).....269
- [Gate mode settings](#).....271
- [Next window list](#).....273

Configure measurement settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".

2. Select "Configure" > "Configure Measurement".

Configure Measurement	Configure Sensors	Configure Diagram	Configure Time Mode	Next Window List		X
Mode Time						
Min		Max				
-5.000 000 μ s		45.000 000 μ s				
Steps		Average				
1 000		1				
Spacing		Execution				
Linear		Continuous				
All Trigger Events						
Wired AND						

The measurement section provides the parameters for configuring the measurement either in frequency, power or time domain. Depending on the measurement domain, the settings vary.

Mode - Power Analysis

Selects the measurement mode.

- "Frequency" Power versus frequency measurement (frequency response).
- "Power" Power versus power measurement (power sweep, AM/AM).
- "Time" Power versus time measurement (envelope power measurement as a function of time, NRP trace mode). The R&S SMA100B samples power over a time interval and assigns the internal power values that have been determined to several points.
This mode also provides gated measurement and pulse data analysis, e.g. with a connected R&S NRP-Z81, and the corresponding graphical display "Gate View" and "Pulse Data View".

Remote command:

`:SENSe[:POWER]:SWEep:MODE` on page 547

Min - Power Analysis

Sets the minimum frequency/power/time of the measurement.

The available frequency/power range depends on the frequency/power range of the generator and the used power sensor.

The range for the start time is -1s to +1s. Value 0 defines the trigger point. By choosing a negative time value, the trace can be shifted in the diagram.

It is possible, that the measurement cannot be performed over the complete time range because of limitations due to sensor settings. In this case, the R&S SMA100B generates an error message.

If you change this value for a finished single measurement, only the scaling of the x-axis changes. This way, you can zoom the trace. However, for subsequent measurements, the measurement range is changed according to the new setting.

If you change this value during a continuous measurement, only the scaling of the x-axis changes for measurement cycles that have been triggered before the change. For subsequent measurement cycles, the measurement range changes according to the new setting.

Remote command:

`:SENSe[:POWer]:SWEep:FREQuency:START` on page 536

`:SENSe[:POWer]:SWEep:POWer:START` on page 548

`:SENSe[:POWer]:SWEep:TIME:START` on page 553

Max - Power Analysis

Sets the maximum frequency/power/time of the measurement.

The available frequency/power range depends on the frequency/power range of the instrument and the used power sensor.

The range for the stop time is 0 s to 2 s. Value 0 defines the trigger point.

It is possible, that the measurement cannot be performed over the complete time range because of limitations due to sensor settings. In this case, an error message is output.

If you change this value for a finished single measurement, only the scaling of the x-axis changes. This way, you can zoom the trace. However, for subsequent measurements the measurement range is changed according to the new setting.

If you change this value during a continuous measurement, only the scaling of the x-axis changes for measurement cycles that have been triggered before the change. For subsequent measurement cycles, the measurement range changes according to the new setting.

Remote command:

`:SENSe[:POWer]:SWEep:FREQuency:STOP` on page 536

`:SENSe[:POWer]:SWEep:POWer:START` on page 548

`:SENSe[:POWer]:SWEep:TIME:STOP` on page 554

Steps - Power Analysis

Sets the number of steps for the sweep. The number of measured points is steps + 1.

The number of steps is one of the parameters that define the measurement speed. The higher the number of steps, the longer the measurement takes (frequency and power mode).

Remote command:

`:SENSe[:POWer]:SWEep:FREQuency:STEPS` on page 536

`:SENSe[:POWer]:SWEep:POWer:STEPS` on page 549

`:SENSe[:POWer]:SWEep:TIME:STEPS` on page 554

Timing - Power Analysis

Selects the timing mode in frequency or power domain.

This parameter is only available for [Configure measurement settings](#) > "Frequency"/"Power".

"Fast"	Fast measurement with an integration time of 2 ms for each measurement step.
"Normal"	A longer but more precise measurement (integration time is 20 ms/step).

Remote command:

[:SENSe\[:POWER\]:SWEep:FREQuency:TIMing\[:MODE\]](#) on page 537

[:SENSe\[:POWER\]:SWEep:POWer:TIMing\[:MODE\]](#) on page 549

Average - Power Analysis

Selects the averaging factor in time domain.

The factor determines how many measurement cycles are used to form a measurement result. Higher averaging counts reduce noise but increase the measurement time. Averaging requires a stable trigger event so that the measurement cycles have the same timing. If factor 1 is selected, no averaging is performed.

This parameter is only available for [Configure measurement settings](#) > "Time".

Remote command:

[:SENSe\[:POWER\]:SWEep:TIME:AVERAge\[:COUNT\]](#) on page 551

Spacing - Power Analysis

Sets the mode for calculating the sweep steps.

In power versus frequency mode, selection between linear and logarithmic spacing is possible.

"Linear"	<ul style="list-style-type: none"> • Power versus frequency In a linear sweep, the frequency is swept in equidistant steps over the continuous frequency range. The x-axis is a linear frequency axis. • Power versus power The sweeps are performed at constant frequency but with variable generator power that is swept in linear, equidistant steps over a continuous range. The x-axis is a dB-linear power axis. • Power versus time The sweeps are performed at constant frequency and stimulus power. The measurement is repeated over a specified period of time at constant time intervals.
"Logarithmic"	<p>Power versus frequency</p> <p>In a logarithmic sweep, the frequency is swept in equidistant steps on a logarithmic scale. The x-axis is a logarithmic frequency axis.</p>

Remote command:

[:SENSe\[:POWER\]:SWEep:FREQuency:SPACing\[:MODE\]](#) on page 536

[:SENSe\[:POWER\]:SWEep:POWer:SPACing\[:MODE\]](#) on page 548

[:SENSe\[:POWER\]:SWEep:TIME:SPACing\[:MODE\]](#) on page 553

Execution - Power Analysis

Selects single or continuous mode in power analysis.

The measurement is started in the diagram using the "Start" button. During measurement, the "Start" button is replaced by a "Stop" button which can be used to abort the measurement. The progress bar indicates the status of the measurement.

"Single" Selects single measurement.

"Cont." Selects continuous measurements.

Remote command:

[:SENSe\[:POWER\]:SWEep:RMODE](#) on page 551

[:SENSe\[:POWER\]:SWEep:POWER:RMODE](#) on page 548

[:SENSe\[:POWER\]:SWEep:FREQuency:RMODE](#) on page 535

[:SENSe\[:POWER\]:SWEep:TIME:RMODE](#) on page 553

All Trigger Events - Power Analysis

Selects the trigger mode for measurements in the time domain.

The measurement data processing starts with a trigger event in one of the sensors (Logical OR), or when all channels are triggered (logical AND). Each sensor evaluates a trigger event according to its setting independently.

This function supports the internal or external trigger modes with multi-channel time measurements.

"Wired AND" The measurement starts when all channels are triggered.

"Wired OR" The measurement starts when a trigger event occurs.

Remote command:

[:SENSe\[:POWER\]:SWEep:TIME:TEVents](#) on page 554

Configure sensors settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Sensors"

Configure Measurement	Configure Sensors	Configure Diagram	Configure Time Mode	Next Window List		✕
2 - NRP-Z81		Zero				
Level Offset		3.00 dB				
On						
S-Parameter		Unused				
Separate Frequency						
Use Separate Frequ.		<input checked="" type="checkbox"/>				
1.000 000 MHz						

The "Configure Sensors" dialog provides specific parameters for the power sensor. This part of the dialog can differ from the following description depending on the sensor used. Refer to the manual of the power sensor in this case.

Power Sensor - Power Analysis

Selects the power sensor to be set if more than one sensor is connected to the instrument.

Remote command:

n.a.

In remote control, the sensor is selected via the numeric suffix in the sense key word of the command, for example `SENSe2:POWer:SWEep:....`

Zero - Power Analysis

Activates the auto zero function.

Zeroing calibrates the external power sensor by adjusting its reading at zero signal power. For this purpose, the RF power source must be switched off or disconnected from the sensor. If a Rohde & Schwarz power sensor receives an input power during the zeroing process, it aborts zeroing and generates an error message. Zeroing takes a few seconds, depending on the sensor model. Refer to the documentation of your power sensor for more information.

Tips for zeroing

When to perform zeroing:

- During warm up after switching on or connecting the instrument
- After a substantial change of the ambient temperature
- After fastening the power sensor module to an RF connector at high temperature
- After several hours of operation
- When low-power signals are to be measured, e.g. less than 10 dB above the lower measurement limit.

- Switch off the RF power source for zeroing, but do not disconnect it from the power sensor. This proceeding keeps the thermal equilibrium, and the zeroing process also compensates the noise that superimposes the measured signal (e.g. from a broadband amplifier).

Pulse Data

Accesses the dialog for configuring the settings for pulse data analysis.

See ["Trace settings"](#) on page 262.

Trigger..

Accesses the dialog for configuring the trigger settings.

See ["Trigger settings"](#) on page 269

Level Offset State- Power Analysis

Activates a level offset at the sensor input. Set the offset value in the entry field on the right.

Remote command:

[:SENSe<ch>\[:POWER\]:SWEep:FREQuency\[:SENSor\]:OFFSet:STATe](#)

on page 526

[:SENSe<ch>\[:POWER\]:SWEep:TIME\[:SENSor\]:OFFSet:STATe](#) on page 529

[:SENSe<ch>\[:POWER\]:SWEep:TIME\[:SENSor\]:OFFSet:STATe](#) on page 529

Level Offset - Power Analysis

Sets the level offset at the sensor input. To consider the value, activate the offset.

Remote command:

[:SENSe<ch>\[:POWER\]:SWEep:FREQuency\[:SENSor\]:OFFSet](#) on page 526

[:SENSe<ch>\[:POWER\]:SWEep:POWer\[:SENSor\]:OFFSet](#) on page 528

[:SENSe<ch>\[:POWER\]:SWEep:TIME\[:SENSor\]:OFFSet](#) on page 529

Use S-Parameter - Power Analysis

Activates the use of the S-parameters correction data of the connected power sensor. For sensors with attenuator, this checkbox is automatically checked.

Refer also to the manual of the connected R&S power sensor for a description on how to use the S-parameters table.

Use Separate Frequency- Power Analysis

This setting is offered for measurements with DUTs that change the measurement frequency (like modulators), thus changing the input frequency of the sensor.

The parameters vary depending on the measurement modes:

- Power versus frequency measurement
Activates the use of a different frequency range other than the set signal generator frequency range for the measurement. The separate minimum and maximum frequency values are set below.
The x-scale of the diagram can be adjusted to the separate frequency range with functions "Use as X Scale" and "Map to X Scale".
- Power versus power measurement / Power versus time measurement

Activates the use of a different frequency other than the set signal generator frequency for the measurement. The separate frequency value is set in the entry window below.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:SRANge[:STATe]`

on page 527

`:SENSe<ch>[:POWER]:SWEep:POWeR[:SENSor]:SFRequency:STATe`

on page 529

`:SENSe<ch>[:POWER]:SWEep:POWeR[:SENSor]:SFRequency` on page 528

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:SFRequency:STATe`

on page 532

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:SFRequency` on page 532

Min Frequency - Power Analysis

This parameter is only available for [Configure measurement settings](#) > "Frequency" and [Use Separate Frequency- Power Analysis](#) > "Active".

Sets the minimum frequency of the measurement.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:SRANge:STARt`

on page 526

Max Frequency - Power Analysis

This parameter is only available for [Configure measurement settings](#) > "Frequency" and [Use Separate Frequency- Power Analysis](#) > "Active".

Sets the maximum frequency of the measurement.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:SRANge:STOP`

on page 527

Use as X Scale - Power Analysis

This parameter is only available for [Configure measurement settings](#) > "Frequency" and [Use Separate Frequency- Power Analysis](#) > "Active".

Activates the use of the separate frequency min and max values for the scaling of the x-axis. Thus, the trace for this sensor is visible in the diagram, especially for frequency ranges that differ substantially from the generator settings.

If more than one sensor is active, which use separate frequencies, the option is only available for one sensor. To indicate the traces of the other sensors, use function "Map to X Scale".

Remote command:

n.a.

Map to X Scale - Power Analysis

This parameter is only available for [Configure measurement settings](#) > "Frequency" and [Use Separate Frequency- Power Analysis](#) > "Active".

Maps the trace of a sensor that uses separate frequency to the current scaling of the diagram. Usually the scale is determined by the set frequency range of the generator. If more than one sensor is active, which use separate frequencies, the scale can also be determined by the separate frequency range of one of the other sensors.


Remote command:

n.a.

Configure diagram

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Diagram"



The "Configure Diagram" covers the parameters for scaling the y-axis and the appearance of the diagram.

Min - Max Level - Power Analysis

Selects the minimum and maximum value of the y-axis.

Remote command:

`:SENSe[:POWER]:SWEep:FREQuency:YScale:MAXimum` on page 538

`:SENSe[:POWER]:SWEep:FREQuency:YScale:MINimum` on page 538

`:SENSe[:POWER]:SWEep:POWer:YScale:MAXimum` on page 551

`:SENSe[:POWER]:SWEep:POWer:YScale:MINimum` on page 551

`:SENSe[:POWER]:SWEep:TIME:YScale:MAXimum` on page 556

`:SENSe[:POWER]:SWEep:TIME:YScale:MINimum` on page 556

Auto Scale - Power Analysis

Activates autoscaling of the y-axis of the diagram. The "Auto Scale" function adjusts the scale divisions so that the entire trace fits into the diagram area.

"Off" Auto scale is deactivated. Switching from activated to be deactivated, the scaling is maintained.

"Expand Only (Coarse/Fine)"

Auto scale is activated. Automatically selects the appropriate scaling of the y-axis so that the trace is always visible. The range is expanded when a value is out of the right or the left end-of-scale value. The step width is 5 dB for selection "Exp. (Coarse)" and variable in the range of 0.2 dB to 5 dB for selection "Exp. (Fine)".

"Float (Coarse/Fine)"

Auto scale is activated, that means this parameter automatically selects the appropriate scaling of the y-axis so that the trace is always visible. The range is either expanded, when a value is out of the right/left end-of-scale value or it is reduced when the trace fits into a smaller scale area. The step width is 5 dB for selection "Flt. (Coarse)" and variable in the range of 0.2 dB to 5 dB for selection "Flt. (Fine)".

Remote command:

`:SENSe[:POWER]:SWEep:FREQuency:YSCale:AUTO` on page 537

`:SENSe[:POWER]:SWEep:POWer:YSCale:AUTO` on page 550

`:SENSe[:POWER]:SWEep:TIME:YSCale:AUTO` on page 555

Reset Auto Scale - Power Analysis

Resets the scaling of the y-axis to suitable values after the use of auto scaling in the expanding mode. For this mode, the Y scale can get too expanded because of temporary high-power values. The reset function resets the diagram again, to indicate smaller power values.

Remote command:

`:SENSe[:POWER]:SWEep:FREQuency:YSCale:AUTO:RESet` on page 538

`:SENSe[:POWER]:SWEep:POWer:YSCale:AUTO:RESet` on page 550

`:SENSe[:POWER]:SWEep:TIME:YSCale:AUTO:RESet` on page 555

Show Grid - Power Analysis

Activates the indication of a grid in the diagram area.

Remote command:

`:DISPlay[:WINDow][:POWER]:SWEep:GRID:STaTe` on page 522

Background Color - Power Analysis

Sets the background color of the diagram to black or white. The background color is also effective for the hardcopy of the diagram.

Remote command:

`:DISPlay[:WINDow][:POWER]:SWEep:BACKground:COLor` on page 522


Configure time mode settings

The time measurement mode enables you to analyze internally generated or externally supplied signals. In time mode, the measurement requires an additional trigger event, with selectable level, hysteresis and drop time. In time domain, you can also analyze measured pulse data.

Trace settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Time".
4. Select "Configure Time Mode"
5. Select the "Trace" tab.



The "Trace" tab contains the parameters for the evaluation of important pulse parameters, provided the used power sensor supports automatic pulse analysis.

Trace

Selects the trace the sensor is assigned to.

To assign a sensor to a trace, use the trace buttons, see [Off / NRP-Zxx](#).

Indication

Indicates the type of power sensor assigned to the selected trace. This field is automatically updated if the sensor is connected or disconnected. Also, this sensor is indicated on the trace button in the measurement diagram.

This parameter is only available for [Configure measurement settings](#) > "Time".

Remote command:

n.a.

Pulse Analysis

Activates pulse data analysis.

To start the automatic pulse analysis, select "Start Cont." button in the main measurement diagram.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:STAtE` on page 530

All Annotations Off

Indicates the state of the annotations.

Remote command:

n.a.

Base

Selects the calculation basis for the threshold parameters.

"Voltage related"

Calculates the pulse parameters rise/fall time and pulse width by the voltage over time $U(t)$.

Voltage-related parameters represent the usual case.

"Power related"

Represents the pulse parameters as power values.

To obtain equivalent power-dependent values, the voltage-dependent threshold values are converted (squared), (see example in table below).

	Distal	Mesial	Proximal
Voltage related:	90%	50%	10%
Power related:	81%	25%	1 %
log. Scale (for example): (approximately, difference between top- base power > 30 dB)	-0.9dB	-6dB	-20dB

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:THReshold:BASE`

on page 530

`:TRACe<ch>[:POWER]:SWEep:PULSe:THReshold:BASE?` on page 564

Distal

Sets the upper reference level in terms of percentage of the overall pulse level (power or voltage related). The distal power defines the end of the rising edge and the start of the falling edge of the pulse.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWER:`

`HREFeRence` on page 530

`:TRACe<ch>[:POWER]:SWEep:PULSe:THReshold:POWER:HREFeRence`

on page 565

Mesial

Sets the medial reference level in terms of percentage of the overall pulse level (power or voltage related). This level is used to define the pulse width (τ) and pulse period.

Remote command:

```
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:
REFErence on page 531
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:REFErence
on page 565
```

Proximal

Sets the lower reference level in terms of percentage of the overall pulse level (power or voltage related).

The proximal power defines the start of the rising edge and the end of the falling edge of the pulse.

Remote command:

```
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:
LREFErence on page 531
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:LREFErence
on page 565
```

Pulse data notifications settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Time".
4. Select "Configure Time Mode"


5. Select the "Pulse Data notifications" tab.

Configure Measurement	Configure Sensors	Configure Diagram	Configure Time Mode	Next Window List	
Duty Cycle	<input type="checkbox"/>	Rise Time	<input checked="" type="checkbox"/>	Trace	
Pulse Width	<input checked="" type="checkbox"/>	Pulse Start Time	<input type="checkbox"/>	Pulse Data Notifications	
Pulse Period	<input checked="" type="checkbox"/>	Overshoot (Rising Edge)	<input type="checkbox"/>	Trigger	
Pulse Off Time	<input checked="" type="checkbox"/>	Fall Time	<input checked="" type="checkbox"/>	Gate Mode	
		Pulse Stop Time	<input type="checkbox"/>		
		Overshoot (Falling Edge)	<input type="checkbox"/>		
Signal Power		Pulse Power			
Peak Power	<input checked="" type="checkbox"/>	Top Power	<input type="checkbox"/>		
Average Power	<input type="checkbox"/>	Base Power	<input checked="" type="checkbox"/>		
Minimal Power	<input type="checkbox"/>	Distal Power	<input checked="" type="checkbox"/>		
		Mesial Power	<input checked="" type="checkbox"/>		
		Proximal Power	<input type="checkbox"/>		

In the "Pulse Data Notification" tab, you can determine the parameter values to be indicated on bottom of the diagram.

Notifications - Pulse Data Analysis

Selects the pulse parameters to be indicated below the measurement diagram.



Duty Cycle ← Notifications - Pulse Data Analysis

Indicates the ratio between the pulse duration (τ) and the pulse period (T) of the measured pulse signal in per cent:

$$\text{Duty Cycle} = (\text{pulse duration} / \text{pulse period}) * 100$$

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DCYClE?` on page 562

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DCYClE:DISPlay:ANNotation[:STATe]` on page 563

Pulse Width ← Notifications - Pulse Data Analysis

Indicates the pulse duration of the pulse data measurement in seconds.

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DURation?` on page 562

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DURation:DISPlay:ANNotation[:STATe]` on page 563

Pulse Period ← Notifications - Pulse Data Analysis

Indicates the time the pulse signal needs to complete one cycle.

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:PERiod?` on page 562

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:PERiod:DISPlay:ANNotation[:STATe]` on page 563

Pulse Off Time ← Notifications - Pulse Data Analysis

Determines the time the pulse signal is low, that means as long as the signal level is below the proximal value.

Remote command:

:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:SEParation? on page 562

:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:PERiod:DISPlay:

ANNotation[:STATe] on page 563

Transition Times - Pulse Data Analysis

Selects the transition parameters of the pulse signal to be indicated below the measurement diagram.

The R&S NRP-Z sensor searches for the first rising edge and the first falling edge in the trace.

Rise Time / Fall Time ← Transition Times - Pulse Data Analysis

Displays the time the signal requires from crossing low reference until it reaches high reference level and vice versa.

Remote command:

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:DURation? on page 562

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:DURation:DISPlay:ANNotation[:STATe] on page 563

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:DURation? on page 562

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:DURation:DISPlay:ANNotation[:STATe] on page 563

Pulse Start Time / Pulse Stop Time ← Transition Times - Pulse Data Analysis

Displays the time when the pulse signal crosses the medial reference level.

Remote command:

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence? on page 562

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence:DISPlay:ANNotation[:STATe] on page 563

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence? on page 562

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence:DISPlay:ANNotation[:STATe] on page 564

Overshoot (Rising Edge / Falling Edge) ← Transition Times - Pulse Data Analysis

Display the maximum value of the pulse signal following a rising transition and the minimum value of the signal after a falling transition, respectively.

Overshoot values are given in per cent of the pulse amplitude as shown below:

- $\text{Overshoot}(\text{pos}) = 100 \cdot (\text{maximum} - \text{top level}) / (\text{top level} - \text{base level})$
- $\text{Overshoot}(\text{neg}) = 100 \cdot (\text{base level} - \text{minimum}) / (\text{top level} - \text{base level})$

Remote command:

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot? on page 562

:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot:DISPlay:ANNotation[:STATe] on page 564

`:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot?` on page 562

`:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot:DISPlay:ANNotation[:STATe]` on page 563

Signal Power - Pulse Data Analysis

Selects the power parameters of the pulse signal to be indicated below the measurement diagram.

Minimal / Peak / Average Power ← Signal Power - Pulse Data Analysis

Display the minimum, the maximum and the average power of the pulse signal in dBm.

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:MINimum?` on page 562

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:MINimum:DISPlay:ANNotation[:STATe]` on page 563

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:MAXimum?` on page 562

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:MAXimum:DISPlay:ANNotation[:STATe]` on page 563

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:AVERage?` on page 562

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:AVERage:DISPlay:ANNotation[:STATe]` on page 563

Pulse Power - Pulse Data Analysis

Selects which pulse power parameters are indicated in the diagram (pulse data view only).

Top / Base Power ← Pulse Power - Pulse Data Analysis

Indicate the pulse top and base level of the analyzed signal in dBm.

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:PULSe:BASE?` on page 562

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:PULSe:BASE:DISPlay:ANNotation[:STATe]` on page 563

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:PULSe:TOP?` on page 562

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:PULSe:TOP:DISPlay:ANNotation[:STATe]` on page 563

Distal / Mesial / Proximal Power ← Pulse Power - Pulse Data Analysis

Display the absolute power values of the medial, low and high reference level in dBm.

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:LREference?` on page 562

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:LREference:DISPlay:ANNotation[:STATe]` on page 563

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:HREference?` on page 562

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:HREference:DISPlay:ANNotation[:STATe]` on page 563

`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:REference?` on page 562
`:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:REference:DISPlay:ANNotation[:STATe]` on page 563

Trigger settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Time".
4. Select "Configure Time Mode"
5. Select the "Trigger" tab.

Configure Measurement	Configure Sensors	Configure Diagram	Configure Time Mode	Next Window List		X
Sensor		2 - NRP-Z81			Trace	
Mode		Auto			Level	
Slope		Positive			1.000 dBm	
Drop Out Time		200 ns			Hysteresis	
					0.500 dB	
		Auto Set			Gate Mode	

Sensor - Power Analysis

Selects the power sensor to be set if more than one sensor is connected to the instrument.

Remote command:

n.a.

In remote control, the sensor is selected via the numeric suffix in the sense key word of the command, for example `SENSe2:POWER:SWEep:....`

Mode - Power Analysis

Selects if the measurement is free running, or starts only after an internal or external trigger event.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:SOURce` on page 534

Level - Power Analysis

Sets the trigger threshold. This setting is also possible by the trigger marker on the left side of the diagram.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:LEVel` on page 533

Slope - Power Analysis

Sets the polarity of the active slope of the trigger signals.

"Positive" The rising edge of a trigger signal is active.

"Negative" The falling edge of a trigger signal is active.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:SLOPe` on page 533

Hysteresis - Power Analysis

Sets the hysteresis of the internal trigger threshold. Hysteresis is the magnitude (in dB) the trigger signal level must drop below the trigger threshold (positive trigger slope) before triggering can occur again.


Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:HYSTeresis`
on page 533

Drop out Time - Power Analysis

Determines the minimum time for which the signal must be below (above) the power level defined by [Level - Power Analysis](#) and [Hysteresis - Power Analysis](#) before triggering can occur again. This setting prevents the trigger system from being activated too early if the trigger threshold is temporarily underranged or exceeded.

The dropout time parameter is useful when dealing with, for example, GSM signals with several active slots. When measuring in sync with the signal, a trigger event must be generated at A, but not at B or C. As the RF power between the slots is below the threshold defined by [Level - Power Analysis](#) and [Hysteresis - Power Analysis](#), the trigger hysteresis cannot prevent triggering at B or at C. To achieve triggering at A, the value of the drop out time must be greater than the time interval between E and B and between F and C. But it must be lower than the time that elapses between G and A.



As the mechanism associated with the dropout time parameter is reactivated whenever the trigger threshold is crossed, unambiguous triggering can also be obtained for many complex signals. By contrast, all triggering is suppressed during the hold-off time. The example nevertheless shows that you can achieve stable triggering conditions with a suitable hold-off time, i.e. regular triggering at the same point. But setting a trigger that occurs at A exclusively is not possible.

it would not be possible to set exclusive triggering at A . But you cannot set a trigger that occurs exclusively at A.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:DTIME` on page 532

Auto Set - Power Analysis

Sets the trigger level, the hysteresis and the drop out time to default values.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:AUTO` on page 532

Gate mode settings



For "Time" measurement mode only.

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Time".
4. Select "Configure Time Mode"

5. Select the "Gate Mode" tab.

Configure Measurement	Configure Diagram	Configure Gate Mode	Configure Sensors	NEXT WINDOW List		✕
Trace		2	Indication	2 - NRP-Z81		
State ● On						
Gate 1						
Start		5.000 000 μ s		Stop		15.000 000 μ s
Gate 2						
Start		25.000 000 μ s		Stop		35.000 000 μ s

The "Gate Mode" tab contains the parameters for defining the time gates for the measurement.

Almost all R&S NRP sensors also support time gated measurements of peak and average power (see the data sheet or operating manual of the respective sensor). Two user-configurable gates can be assigned to one of the traces. Both gates are active at the same time. The values are calculated from the trace data, the time resolution is determined by the resolution of the sensor. An external trigger signal or signal triggering is required for synchronization.

The start and stop time of the gates are indicated as gate markers, a bar between the start and stop marker shows the gate length. The indication state of the gate borders and measurement values is only available for certain diagram views which are switched with the "Next Window List" key. The "Next Window List" dialog provides a selection of views, between which is toggled (see ["Next window list"](#) on page 273).

Trace - Gate

Selects the trace of the sensor assigned for the gate measurement. Both gates are assigned to the same trace.

To assign the sensor to a trace, use the trace buttons, see [Off / NRP-Zxx](#).

Remote command:

`:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:FEED` on page 519

Indication

Indicates the type of power sensor assigned to the selected trace. This field is automatically updated if the sensor is connected or disconnected. Also, this sensor is indicated on the trace button in the measurement diagram.

This parameter is only available for [Configure measurement settings](#) > "Time".

Remote command:

n.a.

State - Gate

Enables time gated measurement. The measurement is started with the "Start" button in the main measurement diagram. Both gates are active at one time.

The gate borders and the measurement values (average and peak power) are indicated in/below the measurement diagram. The indication is only available for certain diagram views which are switched with the "Rearrange" key.

Remote command:

[:CALCulate\[:POWER\]:SWEep:TIME:GATE<ch>:STATE](#) on page 520

[:CALCulate\[:POWER\]:SWEep:TIME:GATE<ch>:AVERage?](#) on page 519

[:CALCulate\[:POWER\]:SWEep:TIME:GATE<ch>:MAXimum?](#) on page 519

[:TRACe\[:POWER\]:SWEep:MEASurement:GATE:DISPlay:ANNOtation\[:STATE\]](#) on page 567

Start / Stop - Gate

Sets the start and the stop times for the respective gate.

Remote command:


[:CALCulate\[:POWER\]:SWEep:TIME:GATE<ch>:START](#) on page 520

[:CALCulate\[:POWER\]:SWEep:TIME:GATE<ch>:STOP](#) on page 520

Next window list

Access:


1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Next Window List"



The "Next Window List" dialog provides functions to activate only the required "Views" on the checkboxes to the right.

Standard View

Shows the graph and the button bar at the left for frequency power and level sweep measurement.



Remote command:

`:TRACe[:POWER]:SWEep:MEASurement:STANDARD:DISPlay:ANNotation[:STATE]` on page 568


Marker View

Shows the graph and the corresponding marker values at the bottom for frequency power and level sweep measurement.

Up to four markers can be used to display the current power according to the position of the marker. R&S SMA100B indicates the marker values on the bottom of the diagram.

To move the marker lines, you can select them and drag them with your finger. Alternatively you can move them with the rotary knob.

For details on configuring the markers, see "[Marker settings](#)" on page 251.



Remote command:

```
:TRACe[:POWER]:SWEep:MEASurement:MARKer:DISPlay:ANNotation[:  
STATe] on page 567
```

Gate View


Shows the graph with the corresponding gate data for time trace and pulse data measurements.

Remote command:

```
:TRACe[:POWER]:SWEep:MEASurement:GATE:DISPlay:ANNotation[:STATe]  
on page 567
```

Pulse Data View

Shows the graph and the corresponding pulse data for time trace and pulse data measurements.




Remote command:

`:TRACe[:POWER]:SWEep:MEASurement:PULSe:DISPlay:ANNotation[:STATe]` on page 567

Full Screen

Shows the graph in fullscreen, and fades out buttons and list values for frequency power and level sweep measurement.



Remote command:

`:TRACe[:POWER]:SWEep:MEASurement:FULLscreen:DISPlay:ANNotation[:STATe]` on page 566

8.4.4.7 Creating screenshots of power analysis settings

The power analysis save function enables you to save current settings in a file. To document the most important settings for a performed signal generation, you can also save a hardcopy of the current display.


Save (Power analysis) settings

In the "Save ..." dialog you can find the settings to store a screenshot of the current measurement diagram. The current screen shot is stored as indicated, that means with or without marker indication.

Main settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP Power Analysis".
2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".



File name - Power Analysis

Indicates the file name and directory.

Remote command:

:SENSe[:POWER]:SWEep:HCOPY[:EXECute] on page 546

:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME] on page 542

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO:STATE` on page 543

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO:FILE?` on page 543

Format - Power Analysis

Selects the file format.

Several bitmap graphic formats are offered. In addition, format `*.csv` is available which stores the measurement values as ASCII data.

You can refine the csv settings further, see ["CSV options"](#) on page 280.

Remote command:

`:SENSe[:POWER]:SWEep:HCOPY:DEVIce:LANGuage` on page 540


Options

Opens a dialog to select the screenshot format and also to activate and select the automatic naming settings.

Common settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP Power Analysis".
2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".
4. Select "Options".



Automatic Naming

If enabled, the file names are created by selected rules. The filename includes at least one number and optionally additional information.

Remote command:

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO:STATE` on page 543

Format - Power Analysis

Selects the file format.

Several bitmap graphic formats are offered. In addition, format `*.csv` is available which stores the measurement values as ASCII data.

You can refine the csv settings further, see ["CSV options"](#) on page 280.

Remote command:

[:SENSe\[:POWER\]:SWEep:HCOPY:DEVIce:LANGuage](#) on page 540

Automatic naming settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP Power Analysis".
2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".
4. Select "Options".
5. In the "Save NRP-Z Analysis Options" dialog, enable "Automatic Naming."

The screenshot shows the 'Save NRP-Z Analysis Options' dialog box. The 'Path' field is highlighted with an orange box and contains the text 'C:\Users\Bozhanov\Documents'. The 'Automatic Naming' tab is selected, showing options for 'Delete All Image Files In Path', 'Clear Path', 'Prefix' (checked), 'Year' (checked), 'Month' (checked), 'Day' (checked), 'Current Auto Number' (000), and 'Resulting File Name' (smab20181113000.bmp).

Path

Sets the directory for saving the files.

Remote command:

[:SENSe\[:POWER\]:SWEep:HCOPY:FILE\[:NAME\]:AUTO:DIRectory](#) on page 542

Clear Parth

Deletes all image files with extensions "bmp", "img", "png", "xpm" and "csv" in the directory set for automatic naming.

Remote command:

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO:DIRectory:CLEar`
on page 542

Prefix, Year, Month, Day, Instrument Name

A selection of the prefix, year, month, day and instrument name are included in the file name.

Remote command:

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe`
on page 545

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFix`
on page 545

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:DAY:STATe`
on page 544

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:DAY?`
on page 544

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe`
on page 544

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH?`
on page 544

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe`
on page 546

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:YEAR?`
on page 546

Current Auto Number

Indicates the number which is used in the automatically generated file name.

Remote command:

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:NUMBer?`
on page 545

Resulting File Name

Indicates the automatically generated file name.

Remote command:

`:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO:FILE?` on page 543

CSV options

Access:

1. Select "Clk Syn/Power Sens" > "NRP Power Analysis".
2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".
4. Set "Format" > "CSV".
5. Select "Options".

6. Select the "CSV Options" tab.

Save NRP-Z Analysis Options			
Orientation	Vertical	Common	
Separator	,	Automatic Naming	
Decimal Point	.	CSV Options	
Row Header	Off		

If file format *.csv is selected, the trace data is saved as an ASCII file with separated values. CSV files can be imported into the program MS Excel and then processed further. Adjust the value separator and the decimal point according to the language version, to import the data correctly.

Orientation

Defines the orientation of the X/Y value pairs:

- **Horizontal:**
 - X/Y values of trace 1 in rows 1 and 2,
 - X/Y values of trace 2 in rows 3 and 4,
 - X/Y values of trace 3 in rows 5 and 6,
 - X/Y values of trace 4 in rows 7 and 8.

Example:

```
Trace1,X[Hz]: 10000.0; 10010.0; 10020.0; 10030.0; ...
Trace1,Y[dBm]: -20.09; -19.17; -18.19; -15.43; ...
Trace2,X[Hz]: 10000.0; 10010.0; 10020.0; 10030.0; ...
Trace2,Y[dBm]: -19.09; -18.17; -17.19; -14.43; ...
Trace3,X[Hz]: 10000.0; 10010.0; 10020.0; 10030.0; ...
Trace3,Y[dBm]: -21.09; -20.17; -19.19; -16.43; ...
Trace4,X[Hz]: 10000.0; 10010.0; 10020.0; 10030.0; ...
Trace4,Y[dBm]: -22.07; -20.14; -21.56; -17.67; ...
```

- **Vertical:**

X/Y values of trace 1 in column 1 and 2,
 X/Y values of trace 2 in column 3 and 4,
 X/Y values of trace 3 in column 5 and 6,
 X/Y values of trace 4 in column 7 and 8.

Example:

```
Trace1,X[Hz]; Trace1,Y[dBm]; Trace2,X[Hz]; Trace2,Y[dBm]; Trace3,X[Hz];
Trace3,Y[dBm]; Trace4,X[Hz]; Trace4,Y[dBm];
10000.0;-20.09;10000.0; -19.09;10000.0;21.09;10000.0;22.07;
10010.0;-19.17;10010.0;-18.17;10010.0; -20.17;10010.0; -20.14;
10020.0;-18.19;10020.0;-17.19;10020.0;-19.19;10020.0;-21.56;
10030.0; -15.43;10030.0; -14.43;10030.0;-16.43;10030.0;-17.67;...
```

Remote command:

```
:SENSe[:POWER]:SWEep:HCOPY:DEvice:LANGuage:CSV:ORientation
on page 541
```

Separator

Defines the character to be used to separate the values: tabulator, semicolon, comma or blank.

Remote command:

```
:SENSe[:POWER]:SWEep:HCOPY:DEvice:LANGuage:CSV[:COLumn]:
SEPARATOR on page 541
```

Decimal Point

Defines the character to be used as the decimal point of the values: dot or comma.

Remote command:

```
:SENSe[:POWER]:SWEep:HCOPY:DEvice:LANGuage:CSV:DPOint on page 540
```

Row Header

Defines a header for each row or column, depending on the orientation. A header contains information on the trace, e.g. the trace index, or frequency, power or time values.

Example:


```
Trace=2;Source=detecting..;X[Hz]";"Trace=2;Source=detecting..;Y[dBm]"
```

Remote command:


```
:SENSe[:POWER]:SWEep:HCOPY:DEvice:LANGuage:CSV:HEADer on page 540
```

How to save a hardcopy of the power analysis window

1. Select "Clk Syn/Power Sens" > "NRP Power Analysis".
2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".



4. To define the output format, select "Format > JPG".
5. Select "Options...".
6. To enable the instrument to create output filenames, select "Automatic Naming > On".
- 7.



In the "Automatic Naming" tab:

- a) To change the default directory the file is saved in, select " Path" and define a path and a filename. For example, select the default directory `/var/user`.
 - b) If necessary, disable or change some of the parameters in the "Automatic Naming Settings".
 - c) Close the "Save NRP-Z Analysis Options" dialog.
8. In the "Save NRP-Z Analysis" dialog, select "Save".
The instrument saves a hardcopy of the current instrument display as a `*.jpg` file. The filename is automatically created.
9. To print the hardcopy, connect the instrument to a LAN and:
 - a) Transfer the file to a remote computer as described in [Chapter 11.9, "How to transfer files from and to the instrument"](#), on page 327.
 - b) On the remote computer, navigate through the file system.
 - c) Print the selected file.

For more information, refer to the online help of the operating system.

8.4.4.8 How to set up a frequency sweep measurement

Prerequisites: the sensor is connected to the instrument and configured, see [Chapter 8.4, "Using power sensors"](#), on page 230.

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Frequency".
4. Configure the measurement:
 - a) Set "Min = 8 KHz".
 - b) Set "Max = 6 GHz".
 - c) Set "Steps = 200".
5. Select the "Configure Diagram" tab.
Ho to: see [Chapter 8.4.4.11, "How to configure the power analysis diagram"](#), on page 286.
6. Select the "Configure Sensors" tab.
7. Select the connected sensor, e.g. "2-NRP-Z81".
8. If you want to configure the frequency settings of the sensor differently than the generator settings, enable "Use Separate Frequ.".
 - a) Set "Min = 1 MHz".
 - b) Set "Max =10 MHz".
9. In the "Next Window List" tab, enable the "Standard View".
10. Close the "Configure" dialog.

11. Press "Start Cont" to start the measurement.

8.4.4.9 How to set up a power sweep measurement

Prerequisites: the sensor is connected to the instrument and configured, see [Chapter 8.4, "Using power sensors"](#), on page 230.

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Power".
4. Configure the measurement:
 - a) Set "Min = -20 dBm".
 - b) Set "Max = 30 dBm".
 - c) Set "Steps = 200".
5. Select the "Configure Diagram" tab.
Ho to: see [Chapter 8.4.4.11, "How to configure the power analysis diagram"](#), on page 286.
6. Select the "Configure Sensors" tab.
7. Select the connected sensor, e.g. "2-NRP-Z81".
8. If you want to configure the frequency settings of the sensor differently than the generator settings, enable "Use Separate Frequ.".
 - a) Set "1 MHz".
9. In the "Next Window List" tab, enable the "Standard View".
10. Close the "Configure" dialog.
11. Press "Start Cont" to start the measurement.

8.4.4.10 How to set up a pulse measurement

Prerequisites: the sensor is connected to the instrument and configured, see [Chapter 8.4, "Using power sensors"](#), on page 230.

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Time".
4. Configure the measurement:
 - a) Set "Min = -5 us".
 - b) Set "Max = 45 us".
 - c) Set "Steps = 200".

5. Select the "Configure Diagram" tab.
How to: see [Chapter 8.4.4.11, "How to configure the power analysis diagram"](#), on page 286.
6. Select the "Configure Sensors" tab.
7. Select the connected sensor, e.g. "2-NRP-Z81".
8. In the "Next Window List" tab, enable the "Pulse Data View".
9. Close the "Configure" dialog.
10. In the diagram window, open the context-sensitive menu.
11. Select "Trace/Pulse Data Notifications/ Trigger".
12. Select the "Trace" tab.
13. Set "State > On".
14. Set the thresholds:
 - a) Set "Base > Voltage Related".
 - b) Set "Distal = 90%".
 - c) "Mesial = 50%".
 - d) "Proximal = 10%".
15. Select the "Pulse Data Notifications" tab.
16. Enable up to six parameters, for example:
 - "Duty Cycle"
 - "Pulse Width"
 - "Pulse Period"
 - "Off Time"
 - "Start Time"
17. Close the "Trace/Pulse Data Notifications/ Trigger" dialog.
18. Press "Start Cont" to start the measurement.

8.4.4.11 How to configure the power analysis diagram

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Diagram".
3. Set "Max Level = 30 dBm".
4. Set "Min Level = -40 dBm".
5. Select "Auto Scale > Expand Only (Coarse)".
6. Enable "Show Grid".
7. Set "Background Color > Black."

8.5 How to calibrate the power level with an R&S NRP power sensor

Using a R&S NRP power sensor and the user correction function of the instrument, you can compensate external frequency responses. The R&S SMA100B utilizes the readings of the power sensor and creates a correction value table for controlling the output level during operation.


To connect the R&S NRP to the R&S SMA100B

1. Connect the power sensor.
See [Chapter 8.4.1, "Connecting R&S NRP power sensors to the R&S SMA100B"](#), on page 230.
2. Select "Clk Syn/Power Sens" > "NRP Sensor Mapping".
3. If the sensor is not detected automatically, select "Scan > Start".
The instrument scans the network and the USB connections for connected sensors and lists all detected R&S NRP sensors in the mapping table.
4. In the "Mapping" column, assign the sensor to a sensor channel, see [Chapter 8.4.2, "NRP sensor mapping"](#), on page 231.
5. Close the dialog.

To configure and calibrate the R&S NRP in the R&S SMA100B

Provided the power sensor is connected to the R&S SMA100B and is assigned to a sensor channel, we recommend that you calibrate and configure the power sensor in the "NRP Power Viewer" dialog.

1. Select "Level" > "RF ON > Off"
2. Select "Clk Syn/Power Sens" > "NRP Power Viewer".




3. If the R&S SMA100B has detected several connected power sensors, select the tab of the sensor you want to use.
4. Select "Zero" to start zeroing of the sensor.
Note: Always turn the RF power off or disconnect the sensor from RF before zeroing, since the function calibrates the power sensor at zero signal power.
The zeroing process takes a few seconds, depending on the power sensor type.
5. Configure additional parameters for the selected sensor as required.

6. Select "State > On".
7. Close the dialog.

To create user correction data with an R&S NRP and the R&S SMA100B

We assume, that the power sensor is connected, assigned and ready for operation.


1. Select "Level" > "User Correction".



2. Select "UCOR Data" > "UCOR Data...."
3. Create a file: "New" > Filename and confirm with "OK".
4. Select the new file with "Select".
5. Select "Edit UCOR Data...".
6. Select "Edit" > "Fill".

The "Fill Table" dialog enables you to fill in the values of the columns automatically.

7. To fill in the frequency column:



- a) Select "Select Column To Fill > Frequency / Hz".
- b) Select "Range > e.g. 15" to determine the number of values.
- c) Select "Start Value > e.g. 1.56 GHz".
- d) Select "Increment Value > e.g. 1 MHz", to determine the frequency steps.
- e) Select "Fill", to insert the frequency values.


The "Fill" function also fills the column of the "Correction Value / dB" values with a predefined value, since empty cells lead to the data loss of the entire line. If you need different values, you can change them manually, or you can use the automatic function "Fill with Sensor" as described in the next steps.

8. Select "Fill with Sensor".

The "Fill User Correction Data With Sensor" dialog provides an overview of the sensor configuration.

9. Select "Execute".

The R&S SMA100B successively sets each frequency point, reads the measured power of the sensor and fills in the value in the correction table.



	Frequency /Hz	Correction Value /dB
0	1 560 000 000.00	-11.51
1	1 561 000 000.00	-11.03
2	1 562 000 000.00	-10.58
3	1 563 000 000.00	-9.80
4	1 564 000 000.00	-9.46

10. Select "Save" to save the data in the file.

11. Close the dialog.

To perform power leveling calibration with user correction data

We assume that a user correction file is available in the user directory of the R&S SMA100B or on a memory stick or in a shared directory.

If you have created and saved the file immediately before this step, the file is loaded in the "User Correction" dialog automatically. Otherwise you can load a previously saved file.

1. Select "Level" > "User Correction".
2. Select "UCOR Data" > "UCOR Data...", if there is no file loaded already.
3. Select the directory and file you want to use.

4. Load the file with "Select".
5. To view the file content, select "Edit UCOR Data...".
6. Select "UCOR Data" > "State" > "On" to apply the user correction values.

When you activate the RF output, the R&S SMA100B considers the user correction data and adjusts the signal level accordingly to compensate external frequency responses.

9 Reference oscillator

The R&S SMA100B is equipped with an internal reference oscillator that generates a reference frequency of 10 MHz. It is used as internal reference source for the synthesizer.

Alternatively, you can apply an external reference signal. If equipped with the required options, the R&S SMA100B can process external reference frequency in the range 1 MHz to 100 MHz and the 1 GHz reference frequency.

Regardless of the used reference source (internal or external), the R&S SMA100B always provides the configured reference frequency at the output. You can use it, for example to synchronize several interconnected instruments, see [Chapter 9.5, "Using the reference frequency for instruments synchronization"](#), on page 297, for an overview of typical test situations.



The reference oscillator settings are not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. They are reset only by factory preset.

9.1 Required options

R&S SMA100B base unit equipped with the following options:


- 100 MHz, 1 GHz ultra low noise reference input and output (R&S SMAB-K703)
- 1 MHz to 100 MHz flexible reference input (R&S SMAB-K704)

For more information, see data sheet.

9.2 Reference frequency settings

Access:


1. Select "Frequency" > "Reference Frequency".



In the "Reference Frequency" tab, you can select the reference frequency signal source and the frequency and synchronization bandwidth mode of an external reference signal.

2. Observe the information on the home screen, "Frequency" tile.
Observe the information on the home screen, "Measurement Setup" tile.

The "Frequency" tile indicates the current reference oscillator configuration, incl. the reference oscillator source, external reference frequency (rounded value) and output connector. A warning symbol in the "Frequency" tile indicates a missing external source.



The remote commands required to define these settings are described in [Chapter 14.17.12, "SOURCE:ROSCillator subsystem"](#), on page 714.

Settings:

Set to Default	293
Source	293
Show Connector	293

Deactivate RF Output (if external reference is missing).....	293
External Reference Frequency.....	293
Variable Reference Frequency.....	294
Synchronization Bandwidth.....	294
Nominal Synchronization Bandwidth.....	294
Minimum Locking Range.....	295
External Tuning Active.....	295
External Tuning Slope.....	295

Set to Default

Calls the default settings.

Remote command:

`[:SOURce] :ROSCillator :PRESet` on page 716


Source

Selects the reference frequency source.

"Internal" Uses the internal reference oscillator, either with calibrated or a user-defined [Adjustment Value](#).

Note: The internal reference frequency automatically uses [Synchronization Bandwidth > Narrow](#). Thus, if you preset this parameter, or set the reference source from "External" to "Internal" manually, the R&S SMA100B sets the bandwidth to "Narrow".

"External" Uses an external reference signal.

Note: If the external reference is missing, the R&S SMA100B issues a warning message and indicates the icon  (external reference missing).

To set the frequency of the external reference, see ["External Reference Frequency"](#) on page 293.

Remote command:

`[:SOURce] :ROSCillator :SOURce` on page 716



Show Connector

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

Deactivate RF Output (if external reference is missing)

Turns off the RF output when the external reference signal is selected, but no signal is supplied.

This function prevents that no improper RF signal due to the missing external reference signal is used for measurements. A message indicates that the RF output is deactivated.

Remote command:

`[:SOURce] :ROSCillator :EXTernal :RFOff [:STATe]` on page 717

External Reference Frequency

Selects the frequency of the external reference signal.

Set the reference output frequency with the parameters in the [Reference output settings](#) dialog.

"10 MHz" Selects 10 MHz for the external reference frequency signal.

"100 MHz, 1 GHz"

Option: R&S SMAB-K703

Selects the external reference frequency.

"Variable"

Option: R&S SMAB-K704

The external reference signal has an arbitrary frequency, within the permissible range from 1 MHz to 100 MHz.

Remote command:

[\[:SOURce\]:ROSCillator:EXternal:FREQuency](#) on page 717

Variable Reference Frequency

Option: R&S SMAB-K704

Sets the variably settable external reference frequency.

Remote command:

[\[:SOURce\]:ROSCillator:EXternal:FREQuency:VARiable](#) on page 717

Synchronization Bandwidth

Selects the synchronization bandwidth for an external reference signal, set with [Source > External](#).

The resulting bandwidth is indicated by the parameter [Nominal Synchronization Bandwidth](#).

Note: If you preset or set the reference source from "External" to "Internal", the synchronization bandwidth is reset to "Narrow".

"Narrow" The internal reference oscillator is synchronized to the external signal with narrow bandwidth.

This setting is recommended if the phase noise of the external signal is worse than the phase noise of the internal OCXO.

"Wide" Synchronizes the internal oscillator to the external signal with the maximum possible bandwidth.

This mode is the recommended standard mode and for precise reference sources of high spectral purity.

Note: If the frequency of the external reference signal is outside the locking range of the internal reference oscillator, spurs due to the difference of the internal and external reference frequency are generated in the reference PLL.

The R&S SMA100B issues an error message.

For more information, see data sheet.

Remote command:

[\[:SOURce\]:ROSCillator:EXternal:SBANDwidth](#) on page 717

Nominal Synchronization Bandwidth

Indicates the nominal synchronization bandwidth for the selected [External Reference Frequency](#) and the [Synchronization Bandwidth](#).

Remote command:

`[:SOURce] :ROSCillator:EXTernal:NSBandwidth?` on page 718

Minimum Locking Range

Indicates the minimum locking range for the selected [External Reference Frequency](#) and the [Synchronization Bandwidth](#).

Remote command:

`[:SOURce] :ROSCillator:EXTernal:MLRange?` on page 718

External Tuning Active

For "Source > Internal", activates the EFC (external frequency control).

EFC is a function that transforms an external tuning voltage into frequency shift, where the value range of the resulting frequency is a technical characteristic listed in the data sheet.

See the data sheet also for information on the sensitivity, input voltage range, impedance and maximum bandwidth for external tuning signal.

Remote command:

`[:SOURce] :ROSCillator:INTernal:TUNing[:STATe]` on page 716

External Tuning Slope

Sets the sensitivity of the external tuning voltage.



Remote command:

`[:SOURce] :ROSCillator:INTernal:TUNing:SLOPe` on page 716

9.3 Reference output settings

Access:

1. Select "Frequency" > "Reference Frequency".
2. Select "Reference Output".

Reference Output 10 MHz	 Show Connector ...
Reference Output 1GHz Off	 Show Connector ...

In the "Reference Output" tab, you can set the reference frequency value at the output connectors.

As a result of parameter dependencies, "Preset This Parameter" sometimes does not affect output dialogs.

The remote commands required to define these settings are described in [Chapter 14.17.12, "SOURce:ROSCillator subsystem"](#), on page 714.

Settings:

Reference Output/1 GHz Reference Output.....	296
Show Connector.....	296

Reference Output/1 GHz Reference Output

Selects frequency reference output signal for downstream instruments.

"Off"	Deactivates the reference signal output.
"10 MHz"	Derives a signal with 10 MHz frequency from the internal reference oscillator and provides this signal at the output.
"100 MHz"	Option: R&S SMAB-K703 Provides the 100 MHz reference frequency signal at the output.
"1 GHz"	Option: R&S SMAB-K703 Provides the 1 GHz reference frequency signal at the output.
"Input Signal (loop through)"	Option: R&S SMAB-K703/-K704 Passes the external reference frequency to the output directly.

Remote command:

[\[:SOURce\]:ROSCillator:OUTPut:FREQuency:MODE](#) on page 718

[\[:SOURce\]:ROSCillator:OUTPut:ALternate:FREQuency:MODE](#) on page 719



Show Connector

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

9.4 Adjustment settings

Access:

1. Select "Frequency" > "Reference Frequency".
2. Select "Adjustment".

Adjustment Active

☒

Adjustment Value

0

Settings:

Adjustment Active.....	296
Adjustment Value.....	297

Adjustment Active

Selects the adjustment mode.

"Off"	Uses the calibrated internal reference frequency.
-------	---------------------------------------------------

"On" Allows you to apply a deviation to the internal reference frequency, according to your requirements.
Enter the value in the [Adjustment Value](#) field.

Remote command:

[\[:SOURce\]:ROSCillator\[:INTernal\]:ADJust\[:STATe\]](#) on page 720

Adjustment Value

Sets a user-defined adjustment value for the internal reference frequency. This value takes effect when it is activated with [Adjustment Active](#).

- "0" represents the calibrated state.
- The setting range depends on the reference oscillator type and its factory calibration value.

Note:

The setting is not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. It is reset only by factory preset.

Remote command:

[\[:SOURce\]:ROSCillator\[:INTernal\]:ADJust:VALue](#) on page 719

9.5 Using the reference frequency for instruments synchronization

Test setups with two or more instruments often require that the instruments use a common reference frequency. Depending on the availability of external reference frequency source and its quality, the instruments are connected and configured in different ways.

This section gives an overview of the possible test setups and the related settings. The following situations are considered:

- External reference source is not available or the **built-in reference oscillator** is of better quality than the external source
(see ["Distributing the internal 10 MHz reference signal to further instruments"](#) on page 298)
- **Clean external reference source** with quality exceeding the quality of the built-in reference oscillator
(see ["Using external reference source"](#) on page 299)
- **Interfered or noisy external reference signal**
(see ["Deriving 10 MHz from the external reference frequency"](#) on page 300)
- **1 GHz reference coupling** for phase coherence of the RF signals with enhanced long-term phase stability
(see ["Sharing the 1 GHz reference frequency to obtain phase-coherent signals"](#) on page 298)

Connectors overview

Use the "Show Connector" function to indicate the connector on the front/real panel:

- ["Ref In/Ref Out"](#) on page 41

- 1GHz "Ref In/Ref Out" on page 41
- "EFC" on page 42

Distributing the internal 10 MHz reference signal to further instruments

The internal reference oscillator provides the reference frequency:

- Internal $f_{\text{ref}} = 10 \text{ MHz}$ (10 MHz at connector Ref Out)
- Source = "Internal"
- Reference Output/1 GHz Reference Output = "10 MHz"
- Optional:
 - External Tuning Active = "On"
 - External Tuning Slope = "Low"




Figure 9-1: Synchronizing instruments using the internal 10 MHz reference signal of the R&S SMA100B

EFC = External frequency control
 EFC, Ref In, Ref Out = Connectors

In phase noise measurement systems, for example, you can also use the EFC (external frequency control) function and shift the frequency. EFC is a function that transforms an external tuning voltage into frequency shift, where the value range of the resulting frequency is a technical characteristic listed in the data sheet. See the data sheet also for information on the sensitivity, input voltage range, impedance and maximum bandwidth for external tuning signal.

Consider the following interdependency:

- EFC in combination with an external PLL
 If the EFC is applied in combination with an external PLL (phase locked loop), the PLL bandwidth must be smaller than the bandwidth of the external tuning signal.
- FM-DC mode
 If the measurement requires higher PLL bandwidth, we recommend that you use the external FM modulation (DC coupling) in low noise mode.
 The FM-DC mode yields a fixed tuning sensitivity that is independent of the RF output frequency and corresponds to the selected FM deviation.

Sharing the 1 GHz reference frequency to obtain phase-coherent signals

Compared to 10 MHz, a 1 GHz reference signal significantly improves the achievable phase stability between two signal sources. Because the synchronization frequency increases by a factor of 100, the relative phase fluctuations between the sources can be reduced.

1 GHz at connector Ref In 1GHz and 1 GHz at Ref Out 1GHz

- External $f_{\text{Ref}} = 1 \text{ GHz}$
- **Source** = "External"
- **External Reference Frequency** = "1 GHz"
- **1GHz Reference Output** = "1 GHz"

Using external reference source

If you have a clean external reference signal with 10 MHz or 100 MHz frequency, for example, you can **directly pass it to the output**. The signal quality remains the same.

10 MHz, 100 MHz at connector Ref Out and Ref In

- External $f_{\text{Ref}} = 10 \text{ MHz}$ or 100 MHz
(earlier RF hardware versions: 5 MHz, 10 MHz, 13 MHz)
- **Source** = "External"
- **Reference Output** = "10 MHz, 100 MHz" or "Input Signal (loop through)"
(earlier RF hardware versions: 5 MHz, 10 MHz, 13 MHz)
- Set the synchronization bandwidth according to the requirements of the application.




Figure 9-2: Synchronizing instruments with a 10 MHz external reference signal

Ref. Frequency Source = e.g., Rohde & Schwarz signal analyzer

f_{Ref} = 10 MHz, 100 MHz, 1 MHz to 100 MHz external reference frequency

Ref In, Ref Out = Connectors

You can forward reference frequency between 1 MHz and 100 MHz directly to the output in the same way.

- External $f_{\text{Ref}} = 1 \text{ MHz to } 100 \text{ MHz}$
(**1 MHz to 100 MHz at connector Ref In and Ref Out**)
- **Source** = "External"
- **Variable Reference Frequency** = "Variable"
- **External Reference Frequency** = current external frequency
- **Reference Output** = "Input Signal (loop through)" or specify the reference frequency the synchronized instrument supports
- Set the synchronization bandwidth according to the requirements of the application.

Deriving 10 MHz from the external reference frequency

10 MHz reference frequency can be derived from the following external reference signals:

- 10 MHz from internal oscillator locked to external input
- 100 MHz and 1 GHz external reference signals
- External reference signal between 1 MHz and 100 MHz
- If the external reference signal is interfered (noisy)




Figure 9-3: Synchronizing instruments with 10 MHz (derived from an external reference frequency)

Ref. Frequency Source = e.g., Rohde & Schwarz signal analyzer

f_{Ref} = 10 MHz, 100 MHz, 1 MHz to 100 MHz, 1 GHz** external reference frequency

** = 1 GHz uses Ref In 1 GHz connector

Ref In, Ref Out = Connectors

1 GHz, 1 MHz to 100 MHz at connector Ref In 1 GHz/Ref In and 10 MHz at Ref Out

- E.g., external Ref. f_{ref} = 100 MHz
- **Source** = "External"
- **External Reference Frequency** = "100 MHz"
- **Reference Output/1 GHz Reference Output** = "10 MHz"
- **Synchronization Bandwidth** = "Narrow"

10 Clock synthesis

The clock synthesis provides a separate system clock with a freely selectable frequency for test setups that require an additional clock reference. For example, in a test setup that uses an A/D converter, the required system clock for data sampling can be provided without the need of additional signal generator.

Output connectors

The generated clock reference is synchronized to the selected reference clock of the signal generator (internal or external). The differential signal is output at the [Clk Syn] and [Clk Syn N] connectors.

Required options


- Option frequency R&S SMAB-B10x
- Option differential clock synthesis up to 3 GHz R&S SMAB-B29
- Option clock synthesis extension 6 GHz R&S SMAB-K722 (requires at least R&S SMAB-B106)

For more information, see data sheet.


Settings

Access:


1. Select "Clk Syn/Power Sens > Clock Synthesis".



2. Select "User Variation" to set the step width to be used when setting the clock frequency using the rotary knob.



3. Observe the information on the home screen, "Clk Syn/Power Sens" tile.



The "Clk Syn/Power Sens" tile indicates that clock synthesis is activated and gives an overview of the key parameters.

Settings

State.....	302
Output Type.....	302
Frequency.....	303
Level.....	303
DC Offset State.....	303
DC Offset.....	304
Voltage.....	304
Delta Phase.....	304
Reset Delta Phase Display.....	304
User Variation.....	304
L Variation Active.....	304
L Variation Step.....	304

State

Activates/deactivates generation of a system clock.
The signal is output at the [Clk Syn] connector.
Remote command:
:CSYNthesis:STATe on page 484

Output Type

Defines the shape of the generated clock signal.

"Single-Ended/Differential Sine"

Sine signals with user-definable amplitude.

"Differential Square"

Squared signal with fixed amplitude.

"CMOS"

CMOS-like signal with user-definable amplitude and limited frequency range.

Remote command:

`:CSYNthesis:OTYPe` on page 485

Frequency

Sets the frequency of the generated clock signal.

Output Type	Min. frequency	Max. frequency
Single-ended sinus Differential sinus	100 kHz	6 GHz
Differential square	10 MHz	6 GHz
CMOS	100 kHz	200 MHz

Remote command:

`:CSYNthesis:FREQuency` on page 485

Level

For **Output Type** = "Single-Ended/Differential Sine", sets the amplitude of the generated clock signal.

Remote command:

`:CSYNthesis:POWer` on page 485

DC Offset State

Activates a DC offset for both clock synthesis signal outputs.

The DC offset can be used e.g. to shift the clock synthesis output signal into the trigger threshold of some logic elements.




Figure 10-1: Example: DC offset = 1.65V and Output Type = Differential Square

Remote command:

`:CSYNthesis:OFFSet:STATe` on page 486

DC Offset

Sets the value of the DC offset for both clock synthesis signal outputs.

Remote command:

`:CSYNthesis:OFFSet` on page 486

Voltage

For **Output Type** = "CMOS", sets the high-level of the output signal.

Remote command:

`:CSYNthesis:VOLTage` on page 486

Delta Phase

Shifts the phase of the generated clock signal.

Remote command:

`:CSYNthesis:PHASe` on page 486

Reset Delta Phase Display

Resets the parameter **Delta Phase**.

User Variation

Defines and activates a user-defined step width for varying the frequency or level with the rotary knob.

If disabled, the step width varies in steps of one unit at the cursor position.

Variation Active ← User Variation

Activates the set user-defined step width.

Remote command:

`:CSYNthesis:FREQuency:STEP:MODE` on page 487

`:CSYNthesis:POWEr:STEP:MODE` on page 487

Variation Step ← User Variation

Sets the user-defined step width.

Remote command:

`:CSYNthesis:FREQuency:STEP` on page 488

`:CSYNthesis:POWEr:STEP[:INCRement]` on page 487

11 File and data management

The R&S SMA100B uses files to save all instrument data. The instrument allows you to save and to load instrument settings, and to import and to export user data for processing in another instrument or later. Finally, you can create a screenshot of the current settings displayed on the screen and save it as a file.

This section focuses on the functions provided for managing of user data files and covers the topics listed below.

For information on the related remote control commands, refer to [Chapter 14.5, "Memory subsystem"](#), on page 469.

For information on how to save the displayed setting in a file, refer to [Chapter 11.10, "Creating screenshots of current settings"](#), on page 333.

• About the file system	305
• Restoring the (default) instrument configuration	308
• Protecting data	313
• Saving and recalling instrument settings	314
• Accessing files with user data	318
• Exporting and importing remote command lists	320
• Loading, importing and exporting lists	321
• Using the file manager	321
• How to transfer files from and to the instrument	327
• Creating screenshots of current settings	333

11.1 About the file system

Depending on the contained information, two file groups can be distinguished: system and user files.



Due to security reasons, system files and the system directory are protected and therefore not accessible.

The scope of this section is only the files with user data.

This section is an overview of the R&S SMA100B file system and covers the following topics:

- ["Types of user data"](#) on page 306
- ["File storage location"](#) on page 306
- ["File handling"](#) on page 307
- ["File naming conventions"](#) on page 307
- ["File extensions"](#) on page 307
- ["File contents"](#) on page 308

Types of user data

Depending on the **content**, the **user data** can be roughly divided into the following data types:

- *Settings*, e.g. the current instrument settings, can be saved and loaded later or used in other instrument of the same kind.
See [Chapter 11.4, "Saving and recalling instrument settings"](#), on page 314
- *SCPI scripts*, a series of commands that can be run to perform a task.
See [Chapter 11.6, "Exporting and importing remote command lists"](#), on page 320
- Externally or internally generated *lists*, e.g. user correction lists, or data lists can be loaded in the instrument.
See [Chapter 11.7, "Loading, importing and exporting lists"](#), on page 321 and [Chapter 11.5, "Accessing files with user data"](#), on page 318

Depending on the **data storage method**, user data can be:

- *Persistent*, i.e. user files that are recorded on the data storage.
Data is preserved when instrument is powered off and can be accessed and modified subsequently.
- *Temporary*, i.e. volatile data that the instrument retains while it is powered on.
Volatile data is immediately lost when the R&S SMA100B is switched off.

File storage location

Without any additional measures, the R&S SMA100B stores user files on the internal memory, the removable memory, or if connected, on a memory stick.

Both, the user directory `/var/user/` on the internal memory or the `/usb/` directory on the memory stick, can be used to **preserve** user-defined data. Any directory structure can be created.

The `/var/volatile` directory serves as a RAM drive and can be used to protect sensitive information. The data is available **temporarily**.

If option R&S SMAB-B85 is installed, the R&S SMA100B maps the user directory to the removable memory. If a memory is mounted, user data is saved there. Otherwise user data is redirected to the volatile memory.

Default storage location

The R&S SMA100B stores user data in the user directory.

Depending on the installed options, the user directory is physically located on the internal memory or on the removable memory.

In the file system, user directory is always indicated as `/var/user/`.

In manual control, you access this directory via the "File Manager", see [Chapter 11.8, "Using the file manager"](#), on page 321. In remote control, you can query it with the command `:SYSTem:MMEMory:PATH:USER?`.

To query and change the default directory used for mass storage, use the command `:MMEMory:CDIRectory`.

File handling

To *access files* and the file system of the instrument or to use the general file management functions such as copying and moving data, use the standard "File Manager" dialog.

See [Chapter 11.8, "Using the file manager"](#), on page 321.

To *transfer files* from and to the instruments or to exchange files, use one of the following alternatives:

- Connect a memory stick to one of the USB interfaces.
The instrument recognizes automatically a connected memory stick and assigns the `/usb/` drive to it.

- Connect the instrument to a LAN.

An instrument connected to a LAN supports two standard file transfer methods from a remote client:

- FTP (file transfer protocol)
- File sharing according to the SAMBA/SMB (server message block) protocol.

Both file transfer methods access the folder `/user`, that is the `/var/user/` folder on the instrument.

For step-by-step description, see [Chapter 11.9, "How to transfer files from and to the instrument"](#), on page 327.

- Map a network folder or a computer to an instrument connected to a LAN.

A mapped network folder is indicated as `/shares/<"Local Folder">`.

For step-by-step description, see [Chapter 11.8.4, "How to map a network folder"](#), on page 325.

File naming conventions

To enable files to be used in different file systems, consider the following file naming conventions:

- The *filename* can be of any length and *is case-sensitive*, i.e it is distinguished between uppercase and lowercase letters.
- All letters and numbers are permitted (numbers are, however, not permitted at the beginning of the filename).
- Avoid using special characters.
- Do not use slashes "\" and "/". These symbols are used in file paths.
- Avoid using the following filenames: `CLOCK$`, `CON`, `COM1` to `COM4`,
`LPT1` to `LPT3`, `NUL` or `PRN`
They are reserved by the operating system.

File extensions

The R&S SMA100B distinguishes the files according to their extensions; each type of file is assigned a specific file content and also a specific file extension. The extension is usually of no consequence to you since access to the files occurs in the individual dialogs where only the relevant type of file is available. For example, files with user correction data can only be saved and loaded in the "UCOR" dialog.

See [Chapter B, "Extensions for user files"](#), on page 808 for an overview of the supported file extensions.

File contents

To maintain the file size and to accelerate the loading and processing times, not all instrument settings but rather the settings in state different than the preset one are saved. Considered is also configuration data for the operating elements and lists with user data, e.g. dialog positions and a list of user correction data. However, if a list data is part of the instrument settings, a reference to this list is saved, not the list itself.

This approach ensures that the created files contain only relevant information and allows you to transfer instrument settings even between different equipped signal generators. During the recall process, the instrument interprets only the relevant settings; all non-referenced parameters are set to their preset values. Error messages indicate the settings which cannot be implemented, like referencing non-existing lists or the attempt to activate settings which are not supported by the instrument.



Network settings and remote settings cannot be saved and restored.

11.2 Restoring the (default) instrument configuration

The R&S SMA100B has various options to set default settings. You can preset the R&S SMA100B to an initial state at any time as a known starting point for configurations. It is often useful as a first step in troubleshooting when unusual results arise.

The graph on [Figure 11-1](#) shows the impact of the particular reset functions.




Figure 11-1: Parameter and operating modes, reset by the respective preset functions

Overview of the characteristics of the preset functions

Select the preset option that most fits to your particular application:



- [Preset]
It is the most frequently used function.
A [Preset](#) executes a defined instrument setup to provide an initial instrument state as a basis for a new configuration. It resets all parameters and switching states, including also the states of inactive operating modes.
Network, remote access or system settings are retained.

- ▶ To execute a preset, press the [Preset] key at the front panel.




- "Set to Default"
[Set To Default](#) relates to individual dialogs or tabs and resets the associated settings of the corresponding dialog. All other settings are retained.

- ▶ To reset the grouped settings, click "Set To Default".



- "Preset this parameter"
Sets a single parameter to its default value.
- ▶ To reset an individual parameter: Open its context-sensitive menu and select "Preset this parameter..."



- "Factory Preset"
A factory preset is the most profound preset function that resets almost all instrument settings, including reference oscillator, network and remote access settings.
Retained are the following settings:
 - Security, password, and settings protected by these passwords
 - User-defined data, like setups or data lists
 - Settings that relate to an integration of the instrument in a measurement setup.
- ▶ To restore the factory defaults, select [System Config > Setup > Settings > Factory Preset](#).

Note: Perform a "Factory Preset" only if it is necessary. After a "Factory Preset", the network connection to the instrument no longer exists.

Presetting the instrument to a user-defined instrument state

The reset functions set the parameters and operating modes to default values predefined by the factory. Alternatively to these default settings, you can:

- Define user-specific recall settings to be restored after a preset (see [Chapter 11.2.3, "How to recall user settings automatically after preset"](#), on page 312)
- Store and reload user-defined instrument states (see [Chapter 11.4.2, "How to save and recall instrument settings"](#), on page 317)

Mark / Do not mark parameters changed from preset

To survey the current state of the settings concerning default values, the R&S SMA100B offers a feature that visually identifies deviations from the default values.

For more information, see [Chapter 11.2.2, "How to identify parameters which are not in a preset state"](#), on page 311.

11.2.1 Preset, set to default and factory preset settings

Preset	310
Set To Default	310
Preset this Parameter	310
Execute Factory Preset	311

Preset

Resets all parameters and switching states, and closes all opened dialogs.

Note:

In contrast to the [Preset] key, the SCPI commands `*RST` and `:SYSTEM:PRESet` do not close open dialogs in the GUI.

Consider also the following possibilities:

- You can define the settings that are restored when you preset the instrument (see [Chapter 11.2.3, "How to recall user settings automatically after preset"](#), on page 312)
- You can reset the instrument to the factory state (see ["Execute Factory Preset"](#) on page 311)

See also [Table 11-1](#) that contains the key parameters that are reset by the corresponding preset functions.

Remote command:

`*RST` on page 466

Set To Default

Resets the associated settings of the corresponding dialog or tab.

Preset this Parameter

Restores the default value of a single parameter.

Execute Factory Preset

Resets the instrument to its factory settings.

Note: "Factory Preset" retains all security settings and does not delete any user files like setups or user data.

See also [Table 11-1](#) that contains the key parameters that are reset by the corresponding preset functions.

Remote command:


`:SYSTem:FPReset` on page 469

11.2.2 How to identify parameters which are not in a preset state

To recognize the current state of the settings related to their default values at the first glance, enable a function that visually identifies parameters in states different than preset.

To activate this display:

1. Open the context-sensitive menu (touch and hold the screen anywhere in the GUI of the R&S SMA100B).
2. Select "Mark all parameters changed from preset".



If enabled, the corresponding settings are marked.

Example:

Frequency	4.000 000 000 000 GHz	
Offset	10.000 000 kHz	Multiplier 1.000
User Variation		
Variation Active	<input checked="" type="checkbox"/>	Variation Step 1.000 000 000 MHz

Figure 11-2: Labeled parameters show that the value deviates from its default

Frequency = changed (default = 1 GHz)
 Offset = changed (default = 0 kHz)
 Multiplier = unchanged
 Variation active = changed (default = disabled)
 Variation step = unchanged

11.2.3 How to recall user settings automatically after preset

You can define the settings that are restored when you preset the instrument.

1. Configure the settings as required. Save them as described in [Chapter 11.4.2, "How to save and recall instrument settings"](#), on page 317.
2. Save the settings as a file with the predefined filename `UserPreset.savrc1.txt`. Save this file in the directory `/var/user/`.

The filename `UserPreset.savrc1.txt` and the directory `/var/user/` are mandatory.

Now when you press the [Preset] key or send the `*RST` command to the instrument, the defined settings are restored.

An "Info" message appears and confirms, that a file with user-defined preset setting is loaded.

11.2.4 Reference

See [Table 11-1](#) for an overview of the main generator settings that are affected by the corresponding preset functions. While the regular [Preset] key primarily resets the signal relevant parameters of the instrument, the "Factory Preset" affects almost all instrument settings.

For information on the default values of further parameters, refer to the description of the corresponding remote commands.

Table 11-1: Key parameters affected by preset and factory preset

Parameter	Preset value	Preset	Factory Preset
RF frequency	1 GHz	x	x
RF level (RF output)	off	x	x
RF OFF mode	-	-	x
Offsets	0	x	x
Modulation state	off	x	x
Uninterrupted level settings	off	x	x
Level attenuator mode	auto	x	x
Level ALC (internal level control)	auto	x	x
Level UCOR (user correction)	off	x	x
LF output state	off	x	x
Sweep state	off	x	x
List mode state	off	x	x
Reference frequency settings (reference oscillator)	-	-	x

Parameter	Preset value	Preset	Factory Preset
Power on settings (Level/EMF)	-	-	x
Network settings	-	-	x
Hostname	-	-	x
GPIB address	-	-	x
Start/Stop display update	-	-	x
Display and keyboard settings	-	-	x
Password and settings protected by passwords (e.g. disabled LAN or USB)	-	-	-
Security settings	-	-	-
User files (setups ²⁾ , data lists, etc.)	-	-	-

- ²⁾ `UserPreset.savrcltxt` is renamed as `UserPresetInactive.savrcltxt`; an existing file with the same name is overwritten.



If the default values in the "Remote Access" dialog had been changed, a factory preset via remote control (`:SYSTem:FPReset`) terminates the connection to the instrument. Security settings are never reset.

Resets all parameters and switching states, and closes all opened dialogs.

11.3 Protecting data

During operation, the R&S SMA100B saves user data permanently in the user directory, see ["File storage location"](#) on page 306.

To protect any classified data and to avoid saving any sensitive data on the R&S SMA100B permanently, you have the following options:

- Activate the **volatile mode**. This mode redirects user data to the volatile memory, see ["Volatile Mode"](#) on page 364.
The internal memory and the removable memory are write-protected.
Once you power off the instrument for at least five minutes, all volatile memory modules lose their contents.
Instead, you can redirect the user data to an **external memory device**, as, e.g., a USB stick.
See also:
 - ["Default storage location"](#) on page 306
 - ["Volatile Mode"](#) on page 364
 - [Chapter 11.9.4, "Using a USB storage device for file transfer"](#), on page 332
- If the R&S SMA100B is equipped with the **removable memory** R&S SMAB-B85 and an SD card is inserted:

- If the volatile mode is disabled (default setting) the R&S SMA100B **saves user data permanently and only on this storage medium**.
You can access data saved on the removable memory just as data saved in the `/var/user/`.
- If the volatile mode is enabled, the R&S SMA100B redirects user data to the **volatile memory** (SDRAM).
The volatile memory loses its contents when you power off the instrument.
- Save user files **temporarily in the `/var/volatile` directory**, which remains available only until the instrument is turned off.
You can access data in the volatile memory just as data that is saved permanently in the `/var/user/`.
See also [Chapter 11.8.3, "How to display all saved files"](#), on page 325.



For detailed information on how to protect the instrument and sensitive data from unauthorized access, see the Instrument Security Document on the product website.

11.4 Saving and recalling instrument settings

Possibly you would like to restore or repeat a signal generation you performed under specific conditions on the instrument. Or, in a test setup with more than one signal generator, you want to transfer the used settings to another R&S SMA100B. In these cases, you can save and recall instrument and user settings, and possibly other related data.

Save/Recall the complete instrument settings

Two different methods are available for managing *complete instrument settings*:

- Immediate (quick) Save/Recall
A defined set of instrument settings are saved or recalled quickly in just one step, without defining a filename or storage location. This function enables a fast switching between different instrument settings.
- Save/Recall in files with user-defined names
The defined set of instrument settings are saved to a definable storage location. The file extension is `*.savrc1.txt`.
Settings files created in this way are visible in the file system and accessible with the supported methods for file handling.


In the general case, a recall process replaces the instruments settings with the saved values. An exception is the frequency and level settings. During recall of the instrument settings, it is possible to retain the current settings or to overwrite them with the saved values.

11.4.1 Save/recall settings

To access the dialog for saving and loading the complete instrument settings

1. Select "System Config > Save/Recall".
2. Select "Operation Mode > Save or Recall" to access the corresponding settings.

The provided settings for both operations are similar and closely related.



Settings:

Operation Mode.....	315
Directory, File List and Filename.....	315
Recent files.....	316
Show SCPI List.....	316
SCPI List.....	316
Save.....	316
Save Immediate x.....	316
Exclude Frequency.....	317
Exclude Level.....	317
Recall.....	317
Recall Immediate x.....	317
File Manager.....	317

Operation Mode

Accesses the settings for storing ("Save") and loading ("Recall") of the instrument settings. Also, you can import SCPI-Files ("SCPI-Import") or export SCPI files ("SCPI-Export").

See [Chapter 11.6, "Exporting and importing remote command lists"](#), on page 320.

Directory, File List and Filename

Note:

You access this generic standard function each time you perform one of the following:

- Save or load (settings) files
- Define a folder in that these files are saved
- Navigate through the file system.

The dialog name changes depending on the context. The provided functions are self-explanatory and similar.

Use the settings for example as follows:

- To navigate through the file system, use the directory tree.
- To create a file, load and save files, use the dedicated functions ["New"](#), ["Select"](#), [Save](#), and [Recent files](#).
- To access the general data list editor, use the ["Edit"](#) button (see also [Chapter 7.7, "List editor"](#), on page 204).
- To perform standard file management functions, like create directories, move, copy, delete files and/or directories, use the standard "File Manager" function (see [Chapter 11.8, "Using the file manager"](#), on page 321).

Remote command:

To list all files in a directory:

[:MMEMory:CDIRectory](#) on page 475

[:MMEMory:CATalog?](#) on page 474

[\[:SOURce\]:CORRection:CSET:CATalog?](#) on page 661

Recent files

Displays the files last used.

Show SCPI List

Opens the "SCPI List", which lists the current settings of the R&S SMA100B as SCPI commands.

The R&S SMA100B provides this function for [Operation Mode > SCPI-Export](#).

SCPI List

Contains a list of all SCPI commands corresponding to the current instrument settings.

See also ["How to create a SCPI list with the current instrument settings in one step"](#) on page 449

Save

Saves the current instrument settings under the defined filename.

Remote command:

[:MMEMory:STORe:STATe](#) on page 479

Save Immediate x

Stores the current instrument setting in one of the intermediate memories.

These instrument settings are retained until a different instrument setting is stored in the intermediate memory. When the instrument is switched off, the contents of the intermediate memories are retained.

Remote command:

[*SAV](#) on page 466

Exclude Frequency

The current frequency is retained when a stored instrument setting is loaded.

Remote command:

`[:SOURce<hw>] :FREQuency [:CW | FIXed] :RCL` on page 667

Exclude Level

The current level is retained when a stored instrument setting is loaded.

Remote command:

`[:SOURce<hw>] :POWer [:LEVel] [:IMMediate] :RCL` on page 712

Recall

Restores the selected configuration.

During recall, the instrument considers all related settings, for example sweeps in active state or lists. An error message indicates the settings which cannot be implemented.

Remote command:

`:MMEMory:LOAD:STATe` on page 477

Recall Immediate x

Loads the selected configuration from one of the intermediate memories. A message appears if no instrument configuration is stored in this memory.

Remote command:

`*RCL` on page 466

File Manager

Accesses the "File Manager" dialog, see [Chapter 11.8, "Using the file manager"](#), on page 321.

11.4.2 How to save and recall instrument settings

Instrument settings can be saved to a file and loaded again later, so that you can repeat the tests with the same settings.

To access and recall instrument setups quickly

- Assign the appropriate action to the [**★** (User)] key.
See [Chapter 12.2.4, "How to assign actions to the \[**★** \(User\)\] key"](#), on page 350.

To save and recall instrument settings

1. Select "System Config > Save/Recall" > "Operation Mode > Save".
2. Select "Save Immediate 1".
The instrument saves its settings in the intermediate memory 1. The filename and the storage location cannot be changed.
3. Adapt the instrument settings as required. Select "Save Immediate 2"
4. To restore the settings, select the "Operation Mode > Recall"

5. Select "Recall Immediate 1"

The instrument is restored to the previous state.

6. Select "Recall Immediate 2" to switch to the settings saved in the second file.

To save complete instrument settings

1. Select "System Config > Save/Recall" > "Operation Mode > Save".
2. In the file selection dialog, select a filename and storage location for the settings file.
3. Select "Save".

A file with the defined name and path and the extension *.savrc1.txt is created.

To restore instrument's configuration

Save the configuration as described in ["To save complete instrument settings"](#) on page 318.

1. To restore settings, select "System Config > Save/Recall" > "Operation Mode > Recall".
2. To retain the current frequency and level settings, enable "Save/Recall > Exclude Frequency/Level"
3. In the file selection dialog, select the filename and storage location of the settings file.

The settings are restored, but the frequency and level settings are retained; you can repeat the signal generation with the same settings.

See also [Chapter 11.2.3, "How to recall user settings automatically after preset"](#), on page 312.

11.5 Accessing files with user data

Signal generation in list mode, the generation of pulse train signals or applying user correction values use data from list files. Whenever a list file is required as a data source, the instrument provides direct access to the standard "File Select" function. This function enables you to select, create and edit the list files.

11.5.1 File select settings

The "File Select" dialog opens automatically each time the signal generation requires list file as data source.

To access a loadable data list file

1. Select "Sweep" > "List Mode Data" > "List Mode" = "Data".

A file select dialog for loading, creating and modifying a file opens.



Tip: The name of the dialog is context-sensitive and differs depending on the particular function this dialog is from. However, the provided functions are similar.

2. To load an existing file:
Navigate through the file system.
Select the file and confirm with "Select".
3. To create a file, for example if there is no data list file specified:
Navigate through the file system.
Select "New" and specify the filename.
A new empty file is created and saved in the selected folder.
4. To edit an existing or newly created file:
Navigate through the file system.
Select the file and select "Edit".

The standard "Data List Editor" dialog opens
5. Edit the file content.
Confirm with "Save".

Settings:

Directory, File List and Filename.....	319
Functions for handling of data lists.....	320
Recent files.....	320
File Manager.....	320

Directory, File List and Filename

Note:

You access this generic standard function each time you perform one of the following:

- Save or load (settings) files
- Define a folder in that these files are saved
- Navigate through the file system.

The dialog name changes depending on the context. The provided functions are self-explanatory and similar.

Use the settings for example as follows:

- To navigate through the file system, use the directory tree.
- To create a file, load and save files, use the dedicated functions ["New"](#), ["Select"](#), [Save](#), and [Recent files](#).
- To access the general data list editor, use the ["Edit"](#) button (see also [Chapter 7.7, "List editor"](#), on page 204).
- To perform standard file management functions, like create directories, move, copy, delete files and/or directories, use the standard "File Manager" function (see [Chapter 11.8, "Using the file manager"](#), on page 321).

Remote command:

To list all files in a directory:

[:MMEMory:CDIRectory](#) on page 475

[:MMEMory:CATalog?](#) on page 474

[\[:SOURce\]:CORRection:CSET:CATalog?](#) on page 661

Functions for handling of data lists

Provided are the following standard functions for file handling:

"Select"	Select and load the file. Remote command: [:SOURce<hw>]:LIST:SElect on page 697 [:SOURce<hw>]:PULM:TRAI:n:SElect on page 611 [:SOURce<hw>]:CORRection:CSET[:SElect] on page 660
"New"	Creates file with the specified "Filename". To confirm, select "OK"; use "Cancel" to undo the operation. To edit the file content, select "File Select > Edit".
"Edit"	Accesses the "Data List Editor" and loads the selected file for editing

Recent files

Displays the files last used.

File Manager

Accesses the "File Manager" dialog, see [Chapter 11.8, "Using the file manager"](#), on page 321.

11.6 Exporting and importing remote command lists

To set specific instrument settings or perform tasks automatically, you can create scripts or import scripts that contain the settings in the form of remote control command sequences.

The R&S SMA100B also offers a SCPI macro recorder with code generator that is used to record manual settings and create an executable script, see [Chapter 13.13.4, "How to record / create SCPI lists"](#), on page 447.

Completed scripts are saved in files and possibly converted to different formats, depending on the used language of the source code.

The R&S SMA100B supports the following commonly used languages:

- Plain SCPI: *.txt
- MATLAB: *.m
- NICVI: *.c
- Python: *.py

It is also possible to convert the SCPI command list to a user-specific language, see [Chapter 13.13.5, "How to convert and save SCPI lists"](#), on page 450.

11.7 Loading, importing and exporting lists

The R&S SMA100B provides built-in editors for creating list files, for example for the list mode or lists with user correction data. You can also create or evaluate them with an external application. The instrument provides interfaces with the following functionality:

- Import and export list files in a standard ASCII format file

Lists are saved and loaded in the corresponding dialogs. For example, the user correction data list is created and saved in the "User Correction" dialog.

11.8 Using the file manager

The "File Manager" is a tool similar to a standard Windows Explorer. It helps you manage mass storage media and files saved on the R&S SMA100B.


You can perform the following tasks:

- Copying multiple files from disk to other media
See [Chapter 11.9, "How to transfer files from and to the instrument"](#), on page 327
- Copying files into another directory
See [Cut, Copy&Paste and Delete](#)
- Renaming and deleting files
- Creating directories
See [Create New Directory](#)
- Mapping shared network folders
See [Chapter 11.8.4, "How to map a network folder"](#), on page 325
- Displaying saved files
See [Chapter 11.8.3, "How to display all saved files"](#), on page 325

Access:

- Select "System Config > Save/Recall" > "File Manager".

Tip: Each "Save/Recall" dialog and each "File Select" dialog provides a quick access to the "File Manager", i.e. whenever you select data lists or files with user data.



The "File Manager" dialog provides all standard functions required for file management. It displays the contents of the selected folder on the R&S SMA100B and provides functions to rename, delete, copy, or move individual files.

11.8.1 File manager settings

Access:

- Select "System Config > Save/Recall" > "File Manager".

Settings:

Map Network Share.....	322
File Type.....	322
Directory and Filename.....	323
Cut, Copy&Paste and Delete.....	323
Rename	323
Create New Directory.....	323

Map Network Share

Accesses the [Map network share settings](#) dialog where you can map one or more network folders.

See also [Chapter 11.8.4, "How to map a network folder"](#), on page 325.

File Type

Selects the file type to be listed. If a file type with a specific file extension is selected, only files with this extension are listed.

See [Chapter B, "Extensions for user files"](#), on page 808 for an overview of the supported file extensions.

Directory and Filename

Selects the directory in which the file to be deleted or copied is located. The dialog lists all files in this directory. Selected files are highlighted. The path is indicated above the directory tree.

Unlike the "Save/Recall" and "File Select" dialogs, the "File Manager" displays the full filenames including extensions.

Remote command:

[:MMEMory:CDIRectory](#) on page 475

Cut, Copy&Paste and Delete

Standard file management functions.

Before a file is deleted, you have to confirm the delete operation.

Remote command:

[:MMEMory:DELeTe](#) on page 477

[:MMEMory:COpy](#) on page 475

Rename

Renames the selected file or directory.

Remote command:

[:MMEMory:MOVE](#) on page 478

Create New Directory

Creates a folder and opens an edit dialog box to enter name and path (absolute or relative to the current directory) of the new folder.

Remote command:

[:MMEMory:MDIRectory](#) on page 478

11.8.2 Map network share settings

Access:

- ▶ Select "System Config > Save/Recall" > "File Manager > Map Network Share".

The "Map Network Share" dialog provides settings that are similar to the standard Windows Explorer function "Map network drive". These settings help you to create up to 10 "shortcuts" to shared folders or computers in the network.

The dialog displays a list of current mapped network folders. The directory tree of the "File Manager", "Save/Recall", and "File Select" dialogs indicate a mapped network folder as `/shares/<"Local Folder">`.

Map Network Share

Network Folder

Local Folder

User Name

Reconnect at Startup

//10.124.0.166/user

setups

instrument

Off

Network Folder

//10.124.0.166/user

Local Folder

setups

User Name

instrument

Password

Reconnect at Startup

☐

Connect

Change

Disconnect

See also [Chapter 11.8.4, "How to map a network folder"](#), on page 325.

Settings:

Network Folder	324
Local Folder	324
User Name	324
Password	324
Reconnect at Startup	324
Connect	325
Change	325
Disconnect	325

Network Folder

Enter the path of the folder or computer, e.g. `//<IP Address>/user` or `//<server name>/user`.

Local Folder

Enter a letter or an alias name to describe the folder.

In the directory tree, a mapped network folder is indicated as `/shares/`
`<"Local Folder">`.

User Name

Enter a user name of a user that has the permission to access the selected network folder.

Password

Enter the password of the selected user.

Reconnect at Startup

Enables reconnecting every time you start up the instrument.

Connect

Triggers the instrument to prove the credential and to map (i.e. connect) the selected network folder or computer to the instrument.

You can map up to 10 network folders.

Change

Applies the changes.

Disconnect

Disconnects the network drive.

11.8.3 How to display all saved files

To display all files on the internal memory

1. Select "System Config > Save/Recall" > "File Manager".
2. Navigate to `/var/user/`.

To display all files on a connected USB flash drive

1. Select "System Config > Save/Recall" > "File Manager".
2. Navigate to `/usb/`.

To display all files in the volatile memory

1. Select "System Config > Save/Recall" > "File Manager".
2. Navigate to `/var/volatile/`.

11.8.4 How to map a network folder

Possibly you would like to transfer instrument or user settings to another R&S SMA100B, distribute waveform files to several instruments or you have to access frequently the same network drive. In these cases, on a R&S SMA100B connected to a LAN you can create a shortcut to this network folder or this computer.

How to: see [Chapter 3.1.7, "Connecting to LAN"](#), on page 27.

To map a network folder, proceed as follows:

1. On the computer or the network folder you want to map, enable remote access.
You can specify a list of users allowed for remote access.
The remote access settings depend on the operating system the remote computer is using. For step-by-step instructions, refer to the documentation of the particular operating system.
2. On the R&S SMA100B, [enable file transfer via SMB \(samba\)](#).

3. Select "System Config > Setup > Remote Access > Network".
Select:
 - a) "Address Mode > Auto (DHCP)"
 - b) Check that the "DNS Suffix" and "DNS Server" are correct.
4. In the "Save/Recall" dialog, select "File Manager > Map Network Share".
5. In the "Map Network Share" dialog, select:
 - a) In the "Network Folder" field, enter `//<IP Address>/user` or `//<Server Name>/user`.
 - b) In the "Local Folder" field, enter an alias name, e.g. *setups*.
 - c) Enter the "User Name" and "Password" of a user with a remote access permission to the selected network folder.
 - d) If necessary, enable "Reconnect at Startup".
 - e) Select "Connect".


The selected network folder is mapped to your instrument. The list of mapped network folders is updated.

Network Folder	Local Folder	User Name	Reconnect at Startup
//10.124.0.166/user	setups	instrument	Off

Network Folder: //10.124.0.166/user
 Local Folder: setups
 User Name: instrument
 Password: *****
 Reconnect at Startup: ☐

6. Close the "Map Network Share" dialog.

The navigation tree in the "File Manager" dialog displays the mapped network folder as `/shares/Setups`.



If the connection does not succeed, consider to check the following:

- Is the network folder or computer you try to map turned on?
- Is the network folder or computer enabled for remote access?
- Does the selected user name have the necessary permissions?

See also [Chapter 11.9.5, "Using a file server for test files exchange"](#), on page 332.

11.9 How to transfer files from and to the instrument

As explained in ["File handling"](#) on page 307, you access the file system of the R&S SMA100B via one of the following ways:

- Via the built-in "File Manager"
See [Chapter 11.8, "Using the file manager"](#), on page 321.
- On an instrument connected to a LAN:
 - Via one of the standard functions FTP or SMB (samba)
See [Chapter 11.9.2, "Accessing the file system of the R&S SMA100B over FTP"](#), on page 329 and
[Chapter 11.9.3, "Accessing the R&S SMA100B file system using SMB \(Samba\)"](#), on page 330
 - Via mapped network drives
See [Chapter 11.8.4, "How to map a network folder"](#), on page 325.
- Via a connected USB storage device
See [Chapter 11.9.4, "Using a USB storage device for file transfer"](#), on page 332

Mainly because of security reasons, the access to the file system of your R&S SMA100B can be denied, because one or all these access methods are deliberately disabled. Access to the file system via LAN and/or USB requires that the corresponding service is enabled and a write access to the file system is enabled. Refer to

[Chapter 11.9.1, "Removing file system protection"](#), on page 328 for description of the required steps.

This section provides an introduction to the topic. For comprehensive information, refer to the application note [1GP72: Connectivity of Rohde&Schwarz Signal Generators](#).

- [Removing file system protection](#)..... 328
- [Accessing the file system of the R&S SMA100B over FTP](#)..... 329
- [Accessing the R&S SMA100B file system using SMB \(Samba\)](#)..... 330
- [Using a USB storage device for file transfer](#)..... 332
- [Using a file server for test files exchange](#)..... 332

11.9.1 Removing file system protection

Before you try to access the file system via FTP, SMB (samba) or USB, fulfill the following:

- Disable write protection on the file system
- Enable the corresponding service or interface

To enable write permission on the file system

1. Select "System Config > Setup > Security > Security > General".
2. Select "Disk & Memory".
3. Enable "Volatile Mode".
4. Enter the "Security Password".
The default password is 123456. For more information, see [Chapter 12.4, "Using the security settings"](#), on page 360.
The R&S SMA100B requests a reboot.
5. Confirm the request.
The system reboots. The enabled settings are active.

To enable file transfer over FTP

1. Select "System Config > Setup > Security > Security > LAN Services".
2. In the "Common Services" tab, enable "LAN Interface"
3. Enable "FTP"
4. Enter the "Security Password".
The default password is 123456. For more information, refer to [Chapter 12.4, "Using the security settings"](#), on page 360.
5. Select "Accept".

To enable file transfer over SMB (samba)

1. Select "System Config > Setup > Security > Security > LAN Services"

2. Enable "LAN Interface"
3. Select "Samba Services".
4. Enable the "SMB 1.0/2.0 Client".
5. Enable the "SMB 1.0/2.0 Server".
6. Enter the "Security Password".
The default password is 123456. For more information, refer to [Chapter 12.4, "Using the security settings"](#), on page 360.
7. Select "Accept".

To enable file transfer over USB

1. Select "System Config > Setup > Security > Security > General"
2. Select "Disk & Memory".
3. Enable "USB Storage"
4. Enter the "Security Password".
The default password is 123456. For more information, refer to [Chapter 12.4, "Using the security settings"](#), on page 360.
5. Select "Accept".

11.9.2 Accessing the file system of the R&S SMA100B over FTP

If the R&S SMA100B is connected to a LAN, you can use file transfer protocol (FTP) to access the file system and to transfer files from and to the instrument.

How to: see [Chapter 3.1.7, "Connecting to LAN"](#), on page 27.

To access the file system over FTP

We assume that the instrument and the remote PC are connected to a LAN.

1. [Enable file transfer via FTP](#)
2. [Enable write permission on the file system](#)
3. On the remote PC, start the Windows Explorer.
4. In the address field, enter `ftp://<"IP Address" of the Instrument>`, e.g. `ftp://10.124.0.166`.

Tip: The R&S SMA100B indicates its IP address on the home screen.

A log-on dialog opens and requests a password.

The default user name and password is *instrument*.

Tip:

Default password


The FTP and SAMBA file access use the user "instrument" with default password "instrument".

We recommend that you change this password in the "Setup > Security > Password Management > Change User Password" dialog before connecting the instrument to the network.

See [Chapter 12.4.4, "Password management"](#), on page 370.

5. Enter the password to access the `user` directory.

The `user` directory corresponds to the `/var/user/` directory of the instrument.




There, you can perform standard functions like creating directory, or saving files.

6. In the `user` directory, create a directory, e.g. `test ftp`.

7. Select "System Config > Save/Recall".

Open the `/var/user/` directory.

The dialog displays the `/var/user/test ftp` directory.



11.9.3 Accessing the R&S SMA100B file system using SMB (Samba)

The SMB (Samba) protocol is an alternative way to access the file system of the instrument from a remote PC. This protocol works if both the instrument and the PC are connected to a LAN.


How to: see [Chapter 3.1.7, "Connecting to LAN"](#), on page 27.

To access the file system over SMB

We assume that the instrument and the remote PC are connected to a LAN.

1. [Enable file transfer via FTP](#)
2. [Enable write permission on the file system](#)
3. On the remote PC, start the Windows Explorer.
4. In the address field, enter `\\<"IP Address" of the Instrument>`, e.g. `ftp://10.124.0.166`.

Tip: The R&S SMA100B indicates its IP address on the home screen.



The `user` directory corresponds to the `/var/user/` directory of the instrument; the `volatile` directory - to the `/var/volatile` directory.

To map the R&S SMA100B as a network drive to the remote PC

We assume that the instrument and the remote PC are connected to a LAN.

1. [Enable file transfer via SMB \(Samba\)](#)
2. [Enable write permission on the file system](#)
3. On the remote PC, start the Windows Explorer.
Open the "Map Network Drive" dialog.

a) Select a valid "Drive", e.g. *W*.

b) In the "Folder" field, enter `\\<"IP Address" of the Instrument>/user` or `\\<"Hostname" of the Instrument>/user`

For example: `\\10.124.0.166/user` or `\\SMA100B-102030/user`.

Tip: The R&S SMA100B indicates its IP address on the screen.

c) Select "Finish".

A log-on dialog opens and requests a user name and a password.

Tip:

Default password


The FTP and SAMBA file access use the user "instrument" with default password "instrument".

We recommend that you change this password in the "Setup > Security > Password Management > Change User Password" dialog before connecting the instrument to the network.

See [Chapter 12.4.4, "Password management"](#), on page 370.

4. Enter the user name and the password of your instrument.

The `/var/user/` directory of the instrument is mapped to and displayed as a network drive of the remote PC.



You can access the files in the `/var/user/` directory, perform standard function like creating directory, or saving files.

11.9.4 Using a USB storage device for file transfer

Alternatively to the file transfer possibility via LAN, you can use a USB storage device for direct file transfer from and to the instrument.

We recommend that you transfer files with user data (like lists or instrument setup files) to the instrument, rather than load and play them from a connected USB storage device.

To transfer a file with user data to the instrument

1. Connect a USB storage device, for example a USB memory stick to one of the USB interfaces of the instrument.

The R&S SMA100B recognizes the connected USB storage device automatically.

2. [Enable file transfer via USB](#)
3. [Enable write permission on the file system](#)
4. Select "System Config > Save/Recall".

The dialog displays the `/var/user/` directory and the `/usb/` drive.

5. In the "Save/Recall" dialog, select "File Manager".
6. In the directory tree, navigate to the `/usb/` drive.
Select the required file with user data.
7. Select "Copy".
8. In the directory tree, navigate to the `/var/user/` directory.
Select "Paste".

The file with user data is transferred to the instrument.

11.9.5 Using a file server for test files exchange

You can use a central file storage location like a file server in your company network to save setup files, SCPI scripts, application programs, or waveform files on it. Usually,

you would like to distribute the files to several instruments. If the R&S SMA100Bs are connected to a LAN, you can create a shortcut on the instruments to the file server.

To access the file server

- On each R&S SMA100B, map the required directory of the file server to the instrument.
Perform the steps described in [Chapter 11.8.4, "How to map a network folder"](#), on page 325.
- On each R&S SMA100B, use the same alias name for the directory of the file server, i.e. enter the same "Local Folder" (in this example *Setups*).

On any of the R&S SMA100B, you access the file server directly from the "File Manager" and under the same name, e.g. */shares/Setups*.
An extra advantage in remote control is that the same application program would control the instruments.
For example, use the remote control command `MMEMory:CDIRECTory` `"/shares/Setups"` to set the default directory for mass storage.


11.10 **Creating screenshots of current settings**

The save/recall function enables you to save current settings in a file. To document the most important settings for a performed signal generation, you can also save a hard-copy of the current display.

- [Hardcopy settings](#)..... 333
- [How to save a hardcopy of the display](#)..... 337

11.10.1 **Hardcopy settings**

- Access:
- Select "System Config > Setup > User Interface > Hardcopy".



The remote commands required to define these settings are described in [Chapter 14.12, "HCOPY subsystem"](#), on page 505.

Settings:

File.....	334
Format.....	335
Options.....	335
Save.....	335
Hardcopy Options > Common.....	335
L Automatic Naming.....	335
L Format.....	335
L Region.....	335
Hardcopy Options > Automatic Naming.....	336
L Path.....	336
L Clear Path.....	336
L Prefix, Year, Month, Day.....	336
L Current Auto Number.....	337

File...

In "Automatic Naming > Off" mode, accesses the standard file select dialog for selecting the filename and folder the hardcopy is stored in.

If you have enabled "Automatic Naming", the instrument displays the automatically generated filename.

Remote command:

`:HCOPY:FILE[:NAME]` on page 507

Format

Selects the output file format, for example *.bmp, *.jpg*.xpm and *.png.

Remote command:

[:HCOPY:IMAGe:FORMat](#) on page 506

[:HCOPY:DEVIce:LANGuage](#) on page 506

Options...

Accesses [Hardcopy Options](#) dialog.

Save

Saves a hardcopy of the current display as a file.


Remote command:

[:HCOPY\[:EXECute\]](#) on page 507

Hardcopy Options > Common

Access: select "Hardcopy > Options... > Common".

With the provided settings, you can customize the file format and the syntax of the automatically assigned filename.

**Automatic Naming ← Hardcopy Options > Common**

If enabled, creates the output filenames automatically according to the rules set with the [Hardcopy Options > Automatic Naming](#) settings.

Remote command:

[:HCOPY:FILE\[:NAME\]:AUTO:STATE](#) on page 509

Format ← Hardcopy Options > Common

Selects the output file format, for example *.bmp, *.jpg*.xpm and *.png.

Remote command:

[:HCOPY:IMAGe:FORMat](#) on page 506

[:HCOPY:DEVIce:LANGuage](#) on page 506

Region ← Hardcopy Options > Common

Displays the snapshot area.

Remote command:

[:HCOPY:REGion](#) on page 507

Hardcopy Options > Automatic Naming

Access: select "Hardcopy > Options... > Automatic Naming".

Provided are the following settings:

Path... ← Hardcopy Options > Automatic Naming

Selects the directory.

Note: To select the destination path, specify also a filename. Otherwise an error message is displayed and selection is canceled.

Remote command:

`:HCOPY:FILE[:NAME]:AUTO:DIRectory` on page 508

Clear Path ← Hardcopy Options > Automatic Naming

Deletes all image files with extensions *.bmp, *.jpg, *.png and *.xmp in the directory set for automatic naming.

Before the command is executed, a warning message prompts you to confirm the deletion of the files.

Remote command:

`:HCOPY:FILE[:NAME]:AUTO:DIRectory:CLEAr` on page 508

Prefix, Year, Month, Day ← Hardcopy Options > Automatic Naming

Determines the rules for "Automatic Naming".

Per default, the automatically generated filename is composed of:

`<Path>/<Prefix><YYYY><MM><DD><Number>.<Format>`, where Y, M and D mean year, month, Day; Number is the [Current Auto Number](#).

You can activate or deactivate each component separately.

The "Resulting filename" indicates the current filename syntax.

Remote command:

`:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFix` on page 510

`:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe` on page 510

:HCOPY:FILE[:NAME]:AUTO[:FILE]:YEAR:STATE on page 509

:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH:STATE on page 509

:HCOPY:FILE[:NAME]:AUTO[:FILE]:DAY:STATE on page 509

Current Auto Number ← Hardcopy Options > Automatic Naming

Indicates the number which is used in the automatically generated filename.


Note: When initially switching on the instrument, the number is reset to the lowest possible value. Starting with number 0 the output directory is scanned for existing files. As long as files with the same name are existing, the number is increased by 1. The number is automatically set so that the resulting filename is unique within the selected path. The current number is not in the save/recall file but is temporarily stored within the database. At the following save operation, the number is increased.

Remote command:

:HCOPY:FILE[:NAME]:AUTO[:FILE]:NUMBER? on page 509

11.10.2 How to save a hardcopy of the display

1. Select "System Config > Setup > User Interface > Hardcopy".



2. To define the output format, select "Format > JPG".
3. To enable the instrument to create output filenames, select "Automatic Naming > On".
4. Select "Options...".
5. In the "Hardcopy Options" dialog:

- a) To change the default directory the file is saved in, select "Automatic Naming Settings > Path" and define a path and a filename. For example, select the default directory `/var/user`.
 - b) If necessary, disable or change some of the parameters in the "Automatic Naming Settings".
 - c) Close the "Hardcopy Options" dialog.
6. In the "Hardcopy" dialog, select "Save".

The instrument saves a hardcopy of the current instrument display as a `*.jpg` file. The filename is automatically created.
7. To print the hardcopy, connect the instrument to a LAN and:
 - a) Transfer the file to a remote computer as described in [Chapter 11.9, "How to transfer files from and to the instrument"](#), on page 327.
 - b) On the remote computer, navigate through the file system.
 - c) Print the selected file.

For more information, refer to the online help of the operating system.

12 General instrument functions

The general instrument functions include basic instrument settings, regardless of the selected operating mode and measurement. Some of these settings like screen display and peripherals are initially configured at the setup of the instrument, according to personal preferences and requirements. However, you can individually adjust the settings at any time, for example, if necessary for specific applications.

The following special functions help you in service and basic system configuration:

- [Chapter 12.1, "Customizing the user interface"](#), on page 339
Allows you to adjust the display and keyboard language settings.
- [Chapter 12.2, "Organizing frequently used settings as favorites"](#), on page 344
Enables you to group user defined settings in a favorites list or to assign actions to the [★ (User)] as quick access for later retrieval.
- [Chapter 12.3, "Managing licenses and license keys"](#), on page 351
If you have purchased an additional option for the R&S SMA100B, you can enable it using a license key.
- [Chapter 11.2, "Restoring the \(default\) instrument configuration"](#), on page 308
At any time, you can restore a default configuration to start a measurement at a defined instrument state, or set the instrument to factory preset.
- [Chapter 17.3, "Performing maintenance tasks"](#), on page 785
Special functions like calibration routines and self-tests put your instrument to an initial state.
- [Chapter 12.4, "Using the security settings"](#), on page 360
Special security and protection functions protect your instrument from unauthorized use or activate specific test routines.

12.1 Customizing the user interface

The R&S SMA100B provides basic alignments of instrument settings regarding the user interface, that means the touch panel (screen), the appearance of the displayed dialogs and graphics, and an external keyboard.

Start / stop display update

The operating system of the R&S SMA100B refreshes the displayed settings by default in almost real-time, to keep the display updated with the internally used values. However, you can turn off this function to reduce settling times when the instrument is remote controlled.



We recommend that you switch off the display update for optimum sweep performance with short dwell times and for fast settling times.

Consider that in this case the displayed values can differ from the operated values.

In detail described in the following paragraphs, you can:

- Set display and keyboard language, see [Chapter 12.1.1, "Display and keyboard settings"](#), on page 340
- Set date and time for the system clock, see [Chapter 17.3.2, "Date and time"](#), on page 791
- Configure and activate a [Screen Saver](#)
- Deactivate display update to improve performance, see [Chapter 12.1.2, "Display update settings"](#), on page 341
- Determine the state of the RF signal, and the level display in the status bar when you turn on the R&S SMA100B, see [Chapter 12.1.3, "Defining the RF signal state on power on"](#), on page 342.

12.1.1 Display and keyboard settings

Access:

1. Select "System Config > Setup > User Interface > Display/Keyboard > Display".

Display	USB Keyboard			X
Screen Saver		<input checked="" type="checkbox"/>	Wait time	
is Active				10 Min
Brightness				
Display		14	RF Hardkey	14

2. Select "Display/Keyboard > USB Keyboard".

Display	USB Keyboard	
Layout		
English (US)		

In the "Display/Keyboard" dialog, you can change regional and language options for the GUI and an external keyboard, and define the screen saver settings.

The remote commands required to configure the display and keyboard are described in [Chapter 14.10, "DISPlay subsystem"](#), on page 499 and [Chapter 14.13, "KBOard subsystem"](#), on page 510.

Screen Saver	341
Wait Time	341
Display	341
RF Hardkey	341
USB Keyboard > Layout	341

Screen Saver

Activates the screensaver.

If activated, the display including backlight is switched off after the selected **Wait Time** elapses and if no entries via touch panel, front panel, external mouse, or external keyboard are made

Remote command:

`:DISPlay:PSAVe[:STATe]` on page 500

Wait Time

Enters the idle time that must elapse before the display lamp is shut off when no entries are made.

Remote command:

`:DISPlay:PSAVe:HOLDoff` on page 500

Display

Adjusts the brightness of the display.

Increase the value to turn up the display brightness.

Remote command:

`:DISPlay:BRIGhtness` on page 500

RF Hardkey

Adjusts the brightness of the [RF on/off] key.

Increase the value to change the contrast between the key and the front panel background color.

Remote command:

`:DISPlay:BUtTon:BRIGhtness` on page 501

USB Keyboard > Layout

Selects the language of an externally connected keyboard via USB. The function assigns the corresponding keys automatically.


Remote command:

`:KBOard:LAYout` on page 510

12.1.2 Display update settings

Access:

- Select "System Config > Setup > User Interface > Start/Stop Display Update".



This dialog enables you, to deactivate updating the display.

The remote command to switch off the display update is described in [Chapter 14.10, "DISPlay subsystem"](#), on page 499.

Display Update is
Disables the automatic refreshing of the displayed values.
Remote command:
`:DISPlay:UPDate[:STATe]` on page 501


12.1.3 Defining the RF signal state on power on

As additional functions for the level settings, you can determine the state of the RF signal, and the level display in the status bar when you turn on the R&S SMA100B.

Power-On/EMF settings

Access:

► Select "Level" > "Power-On / EMF".



The "Power-On/EMF" dialog contains all settings for configuring the power-on behavior and the level display.

Settings:

Power-On State	342
Display Level as Voltage of EMF	342

Power-On State
Determines the RF signal output state when the instrument is switched on.
You can disable the RF output signal in general, or start it in the same state as it had been when it was switched off.
Remote command:
`:OUTPut<hw>[:STATe]:PON` on page 511

Display Level as Voltage of EMF
Activates display of the signal level as voltage of the EMF (no-load voltage).
If disabled, the level is displayed as a voltage over a 50 Ohm load.
Note:

The setting is not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. It is reset only by factory preset.

Remote command:

`[:SOURce<hw>] :POWER:EMF:STATe` on page 708

12.1.4 How to set the initial instrument settings


This section describes how to set up the R&S SMA100B initially.

12.1.4.1 Setting the keyboard language

You can select the language of the external keyboard connected to the instrument.

To adjust the keyboard settings

1. Press the [Setup] key.
2. Select "User Interface > Keyboard".



3. Select the "Layout".


The dialog closes and the changes take effect immediately.

12.1.4.2 Setting the screen saver

You can enable a screen saver that automatically turns off the display after a user-defined period of time. The screen saver is activated if no settings are made on the touch screen, or via keys or the rotary knob during the selected wait time.

To activate the screen saver

1. Press the [Setup] key.
2. Select "User Interface > Display"
3. Activate the "Screen Saver".



4. Define the "Wait Time" in minutes.
The instrument turns off the display after the defined period of time.
5. To reactivate the display, tap the screen or press any key on the front panel.

To deactivate the screen saver

1. Press the [Setup] key.
2. Select "User Interface > Display"
3. Disable the "Screen Saver" state.

12.2 Organizing frequently used settings as favorites

The R&S SMA100B provides two possibilities to define frequently used settings and procedures for later retrieval individually.

User menu and [★ (User)] key

These two functions work similar to the favorites function of a browser or other programs. They allow you to create a list of frequently used actions or to group frequently used settings in one dialog.

You can collect the parameters of your configuration in a favorites list, i.e. in the "User Menu", or define settings and actions with the [★ (User)] key:

- "User Menu" to group settings of specific tasks.
Similar to a favorites function, you can use this menu for:
 - Grouping the settings required for a task in one dialog.
 - Saving and recalling the settings of a task.
 - Transferring the settings for use on multiple instruments.
- [★ (User)] key, with customizable function.
You can perform the following steps using this key:
 - Open the "User Menu" (default functionality).
 - Add or remove settings and functions.
 - Execute actions and access functions.

Possible applications

The ★ (User) key and the "User Menu" are useful for the following situations:

- There are functions or tasks you have to perform in a defined order but the setting parameters are distributed across several dialogs.
- There are functions or tasks you have to perform frequently but they are not accessible via the front panel keys.
- The required functions are grouped in a dialog that is not directly accessible from the home screen.
- Your task involves the frequently loading and executing of certain SCPI scripts. Refer to [Chapter 13.13.4, "How to record / create SCPI lists"](#), on page 447 for information on how to create an SCPI script.
- A quick access to saved setups is required.
- There are functions and tasks you have to perform on several instruments.

Dialog identification

To identify each dialog, the instrument uses a dedicated dialog ID. The dialog ID contains the dialog position on the display and the current active tab. The action that triggers the instrument to open a dialog uses this identification.

Save/Recall vs. recall setup

If you need to restore a specific signal generation setup and perform further configurations based on this particular instrument state, the R&S SMA100B provides two options:

- "Save/Recall" function
For a detailed description, refer to [Chapter 11.4, "Saving and recalling instrument settings"](#), on page 314.
- "Recall Setup" function
If the "Recall Setup" is the only user action assigned to the [★ (User)] key, pressing this key triggers the R&S SMA100B to load the user-defined preset file immediately.

12.2.1 User menu settings

The "User Menu" dialog contains function keys to organize, save and load a favorites list. You can also modify, add or delete list entries directly in the dialog.

Clear User Menu

Removes all entries from the "User Menu" at once.

Save User Menu

Saves the current "User Menu" under the defined filename.

Recall User Menu

Loads the selected "User Menu" file.

This function enables you to use the user specific favorites file on another instrument. However, if functions or parameters are not provided due to varying configuration of the instrument, the settings of these particular parameters take no effect.


12.2.2 How to use the user menu for fast adjustments

Access:



1. Press the [★ (User)] key.

The "User Menu" dialog opens.




If you execute this action for the first time, the dialog displays instructions on how to use the "User Menu".

2. If you already have a saved user menu file on the instrument, you can load with "Recall User Menu".

Creating a "User Menu"


To create your own user dialog with settings:

1. Open a dialog with settings you frequently use.
2. Select a parameter.
3. Open the context menu and select "Add to User Menu".






A favorites icon ★ indicates that the parameter is used in the "User Menu".



The "User Menu" button in the taskbar confirms that you have created a "User Menu" with at least one entry.

4. Press the [★ (User)] key.

The "User Menu" dialog shows all parameters that you have added to the list.



You can modify the parameter settings directly in this dialog, e.g. change a state or set values, as you do in the particular dialog the parameter originally belongs to.

5. To remove an entry, select the parameter either in the "User Menu" or in the dialog where it originally belongs to.
 - a) Open the context menu and select "Remove from User Menu".



6. To remove all entries at once, select "Clear User Menu".
7. To save your individual favorites list, select "Save User Menu", and follow the file managing instructions.

The file system automatically assigns the file extension *.user_menu.

8. To recall a previously saved user menu, select "Recall User Menu" and proceed accordingly.

Providing a user menu favorites list for several instruments


To transfer files from or to an instrument:

1. Create the favorites list, as described in ["Creating a "User Menu" on page 346.](#)
2. Save the favorites list.
3. To transfer a file from or to an instrument, the R&S SMA100B provides several options, see ["File handling" on page 307.](#)

12.2.3 Define user key actions settings

Access:

- Select "System Configuration > Setup > User Interface > Define User Key".



The dialog displays a list of the currently enabled actions and provides functions to define new, edit or remove existing actions. If no actions have been defined, the list is empty.

See [Chapter 12.2.4, "How to assign actions to the \[★ \(User\)\] key", on page 350.](#)

The remote commands required to define these settings are described in [Chapter 14.10, "DISPlay subsystem", on page 499.](#)

Name

Enters a user-defined name for the action.

Wizard

Defines the action to be executed.

"Load SCPI Script"

Selecting the action load and executes the SCPI script.

"Recall Setup"

Load a setup for quick access to the user-defined settings.

"Open Dialog"

Quick access to the selected dialog.

Select

Depending on the selected "Wizard", provides access to:

- The standard "File Select" function for loading of an SCPI script or setup file
- A list of the dialog IDs of all currently opened dialogs. The dialog ID is used for dialog identification in the remote control.

See [SCPI](#).

SCPI

For the currently selected action, displays the corresponding SCPI command with the associated parameter for dialog identification (dialog ID). The automatically displayed SCPIs are enabled for subsequent modification.

Remote command:

[:DISPlay:DIALog:OPEN](#) on page 503

See also [:DISPlay:DIALog:ID?](#) on page 502

Add, Change, Remove


Standard functions for managing of the actions.

Back to Execute Mode

Opens the "Select Action to Execute" dialog. Select an Action form the list to execute it.

To return to the "Define User Key Actions" dialogs, select [Select Action to Execute > Define Actions](#).

Select Action to Execute > Define Actions

Name	Action
Open User Menu	:DISP:DIAL:OPEN "CSetupDlgUserMenu"
Open	:DISP:DIAL:OPEN "CSetupFrontPanelKe...
 Define Actions ...	

Accesses the "Define User Key Actions" dialog.

12.2.4 How to assign actions to the [★ (User)] key


The customizable [★ (User)] key has no predefined function assigned. You can individually define actions to be executed or functions to be accessed when pressing this key.

To assign a frequently used dialog to the [★ (User)] key:


1. Open the dialog you want to quickly access.
For example, select "Level > UCOR > Import/Export"
2. Select "System Configuration > Setup > User Interface > Define User Key".
3. To create an action:
 - a) Specify the "Name".
E.g. *OpenUcorImportExportList*.
 - b) Select "Wizard > Open Dialog"
 - c) Select "Select" and select the dialog ID from the list

The corresponding SCPI command is automatically displayed and can be later modified.

4. Select "Add" to store the new action in the list of user key actions.



5. To execute the created action, press ★ (User).
In the list of actions ("Select Action to Execute" dialog), navigate to the required action.
In this example, this is "OpenUCORImportExportList".



The R&S SMA100B executes the action and opens the dialog.

12.3 Managing licenses and license keys

An option is ready to operate after it is enabled with a license keycode supplied with the option. The license key is delivered as a file or on paper. Unregistered licenses must be registered for a particular instrument before the corresponding option can be enabled for operation.



For reliable operation, a software option usually requires the latest firmware version. The required version is specified in the delivery. If your instrument works with a former firmware version, update the firmware before enabling the software option.

The firmware update is described in the release notes provided on the product page of the R&S SMA100B.

12.3.1 Manage license keys settings

The "Manage Licnese Keys" dialog provides all information on the available licenses. Instrument-related steps guide you through the process of registering or deactivating licenses.

Access:

1. Select "System Config > Setup > Instrument Assembly > Manage License Keys > Manage License Keys".

Manage License Keys | Installed License Keys

Device ID: 1419.8888K02-000000-Ea

Enter License Key

Enter License Key

Import License Key From File ... | Export Deactivation Response To File ...

License Installation Info

In this tab, you can activate licenses for newly purchased or newly registered options.

2. Select "System Config > Setup > Instrument Assembly > Manage License Keys > Installed License Keys".

Manage License Keys | Installed License Keys

Show Inactive ☐ | Show Deactivated ☐ | Open License Server

	Export License Key To File	Option	License Count	License Type	Registrations
1 ...		<InstName>-Opt>	1	Permanent	
2 ...		<InstName>-Opt>	2	Permanent	
3 ...		<InstName>-Opt>	1	Timed (2160 h left)	

This tab lists all active options, with information on the available number of an option, the license type and registration. You can query inactive or disabled options also.

3. Select "Open License Server".

The "Manage License Keys" dialog covers all required parameters for activating or deactivating newly purchased or newly registered options, and provides access to the onboard license server, see [Chapter 12.3.2, "Using the license server"](#), on page 354.

Settings

Device ID.....	353
Enter License Key.....	353
Import License Key from File.....	353
Export Deactivation Response to File.....	353
License Installation Info.....	353
Installed License Keys.....	353
L Show Inactive.....	353
L Show Deactivated.....	353
L Installed License Keys Table.....	354
Open License Server.....	354

Device ID

Displays the instrument-specific identification number. The device ID is a unique string with the following structure:

```
<stock number>-<serial number>-<checksum>
```

Enter License Key

Type here the license key provided with the option.

For license keys delivered as a file, use [Import License Key from File...](#)

Import License Key from File...

Opens a dialog for selecting the file with the license key.

Use this function also to import the deactivation key file generated by the R&S License Manager online tool (see [How to move a portable license](#)).

Export Deactivation Response to File...

Exports the generated deactivation response key to a file and opens a file management dialog to save the file.

This key is required during the unregistration process, e.g. when you want to deinstall an option or have a portable option, which you want to register later on another instrument (see [How to move a portable license](#)).

License Installation Info

Indicates status information on the performed actions.

Installed License Keys

Access: select "System Config > Setup > Instrument Assembly > Manage License Keys > Installed License Keys".

Comprises information on the installed options.

Show Inactive ← Installed License Keys

Enables the display of the inactive (expired) licenses in the [Installed License Keys Table](#).

Show Deactivated ← Installed License Keys

Enables the display of the deactivated licenses in the [Installed License Keys Table](#).

See [How to move a portable license](#) for information on how to activate deactivated licenses.

Installed License Keys Table ← Installed License Keys

Shows information on the currently installed options.

"Export License Key to File"

Opens a dialog to save the generated license key file. This file is required during the unregistration process.

If you have a portable unregistered option, you can register it later on another instrument (see [How to move a portable license](#)).

"Option"

Displays the option short designation.

Tip: Open the [Hardware Options/Software Options](#) dialog to retrieve more information about the installed options.

"License Count"

Displays the number of the licenses for the selected option key.

"License Type"

Displays the type of license.

A license type determines the common qualification application duration and the portability of a license. The following license types are provided: evaluation, permanent, portable, quantified, time-controlled with a duration of 1, 3, 6 or 12 months. A license can also be deactivated or expired.

For time limited licenses, the left time of applicability is displayed too.

"Registrations" (reserved for future use)

Open License Server

Opens the R&S License Server of the R&S SMA100B, see [Chapter 12.3.2, "Using the license server"](#), on page 354.

12.3.2 Using the license server


The R&S SMA100B now supports handling of software licenses using the license server from Rohde & Schwarz.

The R&S License Server is a browser application you can access directly in the R&S SMA100B. The onboard license server is integrated in the instrument firmware with connection to a *local smartcard* memory. The local smartcard holds local licenses, i.e. licenses used on this specific instrument.

To open the license server

Access:

1. Select "System Config > Setup > Instrument Assembly > Manage License Keys > Installed License Keys".



2. Select "Open License Server".

The license server browser opens in a browser window and starts initially in the "Configuration" view.




Figure 12-1: R&S license server dialog

The selection button in the upper left enables you to access the "Analytics" or "Licenses" views, see ["Short glance at the main views"](#) on page 355.

The icons at the upper right lead you to information on the license server:

- "About": shows the software version.
- "User Manual": opens the embedded license server user manual.
- "Help": provides the functional description on a specific dialog and its settings.

Short glance at the main views

The section provides a brief insight into the main windows of the license server. For details and handling of the application, refer to the embedded user documentation.



1. To access a view, select the menu button.
2. Select "Configuration".




Figure 12-2: Configuration menu

Accesses the license server, access lists and installed product definitions.

- a) Select "Local license server".




Figure 12-3: Example of a local license server view

Shows the onboard license server of the instrument. With the column selection, you can indicate or unhide characteristics of the available server. The task bar buttons provide access to the corresponding functions and access lists.

- b) Select "Product definitions".




Figure 12-4: Example of a product definition view

Shows installed product definitions. To view the available characteristics, use the column selection.

3. Select "Licenses".

Provides access to the available license servers.

The "License keys" view lists the license key options that are available on the selected server. To show additional information, use the column selection.

The task bar functions enable you to activate or deactivate a license, to get details on an option and export license keys or information on the selected product.

4. Select "Analytics".




Figure 12-5: Analytics menu

Provides access to the license providers, client applications and enables you to export statistics data for evaluation in external applications.

Shows information on configured client applications, license providers and license types. To show additional information, use the column selection.

To manage licenses on the R&S SMA100B

To request or return a license, proceed as follows:

1. Access: see ["To open the license server"](#) on page 354.

The browser application opens.

2. Select "Licenses"

3. Select a license server in the menu list, e.g. "R&S SMA100B".

The "License keys" view lists the enabled options available on the selected server.

4. Select "Status" > "Select all" to list also options that are currently deactivated.

The "Licenses" view shows all active, inactive and time limited options.

5. To get detailed information on a specific option:

a) Select the option in the list.

- b) In the task bar, select "Details".



Figure 12-6: Example of the license characteristics of an option

6. To enable a discontinued license: , select in the taskbar.
 - a) Select the license you want to activate.
 - b) In the task bar, select .
7. To return a license, proceed the same way:
 - a) Select the license.
 - b) Deactivate the license with .
8. Follow the instructions on the screen.

12.3.3 How to move a portable license

This example is intended to explain how to perform the required steps at the instrument.

Use a USB flash drive to transfer the license key files between the instruments and the browser.



We assume knowledge about the handling of the R&S License Manager online tool and the description of the whole process.

1. Open your browser. Enter <https://extranet.rohde-schwarz.com/service>.
Select "Manage Licenses > Move Portable License".
The first step requires the Device IDs of the source and target instruments.
2. To find out the Device IDs, proceed as follows:

- a) On the source instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > Manage License Keys > Device ID".

Manage License Keys	Installed License Keys		X
Device ID			
1234.1234K02-000000-ID			

- b) On the target instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys".
 - c) In the "Mange License Keys" tab, select "Device ID".
 - d) In the browser, select "Manage Licenses > Move Portable License > Select Devices".
 - e) Enter the Device IDs.
3. On the source instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > Installed License Keys > License Keys Table".
 - a) Navigate to the portable license that you want to move.
 - b) Select the "Export License to File" column.

A standard file manager dialog opens.
 4. Enter a filename.
 5. Save the exported license key, e.g. k123_portable_key_to_move.xml.
 6. In the browser, select "Manage Licenses > Move Portable License > Select License (from file)":
 - a) Select the exported license key.
 - b) Check the selection.
 - c) Create the deactivation key.
 - d) Save it to file.
 7. On the source instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > Manage License Keys > Import License Keys from File". Select the transferred deactivation key.
 8. On the source instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > Manage License Keys > Export Deactivation Response to File".
 9. In the browser, go to "Manage Licenses > Move Portable License > Install Deactivation Key (from file)".
 10. Enter the deactivation response of the instrument.

The license is deactivated for the source instrument.
 11. In the "Manage Licenses > Move Portable License", go to step "Create License" to generate a license key for this portable option and the selected target instrument.
 - a) Download the license key as a file.
 - b) Transfer it to the target instrument.

12. In the target instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > New License > Import License Keys from File".

13. Select the created license key file.

The portable option is installed on the target instrument.

12.4 Using the security settings

The protection function of the R&S SMA100B offers several levels to activate particular functions like self-test or tests for service purposes specifically.

Protection

The five protection levels are automatically active on startup, the protection levels, that means all protected functions are locked.

To unlock a protection level:

- ▶ In the "System Config > Setup > Security > Protection", enter the correct password.

To lock a protection level:

- ▶ Clear the corresponding checkbox.

Protection levels

The following functions are protected in the respective levels:

- Protection level 1
Protects against accidental changes, like, for example, the clock and date, several internal adjustments functions and the self-test, as well as network settings or the instrument hostname.
You can access this level with the password 123456.
- Protection level 2
Unlocks protected service functions. It is accessible to authorized personnel of Rohde & Schwarz service department only.
- Protection level 3 to 5
Are reserved for internal use.

Security

The security concept of the R&S SMA100B helps you to protect your instrument against uncontrolled access and changes. All provided security services require that you enter the security password.

Provided security services are:

- **General** security parameters, such as:
 - **USB storage** that secures controlled access to the mass memory of the instrument

- **Volatile mode** that prevents information to be written to the internal memory permanently.
- **Sanitizing** that prevents the instrument from leaving a secure environment with stored user information.
- **Annotation** frequency and amplitude prevent reading the display.
- **Secure Update Policy** check that verifies the integrity and origin of the firm-ware package to be installed.
To access the settings of these topics, see [Setting security parameters](#) > "[Secure Update Policy](#)" on page 363.
- **Password** management secures controlled user access to the instrument
With the two-step password concept, you can assign a user-defined password for the operating system, and a security password for accessing the mass storage of the instrument.
See also [Chapter 12.4.4, "Password management"](#), on page 370.
- **LAN services** secure controlled network access
You can individually lock and unlock supported LAN interface services. Also you can activate and deactivate SMB client and SMB server, that use versions 1.0 and 2.0 of the SMB protocol. See [Chapter 12.4.3, "Configuring LAN services"](#), on page 367.
Remote control via the LAN interface requires that the interface is activated. Once the interface is activated, enable or disable LAN services as needed.
- **User interface** prevents front panel operation and/or reading the display.

For more information, see the document R&S SMA100B Instrument Security Procedures.

12.4.1 Protection level settings

Access:

- Select "System Config > Setup > Security > Protection".

Protection Level 1	<input checked="" type="checkbox"/>	Password	*****
Protection Level 2	<input checked="" type="checkbox"/>	Password	*****
Protection Level 3	<input checked="" type="checkbox"/>	Password	*****
Protection Level 4	<input checked="" type="checkbox"/>	Password	*****
Protection Level 5	<input checked="" type="checkbox"/>	Password	*****

The "Protection" dialog provides access to the unlocking of different protection levels.

Several functions in the instrument are password-protected to prevent for example accidental changes, "[Protection](#)" on page 360.

The remote commands required to unlock a protected stage are described in [Chapter 14.18, "SYSTem subsystem"](#), on page 735.

Protection Level/Password

Unlocks the selected level of protection, if you enter the correct password.

The default protection level 1 password is 123456.

To lock the protection level again, clear the checkbox.


Remote command:

`:SYSTem:PROTect<ch>[:STATe]` on page 745

12.4.2 Setting security parameters

Access:

- Select "System Config > Setup > Security > Security > General".



In the "General" tab, you can determine the security level for firmware updates, and configure the security settings for the mass memory and manual operation.



All modified settings in this dialog are not applied until you enter the [Security Password](#) and confirm with [Accept](#).

12.4.2.1 Update policy security settings

Access:

- Select "System Config > Setup > Security > Security > General > SW Update".



The SW Update tab enables you to select the security mode for firmware updates.

The remote commands available to control security settings are described in [Chapter 14.18, "SYSTem subsystem"](#), on page 735.

Secure Update Policy

Allows you to configure the automatic signature verification for firmware installation.

To apply the change: enter the security password and confirm with "Accept". Otherwise the change has no effect.

See also:

- [Chapter 12.4, "Using the security settings"](#), on page 360 for more information on the security concept.
- The release notes for details on signature verification when installing new or former firmware versions, available at www.rohde-schwarz.com/firmware/sma100b.

"Confirm Unsigned"

Performs the signature verification.

If the check detects any discrepancies, the instrument issues a warning message. You can still update the firmware or reject updating.

This setting also enables you to downgrade the firmware version.

"All Packages" Accepts all packages without signature verification.

"R&S Signed Packages"

Performs the signature check.

If the check detects any discrepancies, the instrument issues a warning message and locks the update to this firmware.


Remote command:

`:SYSTem:SECurity:SUPolicy` on page 753

12.4.2.2 Disk & memory security settings

Access:

- Select "System Config > Setup > Security > Security > General > Disk & Memory".



The "Disk & Memory" tab secures controlled access to the mass memory and prevents information from leaving a secure environment.

The remote commands available to control security settings are described in [Chapter 14.18, "SYSTem subsystem"](#), on page 735.

USB Storage

Activates the access to external USB storage media.

To apply the change: enter the security password and confirm with "Accept". Otherwise the change has no effect.

See also [Chapter 11.9.4, "Using a USB storage device for file transfer"](#), on page 332.

Note: Remove all USB memory devices before disabling the USB storage. If any USB memory device remains connected, disabling is blocked, and the instrument returns a warning message.

The microSD card is also considered a USB memory device and must be removed. If you have sealed the SD card slot, you can not disable the USB storage.


Volatile Mode

Activates volatile mode, so that no user data can be written on the internal memory permanently.

In volatile mode:

- Data that the instrument normally stores on the internal memory is redirected to volatile memory.
- The user directory is mapped to the volatile memory. You access the temporary data just as data stored in the `/var/user/`, see [Chapter 11.3, "Protecting data"](#), on page 313.
- Data on the internal memory cannot be changed. It is protected against modification or erasure.
- You can only save data:
 - Temporarily in the volatile memory
 - On a connected external storage device, such as a memory stick

To activate volatile mode: enter the security password, confirm with "Accept" and reboot the instrument. Otherwise the change has no effect.

Activated volatile mode is indicated by the icon .

Remote command:

`:SYSTEM:SECurity:VOLMode[:STATe]` on page 745

Sanitize

Executes the erase procedure that sanitizes the internal memory.

The sanitizing function makes sure that no user information is stored on the instrument when it leaves the secure environment.

To apply the change: enter the security password and confirm with "Accept". Otherwise the change has no effect.

Note: If the instrument is subject to high security, and you have disabled volatile mode, the internal memory holds user-data, and thus poses a security risk.

See also [Chapter 12.4, "Using the security settings"](#), on page 360 for more information on the security concept.


Remote command:

`:SYSTEM:SECurity:SANitize[:STATe]` on page 753

12.4.2.3 Manual operation security settings

Access:

- Select "System Config > Setup > Security > Security > General > Manual Operation".



The "SW Update" tab enables you to lock front panel operation and/or reading the display.

The remote commands available to control security settings are described in:

- [Chapter 14.10, "DISPlay subsystem"](#), on page 499
- [Chapter 14.18, "SYSTEM subsystem"](#), on page 735.

Annotation Frequency

Enables the display of the currently used frequency in the status bar.

How to: see ["Disabling the frequency and level indication in the status bar"](#) on page 374.

Remote command:

`:DISPlay:ANNotation:FREQuency` on page 501

Annotation Amplitude

Enables the display of the currently selected level in the status bar.

How to: see ["Disabling the frequency and level indication in the status bar"](#) on page 374.

Remote command:

:DISPlay:ANNotation:AMPLitude on page 501

User Interface

Allows you to lock the controls for manual operation and the display individually.

How to: see ["Deactivating the user interface"](#) on page 374.

See also [Chapter 12.4, "Using the security settings"](#), on page 360.

"Enabled" Enables the display and all controls for the manual operation of the instrument.

"Touchscreen Off"

Locks the touch sensitivity of the screen.

This security feature protects the instrument against unintentional change of settings by accidentally touching of the screen.

Still available controls for manual operation are:

- The keys at the front panel, including the rotary knob
- The external mouse and keyboard
- Remote operation over VNC

The instrument indicates the locked touchscreen by an icon .

Unlocking is possible via VNC, external controls or remote control.

"VNC Only"

Locks the keys at the front panel, the touchscreen and externally connected keyboard and mouse.

The display on the screen remains and shows the current settings and changes.

The instrument indicates the activated "VNC only" feature by the icon .

Unlocking is possible via VNC or turning off and on again.

"Display Only"

Locks the manual operation of the instrument. The display on the screen remains and shows the current settings and changes.

This security feature protects the instrument against unauthorized access, but still shows the current settings and processes, for example when you operate the instrument via remote control.

The function disables:


- The touchscreen functionality of the display
- The keys at the front panel of the instrument
- The external mouse and keyboard

The instrument indicates the locked controls by a padlock  softkey.

How to unlock: see ["Unlocking \(reactivating\) the user interface for manual operation"](#) on page 375.

"Disabled" Locks the display and all controls for the manual operation of the instrument.
This security feature protects the instrument against unauthorized reading and access, for example when you operate the instrument via remote control.
The function disables:

- The display
- The touchscreen
- The keys at the front panel of the instrument
- The external mouse and keyboard

The screen shuts off and displays a padlock symbol  instead.
How to unlock: see ["Unlocking \(reactivating\) the user interface for manual operation"](#) on page 375.

Remote command:

:SYSTem:ULOCK on page 743

:SYSTem:DLOCK on page 742

:SYSTem:KLOCK on page 742

Enabling a locked user interface for manual operation

Follow the instructions listed in ["Unlocking \(reactivating\) the user interface for manual operation"](#) on page 375.

Remote command:

:SYSTem:ULOCK on page 743


:SYSTem:DLOCK on page 742

:SYSTem:KLOCK on page 742

12.4.3 Configuring LAN services


Access:

1. Select "System Config > Setup > Security > Security > LAN Services > Main Services".



In the "Main Services" side tab, you can individually enable or disable the supported LAN interface services.

2. Select "System Config > Setup > Security > Security > LAN Services > Samba Services".



In the "Samba Services" side tab, you can activate older versions of the SMB client and SMB server.

How to:

- ["Disabling the LAN interface"](#) on page 373
- ["Disabling LAN services"](#) on page 374
- ["Activating SMB version 1.0/2.0 client and server"](#) on page 374

Common Services

Enable or disable the LAN interface and supported LAN interface services.

LAN ← Common Services

Enables the LAN interface in general, and thus provides remote access via all unlocked services.

Enable LAN Services individually ← Common Services

Enables or disables the following interface services individually.

"SCPI over LAN"

Activates access over LAN to control the instrument remotely, by using SCPI (Standard Commands for Programmable Instruments) commands.

See also ["To start remote control with R&S VISA"](#) on page 436.

"VNC"

Activates access over VNC (Virtual Network Computing) interface, a graphical desktop sharing system that uses RFB protocol to control the instrument remotely.

See also [Chapter 13.14, "To operate the instrument using VNC"](#), on page 452.

"SSH (SCP)"

Activates access over SSH (Secure Shell), a network protocol for secure data communication.

"Remote Support"

Activates remote support over SSH.

Per default, this service is disabled. It provides communication for service support purposes only.

"HTTP"

Activates access via HTTP (Hyper Text Transfer Protocol), the application protocol for hypermedia information systems.

"FTP"

Activates access over FTP (File Transfer Protocol), used to transfer files from a host to the instrument and vice versa.

See also [Chapter 11.9.2, "Accessing the file system of the R&S SMA100B over FTP"](#), on page 329.

"SMB (Samba)"

Activates access to SMB (Server Message Block), used for providing shared access to files, printers and serial ports of a network.

See also [Chapter 11.9.3, "Accessing the R&S SMA100B file system using SMB \(Samba\)"](#), on page 330.

"Avahi (Zeroconf)"

Activates Avahi, a service for automatic configuration of the instrument in a network environment.

"Software Update"

Allows updating the software.

Samba Services

Activate or deactivate support of SMB client and SMB server version 1.0 and 2.0 of the SMB protocol.

Support of version 1.0 and 2.0 is additional to the current SMB protocol version supported in the firmware. This firmware supports SMB protocol versions up to version 4.

SMB 1.0/2.0 Client ← Samba Services

Activates support of the SMB client compatible with SMB protocol versions 1.0 and 2.0.

SMB 1.0/2.0 Server ← Samba Services

Activates support of the SMB server compatible with SMB protocol versions 1.0 and 2.0.

Security Password

Enters the password that is required to enable or to disable the settings protected by a security password. Default is 123456.

How to:

- "Disabling the LAN interface" on page 373
- "Disabling LAN services" on page 374
- "Changing the default security password" on page 373.

Accept

Applies the modified settings, provided the security password is entered and correct.


12.4.4 Password management

Access:

1. Select "System Config > Setup > Security > Security > Password Management > User Password".

In this tab, you can assign the security and a user-defined password.

2. Select "System Config > Setup > Security > Security > Password Management > Security Password".

General	LAN Services	Password Management	
Old Password		User Password	
New Password		Security Password	
Confirm Password			
		 Change Password	

How to:

- ["Changing the default user password of the instrument"](#) on page 373.
- ["Changing the default security password"](#) on page 373.

User Name

Indicates the user name used for access to the Linux operating system and valid for VNC, FTP and SMB (Samba) access.

User Password

Access: select "System Config > Setup > Security > Security > Password Management > User Password".

Allows you to change and confirm the user password.

Old Password ← User Password

Enters the current user password. The default password is "instrument".

Note: We recommend that you change the default password before connecting the instrument to a network.

How to:

- ["Changing the default user password of the instrument"](#) on page 373.
- ["Changing the default security password"](#) on page 373.

Note: Note that you cannot reset the password to factory state.

If you encounter problems with the password, contact the Rohde & Schwarz customer support, see [Chapter 15.9, "Contacting customer support"](#), on page 782.

New Password ← User Password

Enters the new user password.

The security password can contain decimal characters only.

Confirm Password ← User Password

Confirms the new user password by repeating.

How to:

- ["Changing the default user password of the instrument"](#) on page 373.

- ["Changing the default security password"](#) on page 373.

Change Password ← User Password

Changes the user password accordingly.

Security Password

Access: select "System Config > Setup > Security > Security > Password Management > Security Password".

Enables you to change and confirm the security password.

Old Password ← Security Password

Enters the currently used security password. The default password is '123456'.

Note: We recommend that you change the default password before connecting the instrument to a network.

How to:

- ["Changing the default user password of the instrument"](#) on page 373.
- ["Changing the default security password"](#) on page 373.

The security password is required when changing the status of the USB and LAN interface or other security settings.

Note: Note that you cannot reset the password to factory state.

If you encounter problems with the password, contact the Rohde & Schwarz customer support, see [Chapter 15.9, "Contacting customer support"](#), on page 782.

New Password ← Security Password

Enters the new security password.

The security password can contain decimal characters only.

Confirm Password ← Security Password

Confirms the new security password by repeating.

How to:

- ["Changing the default user password of the instrument"](#) on page 373.
- ["Changing the default security password"](#) on page 373.

Change Password ← Security Password

Changes the password accordingly.

12.4.5 How to prevent unauthorized access

The default computer name and user password are *instrument*. The user password is the password required for VNC, FTP and SMB (samba) connections. If, for example, the VNC service or FTP are enabled, anyone in the network who knows the computer name and user password of the instrument can access it.

The default security password is 123456. The security password is required when changing the status of the USB and LAN interface.

To prevent unauthorized access, use the following configurations exclusively or complementary:

- ["Changing the default user password of the instrument"](#) on page 373
- ["Changing the default security password"](#) on page 373
- ["Disabling the LAN interface"](#) on page 373
- ["Disabling LAN services"](#) on page 374
- ["Activating SMB version 1.0/2.0 client and server"](#) on page 374
- ["Disabling the frequency and level indication in the status bar"](#) on page 374
- ["Deactivating the user interface"](#) on page 374

If security is a concern, see the document instrument security procedures for comprehensive description.

Changing the default user password of the instrument

- **Note:** We recommend that you change the default password before connecting the instrument to a network.

How to:

- ["Changing the default user password of the instrument"](#) on page 373.
 - ["Changing the default security password"](#) on page 373.
- a) Select "System Config > Setup > Security > Security > Password Management > User Password".
 - b) Enter the current password in the "Old Password" field.
 - c) Enter the new password in the "New Password" and "Confirm Password" fields.
 - d) Select "Change Password".

The user password is changed; the user name is displayed ("Security > Password Management > User Password > User Name").

Changing the default security password

- **Note:** We recommend that you change the default password before connecting the instrument to a network.

How to:

- ["Changing the default user password of the instrument"](#) on page 373.
 - ["Changing the default security password"](#) on page 373.
- a) Select "System Config > Setup > Security > Security > Password Management > Security Password".
 - b) Enter the current password in the "Old Password" field.
The default password is 123456.
 - c) Enter the new password in the "New Password" and "Confirm Password" fields.
 - d) Select "Change Password".

Disabling the LAN interface

1. Select "System Config > Setup > Security > Security > LAN Services > Main Services".

2. Select "LAN > Off".

All LAN connections and hence all LAN services are disabled.

Disabling LAN services

1. Select "System Config > Setup > Security > Security > LAN Services > Main Services".
2. Select, for example, "FTP > Off" or "VNC > Off".
3. Enter the [Security Password](#).
4. Select "Accept".

Activating SMB version 1.0/2.0 client and server

By default, support of SMB client and SMB server of the SMB protocol versions 1.0 and 2.0 is deactivated.

Activate support only, if needed:

1. Select "System Config > Setup > Security > Security > LAN Services > Samba Services".
2. Select "SMB 1.0/2.0 Client > On" and "SMB 1.0/2.0 Server > On".
3. Enter the [Security Password](#).
4. Select "Accept".

Disabling the frequency and level indication in the status bar

These settings are useful to prevent unauthorized personnel from reading the display, when you remotely control the instrument from a different location.

1. Select "System Config > Setup > Security > General > Manual Operation".
2. Select "Annotation Frequency > Off" or "Annotation Amplitude > Off".
3. Enter the [Security Password](#).
4. Select "Accept".

Deactivating the user interface


1. Select "System Config > Setup > Security > General > Manual Operation".
2. Select "User Interface > Disabled".
3. Enter the [Security Password](#).
4. Select "Accept".

The screen shuts off and displays a padlock symbol  instead.

There are further possible configurations. For details, see ["User Interface"](#) on page 366.

Unlocking (reactivating) the user interface for manual operation

1. In manual operation:
 - a) On the instrument's keypad or external keyboard, press any key.
The instrument prompts you to enter the security password for unlocking.



If you press the character of the first key, the input field accepts the character immediately.

- b) Delete the entry before inserting the password.
Enter the security password **123456**.
2. In remote control mode:
 - a) Send the command `SYST:ULOC ENABled` to release all locks at once.
 - b) Send the command `SYST:KLOC OFF` to unlock the keyboard and touchscreen.
 - c) Send the command `SYST:DLOC OFF` to release all locks.

Via remote control, there is no password required.

12.5 Undoing or restoring actions


"Undo" is a function that removes the effect of the last action on the instrument and reverts it to an older state. Conversely, "Redo" restores a previously undone action.

You can "Undo/Redo" actions according to two criteria:

- Step by step
Gradually undo/redo the actions in reverse order as previously performed.
Depending on the available memory the "Undo/Redo" steps may restore all actions.
- Multiple steps at once
Select any specific action in the history list to "Undo/Redo" multiple actions in a single step.
Note: This mode requires a system restoration file on the instrument.

Access:

- ▶ Select "Setup > Settings > Undo/Redo".



The dialog contains all functions for enabling the "Undo/Redo" functionality.

Settings:

State.....	376
History List.....	376
Clear History.....	376
Apply.....	376

State

Enables the recording of the performed actions.

History List

Lists the performed actions, provided "Undo/Redo" state is "On".

Clear History

Deletes the recorded list of the performed steps.

Apply

Performs the "Undo/Redo".

If you select a previously performed action of the list, all subsequent actions are undone. The list entries remain.


If you select a subsequently executed action, you can restore all the actions undone up to this state.

12.6 Shutting down and rebooting the instrument

The [On/Standby] front panel key switches the instrument from the standby to the ready state or vice versa. In remote operation from a remote computer or in manual control, there is another possibility to shut down the instrument or to reboot the system.

Access:

- Select "System Config > Setup > Maintenance > Shut Down".



- [:SYSTem:REBoot](#) on page 760
- [:SYSTem:SHUTdown](#) on page 760

13 Network operation and remote control

As an alternative to the interactive operation directly at the instrument, you can operate the R&S SMA100B also from a remote location.

The various interfaces provide flexible access to the instrument, such as *remote control*, *remote operation* or *remote file access*. These remote access modes are fundamentally different, although they are often considered interchangeable, as described in [Overview of remote access modes](#).

[Figure 13-1](#) shows the possibilities of the physical connection (interfaces) for remote access.



The following descriptions provide information required for operating the R&S SMA100B remotely. The information applies to all applications and operating modes supported by the instrument. Definitions specified in the SCPI standard are not provided.

For basic knowledge on remote control operation and additional information, see the following documents, available on the Rohde & Schwarz website:

- [Remote control via SCPI](#)
- [1GP72: Connectivity of Rohde&Schwarz Signal Generators](#)
- [1MA208: Fast Remote Instrument Control with HiSLIP](#)




Figure 13-1: Supported remote connections

• Overview of remote access modes	379
• Remote control interfaces and protocols	380
• Remote control programs and libraries	385
• Status reporting system	388
• Remote access settings	396
• LXI settings	419
• To configure the instrument for remote access	426
• To establish a remote control session over LAN	431
• To establish a remote control session over GPIB	440
• To establish a remote control session over USB	440

• To trace messages with the LXI web browser interface	441
• To return to manual operation	442
• To automate tasks with remote command scripts	442
• To operate the instrument using VNC	452
• References	458

13.1 Overview of remote access modes

This section outlines the possible access modes and their major characteristics.

Remote control (SCPI)

- A remote PC controls the instrument, usually via VISA (Virtual Instrument Software Architecture) interfaces.
- Remote control disables the manual operation of the instrument; you can set different lock states.
- The GUI is not visible.
- Remote control commands (SCPI) perform the settings, either individually or in sequences (SCPI programs).
- Using SCPI programs is faster than the manual operation, since they automate repeating applications.

Remote operation (VNC)

- A remote device accesses the instrument via the common platform technology VNC (Virtual Network Computing).
- The protocol allows simultaneous operation from several remote devices and the instrument nevertheless remains locally operable.
- The GUI is visible.
- To perform the settings, you can operate the instrument as with the manual control.
- During remote operation via VNC, the direct control of the instrument is not disabled.
You can control the instrument from the front panel and via the remote computer alternately.
- Clients supporting remote operation depend on the used remote device, see [Table 13-1](#).
- How to: see [Chapter 13.14, "To operate the instrument using VNC"](#), on page 452.

Table 13-1: Supported VNC operation modes

Remote device	VNC client	Requirements	Characteristics
Desktop (Windows, Linux, Mac™OS)	<ul style="list-style-type: none"> Ultr@VNC Other dedicated client software 	<i>Ultr@VNC or Client Software</i> must be installed.	Fast, supports several options like full screen mode or auto-login.
	<ul style="list-style-type: none"> Any web browser 	<i>Java Runtime</i> must be installed and activated in the browser settings.	Fast and convenient - only the instrument address required. Java runtime is sometimes considered as security concern.
	<ul style="list-style-type: none"> Web browser with HTML5 	<i>Web sockets</i> must be supported.	Slower than the other modes. No additional installation or activation required. No security concern.
Smart device (Tablet/ smartphone)	<ul style="list-style-type: none"> Dedicated client App 	<i>App</i> must be installed.	Fast, supports several options like full screen mode or auto-login.
	<ul style="list-style-type: none"> Web browser with HTML5 	<i>Web sockets</i> must be supported.	Support of QR code scanning Slower than a dedicated App.

Remote file access (FTP, SAMBA/SMB)

- A remote client accesses the instrument's file system, using the protocols FTP (file transfer protocol) and SAMBA/SMB (server message block).
- The protocols enable you to transfer files from or to the instrument and to get direct access to its file sharing directory *share*.

How to:

[Chapter 11.9, "How to transfer files from and to the instrument"](#), on page 327.

["Activating SMB version 1.0/2.0 client and server"](#) on page 374

13.2 Remote control interfaces and protocols

The instrument supports various interfaces for remote control. [Table 13-2](#) gives an overview on the connectivity:

Table 13-2: Remote control interfaces and protocols

Interface	Protocols, VISA ^{*)} address string and library	Remarks
Local area network (LAN)	<ul style="list-style-type: none"> • HiSLIP High-Speed LAN Instrument Protocol (IVI-6.1) TCPIP::host address::hislip0[::INSTR] VISA • VXI-11 TCPIP::host address[:: LAN device name][::INSTR] VISA • Socket communication (Raw Ethernet, simple Telnet) TCPIP::host address[:: LAN device name]::<port>::SOCKET VISA or socket controller 	<p>The LAN connector is at the rear panel of the instrument.</p> <p>The interface is based on TCP/IP, see Chapter 13.2.1, "LAN interface", on page 381 for details on the address information.</p>
USB	<ul style="list-style-type: none"> • USBTMC USB::<vendor ID>::<product ID>:: <serial number>[::INSTR] VISA 	<p>The USB In connector is at the rear panel of the instrument.</p> <p>For a description of the interface, see Chapter 13.2.2, "USB interface", on page 383</p>
GPIB (IEC/IEEE Bus Interface)	<ul style="list-style-type: none"> • VISA^{*)} address string: GPIB::<address>[::INSTR] (no secondary address) VISA (optional) 	<p>The optional GPIB bus interface according to standard IEC 625.1/IEEE 488.1 is at the rear panel of the instrument.</p> <p>For a description of the interface, see Chapter 13.2.3, "GPIB interface (IEC/IEEE bus interface)", on page 384.</p>

^{*)} VISA (Virtual Instrument Software Architecture) is a standardized software interface library providing input and output functions to communicate with instruments. A VISA installation on the controller is a prerequisite for remote control over LAN (when using VXI-11 or HiSLIP protocol), USB and serial interface. When using socket communication or the GPIB interface, VISA installation is optional. For basic information, see [Remote control via SCPI](#).



<http://www.rohde-schwarz.com/rsvisa> provides the standardized I/O software library R&S VISA for download at the Rohde & Schwarz website <http://www.rohde-schwarz.com/rsvisa>.

How to: [Chapter 13.8, "To establish a remote control session over LAN"](#), on page 431 describes how to configure the remote control interfaces.

- [LAN interface](#)..... 381
- [USB interface](#)..... 383
- [GPIB interface \(IEC/IEEE bus interface\)](#)..... 384
- [LXI browser interface](#)..... 385

13.2.1 LAN interface

To be integrated in a LAN, the instrument is equipped with a LAN interface, consisting of a connector, a network interface card and protocols.

For remote control, the PC and the instrument must be connected over the LAN interfaces to a common network with TCP/IP network protocol. The instruments are connected using a commercial RJ45 cable (shielded or unshielded twisted-pair category 5). The TCP/IP network protocol and the associated network services are preconfig-

ured on the instrument. Software for instrument control and, if necessary, the VISA program library must be installed on the controller.



Identifying instruments in a network

If several instruments are connected to the network, each instrument has its own IP address and associated resource string. The controller identifies these instruments by the resource string.

13.2.1.1 VISA resource strings

The VISA resource string is required to establish a communication session between the controller and the instrument in the LAN. The resource string is a unique identifier, composed of the specific IP address of the instrument and some network and VISA-specific keywords.

TCPIP::<host address>[:<LAN device name>][:INSTR]

TCPIP	= designates the network protocol
host address	= designates the IP address or hostname of the instrument
[:LAN device name]	= defines the protocol and the instance number of a subinstrument
[:INSTR]	= indicates the instrument resource class (optional)

The **IP address** (host address/computer name) is used by the programs to identify and control the instrument. It is automatically assigned by the DHCP server the first time the device is registered in the network. Optionally, you can also assign its **LAN device name**.

If assigned, the IP address is displayed in the home screen. You can adjust it manually with the parameter the "System Config > Remote Access > Network" > [IP Address](#)
[Enabling a locked user interface for manual operation](#).

The following section lists the characteristics of the VISA resource strings for the corresponding interface protocols. The emphasized characters determine the protocol.



For description of the interface protocols, control commands and messages, refer to [Remote control via SCPI](#).

HiSLIP

TCPIP::<host address>::hislip0[:INSTR]

hislip0 = HiSLIP device name, designates that the interface protocol HiSLIP is used (mandatory)

hislip0 is composed of `[::HiSLIP device name[,HiSLIP port]]` and must be assigned.

Example:

TCPIP::192.1.2.3::hislip0

VXI-11

TCPIP::**<host address>**::**inst0**::INSTR

[::inst0] = LAN device name, indicates that the VXI-11 protocol is used (optional)

inst0 currently selects the VXI-11 protocol by default and can be omitted.

Example:

TCPIP::192.1.2.3::INSTR

Socket communication

TCPIP::**<host address>**::**<port>**::SOCKET

port = determines the used port number

SOCKET = indicates the raw network socket resource class

Socket communication requires the specification of the port (commonly referred to as port number) and of "SOCKET" to complete the resource string.

Basically, instruments from Rohde & Schwarz use port number 5025 for socket communication.

Example:

TCPIP::192.1.2.3::5025::SOCKET

13.2.2 USB interface

Option: R&S SMAB-B86

For remote control using USB, the controller PC and the instrument must be connected over the USB type B interface. Software for instrument control and the VISA program library must be installed on the controller.

The serial interface "RS232" enables you to connect the instrument over serial interface. You can connect to the interface by using the external USB/serial-adaptor R&S TS1-USB (see recommended extras in the data sheet) and a serial crossover (null modem) cable.

VISA detects and configures the Rohde & Schwarz instrument automatically when the USB connection is established. You do not have to install a separate driver.

USBTMC (USB Test & Measurement Class Specification) is a protocol that is built on top of USB for communication with USB devices. It defines class code information of the instrument, that identifies its functionality to load the respective device driver. Using VISA library, the protocol supports service request, trigger, and other specific operations.

13.2.2.1 USB resource string

The resource string represents an addressing scheme that is used to establish a communication session with the instrument. It is based on the instrument address and some instrument- and vendor-specific information.

The USB resource string syntax is as follows:

USB::<vendor ID>::<product ID>::<serial number>[:INSTR]

USB = denotes the used interface
 <vendor ID> = is the manufacturer ID for Rohde & Schwarz
 <product ID> = is the product identification of the instrument
 <serial number> = is the individual serial number at the rear of the instrument
 [:INSTR] = indicates the instrument resource class (optional)

To set the USB resource string, see [Remote access settings](#).

Example:

USB::0x0AAD::0x01DD::100001::INSTR

0x0AAD is the vendor ID for Rohde & Schwarz.

0x01DD is the product ID for the R&S SMA100B

100001 is the serial number of the particular instrument.

13.2.2.2 RS232 resource string

The RS232 resource string represents the addressing scheme for a device connected to the serial interface of the instrument.

The RS232 resource string syntax is as follows:

ASRL<port number>[:INSTR]

ASRL is the name of the serial interface

<port number> is the number of the serial interface

Example:

ASRL1::INSTR

13.2.3 GPIB interface (IEC/IEEE bus interface)

Option: R&S SMAB-B86

To control the R&S SMA100B over the GPIB bus, the instrument and the controller PC must be connected with a GPIB bus cable. A GPIB bus card, the card drivers and the program libraries for the used programming language must be installed on the controller.



For description of the characteristics, control commands and messages of the GPIB interface, refer to [Remote control via SCPI](#).

GPIB address

The controller PC addresses the instrument with the GPIB bus channel, see [Chapter 13.5.3, "GPIB address settings"](#), on page 403. GPIB provides channel addresses from 0 to 30.

The GPIB resource string syntax is as follows:

`GPIB:://<channel>[:INSTR]`

GPIB	= denotes the used interface
<channel address>	= the used channel
[:INSTR]	= indicates the instrument resource class (optional)

Note: If the VISA implementation supports the GPIB interface, you can optionally define the VISA Instrument Control Resource (INSTR). It is used to define the basic operations and attributes for a device, such as reading, writing, or triggering.

Example:

`GPIB::28::INSTR`

28 is the selected GPIB bus channel

13.2.4 LXI browser interface

The LXI browser interface allows easy configuration of the LAN and remote control of the R&S SMA100B without additional installation requirements. The instrument's LXI browser interface works correctly with all W3C compliant browsers.

See [Chapter 13.15.1, "LXI functionality"](#), on page 458 for more about LXI.

The LAN settings are configured using the instrument's LXI browser interface described in [Chapter 13.6.2.1, "LAN configuration"](#), on page 421.

13.3 Remote control programs and libraries

This section shows how the remote-control programs access the instrument, and the libraries they require for the corresponding interface protocols.




Figure 13-2: Overview of remote control interfaces, protocols and libraries

Possible setups and access functions

The following examples give an overview of dependencies between the available libraries, the possible interfaces and protocols, and whether an instrument driver is provided. For detailed information, see the application note [1GP72: Connectivity of Rohde&Schwarz Signal Generators](#).

Example: Remote control (application) program using VISA




Figure 13-3: Application program using VISA

Protocol	Remote control program
Socket	<pre>viOpen (... , "TCPIP:SMA100B-102030::5025::SOCKET", ...) viPrintf (... , "SOUR:FREQ 2GHz\n")</pre>
VXI-11	<pre>viOpen (... , "TCPIP:SMA100B-102030::inst0::INSTR", ...) viPrintf (... , "SOUR:FREQ 2GHz\n")</pre>

Protocol	Remote control program
HiSLIP	<pre>viOpen (... , "TCPIP:SMA100B-102030::hislip0::INSTR", ...) viPrintf (... , "SOUR:FREQ 2GHz\n")</pre>
USBTMC	<pre>viOpen (... , "USB::0x0AAD::0x01DD::100001::INSTR", ...) viPrintf (... , "SOUR:FREQ 2GHz\n")</pre>
GPIB	<pre>viOpen (... , "GPIB::28::INSTR", ...) viPrintf (... , "SOUR:FREQ 2GHz\n")</pre>

Example: Remote control program using instrument driver (VISA available)




Figure 13-4: Application using instrument driver (VISA available)

Protocol	Remote control program
Socket	<pre>rssma_init ("TCPIP:SMA100B-102030::5025::SOCKET", ...) rssma_SetFrequency (... , 2e9)</pre>
VXI-11	<pre>rssma_init ("TCPIP:SMA100B-102030::inst0::INSTR", ...) rssma_SetFrequency (... , 2e9)</pre>
HiSLIP	<pre>rssma_init ("TCPIP:SMA100B-102030::hislip0::INSTR", ...) rssma_SetFrequency (... , 2e9)</pre>
USBTMC	<pre>rssma_init ("USB::0x0AAD::0x01DD::100001::INSTR", ...) rssma_SetFrequency (... , 2e9)</pre>
GPIB	<pre>rssma_init ("GPIB::28::INSTR", ...) rssma_SetFrequency (... , 2e9)</pre>

Example: Remote control program using instrument driver (VISA not available)




Figure 13-5: Remote control program using instrument driver (VISA not available)

Protocol	Remote control program
Socket	<code>rssma_init ("TCPIP:SMA100B-102030::5025::SOCKET", ...)</code> <code>rssma_SetFrequency (... , 2e9)</code>
GPIB	<code>rssma_init ("GPIB::28::INSTR", ...)</code> <code>rssma_SetFrequency (... , 2e9)</code>

13.4 Status reporting system

The status reporting system stores all information on the current operating state of the instrument, and on errors which have occurred. This information is stored in the status registers and in the error queue.

You can query both with the commands of the [STATus subsystem](#).

13.4.1 Hierarchy of the status registers

The [Figure 13-6](#) shows the hierarchical structure of information in the status registers (ascending from left to right).




Figure 13-6: Graphical overview of the status registers hierarchy

OPER = Operation Status Summary Bit
 RQS/MSS = Service Request Generation
 ESB = Standard Event Status Summary Bit
 MAV = Message Available in Output Queue
 QUES = Questionable Status Summary Bit
 2 = Error- /Event-Queue
 1, 0 = not used

Note: This legend explains the abbreviations to the Status Byte Register.

The R&S SMA100B uses the following status registers:

- **Status Byte (STB)** and **Service Request Enable (SRE)**, see [Chapter 13.4.3, "Status byte \(STB\) and service request enable register \(SRE\)"](#), on page 392.

- **Standard Event Status**, i.e. the Event status Register (ESR) and the Event Status Enable (ESE), see [Chapter 13.4.4, "Event status register \(ESR\) and event status enable register \(ESE\)"](#), on page 393.
- **Questionable Status** and **Operation Status**, the (SCPI status registers, see [Chapter 13.4.2, "Structure of a SCPI status register"](#), on page 390, [Chapter 13.4.5, "Questionable status register \(STATus:QUEStionable\)"](#), on page 393 and [Chapter 13.4.6, "Operation status register \(STATus:OPERation\)"](#), on page 394.
- **Output-Queue**
The output queue contains the messages the instrument returns to the controller. It is not part of the status reporting system but determines the value of the `MAV` bit in the `STB` and thus is represented in the overview.
- **Error- /Event-Queue**
The error-/event-queue contains all errors and events that have occurred in the past. When reading the queue, the instrument starts with the first occurred error/event.

All status registers have the same internal structure.



SRE, ESE

The service request enable register `SRE` can be used as `ENABLE` part of the `STB` if the `STB` is structured according to SCPI. By analogy, the `ESE` can be used as the `ENABLE` part of the `ESR`.

13.4.2 Structure of a SCPI status register

Each SCPI status register consists of five parts. Each part has a width of 16 bits and has different functions. The individual bits are independent of each other, i.e. each hardware status is assigned a bit number, which is valid for all five parts. Bit 15 (the most significant bit) is set to zero for all parts. Thus, the contents of the register parts can be processed by the controller as positive integers.




Figure 13-7: The status-register model

Description of the five status register parts

The five parts of a SCPI status register have different properties and functions:

- **CONDition**

The **CONDition** part is written directly by the hardware or it mirrors the sum bit of the next lower register. Its contents reflect the current instrument status. This register part can only be read, but not written into or cleared. Its contents are not affected by reading.

- **PTRansition / NTRansition**

The two transition register parts define which state transition of the **CONDition** part (none, 0 to 1, 1 to 0 or both) is stored in the **EVENT** part.

The **Positive-TRansition** part acts as a transition filter. When a bit of the **CONDition** part is changed from 0 to 1, the associated **PTR** bit decides whether the **EVENT** bit is set to 1.

- **PTR** bit =1: the **EVENT** bit is set.
- **PTR** bit =0: the **EVENT** bit is not set.

This part can be written into and read as required. Its contents are not affected by reading.

The **Negative-TRansition** part also acts as a transition filter. When a bit of the **CONDition** part is changed from 1 to 0, the associated **NTR** bit decides whether the **EVENT** bit is set to 1.

- **NTR** bit =1: the **EVENT** bit is set.
- **NTR** bit =0: the **EVENT** bit is not set.

This part can be written into and read as required. Its contents are not affected by reading.

- **EVENT**

The **EVENT** part indicates whether an event has occurred since the last reading, it is the "memory" of the condition part. It only indicates events passed on by the transition filters. It is permanently updated by the instrument. This part can only be read by the user. Reading the register clears it. This part is often equated with the entire register.

- **ENABLE**

The **ENABLE** part determines whether the associated **EVENT** bit contributes to the sum bit (see below). Each bit of the **EVENT** part is "ANDed" with the associated **ENABLE** bit (symbol '&'). The results of all logical operations of this part are passed on to the sum bit via an "OR" function (symbol '+').

ENABLE bit = 0: the associated **EVENT** bit does not contribute to the sum bit

ENABLE bit = 1: if the associated **EVENT** bit is "1", the sum bit is set to "1" as well.

This part can be written into and read by the user as required. Its contents are not affected by reading.

Sum bit

The sum bit is obtained from the **EVENT** and **ENABLE** part for each register. The result is then entered into a bit of the **CONDition** part of the higher-order register.

The instrument automatically generates the sum bit for each register. Thus an event can lead to a service request throughout all levels of the hierarchy.

13.4.3 Status byte (STB) and service request enable register (SRE)

The `STatus Byte` (STB) is already defined in IEEE 488.2. It provides a rough overview of the instrument status by collecting the pieces of information of the lower registers. A special feature is that bit 6 acts as the sum bit of the remaining bits of the status byte.

The STB is read using the command `*STB?` or a serial poll.

The `STatus Byte` (STB) is linked to the `Service Request Enable` (SRE) register. Each bit of the STB is assigned a bit in the SRE. Bit 6 of the SRE is ignored. If a bit is set in the SRE and the associated bit in the STB changes from 0 to 1, a service request (SRQ) is generated. The SRE can be set using the command `*SRE` and read using the command `*SRE?`.

Table 13-3: Meaning of the bits used in the status byte

Bit No.	Meaning
0...1	Not used
2	Error Queue not empty The bit is set when an entry is made in the error queue. If this bit is enabled by the SRE, each entry of the error queue generates a service request. Thus an error can be recognized and specified in greater detail by polling the error queue. The poll provides an informative error message. This procedure is to be recommended since it considerably reduces the problems involved with remote control.
3	QUESTionable status register summary bit The bit is set if an <code>EVENT</code> bit is set in the <code>QUESTionable</code> status register and the associated <code>ENABLE</code> bit is set to 1. A set bit indicates a questionable instrument status, which can be specified in greater detail by querying the <code>STATus:QUESTionable</code> status register.
4	MAV bit (message available) The bit is set if a message is available in the output queue which can be read. This bit can be used to enable data to be automatically read from the instrument to the controller.
5	ESB bit Sum bit of the event status register. It is set if one of the bits in the event status register is set and enabled in the event status enable register. Setting of this bit indicates a serious error which can be specified in greater detail by polling the event status register.
6	MSS bit (main status summary bit) The bit is set if the instrument triggers a service request. This is the case if one of the other bits of this registers is set together with its mask bit in the service request enable register SRE.
7	STATus:OPERation status register summary bit The bit is set if an <code>EVENT</code> bit is set in the <code>OPERation</code> status register and the associated <code>ENABLE</code> bit is set to 1. A set bit indicates that the instrument is just performing an action. The type of action can be determined by querying the <code>STATus:OPERation</code> status register.

13.4.4 Event status register (ESR) and event status enable register (ESE)

The ESR is defined in IEEE 488.2. It can be compared with the `EVENT` part of a SCPI register. The event status register can be read out using command `*ESR?`.

The ESE corresponds to the `ENABLE` part of a SCPI register. If a bit is set in the ESE and the associated bit in the ESR changes from 0 to 1, the ESB bit in the STB is set. The ESE register can be set using the command `*ESE` and read using the command `*ESE?`.

Table 13-4: Meaning of the bits used in the event status register

Bit No.	Meaning
0	Operation Complete This bit is set on receipt of the command <code>*OPC</code> exactly when all previous commands have been executed.
1	Not used
2	Query Error This bit is set if either the controller wants to read data from the instrument without having sent a query, or if it does not fetch requested data and sends new instructions to the instrument instead. The cause is often a query which is faulty and hence cannot be executed.
3	Device-dependent Error This bit is set if a device-dependent error occurs. An error message with a number between -300 and -399 or a positive error number, which denotes the error in greater detail, is entered into the error queue.
4	Execution Error This bit is set if a received command is syntactically correct but cannot be performed for other reasons. An error message with a number between -200 and -300, which denotes the error in greater detail, is entered into the error queue.
5	Command Error This bit is set if a command is received, which is undefined or syntactically incorrect. An error message with a number between -100 and -200, which denotes the error in greater detail, is entered into the error queue.
6	User Request This bit is set when the instrument is switched over to manual control.
7	Power On (supply voltage on) This bit is set on switching on the instrument.

13.4.5 Questionable status register (STATus:QUESTionable)

This register contains information on questionable instrument states. Such states may occur when the instrument is not operated in compliance with its specifications.

To read the register, use the query commands `STAT:QUEST:COND?` or `STAT:QUEST[:EVEN]?`.

Table 13-5: Meaning of the bits used in the questionable status register

Bit No.	Meaning
0–15	Not used

13.4.6 Operation status register (STATus:OPERation)

This condition part contains information on the actions currently being performed by the instrument, while the event part contains information on the actions performed by the instrument since the last readout of the register.

To read the register, use the query commands `STAT:OPER:COND?` or `STAT:OPER[:EVEN]?`.

Table 13-6: Meaning of the bits used in the operation status register

Bit No.	Meaning
0	Calibrating The bit is set during the calibration phase.
1–2	Not used
3	Sweeping This bit is set during a sweep in automatic or single mode.
4–15	Not used

13.4.7 Application of the status reporting system

The purpose of the status reporting system is to monitor the status of one or several devices in a measuring system. To do this and react appropriately, the controller must receive and evaluate the information of all devices. The following standard methods are used:

- **Service request** (SRQ) initiated by the instrument
- **Serial poll** of all devices in the bus system, initiated by the controller to find out who sent an SRQ and why
- Query of a **specific instrument status** by commands
- Query of the **error queue**

13.4.7.1 Service request

Under certain circumstances, the instrument can send a service request (SRQ) to the controller. Usually this service request initiates an interrupt at the controller, to which the control program can react appropriately. An SRQ is always initiated if one or several of bits 2, 4 or 5 of the status byte are set and enabled in the SRE. Each of these bits combines the information of the error queue or the output buffer. To use the possibilities of the service request effectively, all bits should be set to "1" in the enable registers SRE and ESE.

Example:

Use command `*OPC` to generate an SRQ .

`*ESE 1` - set bit 0 of ESE (Operation Complete)

`*SRE 32` - set bit 5 of SRE (ESB).

After its settings have been completed, the instrument generates an SRQ.

The SRQ is the only possibility for the instrument to become active on its own. Each controller program should set the instrument such that a service request is initiated in the case of malfunction. The program should react appropriately to the service request.

13.4.7.2 Serial poll

In a serial poll, just as with command `*STB`, the status byte of an instrument is queried. However, the query is realized via interface messages and is thus clearly faster.

The serial poll method is defined in IEEE 488.1 and used to be the only standard possibility for different instruments to poll the status byte. The method also works for instruments which do not adhere to SCPI or IEEE 488.2.

The serial poll is mainly used to obtain a fast overview of the state of several instruments connected to the controller.

13.4.7.3 Query of an instrument status

Each part of any status register can be read using queries. There are two types of commands:

- The common commands `*ESR?`, `*IDN?`, `*IST?`, `*STB?` query the higher-level registers.
- The commands of the `STATus` system query the SCPI registers (`STATus:QUEStionable...`)

The returned value is always a decimal number that represents the bit pattern of the queried register. This number is evaluated by the controller program.

Queries are usually used after an SRQ in order to obtain more detailed information on the cause of the SRQ.

13.4.7.4 Error queue

Each error state in the instrument leads to an entry in the error queue. The entries of the error queue are detailed plain text error messages that can be looked up in the Error Log or queried via remote control using `SYSTem:ERRor[:NEXT]?`. Each call of `SYSTem:ERRor[:NEXT]?` provides one entry from the error queue. If no error messages are stored there any more, the instrument responds with 0, "No error".

The error queue should be queried after every SRQ in the controller program as the entries describe the cause of an error more precisely than the status registers. Especially in the test phase of a controller program the error queue should be queried regu-

larly since faulty commands from the controller to the instrument are recorded there as well.

13.4.8 Reset values of the status reporting system

The following table contains the different commands and events causing the status reporting system to be reset. None of the commands, except of *RST and SYSTem:PRESet affect the functional instrument settings. In particular, DCL does not change the instrument settings.

Table 13-7: Resetting the status reporting system

Event	Switching on supply voltage Power-On-Status-Clear		DCL, SDC (Device Clear, Selected Device Clear)	*RST or SYSTem: PRESet	STATus: PRESet	*CLS
Effect	0	1				
Clear STB, ESR	-	Yes	-	-	-	Yes
Clear SRE, ESE	-	Yes	-	-	-	-
Clear PPE	-	Yes	-	-	-	-
Clear error queue	Yes	Yes	-	-	-	Yes
Clear output buffer	Yes	Yes	Yes	1)	1)	1)
Clear command processing and input buffer	Yes	Yes	Yes	-	-	-
1) The first command in a command line that immediately follows a <PROGRAM MESSAGE TERMINATOR> clears the output buffer.						

13.5 Remote access settings

This section outlines the settings required for accessing and configuring the provided remote control interfaces. It includes network settings, access addresses, emulation settings for using the command sets of other generators, and the access with smart devices.

About instrument emulations

You can remotely control the R&S SMA100B using the command set of another signal generator. With this function you can, for example, replace a signal generator with an R&S SMA100B in an automated test setup, without adjusting the command scripts used.



The R&S SMA100B also covers command sets of Rohde & Schwarz signal generators. To achieve optimal compatibility when replacing an instrument, we recommend that you select the emulation command set for the corresponding signal generator.

You find the remote control command sets supported by the R&S SMA100B in a selection list.

For more information, see the application note:

[1GP120: Remote Emulation with the R&S SMA100B Signal Generator.](#)

The selected instrument also defines the identification string that is retrieved with query `*IDN?`. If necessary, use the parameter `Mode` and `IDN String` to change this string.

As any other parameter, the remote control command set can also be changed remotely by the command `:SYSTem:LANGuage`.

While working in an emulation mode, the R&S SMA100B specific command set is disabled and the SCPI command `:SYSTem:LANGuage` is discarded.

To return to the SCPI command set of the R&S SMA100B, use the appropriate command of the selected command set.

If for example an HP generator is emulated, the HP command `EX` returns to the instrument-specific GPIB command set.

About health and utilization monitoring system (HUMS)

The R&S SMA100B comes with a health and utilization monitoring system (HUMS) providing information about the R&S SMA100B. Aim is to increase the overall utilization, to avoid downtime and to increase the overall security level of a fleet of instruments.

HUMS provides, for example, information about:

- Instrument identification, hardware components, software packages, licenses
- Usage of remote control, usage via keyboard / mouse, usage of test applications
- Hardware utilization and status, including S.M.A.R.T. data of the system drive
- User-defined static information, for example, an inventory code

Interfaces and protocols

The HUMS installation on the R&S SMA100B includes an SNMP agent and a REST service with HTTP endpoints. So you can access the health and usage information via LAN, using the SNMP protocol or the REST protocol. Accessing the data does not interfere with remote control via SCPI commands or with measurement execution.

Reference information for both protocols is available on the R&S SMA100B at the address `http://<instrument>/api/hums/v1/documents?name=<interface>`.

For `<instrument>`, enter the hostname (e.g. `SMA100B-102030`) or the IP address (e.g. `10.121.0.34`) of your instrument, as for access to the GUI.

For `<interface> = snmp`, you get a `.zip` file containing the MIB files for SNMP. For `<interface> = rest`, you get a web page with the OpenAPI specification of the REST API.

Address example: `http://SMA100B-102030/api/hums/v1/documents?name=snmp`.

The following table lists the REST endpoints and the SNMP MIB file names.

REST endpoint /api/hums/v1/...	SNMP MIB	Description	Typical data
documents	---	developer information	SNMP MIB files, swagger specification of HUMS REST endpoints
greetings	RS-GREETINGS-MIB	identity information	manufacturer, model, serial number, version
equipment/bios	RS-BIOS-INFO-MIB	BIOS information	BIOS manufacturer, version and release date
date-time	RS-TIME-DATE-MIB	time and date information	UTC and local time, timezone, dst (daylight savings time)
device-history	RS-DEVICE-HISTORY-MIB	history events	instrument-specific event information and notifications
device-tags	RS-DEVICE-TAGS-MIB	customer information	user-definable key information, associated with the instrument, e.g. asset number, owner, location
equipment	RS-EQUIPMENT-MIB	footprint information	hardware and software configuration, licenses
hums-info	RS-HUMS-INFO-MIB	basic information on the HUMS service	HUMS version, counter of SNMP and REST requests, amount of collected data, HUMS database size
storage	RS-STORAGE-MIB	S.M.A.R.T. data of drive	system drive temperature, drive health
system-info	RS-SYSTEM-INFO-MIB	a system overview	OS and BIOS version, IP address, locale
system-status	RS-SYSTEM-STATUS-MIB	system status information	global system status, static notifications
utilization	RS-UTILIZATION-MIB	utilization information	instrument activity, e.g., power on time, RF on time, option utilization, remote interface traffic

For detailed information about HUMS and its applications, refer to:

- The R&S®HUMS Health and Utilization Monitoring Service user manual, available on the Rohde & Schwarz website.
- The application note [GFM336: Instrument Health and Utilization Monitoring](#)

13.5.1 Network settings

Access:

- Select "System Config > Remote Access > Network".



In the "Network" dialog, you can configure the settings of the general network environment and specific identification parameters of the instrument in the network.

The remote commands required to configure the network remotely are described in [Chapter 14.18, "SYSTem subsystem"](#), on page 735.

How to: see [Chapter 3.1.7, "Connecting to LAN"](#), on page 27.

Network Status

Indicates that the instrument is connected to the network.

Remote command:

`:SYSTem:COMMunicate:NETWork:STATus?` on page 748

Restart Network

Terminates the network connection of the instrument and sets it up again. You can use this function to fix network problems.

Note: This function restarts only the connection of the instrument to the network. It does not impact the network itself.

Remote command:

`:SYSTem:COMMunicate:NETWork:REStart` on page 748

Hostname

Displays the hostname.

Each instrument is delivered with an assigned hostname, a logical name which can be used instead of the IP address. With the default network settings, the IP address is allocated by the DHCP server. This address can change each time the instrument is reconnected. Unlike the IP address, the hostname name does not change.

Note:

This function is password-protected. Unlock the protection level 1 to access it.

- We recommend that you do not change the default network settings or the host-name to avoid problems with the network connection.
If you change the hostname, be sure to use a unique name.

Remote command:

`:SYSTem:COMMunicate:NETWork[:COMMON]:HOSTname` on page 749

Workgroup

Sets the individual windows workgroup name of the R&S SMA100B. This parameter is required in case the instrument is integrated in a windows network.

This function is password-protected. Unlock the protection level 1 to access it.

Remote command:

`:SYSTem:COMMunicate:NETWork[:COMMON]:WORKgroup` on page 749

Address Mode

Selects the mode for assigning the IP address.

How to: [Chapter 13.7.2.1, "How to assign the IP address"](#), on page 428

"Auto (DHCP)"

Assigns the IP address automatically, provided the network supports DHCP (Dynamic Host Configuration Protocol).

"Static"

Enables you to assign the IP address manually.

Remote command:

`:SYSTem:COMMunicate:NETWork:IPAddress:MODE` on page 747

IP Address

Displays the IP address of the instrument in the network.

By default, the R&S SMA100B is configured to use dynamic TCP/IP configuration and to obtain the address information automatically. Setting [Address Mode](#) > "AUTO (DHCP)" denotes that the DHCP server is available. The instrument displays the assigned IP address read-only.

If the network does not support DHCP or there is no DHCP server available, the instrument tries to obtain the IP address using [Zeroconf \(Avahi\)](#) protocol. This feature enables the instrument to self-configure an IP address and subnet mask. Zeroconf (Avahi) IP addresses start with the number blocks 169.254.*.*, with the subnet mask of 255.255.

Note: An IP address that is assigned with the Zeroconf protocol although the network requires an IP address assigned from the DHCP server can cause network connection failures.

See [Chapter 15.5, "Resolving network connection failures"](#), on page 775.

If both services fail to connect, you can configure the address manually.

How to: ["To assign the IP address manually on the instrument"](#) on page 428

Remote command:

`:SYSTem:COMMunicate:NETWork:IPAddress` on page 747

Subnet Mask

Displays the bit group of the subnet in the host identifier.

The TCP/IP protocol is preinstalled with the subnet mask 255.255.255.0. If the DHCP server is available [Address Mode A AUTO \(DHCP\)](#), the setting is read-only. The subnet mask consists of four number blocks separated by dots. Each block contains 3 numbers in maximum (e.g. 100.100.100.100), but also one or two numbers are allowed in a block (as an example see the preinstalled address).

To assign the subnet mask manually, select [Address Mode > Static](#).

Note: When assigning the subnet mask manually, make sure that the address matches with the subnet mask of the controlling host interface.

How to:

["To assign the IP address manually on the instrument"](#) on page 428.

Remote command:

`:SYSTem:COMMunicate:NETWork[:IPAdDress]:SUBNet:MASK` on page 750

Default Gateway

Displays the gateway address.

This address identifies the router on the same network as the instrument that is used to forward traffic to destinations beyond the local network.

To assign the gateway address manually, select [Address Mode > "Static"](#).

Remote command:

`:SYSTem:COMMunicate:NETWork[:IPAdDress]:GATeway` on page 749

DNS Suffix

Displays the primary DNS (Domain Name System) suffix, that means the DNS name without the hostname part.

The DNS system uses the suffix for registration and name resolution for unique identification of the instrument in the entire network.

To assign the DNS suffix manually, select [Address Mode > "Static"](#).

Remote command:

`:SYSTem:COMMunicate:NETWork[:COMMon]:DOMain` on page 748

DNS Server

Determines the preferred server for name resolution. The DNS server contains the underlying numerical values that are required for name resolution of the hostname as part of the IP address.

To select the DNS server manually, select [Address Mode > "Static"](#).

Remote command:

`:SYSTem:COMMunicate:NETWork[:IPAdDress]:DNS` on page 749

MAC Address

Indicates the MAC (Media Access Control) address, a unique identifier of the network adapter in the R&S SMA100B.

Remote command:

`:SYSTem:COMMunicate:NETWork:MACaddress` on page 747

13.5.2 VISA resource strings

Access:

- Select "System Config > Remote Access > Visa Resource Strings".



The "Visa Resource String" dialog displays the VISA resource strings provided for remote control over the different interfaces.

The remote commands required to query the address information remotely are described in [Chapter 14.18, "SYSTem subsystem"](#), on page 735.

Settings

HISLIP	402
VXI11	402
Socket	403
GPIB	403
USB	403
SERIAL	403

HISLIP

Displays the visa resource string for remote control with HiSLIP protocol.

See also [Chapter 13.2.1, "LAN interface"](#), on page 381

Remote command:

`:SYSTem:COMMunicate:HISLip:RESource?` on page 747

VXI11

Displays the visa resource string for remote control over LAN.

See also [Chapter 13.2.1, "LAN interface"](#), on page 381

Remote command:

`:SYSTem:COMMunicate:NETWork:RESource?` on page 748

Socket

Displays the visa resource string for remote control over LAN, using the socket communication protocol.

See also [Chapter 13.2.1, "LAN interface"](#), on page 381

Remote command:

`:SYSTem:COMMunicate:SOCKet:RESource?` on page 751

GPIB

Displays the visa resource string for remote control over the GPIB interface.

See also [Chapter 13.2.3, "GPIB interface \(IEC/IEEE bus interface\)"](#), on page 384.

Remote command:

`:SYSTem:COMMunicate:HISLip:RESource?` on page 747

USB

Displays the visa resource string for remote control over the USB interface.

See also [Chapter 13.2.2, "USB interface"](#), on page 383

Remote command:

`:SYSTem:COMMunicate:USB:RESource?` on page 751

SERIAL

Displays the visa resource string for remote control over the serial interface.

See also [Chapter 13.2.2, "USB interface"](#), on page 383


Remote command:

`:SYSTem:COMMunicate:SERial:RESource?` on page 750

13.5.3 GPIB address settings

Access:

- Select "System Config > Remote Access > GPIB Address".



Net-work	Visa Res. Strings	GPIB Addr.	RS232	Instrument Emulations	Remote Connections	HUMS	QR-Code	✕
GPIB Channel Address 28								

The "GPIB Address" enables you to select the channel for remote control over the IEC/IEE bus interface.

The remote command to configure the setting remotely is described in [Chapter 14.18, "SYSTem subsystem"](#), on page 735.

Settings

[GPIB Channel Address](#).....404

GPIB Channel Address

Sets the GPIB (IEC/IEEE bus) channel address for the connected instrument.


Remote command:

[:SYSTem:COMMunicate:GPIB\[:SELF\]:ADDRes](#) on page 746

13.5.4 RS232 settings

Access:

- Select "System Config > Remote Access > RS232".



The "RS232" dialog enables you to control the instrument over a serial interface using a USB adapter. The controller and the instrument must be connected with the external USB/serial-adapter R&S TS1-USB (see recommended extras in the data sheet) and a serial crossover (null modem) cable. The USB connection requires the Visa library to be installed on the controller. Visa detects and configures the R&S SMA100B automatically when the USB connection is established.

The remote commands required to configure the parameters remotely are described in [Chapter 14.18, "SYSTem subsystem"](#), on page 735.

Settings**Baud Rate**

Sets the baudrate for the serial remote control interface.

Remote command:

[:SYSTem:COMMunicate:SERial:BAUD](#) on page 750

Parity

Sets the parity for the serial remote control interface.

Remote command:

[:SYSTem:COMMunicate:SERial:PARity](#) on page 750

Stop Bits

Sets the number of stop bits for the serial remote control interface.


Remote command:

[:SYSTem:COMMunicate:SERial:SBITs](#) on page 750

13.5.5 Instrument emulations settings

Access:

- Select "System Config > Remote Access > Instrument Emulations".



The "Instrument Emulations" dialog enables you to emulate a remote control command set of another signal generator.

The remote commands required to configure the emulation settings remotely are described in [Chapter 14.18, "SYSTem subsystem"](#), on page 735.

Settings

Language

Selects the instrument whose remote command set is emulated by the R&S SMA100B.

Remote command:

[:SYSTem:LANGuage](#) on page 753

Mode

Selects the way the instrument identification is performed.

"Automatic" Sets the "IDN String" and the "OPT String" automatically for the instrument selected with the parameter [Language](#).

"User Defined" Enables you to define the "IDN String" and the "OPT String".

Remote command:

[:SYSTem:IDENTification](#) on page 751

Set to Default

In "Mode > User Defined", resets the *IDN and *OPT strings.

Remote command:

[:SYSTem:IDENtification:PRESet](#) on page 752

IDN String

Indicates the identification string of the instrument when queried with the common command *IDN?.

In addition to the preset values, you can define your own identification string so that each generator uses an individual identification, like `My_SigGen` for instance, see [Mode](#) .

Remote command:

[*IDN?](#) on page 464

[:SYSTem:IRESpOnse](#) on page 752

OPT String

Indicates the option string of the instrument as queried with common command *OPT?.

In [Mode](#) > "User Defined", you can define your own option string. A query responds with this option string instead of the automatically created option string.

Remote command:

[*OPT?](#) on page 465

[:SYSTem:ORESpOnse](#) on page 752


13.5.6 Remote connections settings

The "Remote Connections" dialog covers the active SCPI and TCP/IP connections, and a history list of the connections that have accessed the instrument before.

13.5.6.1 Active connections

Access:

- Select "System Config > Remote Access > Remote Connections > Active".



The "Active " tab shows the currently active remote connections, and you can enable the display of the active connections in the task bar.

Settings

Show Remote Connections in Taskbar.....	407
SCPI Connections.....	407
TCP/IP Connections.....	407

Show Remote Connections in Taskbar

Displays the currently active connections in the taskbar.

SCPI Connections

Displays the VISA resources strings of the remote connections currently controlling the instrument via the LAN interface.

Remote command:
n.a.

TCP/IP Connections


Displays the types and client addresses of the remote connections currently controlling the instrument via the LAN interface.

Remote command:
n.a.

13.5.6.2 Closed connections

Access:

- Select "System Config > Remote Access > Remote Connections > Closed".



The "Closed" tab shows the currently active remote connections, and you can enable the display of the active connections in the task bar.

Settings

SCPI Connections.....	408
TCP/IP Connections.....	408

SCPI Connections

Lists the VISA resource strings of the last remote connections that have accessed the instrument via the LAN interface before.

Remote command:
 n.a.

TCP/IP Connections

Lists the types and client addresses of the last remote connections that had accessed the instrument via the LAN interface before.

Remote command:
 n.a.

13.5.7 HUMS settings

Requires R&S SMAB-K980.

Access:

- Select "System Config > Remote Access > HUMS".



The dialog provides settings to configure the health and utilization monitoring system (HUMS) of the R&S SMA100B.

The remote commands required to define these settings are described in [Chapter 14.9, "HUMS remote control commands"](#), on page 491.

Settings

State	409
Enhanced Settings	409
Delete History	410
Export History	410

State

Activates HUMS.

Data is only recorded, if HUMS is enabled. If disabled, already recorded data can still be retrieved.

The setting is reset by a factory preset to "off".

Remote command:

[DIAGnostic:HUMS:STaTe](#) on page 494

Enhanced Settings

Opens a dialog for configuring enhanced protocol settings, see [Chapter 13.5.8, "HUMS enhanced settings"](#), on page 410.

Access is only available, when HUMS is enabled, see [State](#).

Delete History

Deletes all information from the HUMS service including the device history.

Note: Regarding the instrument security, the sanitization procedure also deletes the history of the HUMS service, see [Chapter 12.4.2.2, "Disk & memory security settings"](#), on page 363.

Remote command:

[DIAGnostic:HUMS:DEvIce:HISTory:DELeTe:ALL](#) on page 493

Export History

Triggers an export of the logged data of the HUMS service into a *.zip file.

A standard file dialog opens, to save the log file. By default, the file is saved to the directory /var/user/.

Remote command:

[DIAGnostic:HUMS:DEvIce:HISTory?](#) on page 492

[DIAGnostic:HUMS:SAVe](#) on page 493

13.5.8 HUMS enhanced settings

Access:

1. Select "System Config > Remote Access > HUMS".
2. Select "State > ON".
3. Select "Enhanced Settings".

The dialog provides enhanced settings for configuring protocol settings and device tags.

The remote commands required to define these settings are described in [Chapter 14.9, "HUMS remote control commands"](#), on page 491.

• Protocol settings	411
• SNMP user settings	412
• Device tag settings	416

13.5.8.1 Protocol settings

The "Protocol" tab of the "Enhanced HUMS Settings"" dialog provides protocol settings for SNMP or REST protocol.

Access:

1. Select "System Config > Remote Access > HUMS".
2. Select "State > ON".
3. Select "Enhanced Settings".
4. Select "Protocol".

The dialog provides enhanced settings for configuring protocol settings and device tags.

Settings

SNMP	411
REST	411
SNMP Configuration	412
L Location	412
L Contact	412
L Access	412
L Community	412
User Settings	412

SNMP

Enables the SNMP agent and selects the supported SNMP version to communicate with the service.

The setting is reset by a factory preset to "v1/v2c".

"Off"	The SNMP agent is disabled.
"v1/v2c"	Selects SNMP version 2, which also enables version v1.
"v1/v2c/v3"	Selects all SNMP version v1, v2c and v3.
"v3"	Selects SNMP version v3.

Remote command:

[SYSTem:COMMUnicate:SNMP:VERSion](#) on page 498

REST

Enables the REST API protocol.

The setting is reset by a factory preset to "On".

Remote command:

[SYSTem:COMMUnicate:REST:ENABLE](#) on page 495

SNMP Configuration

For SNMPv1 and SNMPv2c authentication, you can define "Access" and "Community".
For SNMPv3 authentication, you can define "User" profiles.

Location ← SNMP Configuration

Defines the SNMP location information. This information complies with the server's physical location and is used for identification of the SNMP server. By default, this input field is empty.

Remote command:

[SYSTem:COMMUnicate:SNMP:LOCation](#) on page 496

Contact ← SNMP Configuration

Sets the SNMP contact information. This information complies with the person who manages the SNMP server and is used for identification of the SNMP server. By default, this input field is empty.

Remote command:

[SYSTem:COMMUnicate:SNMP:CONtact](#) on page 496

Access ← SNMP Configuration

Defines the access type for SNMP community string.

For read access, you can use "Read" or "Read & Write". For write access, use "Read & Write".

The setting is reset by a factory preset to "Read & Write".

Remote command:

[SYSTem:COMMUnicate:SNMP:COMMunity:RO](#) on page 495

[SYSTem:COMMUnicate:SNMP:COMMunity:RW](#) on page 496

Community ← SNMP Configuration

Defines the SNMP community string that can be a group of instruments with SNMP version v2 support.

The setting is reset by a factory preset to the "<serial number>" of the instrument.

User Settings

Accesses the "Configure SNMP Users for HUMS" dialog.


13.5.8.2 SNMP user settings

For SNMPv3 authentication, you can define user profiles.

Access:

1. Select "System Config > Remote Access > HUMS".
2. Select "State > ON".
3. Select "Enhanced Settings".
4. In the protocol tab, select SNMP communication with SNMPv3, e.g. "SNMP > v1/v2c/v3".

5. Select "User Settings".



The "Configure SNMP User for HUMS" dialog provides an overview of all defined SNMP users and their profiles. With the "Add" and "Delete All" controls, you can add or remove users.

Settings

Add.....	413
Delete All.....	413
User table.....	413
L Edit.....	414
L Name.....	414
L Prefix.....	415
L Level.....	415
L Delete.....	415
Add SNMP User for HUMS.....	415
L SNMP User Name.....	415
L SNMP User Prefix.....	415
L SNMP User Level.....	416
L SNMP User Public Passphrase.....	416
L SNMP User Encrypted Passphrase.....	416
L Add / Update.....	416

Add


Accesses the "Add SNMP User for HUMS" dialog.
In this dialog, you can define a user and its profile, see ["Add SNMP User for HUMS"](#) on page 415.

Delete All

Removes all users from the list.
Remote command:
[SYSTEM:COMMunicate:SNMP:USM:USER:DElete:ALL](#) on page 498

User table

Lists all defined SNMP users.



The dialog box titled "SNMP User Settings" contains a table with three columns: Name, Prefix, and Level. It also has an "Add ..." button and a "Delete All" button. The table lists three users: user1, user2, and user3, each with a specific prefix and level.

Edit	Name	Prefix	Level	Delete
	user1	Read Only	No Authentication & No Privacy	
	user2	Read & Write Authentication & No Privacy		
	user3	Read & Write Authentication & Privacy		


The table informs on the user name and its specified user profile.

Remote command:

[SYSTEM:COMMunicate:SNMP:USM:USER:ALL?](#) on page 497

Edit ← User table

Accesses the "Edit SNMP Users for HUMS" dialog, where you can modify an already defined user profile.



The "Edit SNMP User" dialog box shows fields for Name, Prefix, Level, Public Passphrase, and Encrypted Passphrase. The Name field is set to "user1", Prefix to "Read Only", and Level to "No Authentication & No Privacy". There are buttons for "Update" and "Delete".

For description on the entry fields, see [Add SNMP User for HUMS](#).

Name ← User table

Shows the user name of the user who should have specific user rights.

Prefix ← User table

Shows the access right of the selected user.

Level ← User table

Shows the security level of the selected user.

Delete ← User table

Removes the selected user from the list.

Remote command:

[SYSTem:COMMunicate:SNMP:USM:USER:DELeTe](#) on page 498

Add SNMP User for HUMS

Configuration dialog for defining SNMP users and their profiles.

Remote command:

[SYSTem:COMMunicate:SNMP:USM:USER](#) on page 497

SNMP User Name ← Add SNMP User for HUMS

Defines the name of the user for assigning specific user rights. Entering a user name is mandatory.

SNMP User Prefix ← Add SNMP User for HUMS

Defines the access right for a user.

"Read Only" Allows the user to only read information.

"Read & Write" Allows the user to read and modify information.

SNMP User Level ← Add SNMP User for HUMS

Defines the security level of the SNMP user. Depending on the security level, the service requests user name and passphrases for authentication and encryption.

"No Authentication & No Privacy"

Low security level. Using this level, the service queries the user name only. Password authentication and password for encrypted data transfer is not requested.

See ["SNMP User Public Passphrase"](#) on page 416 and ["SNMP User Encrypted Passphrase"](#) on page 416 for data transfer is not requested.

"Authentication & No Privacy"

Medium security level: Requests the user name and password authentication, but no data transfer encryption.

"Authentication & Privacy"

High security level: Requests the user name, and both, the password authentication and the password for data transfer encryption.

SNMP User Public Passphrase ← Add SNMP User for HUMS

Defines the password for authentication. The password must have of 8 to 12 characters with any combination of ASCII characters.

SNMP User Encrypted Passphrase ← Add SNMP User for HUMS

Defines the password for encryption. This password must have at least 8 characters with any combination of ASCII characters. When encryption is defined, the R&S SMA100B supports the DES (directed enhanced services) protocol.

Add / Update ← Add SNMP User for HUMS

Assigns the defined user with its profile to the list.

If you change an already defined user profile, the instrument provides the "Update" button to apply the modifications.

13.5.8.3 Device tag settings

The "Device Tags" tab of the "Enhanced HUMS Settings" dialogs displays the defined device tags. You can also add or delete device tags here.

A device tag is a label to assign to your instrument. You can create any device tag for your instrument and define it by a specific key and value.

Access:

1. Select "System Config > Remote Access > HUMS".
2. Select "State > ON".
3. Select "Enhanced Settings".

Protocol

Device Tags

✕

ID	Key	Value	Delete
0			✕
1			✕
2			✕

+

Add

✕

Delete All

Configures device tags for tagging user-defined information of the instrument in a table. You can define up to 32 device tags, e.g., for HUMS history evaluation. To add a device tag, define "Key" and "Value" of the device tag in the table. Click "Add" to add all device tags of the table to the HUMS history.

Settings

ID.....	417
Key.....	417
Value.....	417
Delete.....	418
Add.....	418
Delete All.....	418

ID
Identification count of a device tag entry.

Key
Sets the identification key of a device tag.

Remote command:
`DIAGnostic:HUMS:TAGS[:VALue]` on page 495

Value
Sets the value of the identification key of a device tag.

Remote command:
`DIAGnostic:HUMS:TAGS[:VALue]` on page 495

Delete

Deletes the selected device tag from the HUMS history.

Remote command:

[DIAGnostic:HUMS:TAGS:DElete](#) on page 494

Add

Adds a new device tag to the HUMS service.

Remote command:

[DIAGnostic:HUMS:TAGS\[:VALue\]](#) on page 495

[DIAGnostic:HUMS:TAGS:ALL?](#) on page 494

Delete All

Removes all device tags from the HUMS history.

Remote command:

[DIAGnostic:HUMS:TAGS:DElete:ALL](#) on page 495

13.5.9 QR code

Access:

- Select "System Config > Remote Access > QR Code".



The "QR Code" dialog shows the current instrument address (IP address) in quick response (QR) format.

This functionality provides fast access to the instrument via VNC with, for example, a smartphone or a tablet.

See [Chapter 13.14.3, "How to set up remote operation from a smart device"](#), on page 455.

13.6 LXI settings


On the R&S SMA100B, an LXI functionality is already installed and enabled, see [LXI status settings](#). Thus, you can access the instrument using any web browser to perform the following tasks:

- Modifying network configurations, see [Chapter 13.6.2.1, "LAN configuration"](#), on page 421.
- Accessing the instrument remotely
- Analyzing SCPI remote diagnostics

13.6.1 LXI status settings

Access:

- Select "System Config > Setup > Remote Access > LXI Status".



The LXI "LAN Status" dialog shows the parameters of the LAN connection.

Alternatively, you can change the LAN settings using the LXI web browser interface, see [Chapter 13.6.2.1, "LAN configuration"](#), on page 421.

LAN Status

The LED indicates the LXI status.

"green" Normal operation

"green (flashing)" Device identification

"red" LAN fault

Hostname / MAC Address / IP Address

See "[Hostname](#)" on page 399.

LAN Reset

Initiates the network configuration reset mechanism for the instrument and resets the hostname, MAC address, and IP address.

According to the LXI standard, a LAN reset must set the following network parameters to a default state:

Parameter	Value
TCP/IP mode	DHCP + Auto IP address
Dynamic DNS	Enabled
ICMP ping	Enabled
Password for LAN configuration	LxiWebIfc

The LAN reset also resets the following parameters for the Signal Generator:

Parameter	
Hostname	Instrument-specific hostname
Description	Vector signal generator
Negotiation	Auto detect
VXI-11 discovery	Enabled

13.6.2 LXI browser settings


The LXI browser functionality enables you to control the instrument remotely over a web browser.

Access:

- In the address field of the browser, enter the URL address, composed of the instrument's IP address or host name, for example *http://10.113.1.151*.

Note: Do not add the missing zeros in the IP address, while opening the instrument homepage.

The instrument homepage (welcome page) opens.



The navigation pane of the browser interface contains the following elements:

- "LXI"
 - "Home" opens the instrument homepage.
The homepage displays the device information required by the LXI standard, including the VISA resource string in read-only format.
 - "Device Indicator" activates or deactivates the LXI status indication.
When activated, the LXI LED flashes. A green LXI status symbol indicates that a LAN connection has been established; a red symbol indicates that no LAN cable is connected.
 - "Lan Configuration" allows you to configure LAN parameters and to initiate a ping, see ["Ping client"](#) on page 423.
 - "Status" displays information about the LXI status of the instrument.
 - "Utilities" provides access to the LXI event logging functionality required by the LXI standard.
- "Instrument Control"
 - "Web Control" provides remote access to the instrument, see ["To start remote control with the LXI web browser"](#) on page 432.
- "Diagnostics"
 - "SCPI Remote Trace" records messages exchanged via the remote control interface, see [Chapter 13.6.2.2, "SCPI remote trace"](#), on page 424.
- "Datasheet"
 - Provides the data sheet with the specification data of the instrument at the time of delivery, see [Chapter 13.6.2.3, "Datasheet"](#), on page 426.
- "Help"
 - "Glossary" explains terms related to the LXI standard.
 - www.rohde-schwarz.com opens the Rohde & Schwarz homepage.

13.6.2.1 LAN configuration

The "LAN Configuration" web page displays all mandatory LAN parameters and allows their modification.

It comprises the following navigation entries.

- [IP configuration](#)..... 422
- [Advanced config](#)..... 422
- [Ping client](#)..... 423

IP configuration

The "IP configuration" web page displays all mandatory LAN parameters and allows their modification.

The screenshot shows the 'LAN Parameters' configuration page. The left sidebar contains navigation links: LXI, Home, Lan Configuration (selected), IP Configuration, Advanced Config, Ping Client, Status, Utilities, Instrument Control, Web Control, Diagnostics, SCPI Remote Trace, Datasheet, Production Version, Help, Glossary, and www.rohde-schwarz.com. The main content area is titled 'LAN Parameters' and contains the following fields:

- Hostname: <host name>
- DNS Hostname(s): <host name.xxxx.net>
- Domain: rsint.net
- Description: <instrument>
- IP Address Mode: DHCP + Auto IP Address (dropdown)
- IP Address: 10.102.189.51
- Subnet Mask: 255.255.252.0
- Default Gateway: 10.102.188.1
- Obtain DNS Server Address automatically: ☒
- DNS Server(s): 10.0.2.166
- Register Device at DNS Server dynamically: ☐
- HiSLIP Port: 4880

A 'Submit' button is located below the HiSLIP Port field. A note on the right states: 'Attention! Changing the hostname reboots the device!'. At the bottom, there is a password field with the label '(Password required!)'. The status bar at the bottom indicates 'No error'.

The "IP Address Mode" selects a configuration mode for the IP address of the instrument. With static configuration, the entered IP address, subnet mask, and default gateway are used. With dynamic configuration, DHCP or dynamic link local addressing (automatic IP) is used to obtain the instrument IP address.



Changing the LAN configuration

This function is password-protected. Unlock the protection level 1 to access it.

Note: We recommend that you change the default password before connecting the instrument to a network.


How to:

- ["Changing the default user password of the instrument"](#) on page 373.
- ["Changing the default security password"](#) on page 373.

See [Chapter 12.4.4, "Password management"](#), on page 370.

Advanced config

The "Advanced Config" web page provides LAN settings that are not declared mandatory by the LXI standard.



The following advanced parameters are available:

- "mDNS and DNS-SD": The additional protocols "multicast DNS" and "DNS service discovery" are used for device communication in zero configuration networks, working without DNS and DHCP.
- "ICMP Ping": Must be enabled to use the ping utility.
If you disable this setting, the instrument does not answer ping requests. The setting does not affect the LXI ping client. You can ping other hosts from the instrument, even if the setting is disabled.
- "VXI-11 Discovery": Must be enabled to detect the instrument in the LAN.
If you disable this setting, the instrument cannot be detected by the VXI-11 discovery protocol mechanism. The setting does not affect other detection mechanisms. Setting up a VXI-11 connection via the IP address or the host name is independent of this setting.



Changing the LAN configuration

This function is password-protected. Unlock the protection level 1 to access it.

Note: We recommend that you change the default password before connecting the instrument to a network.

How to:

- ["Changing the default user password of the instrument"](#) on page 373.
- ["Changing the default security password"](#) on page 373.

See [Chapter 12.4.4, "Password management"](#), on page 370.

Ping client

The "Ping Client" page provides the ping utility to verify the connection between the LXI-compliant instrument and another device.

The ping is initiated from the instrument. Using the `ICMP` echo request and echo reply packets, this function checks whether the communication with a device via LAN is working. Ping is useful for the diagnosis of IP network or router failures.

To initiate a ping at the instrument:

1. On the "Ping Client" page, enter the IP address of the host in the "Destination Address" field (for example 10.113.1.151).
2. Select "Submit".




13.6.2.2 SCPI remote trace

The remote trace functionality allows you to trace input and output strings at the remote control interface of the R&S SMA100B, see [Chapter 13.11, "To trace messages with the LXI web browser interface"](#), on page 441.


A recorded trace (message log) can be evaluated directly in the dialog. Use the highlighting and navigation functions provided by the lower toolbar to locate error messages and messages containing arbitrary search strings. You can also export the message log to a *.CSV file and evaluate the file using a suitable program.

To trace and display messages, switch on "logging" and "live mode" in the toolbar.



Toolbars

The toolbar at the top of the dialog provides basic settings and functions.



- "Live mode" / "logging": If logging is switched on, messages are traced. They are stored in an internal database and can be displayed upon request, using the refresh button (live mode off) or they can be displayed automatically (live mode on).
- "Filter": applies a filter to columns and/or rows when working (live mode off)
- "Refresh": reads the message log from the internal database and displays it
- "Download": stores the SCPI trace log to a *.CSV file
- "Clear": deletes all message log entries in the database and at the screen
- "Details": displays details of the selected message, for example an SCPI command in hex format (also possible by double-clicking a message)

Columns

The following columns are available if no column filter is applied:

- "Rec": record number of the message within the message log
- "I": number of the subinstrument
- "MT": indicates the type of the message. Possible values and related message contents are:
 - > = incoming command
 - < = outgoing response to a query
 - E = error message, highlighted by red color
 - T = execution time, i.e. time required by the instrument to process the command internally.


To configure the instrument for remote access

- "message": indicates the type of the message. Possible values and related message contents are:
 - > = incoming command
 - < = outgoing response to a query
 - E = error message, denoted in red
 - T = execution time, i.e. time required by the instrument to process the command internally

13.6.2.3 Datasheet

The data sheet functionality allows you to retrieve the specification data of the instrument at the time of delivery.

The document contains all specified value ranges and information of the data sheet, for example important as reference values for recalibration.



<instrument> Specifications <version>

This document contains all specified limits of the data sheet. These values can be used as reference values for recalibration. Examples for usage (SCPI): `system:spec? "ID_RF_FREQ_SETTING_TIME_BX03_BX06_MS"` or `system:par? "ID_RF_LEVEL_MAX_GENERAL_FORMULA_GHZ_DBM",1.0`. For details please see user manual.

Contents

ID	Type	Value	ValueTypical	Formula
ID_RF_FREQ_SETTING_TIME_BX03_BX06_MS	ms	1.2	0.9	
ID_RF_FREQ_SETTING_TIME_BX12_BX20_MS	ms	1.4	1.0	
ID_RF_FREQ_SETTING_TIME_B131_B140_MS	ms	1.5	1.2	
ID_RF_FREQ_SETTING_TIME_B141_B142_MS	ms	1.5	1.2	

Status: No error

© 2022 ROHDE & SCHWARZ. All rights reserved.

13.7 To configure the instrument for remote access

The R&S SMA100B is equipped with a network interface and can be connected to an Ethernet LAN (local area network).

There are two methods to establish a LAN connection to the instrument:

- A non-dedicated network (Ethernet) connection from the instrument to an existing network.
- A dedicated network connection (Point-to-point connection) between the instrument and a single computer.

How to: see [Chapter 3.1.7, "Connecting to LAN"](#), on page 27.

For identification in the network, all devices require an IP address.

To configure the instrument for remote access

How to:

- To find the VISA resource string.....427
- To configure the acces over LAN.....427
- To configure the access over GPIB.....431

13.7.1 To find the VISA resource string

- Select "System Config > Remote Access > VISA Resource Strings".



The dialog shows all specified resource strings of the supported remote control interfaces.

Note: Using the RS232 serial interface via USB requires the USB serial adapter R&S TS-USB1.

13.7.2 To configure the acces over LAN

Depending on the network capacities, the TCP/IP address information for the instrument can be obtained in different ways.

- If the network supports dynamic TCP/IP configuration using the [DHCP](#) protocol, this service assigns all address information automatically.
- If the network does not support DHCP, the instrument tries to obtain the IP address by using the Zeroconf (Avahi) protocol.

The automatic address configuration assigns the address information automatically. Thus it is safe to establish a physical connection to the LAN without any previous instrument configuration.



If the dynamic TCP/IP configuration does not succeed, or if the instrument is expected to use alternate TCP/IP configuration, you must set the address information manually.

13.7.2.1 How to assign the IP address

If necessary, you can assign the IP address manually. It is assumed that you have connected controller PC and the instrument.

To assign the IP address manually on the instrument

1. Obtain the IP address and subnet mask for the R&S SMA100B and the IP address for the local default gateway from your network administrator. If necessary, also obtain the name of your DNS domain and the IP addresses of the DNS server on your network.
2. On the instrument, select "System Config > Remote Access > Network".
3. Select "Address Mode > Static".
4. Select the "IP Address".
5. Enter the IP address, for example *192.168.0.1*.

The IP address consists of four number blocks separated by dots. Each block contains 3 numbers in maximum.

6. Select the "Subnet Mask" and enter the subnet mask, for example *255.255.255.0*.

The subnet mask consists of four number blocks separated by dots. Each block contains 3 numbers in maximum.

Note: The subnet mask must be the same for both, the R&S SMA100B and the host interface, the instrument is connected to.

To assign the IP address manually on the computer

- Obtain the necessary information from your network administrator. If you use more than one LAN connector, you need separate address information for each connector.

For information on how to configure the address information, see the documentation of the operating system the computer uses.

13.7.2.2 How to use the hostname

In a LAN that uses a [DNS](#) server, each computer or instrument connected in the LAN can be addressed with an unambiguous [Hostname](#) (also referred to as computer name) instead of the IP address. The DNS server translates the hostname to the IP address.



Using the hostname is useful in networks with dynamic TCP/IP and DHCP protocol services, that assign the address information automatically. Thus, it can be that the services assign a new IP address each time the instruments restarts, but they do not change the hostname.

Each instrument is delivered with an assigned hostname, that remains constant as long as it is not explicitly changed.

This function is password-protected. Unlock the protection level 1 to access it.

The default *hostname* name follows the syntax `<INST>-<Serial Number>`, where:

- `<INST>` is the short name of your instrument, as stated on the front panel.
- `<Serial Number>` is the individual serial number of the instrument.
You can find the serial number at the rear panel of instrument. It is the third part of the device ID printed on the barcode sticker.



Example:

The default hostname of an R&S SMA100B with a serial number 102030 is SMA100B-102030.

To query and change the hostname

1. Select "System Config > Remote Access > Network".
Section "Instrument Name" displays the assigned "Hostname".
Note: This function is password-protected. Unlock the protection level 1 to access it.
2. Select "System Config > Setup > Security > Protection".
3. Enable the "Protection Level 1".
The default protection level 1 password is *123456*.
The parameter "Hostname" in the "Network" tab is now enabled for configuration.
4. Change the "Hostname".

13.7.2.3 How to configure LAN interface access and services

By default, the LAN interface and the supported LAN interface services are enabled.

For security reasons, for example to protect the instrument against unauthorized access, you can block either the LAN services individually, or the access over LAN in general.

To configure the instrument for remote access

To disable LAN access in general

1. Select "System Config > Setup > Security".
2. Select "Security".
3. Select "LAN Services".
4. Disable "LAN" state.
5. Enter the [Security Password](#).
6. Select "Accept".

When disabled, communication over the LAN connection is not possible.


To disable LAN services individually

1. Select "System Config > Setup > Security".
2. Select "Security".
3. Select "LAN Services".
4. Enable "LAN" state.
5. In the "Common Services" side tab, uncheck all services you want to block.

General	LAN Services	Password Management	X
<div> <div>LAN</div> <div><input checked="" type="checkbox"/></div> </div>		Common Services	
<div> <div>SCPI over LAN</div> <div>is Enabled</div> <div><input checked="" type="checkbox"/></div> </div>		<div> <div>FTP</div> <div>is Disabled</div> <div><input type="checkbox"/></div> </div>	<div> <div>VNC</div> <div>is Disabled</div> <div><input type="checkbox"/></div> </div>
<div> <div>SMB (Samba)</div> <div>is Enabled</div> <div><input checked="" type="checkbox"/></div> </div>		<div> <div>SSH (SCP)</div> <div>is Disabled</div> <div><input type="checkbox"/></div> </div>	<div> <div>Remote Support</div> <div>is Disabled</div> <div><input type="checkbox"/></div> </div>
<div> <div>HTTP</div> <div>is Disabled</div> <div><input type="checkbox"/></div> </div>		<div> <div>Software Update</div> <div>is Enabled</div> <div><input checked="" type="checkbox"/></div> </div>	<div> <div>Avahi (Zeroconf)</div> <div>is Enabled</div> <div><input checked="" type="checkbox"/></div> </div>
Security Password		<div> <div><input checked="" type="checkbox"/></div> <div>Accept</div> </div>	

6. Select the "Samba Services" sidetab.

To establish a remote control session over LAN



7. For example, uncheck "SMB 1.0/2.0 Server" to block the access for the SMB Samba server.
8. Enter the [Security Password](#).
9. Select "Accept".

13.7.3 To configure the access over GPIB

Option: R&S SMAB-B86

To control the instrument remotely over the GPIB bus, it must be addressed using the GPIB address. The remote control address is factory-set to 28, but it can be changed if it does not fit in the network environment. For remote control, addresses 0 through 30 are allowed. The GPIB address is maintained after a reset of the instrument settings.

How to change the GPIB address

1. Select "System Config > Remote Access > GPIB Address".
2. Select "GPIB Channel Address" and enter a value between 0 and 30.



Risk of losing remote connection

If the remote access and network settings had been configured to values different to the default, executing a factory preset via remote control terminates the connection to the instrument.

13.8 To establish a remote control session over LAN

This section shows you how to establish remote control connections over the available interfaces.

The following general prerequisites must be fulfilled:

- The instrument and the controller have to be connected over the corresponding interface with the suitable cable.
- The instrument and the controller must be switched on.
- To operate the instrument remotely, it must be addressed using the defined interface address.

See:

- [Chapter 13.2.1, "LAN interface"](#), on page 381
- [Chapter 13.2.2, "USB interface"](#), on page 383
- [Chapter 13.2.3, "GPIB interface \(IEC/IEEE bus interface\)"](#), on page 384
- A remote control program must open a connection to the instrument, before it can send commands to and receive device responses from the instrument.



If security is a concern, see:

- Document Instrument Security Procedures.
- [Chapter 12.4.5, "How to prevent unauthorized access"](#), on page 372.

- [To establish the connection with the LXI web browser](#)..... 432
- [To establish the connection using VXI-11 protocol](#).....433
- [To establish the connection using socket communication](#)..... 438

13.8.1 To establish the connection with the LXI web browser

Using the LXI browser interface you can access and control the R&S SMA100B instrument remotely from another PC without additional installation. File upload and download between the instrument and the remote PC is also available.

To start remote control with the LXI web browser

1. On the instrument, make sure the LAN interface is enabled. Enable the LAN interface on the instrument, if necessary.
See [Chapter 12.4.3, "Configuring LAN services"](#), on page 367.
2. Connect the remote PC and the instrument in the same network.
See [Chapter 3.1.7, "Connecting to LAN"](#), on page 27 .
3. On the remote PC, start a web browser that supports HTML5 (W3C compliant).
4. Enter the IP address of the R&S SMA100B in the browser's address bar.
The R&S SMA100B's welcome page is displayed.
5. In the navigation pane, select "Instrument Control" > "Web Control".
Remote access to the instrument requires the password. The default password is *instrument*.
6. Enter the password and confirm with the [Enter] key.

After the connection is established, the current screen of the R&S SMA100B is displayed in the browser window.

7. Use the mouse cursor and keyboard to access the functionality of the instrument as you would directly perform on the instruments touchscreen and front panel.

13.8.2 To establish the connection using VXI-11 protocol

In this example, the I/O software library R&S VISA from Rohde & Schwarz is used to set up a LAN remote control link and remotely control the R&S SMA100B. R&S VISA is running on a controller PC with Windows operating system. When the connection is set up, you can send commands to the instrument and receive the responses.

The remote control connection requires a VISA installation but no additional hardware on the controller PC. The LAN I/O channel is selected at initialization time using the VISA resource string (also referred to as "address string"). A VISA alias (short name) is used to replace the complete resource string. The host address is the R&S SMA100B's hostname or its IP address.

See also [Chapter 13.2.1, "LAN interface"](#), on page 381.

To set up the controller with R&S VISA

To remote control the R&S SMA100B, we use the R&S VISA Tester application. The application communicates via TCP/IP protocol.



The instrument is preconfigured for networks using DHCP (dynamic host configuration protocol). If this configuration is used, enter the computer name in the position of the IP address.

1. On the instrument, make sure, that the LAN interface and "SCPI over LAN" are enabled.

See [Chapter 12.4.3, "Configuring LAN services"](#), on page 367.

2. On the controller (remote PC), install the R&S VISA program.


See <http://www.rohde-schwarz.com/rsvisa> > "RS VISA Release Notes".

3. Connect the controller and the instrument in the same network (network cable). Switch them on.


See also [Chapter 3.1.7, "Connecting to LAN"](#), on page 27.

4. On the controller, start "R&S VISA > Tester 32bit" or "R&S VISA > Tester 64bit".


To establish a remote control session over LAN



5. In the menu bar, select "Choose VISA Implementation > Rohde & Schwarz Visa" and confirm with "OK".



6. In the menu bar, select "Find Resource" to search for the instrument in the LAN.




7. Select "VXI-11" and "Find Resources".

R&S VISA scans the network for connected instruments and lists all detected instruments in the "Resource" list.

Note: The search may take some time, particularly in large networks.

8. Select the required instrument and confirm with "Select".


To establish a remote control session over LAN



The "Find and select resource" dialog closes and R&S VISA indicates the IP address in the "Resource" field of the main application window.

9. As an alternative to the IP address, you can assign an alias name to the R&S SMA100B:


- a) In the menu bar, select "RsVisaConfig".




- b) In the toolbar, select "+" to access the "VISA Resource String Composer".

To establish a remote control session over LAN

- c) Fill in the "Alias" name, the "VISA Resource String" and the "Device IP Address or hostname" as shown in the figure, and confirm with "OK".



The "Alias" name is assigned.



- d) Close the dialog.
The R&S SMA100B is registered in the program. It can be addressed via the resource string or alias name.

10. In the main window, select "Connect".

R&S VISA establishes the connection to the R&S SMA100B.

You can send settings to configure the instrument and receive its responses.

Note: If the connection cannot be set up, R&S VISA displays an error in the log view.

See also [Chapter 15.5, "Resolving network connection failures"](#), on page 775.

For further information on the functions to read and write to an open session, and the utility applications the software provides, see the R&S VISA user manual.

To start remote control with R&S VISA

To set the instrument to remote control, you can use the addressed command `>R` or send any command from the controller.


1. Start the R&S VISA Tester.
Establish the connection to the R&S SMA100B.
See ["To set up the controller with R&S VISA"](#) on page 433.

To establish a remote control session over LAN

2. In the R&S VISA "Basics" tab, enter a SCPI command, e.g. "*IDN?". Confirm with "Query".

The instrument is switched to remote control when it receives a command from the controller.

3. Select "Read" to obtain the instrument response.



Tip: If the "Show Log" checkbox is checked, R&S VISA displays each VISA function call in the log-view on the left. If you check the "Write Log" checkbox, the log-view entry is written to the log file as well. You can operate the log-view in two modes: the "Live Mode" shows only the most recent messages whereas the "View Mode" allows you to scroll the history.

4. To set, e.g. the frequency, enter `SOUR1:FREQ 4 GHz` and select "Write". To check the performed setting, `SOUR1:FREQ?` and select "Query". The instrument response is `4000000000`. The value corresponds to the frequency in Hz.

While remote control is active, the "Remote" icon in the status bar indicates that the instrument is in remote control mode. Currently ongoing communication (data transfer) is indicated by green colored arrows in the icon.

Operating via the front and touch panel or via mouse and keyboard are locked, allowing a remote control program to be performed without interruption. On the display, keys and entry fields are grayed out and cannot be activated or modified, but you can still open dialogs, for example to verify settings.

5. To disable the access to the dialogs, use the command `SYST:KLOC ON`.
6. To prevent unintentional return to manual operation, use the command `&LLO`. See [Remote control via SCPI](#), section "LAN interface messages".

The instrument switches to "Remote LLO" state.

The [Setup] key is disabled.

7. To enable the [Setup] key, use the command `>R`.
8. To return to manual operation, see [Chapter 13.12, "To return to manual operation"](#), on page 442.

Tip: Switching from manual operation to remote control and vice versa does not affect the other instrument settings.

13.8.3 To establish the connection using socket communication

This section provides an example on how to establish a remote control connection over Telnet client and a simple sockets-based program example that can be further developed.

See also [Chapter A.1, "Telnet program examples"](#), on page 801.



The telnet client transmits information unencrypted. Therefore, for sensitive information we recommend that you use a client which supports secure protocols, like SSH.


In the following example, we assume basic knowledge of programming and operation of the controller. You can find information on the interface commands in the corresponding manuals.

To set up a Telnet connection


To control the software, only a Telnet program is required. The Telnet program is part of every operating system.

1. On the instrument, make sure, that the LAN interface and "SCPI over LAN" are enabled.
See [Chapter 12.4.3, "Configuring LAN services"](#), on page 367.
2. Connect the remote PC and the instrument in the same network.
See [Chapter 3.1.7, "Connecting to LAN"](#), on page 27.
3. On the remote PC, start the Telnet program.
Enter the socket address.
The socket address is a combination of the IP address or the hostname of the R&S SMA100B and the number of the port configured for remote-control via Telnet.
Tip: The R&S SMA100B uses the port number 5025 for remote connection via Telnet.


To establish a remote control session over LAN



The connection to the instrument is set up and you can send remote-control commands.



4. Telnet does not reflect your first entry.
Insert a command, e.g. *IDN and confirm with "Enter".
5. Observe the screen.
A response on the query confirms that the connection is working. The client displays all subsequent inputs and responses.
6. Even if the cursor is not visible on the screen, blindly enter a remote-control command. Confirm with Enter.



13.9 To establish a remote control session over GPIB

The program example in this section is written in VISUAL BASIC. A condition for programming in VISUAL BASIC is that the modules NIGLOBAL (Niglobal.bas) and VBIB32 (Vbib_32.bas) are added to the projects.



Drivers for instrument, for example IVI-COM and LabVIEW drivers, are available for download area on the product page at:

<https://www.rohde-schwarz.com/driver/sma100b/>

To start remote control over GPIB

1. Connect instrument and controller using a GPIB cable.
Switch them on.
2. Select "System Config > Remote Access > GPIB Address " > **"GPIB Channel Address = 28"**.
The GPIB address of the instrument must be the default value of 28.
3. Execute the following commands on the controller:
 - a) Open the port to the instrument.
`CALL IBFIND("DEV1", generator%)`
 - b) Inform the controller about instrument address.
`CALL IBPAD(generator%, 28)`
 - c) Reset the instrument.
`CALL IBWRT(generator%, "*RST;*CLS")`
 - d) Set the instrument to new address.
`CALL IBWRT(generator%, "SYST:COMM:GPIB:ADDR 18")`
 - e) Inform the controller about new address.
`CALL IBPAD(generator%, 18)`

The GPIB address of the instrument is changed.
4. To return to manual operation, press the Local key at the front panel.

13.10 To establish a remote control session over USB

For remote control, the PC and the instrument must be connected over the USB type B interface. A USB connection requires the VISA library to be installed. VISA detects and configures the R&S instrument automatically when the USB connection is established. You do not have to enter an address string or install a separate driver.

To start remote control over USB

1. Connect instrument and controller using USB cable. Switch them on.
2. Execute the following commands on the controller:

To trace messages with the LXI web browser interface

- a) Open the port to the instrument.
`viOpen (... , "USB::0x0AAD::0x01DD::100001::INSTR", ...)`
- b) Reset the instrument.
`viRST (generator%, "*RST;*CLS")`
- c) Set 2 GHz frequency
`viPrintf (... , "SOUR:FREQ 2GHz\n")`
- d) Set 20 dBm output level
`viPrintf (... , "SOUR:POW -20dBm\n")`

The RF frequency and signal level of the instrument are changed.

- 3. To return to manual operation, press the [Local] key.

13.11 To trace messages with the LXI web browser interface

The remote trace functionality allows you to trace commands and messages exchanged via a remote control interface of the R&S SMA100B.

To activate SCPI remote trace

- 1. On the instrument, make sure, that the LAN interface and "SCPI over LAN" are enabled.
See [Chapter 12.4.3, "Configuring LAN services"](#), on page 367.
- 2. Connect the remote PC and the instrument in the same network.
See also [Chapter 3.1.7, "Connecting to LAN"](#), on page 27.
- 3. Start a web browser that supports HTML5 (W3C compliant).
- 4. Enter the IP address of the R&S SMA100B in the browser's address bar.
The welcome page is displayed.
- 5. In the navigation pane, select "Diagnostics > SCPI Remote Trace".
- 6. In the toolbar bar of the "SCPI Remote Trace" page, select "live mode > on" and "logging > on".

"live mode > on" displays all commands and responses, and "logging > on" also traces messages.

If you now control the R&S SMA100B with SCPI commands, using an appropriate tool, the LXI function records the information sent and received.

The function records all sent commands, received responses and messages, and saves them in an internal database. If "live mode" is disabled, you can display the recent traces upon request, using the "refresh" button. You can also save the log in a file.

Note: The diagnostics functionality is extended in later releases, e.g. to download or upload SCPI command files from / to the instrument.

13.12 To return to manual operation



Before returning to manual control, command processing must be completed. Otherwise, the instrument switches back to remote control immediately.

1. To return from "Remote" state to manual state, perform one of the following:
 - On the controller, use the command `>L`
Note: If `&NREN` has been set before `>L` is locked. Use `>R` instead.
 - In the status bar, select the "Remote" icon.
 - On the front panel, press the [Local] key.
 - In the block diagram, select "Context sensitive menu > Key Emulation > Local"
2. **Note:** In the local lockout state, the command `>L` and the [Local] key are locked. You can unlock this state only over remote control.
 To return from "Remote LLO" state to manual or to "Remote" state, perform one of the following:
 To return from "Remote LLO" state to manual or to "Remote" state, perform one of the following:
 - On the controller, use the command `&LOCS`.
 This command switches directly to manual operation.
 - Send the command `&REMS`.
 This command changes the remote control state from "Remote LLO" to "Remote".
 - Use the Visual Basic command `CALL IBLOC (generator%)`.
 The command switches directly to manual operation.
 - VISA function `viGpibControlREN()`
 This function switches directly to manual operation.

13.13 To automate tasks with remote command scripts

To achieve fast configuration, make complex test setups or repeating measurements reproducible, you can automate the required settings with scripts. A script contains a series of SCPI commands corresponding to the settings. When completed, it is converted to an executable format, saved in a file and can be run whenever needed.



If you frequently need to load and run a script, assign the script to the [★ (User)], and you can quickly and easily perform the task.

See [Chapter 12.2.4, "How to assign actions to the \[★ \(User\)\] key"](#), on page 350.

In contrast to "Recall Setup" via the [★ (User)] key, an assigned script execution does not close active dialogs and windows. On the contrary, even active window control (open / close) is possible.

To automate tasks with remote command scripts



Figure 13-8: Steps for performing SCPI Scripts

In the graph, you can see the main steps required to work with a SCPI script.

Creating a SCPI list

With the SCPI record functions, you can create a SCPI command list directly in the instrument and then export the list to the controller. If you want to edit or write a script manually, use a suitable editor on the controller. Even for manually creating, the instrument supports you by showing the corresponding command syntax and the current settings value.

Directly in the instrument, you can create a SCPI list at any time of operation, in the following ways:

- **Recording steps**
Both, automatic and manual SCPI recording of settings is possible. You can start, stop and resume automatic recording, and also record individual commands manually.
 - **Manually record the steps selectively**
In manual recording mode, you can deliberately record a SCPI command with the "Add CPI Command to Recording List" function, see [How to record SCPI lists manually](#).
 - **Automatically record all performed steps**
The instrument records the SCPI command and settings value of each step you perform, and then writes the commands to the file system, see [How to record SCPI lists automatically](#).
You can also add a SCPI command manually to the recording list during automatic SCPI recording.
- **Generating all settings at once**
Generates the SCPI commands of the current instrument settings in one step, and writes the command list in a temporary list, see [How to create a SCPI list with the current instrument settings in one step](#).
Note: This function lists all commands in alphabetical order, in contrast to the recording or manual creation, which consider the order the settings are configured. Using this function can slow down the runtime or cause errors during execution. Therefore, always check and revise a script if necessary, see ["How to check a SCPI list"](#) on page 450.
- **Manually create a command script with "Copy" and paste**
Enables you to copy the SCPI command and the current setting, see [Chapter 13.13.1, "Show SCPI command"](#), on page 445.



Some parameters cannot be set by a SCPI command.

If so, *no SCPI command found* is entered instead of a command when you record or generate all settings at once.

The difference between Show SCPI Command and the provided cross-reference

If you want to enter your settings in a script, or use a remote control program, you must know the corresponding SCPI command and the exact syntax.

If you need to look up the SCPI command, the instrument offers two ways to figure it out quickly.

- "Show SCPI command" (context-sensitive menu)
Displays the SCPI command syntax of a selected parameter including the current setting value, see ["Finding out the SCPI command using 'Show SCPI Command'"](#) on page 451.
The "Copy" function enables you to write a SCPI script conveniently by hand.
- Instrument help ([Help] key)
Opens a help topic that describes the selected parameter or instrument function, including a cross-reference to the corresponding SCPI command. The reference leads you to the description of the SCPI command comprising the complete SCPI syntax, all available setting values, value ranges, etc.
See ["Finding out the SCPI command using the online help"](#) on page 452.

Creating and exporting a script file

When the script list is completed, a code generator translates the SCPI commands into the source code of a proprietary programming language, using a code template. Therefore, each language requires an appropriate code template. When converted, you can save the script in a file with an extension corresponding to the programming language.

The R&S SMA100B provides the following predefined code templates by default:

- Plain SCPI
Represents SCPI base format, that is ASCII format, saved as text file (*.txt).
- MATLAB
A programming environment, frequently used in signal processing and test and measurement applications (*.m).
You can directly use this format with MATLAB(c) Toolkit. For comprehensive information on this topic, refer to the application note [1GP60: MATLAB Toolkit for R&S Signal Generators](#).
- NICVI
An ANSI C programming environment designed for measurements and tests (*.c).
You can directly use this format with National Instruments LabWindows CVI.
- Python3
A general-purpose and high-level programming language (*.py).

You can also convert a script to a user-specific format. In this case, you need a code template with the extension *.expcodetmpl.

For information on how to select the code template and save the script in a file, see [Chapter 13.13.3, "SCPI recording export settings"](#), on page 446.

Executing a SCPI script

A SCPI script primarily runs on the controller PC. In addition, you can execute a script directly on the instrument, by assigning the script to the [★ (User)] key.

See [Chapter 12.2.4, "How to assign actions to the \[★ \(User\)\] key"](#), on page 350.

13.13.1 Show SCPI command

Access:

1. Select the parameter.
2. Open the context-sensitive menu (tap and hold).
3. Select "Show SCPI Command".

This function provides the syntax of the remote command with the current setting.

Copy

Copies the command and the current setting.

Close


Exits the "SCPI Command" dialog.

13.13.2 Displaying an SCPI list

The instrument displays a recorded SCPI list and thus provides viewing the recorded results before exporting.

- ▶ Depending on the starting point, you can access the "SCPI Recording List" dialog as follows:
 - During recording
Select "Show SCPI Recording List" in the context-sensitive menu.
 - At any time outside recording
Select "Show SCPI Recording List" in the context-sensitive menu.
This function assumes that at least one recording has been executed after power-on.
 - At the end of the recording
Select "Stop automatic SCPI recording". The dialog opens automatically.
 - After you have exported the script to a file.
Select "SCPI Recording Export > Show file content"

See [Chapter 13.13.3, "SCPI recording export settings"](#), on page 446.



The "SCPI Recording List" shows the last recorded and exported commands.

SCPI Recording List

Lists the automatically or manually recorded recorded SCPI commands.

Export

Opens the [SCPI Recording Export](#) dialog for configuring the file parameters for export.

Remove All, Remove First, Remove Last

Deletes either the first, the last or all recorded SCPI commands.

To remove several recorded commands, repeat the removing.

For post processing, export the SCPI command list in a file, see [Chapter 13.13.5, "How to convert and save SCPI lists"](#), on page 450.

13.13.3 SCPI recording export settings


Scripts are configured and saved in the "SCPI Recording Export" dialog. This dialog opens automatically, when you stop recording.

Access:

1. Select "Show SCPI Recording List" in the context-sensitive menu.

The "SCPI Recording List" dialog opens.

2. Select "Export".



The "SCPI Recording Export" dialog contains all functions required for export of command lists to a file. It enables you to select the source code format, assign an individual filename and display the file content.

Format

Selects the source code format for the command list.

"Plain SCPI" Uses SCPI syntax.

"Predefined Code Generator"

Accesses the predefined templates for common source code generators that convert the recorded settings in the programming languages MATLAB or NICVI or Python.

"User Code Generator"

Use this setting to convert a script by a user-specific code generator.

Select Code Template

Opens the standard "File Select" dialog and lists the predefined or user-defined code templates.

See [Chapter 11.5.1, "File select settings"](#), on page 318.

File

Opens the standard file select dialog "Select Output File", see [Chapter 11.5.1, "File select settings"](#), on page 318.

Export

Executes data export.

The SCPI list is saved in as file with the selected filename and in the selected directory, see [File](#).

Reload

Reloads a SCPI list from a file.

You can export recorded SCPI lists to files (see [File](#) and [Export](#)), that can be modified.

File content

Displays the content of the script in the selected format and code template.

13.13.4 How to record / create SCPI lists

How to record SCPI lists automatically

The following example briefly explains how to proceed when you want to record SCPI lists.

For comprehensive description, see [1GP98: SCPI Recorder Test Automation on a Fingertip](#).

1. On the screen, open the context-sensitive menu (touch and hold, or right mouse click) and select "Start SCPI recording".



Start SCPI Recording

Starting from now, all steps you perform are recorded.

2. To stop SCPI recording, select "context-sensitive menu > Stop SCPI recording".



Stop SCPI Recording

The "SCPI Recording List" dialog opens automatically.

3. Proceed with [How to check a SCPI list](#).

How to record SCPI lists manually

1. To retrace your settings, open the context-sensitive menu and select "Mark all Parameters Changed from Preset".



Mark All Parameters Changed from Preset

This function identifies and highlights all settings you have changed, both in the block diagram, and in the dialogs.

Frequency	4.000 000 000 000 GHz	
Offset	10.000 000 kHz	Multiplier 1.000
User Variation		
Variation Active	<input checked="" type="checkbox"/>	Variation Step 1.000 000 000 MHz

2. For selectively recording your steps:
 - a) Set the parameter.
 - b) Open the context-sensitive menu.
 - c) Select "Add SCPI Command to Recording List"



Add SCPI Command to Recording List


Tip: You cannot see "Add SCPI ..." in the menu?

A possible reason is opening the menu outside of a dialog or input field, for example in a block diagram. Open the context-sensitive menu within the corresponding dialog or input field, and the feature is available.

- d) Continue with the next setting, and repeat steps *a to b* whenever needed.

Each time you select "Add SCPI ...", the SCPI command is appended to a temporary list.

3. To check the progress of the recording, select "Context-Sensitive > Show SCPI Recording List".



The "SCPI Recording List" dialog opens, displaying all recorded settings so far.


4. Proceed with [How to check a SCPI list](#).

How to create a SCPI list with the current instrument settings in one step

You can also generate a SCPI list from a manually created instrument state at any time, in only one step.

To generate a SCPI list with commands for all settings performed:

1. Select "Save/Recall > SCPI Export".



The instrument opens the standard file select dialog, see [Chapter 11.4.1, "Save/recall settings"](#), on page 315.

2. In the "Format" entry field, select the source code.
3. Depending on the selected format, convert the script as described in [Chapter 13.13.5, "How to convert and save SCPI lists"](#), on page 450
4. Enter a filename.
5. Select "Export".
The instrument writes all SCPI commands of the key parameters and the modified settings in the file. Also assigns the file extension automatically according to the source code format.
6. To preview the content of the SCPI list:
 - a) Select "System Config > Save/Recall".
 - b) Select "Operation Mode > SCPI-Export".

- c) In the `/var/user/` directory, select a previously saved file.
- d) Select "Show SCPI List".

The list of all SCPI commands is displayed, for example, for a final check.



Exporting the SCPI list of the instrument state in one step is a fast and convenient method. Nevertheless, it usually requires postprocessing on an external PC.

How to check a SCPI list

The easiest way to check a list, is to execute it. The generator returns a warning if a setting could not be performed.

However, we recommend that you check the list and possibly rework. It can be that ...

- A parameter has not assigned a SCPI command or an element of the user interface has not an assigned parameter. In these cases, `:SYST:INF:SCPI 'SCPI command not available'` is entered in the list instead.
Such entries are also detected during execution. The instrument recognizes these incomplete commands and displays an error message.
- A preset has been executed, but several standards then perform some internal settings that are also assigned to the list with "SCPI Export".
- After a preset still some settings are defined, which are then written to the list generated with "SCPI Export."

Some suggestions on how you can check and revise a list:

1. Search and remove missing command entries.
2. Remove unnecessary content written after a preset.
3. Rearrange the commands to a reasonable order. If you, for example, set a `STATE` command to the last position of a list, you can avoid intermediate calculations of the signal.
4. Preview the list for completeness by comparing it with the modified settings in the manual mode.
 - a) To retrace your settings in manual operation, open the context-sensitive menu and select "Mark all parameters changed from preset".
The function identifies all settings you have changed, both in the block diagram, and in the dialogs. They appear orange.
 - b) Check whether there is a command in the list for all modified settings.
5. To perform modifications, export the list to a PC, using for example a USB flash drive.

13.13.5 How to convert and save SCPI lists

After completing the recording, the "SCPI Recording Export" dialog opens.

1. Select the "Format" for the command syntax in which you want to save the list.

2. "Select Code Template"

Depending on the selected format, proceed accordingly:

Note: Select the code template **before** exporting.

a) Plain SCPI

Continue with the next step.

b) Predefined code generator

The "SCPI Recording Export - Select Predefined Code Template" dialog opens.
Select one of the predefined code templates.

c) User code generator

A file system ("SCPI Recording Export - Select User Code Template") dialog opens.

Select your user-defined code template. The code template must have file extension *.expcodetmpl.

3. Select "File..."

The "SCPI Recording Export - Select Output File" dialog opens.

4. Select "New" and assign a filename for saving the recorded list.


5. In the "SCPI Recording Export" dialog, select "Export".

Saves the recorded data either in ASCII format (plain SCPI), or in the corresponding format of the used code template, and shows the SCPI list in the "File Content" section.


13.13.6 How to find out the SCPI commands for GUI functions

Finding out the SCPI command using "Show SCPI Command"

1. To find out the SCPI command of a parameter in manual operation, select the respective parameter.
2. Open the context-sensitive menu and select "Show SCPI command"



You get the detailed command syntax, including the currently set value.



With the "Copy" function, you can conveniently paste the command including the current setting, e.g., in a command script.

Finding out the SCPI command using the online help

If you are looking for the remote command to a function in manual operation, you find it in the description of the online help.

1. To find out the SCPI command of a parameter in manual operation, select the respective parameter.
2. To open the corresponding help topic, select one of the following:
 - In the display, select "context-sensitive menu > Help".



- On the front panel, press the [Help] key.

The help topic opens. Apart from the function description, it contains the SCPI command in detailed syntax.



How to find the corresponding GUI function to a command

Conversely, if you are looking for a function in the GUI, which belongs to a SCPI, you find it via a cross-reference in the online help and in the user manual.

13.14 To operate the instrument using VNC

This section shows you some examples of the various possibilities to set up remote operation.

- Using a desktop system
 - [Chapter 13.14.2.1, "Using a web browser"](#), on page 453
 - [Chapter 13.14.2.2, "Using a VNC client software"](#), on page 453
- Using a smart device
 - [Chapter 13.14.3.1, "Using a VNC app"](#), on page 456
 - [Chapter 13.14.3.2, "Using a web browser with HTML5"](#), on page 457
 - [Chapter 13.14.3.3, "Special mode QR code"](#), on page 457

13.14.1 How to enable the VNC service

1. **NOTICE!** Enabled VNC service can lead to unauthorized access.
Change the computer name and password of the instrument.
See [Chapter 12.4.5, "How to prevent unauthorized access"](#), on page 372.
2. Select "System Config > Setup > Security > Security > LAN Services".
3. Select "VNC > On".
4. Enter the [Security Password](#).

5. Select "Accept".

13.14.2 How to set up remote operation from a desktop system

13.14.2.1 Using a web browser

The R&S SMA100B supports remote operation via VNC with any web browser, like Windows Internet Explorer or Mozilla Firefox for instance, or alternatively, an HTML5 web browser.

To operate the instrument via a web browser remotely:

1. Install the *JRE (Java Runtime Environment)* on the remote computer.
Note: Skip this step if you are working with an HTML5 web browser.
2. Type the instruments' IP address in the address field of the web browser on your PC, e.g. `http://10.113.1.151`

The VNC authentication screen appears.

3. Enter the password and confirm with "OK".
The default password is *instrument*.

After the connection is established, the current screen of the signal generator is displayed and the instrument can be remotely operated from the remote computer.

13.14.2.2 Using a VNC client software

A VNC client software is an application which can be used to access and control the instrument from a remote computer through a LAN connection.

The VNC client software for setting up the connection is included in the operating system Linux/Unix per default. For Windows operating systems, a VNC client software must be installed manually.

Various free-of charge programs such as Ultr@VNC or similar VNC client programs are available for download on the Internet.

Setting up the VNC connection on a Linux/Unix desktop client


1. Start a web browser on the remote computer. Enter the IP address of the instrument.
2. Enter the following address:
`vnc://<IP-address of the instrument>, for example vnc://10.113.1.151.`
A dialog opens requesting the password for the remote VNC connection.
3. Enter the password and confirm with "OK".

The default password is *instrument*.

After the connection is established, the current screen of the signal generator is displayed and the instrument can be remotely operated from the remote computer.


Setting up the VNC connection on a Windows desktop client

1. Install the VNC viewer program component on the remote computer.
 - a) On the Internet, select a VNC client program and download it onto your PC.
For example the free of charge software Ultr@VNC (`vncviewer.exe` is available, see <http://www.uvnc.com/download/index.html>.
 - b) Execute the VNC client installation.
 - c) Select the VNC viewer program component and follow the installation instructions.
2. Start VNC viewer program component on the PC.



3. Select "VNC Server" and enter the IP address of the instrument.
4. To initialize the connection, select "Connect".

A dialog opens requesting the password.



5. Enter the password and confirm with "OK".
The default password is *instrument*.

After the connection is established, the current screen of the signal generator is displayed and the instrument can be remotely operated from the remote computer.

Terminating VNC connection

- Perform one of the following:
 - a) On an external Unix/Linux PC, close the Internet browser or the signal generator window.
 - b) On an external Windows PC, close the VNC viewer program.

The connection is terminated but not disabled. It can be established again anytime. In the "Active Connections" tab, the displayed TCP/IP connection disappears. See [Chapter 12.4.5, "How to prevent unauthorized access"](#), on page 372.

13.14.3 How to set up remote operation from a smart device

The R&S SMA100B supports remote operation via VNC from a smart device (remote client), like a tablet (tablet computer) or a smartphone. The smart device accesses the instrument via WLAN, either by a suitable App, or an HTML5 web browser, that means with embedded *javascript*.

There are several possibilities to establish a WLAN connection between the smart device and the R&S SMA100B. This section gives an example of how a network environment can be built up, and some essential configuration steps.

For more information, see:

- [1MA216: Remote Operation of Windows Based Instruments with Apple iPad](#)
- [7BM82: Apple iPad Remote Control of Broadcasting T&M Instruments](#)

Example:




Figure 13-9: Example of a network configuration for remote operation with a smart device

As shown in the figure, the R&S SMA100B and the WLAN router are connected to the LAN router. The smart device accesses the Rohde & Schwarz instrument via the WLAN router.

Prerequisites

For this network configuration, the following prerequisites must be met:

- The required equipment is:
 - A LAN router
 - A WLAN router (hot spot)
Required for accessing the R&S SMA100B
- The smart device must be known and accepted in the network of the R&S SMA100B.
- The *App* or web browser implements the VNC functionality on the smart device for remote operation.

It is recommended that all components in the network use DHCP, which automatically assigns the relevant address information.



With the configuration in the example, you can reach the instrument from a great distance, since the WLAN router acts as an additional access point.

13.14.3.1 Using a VNC app

Using a *VNC App* enables the smart device to access the R&S SMA100B via WLAN.

The VNC Apps are available from various manufacturers of the smart devices.

The list of supported devices is different according to the smart device.

1. Refer to the manufacturer's website to find out whether a VNC App is available for your device, and how it is installed.
2. In the network, establish the connection of the WLAN router to the LAN router.
We assume the connection of the LAN router and the R&S SMA100B and their configuration in the LAN.
3. Configure the WLAN router according to the manufacturer's instructions.
4. Install the required *VNC App* on your smart device.
5. On the smart device, start the *VNC App*.
6. In the address field, enter the IP address of the instrument.
A log-on dialog opens and requests the password for the VNC connection.
7. Enter the password to establish the remote access.
The default user name and password is *instrument*.
See [Chapter 12.4.5, "How to prevent unauthorized access"](#), on page 372.

After the connection is established, the current screen of the signal generator is displayed and the instrument can be remotely operated.

13.14.3.2 Using a web browser with HTML5

The R&S SMA100B supports remote operation from a smart device via VNC with any HTML5 compliant web browser, like Internet Explorer, Firefox, Google Chrome, or Safari for instance.

To operate the instrument remotely via a web browser, proceed as follows:

1. In the web browser enter the IP address of the instrument, e.g. *http://10.113.1.151*.
2. Type the instrument IP address in the address field of the web browser on your PC, e.g. *http://10.113.1.151*

The VNC authentication screen appears.

3. Enter the password and confirm with "OK".

The default password is *instrument*.

See [Chapter 12.4.5, "How to prevent unauthorized access"](#), on page 372.

After the connection is established, the current screen of the signal generator is displayed and the instrument can be remotely operated.

13.14.3.3 Special mode QR code

If your smart device is equipped with a camera and a QR code reader, you can scan the instrument's IP address or access the instrument with the Safari web browser.

QR code readers are available from various manufacturers of the smart devices.

The list of supported devices is different according to the smart device.

1. Refer to the manufacturer's website of your smart device to find out whether a reader is available for your device, and how it is installed.
2. Install the required QR code reader software on your device.
3. Start the reader.
4. On the R&S SMA100B, select "System Config > Remote Access".
5. In the "Remote Access" dialog, select the "QR-Code" tab.
6. Scan the QR code of the instrument with your smart device.
7. On the device, decode the scanned QR code and pass it to the web browser.
A dialog opens requesting the password for the VNC connection.
8. Enter the password and confirm with "OK".

The default password is *instrument*.

After the connection is established, the current screen of the signal generator is displayed and the instrument can be remotely operated.

13.15 References

13.15.1 LXI functionality

LAN Extensions for Instrumentation (LXI) is an instrumentation platform for measuring instruments and test systems that is based on standard Ethernet technology.

LXI is intended to be the LAN-based successor to GPIB, combining the advantages of Ethernet with the simplicity and familiarity of GPIB. Like GPIB, LXI determines and standardizes the way the instrument behaves in a LAN.

The LXI implementation in the R&S SMA100B allows you to change certain LAN settings, to reset the LAN connection, and to identify the instrument.



For information about the LXI standard, refer to the LXI website at <http://www.lxistandard.org>.

See also "News from Rohde & Schwarz, article 2006/II - 190".

The LXI functionality in the R&S SMA100B is characterized by a common LAN implementation, including an ICMP ping responder for diagnostics. Using a web browser, you can configure the instrument. A LAN Configuration Initialize (LCI) mechanism resets the LAN configuration. The instrument also supports automatic detection in a LAN via the VXI-11 discovery protocol and programming by IVI drivers.

In addition, the R&S SMA100B provides the following LXI-related functionality:

- Integrated "LXI Status" dialog for LXI status indication and reset of the LAN configuration, see [Chapter 13.6.1, "LXI status settings"](#), on page 419.
- "LXI Browser Interface", as described in [Chapter 13.6.2.1, "LAN configuration"](#), on page 421.
- "SCPI Remote Trace" utility, see [Chapter 13.6.2.2, "SCPI remote trace"](#), on page 424.



Firmware update

To enable the full LXI functionality after a firmware update, shut down and restart the instrument.

13.15.2 Code generator templates

This section describes the main structure of the code generator templates, and shows the method with the NICVI template.

The code generation is controlled by templates with the following blocks:

Command	Function
#EXTENSION_START #EXTENSION_END	Defines the output file extension.
#INIT_CODE_START #INIT_CODE_END	Contains initial entries, such as included files and libraries, buffer size, commands for synchronization, or creating a VISA session. All entries between start and end are written once at the beginning of the output file.
#COMMAND_CODE_START #COMMAND_CODE_END	Frame for a SCPI command. A command is accessed with %COMMAND.
#NO_COMMAND_CODE_START #NO_COMMAND_CODE_END	Frame for a parameter with no SCPI command available. A parameter is accessed with %PARAMETER.
#EXIT_CODE_START #EXIT_CODE_END	Closes the visa session. All entries between start and end are written once at the end of the output file.

Templates are created in ASCII format with file extension *.expcodetempl.

Example:

Example to the code generator template NICVI.expcodetmpl:

```
#EXTENSION_START
.c
#EXTENSION_END

#INIT_CODE_START
#include <ansi_c.h>
#include <visa.h>
#include <cvirte.h>

#define MAX_BUFFER_SIZE 200
static ViStatus status;
static ViSession defaultRM, handle;

static void write_command(char *command)
{
    char writeBuffer[MAX_BUFFER_SIZE];
    char readBuffer[MAX_BUFFER_SIZE];
    int length;
    int readCount;

    strcpy(writeBuffer, command);
    //append "*OPC?" to sync
    strcat(writeBuffer, "*OPC?");
    length = strlen (writeBuffer);
    writeBuffer[length]='\n';
```

```

        length = length+1;
        viWrite (handle, writeBuffer, length, VI_NULL);
        //read result
        viRead(handle, readBuffer, 100, &readCount);
    }
int main (int argc, char *argv[])
{
    if (InitCVIRTE (0, argv, 0) == 0)
        return -1;    /* out of memory */
        //create a VISA session and return a handle to it
        viOpenDefaultRM (&defaultRM);
        //create a VISA session to the serial port and return a handle to it
        viOpen (defaultRM, (ViRsrc)"TCPIP::localhost::INSTR", VI_NULL, VI_NULL,
&handle);
#INIT_CODE_END

#COMMAND_CODE_START
    write_command("%COMMAND");
#COMMAND_CODE_END

#NO_COMMAND_CODE_START
    //no SCPI command available for parameter %PARAMETER !
#NO_COMMAND_CODE_END

#EXIT_CODE_START
    viClose (handle);
        viClose (defaultRM);
        return 0;
}
#EXIT_CODE_END

```

13.15.3 Remote control states

How to recognize if there is an active remote connection to the instrument

- Observe the indication on the taskbar.



**SCPI, VNC,
SMB, FTP**

A softkey in the taskbar indicates if and what kind of remote connections are currently set up.

See also [Chapter 13.5.6, "Remote connections settings"](#), on page 406.

The following table shows the different remote control states and the associated commands or actions to return to manual control.

Table 13-8: Remote control status icons

GUI symbol	Transition to remote control state...	Transition to manual operation...(local state)
 	<p>&GTR (controller)</p> <p>Remote control, but usable front panel keys.</p> <p>The parameters are in read-only mode.</p>	<ul style="list-style-type: none"> • &GTL (controller) • Tap the "Remote" icon (display) • [Local] (front panel or key emulation) <p>A currently performed setting is indicated by the green arrows.</p> <p>The setting must be completed (white arrows), otherwise the instrument remains in remote state.</p>
	<p>&LLO (controller)</p> <p>Remote control with locked front panel keys to prevent user interaction.</p> <p>The parameters are in read-only mode.</p> <p>You can unlock LLO, and thus return to manual operation only via remote control.</p>	<ul style="list-style-type: none"> • &LOCS (controller) • CALL IBLOC (generator%) (controller) <p>Note: The command &REMS returns to "Remote" state.</p>

14 Remote control commands

In the following, all remote-control commands are presented in detail with their parameters and the ranges of numerical values.

For an introduction to remote control and the status registers, see [Chapter 13, "Network operation and remote control"](#), on page 378.

14.1 Conventions used in SCPI command descriptions

The following conventions are used in the remote command descriptions:

- **Command usage**
If not specified otherwise, commands can be used both for setting and for querying parameters.
If a command can be used for setting or querying only, or if it initiates an event, the usage is stated explicitly.
- **Parameter usage**
If not specified otherwise, a parameter can be used to set a value and it is the result of a query.
Parameters required only for setting are indicated as **Setting parameters**.
Parameters required only to refine a query are indicated as **Query parameters**.
Parameters that are only returned as the result of a query are indicated as **Return values**.
- **Conformity**
Commands that are taken from the SCPI standard are indicated as **SCPI confirmed**. All commands used by the R&S SMA100B follow the SCPI syntax rules.
- **Asynchronous commands**
A command which does not automatically finish executing before the next command starts executing (overlapping command) is indicated as an **Asynchronous command**.
- **Reset values (*RST)**
Default parameter values that are used directly after resetting the instrument (*RST command) are indicated as ***RST** values, if available.
- **Factory preset values**
Default parameter values that are reset only by factory preset.
- **Default unit**
The default unit is used for numeric values if no other unit is provided with the parameter.
- **Manual operation**
If the result of a remote command can also be achieved in manual operation, a link to the description is inserted.

14.2 Programming examples

The corresponding sections of the same title provide simple programming examples for the R&S SMA100B. The purpose of the examples is to present **all** commands for a given task. In real applications, one would rather reduce the examples to an appropriate subset of commands.

The programming examples have been tested with a software tool which provides an environment for the development and execution of remote tests. To keep the examples as simple as possible, only the "clean" SCPI syntax elements are reported. Non-executable command lines (for example comments) start with two // characters.

At the beginning of the most remote control program, an instrument (p)reset is recommended to set the R&S SMA100B to a definite state. The commands `*RST` and `SYSTem:PRESet` are equivalent for this purpose. `*CLS` also resets the status registers and clears the output buffer.

In all the examples we assume that:

- A remote PC is connected to the instrument
- The remote PC and the instrument are switched on
- A connection between them is established
- The security setting "System Config > Setup > Security > SCPI over LAN" is enabled.

14.3 Common commands

Common commands are described in the IEEE 488.2 (IEC 625-2) standard. These commands have the same effect and are employed in the same way on different devices. The headers of these commands consist of "*" followed by three letters. Many common commands are related to the Status Reporting System.

Available common commands:

<code>*CLS</code>	464
<code>*ESE</code>	464
<code>*ESR?</code>	464
<code>*IDN?</code>	464
<code>*IST?</code>	465
<code>*OPC</code>	465
<code>*OPT?</code>	465
<code>*PRE</code>	465
<code>*PSC</code>	465
<code>*RCL</code>	466
<code>*RST</code>	466
<code>*SAV</code>	466
<code>*SRE</code>	467
<code>*STB?</code>	467

*TRG.....	467
*TST?.....	467
*WAI.....	467

*CLS

Clear status

Sets the status byte (STB), the standard event register (ESR) and the `EVENT` part of the `QUESTIONABLE` and the `OPERATION` registers to zero. The command does not alter the mask and transition parts of the registers. It clears the output buffer.

Usage: Setting only

*ESE <Value>

Event status enable

Sets the event status enable register to the specified value. The query returns the contents of the event status enable register in decimal form.

Parameters:

<Value> Range: 0 to 255

*ESR?

Event status read

Returns the contents of the event status register in decimal form and then sets the register to zero.

Return values:

<Contents> Range: 0 to 255

Usage: Query only

*IDN?

Identification

Returns the instrument identification.

Return values:

<ID> "Rohde&Schwarz,<device type>,<part number>/<serial number>,<firmware version>"

Example: Rohde&Schwarz,SMA100B,1419.8888K02/0,4.00.033

Usage: Query only

Manual operation: See ["IDN String"](#) on page 406
 See ["Hardware Options/Software Options"](#) on page 779

***IST?**

Individual status query

Returns the contents of the IST flag in decimal form. The IST flag is the status bit which is sent during a parallel poll.

Return values:

<ISTflag> 0 | 1

Usage: Query only

***OPC**

Operation complete

Sets bit 0 in the event status register when all preceding commands have been executed. This bit can be used to initiate a service request. The query writes a "1" into the output buffer when all preceding commands have been executed, which is useful for command synchronization.

***OPT?**

Option identification query

Queries the options included in the instrument. For a list of all available options and their description, refer to the data sheet.

Return values:

<Options> The query returns a list of options. The options are returned at fixed positions in a comma-separated string. A zero is returned for options that are not installed.

Usage: Query only

Manual operation: See ["OPT String"](#) on page 406
 See ["Hardware Options/Software Options"](#) on page 779

***PRE <Value>**

Parallel poll register enable

Sets parallel poll enable register to the indicated value. The query returns the contents of the parallel poll enable register in decimal form.

Parameters:

<Value> Range: 0 to 255

***PSC <Action>**

Power on status clear

Determines whether the contents of the `ENABLe` registers are preserved or reset when the instrument is switched on. Thus a service request can be triggered when the instrument is switched on, if the status registers ESE and SRE are suitably configured. The query reads out the contents of the "power-on-status-clear" flag.

Parameters:

<Action> 0 | 1

0
The contents of the status registers are preserved.

1
Resets the status registers.

***RCL** <Number>

Recall

Loads the instrument settings from an intermediate memory identified by the specified number. The instrument settings can be stored to this memory using the command `*SAV` with the associated number.

It also activates the instrument settings which are stored in a file and loaded using the `MMEMory:LOAD <number>, <file_name.extension>` command.

Manual operation: See "Recall Immediate x" on page 317

***RST**

Reset

Sets the instrument to a defined default status. The default settings are indicated in the description of commands.

The command is equivalent to `SYSTem:PRESet`.

Usage: Setting only

Manual operation: See "Preset" on page 310

***SAV** <Number>

Save

Stores the current instrument settings under the specified number in an intermediate memory. The settings can be recalled using the command `*RCL` with the associated number.

To transfer the stored instrument settings in a file, use the command `:MMEMory:STORe:STATe`.

Manual operation: See "Save Immediate x" on page 316

***SRE** <Contents>

Service request enable

Sets the service request enable register to the indicated value. This command determines under which conditions a service request is triggered.

Parameters:

<Contents> Contents of the service request enable register in decimal form.
Bit 6 (MSS mask bit) is always 0.
Range: 0 to 255

***STB?**

Status byte query

Reads the contents of the status byte in decimal form.

Usage: Query only

***TRG**

Trigger

Triggers all actions waiting for a trigger event. In particular, *TRG generates a manual trigger signal. This common command complements the commands of the TRIGger subsystem.

*TRG corresponds to the INITiate:IMMediate command.

Usage: Event

***TST?**

Self-test query

Initiates self-tests of the instrument and returns an error code.

Return values:

<ErrorCode> **integer > 0 (in decimal format)**
An error occurred.
(For details, see the Service Manual supplied with the instrument).
0
No errors occurred.

Usage: Query only

***WAI**

Wait to continue

Prevents servicing of the subsequent commands until all preceding commands have been executed and all signals have settled (see also command synchronization and *OPC).

Usage: Event

14.4 Preset commands

The preset commands are not bundled in one subsystem. Therefore, they are listed separately in this section.

Four presetting actions are available:

- Activating the default state of all internal instrument functions (*RST on page 466). Functions that concern the integration of the instrument into a measurement setup are not changed, e.g. reference oscillator source settings.
- Activating the preset state of the parameters related to the selected signal path (:SOURCE<hw>:PRESet on page 468)
- Activating the preset state of all parameters that are not related to the signal path (:DEVice:PRESet on page 468)
- Activating the original state of delivery (factory reset, :SYSTem:FPRreset on page 469). Only functions that are protected by a password remain unchanged as well as the passwords themselves.



When resetting, the following deviation between remote and manual control exists:

In contrast to the [Preset] key, the SCPI commands *RST and :SYSTem:PRESet do not close open dialogs in the GUI.

:DEVice:PRESet.....	468
:SOURCE<hw>:PRESet.....	468
:SYSTem:PRESet.....	469
:SYSTem:FPRreset.....	469

:DEVice:PRESet

Presets all parameters which are not related to the signal path, including the LF generator.

Example: DEV: PRES
Presets all instruments settings that are not related to the signal path.

Usage: Event

:SOURCE<hw>:PRESet

Presets all parameters which are related to the selected signal path.

Example: `SOUR: PRES`
Presets all settings that are related to signal path

Usage: Event

:SYSTem:PRESet

Triggers an instrument reset. It has the same effect as:

- The [Preset] key.
However, the command does not close open GUI dialogs like the key does.
- The *RST command

For an overview of the settings affected by the preset function, see [Table 11-1](#)

Example: `SYST: PRES`
All instrument settings (also the settings that are not currently active) are reset to their default values.

Usage: Setting only

:SYSTem:FPRreset

Triggers an instrument reset to the original state of delivery.

Example: `SYST: FPR`
All instrument settings (also the settings that are not currently active) are reset to the factory values.

Usage: Event

Manual operation: See "[Execute Factory Preset](#)" on page 311

14.5 MMEMory subsystem

The MMEMory subsystem (Mass MEMory) contains the commands for managing files and directories as well as for loading and saving complete instrument settings in files.

Mass storage location

Without any additional measures, the R&S SMA100B stores user files on the internal memory, the removable memory, or if connected, on a memory stick.

Both, the user directory `/var/user/` on the internal memory or the `/usb/` directory on the memory stick, can be used to **preserve** user-defined data. Any directory structure can be created.

The `/var/volatile` directory serves as a RAM drive and can be used to protect sensitive information. The data is available **temporarily**.

If option R&S SMAB-B85 is installed, the R&S SMA100B maps the user directory to the removable memory. If a memory is mounted, user data is saved there. Otherwise user data is redirected to the volatile memory.

Default storage location

The R&S SMA100B stores user data in the user directory.

Depending on the installed options, the user directory is physically located on the internal memory or on the removable memory.

In the file system, user directory is always indicated as `/var/user/`.

In manual control, you access this directory via the "File Manager", see [Chapter 11.8, "Using the file manager"](#), on page 321. In remote control, you can query it with the command `:SYSTem:MMEMory:PATH:USER?`.

To query and change the default directory used for mass storage, use the command `:MMEMory:CDIRectory`.

14.5.1 File naming conventions

To enable files to be used in different file systems, consider the following file naming conventions:

- The *filename* can be of any length and *is case-sensitive*, i.e. it is distinguished between uppercase and lowercase letters.
- All letters and numbers are permitted (numbers are, however, not permitted at the beginning of the filename).
- Avoid using special characters.
- Do not use slashes "\" and "/". These symbols are used in file paths.
- Avoid using the following filenames: CLOCK\$, CON, COM1 to COM4, LPT1 to LPT3, NUL or PRN
They are reserved by the operating system.

File extension

The file and the optional file *extension* are separated by a period sign. The R&S SMA100B distinguishes the files according to their extensions; each type of file is assigned a specific file content and hence a specific file extension. Refer to [Chapter B, "Extensions for user files"](#), on page 808 for an overview of the supported file extensions.

Wildcards

The two characters "*" and "?" function as "wildcards", i.e. they are used for selecting several files. The "?" character represents exactly one character, while the "*" character represents all characters up to the end of the filename. "*. *" therefore represents all files in a directory.

Filename and file path

When used in remote control commands, the parameter `<filename>` is specified as a string parameter with quotation marks. It can contain either the complete path including the root user directory `/var/user` and filename, or only the filename. The filename

must include the file extension. The same applies for the directory `/var/volatile` and for the parameters `<directory_name>` and `<path>`.

Depending on how much information is provided, the values specified in the parameter or with the command `MMEM:CDIR` are used for the path and drive setting in the commands.

14.5.2 Accessing files in the default or in a specified directory

For better overview and easy file handling, you may not save all user files in the user directory `/var/user` but rather organize them into subdirectories.

The command syntax defines two general ways to access files with user data in a *specific* directory:

- **Change the current default directory** for mass memory storage and then directly access the files in this default directory, like saved list files, files with user data or save/recall files.
The subsequent commands for file handling (select, delete, read out files in the directory, etc.) require only specification of the filename. File extension can be omitted; after syntax evaluation of the used command, the R&S SMA100B filters out the relevant files.
- Define the **complete file path**, including the user directory `/var/user`, created subdirectories and filename (see [Example"Load file with user data from a specific directory"](#) on page 471).
As a rule, whenever an complete file path is determined, it overwrites a previously specified default directory.

The following example explains this rule as a principle. Exceptions of this general rule are stated in the description of the corresponding command. The [Chapter 14.5.3, "Programming examples"](#), on page 472 explains the general working principle with the commands for mass memory storage.

The same rule applies to the `/var/volatile` directory, see [Example"Working with files in the volatile memory"](#) on page 473.

Example: Load file with user data from a specific directory

This example shows the principle of file handling in remote environment by using list commands. Working with the files of other subsystems is analogical. We assume that the directory `/var/user/my_files` is existing and contains the files `list_test.lsw` and `list_2.lsw`.

```
//Query files in the user directory
SOURCE1:LIST:CAtalog?
// -
// no files

// Set the default directory
MMEMory:CDIRectory "/var/user/my_files"
SOURCE1:LIST:CAtalog?
```

```
// "list_test","list_2"

// Specify the complete path to select a list file (*.lsw)
// in the specific directory
SOURCE:LIST:SElect "/var/user/my_files/list_test"
SOURCE:LIST:DElete "/var/user/my_files/list_2"
```

14.5.3 Programming examples

Example: Saving and loading current settings

This example shows two ways of how to save the current instrument setting in the file `settings.savrcltxt` in the directory `/var/user/savrcl`.



Before the instrument settings can be saved in a file, they have to be saved in an intermediate memory using common command `*SAV <number>`. The specified number is then used in the `:MMEMory:STORe:STATe` command.

Also, after loading a file with instrument settings with command `:MMEMory:LOAD:STATe`, these settings have to be activated with the common command `*RCL <number>`.

```
// Save the current settings in an intermediate memory with number 4
*SAV 4

// save the settings in a file in a specific directory;
// the complete path has to be specified
MMEMory:STORe:STATe 4,"/var/user/savrcl/settings.savrcltxt"

// save the settings in a file in the default directory;
// set the default directory; specify only the file name
MMEMory:CDIRectory "/var/user/savrcl"
*SAV 4
MMEMory:STORe:STATe 4,"settings.savrcltxt"

// Load the saved settings in the intermediate memory 4 and activate them
MMEMory:LOAD:STATe 4,"/var/user/settings.savrcltxt"
*RCL 4
```

Example: Working with files and directories

This example shows how to list files in a directory, list the subdirectories, query the number of files in a directory, create directory, rename and delete files.

```
// Query the current default directory for mass storage,
// change the directory to the default user directory "/var/user"
// and read out the files in it
MMEMory:CDIRectory?
// "/var/user/temp"
```



```
MMEMory:CDIRectory?
MMEMory:CDIRectory?
// "/var/user/"
MMEMory:CATalog?
// 1282630,8102817792,".,DIR,4096","..,DIR,4096","Log,DIR,4096",
// "settings.savrc1txt,BIN,16949","temp,DIR,4096","test,DIR,4096",
// "list.lsw,BIN,1245201"
// the directory "/var/user" contains the predefined directory "Log",
// the subdirectories "test" and "temp"
// as well as the files "settings.savrc1txt" and "list.lsw"

// query only the subdirectories of the current or specified directory
MMEMory:DCATalog? "/var/user"
// ".,", "..", "Log", "temp", "test"

// query only number of subdirectories in the current or specified directory
MMEMory:DCATalog:LENGth? "/var/user"
// 5

// query number of files in the current or specified directory
MMEMory:CATalog:LENGth? "/var/user"
// 7

// Create a new directory for mass memory storage in the specified directory
MMEMory:MDIRectory "/var/user/new"

// Copy the file "settings.savrc1txt" into the new directory
MMEMory:COPY "/var/user/settings.savrc1txt","/var/user/new/settings.savrc1txt"

// Rename the file "settings.savrc1txt" into the new directory
// and read out the files in this specific directory
MMEMory:CDIRectory "/var/user/new"
MMEMory:MOVE "settings.savrc1txt","settings_new.savrc1txt"
MMEMory:CATalog? "/var/user/new"
// 25141,8102789120,".,DIR,4096","..,DIR,4096","settings_new.savrc1txt,BIN,16949"

// Delete the "test" directory
MMEMory:RDIRectory "/var/user/test"
```

Example: Working with files in the volatile memory

This example shows how to work with files in the `/var/volatile` directory.

```
// Change the default directory for mass storage,
// read out the files, load and play a file with the ARB
MMEemory:CDIRectory "/var/volatile"
MMEemory:CDIRectory?
// "/var/volatile"
MMEemory:CAatalog?
//13928,525352960,"..,DIR,60","..,DIR,4096","list.lst,BIN,9772"
```

```

SOURce1:LIST:SElect "/var/volatile/list"
SOURce1:FREQuency:MODE LIST
OUTPut1:STATe 1

```

14.5.4 Remote control commands

:MMEMory:CATalog?	474
:MMEMory:CATalog:LENGth?	475
:MMEMory:CDIRectory	475
:MMEMory:COPI	475
:MMEMory:DATA	476
:MMEMory:DCATalog?	476
:MMEMory:DCATalog:LENGth?	477
:MMEMory:DELe	477
:MMEMory:LOAD:STATe	477
:MMEMory:MDIRectory	478
:MMEMory:MOVE	478
:MMEMory:MSIS	478
:MMEMory:RDIRectory	478
:MMEMory:STORe:STATe	479
:MEMory:HFRee?	479

:MMEMory:CATalog? <path>

Returns the content of a particular directory.

Query parameters:

<path>	string
	String parameter to specify the directory.
	If you leave out the path, the command returns the contents of the directory selected with :MMEMory:CDIRectory.
	The path may be relative or absolute.

Return values:

<UsedDiskSpace>	Byte size of all files in the directory.
<FreeDiskSpace>	Remaining disk space in bytes.
<FileInfo>	<NameFileN>,<SuffixFileN>,<SizeFileN>
	List of files, separated by commas
	<NameFileN>
	Name of the file.
	<SuffixFileN>
	Type of the file. Possible suffixes are: ASCii, BINary, DIRectory
	<SizeFileN>
	Size of the file in bytes.

Usage: Query only

Manual operation: See "Directory, File List and Filename" on page 315

:MMEMory:CATalog:LENGth? <Path>

Returns the number of files in the current or in the specified directory.

Query parameters:

<Path>	string
	String parameter to specify the directory. If the directory is omitted, the command queries the content of the current directory, queried with :MMEMory:CDIRectory command.

Return values:

<FileCount>	integer
	Number of files.

Usage:	Query only
---------------	------------

:MMEMory:CDIRectory <Directory>

Changes the default directory for mass memory storage. The directory is used for all subsequent `MMEM` commands if no path is specified with them.

Parameters:

<Directory>	<directory_name>
	String containing the path to another directory. The path can be relative or absolute.
	To change to a higher directory, use two dots '..'.

Usage:	SCPI confirmed
---------------	----------------

Manual operation:	See "Directory, File List and Filename" on page 315
	See "Directory and Filename" on page 323

:MMEMory:COPY <SourceFile>[,<DestinationFile>]

Copies an existing file to a new file. Instead of just a file, this command can also be used to copy a complete directory together with all its files.

Setting parameters:

<SourceFile>	string
	String containing the path and file name of the source file
<DestinationFile>	string
	String containing the path and name of the target file. The path can be relative or absolute.
	If <DestinationFile> is not specified, the <SourceFile> is copied to the current directory, queried with the :MMEMory:CDIRectory command.

Note: Existing files with the same name in the destination directory are overwritten without an error message.

Usage:	Setting only
	SCPI confirmed

Manual operation: See ["Cut, Copy&Paste and Delete"](#) on page 323

:MMEMory:DATA <Filename>, <BinaryBlock>

:MMEMory:DATA? <Filename>

The setting command writes the block data <BinaryBlock> to the file identified by <Filename>.

Tip: Use this command to read/transfer stored instrument settings or waveforms directly from/to the instrument.

Parameters:

<BinaryBlock> #<number><length_entry><data>
 #: Hash sign; always comes first in the binary block
 <number>: the first digit indicates how many digits the subsequent length entry has
 <length_entry>: indicates the number of subsequent bytes
 <data>: binary block data for the specified length.
 For files with a size with more than nine digits (gigabytes), the instrument allows the syntax # (<Length>), where <Length> is the file size in decimal format.

Parameters for setting and query:

<Filename> string
 String parameter to specify the name of the file.

Example:

MMEMory:DATA '/var/user/test.txt',#15hallo

Writes the block data to the file test.txt.

The digit 1 indicates a length entry of one digit; the digit 5 indicate a length of the binary data (hallo) in bytes.

MMEMory:DATA? '/var/user/test.txt'

Sends the data of the file test.txt from the instrument to the controller in the form of a binary block.

Response: #15hallo

Usage: SCPI confirmed

:MMEMory:DCATalog? <path>

Returns the subdirectories of a particular directory.

Query parameters:

<path> String parameter to specify the directory. If the directory is omitted, the command queries the content of the current directory, queried with [:MMEMory:CDIRectory](#) command.

Return values:

<Catalog> <file_entry>
 Names of the subdirectories separated by colons. The first two strings are related to the parent directory.

Usage: Query only

:MMEMory:DCATalog:LENGth? [<Path>]

Returns the number of subdirectories in the current or specified directory.

Query parameters:

<Path> String parameter to specify the directory. If the directory is omitted, the command queries the contents of the current directory, to be queried with [:MMEMory:CDIRectory](#) command.

Return values:

<DirectoryCount> integer
Number of parent and subdirectories.

Usage: Query only

:MMEMory:DELeTe <Filename>

Removes a file from the specified directory.

Setting parameters:

<Filename> string
String parameter to specify the name and directory of the file to be removed.

Usage: Event
SCPI confirmed

Manual operation: See ["Cut, Copy&Paste and Delete"](#) on page 323

:MMEMory:LOAD:STATe <SavRclStateNumb>, <file_name>

Loads the specified file stored under the specified name in an internal memory.

After the file has been loaded, the instrument setting must be activated using an [*RCL](#) command.

Setting parameters:

<SavRclStateNumb> Determines to the specific <number> to be used with the [*RCL](#) command, e.g. [*RCL 4](#).

<file_name> String parameter to specify the file name with extension [*.savrc1txt](#).

Usage: Setting only

Manual operation: See ["Recall"](#) on page 317

:MMEMory:MDIRectory <Directory>

Creates a subdirectory for mass memory storage in the specified directory. If no directory is specified, a subdirectory is created in the default directory. This command can also be used to create a directory tree.

Setting parameters:

<Directory> string
 String parameter to specify the new directory.

Usage: Event

Manual operation: See ["Create New Directory"](#) on page 323

:MMEMory:MOVE <SourceFile>, <DestinationFile>

Moves an existing file to a new location or, if no path is specified, renames an existing file.

Setting parameters:

<SourceFile> string
 String parameter to specify the name of the file to be moved.

<DestinationFile> string
 String parameters to specify the name of the new file.

Usage: Event
 SCPI confirmed

Manual operation: See ["Rename "](#) on page 323

:MMEMory:MSIS <Msis>

Defines the drive or network resource (in the case of networks) for instruments with windows operating system, using `msis` (MSIS = Mass Storage Identification String).

Note: Instruments with Linux operating system ignore this command, since Linux does not use drive letter assignment.

Usage: SCPI confirmed

:MMEMory:RDIRectory <Directory>

Removes an existing directory from the mass memory storage system. If no directory is specified, the subdirectory with the specified name is deleted in the default directory.

Setting parameters:

<Directory> string
 String parameter to specify the directory to be deleted.

Usage: Event

:MMEMory:STORe:STATe <savrcl_state_nr>, <file_name>

Stores the current instrument setting in the specified file.

The instrument setting must first be stored in an internal memory with the same number using the common command *SAV.

Setting parameters:

<savrcl_state_nr> Corresponds to the specific <number> defined with the *SAV command, e.g. *SAV 4.

<file_name> String parameter to specify the file name with extension *.savrcltxt.

Usage: Event

Manual operation: See "Save" on page 316

:MEMory:HFRee?

Returns the used and available memory in Kb.

Return values:

<TotalPhysMemKb> integer
Total physical memory.

<ApplicMemKb> integer
Application memory.

<HeapUsedKb> integer
Used heap memory.

<HeapAvailableKb> integer
Available heap memory.

Usage: Query only

14.6 CALibration subsystem

The CALibration subsystem contains the commands needed for performing internal adjustments. This procedure is triggered by the query commands.

Common suffixes

The following common suffixes are used in the remote commands:

Suffix	Value range	Description
CALibration<hw>	[1]	Optional suffix

Understanding the query response

- 0: error-free execution of the adjustments
- 1: indicates that an error occurred; the process has been canceled

:CALibration:ALL[:MEASure]?	480
:CALibration<hw>:ALL:DATE?	480
:CALibration<hw>:ALL:INFormation?	481
:CALibration<hw>:ALL:TEMP?	481
:CALibration<hw>:ALL:TIME?	481
:CALibration:DATA:FACTory:DATE?	481
:CALibration<hw>:CONTInueonerror	482
:CALibration:DELAy:MINutes	482
:CALibration:DELAy:SHUTdown[:STATe]	482
:CALibration:DELAy[:MEASure]?	483

:CALibration:ALL[:MEASure]? [<Force>]

Starts all internal adjustments that do not need external measuring equipment.

NOTICE! High power at the RF output applied during internal adjustment can destroy a connected DUT (device under test).

How to: See ["Running internal adjustments"](#) on page 789.

Query parameters:

<Force> string

Return values:

<Measure> 1 | ON | 0 | OFF

Example:

```
CAL:ALL:MEAS?
// Response: "0"
// Executes the adjustments of all instrument functions.
// When completed, it indicates that the adjustment
// has been performed successfully.
```

Usage: Query only

Manual operation: See ["Adjust All"](#) on page 787

:CALibration<hw>:ALL:DATE?

Queries the date of the most recently executed full adjustment.

Suffix:

<hw> [1]
Optional suffix

Return values:

<Date> string

Example:

```
CAL:ALL:DATE?
// "2016-01-01"
```

Usage: Query only

Manual operation: See ["Last Full Adjustment"](#) on page 787

:CALibration<hw>:ALL:INFormation?

Queries the current state of the internal adjustment.

Return values:

<CallInfoText> string

Example:

```
CAL:ALL:INF?
"Instrument is calibrated, no adjustment required."
"UNCAL, instrument is warming up."
"UNCAL, Please perform full adjustment after warming up."
"UNCAL, Please perform full adjustment."
```

Usage: Query only

Manual operation: See ["Information"](#) on page 787

:CALibration<hw>:ALL:TEMP?

Queries the temperature deviation compared to the calibration temperature.

Suffix:

<hw> [1]
 Optional suffix

Return values:

<Temperature> string

Example:

```
CALibration:ALL:TEMP?
// "+12.00 K"
```

Usage: Query only

Manual operation: See ["Temperature Offset"](#) on page 787

:CALibration<hw>:ALL:TIME?

Queries the time elapsed since the last full adjustment.

Return values:

<Time> string

Example:

```
CAL:ALL:TIME?
// "22 days"
```

Usage: Query only

Manual operation: See ["Time"](#) on page 787

:CALibration:DATA:FACTory:DATE?

Queries the date of the last factory calibration.

Return values:

<Date> string

Example:

```
CAL:DATA:FACT:DATE?  
// "2016-01-01"
```

Usage:

Query only

Manual operation: See ["Last Factory Calibration"](#) on page 777

:CALibration<hw>:CONTInueonerror <State>

Continues the calibration even though an error was detected. By default adjustments are aborted on error.

Suffix:

<hw> [1]
Optional suffix

Parameters:

<State> 1 | ON | 0 | OFF
*RST: n.a. (factory preset: 0)

Example:

```
CAL:CONT ON  
// Continues calibration after an error
```

Manual operation: See ["Continue Adjustment on Error"](#) on page 787

:CALibration:DELaY:MINutes <Minutes>

Sets the warm-up time to wait before internal adjustment starts automatically.

Automatic execution starts only, if you have enabled the calibration with command :
[CALibration:DELaY\[:MEASure\]? ON](#).

Parameters:

<Minutes> integer
Range: 30 to 120
*RST: n.a. (no preset. default: 60)

Example:

```
:CALibration:DELaY:MINutes 30  
// sets the time delay for warm-up of the instrument.
```

Manual operation: See ["Warm Up Time"](#) on page 788

:CALibration:DELaY:SHUTdown[:STATe] <Shutdown>

Enables the instrument to shut down automatically after calibration.

Parameters:

<Shutdown> 1 | ON | 0 | OFF
*RST: 0

Example:

```
:CALibration:DElay:SHUTdown[:STATe] ON|1
// inititates that the instrument shuts down when the adjustments are com
```

Manual operation: See ["Shutdown After Adjustment"](#) on page 788

:CALibration:DElay[:MEASure]?

Starts the delayed adjustment process. When the warm-up time has elapsed (see :
[CALibration:DElay:MINutes](#), it executes the internal adjustments.

If you have enabled automatic shutdown, [:CALibration:DElay:SHUTdown\[:STATe\] ON](#), the instrument shuts down when the adjustments are completed.

Return values:

<Error> 1 | ON | 0 | OFF

*RST: n.a. (no preset. default: 0)

Example:

```
:CALibration:DElay[:MEASure] ON|1
// enables the adjustment processs to start after the warm-up time automa
```

Usage: Query only

Manual operation: See ["Adjust All Delayed"](#) on page 788

14.7 CSYNthesis subsystem

This subsystem contains the commands used to define the frequency settings for the separate clock source (clock synthesis).

Option: see ["Required options"](#) on page 301.

Example:

```

CSYNthesis:OTYPe DSIN
CSYNthesis:FREQuency 10000000
CSYNthesis:POWer -15
CSYNthesis:OFFSet:STATe 1
CSYNthesis:OFFSet 0.1
CSYNthesis:PHASe 180
CSYNthesis:PHASe:REFerence
CSYNthesis:PHASe?
// 0
CSYNthesis:FREQuency:STEP:MODE DEC
CSYNthesis:POWer:STEP:MODE DEC
// CSYNthesis:FREQuency:STEP:MODE USER
// CSYNthesis:FREQuency:STEP 1000
// CSYNthesis:FREQuency UP
// 10001000
// CSYNthesis:POWer:STEP:MODE USER
// CSYNthesis:POWer:STEP:INCRement 0.5
CSYNthesis:STATe 1

```

:CSYNthesis:STATe.....	484
:CSYNthesis:OTYPe.....	485
:CSYNthesis:FREQuency.....	485
:CSYNthesis:POWer.....	485
:CSYNthesis:OFFSet:STATe.....	486
:CSYNthesis:OFFSet.....	486
:CSYNthesis:VOLTage.....	486
:CSYNthesis:PHASe.....	486
:CSYNthesis:PHASe:REFerence.....	487
:CSYNthesis:POWer:STEP:MODE.....	487
:CSYNthesis:FREQuency:STEP:MODE.....	487
:CSYNthesis:POWer:STEP[:INCRement].....	487
:CSYNthesis:FREQuency:STEP.....	488

:CSYNthesis:STATe <State>

Activates the clock synthesis.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Chapter 14.7, "CSYNthesis subsystem"](#), on page 483.

Manual operation: See ["State"](#) on page 302

:CSYNthesis:OTYPe <Mode>

Defines the shape of the generated clock signal.

Parameters:

<Mode> SESine | DSquare | CMOS | DSINe
 SESine = single-ended sine
 DSINe = differential sine
 DSquare = differential square
 CMOS = CMOS
 *RST: SESine

Example: See [Chapter 14.7, "CSYNthesis subsystem"](#), on page 483.

Manual operation: See ["Output Type"](#) on page 302

:CSYNthesis:FREQuency <Frequency>

Sets the frequency of the generated clock signal.

Parameters:

<Frequency> float
Numerical value
 Sets the frequency
UP|DOWN
 Varies the frequency step by step.
 The frequency is increased or decreased by the value set with the command [:CSYNthesis:FREQuency:STEP](#).
 Range: 100E3 to 1.5E9
 Increment: 0.001
 *RST: 10E6

Example: See [Chapter 14.7, "CSYNthesis subsystem"](#), on page 483.

Manual operation: See ["Frequency"](#) on page 303

:CSYNthesis:POWer <Power>

Sets the power level of the generated clock signal.

Parameters:

<Power> float
Numerical value
 Sets the level
UP|DOWN
 Varies the level step by step.
 The level is increased or decreased by the value set with the command [:CSYNthesis:POWer:STEP\[:INCRement\]](#).
 Range: -24 to 10
 Increment: 0.01

*RST: -20

Example: See [Chapter 14.7, "CSYNthesis subsystem"](#), on page 483.

Manual operation: See ["Level"](#) on page 303

:CSYNthesis:OFFSet:STATe <State>

Activates a DC offset.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: 0

Example: See [Chapter 14.7, "CSYNthesis subsystem"](#), on page 483.

Manual operation: See ["DC Offset State"](#) on page 303

:CSYNthesis:OFFSet <Offset>

Sets the value of the DC offset.

Parameters:

<Offset> float

Range: -5 to 5

Increment: 0.001

*RST: 0

Example: See [Chapter 14.7, "CSYNthesis subsystem"](#), on page 483.

Manual operation: See ["DC Offset"](#) on page 304

:CSYNthesis:VOLTage <Voltage>

Sets the voltage for the CMOS signal.

Parameters:

<Voltage> float

Range: 0.8 to 2.7

Increment: 0.001

*RST: 1.8

Example:

```
CSYNthesis:OTYPE CMOS
CSYNthesis:VOLTage 1.8
CSYNthesis:FREQuency 100000000
CSYNthesis:STATe 1
```

Manual operation: See ["Voltage"](#) on page 304

:CSYNthesis:PHASe <Phase>

Shifts the phase of the generated clock signal.

Parameters:

<Phase> float
 Range: -36000 to 36000
 Increment: 0.1
 *RST: 0

Example: See [Chapter 14.7, "CSYNthesis subsystem"](#), on page 483.

Manual operation: See ["Delta Phase"](#) on page 304

:CSYNthesis:PHASe:REference

Resets the delta phase value.

Example: See [Chapter 14.7, "CSYNthesis subsystem"](#), on page 483.

Usage: Event

:CSYNthesis:POWer:STEP:MODE <Mode>**:CSYNthesis:FREQuency:STEP:MODE <Mode>**

Defines the type of step size to vary the frequency and level at discrete steps.

Parameters:

<Mode> DECimal | USER
DECimal
 Increases or decreases the level in steps of 10.
USER
 Increases or decreases the value in increments, set with the command:
[:CSYNthesis:FREQuency:STEP](#)
[:CSYNthesis:POWer:STEP\[:INCRement\]](#)
 *RST: DECimal

Example: See [Chapter 14.7, "CSYNthesis subsystem"](#), on page 483.

Manual operation: See ["Variation Active"](#) on page 304

:CSYNthesis:POWer:STEP[:INCRement] <Increment>

Sets the step width of the rotary knob and, in user-defined step mode, increases or decreases the level.

Parameters:

<Increment> float
 Range: 0 to 35
 Increment: 0.01
 *RST: 1

Example: See [Chapter 14.7, "CSYNthesis subsystem"](#), on page 483.

Manual operation: See ["Variation Step"](#) on page 304

:CSYNthesis:FREQuency:STEP <Step>

Sets the step width of the rotary knob and, in user-defined step mode, increases or decreases the frequency.

Parameters:

<Step> float
 Range: 0 to 14999E5
 Increment: 0.001
 *RST: 1E6

Example: See [Chapter 14.7, "CSYNthesis subsystem"](#), on page 483.

Manual operation: See ["Variation Step"](#) on page 304

14.8 DIAGnostic subsystem

The `DIAGnostic` subsystem contains the commands used for instrument diagnosis and servicing. SCPI does not define any `DIAGnostic` commands; the commands listed here are all device-specific. All `DIAGnostic` commands are query commands which are not affected by `*RST`.



The test functions are intended for services purposes.

They are thus password-protected functions. Unlock the corresponding protection level to access them, see `:SYSTem:PROTect<ch>[:STATe]`.

For more information, see R&S SMA100B Service Manual.

Common suffixes

The following common suffixes are used in remote commands:

Suffix	Value range	Description
<code>DIAGnostic<hw></code>	[1]	Optional suffix

Example: Programming example

The example lists the commands required to query assemblies and test points for diagnosis purposes.

```
// Query the modules available in the instrument
// and variant and revision state of a certain assembly
DIAGnostic1:BGInfo:CATalog?
// FRONT_AF,PSU300,IFB.BV,MB2_AF,...
DIAGnostic1:BGInfo? "PSU300"
// PSU300 2118.2067.02 01.00 100000

// Query the test points available in the instrument
// and trigger the measurement in a selected test point
DIAGnostic1:POINt:CATalog?
// ATT6HP_AF_DET_N,ATT6HP_AF_DET_P,ATT6HP_AF_DET_TEMP...
DIAGnostic1:MEASure:POINt? "ATT6HP_AF_DET_N"
// 0.000000V

// Query the operating hours and number of power-on so far.
DIAGnostic:INFO:OTIMe?
// 112 h
DIAGnostic:INFO:POCounT?
// 14
```

Commands

:DIAGnostic<hw>:BGInfo:CATalog?	489
:DIAGnostic<hw>:BGInfo?	489
:DIAGnostic:INFO:OTIMe?	490
:DIAGnostic:INFO:POCounT?	490
:DIAGnostic<hw>:POINt:CATalog?	491
:DIAGnostic<hw>[:MEASure]:POINt?	491

:DIAGnostic<hw>:BGInfo:CATalog?

Queries the names of the assemblies available in the instrument.

Return values:

<Catalog>	string
	List of all assemblies; the values are separated by commas
	The length of the list is variable and depends on the instrument equipment configuration.

Example: See [Example "Programming example"](#) on page 489.

Usage: Query only

:DIAGnostic<hw>:BGInfo? [<Board>]

Queries information on the modules available in the instrument, using the variant and revision state.

Query parameters:

<Board> string
 Module name, as queried with the command :
[DIAGnostic<hw>:BGInfo:CATalog?](#).
 To retrieve a complete list of all modules, omit the parameter.
 The length of the list is variable and depends on the instrument equipment configuration.

Return values:

<BgInfo> <Module name> <Module stock number incl. variant> <Module revision> <Module serial number>
 List of comma-separated entries, one entry per module.
 Each entry for one module consists of four parts that are separated by space characters.

Example: See [Example"Programming example"](#) on page 489.

Usage: Query only

Manual operation: See ["Assembly"](#) on page 777

:DIAGnostic:INFO:OTIme?

Queries the operating hours of the instrument so far.

Return values:

<OperationTime> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example"Programming example"](#) on page 489.

Usage: Query only

Manual operation: See ["Operation Time / h"](#) on page 777

:DIAGnostic:INFO:POCount?

Queris how often the instrument has been turned on so far.

Return values:

<PowerOnCount> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example"Programming example"](#) on page 489.

Usage: Query only

Manual operation: See ["Power On Count"](#) on page 777

:DIAGnostic<hw>:POINT:CATalog?

Queries the test points available in the instrument.

For more information, see R&S SMA100B Service Manual.

Return values:

<Catalog> string
List of comma-separated values, each representing a test point

Example: See [Example"Programming example"](#) on page 489.

Usage: Query only

:DIAGnostic<hw>[:MEASure]:POINT? <Name>

Triggers the voltage measurement at the specified test point and returns the measured voltage.

For more information, see R&S SMA100B Service Manual.

Query parameters:

<Name> <test point identifier>
Test point name, as queried with the command :
[DIAGnostic<hw>:POINT:CATalog?](#)

Return values:

<Value> <value><unit>

Example: See [Example"Programming example"](#) on page 489.

Usage: Query only

14.9 HUMS remote control commands

The remote control commands for the health and utilizations monitoring system (HUMS) comprise commands of the `DIAGnostic` subsystem and the commands of the `SYSTem:COMMunicate:REST` and `SYSTem:COMMunicate:REST` subsystems.

For all HUMS-related remote control commands, see refer to the "R&S®HUMS Health and Utilization Monitoring Service" User Manual on the Internet.

Commands

DIAGnostic:HUMS:DELeTe:ALL	492
DIAGnostic:HUMS:DEViCe:HISTory?	492
DIAGnostic:HUMS:DEViCe:HISTory:DELeTe:ALL	493
DIAGnostic:HUMS:FORMat	493
DIAGnostic:HUMS:SAVE	493
DIAGnostic:HUMS:STATe	494
DIAGnostic:HUMS:TAGS:ALL?	494
DIAGnostic:HUMS:TAGS:DELeTe	494

DIAGnostic:HUMS:TAGS:DELeTe:ALL.....	495
DIAGnostic:HUMS:TAGS[:VALue].....	495
SYSTem:COMMunicate:REST:ENABle.....	495
SYSTem:COMMunicate:SNMP:COMMunity:RO.....	495
SYSTem:COMMunicate:SNMP:COMMunity:RW.....	496
SYSTem:COMMunicate:SNMP:CONtAct.....	496
SYSTem:COMMunicate:SNMP:LOCation.....	496
SYSTem:COMMunicate:SNMP:USM:USER.....	497
SYSTem:COMMunicate:SNMP:USM:USER:ALL?.....	497
SYSTem:COMMunicate:SNMP:USM:USER:DELeTe.....	498
SYSTem:COMMunicate:SNMP:USM:USER:DELeTe:ALL.....	498
SYSTem:COMMunicate:SNMP:VERsion.....	498

DIAGnostic:HUMS:DELeTe:ALL

Deletes the complete HUMS data. This includes device history, device tags, SCPI connections, utilization history and utilizations.

Example: //Delete HUMS data
 DIAG:HUMS:DEL:ALL

Usage: Event

DIAGnostic:HUMS:DEvIce:HISToRy?

Queries the device history information of the connected instrument. Depending on the set data format, the queried data is either displayed in XML or JSON format. For more information about setting the data format, see [DIAGnostic:HUMS:FORMat](#) on page 493.

Return values:

<HistoryInfo> <block_data>
Device history information of the connected instrument as block data in a comma-separated list:
#blockdata[{event1},{event2},{event3}...]

With the following parameters:
 <eventID>,<eventTimestamp>,<eventMessage>,<eventDetails>,<eventSeverity>
 Binary block data with the following syntax:
 #<Digits><Length><Binarydata>
 #
 Indicates the start of the binary block
<Digits>
 Decimal value
 Gives the number of decimal digits used for the <Length> value
<Length>
 Decimal value
 Number of bytes the follow in the <Binary data> part
<Binary data>

Binary data in ASCII format

Example: //Return device history
 DIAG:HUMS:DEV:HIST?
Returns for example:
 #44715[{"eventId":32,"eventTimestamp":
 "2021-02-02T17:25:39Z","eventMessage":
 "Deviation from Self Alignment Temperature",
 "eventDetails":
 "Deviations resolved","eventSeverity":0}
Usage: Query only
Manual operation: See ["Export History"](#) on page 410

DIAGnostic:HUMS:DEvIce:HISTory:DELeTe:ALL

Deletes the complete device history information of the connected instrument.

Example: //Delete complete device history
 DIAG:HUMS:DEV:HIST:DEL:ALL
Usage: Event
Manual operation: See ["Delete History"](#) on page 410

DIAGnostic:HUMS:FORMat <DataFormat>

Selects the format for the queried HUMS data. You can query the HUMS data either in JSON format or XML format.

The defined format affects all other commands that return block data.

Parameters:

<DataFormat> JSON | XML
JSON
 Returns the HUMS data in JSON format.
XML
 Returns the HUMS data in XML format.
 *RST: JSON

Example: //Return data in JSON format
 DIAG:HUMS:FORM JSON

DIAGnostic:HUMS:SAVE <path>

Saves the HUMS history as a ZIP file to your preferred path.

Setting parameters:

<path>

Example: //Save HUMS history data
 DIAG:HUMS:SAVE 'C:\HUMS\hums_2021.zip'

Usage: Setting only

Manual operation: See ["Export History"](#) on page 410

DIAGnostic:HUMS:STATe <State>

Turns the HUMS service and data collection on and off.

Parameters:

<State> ON | OFF | 1 | 0
*RST: ON

Example: //Turn on HUMS service
DIAG:HUMS:STAT ON

Manual operation: See ["State"](#) on page 409

DIAGnostic:HUMS:TAgS:ALL?

Queries all key-value tags that you have assigned to the instrument. Depending on the set data format, the queried data is either displayed in XML or JSON format. For more information about setting the data format, see [DIAGnostic:HUMS:FORMat](#) on page 493.

Return values:

<ID> ID number of the defined tag.
<Key> String containing key name of the defined tag.
<Value> String containing value of the defined tag.

Example: //Return all tags
DIAG:HUMS:TAgS:ALL?
1,"location","building_11",2,"time zone","CET"

Usage: Query only

Manual operation: See ["Add"](#) on page 418

DIAGnostic:HUMS:TAgS:DELeTe <ID>

Deletes a certain tag you assigned to your instrument, including its key and value.

Setting parameters:

<ID> ID number of the tag you want to delete.
To identify the ID number, query all device tags from the system first. For more information, see [DIAGnostic:HUMS:TAgS:ALL?](#) on page 494.

Example: //Delete tag
DIAG:HUMS:TAgS:DEL 0

Usage: Setting only

Manual operation: See ["Delete"](#) on page 418

DIAGnostic:HUMS:TAGS:DELeTe:ALL

Deletes all key-value tags you have assigned to the instrument.

Example: //Delete all tags
 DIAG:HUMS:TAGS:DEL:ALL

Usage: Event

Manual operation: See ["Delete All"](#) on page 418

DIAGnostic:HUMS:TAGS[:VALue] <ID>, <Key>, <Value>**DIAGnostic:HUMS:TAGS[:VALue]? <ID>**

Adds or modifies a key-value pair (device tag).

The query returns the key-value pair for a given ID or an empty string if the ID is unknown.

Parameters:

<Key> String containing key name of the queried tag.

<Value> String containing value of the queried tag.

Parameters for setting and query:

<ID> 0 - 31
 ID number of the tag you want to modify or query.
 To identify the ID number, query all device tags from the system first. For more information, read here [DIAGnostic:HUMS:TAGS:ALL?](#) on page 494.

Example: //Add or modify a tag (tag 1)
 DIAG:HUMS:TAGS 1, 'location', 'building_11'

Manual operation: See ["Key"](#) on page 417
 See ["Value"](#) on page 417
 See ["Add"](#) on page 418

SYSTem:COMMunicate:REST:ENABle <RestState>

Turns communication via the REST API on and off.

Parameters:

<RestState> ON | OFF | 0 | 1

Example: //Return REST state
 SYST:COMM:REST:ENAB?

Manual operation: See ["REST"](#) on page 411

SYSTem:COMMunicate:SNMP:COMMunity:RO <CommunityString>

Defines the SNMP community string for read-only access.

Prerequisites for this command:

- Select an SNMP version that supports communities (`SYSTem:COMMunicate:SNMP:VERSion` on page 498).

Setting parameters:

<CommunityString> String containing the community name.

Example: //Set community name
 SYST:COMM:SNMP:VERS V12
 SYST:COMM:SNMP:COMM:RO 'ABC'

Usage: Setting only

Manual operation: See "[Access](#)" on page 412

SYSTem:COMMunicate:SNMP:COMMunity:RW <CommunityString>

Defines the SNMP community string for read-write access.

Prerequisites for this command:

- Select an SNMP version that supports communities (`SYSTem:COMMunicate:SNMP:VERSion` on page 498).

Setting parameters:

<CommunityString> String containing the community name.

Example: //Set read-write access
 SYST:COMM:SNMP:VERS V12
 SYST:COMM:SNMP:COMM:RW 'ABC'

Usage: Setting only

Manual operation: See "[Access](#)" on page 412

SYSTem:COMMunicate:SNMP:CONtact <SnmpContact>

Defines the SNMP contact information for the administrator.

You can also set the contact information via SNMP if you do not set it via SCPI.

Parameters for setting and query:

<SnmpContact> String containing SNMP contact.
 *RST: "" (empty string)

Example: //Set SNMP contact
 SYST:COMM:SNMP:CONT 'ABC'

Manual operation: See "[Contact](#)" on page 412

SYSTem:COMMunicate:SNMP:LOCation <SnmpLocation>

Defines the SNMP location information for the administrator.

You can also set the location information via SNMP if you do not set it via SCPI.

Parameters for setting and query:

<SnmpLocation> String containing SNMP location.
 *RST: "" (empty string)

Example: //Return SNMP location
 SYST:COMM:SNMP:LOC?

Manual operation: See ["Location"](#) on page 412

SYSTem:COMMunicate:SNMP:USM:USER <Name>, <Access>, <Level>[, <Auth_pwd>[, <Priv_pwd>]]

Defines an SNMP user profile.

Prerequisites for this command:

- Select SNMPv3 ([SYSTem:COMMunicate:SNMP:VERSion](#) on page 498).

Setting parameters:

<Name> String containing name of the user.
 <Access> RO | RW
 Defines the access right a user can have.
 <Level> NOAuth | AUTH | PRIVacy
 Defines the security level.

<Auth_pwd> String containing the authentication password.
 <Priv_pwd> String containing the privacy password.

Example: //Create user profile
 SYST:COMM:SNMP:VERS V123
 SYST:COMM:SNMP:USM:USER 'Peter','RO','PRIV',
 '1234','XYZ'

Usage: Setting only

Manual operation: See ["Add SNMP User for HUMS"](#) on page 415

SYSTem:COMMunicate:SNMP:USM:USER:ALL?

Queries the number of users and a list of all SNMP users for SNMPv3.

Prerequisites for this command:

- Select SNMPv3 ([SYSTem:COMMunicate:SNMP:VERSion](#) on page 498).

Return values:

<Count> Total number of registered SNMP users.
 <Name> List of all user names as a comma-separated list.

Example: //Return all SNMP users
 SYST:COMM:SNMP:USM:USER:ALL?

Usage: Query only

Manual operation: See ["User table"](#) on page 413

SYSTem:COMMunicate:SNMP:USM:USER:DELeTe <UserName>

Deletes a specific SNMP user profile.

Setting parameters:

<UserName> String containing name of SNMP user profile to be deleted.

Example: //Delete SNMP user profile
 SYST:COMM:SNMP:USM:USER:DEL "Peter"

Usage: Setting only

Manual operation: See ["Delete"](#) on page 415

SYSTem:COMMunicate:SNMP:USM:USER:DELeTe:ALL

Deletes all SNMP user profiles.

Example: //Delete all SNMP user profiles
 SYST:COMM:SNMP:USM:USER:DEL:ALL

Usage: Event

Manual operation: See ["Delete All"](#) on page 413

SYSTem:COMMunicate:SNMP:VERSion <SnpVersion>

Selects the SNMP version.

Parameters for setting and query:

<SnpVersion> OFF | V12 | V123 | V3 | DEFault

OFF

SNMP communication is off.

V12

SNMP communication with SNMPv2 or lower.

V123

SNMP communication with SNMPv2 and SNMPv3.

V3

SNMP communication with SNMPv3.

*RST: V123

Example: //Select the SNMP version
 SYST:COMM:SNMP:VERS V12

Manual operation: See ["SNMP"](#) on page 411

14.10 DISPlay subsystem

The DISPlay system contains the commands to set the power-save mode of the instrument.

Programming Examples

Example: Activating screen saver mode and display update

Use the following commands to switch on the screen saver of your instrument or to automatic display. These settings are particularly useful when you control the instrument remotely.

```
// Set the wait time interval and activate the screen saver
DISPlay:PSAVE:HOLDoff 10
DISPlay:PSAVE:STATE ON

// Disable the display of the current frequency and level values in remote control
DISPlay:ANNotation:ALL ON
// DISPlay:ANNotation:FREQuency ON
// DISPlay:ANNotation:AMPLitude ON

// Enable automatic update of the display at defined time intervals
DISPlay:UPDate[:STATE] ON
```

Example: Querying the dialog IDs, opening and closing dialogs

Use the following commands to query the dialog IDs of all currently open dialogs. The dialog ID is a prerequisite for opening and closing dialogs via the remote control.



The dialog ID is also required to define user key actions.

See [Chapter 12.2.4, "How to assign actions to the \[★ \(User\)\] key"](#), on page 350.

```
// Query the dialog IDs of all open dialogs
DISPlay:DIALOG:ID?
// CEUtraDLGenSetDlg,_, $A DlgKeyRf_Rosc
```

```
// Open and close dialogs via remote control
DISPlay:DIALOG:OPEN "CEUtraDLGenSetDlg,_, $A"
DISPlay:DIALOG:OPEN "DlgKeyRf_Rosc"
DISPlay:DIALOG:CLOSE "DlgKeyRf_Rosc"
DISPlay:DIALOG:CLOSE:ALL
```

:DISPlay:PSAVE:HOLDoff.....	500
:DISPlay:PSAVE[:STATE].....	500
:DISPlay:BRIGhtness.....	500
:DISPlay:BUTTon:BRIGhtness.....	501
:DISPlay:UPDate[:STATE].....	501
:DISPlay:ANNotation:AMPLitude.....	501
:DISPlay:ANNotation:FREQuency.....	501

:DISPlay:ANNotation[:ALL].....	502
:DISPlay:DIALog:ID?.....	502
:DISPlay:DIALog:OPEN.....	503
:DISPlay:DIALog:CLOSe.....	503
:DISPlay:DIALog:CLOSe:ALL.....	503

:DISPlay:PSAVe:HOLDoff <HoldoffTimeMin>

Sets the wait time for the screen saver mode of the display.

Parameters:

<HoldoffTimeMin> integer
 Range: 1 to 60
 *RST: n.a. (factory preset: 10)
 Default unit: minute

Example: see [Example"Activating screen saver mode and display update"](#)
 on page 499

Manual operation: See ["Wait Time"](#) on page 341

:DISPlay:PSAVe[:STATe] <State>

Activates the screen saver mode of the display.

We recommend that you use this mode to protect the display, if you operate the instrument in remote control.

To define the wait time, use the command `:DISPlay:PSAVe:HOLDoff`.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 0)

Example: See [Example"Activating screen saver mode and display update"](#)
 on page 499

Manual operation: See ["Screen Saver"](#) on page 341

:DISPlay:BRIGhtness <BRIGhtness>

Sets the brightness of the display.

Parameters:

<BRIGhtness> float
 Range: 1.0 to 20.0
 Increment: 1.0
 *RST: 14.0

Example: `DISPlay:BRIGhtness 14`

Manual operation: See ["Display"](#) on page 341

:DISPlay:BUtTon:BRIGhtness <ButtonBrightnes>

Sets the brightness of the [RF on/off] key.

Parameters:

<ButtonBrightnes> integer
 Range: 1 to 20
 *RST: n.a. (no preset. default: 14)

Example: DISPlay:BUtTon:BRIGhtness 15

Manual operation: See ["RF Hardkey"](#) on page 341

:DISPlay:UPDate[:STATe] <Update>

Activates the refresh mode of the display.

Parameters:

<Update> 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 1)

Example: See [Example"Activating screen saver mode and display update"](#) on page 499

Manual operation: See ["Display Update is"](#) on page 342

:DISPlay:ANNotation:AMPLitude <State>

Indicates asterisks instead of the level values in the status bar.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 1)

Example: See [Example"Activating screen saver mode and display update"](#) on page 499

Manual operation: See ["Annotation Amplitude"](#) on page 366

:DISPlay:ANNotation:FREQuency <State>

Indicates asterisks instead of the frequency values in the status bar.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 1)

Example: See [Example"Activating screen saver mode and display update"](#) on page 499

Manual operation: See ["Annotation Frequency"](#) on page 365

:DISPlay:ANNotation[:ALL] <State>

Displays asterisks instead of the level and frequency values in the status bar of the instrument.

We recommend that you use this mode if you operate the instrument in remote control.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 1

Example: See [Example "Activating screen saver mode and display update"](#) on page 499

:DISPlay:DIALog:ID?

Returns the dialog identifiers of the open dialogs in a string separated by blanks.

Return values:

<DialogIdList> <DialogID#1>< ><DialogID#2>< > ... < ><DialogID#n>
Dialog identifiers are string without blanks. Blanks are represented as \$\$.
Dialog identifiers <DialogID> are composed of two main parts:
<DialogName> [<OptionalParts>]
<DialogName>
Meaningful information, mandatory input parameter for the commands:
[:DISPlay:DIALog:OPEN](#) on page 503
[:DISPlay:DIALog:CLOSe](#) on page 503
<Optional parts>
String of \$<X> values, where <X> is a character, interpreted as follows:
\$q<DialogQualifier>: optional dialog qualifier, usually the letter A or B, as displayed in the dialog title.
\$i<Instances>: comma-separated list of instance indexes, given in the order h, c, s, d, g, u, 0. Default is zero; the terminating ", 0" can be omitted.
\$t<TabIds>: comma-separated indexes or tab names; required, if a dialog is composed of several tabs.
\$x<Left>\$y<Top>\$h<Left>\$w<Top>: position and size; superfluous information.

Example: See [Example "Querying the dialog IDs, opening and closing dialogs"](#) on page 499

Usage: Query only

Manual operation: See ["SCPI"](#) on page 349

:DISPlay:DIALog:OPEN <DialogId>

Opens the specified dialog.

Setting parameters:

<DialogId> string
To find out the dialog identifier, use the query **:DISPlay:DIALog:ID?**.
The <DialogName> part of the query result is mandatory.

Example: See [Example"Querying the dialog IDs, opening and closing dialogs"](#) on page 499

Usage: Setting only

Manual operation: See ["SCPI"](#) on page 349

:DISPlay:DIALog:CLOSe <DialogId>

Closes the specified dialog.

Setting parameters:

<DialogId> string
To find out the dialog identifier, use the query **:DISPlay:DIALog:ID?**.
The <DialogName> part of the query result is sufficient.

Example: See [Example"Querying the dialog IDs, opening and closing dialogs"](#) on page 499

Usage: Setting only

:DISPlay:DIALog:CLOSe:ALL

Closes all open dialogs.

Example: See [Example"Querying the dialog IDs, opening and closing dialogs"](#) on page 499

Usage: Event

14.11 FORMat subsystem

The commands in the FORMat subsystem determine the format of data returned by the R&S SMA100B to the controller. This affects all query commands that return a list of numerical data or block data, noted in the descriptions of the commands. The set data format applies to both paths.

:FORMat:BORDer	504
:FORMat:SREGister	504
:FORMat[:DATA]	504

:FORMat:BORDER <Border>

Determines the sequence of bytes within a binary block. This only affects blocks which use the IEEE754 format internally.

Parameters:

<Border> NORMal | SWAPped

NORMal

Expects/sends the *least* significant byte of each IEEE754 floating-point number first and the *most* significant byte last.

SWAPped

Expects/sends the *most* significant byte of each IEEE754 floating-point number first and the *least* significant byte last.

*RST: NORMal

Example:

:FORM:BORD SWAP

transfers the data with the most significant bit first.

:FORMat:SREGister <Format>

Determines the numeric format for responses of the status register.

Parameters:

<Format> ASCii | BINary | HEXadecimal | OCTal

ASCii

Returns the register content as a decimal number.

BINary|HEXadecimal|OCTal

Returns the register content either as a binary, hexadecimal or octal number. According to the selected format, the number starts with #B (binary), #H (hexadecimal) or #O (octal).

*RST: ASCii

Example:

:FORM:SREG HEX

returns the register content as a hexadecimal number.

:FORMat[:DATA] <Data>

Determines the data format the instrument uses to return data via the IEC/IEEE bus.

The instrument automatically detects the data format used by the controller, and assigns it accordingly. Data format determined by this SCPI command is in this case irrelevant.

Parameters:

<Data> ASCii | PACKed

ASCii

Transfers numerical data as plain text separated by commas.

PACKed

Transfers numerical data as binary block data.

The format within the binary data depends on the command.

The various binary data formats are explained in the description of the parameter types.

*RST: ASCii

Example:

:FORM ASC

transfers the data as ASCII data.

14.12 HCOpy subsystem

The HCOpy subsystem contains the commands to generate and save a hard copy of the display.



To access a stored hard copy file, use the commands of the MEMM subsystem.

Example: Store a hard copy of the display

The following example lists commands to configure and execute a hard copy to an automatic named file.

```
:HCOpy:DEVIce:LANGUage PNG
:HCOpy:FILE:NAME:AUTO:STATe 1
// defines the output format
// sets the instrument to automatically create output file names

// *****
// Configure hard copy options, set automatic naming rules
// An automatically generated file name consists of:
// <Prefix><YYYY><MM><DD><Number>.<Format>
// *****
:HCOpy:DEVIce:LANGUage BMP
// defines output format *.bmp
:HCOpy:REGion DIALog
// selects the region to be copied
:HCOpy:FILE:AUTO:DIR "/usb/HCOpy"
// sets destination directory of automatic named file
:HCOpy:FILE:NAME:AUTO:FILE:PREFix:STATe 1
:HCOpy:FILE:NAME:AUTO:FILE:PREFix:"hardcopy"
:HCOpy:FILE:NAME:AUTO:FILE:YEAR:STATe 1
:HCOpy:FILE:NAME:AUTO:FILE:MONTH:STATe 1
// uses automatic naming prefix
// sets automatic naming prefix to "hardcopy"
// uses automatic naming date parameters year and month

// *****
```

```
// Execute and transfer the hard copy
// *****
:HCOPY:EXECute
:HCOPY:DATA
// generates a hard copy
// transfers the hard copy to the remote client
:HCOPY:FILE:AUTO:FILE?
// queries the automatic file name
// "hardcopy1607001.bmp"
:HCOPY:FILE:AUTO:NUMBer?
// queries the number in the automatic file name
// "001"
:HCOPY:FILE:AUTO?
// queries the path and file name of the automatically generated file
// "/usb/HCopy/hardcopy1607001.bmp"
```

14.12.1 Hard copy settings

With the following commands, you can configure the settings of a hard copy.

:HCOPY:DATA?	506
:HCOPY:IMAGe:FORMat	506
:HCOPY:DEVIce:LANGuage	506
:HCOPY:REGion	507
:HCOPY:FILE[:NAME]	507
:HCOPY[:EXECute]	507

:HCOPY:DATA?

Transfers the hard copy data directly as a NByte stream to the remote client.

Return values:	
<Data>	block data
Example:	See Example"Store a hard copy of the display" on page 505
Usage:	Query only

:HCOPY:IMAGe:FORMat <Format>
:HCOPY:DEVIce:LANGuage <Language>

Selects the graphic format for the hard copy. You can use both commands alternatively.

Parameters:	
<Language>	BMP JPG XPM PNG
*RST:	PNG
Example:	See Example"Store a hard copy of the display" on page 505
Manual operation:	See "Format" on page 335

:HCOpy:REGion <Region>

Selects the area to be copied.

You can create a snapshot of the screen or an active dialog.

Parameters:

<Region> ALL | DIALog
*RST: ALL

Example: See [Example"Store a hard copy of the display"](#) on page 505

Manual operation: See ["Region"](#) on page 335

:HCOpy:FILE[:NAME] <Name>

Determines the file name and path to save the hard copy, provided automatic naming is disabled.

Note: If you have enabled automatic naming, the instrument automatically generates the file name and directory, see [Chapter 14.12.2, "Automatic naming"](#), on page 507.

Parameters:

<Name> string

Example: See [Example"Store a hard copy of the display"](#) on page 505

Manual operation: See ["File..."](#) on page 334

:HCOpy[:EXECute]

Generates a hard copy of the current display. The output destination is a file.

Example: See [Example"Store a hard copy of the display"](#) on page 505

Usage: Event

Manual operation: See ["Save"](#) on page 335

14.12.2 Automatic naming

Use the following commands to automatically assign a file name.

:HCOpy:FILE[:NAME]:AUTO?	508
:HCOpy:FILE[:NAME]:AUTO:DIRectory	508
:HCOpy:FILE[:NAME]:AUTO:DIRectory:CLEar	508
:HCOpy:FILE[:NAME]:AUTO:FILE?	508
:HCOpy:FILE[:NAME]:AUTO:STATe	509
:HCOpy:FILE[:NAME]:AUTO[:FILE]:DAY:STATe	509
:HCOpy:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe	509
:HCOpy:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe	509
:HCOpy:FILE[:NAME]:AUTO[:FILE]:NUMBer?	509
:HCOpy:FILE[:NAME]:AUTO[:FILE]:PREFix	510
:HCOpy:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe	510

:HCOPY:FILE[:NAME]:AUTO?

Queries path and file name of the hardcopy file, if you have enabled *Automatic Naming*.

Return values:

<Auto> string

Example: See [Example"Store a hard copy of the display"](#) on page 505

Usage: Query only

:HCOPY:FILE[:NAME]:AUTO:DIRectory <Directory>

Determines the path to save the hard copy, if you have enabled *Automatic Naming*.

If the directory does not yet exist, the instrument automatically creates a new directory, using the instrument name and `/var/user/` by default.

Parameters:

<Directory> string
 *RST: /var/user/

Example: See [Example"Store a hard copy of the display"](#) on page 505

Manual operation: See ["Path..."](#) on page 336

:HCOPY:FILE[:NAME]:AUTO:DIRectory:CLEar

Deletes all files with extensions `*.bmp`, `*.jpg`, `*.png` and `*.xpm` in the directory set for automatic naming.

Example: See [Example"Store a hard copy of the display"](#) on page 505

Usage: Event

Manual operation: See ["Clear Path"](#) on page 336

:HCOPY:FILE[:NAME]:AUTO:FILE?

Queries the name of the automatically named hard copy file.

An automatically generated file name consists of:

<Prefix><YYYY><MM><DD><Number>.<Format>.

You can activate each component separately, to individually design the file name.

Return values:

<File> string

Example: See [Example"Store a hard copy of the display"](#) on page 505.

Usage: Query only

:HCOPY:FILE[:NAME]:AUTO:STATe <State>

Activates automatic naming of the hard copy files.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 1

Example: See [Example"Store a hard copy of the display"](#) on page 505

Manual operation: See ["Automatic Naming"](#) on page 335

:HCOPY:FILE[:NAME]:AUTO[:FILE]:DAY:STATe <State>

:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe <State>

:HCOPY:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe <State>

Uses the date parameters (year, month or day) for the automatic naming. You can activate each of the date parameters separately.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 1

Example: See [Example"Store a hard copy of the display"](#) on page 505

Manual operation: See ["Prefix, Year, Month, Day"](#) on page 336

:HCOPY:FILE[:NAME]:AUTO[:FILE]:NUMBer?

Queries the number that is used as part of the file name for the next hard copy in automatic mode.

At the beginning, the count starts at 0. The R&S SMA100B searches the specified output directory for the highest number in the stored files. It increases this number by one to achieve a unique name for the new file.

The resulting auto number is appended to the resulting file name with at least three digits.

Return values:

<Number> integer
 Range: 0 to 999999
 *RST: 0

Example: See [Example"Store a hard copy of the display"](#) on page 505

Usage: Query only

Manual operation: See ["Current Auto Number"](#) on page 337

:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFIX <Prefix>

:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFIX:STATe <State>

Uses the prefix for the automatic generation of the file name, provided `PREF:STAT` is activated.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 1

Example: See [Example "Store a hard copy of the display"](#) on page 505

Manual operation: See ["Prefix, Year, Month, Day"](#) on page 336

14.13 KBOard subsystem

The `KBOard` subsystem contains the commands to set a connected keyboard.

[:KBOard:LAYout](#).....510

:KBOard:LAYout <Layout>

Selects the language for an external keyboard and assigns the keys accordingly.

Parameters:

<Layout> CHINEse | DANish | DUTCh | DUTBe | ENGLish | ENGUK |
 FINNish | FRENch | FREBe | FRECa | GERMan | ITALian |
 JAPANese | KORean | NORWegian | PORTuguese | RUSSian |
 SPANish | SWEDish | ENGUS
 *RST: n.a. (factory preset: ENGLish)

Example: :KBOard:LAYout US
 // activates American keyboard

Manual operation: See ["USB Keyboard > Layout"](#) on page 341

14.14 OUTPut subsystem

In the `OUTPut` subsystem, you can configure the output signals.

The LF output signal is defined with the commands of the [Chapter 14.17.6, "SOURce:LFOutput subsystem"](#), on page 674 system.

Common suffixes

The following common suffixes are used in remote commands:

Suffix	Value range	Description
OUTPut<hw>	[1]	Optional suffix

:OUTPut:ALL[:STATe].....	511
:OUTPut<hw>[:STATe].....	511
:OUTPut<hw>[:STATe]:PON.....	511
:OUTPut<hw>:AMODE.....	512
:OUTPut<hw>:FILTer:MODE.....	512
:OUTPut<hw>:IMPedance?.....	512
:OUTPut:FPRoportional:SCALE.....	513
:OUTPut:USER:MARKer.....	513
:OUTPut<hw>:AFIXed:RANGe:LOWer?.....	513
:OUTPut<hw>:AFIXed:RANGe:UPPer?.....	513
:OUTPut<hw>:PROTection:CLEar.....	514
:OUTPut<hw>:PROTection:TRIPped?.....	514

:OUTPut:ALL[:STATe] <State>

Activates the RF output signal of the instrument.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 0)

Example: :OUTPut:ALL:STATe 0

:OUTPut<hw>[:STATe] <State>

Activates the RF output signal.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: :OUTPut1 ON
 Activates the RF output.

Manual operation: See "RF State/RF ON" on page 63

:OUTPut<hw>[:STATe]:PON <Pon>

Defines the state of the RF output signal when the instrument is switched on.

Parameters:

<Pon> OFF | UNCHanged
 *RST: n.a. (factory preset: UNCHanged)

Example: :OUTPut1:PON OFF
 The RF output is deactivated when the instrument is switched on.

Manual operation: See ["Power-On State"](#) on page 342

:OUTPut<hw>:AMODE <AMode>

Sets the step attenuator mode at the RF output.

Parameters:

<AMode>

AUTO | FIXEd

AUTO

The step attenuator adjusts the level settings automatically, within the full variation range.

FIXEd

The step attenuator and amplifier stages are fixed at the current position, providing level settings with constant output VSWR. The resulting variation range is calculated according to the position.

*RST: AUTO

Example:

```
:SOURce1:POWer:ALC:STAtE 1
:OUTPut1:AMODE FIXEd
```

Manual operation: See ["Mode"](#) on page 212

:OUTPut<hw>:FILTer:MODE <Mode>

Activates low harmonic filter or enables its automatic switching.

Parameters:

<Mode>

ON | AUTO | 1

ON|1

Ensures best low harmonics performance but decreases the level range

AUTO

Applies an automatically selected harmonic filter that fits to the current level setting.

*RST: AUTO

Example:

```
:OUTPut1:FILTer:MODE AUTO
```

Manual operation: See ["Harmonic Filter"](#) on page 75

:OUTPut<hw>:IMPedance?

Queries the impedance of the RF outputs.

Return values:

<Impedance>

G1K | G50 | G10K

*RST: G50

Example: :OUTPut1:IMP?
 queries the impedance of RF output.
 Response: 50
 the impedance is 50 ohms

Usage: Query only

Manual operation: See "[RF output impedance](#)" on page 63

:OUTPut:FPRoportional:SCALE <OutpSelScale>

Selects the mode the voltage is supplied depending on the frequency.

The R&S SMA100B supplies the signal at the V/GHz X-Axis connector.

Parameters:

<OutpSelScale> S0V25 | S0V5 | S1V0 | XAXis

S0V25|S0V5|S1V0

Supplies the voltage proportional to the set frequency, derived from the selected setting.

XAXis

Supplies a voltage range from 0 V to 10 V proportional to the frequency sweep range, set with [:SOURce<hw>] :FREQuency:STARt and [:SOURce<hw>] :FREQuency:STOP.

*RST: S0V25

Options: R&S SMAB-B28

Manual operation: See "[V/GHz / X-Axis](#)" on page 196

:OUTPut:USER:MARKer <SelUserMarker>

Selects the signal for output at the Marker User1 connector.

Parameters:

<SelUserMarker> MARK | USER

MARK

Assigns a marker signal to the output.

USER

Intended for future use.

*RST: MARK

Options: R&S SMAB-B28

Manual operation: See "[Marker / User](#)" on page 196

:OUTPut<hw>:AFIXed:RANGe:LOWer?

:OUTPut<hw>:AFIXed:RANGe:UPPer?

Queries the settable minimum/maximum value in mode :OUTPut:AMODE FIXed, i.e. when the attenuator is not being adjusted.

See `:OUTPut<hw>:AMODE` on page 512

Return values:

<Upper> float
Increment: 0.01
Default unit: dBm

Example:

```
:OUTPut1:AMODE FIXEd
:OUTPut1:AFIXEd:RANGE:UPPer?
// -27
:OUTPut1:AFIXEd:RANGE:LOW?
// -50
```

Usage: Query only

Manual operation: See "Level Range" on page 212

:OUTPut<hw>:PROTection:CLEAr

Resets the protective circuit after it has been tripped.

To define the output state, use the command `:OUTPut<hw>[:STATe]`.

Example:

```
:OUTPut1:PROT:CLE
Resets the protective circuit of the RF output.
```

Usage: Event

Manual operation: See "Overload" on page 213

:OUTPut<hw>:PROTection:TRIPped?

Queries the state of the protective circuit.

Return values:

<Tripped> 1 | ON | 0 | OFF
*RST: 0

Example:

```
:OUTPut1:PROT:TRIP
queries the state of the protective circuit of the RF output.
Response: 0
the protective circuit has not tripped.
```

Usage: Query only

Manual operation: See "Overload" on page 213

14.15 Power sensor measurement subsystems

The power sensor measurement uses several subsystems:

- The `CALCulate` subsystem is used to configure the time gated measurements in power analysis.

- The `DISPlay` subsystem is used to configure the diagram appearance.
- The `INITiate` command switches the local state of the continuous power measurement on and off.
- The `READ` system is used to start and to retrieve the measurement result of the power viewer measurement.
- The `SENSe` subsystem contains the commands for configuring the power viewer and power analysis measurements with power sensors connected to the generator. Up to four sensors can be connected to the signal generator.
- The `TRACe` subsystem is used to configure the traces in power analysis and to retrieve the measurement results.

Power Viewer

The power viewer measurement is started with the `READ` command, this command also retrieves the measurement results.

The sensors are distinguished by the suffix under `SENSe`:

- Power sensor connected to the `SENSOR` port = `SENSe[1]`
- First Power sensor connected to the USB interface = `SENSe2`
- Second Power sensor connected to the USB interface = `SENSe3`
- Third Power sensor connected to the USB interface = `SENSe4`

Power and Pulse Data Analysis, Gated Measurements (option R&S SMA100B-K28)

The power analysis measurement commands are subsumed under the `SENSe[:POWER]:SWEep:...` commands. Three measurement modes are available: Frequency, Power and Time.

The power analysis measurement is started with the `SENSe[:POWER]:SWEep:INITiate` command and the measurement result retrieved with the `TRACe[:POWER]:SWEep:...` commands.

The four sensors are distinguished by the suffix at the second key word `SENSe`.

The time gate settings are performed using the `CALCulate[:POWER]:SWEep:...` commands.

The measurement diagram and results can be stored in a hardcopy with the `SENSe[:POWER]:SWEep:HCOpy:...` commands.

General parameter and measurement settings are valid for all connected sensors, therefore, no suffix is used in these commands.

14.15.1 CALCulate subsystem

<code>:CALCulate[:POWER]:SWEep:FREQuency:MATH<ch>:STATe</code>	516
<code>:CALCulate[:POWER]:SWEep:FREQuency:MATH<ch>:SUBTract</code>	516
<code>:CALCulate[:POWER]:SWEep:FREQuency:MATH<ch>:XVAL</code>	517
<code>:CALCulate[:POWER]:SWEep:FREQuency:MATH<ch>:YVAL</code>	517

:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:STATe.....	517
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:SUBTract.....	518
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:XVAL.....	518
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:YVAL.....	518
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:AVERAge?	519
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:FEED.....	519
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:MAXimum?	519
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:START.....	520
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:STOP.....	520
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:STATe.....	520
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:STATe.....	521
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:SUBTract.....	521
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:XVAL.....	521
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:YVAL.....	522

:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:STATe <State>

Activates the trace mathematics mode for "Frequency" measurement. This feature enables you to calculate the difference between the measurement values of two traces. For further calculation, a math result can also be assigned to a trace.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

CALC:POW:SWE:FREQ:MATH2:STATe
 Switches on math mode in trace 2.

Options:

R&S SMAB-K28

Manual operation: See ["Mathematics - Trace Power Analysis"](#) on page 248

:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:SUBTract <Subtract>

Subtracts the operands 1 and 2 and assigns the result to the selected trace in "Frequency" measurement mode.

Parameters:

<Subtract> T1T1 | T1T2 | T1T3 | T1T4 | T1REf | T2T1 | T2T2 | T2T3 | T2T4 |
 T2REf | T3T1 | T3T2 | T3T3 | T3T4 | T3REf | T4T1 | T4T2 |
 T4T3 | T4T4 | T4REf

Example:

CALC:POW:SWE:FREQ:MATH4:SUBT T2REF
 Subtracts the Reference and Trace 2, and assigns the result to Trace 4. The resulting curve is shown in the diagram.

Options:

R&S SMAB-K28

Manual operation: See ["Mathematics - Trace Power Analysis"](#) on page 248

:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:XVAL <XVal>

Sets the x-axis values for calculating the reference curve in frequency measurement mode.

To determine two points ("Point A"/"Point B"), set suffix 1 and 2 in keyword `MATH<ch>`.

Parameters:

`<XVal>` float
 Range: 0 to 1E12
 Increment: 1
 *RST: 1E12

Example:

```
CALCulate:POWer:SWEep:FREQuency:MATH1:XVAL 8000
CALCulate:POWer:SWEep:FREQuency:MATH2:XVAL
10000000000
Sets the frequency points to calculate the reference curve.
```

Manual operation: See "[Freq \(X\)](#)" on page 250

:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:YVAL <YVal>

Sets the y-axis values for calculating the reference curve in frequency measurement mode.

To determine two points ("Point A"/"Point B"), set suffix 1 and 2 in keyword `MATH<ch>`.

Parameters:

`<YVal>` float
 Range: 200 to 100
 Increment: 0.0001
 *RST: -40

Example:

```
CALCulate:POWer:SWEep:FREQuency:MATH1:YVAL -20
CALCulate:POWer:SWEep:FREQuency:MATH2:YVAL -20
Sets the power values for the two frequency points to calculate
the reference curve.
```

Manual operation: See "[POW \(Y\)](#)" on page 250

:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:STATe <State>

Activates the trace mathematics mode for "Power" measurement. This feature enables you to calculate the difference between the measurement values of two traces. For further calculation, a math result can also be assigned to a trace.

Parameters:

`<State>` 0 | 1 | OFF | ON
 *RST: 0

Example:

```
CALC:POW:SWE:POW:MATH2:STATe
Switches on math mode in trace 2.
```

Options:

R&S SMAB-K28

Manual operation: See ["Mathematics - Trace Power Analysis"](#) on page 248

:CALCulate[:POWER]:SWEep:POWer:MATH<ch>:SUBTract <Subtract>

Subtracts the operands 1 and 2 and assigns the result to the selected trace in "Power" measurement mode.

Parameters:

<Subtract> T1T1 | T1T2 | T1T3 | T1T4 | T1REf | T2T1 | T2T2 | T2T3 | T2T4 |
 T2REf | T3T1 | T3T2 | T3T3 | T3T4 | T3REf | T4T1 | T4T2 |
 T4T3 | T4T4 | T4REf

Example:

CALC:POW:SWE:POW:MATH4:SUBT T2REF

Subtracts the Reference and Trace 2, and assigns the result to Trace 4. The resulting curve is shown in the diagram.

Options: R&S SMAB-K28

Manual operation: See ["Mathematics - Trace Power Analysis"](#) on page 248

:CALCulate[:POWER]:SWEep:POWer:MATH<ch>:XVAL <XVal>

Sets the x-axis values for calculating the reference curve in power measurement mode.

To determine two points ("Point A"/"Point B"), set suffix 1 and 2 in keyword MATH<ch>.

Parameters:

<XVal> float
 Range: -145 to 20
 Increment: 0.01
 *RST: 20

Example:

CALCulate:POWer:SWEep:POWer:MATH1:XVAL 8000

CALCulate:POWer:SWEep:POWer:MATH2:XVAL
 1000000000

Sets the power points of the x-axis to calculate the reference curve.

Manual operation: See ["Pow \(X\)"](#) on page 250

:CALCulate[:POWER]:SWEep:POWer:MATH<ch>:YVAL <YVal>

Sets the y-axis values for calculating the reference curve in power measurement mode.

To determine two points ("Point A"/"Point B"), set suffix 1 and 2 in keyword MATH<ch>.

Parameters:

<YVal> float
 Range: -200 to 100
 Increment: 0.0001
 *RST: -40

Example: `CALCulate:POWer:SWEep:POWer:MATH1:YVAL 20`
`CALCulate:POWer:SWEep:POWer:MATH2:YVAL -30`
 Sets the power values on the y-axis for the two values defined for the x-axis to calculate the reference curve.

Manual operation: See "[Pow \(Y\)](#)" on page 251

:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:AVERage?

Queries the average power value of the time gated measurement.

Return values:

<Average> float
 Range: -1000 to 1000
 Increment: 1E-12
 *RST: 0

Example: `SENS:SWE:MODE TIME`
 Activates time mode for power analysis.
`CALC:SWE:TIME:GATE:STAT ON`
 Activates time gated measurement.
`SENS:SWE:INIT`
 Activates a single power analysis measurement.
`CALC:SWE:TIME:GATE2:AVER?`
 Queries the average power in time gate 2 for trace 1 (=default).

Usage: Query only

Options: Option R&S SMAB-K28

Manual operation: See "[State - Gate](#)" on page 273

:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:FEED <Feed>

Selects the trace for time gated measurement. Both gates are assigned to the same trace.

Parameters:

<Feed> TRAC1 | TRAC2 | TRAC3 | TRACe1 | TRACe2 | TRACe3 |
 TRAC4 | TRACe4
 *RST: TRAC1

Example: `CALC:SWE:TIME:GATE:FEED TRAC2`
 Assigns the gates to trace 2.

Options: Option R&S SMAB-K28

Manual operation: See "[Trace - Gate](#)" on page 272

:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:MAXimum?

Queries the average power value of the time gated measurement.

Return values:

<Maximum> float
 Range: -1000 to 1000
 Increment: 1E-12
 *RST: 0

Example:

SENS:SWE:MODE TIME
 Activates time mode for power analysis.
 CALC:SWE:TIME:GATE:STAT ON
 Activates time gated measurement.
 SENS:SWE:INIT
 Activates a single power analysis measurement.
 CALC:SWE:TIME:GATE2:MAX?
 Queries the peak power in time gate 2 for trace 1 (=default).

Usage: Query only

Options: Option R&S SMAB-K28

Manual operation: See "State - Gate" on page 273

:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:START <Start>

:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:STOP <Stop>

Sets the start time of the selected gate. Insert value and unit.

Parameters:

<Stop> float
 Increment: 1E-12
 *RST: Start/Stop: 5/15 (Gate1), 25/35 (Gate2)

Example:

CALC:SWE:TIME:GATE2:STAR 20us
 Sets a start time of 20 us for gate 2.
 CALC:SWE:TIME:GATE2:STOP 30us
 Sets a stop time of 30us for gate 2.

Options: Option R&S SMAB-K28

Manual operation: See "Start / Stop - Gate" on page 273

:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:STATe <State>

Activates the gate settings for the selected trace. The measurement is started with command SENS:POW:INIT. Both gates are active at one time.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

CALC:SWE:TIME:GATE:STAT ON
 Enables time gated measurement.

Options: Option R&S SMAB-K28

Manual operation: See ["State - Gate"](#) on page 273

:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:STATe <State>

Activates the trace mathematics mode for "Time" measurement. This feature enables you to calculate the difference between the measurement values of two traces. For further calculation, a math result can also be assigned to a trace.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example: CALC:POW:SWE:TIME:MATH1:STATe
Switches on math mode.

Options: R&S SMAB-K28

Manual operation: See ["Mathematics - Trace Power Analysis"](#) on page 248

:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:SUBTract <Subtract>

Subtracts the operands 1 and 2 and assigns the result to the selected trace in "Time" measurement mode.

Parameters:

<Subtract> T1T1 | T1T2 | T1T3 | T1T4 | T1REF | T2T1 | T2T2 | T2T3 | T2T4 |
T2REF | T3T1 | T3T2 | T3T3 | T3T4 | T3REF | T4T1 | T4T2 |
T4T3 | T4T4 | T4REF

Example: CALC:POW:SWE:TIME:MATH4:SUBT T2REF
Subtracts the Reference and Trace 2, and assigns the result to Trace 4. The resulting curve is shown in the diagram.

Options: R&S SMAB-K28

Manual operation: See ["Mathematics - Trace Power Analysis"](#) on page 248

:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:XVAL <XVal>

Sets the x-axis values for calculating the reference curve in time measurement mode.

To determine two points ("Point A"/"Point B"), set suffix 1 and 2 in keyword MATH<ch>.

Parameters:

<XVal> float
Range: 0 to 2
Increment: 1E-12
*RST: -5E-6

Example: CALCulate:POWer:SWEep:TIME:MATH1:XVAL -0.000005
CALCulate:POWer:SWEep:TIME:MATH2:XVAL 0.000045
Sets the time points to calculate the reference curve.

Manual operation: See ["Time \(X\)"](#) on page 251

:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:YVAL <YVal>

Sets the y-axis values for calculating the reference curve in time measurement mode.

To determine two points ("Point A"/"Point B"), set suffix 1 and 2 in keyword **MATH<ch>**.

Parameters:

<YVal> float
 Range: -200 to 100
 Increment: 0.0001
 *RST: -40

Example:

CALCulate:POWER:SWEep:TIME:MATH1:YVAL 20
 CALCulate:POWER:SWEep:TIME:MATH2:YVAL -30
 Sets the power values for the two time points to calculate the reference curve.

Manual operation: See "[Pow \(Y\)](#)" on page 251

14.15.2 DISPlay subsystem

:DISPlay[:WINDow][:POWER]:SWEep:BACKground:COLor.....522
 :DISPlay[:WINDow][:POWER]:SWEep:GRID:STATe.....522

:DISPlay[:WINDow][:POWER]:SWEep:BACKground:COLor <Color>

Defines the background color of the measurement diagram. The selected color applies also to the hardcopy of the diagram.

Parameters:

<Color> BLACK | WHITE
 *RST: BLACK

Example:

DISP:SWE:BACK:COL WHIT
 The measurement is indicated with a white background.

Manual operation: See "[Background Color - Power Analysis](#)" on page 261

:DISPlay[:WINDow][:POWER]:SWEep:GRID:STATe <State>

Indicates a grid in the diagram.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 1

Example:

DISP:SWE:GRID:STAT OFF
 Deactivates the indication of a grid in the diagram area.

Manual operation: See "[Show Grid - Power Analysis](#)" on page 261

14.15.3 INITiate command

:INITiate<hw>[:POWER]:CONTinuous <Continuous>

Switches the local state of the continuous power measurement by R&S NRP power sensors on and off. Switching off local state enhances the measurement performance during remote control.

The remote measurement is triggered with **:READ<ch>[:POWER]?**. This command also returns the measurement results. The local state is not affected, measurement results can be retrieved with local state on or off.

Parameters:

<Continuous> 1 | ON | 0 | OFF
*RST: 0

Example:

INIT1:CONT ON

Switches on the local state of continuous power measurement.

Manual operation: See "State" on page 238

14.15.4 READ subsystem

:READ<ch>[:POWER]?

Triggers power measurement and displays the results.

Note: This command does not affect the local state, i.e. you can get results with local state on or off. For long measurement times, we recommend that you use an SRQ for command synchronization (MAV bit).

Suffix:

<ch> 1 to 3

Return values:

<Power> float or float,float

The sensor returns the result in the unit set with command **:**

SENSe<ch>:UNIT[:POWER]

Certain power sensors, such as the R&S NRP-Z81, return two values, first the value of the average level and - separated by a comma - the peak value.

Example:

:SENS1:UNIT DBM

Selects unit dBm for presentation of measurement result.

:READ1?

Queries the measurement result of the sensor.

-45.6246576745440230

-45.6 dBm were measured at the given frequency.

Example: R&S NRP-Z81
:READ1?
-55.62403263352178,-22.419472478812476
-55.6 dBm is the measured average level, -22.4 dBm is the measured peak level at the given frequency.

Usage: Query only

Manual operation: See "Level (Peak) / Level (Average)" on page 238

14.15.5 SENSE SWEEP subsystem

:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:OFFSet.....	526
:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:OFFSet:STATe.....	526
:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:SRANge:START.....	526
:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:SRANge:STOP.....	527
:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:SRANge[:STATe].....	527
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet.....	528
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet:STATe.....	528
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRequency.....	528
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRequency:STATe.....	529
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet.....	529
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet:STATe.....	529
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:STATe.....	530
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:BASE.....	530
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:HREFerence.....	530
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:LREFerence.....	531
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:REFerence.....	531
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRequency.....	532
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRequency:STATe.....	532
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:AUTO.....	532
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:DTIME.....	532
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:HYSTeresis.....	533
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:LEVel.....	533
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:SLOPe.....	533
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:SOURce.....	534
:SENSe<ch>[:POWer]:ZERO.....	534
:SENSe[:POWer]:SWEep:ABORT.....	534
:SENSe[:POWer]:SWEep:FREQUency:REFerence:DATA:COPI.....	534
:SENSe[:POWer]:SWEep:FREQUency:REFerence:DATA:POINts?.....	535
:SENSe[:POWer]:SWEep:FREQUency:REFerence:DATA:XVALues.....	535
:SENSe[:POWer]:SWEep:FREQUency:REFerence:DATA:YVALues.....	535
:SENSe[:POWer]:SWEep:FREQUency:RMODE.....	535
:SENSe[:POWer]:SWEep:FREQUency:SPACing[:MODE].....	536
:SENSe[:POWer]:SWEep:FREQUency:START.....	536
:SENSe[:POWer]:SWEep:FREQUency:STEPS.....	536
:SENSe[:POWer]:SWEep:FREQUency:STOP.....	536
:SENSe[:POWer]:SWEep:FREQUency:TIMing[:MODE].....	537

Power sensor measurement subsystems

:SENSe[:POWER]:SWEep:FREQuency:YSCale:AUTO.....	537
:SENSe[:POWER]:SWEep:FREQuency:YSCale:AUTO:RESet.....	538
:SENSe[:POWER]:SWEep:FREQuency:YSCale:MAXimum.....	538
:SENSe[:POWER]:SWEep:FREQuency:YSCale:MINimum.....	538
:SENSe[:POWER]:SWEep:HCOPy:DATA?.....	538
:SENSe[:POWER]:SWEep:HCOPy:DEVIce.....	539
:SENSe[:POWER]:SWEep:HCOPy:DEVIce:LANGuage.....	540
:SENSe[:POWER]:SWEep:HCOPy:DEVIce:LANGuage:CSV:DPOint.....	540
:SENSe[:POWER]:SWEep:HCOPy:DEVIce:LANGuage:CSV:HEADer.....	540
:SENSe[:POWER]:SWEep:HCOPy:DEVIce:LANGuage:CSV:ORlentation.....	541
:SENSe[:POWER]:SWEep:HCOPy:DEVIce:LANGuage:CSV[:COLUMn]:SEPArator.....	541
:SENSe[:POWER]:SWEep:HCOPy:DEVIce:SIZE.....	541
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME].....	542
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory.....	542
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory:CLear.....	542
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO:FILE?.....	543
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO:STATe.....	543
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY?.....	544
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY:STATe.....	544
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH?.....	544
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe.....	544
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:NUMBER?.....	545
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFIX.....	545
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFIX:STATe.....	545
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR?.....	546
:SENSe[:POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe.....	546
:SENSe[:POWER]:SWEep:HCOPy[:EXECute].....	546
:SENSe[:POWER]:SWEep:INITiate.....	546
:SENSe[:POWER]:SWEep:MODE.....	547
:SENSe[:POWER]:SWEep:POWer:REFerence:DATA:COPI.....	547
:SENSe[:POWER]:SWEep:POWer:REFerence:DATA:POINts?.....	547
:SENSe[:POWER]:SWEep:POWer:REFerence:DATA:XVALues.....	547
:SENSe[:POWER]:SWEep:POWer:REFerence:DATA:YVALues.....	548
:SENSe[:POWER]:SWEep:POWer:RMODE.....	548
:SENSe[:POWER]:SWEep:POWer:SPACing[:MODE].....	548
:SENSe[:POWER]:SWEep:POWer:STARt.....	548
:SENSe[:POWER]:SWEep:POWer:STEPs.....	549
:SENSe[:POWER]:SWEep:POWer:STOP.....	549
:SENSe[:POWER]:SWEep:POWer:TIMing[:MODE].....	549
:SENSe[:POWER]:SWEep:POWer:YSCale:AUTO.....	550
:SENSe[:POWER]:SWEep:POWer:YSCale:AUTO:RESet.....	550
:SENSe[:POWER]:SWEep:POWer:YSCale:MAXimum.....	551
:SENSe[:POWER]:SWEep:POWer:YSCale:MINimum.....	551
:SENSe[:POWER]:SWEep:RMODE.....	551
:SENSe[:POWER]:SWEep:TIME:AVERage[:COUNT].....	551
:SENSe[:POWER]:SWEep:TIME:REFerence:DATA:COPI.....	552
:SENSe[:POWER]:SWEep:TIME:REFerence:DATA:POINts?.....	552
:SENSe[:POWER]:SWEep:TIME:REFerence:DATA:XVALues.....	552
:SENSe[:POWER]:SWEep:TIME:REFerence:DATA:YVALues.....	553
:SENSe[:POWER]:SWEep:TIME:RMODE.....	553

:SENSe[:POWer]:SWEep:TIME:SPACing[:MODE]	553
:SENSe[:POWer]:SWEep:TIME:START	553
:SENSe[:POWer]:SWEep:TIME:STEPS	554
:SENSe[:POWer]:SWEep:TIME:STOP	554
:SENSe[:POWer]:SWEep:TIME:TEVents	554
:SENSe[:POWer]:SWEep:TIME:YScale:AUTO	555
:SENSe[:POWer]:SWEep:TIME:YScale:AUTO:RESet	555
:SENSe[:POWer]:SWEep:TIME:YScale:MAXimum	556
:SENSe[:POWer]:SWEep:TIME:YScale:MINimum	556

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet <Offset>

Defines the level offset at the sensor input in dB. Activate the offset with the command :SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet:STATe on page 526.

Parameters:

<Offset> float
 Range: -100 to 100
 Increment: 0.01
 *RST: 0

Example:

SENS2:SWE:FREQ:OFFS -3dB
 Defines a level offset of -3 dB.
 SENS2:SWE:FREQ:OFFS:STAT ON
 Activates the specified level offset.

Options: Option R&S SMAB-K28

Manual operation: See "Level Offset - Power Analysis" on page 258

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet:STATe <State>

Activates a level offset at the sensor input. Define the appropriate value with the command :SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet on page 526.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

SENS2:SWE:FREQ:OFFS:STAT ON
 Activates the specified level offset.

Options: Option R&S SMAB-K28

Manual operation: See "Level Offset State- Power Analysis" on page 258

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge:START <Start>

Sets the start frequency for the frequency power analysis with separate frequencies.

Parameters:

<Start> integer
 Range: 0 to 1E12
 *RST: 1E6

Example:

SENS2:SWE:FREQ:SENS:SRAN:STAT ON

Activates use of a separate frequency range for frequency versus power measurement for sensor 2.

SENS2:SWE:FREQ:SENS:STAR 2.0GHZ

Sets a sweep start at 2 GHz irrespective of the current signal generator frequency settings.

Manual operation: See ["Min Frequency - Power Analysis"](#) on page 259

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge:STOP <Stop>

Sets the stop frequency for the frequency power analysis with separate frequencies.

Parameters:

<Stop> integer
 Range: 0 to 1E12
 *RST: 10E6

Example:

SENS:SWE:FREQ:SENS2:SRAN:STAT ON

Activates use of a separate frequency range for frequency versus power measurement.

SENS:SWE:FREQ:SENS2:STAR 2.0GHZ

Sets a sweep start at 2 GHz irrespective of the current signal generator frequency settings.

SENS:SWE:FREQ:SENS2:STOP 2.9GHZ

Sets a sweep stop at 2.9 GHz irrespective of the current signal generator frequency settings.

Manual operation: See ["Max Frequency - Power Analysis"](#) on page 259

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge:STATe <State>

Activates the use of a frequency range for the power measurement that is different to the set signal generator frequency range. The separate frequency range is entered with commands [:SENSe<ch>\[:POWer\]:SWEep:FREQuency\[:SENSor\]:SRANge:START](#) on page 526 and [:SENSe<ch>\[:POWer\]:SWEep:FREQuency\[:SENSor\]:SRANge:STOP](#) on page 527.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

```
SENS2:SWE:FREQ:SENS:SRAN ON
```

Activates use of a separate frequency range for frequency versus power measurement for sensor 2.

```
SENS2:SWE:FREQ:SENS:STAR 2.0GHZ
```

Sets a sweep start at 2 GHz irrespective of the current signal generator frequency settings.

```
SENS2:SWE:FREQ:SENS:STOP 2.9GHZ
```

Sets a sweep stop at 2.9 GHz irrespective of the current signal generator frequency settings.

Manual operation: See ["Use Separate Frequency- Power Analysis"](#) on page 258

:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet <Offset>

Defines the level offset at the sensor input in dB. Activate the offset with the command [:SENSe<ch>\[:POWer\]:SWEep:POWer\[:SENSor\]:OFFSet:STATe](#) on page 528.

Parameters:

<Offset> float
 Range: -100 to 100
 Increment: 0.01
 *RST: 0

Example:

```
SENS2:SWE:POW:OFFS -5dB
```

Defines a level offset of -5 dB.

```
SENS2:SWE:POW:OFFS:STAT ON
```

Activates that the specified level offset is considered.

Options: Option R&S SMAB-K28

Manual operation: See ["Level Offset - Power Analysis"](#) on page 258

:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet:STATe <State>

Activates a level offset at the sensor input. Define the appropriate value with the command [:SENSe<ch>\[:POWer\]:SWEep:POWer\[:SENSor\]:OFFSet](#) on page 528.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

```
SENS2:SWE:POW:OFFS:STAT ON
```

Activates the specified level offset.

Options: Option R&S SMAB-K28

:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRequency <SFRequency>

Defines the separate frequency used for power vs. power measurement.

Parameters:

<SFRrequency> float
 Range: 0 to 1E12
 Increment: 1
 *RST: 1E6

Example:

SENS1:SWE:POW:SENS:SFR 2GHz
 The measurement is performed at 2 GHz

Manual operation: See ["Use Separate Frequency- Power Analysis"](#) on page 258

:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRrequency:STATe <State>

Activates the use of a different frequency for the power measurement.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

SENS1:SWE:POW:SENS:SFR:STAT ON
 Activates the use of a separate frequency than the generator frequency for power analysis

Manual operation: See ["Use Separate Frequency- Power Analysis"](#) on page 258

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet <Offset>

Defines the level offset at the sensor input in dB. Activate the offset with the command `:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet:STATe` on page 529.

Parameters:

<Offset> float
 Range: -100 to 100
 Increment: 0.01
 *RST: 0

Example:

SENS2:SWE:TIME:OFFS -7dB
 Defines a level offset of -7 dB.
 SENS2:SWE:TIME:OFFS:STAT ON
 The specified level offset is considered.

Options: Option R&S SMAB-K28

Manual operation: See ["Level Offset - Power Analysis"](#) on page 258

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet:STATe <State>

Activates a level offset at the sensor input. Define the appropriate value with the command `:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet` on page 529.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

SENS2:SWE:POW:TIME:STAT ON
 Activates the specified level offset.

Options:

Option R&S SMAB-K28

Manual operation: See ["Level Offset State- Power Analysis"](#) on page 258

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:STATe <State>

Enables pulse data analysis. The measurement is started with command INITiate.

Note: The command is only available in time measurement mode and with R&S NRP-Z81 power sensors.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

SENS1:SWE:TIM:PULS:STAT ON
 Enables pulse data analysis.

Options:

Option R&S SMAB-K28

Manual operation: See ["Pulse Analysis"](#) on page 263

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:BASE <Base>

Selects how the threshold parameters for pulse analysis are calculated.

Note: The command is only available in time measurement mode and with R&S NRPZ81 power sensors.

Parameters:

<Base> VOLTage | POWer
 *RST: VOLTage

Example:

SENS1:SWE:TIME:PULS:THR:BASE POW
 Activates threshold calculation related to power.

Options:

Option R&S SMAB-K28

Manual operation: See ["Base"](#) on page 263

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWER: HREFerence <HReference>

Sets the upper reference level in terms of percentage of the overall pulse level (power or voltage). The distal power defines the end of the rising edge and the start of the falling edge of the pulse.

Note: The command is only available in time measurement mode and with R&S NRPZ81 power sensors.

Parameters:

<HReference> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 90

Options: Option R&S SMAB-K28

Manual operation: See "[Distal](#)" on page 263

**:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:
 LREference <LReference>**

Sets the lower reference level in terms of percentage of the overall pulse level. The proximal power defines the start of the rising edge and the end of the falling edge of the pulse.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Parameters:

<LReference> float
 Range: 0.0 to 100.0
 Increment: 0.01
 *RST: 10.0

Example: SENS:SWE:TIM:PULS:THR:LREF 10
 Sets the lower reference level to 10%.

Options: Option R&S SMAB-K28

Manual operation: See "[Proximal](#)" on page 264

**:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:
 REFERENCE <Reference>**

Sets the medial reference level in terms of percentage of the overall pulse level (power or voltage related). This level is used to define pulse width and pulse period.

Note: The command is only available in time measurement mode and with R&S NRPZ81 power sensors.

Parameters:

<Reference> float
 Range: 0.0 to 100.0
 Increment: 0.01
 *RST: 50.0

Example: SENS1:SWE:TIM:PULS:THR:REF 40
 Sets the medial reference level to 40% of the overall pulse level.

Options: Option R&S SMAB-K28

Manual operation: See ["Mesial"](#) on page 264

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRequency <SFrequency>

Defines the separate frequency used for power vs. time measurement.

Parameters:

<SFrequency> float
 Range: 0 to 1E12
 Increment: 1
 *RST: 1E6

Example: SENS1:SWE:TIME:SENS:SFR 2GHz
 The measurement is performed at 2 GHz

Manual operation: See ["Use Separate Frequency- Power Analysis"](#) on page 258

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRequency:STATe <State>

Activates the use of a different frequency for the power measurement.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: SENS1:SWE:TIME:SENS:SFR:STAT ON
 Activates the use of a separate frequency than the generator frequency for power analysis

Manual operation: See ["Use Separate Frequency- Power Analysis"](#) on page 258

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:AUTO <Auto>

Sets the trigger level, the hysteresis and the dropout time to default values.

Parameters:

<Auto> ONCE
 *RST: ---

Example: SENS1:SWE:TIME:SENS:TRIG:AUTO ONCE
 The trigger level is automatically determined

Manual operation: See ["Auto Set - Power Analysis"](#) on page 271

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:DTIME <DTime>

Determines the minimum time for which the signal must be below (above) the power level defined by level and hysteresis before triggering can occur again.

Parameters:

<DTime> float
 Range: 0 to 10
 *RST: 200E-9

Example:

SENS1:SWE:TIME:SENS:TRIG:DTIM 10 us
 The drop out time is 10 us

Manual operation: See ["Drop out Time - Power Analysis"](#) on page 270

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:HYSTeresis <Hysteresis>

Sets the hysteresis of the internal trigger threshold. Hysteresis is the magnitude (in dB) the trigger signal level must drop below the trigger threshold (positive trigger slope) before triggering can occur again.

Parameters:

<Hysteresis> float
 Range: 0 to 10
 Increment: 0.001
 *RST: 0.5

Example:

SENS1:SWE:TIME:SENS:TRIG:HYST 0.5 dB
 The hysteresis is 0.5 dB

Manual operation: See ["Hysteresis - Power Analysis"](#) on page 270

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:LEVel <Level>

Sets the trigger threshold.

Parameters:

<Level> float
 Range: -200 to 100
 Increment: 0.001
 *RST: 1

Example:

SENS1:SWE:TIME:SENS:TRIG:LEV -20 dBm
 Sets the trigger level to -20 dBm.

Manual operation: See ["Level - Power Analysis"](#) on page 270

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:SLOPe <TriggerSlope>

Sets the polarity of the active slope for the trigger signals.

Parameters:

<TriggerSlope> POSitive | NEGative
 *RST: POSitive

Example:

SENS1:SWE:TIME:TRIG:SLOP POS
 The positive edge of a trigger signal is active.

Options: Option R&S SMAB-K28

Manual operation: See ["Slope - Power Analysis"](#) on page 270

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:SOURce <Source>

Selects if the measurement is free running (FREE) or starts only after a trigger event. The trigger can be applied internally or externally.

Parameters:

<Source> FREE | AUTO | INTernal | EXTernal
*RST: AUTO

Example: SENS1:SWE:TIME:SENS:TRIG:SOUR FREE
The power versus time measurement is performed free running

Manual operation: See ["Mode - Power Analysis"](#) on page 269

:SENSe<ch>[:POWer]:ZERO

The command activates the autozero function. Zeroing is required in regular interval (at least once a day) and if the temperature has varied more than about 5 °C, if the sensor has been replaced or if measurements of signals with very low power are to be performed. The RF power source must be switched off or disconnected from the sensor before starting the autozero function.

Example: SENS:ZERO
activates autozero function.

Usage: Event

:SENSe[:POWer]:SWEep:ABORt

Aborts the power analysis with NRP power sensors.

Example: SENS:SWE:ABOR;*OPC?
Aborts the current power measurement.

Usage: Setting only

:SENSe[:POWer]:SWEep:FREQuency:REFeRence:DATA:COpy

Generates a reference curve for "Frequency" measurement.

Example: SENS:POW:SWE:FREQ:REF:DATA:COpy
Generates a reference curve in frequency mode.

Usage: Event

Manual operation: See ["Save To Ref"](#) on page 251

:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:POINts?

Queries the number of points from the reference curve in "Frequency" measurement.

Return values:

<Points> integer
Range: 10 to 1000

Example: SENS:POW:SWE:FREQ:REF:DATA:POIN?
Queries the number of points from the reference curve in frequency mode.

Usage: Query only

:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:XVALues <XValues>

Sets the x values of the two reference points, i.e. "Frequency X (Point A)" and "Frequency X (Point B)" in "Frequency" measurement.

Parameters:

<XValues> string

Example: SENSE:POW:SWE:FREQ:REF:DATA:XVAL 100MHZ,22GHZ
Sets the x value of reference "Point A" to 10 MHz, and the value of "Point B" to 10 GHz.

Manual operation: See "[Freq \(X\)](#)" on page 250

:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:YVALues <YValues>

Sets or queries the y values of the two reference points, i.e. "Pow Y (Point A)" and "Power Y (Point B)" in "Frequency" measurement.

Parameters:

<YValues> string

Example: SENSE:POW:SWE:FREQ:REF:DATA:YVAL -10,25
Sets the y value of reference "Point A" to -10 dBm, and the value of "Point B" to -25 dBm.

Manual operation: See "[POW \(Y\)](#)" on page 250

:SENSe[:POWer]:SWEep:FREQuency:RMODe <RMode>

Selects single or continuous mode for measurement mode frequency in power analysis.

Parameters:

<RMode> SINGle | CONTInuous
*RST: CONTInuous

Example: SENS:SWE:FREQ:RMOD SING
Selects single measurement

Manual operation: See ["Execution - Power Analysis"](#) on page 255

:SENSe[:POWer]:SWEep:FREQuency:SPACing[:MODE] <Mode>

Selects the spacing for the frequency power analysis.

Parameters:

<Mode> LINear | LOGarithmic
*RST: LINear

Example: SENS:SWE:FREQ:SPAC:MODE LIN
Sets linear spacing of the sweep

Manual operation: See ["Spacing - Power Analysis"](#) on page 255

:SENSe[:POWer]:SWEep:FREQuency:STARt <Start>

Sets the start frequency for the frequency mode.

Parameters:

<Start> float
Range: 0 to 1E12
*RST: 1E6

Example: SENS:SWE:FREQ:STAR 2.0GHZ
Sets a sweep start at 2 GHz.

Manual operation: See ["Min - Power Analysis"](#) on page 253

:SENSe[:POWer]:SWEep:FREQuency:STEPs <Steps>

Sets the number of measurement steps for the frequency mode.

Parameters:

<Steps> integer
Range: 10 to 1000
*RST: 200

Example: SENS:SWE:FREQ:STEP 500
Sets 500 steps

Manual operation: See ["Steps - Power Analysis"](#) on page 254

:SENSe[:POWer]:SWEep:FREQuency:STOP <Stop>

Sets the stop frequency for the frequency mode.

Parameters:

<Stop> float
Range: 0 to 1E12
*RST: 22GHZ

Example: `SENS:SWE:FREQ:STOP 20.0GHZ`
Sets the sweep stop to 20 GHz

Manual operation: See ["Max - Power Analysis"](#) on page 254

:SENSe[:POWer]:SWEep:FREQuency:TIMing[:MODE] <Mode>

Selects the mode in terms of speed and precision of the response of a measurement.

Parameters:

<Mode> FAST | NORMAl | HPRecision | FAST | NORMAl

FAST

Selection FAST leads to a fast measurement with a short integration time for each measurement step.

NORMAl

NORMAl leads to a longer but more precise measurement due to a higher integration time for each step.

*RST: FAST

Example: `SENS:SWE:FREQ:TIM:MODE FAST`

The fast measurement mode is selected.

Manual operation: See ["Timing - Power Analysis"](#) on page 254

:SENSe[:POWer]:SWEep:FREQuency:YSCale:AUTO <Auto>

Activates autoscaling of the Y axis of the diagram.

Parameters:

<Auto> OFF | CEXPanding | FEXPanding | CFLoating | FFLoating

OFF

Auto scaling is deactivated. If switching from activated to deactivated Auto scaling, the scaling is maintained.

CEXPanding | FEXPanding

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is expanded if the minimum or maximum values of the trace move outside the current scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

CFLoating | FFLoating

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is either expanded if the minimum or maximum values of the trace move outside the current scale or scaled down if the trace fits into a reduced scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

*RST: CEXPanding

Example: `SENS:SWE:FREQ:YSC:AUTO OFF`
Deactivates auto scale

Manual operation: See ["Auto Scale - Power Analysis"](#) on page 260

:SENSe[:POWer]:SWEep:FREQuency:YSCale:AUTO:RESet

Resets the Y scale to suitable values after the use of auto scaling in the expanding mode. For this mode, the scale might get expanded because of temporarily high-power values. The reset function resets the diagram in such a way that it matches smaller power values again.

Example: `SENS:SWE:FREQ:YSC:AUTO:RES`
Resets auto scale

Usage: Event

Manual operation: See ["Reset Auto Scale - Power Analysis"](#) on page 261

:SENSe[:POWer]:SWEep:FREQuency:YSCale:MAXimum <Maximum>

Sets the maximum value for the y axis of the measurement diagram.

Parameters:

<Maximum>	float
Range:	-200 to 100
Increment:	0.01
*RST:	40

Example: `SENS:SWE:FREQ:YSC:MAX 10DBM`
Sets 10 dBm as the upper limit of the measurement diagram.

Manual operation: See ["Min - Max Level - Power Analysis"](#) on page 260

:SENSe[:POWer]:SWEep:FREQuency:YSCale:MINimum <Minimum>

Sets the minimum value for the y axis of the measurement diagram.

Parameters:

<Minimum>	float
Range:	-200 to 100
Increment:	0.01
*RST:	-40

Example: `SENS:SWE:FREQ:YSC:MIN -10DB`
Sets -10 dBm as the lower limit of the measurement diagram.

Manual operation: See ["Min - Max Level - Power Analysis"](#) on page 260

:SENSe[:POWer]:SWEep:HCOPY:DATA?

Queries the measurement data directly. The data is transferred to the remote client as data stream.

Readable ASCII data is available for hardcopy language CSV. The representation of the values depends on the selected orientation for the CSV format.

Return values:

<Data> block data

Example:

```
SENS:SWE:HCOP:DEV:LANG CSV
selects output format *.csv.
SENS:SWE:HCOP:DEV:LANG:CSV:ORI HOR
selects horizontal orientation
SENS:SWE:HCOP:DEV:LANG:CSV:SEP SEM
selects ";" as the separator between the values
SENS:SWE:HCOP:DEV:LANG:CSV:DPO DOT
selects "." as decimal point
SENS:SWE:HCOP:DATA?
queries the measurement data of the current traces
Response:
#2651009500000;1019000000;1028500000;1038000000
-9.5;-9.7;-6.3;-2.5
```

The hash symbol # introduces the data block. The next number indicates how many of the following digits describe the length of the data block. In the example, the 2 following digit indicates the length to be 65 characters.

Because horizontal representation is selected, a row with all the x-values of the active trace (frequency) follows. The second row contains all the y-values of the active trace (power). The rows end with a new line (each counts as one character).

Note: if more than one trace is active, the third row contains the x values of the second active trace, and so on.

Example:

```
SENS:SWE:HCOP:DEV:LANG:CSV:ORI VERT
selects horizontal orientation
SENS:SWE:HCOP:DATA?
queries the measurement data of the current traces
Response:
#2681009500000;-9.5; 1019000000;-9.7; 1028500000;-6.3;
1038000000;-2.5;
```

for vertical representation the length of the data block is 68 the first power value, the second row contains the second frequency value of the active trace followed by the second power value, and so on. The rows end with a new line (each counts as one character).

Note: if more than one trace is active, the first row also contains the value pairs of the second active trace, and so on.

Usage:

Query only

:SENSe[:POWer]:SWEep:HCOPy:DEVIce <Device>

Defines the output device. The setting is fixed to FILE, i.e. the hardcopy is stored in a file.

Parameters:

<Device> FILE | PRINter
 *RST: FILE

Example:

SENS:SWE:HCOP:DEV FIL
 Selects output device file.

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage <Language>

Selects the bitmap graphic format for the screenshot of the power analysis trace.

In addition, ASCII file format *.csv is offered. If file format *.csv is selected, the trace data is saved as an ASCII file with comma separated values. It is also possible to directly retrieve the data using command :SENSe[:POWer]:SWEep:HCOPy:DATA? on page 538

Parameters:

<Language> BMP | JPG | XPM | PNG | CSV
 *RST: BMP

Example:

SENS:SWE:HCOP:DEV:LANG BMP
 Selects output format *.bmp.

Manual operation: See ["Format - Power Analysis"](#) on page 278

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:DPOint <DPoint>

Defines which character is used as the decimal point of the values, either dot or comma.

Parameters:

<DPoint> DOT | COMMa
 *RST: DOT

Example:

SENS:SWE:HCOP:DEV:LANG CSV
 Selects output format *.csv.
 SENS:SWE:HCOP:DEV:LANG:CSV:DPO DOT
 Selects character dot for being used as decimal point.

Manual operation: See ["Decimal Point"](#) on page 282

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:HEADer <Header>

Defines whether each row (or column depending on the orientation) should be preceded by a header containing information about the trace (see also :SENSe[:POWer]:SWEep:HCOPy:DATA? on page 538).

Parameters:

<Header> OFF | STANdard
 *RST: OFF

Example: `SENS:SWE:HCOP:DEV:LANG CSV`
 Selects output format *.csv.
 `SENS:SWE:HCOP:DEV:LANG:CSV:HEAD STAN`
 Selects the standard header for the *.csv file.

Manual operation: See ["Row Header"](#) on page 282

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:ORientation
 <Orientation>

Defines the orientation of the X/Y value pairs.

Parameters:

<Orientation> HORizontal | VERTical
 *RST: VERTical

Example: `SENS:SWE:HCOP:DEV:LANG CSV`
 Selects output format *.csv.
 `SENS:SWE:HCOP:DEV:LANG:CSV:ORI VERT`
 Selects vertical orientation, the value pairs are written in a column like structure (separated by the selected separator, e.g. tab)

Manual operation: See ["Orientation"](#) on page 281

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV[:COLumn]:SEParator
 <Separator>

Defines which character is to separate the values, either tabulator, semicolon, comma or blank.

Parameters:

<Separator> TABulator | SEMicolon | COMMa | BLANK
 *RST: COMMa

Example: `SENS:SWE:HCOP:DEV:LANG CSV`
 Selects output format *.csv.
 `SENS:SWE:HCOP:DEV:LANG:CSV:SEP TAB`
 A tab separates the values.

Manual operation: See ["Separator"](#) on page 282

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:SIZE <Size>

Sets the size of the hardcopy in number of pixels. The first value of the size setting defines the width, the second value the height of the image.

Parameters:

<Size> 320,240 | 640,480 | 800,600 | 1024,768
 *RST: 320,240

Example: SENS:SWE:HCOP:DEV:LANG BMP
 Selects output format *.bmp.
 SENS:SWE:HCOP:DEV:SIZE 320,240
 The size of the bitmap is 320 pixels by 240 pixels.

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME] <Name>

Creates or selects a file for storing the hardcopy after the :SENSe[:POWer]:SWEep:HCOPy[:EXECute] on page 546 command is sent. The directory is either defined with the command MMEMoRY:CDIR or the path is specified together with the file name. Access to the file via remote control is possible using the commands of the MMEM-Subsystem. In contrast, command :SENSe[:POWer]:SWEep:HCOPy:DATA? on page 538 transfers the hardcopy contents directly to the remote client where they can be further processed.

Parameters:

<Name> string

Example: SENS:SWE:HCOP:DEV:LANG BMP
 Selects output format *,bmp.
 SENS:SWE:HCOP:FILE:AUTO:STAT OFF
 Switches off automatic naming.
 SENS:SWE:HCOP:FILE 'var/trace/nrp_tracel'
 creates the file nrp_tracel.bmp in the trace directory.
 SENS:SWE:HCOP:EXEC
 Triggers the generation of a hardcopy of the current trace. The
 hardcopy is stored in the file nrp_tracel.bmp.

Manual operation: See "File name - Power Analysis" on page 277

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory <Directory>

Defines the directory into which the hardcopy files are stored if auto naming is activated (SENS:SWE:HCOP:FILE:AUTO:STAT ON).

Parameters:

<Directory> string

Example: SENS:SWE:HCOP:FILE:AUTO:DIR 'var/nrp'
 Hardcopy file are stored in directory var/nrp if automatic nam-
 ing is activated.

Manual operation: See "Path" on page 279

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory:CLEar

Deletes all files with extensions bmp , img, png, xpm and csv in the directory set for automatic naming.

Example: `SENS:SWE:HCOP:FILE:AUTO:DIR 'var/nrp'`
 Hardcopy file are stored in directory `var/nrp` if automatic naming is activated.
`SENS:SWE:HCOP:FILEAUTO:DIR:CLE`
 Deletes all hardcopy file that are stored in the directory `var/nrp`.

Usage: Event

Manual operation: See ["Clear Parth"](#) on page 279

:SENSe[POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO:FILE?

Queries the file name generated with the automatic naming settings.

Note: As default the automatically generated file name is composed of: `>PAth>/<Prefix><YYYY><MM><DD><Number>.<Format>`. Each component can be deactivated/ activated separately to individually design the file name.

Return values:

`<File>` string

Example: `SENS:SWE:HCOP:DEV:LANG BMP`
 Selects output format `*.bmp`.
`SENS:SWE:HCOP:FILE:AUTO:DIR 'var/nrp'`
 Hardcopy files are stored in directory `var/nrp` if automatic naming is activated.
`SENS:SWE:HCOP:FILE:AUTO:PREF 'sens1'`
 The file name starts with the prefix `sens1`. The usage of automatic naming with prefix and date in the file name is preset (`...:STAT ON`).
`SENS:SWE:HCOP`
 Triggers the generation of a hardcopy of the current trace.
`SENS:SWE:HCOP:FILE:AUTO:FILE?`
 Queries the file name

Usage: Query only

Manual operation: See ["File name - Power Analysis"](#) on page 277
 See ["Resulting File Name"](#) on page 280

:SENSe[POWER]:SWEep:HCOPy:FILE[:NAME]:AUTO:STATe <State>

Activates/deactivates automatic naming of the hardcopy files.

Parameters:

`<State>` 0 | 1 | OFF | ON
 *RST: 1

Example: `SENS:SWE:HCOP:FILE:AUTO:STAT OFF`
 Deactivates automatic naming of the hardcopy files. The file name and directory is now defined with command.
`SENS:SWE:HCOP:FILE:NAME <psth>`

Manual operation: See ["File name - Power Analysis"](#) on page 277
See ["Automatic Naming"](#) on page 278

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY?

Queries the day of the date part in the automatic file name.

Return values:

<Day> integer
Range: 1 to 31
*RST: 1

Example: SENS:SWE:HCOP:FILE:AUTO:DAY?
Queries the day of the date part in the automatic file name.

Usage: Query only

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 280

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY:STATe <State>

Activates the usage of the day in the automatic file name.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 1

Example: SENS:SWE:HCOP:FILE:AUTO:DAY:STAT OFF
Deactivates the usage of the day in the automatic file name.

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 280

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH?

Queries the day of the date part in the automatic file name.

Return values:

<Month> integer
Range: 1 to 12
*RST: 1

Example: SENS:SWE:HCOP:FILE:AUTO:MONT?
Queries the month of the date part in the automatic file name.

Usage: Query only

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 280

**:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe
<State>**

Activates the usage of the month in the automatic file name.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 1

Example:

SENS:SWE:HCOP:FILE:AUTO:MONT:STAT OFF
 Deactivates the usage of the month in the automatic file name.

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 280

:SENSe[POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:NUMBer?

Queries the generated number in the automatic file name.

Return values:

<Number> integer
 Range: 0 to 999999
 *RST: 0

Example:

SENS:SWE:HCOP:FILE:AUTO:NUMB?
 Queries the number in the automatic file name.

Usage: Query only

Manual operation: See ["Current Auto Number"](#) on page 280

:SENSe[POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix <Prefix>

Sets the prefix part in the automatic file name.

Parameters:

<Prefix> string

Example:

SENS:SWE:HCOP:FILE:AUTO:PREF 'sensor'
 The prefix sensor is used in the automatically generated file name of the hardcopy file.

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 280

**:SENSe[POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe
<State>**

Activates the usage of the prefix in the automatic file name.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 1

Example:

SENS:SWE:HCOP:FILE:AUTO:PREF:STAT OFF
 Deactivates the usage of the prefix in the automatic file name.

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 280

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR?

Queries the year of the date part in the automatic file name.

Return values:

<Year>	integer
Range:	1784 to 8000
*RST:	0

Example:

SENS:SWE:HCOP:FILE:AUTO:YEAR?

Queries the year of the date part in the automatic file name.

Usage:

Query only

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 280

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe <State>

Activates the usage of the year in the automatic file name.

Parameters:

<State>	0 1 OFF ON
*RST:	1

Example:

SENS:SWE:HCOP:FILE:AUTO:YEAR:STAT OFF

Deactivates the usage of the year in the automatic file name.

Manual operation: See ["Prefix, Year, Month, Day, Instrument Name"](#) on page 280

:SENSe[:POWer]:SWEep:HCOPy[:EXECute]

Triggers the generation of a hardcopy of the current measurement diagram. The data is written into the file selected/created with the [:SENSe\[:POWer\]:SWEep:HCOPy:FILE\[:NAME\]](#) on page 542 command.

Example:

SENS:SWE:HCOP:DEV:LANG BMP

Selects output format *.bmp.

SENS:SWE:HCOP:FILE:AUTO:STAT OFF

Switches off automatic file naming.

SENS:SWE:HCOP:FILE 'var/nrp_tracel'

Creates the file nrp_tracel.bmp in the set path.

SENS:SWE:HCOP

Triggers the generation of a hardcopy of the current measurement diagram. The hardcopy is stored in the file nrp_tracel.bmp.

Usage:

Event

Manual operation: See ["File name - Power Analysis"](#) on page 277

:SENSe[:POWer]:SWEep:INITiate

Starts the power analysis with NRP power sensor.

Example: `SENS:SWE:INIT`
Start the power measurement.

Usage: Setting only

:SENSe[:POWer]:SWEep:MODE <Mode>

Selects power versus frequency measurement (frequency response), power vs power measurement (power sweep, AM/AM) or power vs. time measurement.

Parameters:

<Mode> FREQuency | POWer | TIME
*RST: FREQuency

Example: `SENS:SWE:MODE FREQ`
Selects frequency mode.

Manual operation: See "[Mode - Power Analysis](#)" on page 253

:SENSe[:POWer]:SWEep:POWer:REFeRence:DATA:COpy

Generates a reference curve for "Power" measurement.

Example: `SENS:POW:SWE:POW:REF:DATA:COpy`
Generates a reference curve in power mode.

Usage: Event

Manual operation: See "[Save To Ref](#)" on page 251

:SENSe[:POWer]:SWEep:POWer:REFeRence:DATA:POINts?

Queries the number of points from the reference curve in "Power" measurement.

Return values:

<Points> integer
Range: 10 to 1000

Example: `SENS:POW:SWE:POW:REF:DATA:POIN?`
Queries the number of points from the reference curve in power mode.

Usage: Query only

:SENSe[:POWer]:SWEep:POWer:REFeRence:DATA:XVALues <XValues>

Sets or queries the x values of the two reference points, i.e. "Power X (Point A)" and "Power X (Point B)" in "Power" measurement.

Parameters:

<XValues> string

Example: `SENSe:POW:SWE:POW:REF:DATA:XVAL -15DBM,20DBM`
Sets the x value of reference "Point A" to -15 dBm, and the value of "Point B" to 20 dBm.

Manual operation: See "[Pow \(X\)](#)" on page 250

:SENSe[:POWer]:SWEep:POWer:REFeRence:DATA:YVALues <YValues>

Sets or queries the y values of the two reference points, i.e. "Power Y (Point A)" and "Power Y (Point B)" in "Power" measurement.

Parameters:

<YValues> string

Example: `SENSe:POW:SWE:TIME:REF:DATA:YVAL -30,10`
Sets the y value of reference "Point A" to -30 dBm, and the value of "Point B" to 10 dBm.

Manual operation: See "[Pow \(Y\)](#)" on page 251

:SENSe[:POWer]:SWEep:POWer:RMODe <RMode>

Selects single or continuous mode for measurement mode power in power analysis.

Parameters:

<RMode> SINGLE | CONTInuous

*RST: CONTInuous

Example: `SENS:SWE:POW:RMOD SING`
Selects single measurement.

Manual operation: See "[Execution - Power Analysis](#)" on page 255

:SENSe[:POWer]:SWEep:POWer:SPACing[:MODE] <Mode>

Selects the spacing for the frequency power analysis.

Parameters:

<Mode> LINear

*RST: LINear

Example: `SENS:SWE:FREQ:SPAC:MODE LIN`
Sets linear spacing of the sweep.

Manual operation: See "[Spacing - Power Analysis](#)" on page 255

:SENSe[:POWer]:SWEep:POWer:STARt <Start>

Sets the start level for the power versus power measurement.

Parameters:

<Start> float
 Range: -145 to 20
 Increment: 0.01
 *RST: 1MHZ

Example:

SENS:SWE:POW:STAR -20DBM
 Sets the start level to -20 dBm

Manual operation:

See ["Min - Power Analysis"](#) on page 253
 See ["Max - Power Analysis"](#) on page 254

:SENSe[:POWer]:SWEep:POWer:STEPs <Steps>

Sets the number of measurement steps for the power versus power measurement.

Parameters:

<Steps> integer
 Range: 10 to 1000
 *RST: 500

Example:

SENS:SWE:POW:STEP 500
 Sets the 500 measurement steps.

Manual operation:

See ["Steps - Power Analysis"](#) on page 254

:SENSe[:POWer]:SWEep:POWer:STOP <Stop>

Sets the stop level for the power versus power measurement.

Parameters:

<Stop> float
 Range: -145 to 20
 Increment: 0.01
 *RST: 40

Example:

SENS:SWE:POW:STOP 20.0DBM
 Sets the stop level to 20 dBm.

:SENSe[:POWer]:SWEep:POWer:TIMing[:MODE] <Mode>

Selects the timing mode of the measurement.

Parameters:

<Mode> FAST | NORMal | HPRecision | FAST | NORMal

FAST

Selection FAST leads to a fast measurement with a short integration times for each measurement step.

NORMal

NORMal leads to a longer but more precise measurement due to a higher integration time for each step.

*RST: NORMal

Example: SENS:SWE:POW:TIM:MODE FAST
Selects fast mode.

Manual operation: See ["Timing - Power Analysis"](#) on page 254

:SENSe[:POWer]:SWEep:POWer:YSCale:AUTO <Auto>

Activates autoscaling of the Y axis of the diagram.

Parameters:

<Auto> OFF | CEXPanding | FEXPanding | CFLoating | FFLoating

OFF

Auto scaling is deactivated. When switching from activated to deactivated Auto scaling, the scaling is maintained. When switching from deactivated to activated Auto scaling, the scaling is reset to min = max = 0.

CEXPanding | FEXPanding

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is expanded if the minimum or maximum values of the trace move outside the current scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

CFLoating | FFLoating

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is either expanded if the minimum or maximum values of the trace move outside the current scale or scaled down if the trace fits into a reduced scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

*RST: CEXPanding

Example: SENS:SWE:POW:YSC:AUTO OFF
Deactivates auto scale.

Manual operation: See ["Auto Scale - Power Analysis"](#) on page 260

:SENSe[:POWer]:SWEep:POWer:YSCale:AUTO:RESet

Resets the Y scale to suitable values after the use of auto scaling in the expanding mode. For this mode, the scale might get expanded because of temporarily high power values. The reset function allows resetting the diagram to match smaller power values again.

Example: SENS:SWE:POW:YSC:AUTO:RES
Resets auto scale.

Usage: Event

Manual operation: See ["Reset Auto Scale - Power Analysis"](#) on page 261

:SENSe[:POWer]:SWEep:POWer:YSCale:MAXimum <Maximum>

Sets the maximum value for the y axis of the measurement diagram.

Parameters:

<Maximum>	float
Range:	-200 to 100
Increment:	0.01
*RST:	30

Example: `SENS:SWE:POW:YSC:MAX 10DBM`
Sets 10 dBm as the upper limit of the measurement diagram.

Manual operation: See ["Min - Max Level - Power Analysis"](#) on page 260

:SENSe[:POWer]:SWEep:POWer:YSCale:MINimum <Minimum>

Sets the minimum value for the y axis of the measurement diagram.

Parameters:

<Minimum>	float
Range:	-200 to 100
Increment:	0.01
*RST:	-40

Example: `SENS:SWE:POW:YSC:MIN -10DBM`
Sets -10 dBm as the lower limit of the measurement diagram.

Manual operation: See ["Min - Max Level - Power Analysis"](#) on page 260

:SENSe[:POWer]:SWEep:RMODe <RMode>

Selects single or continuous mode for power analysis (all measurement modes).

Parameters:

<RMode>	SINGLE CONTInuous
*RST:	SINGLE

Example: `SENS:SWE:RMOD SING`
Selects single measurement.

Manual operation: See ["Execution - Power Analysis"](#) on page 255

:SENSe[:POWer]:SWEep:TIME:AVERAge[:COUNT] <Count>

Selects the averaging factor in time mode. The count number determines how many measurement cycles are used to form a measurement result. Higher averaging counts reduce noise but increase the measurement time. Averaging requires a stable trigger event so that the measurement cycles have the same timing.

Parameters:

<Count> 1 | 2 | 4 | 8 | 16 | 32 | 64 | 128 | 256 | 512 | 1024
 *RST: 1

Example:

SENS:SWE:MODE TIME
 Selects time mode.
 SENS:SWE:TIME:AVER 128
 Selects averaging factor 128.

Options:

Option R&S SMAB-K28

Manual operation: See ["Average - Power Analysis"](#) on page 255

:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:COpy

Generates a reference curve for "Time" measurement.

Example:

SENS:POW:SWE:TIME:REF:DATA:COpy
 Generates a reference curve in time mode.

Usage:

Event

Manual operation: See ["Save To Ref"](#) on page 251

:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:POINts?

Queries the number of points from the reference curve in "Time" measurement.

Return values:

<Points> integer
 Range: 10 to 1000
 *RST: 0

Example:

SENS:POW:SWE:TIME:REF:DATA:POIN?
 Queries the number of points from the reference curve in time mode.

Usage:

Query only

:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:XVALues <XValues>

Sets or queries the x values of the two reference points, i.e. "Time X (Point A)" and "Time X (Point B)" in "Time" measurement.

Parameters:

<XValues> string

Example:

SENSe:POW:SWE:TIME:REF:DATA:XVAL 5,45
 Sets the x value of reference "Point A" to 5 μ s, and the value of "Point B" to 45 μ s.

Manual operation: See ["Time \(X\)"](#) on page 251

:SENSe[:POWer]:SWEep:TIME:REFeRence:DATA:YVALues <YValues>

Sets or queries the y values of the two reference points, i.e. "Power Y (Point A)" and "Power Y (Point B)" in "Time" measurement.

Parameters:

<YValues> string

Example:

SENSe:POW:SWE:TIME:REF:DATA:YVAL -30,10
sets the y value of reference "Point A" to -30 dBm, and the value of "Point B" to 10 dBm.

Manual operation: See ["Pow \(Y\)"](#) on page 251

:SENSe[:POWer]:SWEep:TIME:RMODE <RMode>

Selects single or continuous mode for measurement mode time in power analysis.

Parameters:

<RMode> SINGLE | CONTInuous
*RST: CONTInuous

Example:

SENS:SWE:TIME:RMODE SING
Selects single measurement.

Manual operation: See ["Execution - Power Analysis"](#) on page 255

:SENSe[:POWer]:SWEep:TIME:SPACing[:MODE] <Mode>

Queries the sweep spacing for the power versus time measurement. The spacing is fixed to linear.

Parameters:

<Mode> LINear
*RST: LINear

Example:

SENS:SWE:TIME:SPAC?
Queries the sweep spacing.

Manual operation: See ["Spacing - Power Analysis"](#) on page 255

:SENSe[:POWer]:SWEep:TIME:STARt <Start>

Sets the start time for the power versus time measurement. Value 0 defines the trigger point. By choosing a negative time value, the trace can be shifted in the diagram. It is possible, that the measurement cannot be performed over the complete time range because of limitations due to sensor settings. In this case, an error message is output.

Parameters:

<Start> float
Range: -1 to 1
Increment: 1E-12
*RST: -5E-6

Example: `SENS:SWE:TIME:STAR 0s`
Sets the start time to 0 s.

Manual operation: See ["Min - Power Analysis"](#) on page 253

:SENSe[:POWer]:SWEep:TIME:STEPS <Steps>

Sets the number of measurement steps for the power versus time measurement. Value 0 defines the trigger point.

Parameters:

<Steps> integer
Range: 10 to 1000
*RST: 500

Example: `SENS:SWE:TIME:STEP 500`
Sets the 500 measurement steps.

Manual operation: See ["Steps - Power Analysis"](#) on page 254

:SENSe[:POWer]:SWEep:TIME:STOP <Stop>

Sets the stop time for the power versus time measurement.

Parameters:

<Stop> float
Range: 0 to 2
Increment: 1E-12
*RST: 1E-3

Example: `SENS:SWE:TIME:STOP 1ms`
Sets the stop time to 1 ms.

Manual operation: See ["Max - Power Analysis"](#) on page 254

:SENSe[:POWer]:SWEep:TIME:TEVents <TriggerTEvents>

Determines, whether the measurement data processing starts with a trigger event in one of the sensors (Logical OR), or whether all channels have to be triggered (logical AND). Each sensor evaluates a trigger event according to its setting independently. This function supports the internal or external trigger modes with multi-channel time measurements.

Parameters:

<TriggerTEvents> AND | OR
*RST: AND

Example: `SENS:POW:SWE:TIME:TEV AND`
The measurement data processing starts when all channels are triggered.

Options: Option R&S SMAB-K28

Manual operation: See ["All Trigger Events - Power Analysis"](#) on page 256

:SENSe[:POWer]:SWEep:TIME:YSCale:AUTO <Auto>

Activates autoscaling of the Y axis in the diagram.

Parameters:

<Auto>

OFF | CEXPanding | FEXPanding | CFLoating | FFLoating

OFF

Auto scaling is deactivated. When switching from activated to deactivated Auto scaling, the scaling is maintained. When switching from deactivated to activated Auto scaling, the scaling is reset to min = max = 0.

CEXPanding | FEXPanding

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is expanded if the minimum or maximum values of the trace move outside the current scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

CFLoating | FFLoating

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is either expanded if the minimum or maximum values of the trace move outside the current scale or scaled down if the trace fits into a reduced scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

*RST: CEXPanding

Example:

SENS:SWE:TIME:YSC:AUTO OFF

Deactivates auto scale

Manual operation: See ["Auto Scale - Power Analysis"](#) on page 260

:SENSe[:POWer]:SWEep:TIME:YSCale:AUTO:RESet

Resets the Y scale to suitable values after the use of auto scaling in the expanding mode. For this mode, the scale might get expanded because of temporarily high power values. The reset function allows resetting the diagram to match smaller power values again.

Example:

SENS:SWE:TIME:YSC:AUTO:RES

Resets auto scale.

Usage:

Event

Manual operation: See ["Reset Auto Scale - Power Analysis"](#) on page 261

:SENSe[:POWer]:SWEep:TIME:YSCale:MAXimum <Maximum>

Sets the maximum value for the y axis of the measurement diagram.

Parameters:

<Maximum> float
 Range: -200 to 100
 Increment: 0.01
 *RST: 30.0
 Default unit: dBm

Example:

SENS:SWE:TIME:YSC:MAX 10DBM

Sets 10 dBm as the upper limit of the measurement diagram.

Manual operation: See ["Min - Max Level - Power Analysis"](#) on page 260

:SENSe[:POWer]:SWEep:TIME:YSCale:MINimum <Minimum>

Sets the minimum value for the y axis of the measurement diagram.

Parameters:

<Minimum> float
 Range: -200 to 100
 Increment: 0.01
 *RST: dBm

Example:

SENS:SWE:TIME:YSC:MIN -10DBM

Sets -10 dBm as the lower limit of the measurement diagram.

Manual operation: See ["Min - Max Level - Power Analysis"](#) on page 260

14.15.6 TRACe subsystem

:TRACe<ch>:FREQ:SWEep:SRC.....	558
:TRACe<ch>:POW:SWEep:SRC.....	558
:TRACe<ch>:TIME:SWEep:SRC.....	559
:TRACe<ch>[:POWer]:SWEep:COLor.....	559
:TRACe<ch>[:POWer]:SWEep:COPY.....	560
:TRACe<ch>[:POWer]:SWEep:DATA:POINts?.....	560
:TRACe<ch>[:POWer]:SWEep:DATA:XVALues?.....	560
:TRACe<ch>[:POWer]:SWEep:DATA:YSValue?.....	561
:TRACe<ch>[:POWer]:SWEep:DATA:YVALues?.....	561
:TRACe<ch>[:POWer]:SWEep:FEED.....	561
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERage?.....	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence?.....	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence?.....	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum?.....	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum?.....	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE?.....	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP?.....	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence?.....	562

Power sensor measurement subsystems

:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYClE?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEParation?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:STATe?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYClE:DISPlay:ANNotation[: STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation:DISPlay:ANNotation[: STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod:DISPlay:ANNotation[: STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERage:DISPlay:ANNotation[: STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE:DISPlay: ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence:DISPlay: ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence:DISPlay: ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum:DISPlay:ANNotation[: STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum:DISPlay:ANNotation[: STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence:DISPlay:ANNotation[: STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP:DISPlay: ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEParation:DISPlay:ANNotation[: STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation:DISPlay: ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence: DISPlay:ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot: DISPlay:ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation:DISPlay: ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence: DISPlay:ANNotation[:STATe]	564
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot: DISPlay:ANNotation[:STATe]	564
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:ALL:DISPlay:ANNotation[:STATe]	564
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:BASE?	564
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:HREFerence	565

:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:LREference.....	565
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:REference.....	565
:TRACe<ch>[:POWer]:SWEep:STAtE.....	566
:TRACe[:POWer]:SWEep:MEASurement:FULLscreen:DISPlay:ANNotation[:STAtE].....	566
:TRACe[:POWer]:SWEep:MEASurement:GATE:DISPlay:ANNotation[:STAtE].....	567
:TRACe[:POWer]:SWEep:MEASurement:MARKer:DISPlay:ANNotation[:STAtE].....	567
:TRACe[:POWer]:SWEep:MEASurement:PULSe:DISPlay:ANNotation[:STAtE].....	567
:TRACe[:POWer]:SWEep:MEASurement:STANdard:DISPlay:ANNotation[:STAtE].....	568

:TRACe<ch>:FREQ:SWEep:SRC <FreqSource>

Determines the source of a trace for display in frequency measurement mode.

Parameters:

<FreqSource>	OFF SEN1 SEN2 SEN3 SEN4 HOLD REF ON
	ON OFF
	Activates or deactivates the display of a trace.
	SEN1 SEN2 SEN3 SEN4
	Activates the measurement results display of the sensor that is assigned to the trace.
	REF
	Selects a reference trace.
	HOLD
	Freezes the measurement results display of the sensor that is assigned to the trace.
	*RST: OFF

Example:

```
:TRACe2:FREQ:SWEep:SRC SEN2
Selects sensor2 for display in trace 2.
:TRACe1:FREQ:SWEep:SRC REF
Assigns the reference trace to trace 1.
:TRACe1:FREQ:SWEep:SRC ON
Activates trace 1 i.e. the reference trace.
```

Manual operation: See ["Indication - Trace Power Analysis"](#) on page 248

:TRACe<ch>:POW:SWEep:SRC <PowSource>

Determines the trace source of a trace for display in power measurement mode.

Parameters:

<PowSource>	OFF SEN1 SEN2 SEN3 SEN4 HOLD REF ON
	ON OFF
	Activates or deactivates the display of a trace.
	SEN1 SEN2 SEN3 SEN4
	Activates the measurement results display of the sensor that is assigned to the trace.
	REF
	Selects a reference trace.

HOLD

Freezes the measurement results display of the sensor that is assigned to the trace.

*RST: OFF

Example:

:TRACe1:POW:SWEep:SRC SEN1

Selects the connector assigned to the first port for display in trace 1.

:TRACe2:POW:SWEep:SRC HOLD

Freezes the power sweep measurement results in trace 1.

Manual operation: See ["Indication - Trace Power Analysis"](#) on page 248

:TRACe<ch>:TIME:SWEep:SRC <TimeSource>

Determines the trace source of a trace for display in time measurement mode.

Parameters:

<TimeSource>

OFF | SEN1 | SEN2 | SEN3 | SEN4 | HOLD | REF | ON

ON|OFF

Activates or deactivates the display of a trace.

SEN1|SEN2|SEN3|SEN4

Activates the measurement results display of the sensor that is assigned to the trace.

REF

Selects a reference trace.

HOLD

Freezes the measurement results display of the sensor that is assigned to the trace.

*RST: OFF

Example:

:TRACe2:TIME:SWEep:SRC SEN2

Selects sensor2 for display in trace 2.

:TRACe1:TIME:SWEep:SRC REF

Assigns the reference trace to trace 1.

:TRACe1:TIME:SWEep:SRC ON

Activates trace 1 i.e. the reference trace.

Manual operation: See ["Indication - Trace Power Analysis"](#) on page 248

:TRACe<ch>[:POWer]:SWEep:COLor <Color>

Defines the color of a trace.

Parameters:

<Color>

INVers | GRAY | YELLow | BLUE | GREen | RED | MAGenta

*RST: trace 1 = YELLow, trace 2 = GREen, trace 3 = RED.

Example:

TRAC2:SWE:COL GRAY

Trace2 is indicated in gray color.

Manual operation: See ["Color - Trace Power Analysis"](#) on page 248

:TRACe<ch>[:POWer]:SWEep:COpy <Copy>

Stores the selected trace data as reference trace.

Setting parameters:

<Copy> REFerence

Example:

TRAC2:SWE:COpy REF

Stores the current trace2 as reference trace'

TRAC1:SWE:FEED REF

Assigns the reference trace to trace 1.

Usage: Setting only

Manual operation: See ["Save to Ref - Trace Power Analysis"](#) on page 248

:TRACe<ch>[:POWer]:SWEep:DATA:POINts?

Queries the number of measurement points of the selected trace of the current power analysis.

Return values:

<Points> integer

Range: 10 to 1000

*RST: 0

Example:

TRAC1:SWE:DATA:POIN?

Response: 624

Measurement trace 1 contains 624 measurement points

Usage: Query only

:TRACe<ch>[:POWer]:SWEep:DATA:XVALues?

Queries the x-axis values - frequency, power or time values - of the selected trace of the current power analysis.

Return values:

<XValues> string

Example:

```
SENS:SWE:MODE FREQ
Sets measurement mode frequency versus power.
SENS:SWE:RMOD SING
Selects single measurement.
SENS:SWE:INIT
Starts the measurement.
*OPC?
Waits until measurement is performed.
TRAC1:SWE:DATA:XVAL?
Queries the x-axis values of trace 1.
TRAC1:SWE:DATA:YVAL?
Queries the y-axis values of trace 1
```

Usage: Query only

:TRACe<ch>[:POWER]:SWEep:DATA:YSValue? <XValue>

For a given x-axis value, queries the measurement (y-axis) value of the selected trace of the current power analysis.

Query parameters:

<XValue> float

Return values:

<YSValue> float
Increment: 1E-9

Example: TRACe1:SWE:DATA:YSValue? 2.3

Example: Queries the y-axis values of trace 1 at x-axis value of 2.3.
See [:TRACe<ch>\[:POWER\]:SWEep:DATA:XVALues?](#) on page 560.

Usage: Query only

:TRACe<ch>[:POWER]:SWEep:DATA:YVALues?

Queries the measurement (y-axis) values of the selected trace of the current power analysis.

Return values:

<YValues> string

Example: SENS:SWE:TRAC2:DATA:YVAL?
Queries the power values of trace 2.
See [:TRACe<ch>\[:POWER\]:SWEep:DATA:XVALues?](#) on page 560.

Usage: Query only

:TRACe<ch>[:POWER]:SWEep:FEED <Feed>

Selects the source for the trace data.

Parameters:

<Feed>

SENS1 | SENS2 | SENS3 | REFERENCE | NONE | SENSOR1 |
SENSOR2 | SENSOR3 | SENS4 | SENSOR4

*RST: The preset value for each trace is evaluated during runtime as follows: If a sensor is plugged into the generator whose number corresponds to the trace number, this sensor is used to feed the trace and the state of the trace is ON; If no sensor is found with number corresponding to the trace number, the preset value of the trace is "Off".

Example:

```
TRAC2:SWE:COPY REF
Stores trace2 as reference trace.
TRAC1:SWE:FEED REF
Assigns the reference trace to trace 1.
TRAC1:SWE:STAT ON
Assigns the reference trace to trace 1.
SENS:SWE:RMOD SING
Selects single measurement
SENS:SWE:INIT
Starts the measurement
```

Manual operation: See ["Indication - Trace Power Analysis"](#) on page 248

```
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:AVERage?
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:HREFERENCE?
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:LREFERENCE?
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:MAXimum?
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:MINimum?
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:PULSe:BASE?
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:PULSe:TOP?
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWER:REFERENCE?
:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DCYCLE?
:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DURATION?
:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:PERiod?
:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:SEPARation?
:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:STATe?
:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:DURATION?
:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:
  OCCurrence?
:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot?
:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:DURATION?
:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence?
:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot?
```

The above listed commands query the measured pulse parameter values.

Note: These commands are only available in time measurement mode and with R&S NRP-Z81 power sensors.

Return values:

<Overshoot> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 0

Example:

TRAC1:SWE:MEAS:POW:HREF?
 Queries the measured mesial threshold level of trace 1.
 TRAC3:SWE:MEAS:POW:MAX?
 Queries the measured peak power of trace 3.

Usage: Query only

Options: Option R&S SMAB-K28

Manual operation: See "[Overshoot \(Rising Edge / Falling Edge\)](#)" on page 267

```
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYCle:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERage:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEParation:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation:
  DISPlay:ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence:
  DISPlay:ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot:
  DISPlay:ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation:
  DISPlay:ANNotation[:STATe] <State>
```

:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence:DISPlay:ANNotation[:STATe] <State>

:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot:DISPlay:ANNotation[:STATe] <State>

The above listed commands select the pulse parameters which are indicated in the display and hardcopy file. Only six parameters can be indicated at a time.

Note: These commands are only available in time measurement mode and with R&S NRP-Z81 power sensors.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example:

TRAC:SWE:MEAS:TRAC2:PULS:PER:DISP:ANN ON

Selects the pulse period to be indicated in the display.

TRAC:SWE:MEAS:PULS:DISP:ANN ON

Activates indication of the selected pulse data in the display.

Options:

Option R&S SMAB-K28

Manual operation: See "[Overshoot \(Rising Edge / Falling Edge\)](#)" on page 267

:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:ALL:DISPlay:ANNotation[:STATe] <State>

Deactivates the indication of all pulse data of the selected trace. The parameters to be indicated can be selected with the TRAC:SWE:MEAS:... commands. Only six parameters are indicated at a time.

Note: This command is only available in time measurement mode and with R&S NRP-Z81 power sensors.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example:

TRAC:SWE:MEAS:PULS:ALL:DISP:ANN OFF

Switches the indication of all pulse data off.

Options:

Option R&S SMAB-K28

:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:BASE?

Queries how the threshold parameters are calculated.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Return values:

<Base> VOLTage | POWer
*RST: VOLTage

Example: `TRAC1:SWE:PULS:THR:BAS?`
Queries the threshold base of pulse data calculation.

Usage: Query only

Manual operation: See "[Base](#)" on page 263

:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:HREference
<HReference>

Queries the upper threshold level of the overall pulse level. The distal power defines the end of the rising edge and the start of the falling edge of the pulse.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Parameters:

<HReference>	float
Range:	0.0 to 100.0
Increment:	0.01
*RST:	90.0

Example: `TRAC2:SWE:PULS:THR:POW:HREF?`
Queries the upper reference level of trace 2.

Manual operation: See "[Distal](#)" on page 263

:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:LREference
<LReference>

Queries the lower medial threshold level of the overall pulse level. The proximal power defines the start of the rising edge and the end of the falling edge of the pulse.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Parameters:

<LReference>	float
Range:	0.0 to 100.0
Increment:	0.01
*RST:	10.0

Example: `TRAC:SWE:PULS:THR:POW:LREF?`
Queries the medial threshold level of trace 1.

Manual operation: See "[Proximal](#)" on page 264

:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:REference <Reference>

Queries the medial threshold level of the overall pulse level. This level is used to define the pulse width and pulse period.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Parameters:

<Reference> float
 Range: 0.0 to 100.0
 Increment: 0.01
 *RST: 50.0

Example:

TRAC3:SWE:PULS:THR:POW:REF?
 Queries the medial threshold level of trace 3.

Manual operation: See "[Mesial](#)" on page 264

:TRACe<ch>[:POWer]:SWEep:STATe <State>

Activates the selected trace.

Parameters:

<State> OFF | ON | HOLD
 *RST: The preset value for each trace is evaluated during runtime as follows: If a sensor is plugged into the generator whose number corresponds to the trace number, this sensor is used to feed the trace and the state of the trace is ON; If no sensor is found with a number corresponding to the trace number, the preset value of the trace is "Off".

Example:

TRAC2:SWE:COPY REF
 Stores trace2 as reference trace.
 TRAC1:SWE:FEED REF
 Assigns the reference trace to trace 1.
 TRAC1:SWE:STAT ON
 Assigns the reference trace to trace 1.
 SENS:SWE:RMOD SING
 Selects single measurement.
 SENS:SWE:INIT
 Starts the measurement.

Manual operation: See "[Indication - Trace Power Analysis](#)" on page 248

:TRACe[:POWer]:SWEep:MEASurement:FULLscreen:DISPlay:ANNotation[:STATe] <State>

Selects fullscreen display of the measurement diagram on the display and in the hard-copy file.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 1

Example: TRAC:SWE:MEAS:FULL:DISP:ANN ON
The display only shows the diagram.

Options: Option R&S SMAB-K28

Manual operation: See ["Full Screen"](#) on page 276

:TRAC[:POWER]:SWEep:MEASurement:GATE:DISPlay:ANNotation[:STATe]
<State>

Activates the indication of the time gate borders and values in the measurement diagram and in the hardcopy file. The gate settings are performed with the CALC:POW:SWE:TIME:GATE:... commands.

Parameters:
<State> 0 | 1 | OFF | ON
*RST: 1

Example: TRAC:SWE:MEAS:GATE:DISP:ANN ON
The diagram also shows the gate information.

Options: Option R&S SMAB-K28

Manual operation: See ["State - Gate"](#) on page 273
See ["Gate View"](#) on page 275

:TRAC[:POWER]:SWEep:MEASurement:MARKer:DISPlay:ANNotation[:STATe]
<State>

Activates the indication of the markers and the marker list in the measurement diagram and in the hardcopy file.

Parameters:
<State> 0 | 1 | OFF | ON
*RST: 1

Example: TRAC:SWE:MEAS:MARK:DISP:ANN ON
The diagram also shows the marker information.

Options: Option R&S SMAB-K28

Manual operation: See ["Marker View"](#) on page 274

:TRAC[:POWER]:SWEep:MEASurement:PULSe:DISPlay:ANNotation[:STATe]
<State>

Activates the indication of the pulse data below the measurement diagram and storing the data in the hardcopy file. The parameters to be indicated can be selected with the following TRAC:SWE:MEAS:... commands. Only six parameters are indicated at one time.

Note: This command is only available in time measurement mode and with R&S NRPZ81 power sensors.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 1

Example:

TRAC:SWE:MEAS:PULS:DISP:ANN ON
 Activates indication of the selected pulse data.

Options:

Option R&S SMAB-K28

Manual operation: See ["Pulse Data View"](#) on page 275

:TRACe[:POWer]:SWEep:MEASurement:STANdard:DISPlay:ANNotation[:STATe]
 <State>

Selects the standard view, i.e. diagram and buttons but no lists are displayed and also stored in the hardcopy file.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 1

Example:

TRAC:SWE:MEAS:STAN:DISP:ANN ON
 Activates indication of the selected pulse data.

Options:

Option R&S SMAB-K28

Manual operation: See ["Standard View"](#) on page 274

14.16 SENSe, READ, INITiate and SLISt subsystems

These subsystems contain the commands for configuring the power measurements with R&S NRP power sensor connected to the R&S SMA100B.



The local state is set with the `INIT` command. Switching off the local state enhances the measurement performance. Measurements results can be retrieved in local state on or off.

Sensor parameters are set with the `SENSe` commands.

To start the measurement and retrieve the result, use the `:READ<ch>[:POWer]?` command.

SENSe, READ, INITiate and SLISt subsystems

Suffix	Value range	Description
SENSe<ch>	[1] to 4	<p>Indicates the sensor</p> <p>Sensor mapping:</p> <ul style="list-style-type: none"> • <code>SENSe[1]</code> - default mapping for sensors connected to the [Sensor] connector • <code>SENSe2</code> - sensor connected to a [USB] connector • <code>SENSe3 4</code> - further connected sensors to [USB] connectors, in the connection order <p>Use the <code>:SLISt</code> commands to change the sensor mapping</p>
READ<ch>	[1] to 4	Sensor assignment
INITiate<hw>	[1] to 4	Sensor assignment
ELEMeNt<ch>	[1] to 25	Sensor-mapping list

Programming examples

Example: Detecting and assigning a power sensor

```
SLISt:LIST?
// Response: "NRP33SN-V-900007-USB Legacy","NRP-Z211-900001-USB Legacy"
// Lists all automatically detected sensors.

SLISt:SCAN:STATe 1
// Searches for sensors connected in the LAN or via the USBTMC protocol.

SLISt:SCAN:LENSor 'NRQ6',101624 // sensor name, serial number
SLISt:SCAN:LENSor 11.123.1.123, 101624 // IP address, serial number
// Adds sensors to the list, that are connected to LAN.

SLISt:SCAN:USENSor 'NRQ6',101624 //sensor name, serial number
SLISt:SCAN:USENSor #H15b,101624 //device ID (hexadecimal), serial number
SLISt:SCAN:USENSor 347,101624 //device ID (decimal), serial number
// Adds a sensor to the list, that is connected to the USB interface.

SLISt:LIST?
// Response: "NRP33SN-V-900007-USB Legacy","NRP-Z211-900001-USB Legacy",
// "NRP33SN-V-900005-USBTMC","NRP33SN-V-900011-LAN"
// Lists all automatically detected sensors.

SLISt:ELEMent3:MAPPing SENS1
// Maps the third sensor from the list to the first sensor channel.

SLISt:SENSor:MAP "NRPS18S-100654-USB Legacy", SENS3
// Maps the sensor to channel 3.

SLISt:CLEar[ALL]
// Remove all sensors from the list.
SLISt:CLEar:LAN
// Remove all sensors from the list, that are connected over LAN.
SLISt:CLEar:USB
// Remove all sensors from the list, that are connected over USB.
```

Example: Performing a simple power measurement

Prerequisite: The sensor is connected to the instrument and mapped to the first sensor channel.

```
INITiate1:CONTinuous ON
// Switches the continuous power measurement on.

READ1?
// Triggers the measurement and displays the results.
```

Example: Performing a power measurement with a fixed filter

Prerequisite: The sensor is connected to the instrument and mapped to the first sensor channel.

```

SENSe1:SOURce RF
// Sensor measures the power of the RF signal.

SENSe1:FILTer:TYPE NSRatio
// Selects fixed noise filter mode.

SENSe1:FILTer:NSRatio 0.02 DB
// Sets the maximum noise component in the result to 0.02 DB.

SENSe1:FILTer:NSRatio:MTIME 10
//Limits the settling time to 10 seconds.

SENSe1:APERture:DEFAult:STATe 0
// Deactivates the default aperture time of the sensor.

SENSe1:APERture:TIME 10e-6
// Sets the aperture time to 10 us.

SENSe1:UNIT DBM
// Selects unit dBm for the measured value.

INITiate:CONTinuous ON
// Switches the continous power measurement on.

READ?
// Triggers the measurement and displays the results.

```

:SLISt[:LIST]?	572
:SLISt:SCAN[:STATe]	572
:SLISt:SCAN:LENSor	572
:SLISt:SCAN:USENSor	573
:SLISt:CLEar:LAN	573
:SLISt:CLEar:USB	573
:SLISt:CLEar[:ALL]	574
:SLISt:ELEMent<ch>:MAPPing	574
:SLISt:SENSor:MAP	574
:SENSe<ch>:UNIT[:POWer]	574
:SENSe<ch>[:POWer]:APERture:DEFAult:STATe	575
:SENSe<ch>[:POWer]:APERture:TIME	575
:SENSe<ch>[:POWer]:CORRection:SPDevice:SELEct	575
:SENSe<ch>[:POWer]:CORRection:SPDevice:STATe	576
:SENSe<ch>[:POWer]:CORRection:SPDevice:LIST?	576
:SENSe<ch>[:POWer]:DISPlay:PERManent:PRiority	576
:SENSe<ch>[:POWer]:DISPlay:PERManent:STATe	576
:SENSe<ch>[:POWer]:FILTer:LENGth:AUTO?	577
:SENSe<ch>[:POWer]:FILTer:LENGth[:USER]	577
:SENSe<ch>[:POWer]:FILTer:NSRatio	578

:SENSe<ch>[:POWer]:FILTer:NSRatio:MTIME.....	578
:SENSe<ch>[:POWer]:FILTer:SONCe.....	578
:SENSe<ch>[:POWer]:FILTer:TYPE.....	579
:SENSe<ch>[:POWer]:FREQuency.....	579
:SENSe<ch>[:POWer]:LOGGing:STATe.....	580
:SENSe<ch>[:POWer]:OFFSet.....	580
:SENSe<ch>[:POWer]:OFFSet:STATe.....	580
:SENSe<ch>[:POWer]:SNUMber?.....	580
:SENSe<ch>[:POWer]:SOURce.....	581
:SENSe<ch>[:POWer]:STATus[:DEVice]?.....	581
:SENSe<ch>[:POWer]:SVERsion?.....	581
:SENSe<ch>[:POWer]:TYPE?.....	582
:SENSe<ch>[:POWer]:ZERO.....	582

:SLISt[:LIST]?

Returns a list of all detected sensors in a comma-separated string.

Return values:

<SensorList> String of comma-separated entries
 Each entry contains information on the sensor type, serial number and interface.
 The order of the entries does not correspond to the order the sensors are displayed in the "NRP Sensor Mapping" dialog.

Example: See [Example "Detecting and assigning a power sensor"](#) on page 570.

Usage: Query only

Manual operation: See ["Sensor Mapping List"](#) on page 232

:SLISt:SCAN[:STATe] <State>

Starts the search for R&S NRP power sensors, connected in the LAN or via the USBTMC protocol.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Detecting and assigning a power sensor"](#) on page 570.

Manual operation: See ["Scan"](#) on page 233

:SLISt:SCAN:LSEnSor <IP>

Scans for R&S NRP power sensors connected in the LAN.

Setting parameters:

<IP> string
 *RST: 0

Example: See [Example](#) "Detecting and assigning a power sensor" on page 570.

Usage: Setting only

Manual operation: See ["Add LAN Sensor settings"](#) on page 233

:SLISt:SCAN:USENSor <DeviceID>, <Serial>

Scans for R&S NRP power sensors connected over a USB interface.

Parameters:

<Serial> integer
 Range: 0 to 999999

Setting parameters:

<DeviceID> String or Integer
 Range: 0 to 999999
 *RST: 0

Example: See [Example](#) "Detecting and assigning a power sensor" on page 570.

Usage: Setting only

Manual operation: See ["Add USB Sensor settings"](#) on page 233

:SLISt:CLEAr:LAN

Removes all R&S NRP power sensors connected in the LAN from the list.

Example: See [Example](#) "Detecting and assigning a power sensor" on page 570.

Usage: Event

Manual operation: See ["Clear"](#) on page 233

:SLISt:CLEAr:USB

Removes all R&S NRP power sensors connected over USB from the list.

Example: See [Example](#) "Detecting and assigning a power sensor" on page 570.

Usage: Event

Manual operation: See ["Clear"](#) on page 233

:SLISt:CLEAr[:ALL]

Removes all R&S NRP power sensors from the list.

Example: See [Example "Detecting and assigning a power sensor"](#) on page 570.

Usage: Event

Manual operation: See ["Clear"](#) on page 233

:SLISt:ELEMent<ch>:MAPPING <Mapping>

Assigns an entry from the [:SLISt\[:LIST\]?](#) to one of the four sensor channels.

Parameters:

<Mapping> SENS1 | SENSor1 | SENS2 | SENSor2 | SENS3 | SENSor3 |
SENS4 | SENSor4 | UNMapped
Sensor channel.
*RST: UNMapped

Example: See [Example "Detecting and assigning a power sensor"](#) on page 570.

Manual operation: See ["Sensor Mapping List"](#) on page 232

:SLISt:SENSor:MAP <SensorId>, <Mapping>

Assigns a sensor directly to one of the sensor channels, using the sensor name and serial number.

To find out the the sensor name and ID, you can get it from the label of the R&S NRP, or using the command [:SLISt:SCAN\[:STATe\]](#). This command detects all R&S NRP power sensors connected in the LAN or via 'USBTMC protocol.

Setting parameters:

<SensorId> string
<Mapping> enum

Example: See [Example "Detecting and assigning a power sensor"](#) on page 570.

Usage: Setting only

Manual operation: See ["Sensor Mapping List"](#) on page 232

:SENSe<ch>:UNIT[:POWER] <Power>

Selects the unit (Watt, dBm or dBµV) of measurement result display, queried with [:READ<ch>\[:POWER\]?](#).

Parameters:

<Power> DBM | DBUV | WATT
 *RST: DBM

Example:

```
:SENS2:UNIT DBM
Selects dBm as unit for the measured value returned by command READ.
:READ2?
Response: 7.34
7.34 dBm are measured by sensor 2.
```

Manual operation: See ["Level \(Peak\) / Level \(Average\)"](#) on page 238

:SENSe<ch>[:POWer]:APERTure:DEFault:STATe <UseDefAp>

Deactivates the default aperture time of the respective sensor.

To specify a user-defined value, use the command [:SENSe<ch>\[:POWer\]:APERTure:TIME](#) on page 575.

Parameters:

<UseDefAp> 1 | ON | 0 | OFF
 *RST: 1

Example:

See [Example"Performing a power measurement with a fixed filter"](#) on page 571.

Manual operation: See ["Default Aperture Time"](#) on page 241

:SENSe<ch>[:POWer]:APERTure:TIME <ApTime>

Defines the aperture time (size of the acquisition interval) for the corresponding sensor.

Parameters:

<ApTime> float
 Range: depends on connected power sensor
 Increment: 1E-9
 *RST: depends on connected power sensor

Example:

See [Example"Performing a power measurement with a fixed filter"](#) on page 571.

Manual operation: See ["Aperture Time"](#) on page 241

:SENSe<ch>[:POWer]:CORRection:SPDevice:SELeCt <Select>

Several S-parameter tables can be stored in a sensor. The command selects a loaded data set for S-parameter correction for the corresponding sensor.

Parameters:

<Select> float
 *RST: 0

Manual operation: See ["S-Parameter"](#) on page 241

:SENSe<ch>[:POWer]:CORRection:SPDevice:STATe <State>

Activates the use of the S-parameter correction data.

Note: If you use power sensors with attenuator, the instrument automatically activates the use of S-parameter data.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: :SENS1:POWer:CORRection:SPDevice:STATe 1
 Activates the use of the S-parameters correction data.

Manual operation: See ["S-Parameter"](#) on page 241

:SENSe<ch>[:POWer]:CORRection:SPDevice:LIST?

Queries the list of the S-parameter data sets that have been loaded to the power sensor.

Return values:

<List> string list
 *RST: 0

Usage: Query only

Manual operation: See ["S-Parameter"](#) on page 241

:SENSe<ch>[:POWer]:DISPlay:PERMANent:PRiority <Priority>

Selects average or peak power for permanent display.

Parameters:

<Priority> AVERAge | PEAK
 *RST: AVERAge

Example: :SENS1:DISP:PERM:STAT ON
 Turns on the permanent view.
 :SENS1:DISP:PERM:PRI AVER
 Sets the average power for display.

Manual operation: See ["Display"](#) on page 239

:SENSe<ch>[:POWer]:DISPlay:PERMANent:STATe <State>

Activates the permanent display of the measured power level results. The instrument also indicates the sensor type, the connection, the measurement source and the offset if set.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example:

:SENS1:POW:DISP:PERM:STAT ON
 Turns on the permanent view.

Manual operation: See ["Permanent"](#) on page 239

:SENSe<ch>[:POWer]:FILTer:LENGth:AUTO?

Queries the current filter length in filter mode AUTO (:SENSe<ch>[:POWer]:FILTer:TYPE)

Return values:

<Auto> float
 Range: 1 to 65536

Example:

:SENS1:FILT:TYPE AUTO
 Selects auto filter.
 :SENS1:FILT:LENG:AUTO?
 Queries the automatically set filter length.
 Response: 1024

Usage: Query only

Manual operation: See ["Filter Length"](#) on page 240

:SENSe<ch>[:POWer]:FILTer:LENGth[:USER] <User>

Selects the filter length for SENS:POW:FILT:TYPE USER. As the filter length works as a multiplier for the time window, a constant filter length results in a constant measurement time (see also ["About the measuring principle, averaging filter, filter length, and achieving stable results"](#) on page 234).

The R&S NRP power sensors provide different resolutions for setting the filter length, depending on the used sensor type:

- Resolution = 1 for R&S NRPxx power sensors
- Resolution = 2^n for sensors of the R&S NRP-Zxx family, with $n = 1$ to 16

Parameters:

<User> float
 Range: 1 to 65536
 *RST: 1

Example:

:SENS1:FILT:TYPE USER
 Selects user filter mode.
 :SENS1:FILT:LENG 16
 Sets a filter length of 16. E.g. using a sensor with 20 ms time window, the resulting measurement time is 640 ms (2x16x20 ms)

Manual operation: See ["Filter Length"](#) on page 240

:SENSe<ch>[:POWer]:FILTer:NSRatio <NSRatio>

Sets an upper limit for the relative noise content in fixed noise filter mode (:SENSe<ch>[:POWer]:FILTer:TYPE). This value determines the proportion of intrinsic noise in the measurement results.

Parameters:

<NSRatio> float
 Range: 0.001 to 1
 Increment: 0.001
 *RST: 0.01

Example: See [Example"Performing a power measurement with a fixed filter"](#) on page 571.

Manual operation: See ["Noise/Signal Ratio"](#) on page 240

:SENSe<ch>[:POWer]:FILTer:NSRatio:MTIME <MTime>

Sets an upper limit for the settling time of the auto-averaging filter in the NSRatio mode and thus limits the length of the filter. The filter type is set with command :SENSe<ch>[:POWer]:FILTer:TYPE.

Parameters:

<MTime> float
 Range: 1 to 999.99
 Increment: 0.01
 *RST: 4

Example: See [Example"Performing a power measurement with a fixed filter"](#) on page 571.

Manual operation: See ["Timeout"](#) on page 241

:SENSe<ch>[:POWer]:FILTer:SONCe

Starts searching the optimum filter length for the current measurement conditions. You can check the result with command :SENS1:POW:FILT:LENG:USER? in filter mode USER (:SENSe<ch>[:POWer]:FILTer:TYPE).

Example:

```
SENS1:FILT:TYPE USER
Selects user filter mode.
:SENS1:FILT:SONC
Activates the search for the optimum filter length.
:SENS1:FILT:LENG?
Returns the found optimum filter length.
Response: 128
```

Usage: Event

Manual operation: See ["Auto Once"](#) on page 240

:SENSe<ch>[:POWer]:FILTer:TYPE <Type>

Selects the filter mode. The filter length is the multiplier for the time window and thus directly affects the measurement time.

Parameters:

<Type>

AUTO | USER | NSRatio

AUTO

Automatically selects the filter length, depending on the measured value. The higher the power, the shorter the filter length, and vice versa.

USER

Allows you to set the filter length manually. As the filter-length takes effect as a multiplier of the measurement time, you can achieve constant measurement times.

NSRatio

Selects the filter length (averaging factor) according to the criterion that the intrinsic noise of the sensor (2 standard deviations) does not exceed the specified noise content. You can define the noise content with command `:SENSe<ch>[:POWer]:FILTer:NSRatio`.

Note: To avoid long settling times when the power is low, you can limit the averaging factor limited with the "timeout" parameter (`:SENSe<ch>[:POWer]:FILTer:NSRatio:MTIME`).

*RST: AUTO

Example: See [Example "Performing a power measurement with a fixed filter"](#) on page 571.

Manual operation: See ["Filter"](#) on page 240

:SENSe<ch>[:POWer]:FREQuency <Frequency>

Sets the RF frequency of the signal, if signal source `:SENSe<ch>[:POWer]:SOURce USER` is selected.

Parameters:

<Frequency>

float

*RST: 1 GHz

Example:

`:SENS1:SOUR USER`

Selects user-defined source.

`:SENS1:FREQ 2.44GHz`

Sets the RF frequency of the source which is 2.44 GHz.

Manual operation: See ["Frequency"](#) on page 239

:SENSe<ch>[:POWer]:LOGGing:STATe <State>

Activates the recording of the power values, measured by a connected R&S NRP power sensor.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example:

:SENS:LOGG:STAT ON
Activates recording of the power measurement of the first sensor.

Manual operation: See ["Enable Logging"](#) on page 241

:SENSe<ch>[:POWer]:OFFSet <Offset>

Sets a level offset which is added to the measured level value after activation with command [:SENSe<ch>\[:POWer\]:OFFSet:STATe](#). The level offset allows, e.g. to consider an attenuator in the signal path.

Parameters:

<Offset> float
Range: -100.0 to 100.0
*RST: 0
Default unit: dB

Example:

:SENS1:POW:OFFS 10.0
Sets a level offset of 10 dB

Manual operation: See ["Level Offset State,Level Offset"](#) on page 239

:SENSe<ch>[:POWer]:OFFSet:STATe <State>

Activates the addition of the level offset to the measured value. The level offset value is set with command [:SENSe<ch>\[:POWer\]:OFFSet](#).

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example:

:SENS1:POW:OFFS 0.4dB
Sets a level offset of 0.4 dB
:SENS1:POW:OFFS:STAT ON
A level offset of 0.4 dB is added to the measured value.

Manual operation: See ["Level Offset State,Level Offset"](#) on page 239

:SENSe<ch>[:POWer]:SNUMber?

Queries the serial number of the sensor.

Return values:

<SNumber> string

Example:

:SENS1:SNUM?

Queries the serial number.

Usage:

Query only

Manual operation: See ["Sensor type and serial number"](#) on page 238

:SENSe<ch>[:POWer]:SOURce <Source>

Determines the signal to be measured.

Note: When measuring the RF signal, the sensor considers the corresponding correction factor at that frequency, and uses the level setting of the instrument as reference level.**Parameters:**

<Source> A | USER | RF

*RST: A

Example:See [Example "Performing a power measurement with a fixed filter"](#) on page 571.**Manual operation:** See ["Use Frequency Of"](#) on page 239

:SENSe<ch>[:POWer]:STATus[:DEVice]?

Queries if a sensor is connected to the instrument.

Return values:

<Status> 1 | ON | 0 | OFF

*RST: 0

Example:

:SENS1:STAT?

Response: 1

A sensor is connected.

Usage:

Query only

Manual operation: See ["State"](#) on page 238

:SENSe<ch>[:POWer]:SVERsion?

Queries the software version of the connected R&S NRP power sensor.

Return values:

<SVersion> string

Example:

:SENS1:POW:SVER?

Queries the software version of the power sensor.

Usage:

Query only

:SENSe<ch>[:POWer]:TYPE?

Queries the sensor type. The type is automatically detected.

Return values:

<Type> string

Example:

:SENS1:TYPE?

Queries the type of sensor.

Response: NRP-Z21

The R&S NRP-Z21 sensor is used.

Usage: Query only

Manual operation: See ["Sensor type and serial number"](#) on page 238

:SENSe<ch>[:POWer]:ZERO

Performs zeroing of the sensor.

Zeroing is required after warm-up, i.e. after connecting the sensor.

Note: Switch off or disconnect the RF power source from the sensor before zeroing.

We recommend that you zero in regular intervals (at least once a day), if:

- The temperature has varied more than about 5 °C.
- The sensor has been replaced.
- You want to measure very low power.

Example:

:SENS1:ZERO

Executes zeroing.

Usage: Event

Manual operation: See ["Zero"](#) on page 238

14.17 SOURce subsystem

The SOURce subsystem contains the commands for configuring signals.

Common suffixes

The following common suffixes are used in remote commands:

Suffix	Value range	Description
SOURce<hw>	[1]	<ul style="list-style-type: none"> • SOURce[1] = RF output (optional keyword) • LF output = SOURce:LFOutput (SOURce is optional keyword)

• Analog modulation subsystems	583
• Avionic standards subsystems	614
• SOURce:CORRection subsystem	656
• SOURce:FREQuency subsystem	664
• SOURce:INPut subsystem	673
• SOURce:LFOutput subsystem	674
• SOURce:LIST subsystem	687
• SOURce:NOISe subsystem	699
• SOURce:PGEN subsystem	701
• SOURce:PHASe subsystem	703
• SOURce:POWer subsystem	704
• SOURce:ROSCillator subsystem	714
• SOURce:SWEEP subsystem	720

14.17.1 Analog modulation subsystems

Option: see [Chapter 5.1, "Required options"](#), on page 79.

The subsystems in this section describe all commands for analog modulation of the RF signal. Divided in separate sections, you can configure amplitude modulation (AM), frequency modulation (FM), phase modulation (PhiM) and pulse modulation (PULM).

You can perform each of the modulations either with an internally generated modulation signal or with an externally applied signal.

To configure the internal signal, use the commands listed in [Chapter 14.17.6, "SOURce:LFOutput subsystem"](#), on page 674.

For more information:

See [Chapter 5, "Analog modulations"](#), on page 79.

14.17.1.1 SOURce:MODulation subsystem

The command in this subsystem allows you to disable all active modulations at once, and, vice versa, to restore the last active ones.

[[:SOURce<hw>]:MODulation[:ALL][:STATE] <State>

Activates all modulations that were active before the last switching off.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example:

```

SOURce1:AM1:DEPT h 30
SOURce1:AM1:SOURce LF1
SOURce1:AM1:STATe 1
SOURce1:FM1:DEVIation 1000
SOURce1:FM1:STATe 1
// disable both modulation
SOURce1:MODulation:ALL:STATe 0
SOURce1:AM1:STATe?
// 0
SOURce1:FM1:STATe?
// 0
// enable both modulation
SOURce1:MODulation:ALL:STATe 1
SOURce1:AM1:STATe?
// 1
SOURce1:FM1:STATe?
// 1

```

Manual operation: See "[Mod on/off]" on page 82

14.17.1.2 SOURce:AM subsystem

Option: R&S SMAB-K720

The AM subsystem contains the commands for setting the amplitude modulation and also the broadband amplitude modulation.

The following examples show some variants for generating AM signals.

Example: Creating an amplitude modulated RF signal

Using the internal LF generator, the following command sequence configures an amplitude modulated signal.

```

// Reset the instrument to start from a defined state
*RST

// Set RF frequency and amplitude
SOURce1:FREQuency:CW 6000000000
SOURce1:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the modulation signal
SOURce1:LFOutput1:SHAPE SINE
SOURce1:LFOutput1:FREQuency 20000

// Configure the amplitude modulation settings and switch AM on
SOURce1:AM1:SOURce LF1
SOURce1:AM1:DEPT h 30
SOURce1:AM:RATio 40
SOURce1:AM1:DEVIation:MODE UNC
SOURce1:AM1:STATe 1

```


Example: Using combined LF signals

Using the internal LF generators of both paths, the following command sequences configure an amplitude modulated signal with determined deviations depths.

```
// Configure the AM modulation settings with combined LF signal sources
SOURcel:AM1:SOURce LF1
SOURcel:AM1:DEPTh:LINear 32
// Select the modulation signal source for the second path
SOURcel:AM2:SOURce LF2
// Combine the signals of both paths with fixed total deviation depth
SOURcel:AM1:DEVIation:MODE TOT
SOURcel:AM1:DEPTh:SUM 60

// Query the deviation depth of modulation signal in the second path
SOURcel:AM2:DEPTh:LINear?
// Response: 28

// Combine the signals of both paths with fixed ratio
SOURcel:AM1:DEVIation:MODE RAT
SOURcel:AM1:RATio 100
SOURcel:AM2:DEPTh:LINear 25

// Query the deviation depth of modulation signal in the first path
SOURcel:AM1:DEPTh:LINear?
// Response: 25

SOURcel:AM1:STATe 1
SOURcel:AM2:STATe 1
```

Example: Using an external signal source

Using an external signal source, you can additionally determine whether you want to use only the AC component of the external modulation signal.

```
// Reset the instrument to start from a defined state
*RST

// Set frequency and amplitude
SOURcel:FREQuency:CW 6000000000
SOURcel:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the amplitude modulation settings and turn on AM
SOURcel:AM1:SOURce EXT1
SOURcel:AM1:DEPTh 40

// Query the input sensitivity at the external modulation input
SOURcel:AM1:SENSitivity?
// Response: 40
// Since the voltage value for full modulation is 1V,
// the resulting sensitivity is precisely 50%/V.
```

```
// This value is assigned to the voltage value for full
// modulation of the input.

// Select the coupling mode AC for external amplitude modulation
SOURce1:INPut:MODext:COUPling1 AC

// For external AM signal input, adjust the sensitivity
SOURce1:AM1:TYPE EXP
SOURce1:AM1:SOURce EXT1
SOURce1:AM1:SENSitivity 25
SOURce1:AM1:SENSitivity?
Response: 25

// Alternatively use the scan mode for the level behavior of rotating antennas
// SCAN automatically sets the modulation type to exponential
SOURce1:AM1:MODE SCAN
SOURce1:AM1:SOURce EXT2
SOURce1:AM1:DEPTh:EXPonential 12
SOURce1:AM1:DEPTh:EXPonential?
Response: 12

// Activating the external exponential AM changes the coupling
// in this example for EXT2
INPut:MODext:COUPling2 DC

// Configure the modulation settings

// Switch on AM and RF signal output
SOURce1:AM1:STATe 1
OUTPut1:STATe 1
```

The following commands are available:

[:SOURce<hw>]:AM<ch>:STATe	586
[:SOURce<hw>]:AM<ch>:SOURce	587
[:SOURce<hw>]:AM<ch>[:DEPTh]	587
[:SOURce<hw>]:AM<ch>:DEPTh:LINear	587
[:SOURce<hw>]:AM<ch>:DEPTh:EXPonential	588
[:SOURce<hw>]:AM:MODE	588
[:SOURce<hw>]:AM:DEPTh:SUM	588
[:SOURce<hw>]:AM:DEViation:MODE	589
[:SOURce<hw>]:AM:RATio	589
[:SOURce<hw>]:AM<ch>:SENSitivity:EXPonential	589
[:SOURce<hw>]:AM<ch>:SENSitivity[:LINear]	590
[:SOURce<hw>]:AM:TYPE	590

[\[:SOURce<hw>\]:AM<ch>:STATe <State>](#)

Activates amplitude modulation.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 584.

Manual operation: See ["State"](#) on page 85

[:SOURce<hw>]:AM<ch>:SOURce <Source>

Selects the modulation source for amplitude modulation.

Parameters:

<Source> LF1 | LF2 | NOISe | EXT1 | EXT2 | EXTeRnal | INTeRnal

LF1|LF2

Uses an internally generated LF signal.

EXT1|EXT2

Uses an externally supplied LF signal.

NOISe

Uses the internally generated noise signal.

INTeRnal

Uses the internally generated signal of LF1.

EXTeRnal

Uses an external LF signal (EXT1).

*RST: LF1 <AM1>; LF2 <AM2>

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 584.

Manual operation: See ["Source"](#) on page 85

[:SOURce<hw>]:AM<ch>[:DEPT h] <Depth>

Sets the depth of the amplitude modulation in percent.

Suffix:

<ch> 1..2
 Modulation signal channel

Parameters:

<Depth> float
 Range: 0 to 100

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 584.

[:SOURce<hw>]:AM<ch>:DEPT h:LINear <DepthLin>

Sets the depth of the linear amplitude modulation in percent / volt.

Parameters:

<DepthLin> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 30

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 584. Similar to DEPTH.

Manual operation: See ["Depth"](#) on page 90

[:SOURce<hw>]:AM<ch>:DEPTH:EXPOnential <DepthExp>

Sets the depth of the exponential amplitude modulation in dB/volt.

Parameters:

<DepthExp> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 10

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 584. Similar to DEPTH.

Manual operation: See ["Depth"](#) on page 90

[:SOURce<hw>]:AM:MODE <AmMode>

Selects the mode of the amplitude modulation.

[\[:SOURce<hw>\]:AM:MODE > SCAN](#) sets [\[:SOURce<hw>\]:AM:TYPE > EXPOnential](#).

For active external exponential AM, automatically sets [\[:SOURce<hw>\]:INPut:MODext:COUPling<ch> > DC](#).

Parameters:

<AmMode> SCAN | NORMAl
 *RST: NORMAl

Example: See [Example "Using an external signal source"](#) on page 585.

Options: R&S SMAB-K721

Manual operation: See [" Mode"](#) on page 89

[:SOURce<hw>]:AM:DEPTH:SUM <AmDepthSum>

Sets the total depth of the LF signal when using combined signal sources in amplitude modulation.

Parameters:

<AmDepthSum> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 30

Example: See [Example"Using combined LF signals"](#) on page 585.

Manual operation: See [" Total Depth"](#) on page 90

[:SOURce<hw>]:AM:DEVIation:MODE <AmDevMode>

Selects the coupling mode. The coupling mode parameter also determines the mode for fixing the total depth.

Parameters:

<AmDevMode> UNCoupled | TOTal | RATio
UNCoupled
 Does not couple the LF signals.
 The deviation depth values of both paths are independent.
TOTal
 Couples the deviation depth of both paths.
RATio
 Couples the deviation depth ratio of both paths
 *RST: UNCoupled

Example: See [Example"Using combined LF signals"](#) on page 585.

Manual operation: See [" Deviation Mode"](#) on page 90

[:SOURce<hw>]:AM:RATio <Ratio>

Sets the deviation ratio (path#2 to path#1) in percent.

Parameters:

<Ratio> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 100

Example: See [Example"Creating an amplitude modulated RF signal"](#) on page 584.

Manual operation: See [" Ratio Path2/Path1"](#) on page 91

[:SOURce<hw>]:AM<ch>:SENSitivity:EXPonential <Sensitivity>

For [:SOURce<hw>]:AM:TYPEEXP, sets the sensitivity of the external signal source for amplitude modulation.

Parameters:

<Sensitivity> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 10

Example: See [Example"Using an external signal source"](#) on page 585.

Manual operation: See ["Sensitivity"](#) on page 90

[:SOURce<hw>]:AM<ch>:SENSitivity[:LINear] <Sensitivity>

For [:SOURce<hw>]:AM:TYPE LIN, sets the sensitivity of the external signal source for amplitude modulation.

Parameters:

<Sensitivity> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 30

Example: See [Example"Using an external signal source"](#) on page 585.

Manual operation: See ["Sensitivity"](#) on page 90

[:SOURce<hw>]:AM:TYPE <AmType>

Selects the type of amplitude modulation.

For [:SOURce<hw>]:AM:MODE SCAN, only EXPonential is available.

For active external exponential AM, automatically sets [:SOURce<hw>]:INPut:MODext:COUPling<ch>DC.

Parameters:

<AmType> LINear | EXPonential
 *RST: LINear

Example: See [Example"Using an external signal source"](#) on page 585.

Options: R&S SMAB-K721

Manual operation: See ["Type"](#) on page 89

14.17.1.3 SOURce:CHIRp subsystem

Option: see [Chapter 5.1, "Required options"](#), on page 79.

With the commands described in this section, you can configure the settings for chirp modulation, select the trigger mode and determine the parameters for an external pulse / trigger signal.

The following examples show some variants for generating the modulation chirp.

Example: Perform chirp modulation

Using the internal pulse generator, the following command sequence configures a chirp modulated RF signal.

```
// Reset the instrument to start from an initial state
*RST; *CLS

// Set the RF signal frequency and level
SOURce:FREQuency:CW 4000000000
SOURce:POWer:POWer: -25

// Configure the chirp modulation settings
// set the pulse parameters and the trigger mode
// query the compression ratio
// activate RF signal output

// Trigger a continuous chirp modulated signal
SOURce:CHIRp:TRIGger:MODE AUTO
SOURce:CHIRp:DIRectioN UP
SOURce:CHIRp:PULSe:PERiod 0.00001
SOURce:CHIRp:PULSe:WIDTh 0.000008
SOURce:CHIRp:BANDwidth 2000
SOURce:CHIRp:COMPressioN:RATio?
// Response: 0.01
SOURce:CHIRp:STAtE 1
OUTPut1:STAtE 1

// Trigger a single chirp modulation signal
SOURce:CHIRp:TRIGger:MODE SING
SOURce:CHIRp:DIRectioN DOWN
SOURce:CHIRp:PULSe:PERiod 0.00002
SOURce:CHIRp:PULSe:WIDTh 0.000002
SOURce:CHIRp:BANDwidth 5000
SOURce:CHIRp:STAtE 1
SOURce:CHIRp:TRIGger:IMMediate

// Alternatively configure the chirp modulation settings
// using an external pulse signal.
// Select the trigger mode, set the polarity of the external signal,
// select the impedance of the external pulse signal input
SOURce:CHIRp:TRIGger:MODE EXT
SOURce:CHIRp:TRIGger:EXternal:POLarity NORMal
SOURce:CHIRp:TRIGger:EXternal:IMPEDance G10K
SOURce:CHIRp:STAtE 1
```

The following commands are available:

[:SOURce<hw>]:CHIRp:BANDwidth	592
[:SOURce<hw>]:CHIRp:COMPressioN:RATio?	592
[:SOURce<hw>]:CHIRp:DIRectioN	592
[:SOURce<hw>]:CHIRp:PULSe:PERiod	592
[:SOURce<hw>]:CHIRp:PULSe:WIDTh	593

[:SOURce<hw>]:CHIRp:STATe.....	593
[:SOURce<hw>]:CHIRp:TRIGger:IMMediate.....	593
[:SOURce<hw>]:CHIRp:TRIGger:MODE.....	593

[:SOURce<hw>]:CHIRp:BANDwidth <Bandwidth>

Sets the modulation bandwidth of the chirp modulated signal.

Parameters:

<Bandwidth>	float
Range:	0 to Depends on hardware variant
Increment:	0.01
*RST:	1E3

Example: See [Example"Perform chirp modulation"](#) on page 591.

Manual operation: See ["Bandwidth"](#) on page 94

[:SOURce<hw>]:CHIRp:COMPression:RATio?

Queries the pulse compression ratio (= product of pulse width (s) and bandwidth (Hz)).

Return values:

<Ratio>	float
Range:	0 to 80E6
Increment:	0.01

Example: See [Example"Perform chirp modulation"](#) on page 591.

Usage: Query only

Manual operation: See ["Compression Ratio"](#) on page 95

[:SOURce<hw>]:CHIRp:DIRection <Direction>

Selects the direction of the chirp modulation.

Parameters:

<Direction>	DOWN UP
*RST:	UP

Example: See [Example"Perform chirp modulation"](#) on page 591.

Manual operation: See ["Direction"](#) on page 93

[:SOURce<hw>]:CHIRp:PULSe:PERiod <Period>

Sets the period of the generated modulation chirp. The period determines the repetition frequency of the internal signal.

Parameters:

<Period> float
 Range: 5E-6 (2E-7 with K23) to 100
 Increment: 1E-6
 *RST: 10E-6

Example: See [Example"Perform chirp modulation"](#) on page 591.

Manual operation: See ["Pulse Period"](#) on page 94

[SOURce<hw>]:CHIRp:PULSe:WIDTh <Width>

Sets the width of the generated pulse. The pulse width must be at least 1us less than the set pulse period.

Parameters:

<Width> float
 Range: 2E-6 (1E-7 with K23) to 100
 Increment: 1E-6
 *RST: 2E-6

Example: See [Example"Perform chirp modulation"](#) on page 591.

Manual operation: See ["Pulse Width"](#) on page 95

[SOURce<hw>]:CHIRp:STATe <State>

Activates the generation of a chirp modulation signal.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example"Perform chirp modulation"](#) on page 591.

Manual operation: See ["State"](#) on page 93

[SOURce<hw>]:CHIRp:TRIGger:IMMediate

Immediately starts the chirp signal generation.

Example: See [Example"Perform chirp modulation"](#) on page 591.

Usage: Event

Manual operation: See ["Execute Single Trigger"](#) on page 95

[SOURce<hw>]:CHIRp:TRIGger:MODE <Mode>

Selects the trigger mode for the chirp modulation signal.

Parameters:

<Mode> AUTO | EXTeRnal | EGATe | SINGle | ESINGle
 *RST: AUTO

Example: See [Example "Perform chirp modulation"](#) on page 591.

Manual operation: See ["Trigger Mode"](#) on page 95

14.17.1.4 SOURce:FM subsystem

Option: R&S SMAB-K720

The FM subsystem contains the commands for setting the frequency modulation.

Example: Creating a frequency modulated RF signal

Using the internal LF generator, the following command sequence configures a frequency modulated signal.

```
// Reset the instrument to start from a defined state
*RST

// Set RF frequency and amplitude
SOURce1:FREQuency:CW 6000000000
SOURce1:POWeR:LEVel:IMMediate:AMPLitude -25

// Configure the modulation signal
SOURce1:LFOutput1:SHAPE SINE
SOURce1:LFOutput1:FREQuency 20000

// Configure the frequency modulation settings and switch FM on
SOURce1:FM1:SOURce LF1
SOURce1:FM1:DEVIation 1000
SOURce1:FM:RATio 40
SOURce1:FM:MODE LNOise
SOURce1:FM1:STATe 1

// Switch on LF and RF signal output
SOURce1:LFOutput1:STATe 1
OUTPut1:STATe 1
```

Example: Using combined LF signals

Using the internal LF generators of both paths, the following command sequences configure a frequency modulated signal with determined deviations.

```
// Configure the FM modulation settings with combined LF signal sources
SOURce1:FM1:SOURce LF1
SOURce1:FM1:DEVIation 1000
// Select the modulation signal source for the second path
SOURce1:FM2:SOURce LF2
// Combine the signals of both paths with fixed total deviation depth
```

```

SOURce1:FM1:DEVIation:MODE TOT
SOURce1:FM1:DEVIation:SUM 5000

// Query the deviation depth of modulation signal in the second path
SOURce1:FM2:DEVIation?
// Response: 4000

// Combine the signals of both paths with fixed ratio
SOURce1:FM1:DEVIation:MODE RAT
SOURce1:FM1:RATio 100
SOURce1:FM2:DEVIation 10000

// Query the deviation depth of modulation signal in the first path
SOURce1:AM1:DEVIation?
// Response: 1000

SOURce1:FM1:STATe 1
SOURce1:FM2:STATe 1

```

Example: Using an external signal source

Alternatively configure the frequency modulation settings with an external modulation signal.

```

// Reset the instrument to start from a defined state
*RST

// Set RF frequency and amplitude
SOURce1:FREQuency:CW 6000000000
SOURce1:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the frequency modulation settings and switch FM on
SOURce1:FM1:SOURce EXT1
SOURce1:FM1:DEVIation 5000

// Query the input sensitivity at the external modulation input
:SOURce1:FM1:SENSitivity?
// Response: 1000
// since the voltage value for full modulation is 1V,
// the resulting sensitivity is precisely 5000 Hz/V.

// Switch on FM and RF signal output
SOURce1:FM1:STATe 1
OUTPut1:STATe 1

```

The following commands are available:

[:SOURce<hw>]:FM<ch>:STATe	596
[:SOURce<hw>]:FM<ch>[:DEVIation]	596
[:SOURce<hw>]:FM<ch>:SOURce	596
[:SOURce<hw>]:FM:DEVIation:MODE	597
[:SOURce<hw>]:FM:DEVIation:SUM	597

[:SOURce<hw>]:FM:RATio.....	598
[:SOURce<hw>]:FM:MODE.....	598
[:SOURce<hw>]:FM:SENSitivity?.....	598

`[:SOURce<hw>]:FM<ch>:STATe <State>`

Activates frequency modulation.

Suffix:

FM<ch> 1..2
determines the modulation signal channel.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: See [Example "Creating a frequency modulated RF signal"](#) on page 594.

Manual operation: See ["State"](#) on page 85

`[:SOURce<hw>]:FM<ch>[:DEViation] <Deviation>`

Sets the modulation deviation of the frequency modulation in Hz.

Suffix:

FM<ch> 1|2
Modulation signal channel

Parameters:

<Deviation> float
The maximum deviation depends on the RF frequency and the selected modulation mode (see data sheet).
Range: 0 to max
Increment: 0.01
*RST: 1E3

Example: See [Example "Creating a frequency modulated RF signal"](#) on page 594.

Manual operation: See ["Deviation"](#) on page 86

`[:SOURce<hw>]:FM<ch>:SOURce <Source>`

Selects the modulation source for frequency modulation.

Suffix:

FM<ch> 1|2
Modulation signal channel.

Parameters:

<Source> LF1 | LF2 | NOISe | EXT1 | INTernal | EXTernal | EXT2

LF1|LF2

Uses an internally generated LF signal.

INTernal = LF1

Works like `LF1`

EXTernal

Works like `EXT1`

EXT1|EXT2

Uses an externally supplied LF signal.

NOISe

Uses the internally generated noise signal.

*RST: LF1 <FM1>; LF2 <FM2>

Example: See [Example"Creating a frequency modulated RF signal"](#) on page 594.

Manual operation: See ["Source"](#) on page 85

[[:SOURce<hw>]:FM:DEVIation:MODE <FmDevMode>

Selects the coupling mode. The coupling mode parameter also determines the mode for fixing the total deviation.

Parameters:

<FmDevMode> UNCoupled | TOTal | RATio

UNCoupled

Does not couple the LF signals.

The deviation values of both paths are independent.

TOTal

Couples the deviation of both paths.

RATio

Couples the deviation ratio of both paths

*RST: UNCoupled

Example: See [Example"Using combined LF signals"](#) on page 594.

Manual operation: See [" Deviation Mode"](#) on page 86

[[:SOURce<hw>]:FM:DEVIation:SUM <FmDevSum>

Sets the total deviation of the LF signal when using combined signal sources in frequency modulation.

Parameters:

<FmDevSum> float
 Range: 0 to 40E6
 Increment: 0.01
 *RST: 1E3

Example: See [Example"Using combined LF signals"](#) on page 594.

Manual operation: See [" Total Deviation"](#) on page 86

[[:SOURce<hw>]:FM:RATio <Ratio>

Sets the deviation ratio (path2 to path1) in percent.

Parameters:

<Ratio> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 100

Example: See [Example"Creating a frequency modulated RF signal"](#) on page 594.

Manual operation: See [" Ratio Path2/Path1"](#) on page 86

[[:SOURce<hw>]:FM:MODE <Mode>

Selects the mode for the frequency modulation.

Parameters:

<Mode> HBANdwidth | LNOise
HBANdwidth
 Selects maximum range for modulation bandwidth.
LNOise
 Selects optimized phase noise and spurious characteristics with reduced modulation bandwidth and FM deviation.
 *RST: HBANdwidth

Example: See [Example"Creating a frequency modulated RF signal"](#) on page 594.

Manual operation: See ["Mode"](#) on page 87

[[:SOURce<hw>]:FM:SENSitivity?

Queries the sensitivity of the externally supplied signal for frequency modulation. The sensitivity depends on the set modulation deviation.

Return values:

<Sensitivity> float
 Sensitivity in Hz/V.
 It is assigned to the voltage value for full modulation of the input.
 Range: 0 to max
 Increment: 0.01

Example: See [Example"Using an external signal source"](#) on page 595.

Usage: Query only

14.17.1.5 SOURce:PM subsystem

Option: R&S SMAB-K720

The PM subsystem contains the commands for setting the phase modulation. You can configure the internal modulation source (LF generator) with the commands listed in [Chapter 14.17.6, "SOURce:LFOutput subsystem"](#), on page 674 .

Example: Performing phase modulation

The following example shows a command sequence to perform phase modulation.

```
// Reset the instrument to start from an initial state
*RST; *CLS

// Set the RF signal frequency and level
SOURce:FREQuency:CW 4000000000
SOURce:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the phase modulation settings
SOURce1:LFOutput1:SHAPE SINE
SOURce1:LFOutput1:FREQuency 1000

// Select the LF signal generated by the internal modulation generator
// or the internally generated noise signal
SOURce1:PM1:DEVIation 1
SOURce1:PM1:SOURce LF1
// SOURce1:PM1:SOURce INTernal
// SOURce1:PM1:SOURce NOISe
SOURce1:PM1:RATio 40
SOURce1:PM1:MODE HBAN

// Alternatively configure the phase modulation settings for an
// external modulation source and query the input sensitivity.
SOURce1:PM1:SOURce EXT1
// SOURce1:PM1:SOURce EXTernal
SOURce1:PM1:DEVIation 1
SOURce1:PM1:SENSitivity?
// Response: 1
// since the voltage value for full modulation is 1V,
// the resulting sensitivity is precisely 1RAD/V.

// Activate the signal output
SOURce1:PM1:STATe 1
OUTPut1:STATe 1
```

Example: Using combined LF signals

Using the internal LF generators of both paths, the following command sequences configure an phase modulated signal with determined deviations.

```
// Configure the Phase modulation settings with combined LF signal sources
SOURce1:PM1:SOURce LF1
SOURce1:PM1:DEVIation 1.5
// Select the modulation signal source for the second path
SOURce1:PM2:SOURce LF2
// Combine the signals of both paths with fixed total deviation depth
SOURce1:PM1:DEVIation:MODE TOT
SOURce1:PM1:DEVIation:SUM 2

// Query the deviation depth of the modulation signal in the second path
SOURce1:PM2:DEVIation?
// Response: 0.5

// Combine the signals of both paths with fixed ratio
SOURce1:PM1:DEVIation:MODE RAT
SOURce1:PM1:RATio 80
SOURce1:PM2:DEVIation?
// Response: 1.2

// Query the deviation depth of modulation signal in the first path
SOURce1:PM1:DEVIation?
// Response: 1.5

SOURce1:FM1:STATe 1
SOURce1:FM2:STATe 1
```

The following commands are available:

[:SOURce<hw>]:PM<ch>:STATe	600
[:SOURce<hw>]:PM<ch>:SOURce	601
[:SOURce<hw>]:PM:MODE	601
[:SOURce<hw>]:PM:DEVIation:MODE	602
[:SOURce<hw>]:PM:DEVIation:SUM	602
[:SOURce<hw>]:PM:RATio	602
[:SOURce<hw>]:PM:SENSitivity?	602
[:SOURce]:PM<ch>[:DEVIation]	603

[\[:SOURce<hw>\]:PM<ch>:STATe <State>](#)

Activates phase modulation.

Activation of phase modulation deactivates frequency modulation.

Suffix:

PM<ch> 1|2
 Sets the modulation signal channel.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: See [Example"Performing phase modulation"](#) on page 599.

Manual operation: See ["State"](#) on page 85

[[:SOURce<hw>]:PM<ch>:SOURce <Source>

Selects the modulation source for phase modulation signal.

Suffix:

PM<ch> 1|2
Sets the modulation signal channel.

Parameters:

<Source> LF1 | LF2 | NOISe | EXT1 | EXT2 | INTernal | EXTernal

LF1|LF2

Uses an internally generated LF signal.

EXT1|EXT2

Uses an externally supplied LF signal.

NOISe

Uses the internally generated noise signal.

INTernal

Uses the internally generated signal of LF1.

EXTernal

Uses an external LF signal (EXT1).

*RST: LF1 <PM1>; LF2 <PM2>

Example: See [Example"Performing phase modulation"](#) on page 599.

Manual operation: See ["Source"](#) on page 85

[[:SOURce<hw>]:PM:MODE <Mode>

Selects the mode for the phase modulation.

Parameters:

<Mode> HBANdwidth | HDEViation | LNOise

HBANdwidth

Sets the maximum available bandwidth.

HDEViation

Sets the maximum range for Φ M deviation.

LNOise

Selects a phase modulation mode with phase noise and spurious characteristics close to CW mode.

*RST: HBANdwidth

Example: See [Example"Performing phase modulation"](#) on page 599.

Manual operation: See ["Mode"](#) on page 88

[[:SOURce<hw>]:PM:DEVIation:MODE <PmDevMode>

Selects the coupling mode. The coupling mode parameter also determines the mode for fixing the total deviation.

Parameters:

<PmDevMode> UNCoupled | TOTal | RATio

UNCoupled

Does not couple the LF signals.

The deviation values of both paths are independent.

TOTal

Couples the deviation of both paths.

RATio

Couples the deviation ratio of both paths

*RST: UNCoupled

Example: See [Example"Using combined LF signals"](#) on page 599

Manual operation: See [" Deviation Mode"](#) on page 87

[[:SOURce<hw>]:PM:DEVIation:SUM <PmDevSum>

Sets the total deviation of the LF signal when using combined signal sources in phase modulation.

Parameters:

<PmDevSum> float
 Range: 0 to max
 Increment: 1E-6
 *RST: 1

Example: See [Example"Using combined LF signals"](#) on page 599

Manual operation: See [" Total Deviation"](#) on page 88

[[:SOURce<hw>]:PM:RATio <Ratio>

Sets the deviation ratio (path2 to path1) in percent.

Parameters:

<Ratio> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 100

Example: See [Example"Performing phase modulation"](#) on page 599.

Manual operation: See [" Ratio Path2/Path1"](#) on page 88

[[:SOURce<hw>]:PM:SENSitivity?

Queries the sensitivity of the externally applied signal for phase modulation.

The returned value reports the sensitivity in RAD/V. It is assigned to the voltage value for full modulation of the input.

Return values:

<Sensitivity> float

Example: See [Example "Performing phase modulation"](#) on page 599.

Usage: Query only

[[:SOURce]:PM<ch>[:DEViation] <Deviation>

Sets the modulation deviation of the phase modulation in RAD.

Parameters:

<Deviation> float

The maximal deviation depends on the RF frequency and the selected modulation mode (see data sheet).

Range: 0 to max

Increment: 1

*RST: 1

Default unit: RAD

Example: See [Example "Performing phase modulation"](#) on page 599.

Manual operation: See ["Deviation"](#) on page 87

14.17.1.6 SOURce:PULM subsystem

Option: see [Chapter 5.1, "Required options"](#), on page 79.

The PULM subsystem contains the commands for setting the pulse modulation.

- [Pulse modulation settings](#).....603
- [Pulse train settings](#).....609
- [Pulse train data exchange](#).....612

Pulse modulation settings

With the commands described in this section, you can configure the settings for pulse modulation, select the trigger mode and determine delay times for the pulse modulation signal.

Example: Perform pulse modulation

The example shows a command sequence to perform pulse modulation.

```
// Reset the instrument to start from an initial state
*RST; *CLS

// Set the RF signal frequency and level
SOURce:FREQuency:CW 4000000000
SOURce:POWer:LEVel:IMMediate:AMPLitude -25
```

```

// Configure the pulse modulation settings
// Select the internal modulation generator,
// set trigger mode, select pulse mode, transition type

// Trigger a single pulse

SOURce:PULM:SOURce INT
SOURce:PULM:TRIGger:MODE SING
SOURce:PULM:MODE DOUB
SOURce:PULM:TTYPe SMO

SOURce:PULM:TRIG:IMM

// Alternatively configure the pulse modulation settings for
// external modulation source
// Select the source, set the polarity of the external signal,
// select the impedance for the external pulse modulation input/
// for the external pulse modulation trigger input
SOURce:PULM:SOURce EXT
SOURce:PULM:POLarity NORMal
SOURce:PULM:IMPedance G1K

// Configure the pulse generator settings
// Set pulse period, width, and delay
SOURce:PULM:PERiod 10 us
SOURce:PULM:WIDTh 8 us
SOURce:PULM:DOUBle:WIDTh 0.0000012
SOURce:PULM:DOUBle:DELay 0.0000045

// Activate the signal output
SOURce:PGENERator:OUTPut:STATe 1
SOURce:PULM:STATe 1
OUTPut1:STATe 1

```

The following commands are available:

[SOURce<hw>]:PULM:MODE.....	605
[SOURce<hw>]:PULM:TRIGger:MODE.....	605
[SOURce]:PULM[:INTernall][:TRAIIn]:TRIGger:IMMEDIATE.....	605
[SOURce<hw>]:PULM:PERiod.....	605
[SOURce<hw>]:PULM:WIDTh.....	606
[SOURce<hw>]:PULM:DELay.....	606
[SOURce<hw>]:PULM:DOUBle:DELay.....	606
[SOURce<hw>]:PULM:DOUBle:WIDTh.....	607
[SOURce<hw>]:PULM:DOUBle:STATe.....	607
[SOURce<hw>]:PULM:STATe.....	607
[SOURce<hw>]:PULM:SOURce.....	607
[SOURce<hw>]:PULM:TTYPe.....	607
[SOURce<hw>]:PULM:POLarity.....	608
[SOURce<hw>]:PULM:IMPedance.....	608
[SOURce<hw>]:PULM:THReshold.....	608

[:SOURce<hw>]:PULM:MODE <Mode>

Selects the mode for the pulse modulation.

Parameters:

<Mode> SINGle | DOUBle | PTRain

SINGle
Generates a single pulse.

DOUBle
Generates two pulses within one pulse period.

PTRain
Generates a user-defined pulse train.
Specify the pulse sequence with the commands:
[\[:SOURce<hw>\]:PULM:TRAIIn:ONTime](#)
[\[:SOURce<hw>\]:PULM:TRAIIn:OFFTime](#)
[\[:SOURce<hw>\]:PULM:TRAIIn:REPetition](#)
 *RST: SINGle

Example: See [Example "Perform pulse modulation"](#) on page 603.

Options: PTRain requires R&S SMAB-K27

Manual operation: See ["Pulse Mode"](#) on page 98

[:SOURce<hw>]:PULM:TRIGger:MODE <Mode>

Selects a trigger mode - auto, single, external, external single or external gated - for generating the modulation signal.

Parameters:

<Mode> AUTO | EXTeRnal | EGATe | SINGle | ESINgle

*RST: AUTO

Example: See [Example "Perform pulse modulation"](#) on page 603.

Manual operation: See ["Trigger Mode"](#) on page 99

[:SOURce]:PULM[:INTernal][:TRAIIn]:TRIGger:IMMediate

If [\[:SOURce<hw>\]:PULM:TRIGger:MODE](#)SINGle, triggers the pulse generator.

Example: See [Example "Perform pulse modulation"](#) on page 603.

Manual operation: See ["Execute Single Trigger"](#) on page 102

[:SOURce<hw>]:PULM:PERiod <Period>

Sets the period of the generated pulse, that means the repetition frequency of the internally generated modulation signal.

Parameters:

<Period> float
 The minimum value depends on the installed options
 R&S SMAB-K22 or R&S SMAB-K23
 Range: 20E-9 to 100
 Increment: 5E-9
 *RST: 10E-6

Example: See [Example"Perform pulse modulation"](#) on page 603.

Manual operation: See ["Pulse Period"](#) on page 101

[SOURce<hw>]:PULM:WIDTH <Width>

Sets the width of the generated pulse, that means the pulse length. It must be at least 20ns less than the set pulse period.

Parameters:

<Width> float
 Range: 20E-9 to 100
 Increment: 10E-9
 *RST: 2E-6

Example: See [Example"Perform pulse modulation"](#) on page 603.

Manual operation: See ["Pulse Width"](#) on page 101

[SOURce<hw>]:PULM:DELay <Delay>

Sets the pulse delay.

Parameters:

<Delay> float
 *RST: 1ms

Example: See [Example"Perform pulse modulation"](#) on page 603.

Manual operation: See ["Pulse Delay"](#) on page 102

[SOURce<hw>]:PULM:DOUBLE:DELay <Delay>

Sets the delay from the start of the first pulse to the start of the second pulse.

Parameters:

<Delay> float
 *RST: 1E-6

Example: See [Example"Perform pulse modulation"](#) on page 603.

Manual operation: See ["Double Pulse Delay"](#) on page 102

[:SOURce<hw>]:PULM:DOUBLE:WIDTH <Width>

Sets the width of the second pulse.

Parameters:

<Width> float
Increment: 5E-9

Example: See [Example"Perform pulse modulation"](#) on page 603.

Manual operation: See ["Double Pulse Width"](#) on page 102

[:SOURce<hw>]:PULM:DOUBLE:STATE <State>

Provided for backward compatibility with former Rohde & Schwarz signal generators.

Works like the command `[:SOURce<hw>] :PULM:MODEDOUBLE`.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

[:SOURce<hw>]:PULM:STATE <State>

Activates pulse modulation.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: See [Example"Perform pulse modulation"](#) on page 603.

Manual operation: See ["State"](#) on page 83

[:SOURce<hw>]:PULM:SOURce <Source>

Selects between the internal (pulse generator) or an external pulse signal for the modulation.

Parameters:

<Source> INTernal | EXTernal
*RST: INTernal

Example: See [Example"Perform pulse modulation"](#) on page 603.

Manual operation: See ["Source"](#) on page 83

[:SOURce<hw>]:PULM:TTYPe <Source>

Sets the transition mode for the pulse signal.

Parameters:

<Source> SMOothed | FAST

SMOothed

flattens the slew rate, resulting in longer rise/fall times.

FAST

enables fast transitions with shortest rise and fall times.

*RST: FAST

Example: See [Example "Perform pulse modulation"](#) on page 603.

Manual operation: See ["Transition Type"](#) on page 84

[[:SOURce<hw>]:PULM:POLarity <Polarity>

Sets the polarity of the externally applied modulation signal.

Parameters:

<Polarity> NORMal | INVerted

NORMal

Suppresses the RF signal during the pulse pause.

INVerted

Suppresses the RF signal during the pulse.

*RST: NORMal

Example: See [Example "Perform pulse modulation"](#) on page 603.

Manual operation: See ["Polarity"](#) on page 110

[[:SOURce<hw>]:PULM:IMPedance <Impedance>

Sets the impedance for the external pulse trigger and pulse modulation input.

Parameters:

<Impedance> G50 | G10K

*RST: G10K

Example: See [Example "Perform pulse modulation"](#) on page 603.

Manual operation: See ["Impedance"](#) on page 110

[[:SOURce<hw>]:PULM:THReshold <Threshold>

Sets the threshold for the input signal at the [Pulse Ext] connector.

Parameters:

<Threshold> float

Range: 0 to 2

Increment: 0.1

*RST: 1

Default unit: V

Example: SOURce:PULM:THReshold 1

Manual operation: See ["Threshold"](#) on page 110

Pulse train settings

Option: R&S SMAB-K27

This section describes the commands for the pulse train modulation and the associated file handling.

See [Chapter 5.4.4.2, "Pulse generator > pulse train settings"](#), on page 102.

Example: Generating a pulse train signal

The following settings are required to perform pulse train modulation.



Always create and select pulse train data list first before you activate the pulse train mode.

Otherwise, an error is displayed

```
*RST; *CLS

// Set the RF signal frequency and level
SOURce:FREQuency:CW 4000000000
SOURce:POWer:LEVel:IMMediate:AMPLitude -25

// Create a pulse train data list
// Select the directory
MMEM:CDIR '/var/user/'
SOURcel:PULM:TRAI:n:CATalog?
// my_pt
// Create and/or select the pulse train data file
SOURcel:PULM:TRAI:n:SElect "/var/user/pt"
// Enter the pulse train data
SOURce:PULM:TRAI:n:ONTime 0.0001,0.00025,0.0001
SOURce:PULM:TRAI:n:OFFTime 500us,500us,300us
SOURce:PULM:TRAI:n:REPetition 2,0,3
// the second pulse is ignored

// Select pulse train mode
// Select the internal modulation generator and the pulse mode
SOURcel:PULM:SOURce INT
SOURcel:PULM:MODE PTR
SOURcel:PULM:TRIGger:MODE EXT
SOURcel:PGENerator:OUTPut:STATe 1
SOURcel:PGENerator:OUTPut:POLarity NORM
SOURce:PGENerator:OUTPut:STATe 1
SOURce:PULM:STATe 1
OUTPut1:STATe 1

// SOURcel:PULM:TRAI:n:CATalog?
// my_pt, pt
// SOURcel:PULM:TRAI:n:DEL "/var/user/my_pt"
```

The following commands are available:

<code>[SOURce<hw>]:PULM:TRAI:n:CATalog?</code>	610
<code>[SOURce<hw>]:PULM:TRAI:n:DELe</code>	610
<code>[SOURce<hw>]:PULM:TRAI:n:ONTime</code>	610
<code>[SOURce<hw>]:PULM:TRAI:n:OFFTime</code>	610
<code>[SOURce<hw>]:PULM:TRAI:n:REPetition:POINts?</code>	611
<code>[SOURce<hw>]:PULM:TRAI:n:ONTime:POINts?</code>	611
<code>[SOURce<hw>]:PULM:TRAI:n:OFFTime:POINts?</code>	611
<code>[SOURce<hw>]:PULM:TRAI:n:REPetition</code>	611
<code>[SOURce<hw>]:PULM:TRAI:n:SElect</code>	611

`[SOURce<hw>]:PULM:TRAI:n:CATalog?`

Queries the available pulse train files in the specified directory.

Return values:

<Catalog> string
 List of list filenames, separated by commas

Example: See [Example "Generating a pulse train signal"](#) on page 609.

Usage: Query only

Manual operation: See ["Pulse Train Data"](#) on page 104

`[SOURce<hw>]:PULM:TRAI:n:DELe` <Filename>

Deletes the specified pulse train file.

Setting parameters:

<Filename> string
 Filename or complete file path; file extension is optional.

Example: See [Example "Generating a pulse train signal"](#) on page 609.

Usage: Setting only

Manual operation: See ["Pulse Train Data"](#) on page 104
 See ["Edit Pulse Train Data"](#) on page 105

`[SOURce<hw>]:PULM:TRAI:n:ONTime` <OnTime>

`[SOURce<hw>]:PULM:TRAI:n:OFFTime` <OffTime>

Enters the pulse on/off times values in the selected list.

Parameters:

<OffTime> Offtime#1{, Offtime#2, ...} | binary block data
 List of comma-separated numeric values or binary block data, where:
 The list of numbers can be of any length.
 In binary block format, 8 (4) bytes are always interpreted as a floating-point number with double accuracy.

See [:FORMat \[:DATA\]](#) on page 504 for details.

The maximum length is 2047 values.

Range: 0 ns to 5 ms

Example: See [Example"Generating a pulse train signal"](#) on page 609.

Manual operation: See ["Edit Pulse Train Data"](#) on page 105

[:SOURce<hw>]:PULM:TRAI:n:REPetition:POINts?

[:SOURce<hw>]:PULM:TRAI:n:ONTime:POINts?

[:SOURce<hw>]:PULM:TRAI:n:OFFTime:POINts?

Queries the number of on and off time entries and repetitions in the selected list.

Return values:

<Points> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example"Generating a pulse train signal"](#) on page 609.

Usage: Query only

[:SOURce<hw>]:PULM:TRAI:n:REPetition <Repetition>

Sets the number of repetitions for each pulse on/off time value pair.

Parameters:

<Repetition> Repetition#1{, Repetition#2, ...}
 0 = ignore value pair
 Set "Repetition = 0" to skip a particular pulse without deleting the pulse on/off time value pair
 Range: 0 to 65535

Example: See [Example"Generating a pulse train signal"](#) on page 609.

Manual operation: See ["Edit Pulse Train Data"](#) on page 105

[:SOURce<hw>]:PULM:TRAI:n:SELEct <Filename>

Selects or creates a data list in pulse train mode.

If the list with the selected name does not exist, a new list is created.

Parameters:

<Filename> string
 Filename or complete file path; file extension can be omitted.

Example: See [Example"Generating a pulse train signal"](#) on page 609.

Manual operation: See ["Pulse Train Data"](#) on page 104
 See ["File Name"](#) on page 109
 See ["Functions for handling of data lists"](#) on page 320

Pulse train data exchange

Option: R&S SMAB-K27

With the following commands, you can configure pulse trains in ASCII format and export or import them accordingly.

```
SOURcel:PULM:SOURce INT
SOURcel:PULM:MODE PTR
SOURcel:PULM:TRAI:n:SElect "/var/user/pt"
SOURcel:PULM:STATe 1

SOURcel:PULM:TRAI:n:DEXChange:MODE EXP
SOURcel:PULM:TRAI:n:DEXChange:AFILe:EXTension TXT
SOURcel:PULM:TRAI:n:DEXChange:AFILe:SEParator:DECimal DOT
SOURcel:PULM:TRAI:n:DEXChange:AFILe:SEParator:COLumn SEM
SOURcel:PULM:TRAI:n:DEXChange:AFILe:SEParator:COLumn COMM
SOURcel:PULM:TRAI:n:DEXChange:SElect "/var/user/pt.pulstrn"
SOURcel:PULM:TRAI:n:DEXChange:AFILe:SElect "/var/user/pt_script.txt"
SOURcel:PULM:TRAI:n:DEXChange:EXECute
```

The following commands are available:

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:MODE	612
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:EXTension	612
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SEParator:DECimal	613
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SEParator:COLumn	613
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:CATalog?	613
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SElect	613
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:SElect	614
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:EXECute	614

[\[:SOURce<hw>\]:PULM:TRAI:n:DEXChange:MODE <Mode>](#)

Determines the import or export of a list.

Specify the source or destination file with the command [\[:SOURce<hw>\]:PULM:TRAI:n:DEXChange:SElect](#).

Parameters:

<Mode> IMPort | EXPort
 *RST: IMPort

Example: See ["Pulse train data exchange"](#) on page 612.

Manual operation: See ["Mode"](#) on page 107

[\[:SOURce<hw>\]:PULM:TRAI:n:DEXChange:AFILe:EXTension <Extension>](#)

Determines the extension of the ASCII file for import or export, or to query existing files.

Parameters:

<Extension> TXT | CSV
 *RST: TXT

Example: See ["Pulse train data exchange"](#) on page 612.

Manual operation: See ["ASCII File Settings"](#) on page 107

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SEParator:DECimal <Decimal>

Sets "." (decimal point) or "," (comma) as the decimal separator used in the ASCII data with floating-point numerals.

Parameters:

<Decimal> DOT | COMMa
 *RST: DOT

Example: See ["Pulse train data exchange"](#) on page 612.

Manual operation: See ["ASCII File Settings"](#) on page 107

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SEParator:COLumn <Column>

Selects the separator between the frequency and level column of the ASCII table.

Parameters:

<Column> TABulator | SEMicolon | COMMa | SPACe
 *RST: COMMa

Example: See ["Pulse train data exchange"](#) on page 612.

Manual operation: See ["ASCII File Settings"](#) on page 107

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:CATalog?

Queries the available ASCII files in the current or specified directory.

Return values:

<Catalog> string
 List of ASCII files *.txt or *.csv, separated by commas.

Example: See ["Pulse train data exchange"](#) on page 612.

Usage: Query only

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 108

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SElect <Filename>

Selects the ASCII file to be imported or exported.

Parameters:

<Filename> string
 Filename or complete file path; file extension can be omitted.

Example: See ["Pulse train data exchange"](#) on page 612.

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 108

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:SELEct <Filename>

Selects the ASCII file for import or export, containing a pulse train list.

Parameters:

<Filename> string
 Filename or complete file path; file extension can be omitted.

Example: See ["Pulse train data exchange"](#) on page 612.

Manual operation: See ["Select Source/Select ASCII Destination"](#) on page 108

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:EXECute

Usage: Event

Manual operation: See ["Import / Export"](#) on page 108

Executes the import or export of the selected list file, according to the transfer direction set with command `[:SOURce<hw>]:PULM:TRAI:n:DEXChange:MODE`.

14.17.2 Avionic standards subsystems

Option: see [Chapter 6.1, "Required options"](#), on page 125.

The following subsections describe all commands for avionic standard modulation of the RF signal. Divided into separate avionic subsystem command sections, you can configure ADF, ILS and VOR modulation.

Programming examples are given for general configuration and avionic standard-specific configuration tasks.

Placeholder <Subsystem>

To simplify the description of the remote control commands, the placeholder <Subsystem> is introduced. Depending on the avionic standard used as an entry standard, replace this placeholder <Subsystem> with for example `SOURce:ADF` for ADF.



The replacement of the place holder <Subsystem> is mandatory, i.e. remote control commands containing this placeholder are not recognized and accepted by the instrument.

Example:SCPI command `<subsystem>:STATe:`

- Entry Standard = ADF
SOURce:ADF:STATe
- Entry Standard = ILS
SOURce:ILS:STATe
- Entry Standard = VOR
SOURce:VOR:STATe
- Invalid command
<Subsystem>:STAT

Contents

• Programming examples	615
• General commands	619
• SOURce:ADF subsystem	622
• SOURce:ILS subsystem	625
• SOURce:VOR subsystem	647

14.17.2.1 Programming examples**Example: Saving and recalling a configuration**

This example shows how to query and load settings files, saved with the save/recall function for the ADF standard.

For other avionic standards, replace ADF by ILS or VOR.

```

SOURce1:ADF:PRESet
// Go to the "settings" directory.
MME:CDIR "/var/user/settings"
// List all files in the directory with extension *.adf.
SOURce1:ADF:SETTING:CATalog?
// adf_general, adf_comid

// Save the ADF configuration in the file "adf_general_latest.adf".
SOURce1:ADF:SETTING:STORe "/var/user/settings/adf_general_latest"
// Delete the file "adf_general.adf".
SOURce1:ADF:SETTING:DELeTe "/var/user/settings/adf_general"
SOURce1:ADF:SETTING:CATalog?
// adf_general_latest, adf_comid

// Load the file "adf_general_latest.adf".
SOURce1:ADF:SETTING:LOAD "/var/user/settings/adf_general_latest"

// Activate ADF signal generation.
SOURce1:ADF:STATe 1

```

Example: Configuring and generating a ADF signal

```
SOURcel:ADF:PRESet

// Configure ADF COM/ID settings.
SOURcel:ADF:COMid:PERiod 9
SOURcel:ADF:COMid:FREQuency 1020
SOURcel:ADF:COMid:DEPTh 11
SOURcel:ADF:COMid:TSCHEMA USER
SOURcel:ADF:COMid:DOT 0.11
SOURcel:ADF:COMid:DASH 0.29
SOURcel:ADF:COMid:SYMBOL 0.11
SOURcel:ADF:COMid:LETter 0.29
SOURcel:ADF:COMid:STATE 1

// Activate ADF signal generation.
SOURcel:ADF:STATe 1
```

Example: Configure and generate an ILS glide slope signal

```
SOURcel:BB:ILS:PRESet

// Configure ILS localizer general settings.
SOURcel:ILS:TYPE GS
SOURcel:ILS:GS:FREQuency:MODE USER
SOURcel:ILS:GS:FREQuency 334700000
SOURcel:ILS:GS:FREQuency:MODE ICAO
SOURcel:ILS:GS:ICAO:CHANnel?
// Response: CH18X
SOURcel:ILS:GS:FREQuency:SYNChronize 1
SOURcel:ILS:LOCALizer:ICAO:CHANnel?
// Response: CH18X
SOURcel:ILS:LOCALizer:FREQuency?
// Response: 108100000
SOURcel:ILS:GSLope:SOURce?
// Response: INT

// Configure ILS glide slope signal settings.
SOURcel:ILS:GS:MODE NORM
SOURcel:ILS:GS:DDM:POLarity P90_150
SOURcel:ILS:GS:ULObE:FREQuency 90
SOURcel:ILS:GS:LLObE:FREQuency 150
SOURcel:ILS:GS:PHASe 0

// Configure ILS glide slope amplitude settings.
SOURcel:ILS:GS:DDM:DIREction UP
SOURcel:ILS:GS:SDM 80
SOURcel:ILS:GS:DDM:COUPling FIX
SOURcel:ILS:GS:DDM:STEP DEC
SOURcel:ILS:GS:DDM:CURREnt 0
SOURcel:ILS:GS:DDM:DEPTh 0
SOURcel:ILS:GS:DDM:LOGarithmic 0
```



```
SOURcel:ILS:GS:DDM:PCT 0
```

```
// Activate ILS signal generation.  
SOURcel:ILS:STAt 1
```

Example: Configure and generate an ILS localizer signal

```
SOURcel:ILS:PRESet  
  
// Configure ILS localizer general settings.  
SOURcel:ILS:TYPE LOC  
SOURcel:ILS:LOCalizer:FREQuency:MODE USER  
SOURcel:ILS:LOCalizer:FREQuency 108100000  
SOURcel:ILS:LOCalizer:FREQuency:SYNChronize 1  
SOURcel:ILS:GS:FREQuency?  
// Response: 108100000  
SOURcel:ILS:LOCalizer:FREQuency:MODE ICAO  
SOURcel:ILS:LOCalizer:ICAO:CHANnel CH26Y  
SOURcel:ILS:GS:ICAO:CHANnel?  
// Response: CH26Y  
SOURcel:ILS:GS:FREQuency?  
// Response: 108950000  
SOURcel:ILS:LOCalizer:SOURce?  
// Response: INT  
  
// Configure ILS localizer signal settings.  
SOURcel:ILS:LOCalizer:MODE NORM  
SOURcel:ILS:LOCalizer:DDM:POLarity P90_150  
SOURcel:ILS:LOCalizer:LLOBe:FREQuency 90  
SOURcel:ILS:LOCalizer:RLOBe:FREQuency 150  
SOURcel:ILS:LOCalizer:PHASe 0  
  
// Configure ILS localizer amplitude settings.  
SOURcel:ILS:LOCalizer:DDM:DIRection LEFT  
SOURcel:ILS:LOCalizer:SDM 40  
SOURcel:ILS:LOCalizer:DDM:COUpling FIX  
SOURcel:ILS:LOCalizer:DDM:STEP DEC  
SOURcel:ILS:LOCalizer:DDM:CURREnt 0  
SOURcel:ILS:LOCalizer:DDM:DEPTh 0  
SOURcel:ILS:LOCalizer:DDM:LOGarithmic 0  
SOURcel:ILS:LOCalizer:DDM:PCT 0  
  
// Configure ILS localizer COM/ID settings.  
SOURcel:ILS:LOCalizer:COMid:CODE "MUC"  
SOURcel:ILS:LOCalizer:COMid:PERiod 9  
SOURcel:ILS:LOCalizer:COMid:FREQuency 1020  
SOURcel:ILS:LOCalizer:COMid:DEPTh 10  
SOURcel:ILS:LOCalizer:COMid:TSCHEMA USER  
SOURcel:ILS:LOCalizer:COMid:DOT 0.11  
SOURcel:ILS:LOCalizer:COMid:DASH 0.29  
SOURcel:ILS:LOCalizer:COMid:SYMBOL 0.11  
SOURcel:ILS:LOCalizer:COMid:LETter 0.29
```

```

SOURCE1:ILS:LOCALizer:COMid:STATE 1

// Activate ILS signal generation.
SOURCE1:ILS:STATE 1

```

Example: Configure and generate an ILS marker beacons signal

```

SOURCE1:ILS:PRESet

// Configure ILS marker beacons general settings.
SOURCE1:ILS:TYPE MBE
SOURCE1:ILS:MBEacon:FREQuency:MODE USER
SOURCE1:ILS:MBEacon:FREQuency 75000000
SOURCE1:ILS:MBEacon:MARKer:FREQuency 400
SOURCE1:ILS:MBEacon:MARKer:DEPTh 95
SOURCE1:ILS:MBEacon:MARKer:PULSed?
// Response: "0"

// Configure ILS marker beacons COM/ID settings.
SOURCE1:ILS:MBEacon:COMid:CODE "MUC"
SOURCE1:ILS:MBEacon:COMid:PERiod 9
SOURCE1:ILS:MBEacon:COMid:FREQuency 1020
SOURCE1:ILS:MBEacon:COMid:DEPTh 5
SOURCE1:ILS:MBEacon:COMid:TSCHEMA USER
SOURCE1:ILS:MBEacon:COMid:DOT 0.11
SOURCE1:ILS:MBEacon:COMid:DASH 0.29
SOURCE1:ILS:MBEacon:COMid:SYMBOL 0.11
SOURCE1:ILS:MBEacon:COMid:LETTer 0.29
SOURCE1:ILS:MBEacon:COMid:STATE 1

// Activate ILS signal generation.
SOURCE1:BB:ILS:STATE 1

```

Example: Configure and generate a VOR signal

```

SOURCE1:VOR:PRESet

// Configure VOR general settings.
SOURCE1:VOR:FREQuency:MODE USER
SOURCE1:VOR:FREQuency 108000000
SOURCE1:VOR:FREQuency:MODE ICAO
SOURCE1:VOR:ICAO:CHANnel?
// Response: RCH17X
SOURCE1:VOR:SOURce?
// Response: INT

// Configure VOR signal settings.
SOURCE1:VOR:MODE NORM
SOURCE1:VOR:VAR:FREQuency 30
SOURCE1:VOR:VAR:DEPTh 30
SOURCE1:VOR:SUBCarrier:FREQuency 9960
SOURCE1:VOR:SUBCarrier:DEPTh 30

```

```

SOURCE1:VOR:REfERENCE:DEVIation 480

// Configure VOR position settings.
SOURCE1:VOR:BANGLe 1
SOURCE1:VOR:BANGLe:DIRection FROM

// Configure VOR COM/ID settings.
SOURCE1:VOR:COMid:PERiod 9
SOURCE1:VOR:COMid:FREQuency 1020
SOURCE1:VOR:COMid:DEPTh 11
SOURCE1:VOR:COMid:TSCHEMA USER
SOURCE1:VOR:COMid:DOT 0.11
SOURCE1:VOR:COMid:DASH 0.29
SOURCE1:VOR:COMid:SYMBOL 0.11
SOURCE1:VOR:COMid:LETTer 0.29
SOURCE1:VOR:COMid:STATe 1

// Activate VOR signal generation.
SOURCE1:VOR:STATe 1

```

14.17.2.2 General commands

<subsystem>:PRESet.....	620
[[:SOURCE<hw>]:ADF:PRESet.....	620
[[:SOURCE<hw>]:ILS:PRESet.....	620
[[:SOURCE<hw>]:VOR:PRESet.....	620
<subsystem>:SETTING:CATalog.....	620
[[:SOURCE<hw>]:ADF:SETTING:CATalog.....	620
[[:SOURCE<hw>]:ILS:SETTING:CATalog?.....	620
[[:SOURCE<hw>]:VOR:SETTING:CATalog?.....	620
<subsystem>:SETTING:DELeTe.....	620
[[:SOURCE<hw>]:ADF:SETTING:DELeTe.....	620
[[:SOURCE<hw>]:ILS:SETTING:DELeTe.....	620
[[:SOURCE<hw>]:VOR:SETTING:DELeTe.....	620
<subsystem>:SETTING:LOAD.....	620
[[:SOURCE<hw>]:ADF:SETTING:LOAD.....	620
[[:SOURCE<hw>]:ILS:SETTING:LOAD.....	620
[[:SOURCE<hw>]:VOR:SETTING:LOAD.....	620
<subsystem>:SETTING:STORe.....	621
[[:SOURCE<hw>]:ADF:SETTING:STORe.....	621
[[:SOURCE<hw>]:ILS:SETTING:STORe.....	621
[[:SOURCE<hw>]:VOR:SETTING:STORe.....	621
<subsystem>:STATe.....	621
[[:SOURCE<hw>]:ADF:STATe.....	621
[[:SOURCE<hw>]:ILS:STATe.....	621
[[:SOURCE<hw>]:VOR:STATe.....	621
<subsystem>:FREQuency:SYNChronize:STATe.....	621
[[:SOURCE<hw>]:ILS[:GS GSLope]:FREQuency:SYNChronize[:STATe].....	621
[[:SOURCE<hw>]:ILS:LOCalizer:FREQuency:SYNChronize[:STATe].....	621

```
<subsystem>:PRESet
[:SOURce<hw>]:ADF:PRESet
[:SOURce<hw>]:ILS:PRESet
[:SOURce<hw>]:VOR:PRESet
```

Sets the parameters of the digital standard to their default values (*RST values specified for the commands).

Not affected is the state set with the command `SOURce<hw>:VOR:STATe`.

Example: See [Example "Saving and recalling a configuration"](#) on page 615.

```
<subsystem>:SETTing:CATalog
[:SOURce<hw>]:ADF:SETTing:CATalog
[:SOURce<hw>]:ILS:SETTing:CATalog?
[:SOURce<hw>]:VOR:SETTing:CATalog?
```

Queries the files with settings in the default directory. Listed are files with the file extension *.adf/*.ils/*.vor.

Return values:

<FileNames> <filename1>,<filename2>,...
Returns a string of filenames separated by commas.

Example: See [Example "Saving and recalling a configuration"](#) on page 615.

Usage: Query only

```
<subsystem>:SETTing:DELeTe
[:SOURce<hw>]:ADF:SETTing:DELeTe <Filename>
[:SOURce<hw>]:ILS:SETTing:DELeTe <Filename>
[:SOURce<hw>]:VOR:SETTing:DELeTe <Filename>
```

Deletes the selected file from the default or the specified directory. Deleted are files with extension *.adf/*.ils/*.vor.

Setting parameters:

<Filename> "<filename>"
Filename or complete file path; file extension can be omitted

Example: See [Example "Saving and recalling a configuration"](#) on page 615.

Usage: Setting only

```
<subsystem>:SETTing:LOAD
[:SOURce<hw>]:ADF:SETTing:LOAD <Filename>
[:SOURce<hw>]:ILS:SETTing:LOAD <Filename>
[:SOURce<hw>]:VOR:SETTing:LOAD <Filename>
```

Loads the selected file from the default or the specified directory. Loaded are files with extension *.adf/*.ils/*.vor.

Parameters:

<Filename> "<filename>"
 Filename or complete file path; file extension can be omitted

Example: See [Example "Saving and recalling a configuration"](#) on page 615.

Usage: Setting only

<subsystem>:SETting:STORe

[[:SOURce<hw>]:ADF:SETting:STORe <Filename>

[[:SOURce<hw>]:ILS:SETting:STORe <Filename>

[[:SOURce<hw>]:VOR:SETting:STORe <Filename>

Saves the current settings into the selected file; the file extension (* .adf/* .ils/* .vor) is assigned automatically.

Parameters:

<Filename> "<filename>"
 Filename or complete file path

Example: See [Example "Saving and recalling a configuration"](#) on page 615.

Usage: Setting only

<subsystem>:STATe

[[:SOURce<hw>]:ADF:STATe <State>

[[:SOURce<hw>]:ILS:STATe <State>

[[:SOURce<hw>]:VOR:STATe <State>

Activates/deactivates the VOR modulation.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Saving and recalling a configuration"](#) on page 615.

<subsystem>:FREQuency:SYNChronize:STATe

[[:SOURce<hw>]:ILS[:GS|GSLope]:FREQuency:SYNChronize[:STATe] <Mode>

[[:SOURce<hw>]:ILS:LOCALizer:FREQuency:SYNChronize[:STATe] <Mode>

Activates synchronization of the ILS localizer ICAO channel with the ILS glide slope ICAO channel.

The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Parameters:

<Mode> 0 | 1 | OFF | ON
 *RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 617.

14.17.2.3 SOURce:ADF subsystem

Option: R&S SMAB-K25

The `SOURce:ADF` subsystem contains all commands for configuring the ADF signal.

Characteristics which are valid for all modulations and the LF output are configured in the `SOURce:LFOutput` subsystem. The signal is output at the LF connector.

Commands

<code>[SOURce<hw>]:ADF:COMid:CODE</code>	622
<code>[SOURce<hw>]:ADF:COMid:DASH</code>	622
<code>[SOURce<hw>]:ADF:COMid:DEPT</code>	623
<code>[SOURce<hw>]:ADF:COMid:DOT</code>	623
<code>[SOURce<hw>]:ADF:COMid:FREQuency</code>	623
<code>[SOURce<hw>]:ADF:COMid:LETTer</code>	623
<code>[SOURce<hw>]:ADF:COMid:PERiod</code>	624
<code>[SOURce<hw>]:ADF:COMid:SYMBol</code>	624
<code>[SOURce<hw>]:ADF:COMid:TSCHEMA</code>	624
<code>[SOURce<hw>]:ADF:COMid[:STATe]</code>	625

`[SOURce<hw>]:ADF:COMid:CODE <Code>`

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse code settings"](#), on page 811.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Parameters:

<Code> string

Example: See [Example "Configuring and generating a ADF signal"](#) on page 616.

Manual operation: See ["Code"](#) on page 166

`[SOURce<hw>]:ADF:COMid:DASH <Dash>`

Sets the length of a Morse code dash.

Parameters:

<Dash> float

Range: 50E-3 to 1

Increment: 1E-4

*RST: 300E-3

Example: See [Example "Configuring and generating a ADF signal"](#) on page 616.

Manual operation: See ["Dash Length"](#) on page 167

[[:SOURce<hw>]:ADF:COMid:DEPT_h <Depth>

Sets the AM modulation depth of the COM/ID signal.

Parameters:

<Depth> float
Range: 0 to 100
Increment: 0.1
*RST: 95

Example: See [Example"Configuring and generating a ADF signal"](#) on page 616.

Manual operation: See ["Depth"](#) on page 166

[[:SOURce<hw>]:ADF:COMid:DOT <Dot>

Sets the length of a Morse code dot.

Parameters:

<Dot> float
Range: 50E-3 to 1
Increment: 1E-4
*RST: 100E-3

Example: See [Example"Configuring and generating a ADF signal"](#) on page 616.

Manual operation: See ["Dot Length"](#) on page 166

[[:SOURce<hw>]:ADF:COMid:FREQuency <Frequency>

Sets the frequency of the COM/ID signal.

Parameters:

<Frequency> float
Range: 0.1 to 20E3
Increment: 0.01
*RST: 1020

Example: See [Example"Configuring and generating a ADF signal"](#) on page 616.

Manual operation: See ["Frequency"](#) on page 166

[[:SOURce<hw>]:ADF:COMid:LET_Ter <Letter>

Sets the length of a Morse code letter space.

Parameters:

<Letter> float
 Range: 50E-3 to 1
 Increment: 1E-4
 *RST: 300E-3

Example: See [Example"Configuring and generating a ADF signal"](#) on page 616.

Manual operation: See ["Letter Space"](#) on page 167

[SOURce<hw>]:ADF:COMid:PERiod <Period>

Sets the period of the COM/ID signal.

Parameters:

<Period> float
 Range: 0 to 120
 Increment: 1E-3
 *RST: 9

Example: See [Example"Configuring and generating a ADF signal"](#) on page 616.

Manual operation: See ["Period"](#) on page 166

[SOURce<hw>]:ADF:COMid:SYMBOL <Symbol>

Sets the length of the Morse code symbol space.

Parameters:

<Symbol> float
 Range: 50E-3 to 1
 Increment: 1E-4
 *RST: 100E-3

Example: See [Example"Configuring and generating a ADF signal"](#) on page 616.

Manual operation: See ["Symbol Space"](#) on page 167

[SOURce<hw>]:ADF:COMid:TSCHEMA <TSCHEMA>

Sets the time schema of the Morse code for the COM/ID signal.

Parameters:

<TSCHEMA> STD | USER
 *RST: STD

Example: See [Example"Configuring and generating a ADF signal"](#) on page 616.

Manual operation: See ["Time Schema"](#) on page 166

[[:SOURce<hw>]:ADF:COMid[:STATe] <State>

Enables/disables the COM/ID signal.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: See [Example "Configuring and generating a ADF signal"](#) on page 616.

Manual operation: See ["COM/ID State"](#) on page 166

14.17.2.4 SOURce:ILS subsystem

Option: R&S SMAB-K25

The SOURce:BB:ILS subsystem contains all commands for configuring the ILS signal.

Characteristics which are valid for all modulations and the LF output are configured in the SOURce:LFOutput subsystem. The signal is output at the LF connector.

Commands

[[:SOURce<hw>]:ILS:TYPE.....	626
[[:SOURce<hw>]:ILS[:GS GSLope]:DDM:COUPling.....	627
[[:SOURce<hw>]:ILS[:GS GSLope]:DDM:CURREnt.....	627
[[:SOURce<hw>]:ILS[:GS GSLope]:DDM:DIRectiOn.....	627
[[:SOURce<hw>]:ILS[:GS GSLope]:DDM:LOGarithmic.....	628
[[:SOURce<hw>]:ILS[:GS GSLope]:DDM:PCT.....	628
[[:SOURce<hw>]:ILS[:GS GSLope]:DDM:POLarity.....	628
[[:SOURce<hw>]:ILS[:GS GSLope]:DDM:STEP.....	629
[[:SOURce<hw>]:ILS[:GS GSLope]:DDM[:DEPTH].....	629
[[:SOURce<hw>]:ILS[:GS GSLope]:FREQuency.....	629
[[:SOURce<hw>]:ILS[:GS GSLope]:FREQuency:MODE.....	630
[[:SOURce<hw>]:ILS[:GS GSLope]:FREQuency:SYNChronize[:STATe].....	630
[[:SOURce<hw>]:ILS[:GS GSLope]:ICAO:CHANnel.....	630
[[:SOURce<hw>]:ILS[:GS GSLope]:LLOBe[:FREQuency].....	631
[[:SOURce<hw>]:ILS[:GS GSLope]:MODE.....	631
[[:SOURce<hw>]:ILS[:GS GSLope]:PHASe.....	631
[[:SOURce<hw>]:ILS[:GS GSLope]:PRESet.....	632
[[:SOURce<hw>]:ILS[:GS GSLope]:SDM.....	632
[[:SOURce<hw>]:ILS[:GS GSLope]:SOURce.....	632
[[:SOURce<hw>]:ILS[:GS GSLope]:ULOBe[:FREQuency].....	633
[[:SOURce<hw>]:ILS:LOCalizer:COMid:CODE.....	633
[[:SOURce<hw>]:ILS:LOCalizer:COMid:DASH.....	633
[[:SOURce<hw>]:ILS:LOCalizer:COMid:DEPTTh.....	634
[[:SOURce<hw>]:ILS:LOCalizer:COMid:DOT.....	634
[[:SOURce<hw>]:ILS:LOCalizer:COMid:FREQuency.....	634
[[:SOURce<hw>]:ILS:LOCalizer:COMid:LETTer.....	635
[[:SOURce<hw>]:ILS:LOCalizer:COMid:PERiod.....	635
[[:SOURce<hw>]:ILS:LOCalizer:COMid:SYMBol.....	635

[SOURce<hw>]:ILS:LOCalizer:COMid:TSCHEMA.....	635
[SOURce<hw>]:ILS:LOCalizer:COMid[:STATe].....	636
[SOURce<hw>]:ILS:LOCalizer:DDM:COUPLing.....	636
[SOURce<hw>]:ILS:LOCalizer:DDM:CURREnt.....	636
[SOURce<hw>]:ILS:LOCalizer:DDM:DIRectiOn.....	637
[SOURce<hw>]:ILS:LOCalizer:DDM:LOGarithmic.....	637
[SOURce<hw>]:ILS:LOCalizer:DDM:PCT.....	638
[SOURce<hw>]:ILS:LOCalizer:DDM:POLarity.....	638
[SOURce<hw>]:ILS:LOCalizer:DDM:STEP.....	638
[SOURce<hw>]:ILS:LOCalizer:DDM[:DEPTH].....	639
[SOURce<hw>]:ILS:LOCalizer:FREQuency.....	639
[SOURce<hw>]:ILS:LOCalizer:FREQuency:MODE.....	639
[SOURce<hw>]:ILS:LOCalizer:FREQuency:SYNChronize[:STATe].....	640
[SOURce<hw>]:ILS:LOCalizer:ICAO:CHANnel.....	640
[SOURce<hw>]:ILS:LOCalizer:LLOBe[:FREQuency].....	640
[SOURce<hw>]:ILS:LOCalizer:MODE.....	641
[SOURce<hw>]:ILS:LOCalizer:PHASe.....	641
[SOURce<hw>]:ILS:LOCalizer:PRESet.....	641
[SOURce<hw>]:ILS:LOCalizer:RLOBe[:FREQuency].....	642
[SOURce<hw>]:ILS:LOCalizer:SDM.....	642
[SOURce<hw>]:ILS:LOCalizer:SOURce.....	642
[SOURce<hw>][:ILS]:MBEacon:COMid:CODE.....	643
[SOURce<hw>][:ILS]:MBEacon:COMid:DASH.....	643
[SOURce<hw>][:ILS]:MBEacon:COMid:DEPTH.....	643
[SOURce<hw>][:ILS]:MBEacon:COMid:DOT.....	644
[SOURce<hw>][:ILS]:MBEacon:COMid:FREQuency.....	644
[SOURce<hw>][:ILS]:MBEacon:COMid:LETTer.....	644
[SOURce<hw>][:ILS]:MBEacon:COMid:PERiod.....	645
[SOURce<hw>][:ILS]:MBEacon:COMid:SYMBOL.....	645
[SOURce<hw>][:ILS]:MBEacon:COMid:TSCHEMA.....	645
[SOURce<hw>][:ILS]:MBEacon:COMid[:STATe].....	646
[SOURce<hw>][:ILS]:MBEacon:FREQuency.....	646
[SOURce<hw>][:ILS]:MBEacon:FREQuency:MODE.....	646
[SOURce<hw>][:ILS]:MBEacon:MARKer:FREQuency.....	646
[SOURce<hw>][:ILS]:MBEacon[:MARKer]:DEPTH.....	647
[SOURce<hw>][:ILS]:MBEacon:PRESet.....	647
[SOURce<hw>][:ILS]:MBEacon[:MARKer]:PULSed.....	647

[SOURce<hw>]:ILS:TYPE <Type>

Selects the ILS modulation type.

Parameters:

<Type> GS | LOCalize | GSLope | MBEacon
 *RST: GS

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["ILS Component"](#) on page 141

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:COUPling <Coupling>

Selects if the DDM value is fixed or is changed with a change of sum of modulation depths (SDM, see [:SOURce<hw>]:ILS[:GS|GSLope]:SDM on page 632).

Parameters:

<Coupling> FIXed | SDM
 *RST: FIXed

Example: See [Example"Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["DDM - SDM Coupling"](#) on page 148

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:CURREnt <Current>

Sets the DDM value alternatively as a current by means of the ILS indicating instrument. The instrument current is calculated according to:

$$\text{DDM Current } \mu\text{A} = \text{DDM Depth } [\%] \times 857,125 \mu\text{A}$$

A variation of the instrument current automatically leads to a variation of the DDM value and the DDM value in dB.

Parameters:

<Current> float
 Range: -8.57125E-4 to 8.57125E-4
 Increment: 1E-7
 *RST: 0

Example: See [Example"Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["DDM Current"](#) on page 147

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:DIRectioN <Direction>

Sets the simulation mode for the ILS glide slope modulation signal. A change of the setting automatically changes the sign of the DDM value.

Parameters:

<Direction> UP | DOWN
 UP
 The 150-Hz modulation signal is predominant, the DDM value is negative (the airplane is too low, it must climb).
 DOWN
 The 90-Hz modulation signal is predominant, the DDM value is positive (the airplane is too high, it must descend).
 *RST: UP

Example: See [Example"Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["Fly Mode"](#) on page 147

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:LOGarithmic <Logarithmic>

Sets the depth of modulation value for ILS glide slope modulation in dB.

See also [\[:SOURce<hw>\] : ILS \[:GS | GSLope \] : DDM \[:DEPTh \]](#) on page 629.

Parameters:

<Logarithmic> float
 Range: -999.9 to 999.9
 Increment: 1E-4
 *RST: 0

Example: See [Example"Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["DDM Logarithmic"](#) on page 147

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:PCT <Pct>

Sets the difference in depth of modulation between the signal of the upper lobe (90 Hz) and the lower lobe (150 Hz). The maximum value equals the sum of the modulation depths of the 90 Hz and the 150 Hz tone.

See also [\[:SOURce<hw>\] : ILS \[:GS | GSLope \] : DDM \[:DEPTh \]](#) on page 629.

Parameters:

<Pct> float
 Range: -80.0 to 80.0
 Increment: 0.01
 *RST: 0

Example: See [Example"Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["DDM Percent"](#) on page 148

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:POLarity <Polarity>

Sets the polarity for DDM calculation (see [\[:SOURce<hw>\] : ILS \[:GS | GSLope \] : DDM \[:DEPTh \]](#) on page 629).

The DDM depth calculation depends on the selected polarity:

- Polarity 90 Hz - 150 Hz (default setting):

$$\text{DDM} = [\text{AM}(90 \text{ Hz}) - \text{AM}(150 \text{ Hz})] / 100\%$$
- Polarity 150 Hz - 90 Hz:

$$\text{DDM} = [\text{AM}(150 \text{ Hz}) - \text{AM}(90 \text{ Hz})] / 100\%$$

Parameters:

<Polarity> P90_150 | P150_90
 *RST: P90_150

Example: See [Example"Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["DDM Polarity"](#) on page 145

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:STEP <DdmStep>

Sets the variation of the difference in depth of modulation via the rotary knob.

Parameters:

<DdmStep> DECimal | PREDefined
*RST: DECimal

Example: See [Example"Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["DDM Step"](#) on page 147

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM[:DEPT] <Depth>

Sets the difference in depth of modulation between the signal of the upper/left lobe (90 Hz) and the lower/right lobe (150 Hz). The maximum value equals the sum of the modulation depths of the 90 Hz and the 150 Hz tone. The following is true:

$$\text{ILS:GS|GSL:DDM:DEPT} = (\text{AM}(90\text{Hz}) - \text{AM}(150\text{Hz})) / 100\%$$

A variation of the DDM value automatically leads to a variation of the DDM value in dB and the value of the instrument current.

Parameters:

<Depth> float
Range: -0.8 to 0.8
Increment: 1E-4
*RST: 0

Example: See [Example"Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["DDM Depth"](#) on page 147

[:SOURce<hw>]:ILS[:GS|GSLope]:FREQUENCY <CarrierFreq>

Sets the carrier frequency of the signal.

Parameters:

<CarrierFreq> float
Range: 100E3 to 6E9
Increment: 0.01
*RST: 334.7E6

Example: See [Example"Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["Carrier Frequency"](#) on page 143

[:SOURce<hw>] :ILS[:GS|GSLope] :FREQuency:MODE <Mode>

Sets the mode for the carrier frequency of the signal.

Parameters:

<Mode> USER | ICAO

DECimal

Activates user-defined variation of the carrier frequency.

ICAO

Activates variation in predefined steps according to standard ILS transmitting frequencies (see [Table 6-2](#)).

*RST: DECimal

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["Carrier Frequency Mode"](#) on page 143

[:SOURce<hw>] :ILS[:GS|GSLope] :FREQuency:SYNChronize[:STATe] <Mode>

Activates synchronization of the ILS glide slope ICAO channel with the ILS localizer ICAO channel.

The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Parameters:

<Mode> 0 | 1 | OFF | ON

*RST: 0

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 616.

[:SOURce<hw>] :ILS[:GS|GSLope] :ICAO:CHANnel <Channel>

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

The ICAO channel settings for ILS glide slope/localizer components are coupled. For an overview of the ILS ICAO channel frequencies, see [Table 6-2](#).

Parameters:

<Channel> CH18X | CH18Y | CH20X | CH20Y | CH22X | CH22Y | CH24X | CH24Y | CH26X | CH26Y | CH28X | CH28Y | CH30X | CH30Y | CH32X | CH32Y | CH34X | CH34Y | CH36X | CH36Y | CH38X | CH38Y | CH40X | CH40Y | CH42X | CH42Y | CH44X | CH44Y | CH46X | CH46Y | CH48X | CH48Y | CH50X | CH50Y | CH52X | CH52Y | CH54X | CH54Y | CH56X | CH56Y

*RST: CH18X

Example: See [Example"Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["ICAO Channel"](#) on page 143

[:SOURce<hw>]:ILS[:GS[GSLope]:LLOBe]:FREQuency <Frequency>

Sets the modulation frequency of the antenna lobe arranged at the bottom viewed from the air plane for the ILS glide slope modulation signal.

Parameters:

<Frequency> float
 Range: 100 to 200
 Increment: 0.05
 *RST: 150

Example: See [Example"Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["Down Frequency"](#) on page 145

[:SOURce<hw>]:ILS[:GS[GSLope]:MODE <Mode>

Sets the operating mode for the ILS glide slope modulation signal.

Parameters:

<Mode> NORM | ULOBe | LLOBe
NORM
 ILS glide slope modulation is active.
ULOBe
 Amplitude modulation of the output signal with the upper lobe (90Hz) signal component of the ILS glide slope signal is active.
LLOBe
 Amplitude modulation of the output signal with the lower lobe (150Hz) signal component of the ILS glide slope signal is active.
 *RST: NORM

Example: See [Example"Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["Operating Mode"](#) on page 145

[:SOURce<hw>]:ILS[:GS[GSLope]:PHASe <Phase>

Sets the phase between the modulation signals of the upper and lower antenna lobe of the ILS glide slope signal.

Zero crossing of the lower lobe (150Hz) signal serves as a reference. The angle refers to the period of the signal of the right antenna lobe.

Parameters:

<Phase> float
 Range: -60 to 120
 Increment: 0.01
 *RST: 0.0

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["Up/Down Phase"](#) on page 145

[:SOURce<hw>]:ILS:GS|GSLope:PRESet

Sets the parameters of the ILS glide slope component to their default values (*RST values specified for the commands).

For other ILS preset commands, see [\[:SOURce<hw>\]:ILS:PRESet](#) on page 620.

Example: SOURce1:ILS:GS:PRESet

Usage: Event

[:SOURce<hw>]:ILS[:GS|GSLope]:SDM <Sdm>

Sets the arithmetic sum of the modulation depths of the upper lobe (90 Hz) and lower lobe (150 Hz) for the ILS glide slope signal contents.

The RMS modulation depth of the sum signal depends on the phase setting of both modulation tones.

Parameters:

<Sdm> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 80

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["Sum of Depth"](#) on page 146

[:SOURce<hw>]:ILS[:GS|GSLope]:SOURce <ILsGsSource>

Sets the modulation source for the avionic standard modulation.

If external modulation source is set, the external signal is added to the internal signal. Switching off the internal modulation source is not possible.

Parameters:

<ILsGsSource> INT | EXT | INT,EXT
INT
 Internal modulation source is used.

EXT|INT,EXT

An external modulation source is used, additional to the internal modulation source.

The external signal is input at the Ext connector.

*RST: INT

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["EXT AM"](#) on page 144

[SOURce<hw>]:ILS[:GS|GSLope]:ULOB[:FREQuency] <Frequency>**Parameters:**

<Frequency> float
 Range: 60 to 120
 Increment: 0.03
 *RST: 90

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 616.

Manual operation: See ["Up Frequency"](#) on page 145

[SOURce<hw>]:ILS:LOCalizer:COMid:CODE <Code>

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse code settings"](#), on page 811.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Parameters:

<Code> string

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Code"](#) on page 156

[SOURce<hw>]:ILS:LOCalizer:COMid:DASH <Dash>

Sets the length of a Morse code dash.

Parameters:

<Dash> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Dash Length"](#) on page 157

[SOURce<hw>]:ILS:LOCalizer:COMid:DEPTh <Depth>

Sets the AM modulation depth of the COM/ID signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 10

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Depth"](#) on page 156

[SOURce<hw>]:ILS:LOCalizer:COMid:DOT <Dot>

Sets the length of a Morse code dot.

Parameters:

<Dot> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Dot Length"](#) on page 157

[SOURce<hw>]:ILS:LOCalizer:COMid:FREQuency <Frequency>

Sets the frequency of the COM/ID signal.

Parameters:

<Frequency> float
 Range: 0.1 to 20E3
 Increment: 0.01
 *RST: 1020

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Frequency"](#) on page 156

[:SOURce<hw>]:ILS:LOCalizer:COMid:LETTer <Letter>

Sets the length of a Morse code letter space.

Parameters:

<Letter> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Letter Space"](#) on page 157

[:SOURce<hw>]:ILS:LOCalizer:COMid:PERiod <Period>

Sets the period of the COM/ID signal.

Parameters:

<Period> float
 Range: 0 to 120
 Increment: 1E-3
 *RST: 9

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Period"](#) on page 156

[:SOURce<hw>]:ILS:LOCalizer:COMid:SYMBol <Symbol>

Sets the length of the Morse code symbol space.

Parameters:

<Symbol> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Symbol Space"](#) on page 157

[:SOURce<hw>]:ILS:LOCalizer:COMid:TSCHEMA <TSchema>

Sets the time schema of the Morse code for the COM/ID signal.

Parameters:

<TSchema> STD | USER

STD

Activates the standard time schema of the Morse code.

The set `dot length` determines the `dash length`, which is 3 times the dot length.

USER

Activates the user-defined time schema of the Morse code.

Dot and dash length, as well as `symbol` and `letter space` can be set separately.

*RST: STD

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Time Schema"](#) on page 157

[:SOURce<hw>] :ILS:LOCalizer:COMid[:STATe] <State>

Enables/disables the COM/ID signal.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["COM/ID State"](#) on page 156

[:SOURce<hw>] :ILS:LOCalizer:DDM:COUPling <Coupling>

Selects if the DDM value is fixed or is changed with a change of sum of modulation depths (SDM, see [\[:SOURce<hw> \] :ILS:LOCalizer:SDM](#) on page 642).

Parameters:

<Coupling> FIXed | SDM

*RST: FIXed

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["DDM - SDM Coupling"](#) on page 154

[:SOURce<hw>] :ILS:LOCalizer:DDM:CURREnt <Current>

Sets the DDM value alternatively as a current by means of the ILS indicating instrument. The instrument current is calculated according to:

$$\text{DDM } \mu\text{A} = \text{DDM} \times 857,1 \mu\text{A}$$

A variation of the instrument current automatically leads to a variation of the DDM value and the DDM value in dB.

Parameters:

<Current> float
 Range: -9.6775E-4 to 9.6775E-4
 Increment: 1E-7
 *RST: 0

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["DDM Current"](#) on page 154

[:SOURce<hw>]:ILS:LOCalizer:DDM:DIRection <Direction>

Sets the simulation mode for the ILS-LOC modulation signal. A change of the setting automatically changes the sign of the DDM value.

Parameters:

<Direction> LEFT | RIGHT
LEFT
 The 150 Hz modulation signal is predominant, the DDM value is negative (the airplane is too far to the right, it must turn to the left).
RIGHT
 The 90 Hz modulation signal is predominant, the DDM value is positive (the airplane is too far to the left, it must turn to the right).
 *RST: LEFT

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Fly Mode"](#) on page 153

[:SOURce<hw>]:ILS:LOCalizer:DDM:LOGarithmic <Logarithmic>

Sets the modulation depth in dB for ILS localizer modulation.

See also [\[:SOURce<hw>\]:ILS:LOCalizer:DDM\[:DEPTh\]](#) on page 639.

Parameters:

<Logarithmic> float
 Range: -999.9 to 999.9
 Increment: 1E-4
 *RST: 0

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["DDM Logarithmic"](#) on page 155

[:SOURce<hw>]:ILS:LOCalizer:DDM:PCT <Pct>

Sets the difference in depth of modulation between the signal of the left lobe (90 Hz) and the right lobe (150 Hz). The maximum value equals the sum of the modulation depths of the 90 Hz and the 150 Hz tone.

See also [\[:SOURce<hw>\]:ILS:LOCalizer:DDM\[:DEPTh\]](#) on page 639.

Parameters:

<Pct> float
 Range: -80.0 to 80.0
 Increment: 0.01
 *RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["DDM Percent"](#) on page 155

[:SOURce<hw>]:ILS:LOCalizer:DDM:POLarity <Polarity>

Sets the polarity for DDM calculation (see [\[:SOURce<hw>\]:ILS:LOCalizer:DDM\[:DEPTh\]](#)).

The DDM depth calculation depends on the selected polarity:

- Polarity 90 Hz - 150 Hz (default setting):
 $DDM = [AM(90\text{ Hz}) - AM(150\text{ Hz})] / 100\%$
- Polarity 150 Hz - 90 Hz:
 $DDM = [AM(150\text{ Hz}) - AM(90\text{ Hz})] / 100\%$

Parameters:

<Polarity> P90_150 | P150_90
 *RST: P90_150

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["DDM polarity"](#) on page 152

[:SOURce<hw>]:ILS:LOCalizer:DDM:STEP <DdmStep>

Sets the variation step of the DDM values.

Parameters:

<DdmStep> DECimal | PREDefined
 *RST: DECimal

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["DDM Step"](#) on page 154

[[:SOURce<hw>]:ILS:LOCalizer:DDM[:DEPT] <Depth>

Sets the difference in depth of modulation between the signal of the upper/left lobe (90 Hz) and the lower/right lobe (150 Hz). The maximum value equals the sum of the modulation depths of the 90 Hz and the 150 Hz tone. The following is true:

$$\text{ILS:LOC:DDM:DEPT} = (\text{AM}(90\text{Hz}) - \text{AM}(150\text{Hz})) / 100\%$$

A variation of the DDM value automatically leads to a variation of the DDM value in dB and the value of the instrument current.

Parameters:

<Depth> float
 Range: -0.4 to 0.4
 Increment: 1E-4
 *RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["DDM Depth"](#) on page 154

[[:SOURce<hw>]:ILS:LOCalizer:FREQuency <CarrierFreq>

Sets the carrier frequency of the signal.

Parameters:

<CarrierFreq> float
 Range: 100E3 to 6E9
 Increment: 0.01
 *RST: 108.1E6

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Carrier Frequency"](#) on page 149

[[:SOURce<hw>]:ILS:LOCalizer:FREQuency:MODE <ILsLocFreqMode>

Sets the mode for the carrier frequency of the signal.

Parameters:

<Mode> DECimal | ICAO
DECimal
 Activates user-defined variation of the carrier frequency.
ICAO
 Activates variation in predefined steps according to standard ILS transmitting frequencies (see [Table 6-2](#)).
 *RST: DECimal

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Carrier Frequency Mode"](#) on page 149

[[:SOURce<hw>]:ILS:LOCalizer:FREQuency:SYNChronize[:STATe] <Mode>

Activates synchronization of the ILS localizer ICAO channel with the ILS glide slope ICAO channel.

The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Parameters:

<Mode> 0 | 1 | OFF | ON
*RST: 0

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

[[:SOURce<hw>]:ILS:LOCalizer:ICAO:CHANnel <SellcaoChan>

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

The ICAO channel settings for ILS glide slope/localizer components are coupled. For an overview of the ILS ICAO channel frequencies, see [Table 6-2](#).

Parameters:

<SellcaoChan> CH18X | CH18Y | CH20X | CH20Y | CH22X | CH22Y | CH24X | CH24Y | CH26X | CH26Y | CH28X | CH28Y | CH30X | CH30Y | CH32X | CH32Y | CH34X | CH34Y | CH36X | CH36Y | CH38X | CH38Y | CH40X | CH40Y | CH42X | CH42Y | CH44X | CH44Y | CH46X | CH46Y | CH48X | CH48Y | CH50X | CH50Y | CH52X | CH52Y | CH54X | CH54Y | CH56X | CH56Y
*RST: CH18X

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["ICAO Channel"](#) on page 150

[[:SOURce<hw>]:ILS:LOCalizer:LLOBe[:FREQuency] <Frequency>

Sets the modulation frequency of the antenna lobe arranged at the bottom viewed from the air plane for the ILS localizer modulation signal.

Parameters:

<Frequency> float
Range: 60 to 120
Increment: 0.03
*RST: 90

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Left Frequency"](#) on page 152

[:SOURce<hw>]:ILS:LOCalizer:MODE <Mode>

Sets the operating mode for the ILS localizer modulation signal.

Parameters:

<Mode> NORM | LLOBe | RLOBe

NORM

ILS localizer modulation is active.

LLOBe

Amplitude modulation of the output signal with the left lobe (90Hz) signal component of the ILS localizer signal is active.

RLOBe

Amplitude modulation of the output signal with the right lobe (150Hz) signal component of the ILS localizer signal is active.

*RST: NORM

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Operating Mode"](#) on page 151

[:SOURce<hw>]:ILS:LOCalizer:PHASe <Phase>

Sets the phase between the modulation signals of the left and right antenna lobe of the ILS localizer signal.

The zero crossing of the right lobe (150Hz) signal serves as a reference. The angle refers to the period of the signal of the right antenna lobe.

Parameters:

<Phase> float
Range: -60 to 120
Increment: 0.01
*RST: 0

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Left/Right Phase"](#) on page 152

[:SOURce<hw>]:ILS:LOCalizer:PRESet

Sets the parameters of the ILS localizer component to their default values (*RST values specified for the commands).

For other ILS preset commands, see [\[:SOURce<hw>\]:ILS:PRESet](#) on page 620.

Example: SOURce1:ILS:LOCalizer:PRESet

Usage: Event

[SOURce<hw>]:ILS:LOCalizer:RLOBe[:FREQuency] <Frequency>

Sets the modulation frequency of the antenna lobe arranged at the right viewed from the air plane.

Parameters:

<Frequency> float
 Range: 100 to 200
 Increment: 0.05
 *RST: 150

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Right Frequency"](#) on page 152

[SOURce<hw>]:ILS:LOCalizer:SDM <Sdm>

Sets the arithmetic sum of the modulation depths of the left lobe (90 Hz) and right lobe (150 Hz) for the ILS localizer signal contents.

The RMS modulation depth of the sum signal depends on the phase setting of both modulation tones.

Parameters:

<Sdm> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 40

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["Sum of Depth"](#) on page 153

[SOURce<hw>]:ILS:LOCalizer:SOURce <ILsLocSource>

Sets the modulation source for the avionic standard modulation.

If external modulation source is set, the external signal is added to the internal signal. Switching off the internal modulation source is not possible.

Parameters:

<ILsLocSource> INT | EXT | INT,EXT
INT
 Internal modulation source is used.

EXT|INT,EXT

An external modulation source is used, additional to the internal modulation source.

The external signal is input at the Ext connector.

*RST: INT

Example: See [Example"Configure and generate an ILS localizer signal"](#) on page 617.

Manual operation: See ["EXT AM"](#) on page 150

[[:SOURce<hw>][:ILS]:MBEacon:COMid:CODE <Code>

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse code settings"](#), on page 811.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Parameters:

<Code> string

Example: See [Example"Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["Code"](#) on page 161

[[:SOURce<hw>][:ILS]:MBEacon:COMid:DASH <Dash>

Sets the length of a Morse code dash.

Parameters:

<Dash> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3

Example: See [Example"Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["Dash Length"](#) on page 162

[[:SOURce<hw>][:ILS]:MBEacon:COMid:DEPTH <Depth>

Sets the AM modulation depth of the COM/ID signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 5

Example: See [Example"Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["Depth"](#) on page 161

[:SOURce<hw>][:ILS]:MBEacon:COMid:DOT <Dot>

Sets the length of a Morse code dot.

Parameters:

<Dot>	float
Range:	0.05 to 1
Increment:	1E-4
*RST:	0.1

Example: See [Example"Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["Dot Length"](#) on page 162

[:SOURce<hw>][:ILS]:MBEacon:COMid:FREQUENCY <Frequency>

Sets the frequency of the COM/ID signal.

Parameters:

<Frequency>	float
Range:	0.1 to 20E3
Increment:	0.01
*RST:	1020

Example: See [Example"Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["Frequency"](#) on page 161

[:SOURce<hw>][:ILS]:MBEacon:COMid:LETter <Letter>

Sets the length of a Morse code letter space.

Parameters:

<Letter>	float
Range:	0.05 to 1
Increment:	1E-4
*RST:	0.3

Example: See [Example"Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["Letter Space"](#) on page 162

[[:SOURce<hw>]][:ILS]:MBEacon:COMid:PERiod <Period>

Sets the period of the COM/ID signal.

Parameters:

<Period> float
 Range: 0 to 120
 Increment: 1E-3
 *RST: 9

Example: See [Example"Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["Period"](#) on page 161

[[:SOURce<hw>]][:ILS]:MBEacon:COMid:SYMBol <Symbol>

Sets the length of the Morse code symbol space.

Parameters:

<Symbol> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example"Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["Symbol Space"](#) on page 162

[[:SOURce<hw>]][:ILS]:MBEacon:COMid:TSCHEMA <Tschema>

Sets the time schema of the Morse code for the COM/ID signal.

Parameters:

<Tschema> STD | USER

STD

Activates the standard time schema of the Morse code.

The set [dot length](#) determines the [dash length](#), which is 3 times the dot length.

USER

Activates the user-defined time schema of the Morse code.

Dot and dash length, as well as [symbol](#) and [letter space](#) can be set separately.

*RST: STD

Example: See [Example"Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["Time Schema"](#) on page 161

[[:SOURce<hw>][:ILS]:MBEacon:COMid[:STATe] <State>

Enables/disables the COM/ID signal.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example"Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["COM/ID State"](#) on page 161

[[:SOURce<hw>][:ILS]:MBEacon:FREQuency <CarrierFreq>

Sets the carrier frequency for the ILS marker beacon signal.

Parameters:

<CarrierFreq> float
 Range: 100E3 to 6E9
 Increment: 0.01
 *RST: 75E6

Example: See [Example"Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["Carrier Frequency"](#) on page 158

[[:SOURce<hw>][:ILS]:MBEacon:FREQuency:MODE <Mode>

Sets the carrier frequency mode of the ILS marker beacon signal.

Parameters:

<Mode> USER | PREDefined
 *RST: USER

Example: See [Example"Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["Carrier Frequency Mode"](#) on page 158

[[:SOURce<hw>][:ILS]:MBEacon:MARKer:FREQuency <Frequency>

Sets the modulation frequency of the marker signal for the ILS marker beacon modulation signal.

Parameters:

<Frequency> 400 | 1300 | 3000
 *RST: 400
 Default unit: Hz

Example: See [Example"Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["Marker Frequency"](#) on page 159

[:SOURce<hw>] [:ILS] :MBEacon [:MARKer] :DEPTh <Depth>

Sets the modulation depth of the marker signal for the ILS marker beacon signal.

Parameters:

<Depth>	float
Range:	0 to 100
Increment:	0.1
*RST:	95

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["Marker Depth"](#) on page 159

[:SOURce<hw>] [:ILS] :MBEacon :PRESet

Sets the parameters of the ILS marker beacons component to their default values (*RST values specified for the commands).

For other ILS preset commands, see [\[:SOURce<hw> \] :ILS :PRESet](#) on page 620.

Example: SOURce1:ILS:MBEacon:PRESet

Usage: Event

[:SOURce<hw>] [:ILS] :MBEacon [:MARKer] :PULSed <Pulsed>

Activates the modulation of a pulsed marker signal (morse coding).

Parameters:

<Pulsed>	1 ON 0 OFF
*RST:	0

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 618.

Manual operation: See ["Pulsed Marker"](#) on page 159

14.17.2.5 SOURce:VOR subsystem

Option: R&S SMAB-K25

The SOURce:VOR subsystem contains all commands for configuring the VOR signal.

Characteristics which are valid for all modulations and the LF output are configured in the [SOURce:LFOutput](#) subsystem. The signal is output at the LF connector.

Commands

<code>[SOURce<hw>]:VOR:SOURce</code>	648
<code>[SOURce<hw>]:VOR[:BANGLe]</code>	648
<code>[SOURce<hw>]:VOR[:BANGLe]:DIRection</code>	649
<code>[SOURce<hw>]:VOR:COMid:CODE</code>	649
<code>[SOURce<hw>]:VOR:COMid:DASH</code>	650
<code>[SOURce<hw>]:VOR:COMid:DEPT</code>	650
<code>[SOURce<hw>]:VOR:COMid:DOT</code>	650
<code>[SOURce<hw>]:VOR:COMid:FREQuency</code>	650
<code>[SOURce<hw>]:VOR:COMid:LETTer</code>	651
<code>[SOURce<hw>]:VOR:COMid:PERiod</code>	651
<code>[SOURce<hw>]:VOR:COMid:SYMBol</code>	651
<code>[SOURce<hw>]:VOR:COMid:TSCHema</code>	652
<code>[SOURce<hw>]:VOR:COMid[:STATe]</code>	652
<code>[SOURce<hw>]:VOR:FREQuency</code>	652
<code>[SOURce<hw>]:VOR:FREQuency:MODE</code>	653
<code>[SOURce<hw>]:VOR:ICAO:CHANnel</code>	653
<code>[SOURce<hw>]:VOR:MODE</code>	654
<code>[SOURce<hw>]:VOR:REFeRence[:DEViation]</code>	655
<code>[SOURce<hw>]:VOR:SUBCarrier:DEPT</code>	655
<code>[SOURce<hw>]:VOR:SUBCarrier[:FREQuency]</code>	655
<code>[SOURce<hw>]:VOR:VAR:FREQuency</code>	656
<code>[SOURce<hw>]:VOR:VAR[:DEPT]</code>	656

`[SOURce<hw>]:VOR:SOURce` <VorSourceSel>

Sets the modulation source for the avionic standard modulation.

If external modulation source is set, the external signal is added to the internal signal. Switching off the internal modulation source is not possible.

Parameters:

<VorSourceSel> INT | EXT | INT,EXT

INT

Internal modulation source is used.

EXT|INT,EXT

An external modulation source is used, additional to the internal modulation source.

The external signal is input at the Ext connector.

*RST: INT

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["EXT AM"](#) on page 130

`[SOURce<hw>]:VOR[:BANGLe]` <BAngle>

Sets the bearing angle between the VAR signal and the reference signal.

The orientation of the angle can be set with `[:SOURce<hw>] :VOR[:BANGLe] :DIRection`.

Parameters:

<BAngle> float
 Range: 0 to 360
 Increment: 0.01
 *RST: 0

Example: See [Example "Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Bearing Angle"](#) on page 133

`[:SOURce<hw>] :VOR[:BANGLe] :DIRection <Direction>`

Sets the reference position of the phase information.

Parameters:

<Direction> FROM | TO
FROM
 The bearing angle is measured between the geographic north and the connection line from beacon to airplane.
TO
 The bearing angle is measured between the geographic north and the connection line from airplane to beacon.
 *RST: FROM

Example: See [Example "Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Direction"](#) on page 133

`[:SOURce<hw>] :VOR :COMid :CODE <Code>`

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse code settings"](#), on page 811.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Parameters:

<Code> string

Example: See [Example "Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Code"](#) on page 134

[[:SOURce<hw>]:VOR:COMid:DASH <Dash>

Sets the length of a Morse code dash.

Parameters:

<Dash> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Dash Length"](#) on page 135

[[:SOURce<hw>]:VOR:COMid:DEPTH <Depth>

Sets the AM modulation depth of the COM/ID signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 10

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Depth"](#) on page 135

[[:SOURce<hw>]:VOR:COMid:DOT <Dot>

Sets the length of a Morse code dot.

If the [time schema](#) is set to standard, the dash length (= 3 times dot length), symbol space (= dot length) and letter space (= 3 times dot length) is also determined by this entry.

Parameters:

<Dot> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Dot Length"](#) on page 135

[[:SOURce<hw>]:VOR:COMid:FREQuency <Frequency>

Sets the frequency of the COM/ID signal.

Parameters:

<Frequency> float
 Range: 0.1 to 20E3
 Increment: 0.01
 *RST: 1020

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Frequency"](#) on page 135

[:SOURce<hw>]:VOR:COMid:LETter <Letter>

Sets the length of a Morse code letter space.

Parameters:

<Letter> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3
 Default unit: s

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Letter Space"](#) on page 136

[:SOURce<hw>]:VOR:COMid:PERiod <Period>

Sets the period of the COM/ID signal.

Parameters:

<Period> float
 Range: 0 to 120
 Increment: 1E-3
 *RST: 9

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Period"](#) on page 135

[:SOURce<hw>]:VOR:COMid:SYMBol <Symbol>

Sets the length of the Morse code symbol space.

Parameters:

<Symbol> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Symbol Space"](#) on page 136

[[:SOURce<hw>]:VOR:COMid:TSCHEMA <Tschema>

Sets the time schema of the Morse code for the COM/ID signal.

Parameters:

<Tschema> STD | USER

STD

Activates the standard time schema of the Morse code.

The set [dot length](#) determines the [dash length](#), which is 3 times the dot length.

USER

Activates the user-defined time schema of the Morse code.

Dot and dash length, as well as [symbol](#) and [letter space](#) can be set separately.

*RST: STD

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Time Schema"](#) on page 135

[[:SOURce<hw>]:VOR:COMid:STATE] <State>

Enables/disables the COM/ID signal.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: 0

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["COM/ID State"](#) on page 134

[[:SOURce<hw>]:VOR:FREQUENCY <CarrierFreq>

Sets the carrier frequency of the signal.

Parameters:

<CarrierFreq> float

Range: 100E3 to 6E9

Increment: 0.01

*RST: 108E6

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Carrier Frequency"](#) on page 130

[[:SOURce<hw>]:VOR:FREQuency:MODE <Mode>

Sets the mode for the carrier frequency of the signal.

Parameters:

<Mode> DECimal | ICAO

DECimal

Activates user-defined variation of the carrier frequency.

ICAO

Activates variation in predefined steps according to standard VOR transmitting frequencies (see [Table 6-1](#)).

*RST: DECimal

Example: See [Example "Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Carrier Frequency Mode"](#) on page 130

[[:SOURce<hw>]:VOR:ICAO:CHANnel <Channel>

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

The carrier frequency is set automatically to the value of the ICAO channel. For an overview of the VOR ICAO channel frequencies, see [Table 6-1](#).

Parameters:

<Channel>

CH17X | CH17Y | CH19X | CH19Y | CH21X | CH21Y | CH23X |
 CH23Y | CH25X | CH25Y | CH27X | CH27Y | CH29X | CH29Y |
 CH31X | CH31Y | CH33X | CH33Y | CH35X | CH35Y | CH37X |
 CH37Y | CH39X | CH39Y | CH41X | CH41Y | CH43X | CH43Y |
 CH45X | CH45Y | CH47X | CH47Y | CH49X | CH49Y | CH51X |
 CH51Y | CH53X | CH53Y | CH55X | CH55Y | CH57X | CH57Y |
 CH58X | CH58Y | CH59X | CH59Y | CH70X | CH70Y | CH71X |
 CH71Y | CH72X | CH72Y | CH73X | CH73Y | CH74X | CH74Y |
 CH75X | CH75Y | CH76X | CH76Y | CH77X | CH77Y | CH78X |
 CH78Y | CH79X | CH79Y | CH80X | CH80Y | CH81X | CH81Y |
 CH82X | CH82Y | CH83X | CH83Y | CH84X | CH84Y | CH85X |
 CH85Y | CH86X | CH86Y | CH87X | CH87Y | CH88X | CH88Y |
 CH89X | CH89Y | CH90X | CH90Y | CH91X | CH91Y | CH92X |
 CH92Y | CH93X | CH93Y | CH94X | CH94Y | CH95X | CH95Y |
 CH96X | CH96Y | CH97X | CH97Y | CH98X | CH98Y | CH99X |
 CH99Y | CH100X | CH100Y | CH101X | CH101Y | CH102X |
 CH102Y | CH103X | CH103Y | CH104X | CH104Y | CH105X |
 CH105Y | CH106X | CH106Y | CH107X | CH107Y | CH108X |
 CH108Y | CH109X | CH109Y | CH110X | CH110Y | CH111X |
 CH111Y | CH112X | CH112Y | CH113X | CH113Y | CH114X |
 CH114Y | CH115X | CH115Y | CH116X | CH116Y | CH117X |
 CH117Y | CH118X | CH118Y | CH119X | CH119Y | CH120X |
 CH120Y | CH121X | CH121Y | CH122X | CH122Y | CH123X |
 CH123Y | CH124X | CH124Y | CH125X | CH125Y | CH126X |
 CH126Y

*RST: CH17X

Example:

See [Example"Configure and generate a VOR signal"](#)
 on page 618.

Manual operation: See ["ICAO Channel"](#) on page 130

[:SOURce<hw>]:VOR:MODE <Mode>

Sets the operating mode for the VOR modulation signal.

Parameters:

<Mode>

NORM | VAR | SUBCarrier | FMSubcarrier

NORM

VOR modulation is active.

VAR

Amplitude modulation of the output signal with the variable signal component (30Hz signal content) of the VOR signal.

The modulation depth of the 30 Hz signal can be set with [:
[SOURce<hw>\]:VOR:VAR\[:DEPTH\]](#).

SUBCarrier

Amplitude modulation of the output signal with the unmodulated FM carrier (9960Hz) of the VOR signal.

The modulation depth of the 30 Hz signal can be set with [:SOURce<hw>]:VOR:SUBCarrier:DEPTh.

FMSubcarrier

Amplitude modulation of the output signal with the frequency modulated FM carrier (9960Hz) of the VOR signal.

The modulation depth of the 30 Hz signal can be set with [:SOURce<hw>]:VOR:SUBCarrier:DEPTh.

The frequency deviation can be set with [:SOURce<hw>]:VOR:REFErence[:DEViation].

*RST: NORM

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Mode"](#) on page 131

[[:SOURce<hw>]:VOR:REFErence[:DEViation] <Deviation>

Sets the frequency deviation of the reference signal on the FM carrier.

Parameters:

<Deviation> integer
Range: 0 to 960
*RST: 480

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["REF Deviation"](#) on page 132

[[:SOURce<hw>]:VOR:SUBCarrier:DEPTh <Depth>

Sets the AM modulation depth of the FM carrier.

Parameters:

<Depth> float
Range: 0 to 100
Increment: 0.1
*RST: 30

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Subcarrier Depth"](#) on page 132

[[:SOURce<hw>]:VOR:SUBCarrier[:FREQuency] <Frequency>

Sets the frequency of the FM carrier.

Parameters:

<Frequency> float
 Range: 5E3 to 15E3
 Increment: 0.01
 *RST: 9.96E3

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["Subcarrier Frequency"](#) on page 132

[SOURce<hw>]:VOR:VAR:FREQuency <Frequency>

Sets the frequency of the variable and the reference signal. As the two signals must have the same frequency, the setting is valid for both signals.

Parameters:

<Frequency> float
 Range: 10 to 60
 Increment: 0.01
 *RST: 30

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["VAR/REF Frequency"](#) on page 132

[SOURce<hw>]:VOR:VAR[:DEPT]h <Depth>

Sets the AM modulation depth of the 30Hz variable signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 30

Example: See [Example"Configure and generate a VOR signal"](#) on page 618.

Manual operation: See ["VAR Depth"](#) on page 132

14.17.3 SOURce:CORRection subsystem

The SOURce:CORRection subsystem contains the commands for defining correction values for external test assemblies.

You can acquire the correction values anytime, regardless of the modulation settings of the generator. The correction is performed by adding the correction values to the output level of the respective RF frequency.

Determine the correction values in one of the following ways:

- Measure the RF output level at several frequency points and enter the value pairs manually in a table
- Connect an R&S NRP to the generator output signal and send the command `[:SOURce<hw>] :CORRection:CSET:DATA [:SENSor<ch>] [:POWer] :SONCe` to fill the table automatically.

Correction values can be stored in files with the predefined file extension `*.uco`.

Refer to [Chapter 14.5.2, "Accessing files in the default or in a specified directory"](#), on page 471 for general information on file handling in the default and in a specific directory.

Programming example

The examples in this section assume that:

- The files are stored in the default directory.
- `*RST` does not affect data lists.

Example: Create a table with user-defined correction values for the RF level

The following example shows a command sequence to create and activate a list for assigning level correction values to arbitrary RF frequencies. Further hardware settings are not considered.

```
// Reset the instrument to start from an initial state
// Query the available user correction list files in the default directory
// Select a file or create a new one
// *****
*RST; *CLS
SOURcel:CORRection:CSET:CATalog?
// Response: shows the name of available user correction files (if applicable)
// Select a file
SOURcel:CORRection:CSET:SElect "/var/user/ucor1"
// Create a new file (if not existing)
SOURcel:CORRection:CSET:SElect "/var/user/ucor2"

// Enter the frequency/level value pairs in the table;
// existing data is overwritten
// Query the number of frequency/power entries in the selected list
SOURcel:CORRection:CSET:DATA:FREquency 100MHz,110MHz,120MHz,130MHz,140MHz,150MHz
SOURcel:CORRection:CSET:DATA:POWer -10,-7.5,-5.0,-2.5,0,2.5
SOURcel:CORRection:CSET:DATA:FREquency:POINts?
// 6
SOURcel:CORRection:CSET:DATA:POWer:POINts?
// 6

// Enable user correction mode and RF output
SOURcel:CORRection:STATe 1
OUTPut1:STATe ON
```

```
// Query the currently used correction value
SOURcel:CORRection:VALue?
// -2.5

// Delete a user correction file
SOURcel:CORRection:CSET:DELEte "/var/user/ucor1.uco"
```

Example: Fill user correction data with sensor

The following example shows a command sequence to fill a user correction list automatically supported by a connected R&S NRP.

```
// Fill a user correction list with the level values
// measured by an R&S NRP,
// store the data in a file and enable user correction.

*RST; *CLS

SOURcel:CORRection:CSET:SElect "/var/user/Ucor1_AutoFill.uco"
SOURcel:CORRection:CSET:DATA:FREQuency 100MHz,110MHz,120MHz,130MHz,140MHz,150MHz
SOURcel:CORRection:ZERoing:STATe 1
SOURcel:CORRection:CSET:DATA:SENSor1:POWer:SONCe
// Query the number of automatically filled correction level values
SOURcel:CORRection:CSET:DATA:POWer:POINTs?
// 6
SOURcel:CORRection:STATe 1

// Query the correction value at a certain frequency
FREQ 120000000
SOURcel:CORRection:VALue?
// -52.13
```

Example: User correction data exchange

The following example shows a command sequence to export a user correction list (here the list created with the example before) into an ASCII file. Further hardware settings are not considered.

```
// Select a user correction file for exporting to file in ASCII format
// Set ASCII data parameters
// Set the ASCII file extension, the decimal separator
// and the column separator for the ASCII data
SOURcel:CORRection:DEXChange:AFILe:CATalog?
// my_ucor
SOURcel:CORRection:CSET:CATalog?
// ucor1,Ucor1_AutoFill
SOURcel:CORRection:CSET:SElect "/var/user/Ucor1_AutoFill.uco"
SOURcel:CORRection:DEXChange:AFILe:EXTension CSV
SOURcel:CORRection:DEXChange:AFILe:SEParator:DECimal DOT
SOURcel:CORRection:DEXChange:AFILe:SEParator:COLumn COMMa
```

```
// Select source and destination
SOURCE1:CORRection:DEXChange:AFIle:SElect "/var/user/ucor2ASCII"

// Export the user correction data into the ASCII file
SOURCE1:CORRection:DEXChange:MODE EXPort
SOURCE1:CORRection:DEXChange:EXECute

// Query the available ASCII files with extension .csv
SOURCE1:CORRection:DEXChange:AFIle:CATalog?
// ucor2ASCII,my_ucor

// Import a user correction ASCII file
SOURCE1:CORRection:DEXChange:MODE IMPort
SOURCE1:CORRection:DEXChange:AFIle:SElect "/var/user/my_ucor"
SOURCE1:CORRection:DEXChange:EXECute
```

- [Correction settings](#)..... 659
- [Correction data exchange](#)..... 662

14.17.3.1 Correction settings

[:SOURCE<hw>]:CORRection:CSET:DATA:FREQuency <Frequency>

Enters the frequency value in the table selected with [\[:SOURCE<hw>\]:CORRection:CSET\[:SElect\]](#).

Parameters:

<Frequency> Frequency#1[, Frequency#2, ...]
 String of values with default unit Hz.

Example: See [Example"Create a table with user-defined correction values for the RF level"](#) on page 657 .

Manual operation: See ["Edit List Mode Data"](#) on page 206

[:SOURCE<hw>]:CORRection:CSET:DATA:POWer <Power>

Enters the level values to the table selected with [\[:SOURCE<hw>\]:CORRection:CSET\[:SElect\]](#).

Parameters:

<Power> Power#1[, Power#2, ...]
 String of values with default unit dB.
 *RST: 0

Example: See [Example"Create a table with user-defined correction values for the RF level"](#) on page 657 .

Manual operation: See ["Edit List Mode Data"](#) on page 206

[[:SOURce<hw>]:CORRection:CSET:DATA:FREQuency:POINts?

[[:SOURce<hw>]:CORRection:CSET:DATA:POWer:POINts?

Queries the number of frequency/level values in the selected table.

Return values:

<Points> integer
 Range: 0 to 10000
 *RST: 0

Example: See [Example "Create a table with user-defined correction values for the RF level"](#) on page 657 .

Usage: Query only

[[:SOURce<hw>]:CORRection:CSET:DATA[:SENSor<ch>]][:POWer]:SONCe

Fills the selected user correction table with the level values measured by the power sensor for the given frequencies.

To select the used power sensor set the suffix in key word `SENSe`.

Example: See [Example "Fill user correction data with sensor"](#) on page 658.

Usage: Event

Manual operation: See ["Fill User Correction Data with Sensor"](#) on page 226

[[:SOURce<hw>]:CORRection:CSET[:SELEct] <Filename>

Selects or creates a file for the user correction data.

If the file with the selected name does not exist, a new file is created.

Parameters:

<Filename> string
 Filename or complete file path; file extension can be omitted.

Example: See [Example "Create a table with user-defined correction values for the RF level"](#) on page 657 .

Manual operation: See ["UCOR Data"](#) on page 222
 See ["Functions for handling of data lists"](#) on page 320

[[:SOURce<hw>]:CORRection:VALue?

Queries the current value for user correction.

Return values:

<Value> float
 Range: -100 to 100
 Increment: 0.01
 *RST: 0

Example: See [Example "Create a table with user-defined correction values for the RF level"](#) on page 657 .

Usage: Query only

Manual operation: See ["User Correction"](#) on page 221

[:SOURce<hw>]:CORRection:ZERoing:STATe <State>

Activates the zeroing procedure before filling the user correction data acquired by a sensor.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 1

Example: See [Example "Fill user correction data with sensor"](#) on page 658.

Manual operation: See ["Fill User Correction Data with Sensor"](#) on page 226

[:SOURce<hw>]:CORRection:CSET:DATA[:SENSor<ch>][:POWer]:SONCe

Fills the selected user correction list with the level values measured by the power sensor for the given frequencies.

Suffix:

SENSor<ch> Defines the used power sensor, i.e. the sensor whose values are used.

Example: See [Example "Fill user correction data with sensor"](#) on page 658.

Usage: Event

[:SOURce<hw>]:CORRection[:STATe] <State>

Activates user correction with the currently selected table.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Example: See [Example "Create a table with user-defined correction values for the RF level"](#) on page 657 .

Manual operation: See ["State"](#) on page 221

[:SOURce]:CORRection:CSET:CATalog?

Queries a list of available user correction tables.

Return values:

<Catalog> string
List of list filenames, separated by commas

Example: See [Example"Create a table with user-defined correction values for the RF level"](#) on page 657 .

Usage: Query only

Manual operation: See ["UCOR Data"](#) on page 222
See ["Directory, File List and Filename"](#) on page 315

[:SOURce]:CORRection:CSET:DELeTe <Filename>

Deletes the specified user correction list file.

Setting parameters:

<Filename> string
Filename or complete file path; file extension is optional.

Example: See [Example"Create a table with user-defined correction values for the RF level"](#) on page 657 .

Usage: Setting only

Manual operation: See ["UCOR Data"](#) on page 222

14.17.3.2 Correction data exchange

With the following commands, you can configure user correction lists and export or import them accordingly.

[:SOURce<hw>]:CORRection:DEXChange:AFILe:CATalog?

Queries the available ASCII files for export or import of user correction data in the current or specified directory.

Return values:

<Catalog> string
List of ASCII files *.txt or *.csv, separated by commas.

Example: See [Example"Create a table with user-defined correction values for the RF level"](#) on page 657 .

Usage: Query only

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 108

[:SOURce<hw>]:CORRection:DEXChange:AFILe:EXTension <Extension>

Determines the extension of the ASCII files for file import or export, or to query existing files.

Parameters:

<Extension> TXT | CSV
*RST: TXT

Example: See [Example"User correction data exchange"](#) on page 658 .

Manual operation: See ["ASCII File Settings"](#) on page 107

[:SOURce<hw>]:CORRection:DEXChange:AFILe:SElect <Filename>

Selects the ASCII file to be imported or exported.

Parameters:

<Filename> string
 Filename or complete file path; file extension can be omitted.

Example: See [Example"User correction data exchange"](#) on page 658 .

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 108

[:SOURce<hw>]:CORRection:DEXChange:AFILe:SEParator:COLumn <Column>

Selects the separator between the frequency and level column of the ASCII table.

Parameters:

<Column> TABulator | SEMicolon | COMMa | SPACe
 *RST: COMMa

Example: See [Example"User correction data exchange"](#) on page 658 .

Manual operation: See ["ASCII File Settings"](#) on page 107

[:SOURce<hw>]:CORRection:DEXChange:AFILe:SEParator:DECimal <Decimal>

Sets the decimal separator used in the ASCII data between '.' (decimal point) and ',' (comma) with floating-point numerals.

Parameters:

<Decimal> DOT | COMMa
 *RST: DOT

Example: See [Example"User correction data exchange"](#) on page 658 .

Manual operation: See ["ASCII File Settings"](#) on page 107

[:SOURce<hw>]:CORRection:DEXChange:EXECute

Executes the import or export of the selected correction list, according to the previously set transfer direction with command [\[:SOURce<hw>\]:CORRection:DEXChange:MODE](#).

Example: See [Example"User correction data exchange"](#) on page 658 .

Usage: Event

Manual operation: See ["Import / Export"](#) on page 108

```
[ :SOURce<hw>]:CORRection:DEXChange:MODE <Mode>
```

Determines import or export of a user correction list.

Specify the source or destination file with the command `[:SOURce<hw>]:CORRection:DEXChange:SElect.`

Parameters:

```
<Mode>      IMPort | EXPort
              *RST:      IMPort
```

Example: See [Example "User correction data exchange"](#) on page 658.

Manual operation: See "Mode" on page 107

```
[:SOURce<hw>]:CORRection:DEXChange:SELEct <Filename>
```

Selects the ASCII file for import or export, containing a user correction list.

Parameters:

<Filename>	string
	Filename or complete file path; file extension can be omitted.

Example: See [Example "User correction data exchange"](#) on page 658.

Manual operation: See "Select Source/Select ASCII Destination" on page 108

14.17.4 SOURce:FREQuency subsystem

The `SOURCE:FREQUENCY` subsystem contains the commands used to define the frequency settings for the RF sources and sweeps.

Example: Frequency configuration

```
SOURce1:FREQuency:MODE CW
SOURce1:FREQuency:CW 6000000000
SOURce1:FREQuency:OFFSet 2000000000
SOURce1:FREQuency:MULTIplier 1.5
SOURce1:FREQuency:CW?
// 11000000000

// SOURce1:FREQuency:STEP:MODE USER
// SOURce1:FREQuency:STEP:INCRement 1000000
// SOURce1:FREQuency:CW UP

SOURce1:PHASe 2
SOURce1:PHASe:REference
```


Example: Setting a phase continuous frequency range

```

SOURce1:FREQuency:CW 502000000
SOURce1:FREQuency:PHASe:MODE NARR
SOURce1:FREQuency:PHASe:CONTInuous:STATe 1
*****
// Query the frequency range
SOURce1:FREQuency:PHASe:CONTInuous:LOW?
// Response: 49370890
SOURce1:FREQuency:PHASe:CONTInuous:HIGh?
// Response: 50421376
*****
// Vary the frequency. Within the specified range the signal is phase continuous.
SOURce1:FREQuency:CW 499000000
SOURce1:FREQuency:CW 500000000
SOURce1:FREQuency:CW 501000000
SOURce1:FREQuency:CW 503000000

```

[SOURce<hw>]:FREQuency:MODE.....	665
[SOURce<hw>]:FREQuency[:CW FIXed].....	666
[SOURce<hw>]:FREQuency[:CW FIXed]:RCL.....	667
[SOURce<hw>]:FREQuency:MANual.....	668
[SOURce<hw>]:FREQuency:MULTIplier.....	668
[SOURce<hw>]:FREQuency:OFFSet.....	668
[SOURce<hw>]:FREQuency:CENTer.....	669
[SOURce<hw>]:FREQuency:SPAN.....	669
[SOURce<hw>]:FREQuency:STARt.....	669
[SOURce<hw>]:FREQuency:STOP.....	670
[SOURce<hw>]:FREQuency:STEP:MODE.....	670
[SOURce<hw>]:FREQuency:STEP[:INCRement].....	671
[SOURce<hw>]:FREQuency:PLL:MODE.....	671
[SOURce<hw>]:FREQuency:PHASe:CONTInuous:HIGh?.....	671
[SOURce<hw>]:FREQuency:PHASe:CONTInuous:LOW?.....	672
[SOURce<hw>]:FREQuency:PHASe:CONTInuous:MODE.....	672
[SOURce<hw>]:FREQuency:PHASe:CONTInuous:STATe.....	673

[SOURce<hw>]:FREQuency:MODE <Mode>

Sets the frequency mode for generating the RF output signal. The selected mode determines the parameters to be used for further frequency settings.

Parameters:

<Mode>

CW | FIXed | SWEep | LIST | COMBined

CW|FIXed

Sets the fixed frequency mode. CW and FIXed are synonyms. The instrument operates at a defined frequency, set with command [:SOURce<hw>] :FREQuency [:CW|FIXed].

SWEEp

Sets sweep mode.

The instrument processes frequency (and level) settings in defined sweep steps.

Set the range and current frequency with the commands:

[:SOURce<hw>] :FREQuency:STARt on page 669 and [:SOURce<hw>] :FREQuency:STOP on page 670,
[:SOURce<hw>] :FREQuency:CENTer on page 669,
[:SOURce<hw>] :FREQuency:SPAN on page 669,
[:SOURce<hw>] :FREQuency:MANual on page 668

LIST

Sets list mode.

The instrument processes frequency and level settings by means of values loaded from a list.

To configure list mode settings, use the commands of the [Chapter 14.17.7, "SOURce:LIST subsystem"](#), on page 687.

COMBined

Sets the combined RF frequency / level sweep mode.

The instrument processes frequency and level settings in defined sweep steps.

Set the range and current frequency with the commands:

[:SOURce<hw>] :COMBined:FREQuency:STARt on page 730 and [:SOURce<hw>] :COMBined:FREQuency:STOP on page 730,
[:SOURce<hw>] :COMBined:POWer:STARt on page 730 and [:SOURce<hw>] :COMBined:POWer:STOP on page 731

*RST: CW

Example:

See [Example"Frequency configuration"](#) on page 664, and [Example"Setup an RF frequency or power sweep"](#) on page 720

Manual operation:

See ["State \(RF frequency sweep\)"](#) on page 185
See ["State \(RF frequency / level sweep\)"](#) on page 186
See ["State"](#) on page 199

[:SOURce<hw>] :FREQuency[:CW|FIXed] <Fixed>

Sets the frequency of the RF output signal in the selected path.

The effect depends on the selected mode:

- In CW mode ([FREQ:MODE CW](#) | [FIXed](#)), the instrument operates at a fixed frequency.
- In sweep mode ([FREQ:MODE SWE](#)), the value applies to the sweep frequency. The instrument processes the frequency settings in defined sweep steps.

- In user mode (`FREQ:STEP:MODE USER`), you can vary the current frequency step by step.

Parameters:

<Fixed>

float

The following settings influence the value range:

An offset set with the command `[:SOURce<hw>] :FREQuency:OFFSet`

Numerical value

Sets the frequency in CW and sweep mode

UP|DOWN

Varies the frequency step by step in user mode.

The frequency is increased or decreased by the value set with the command `[:SOURce<hw>] :FREQuency:STEP [:INCRement]`.

Range: (RFmin + OFFSet) to (RFmax + OFFSet)

*RST: 100 MHz

Example:

See [Example "Frequency configuration"](#) on page 664

Example:

See [Example "Setup an RF frequency or power sweep"](#) on page 720

Options:

RFmax depends on the installed options, for example 3 GHz with R&S SMAB-B103

Manual operation:

See ["Frequency"](#) on page 70

`[:SOURce<hw>] :FREQuency [:CW | FIXed] :RCL <Rcl>`

Set whether the RF frequency value is retained or taken from a loaded instrument configuration, when you recall instrument settings with command `*RCL`.

Parameters:

<Rcl>

INCLude | EXCLude

INCLude

Takes the frequency value of the loaded settings.

EXCLude

Retains the current frequency when an instrument configuration is loaded.

*RST: INCLude

Example:

`SOURce1:FREQuency:CW:RCL INCLude`

Manual operation:

See ["Exclude Frequency"](#) on page 317

[:SOURce<hw>]:FREQuency:MANual <Manual>

Sets the frequency and triggers a sweep step manually if [SWEep:MODE MAN](#).

Parameters:

<Manual>

float

You can select any frequency within the setting range, where:

START is set with [\[:SOURce<hw>\]:FREQuency:START](#)

STOP is set with [\[:SOURce<hw>\]:FREQuency:STOP](#)

OFFSet is set with [\[:SOURce<hw>\]:FREQuency:OFFSet](#)

Range: (START + OFFSet) to (STOP + OFFSet)

Increment: 0.01Hz

*RST: 100 MHz

Default unit: Hz

Example:

See [Example"Setup an RF frequency or power sweep"](#) on page 720

Manual operation: See ["Current Frequency"](#) on page 186

[:SOURce<hw>]:FREQuency:MULTiplier <Multiplier>

Sets the multiplication factor $N_{\text{FREQ:MULT}}$ of a subsequent downstream instrument.

The parameters offset $f_{\text{FREQ:OFFSer}}$ and multiplier $N_{\text{FREQ:MULT}}$ affect the frequency value set with the command [FREQ](#).

The query [FREQ?](#) returns the value corresponding to the formula:

$$f_{\text{FREQ}} = f_{\text{RFout}} * N_{\text{FREQ:MULT}} + f_{\text{FREQ:OFFSer}}$$

See ["RF frequency and level display with a downstream instrument"](#) on page 64.

Parameters:

<Multiplier>

float

Range: -10000 to 10000

Increment: 0.001

*RST: 1

Example:

See [Example"Frequency configuration"](#) on page 664

Manual operation: See ["Multiplier"](#) on page 71

[:SOURce<hw>]:FREQuency:OFFSet <Offset>

Sets the frequency offset $f_{\text{FREQ:OFFSet}}$ of a downstream instrument.

The parameters offset $f_{\text{FREQ:OFFSer}}$ and multiplier $N_{\text{FREQ:MULT}}$ affect the frequency value set with the command [FREQ](#).

The query [FREQ?](#) returns the value corresponding to the formula:

$$f_{\text{FREQ}} = f_{\text{RFout}} * N_{\text{FREQ:MULT}} + f_{\text{FREQ:OFFSer}}$$

See ["RF frequency and level display with a downstream instrument"](#) on page 64.

Note: The offset also affects RF frequency sweep.

Parameters:

<Offset> float
Increment: 0.01
*RST: 0

Example: See [Example"Frequency configuration"](#) on page 664

Manual operation: See ["Offset"](#) on page 71

[[:SOURce<hw>]:FREQUENCY:CENTer <Center>

Sets the center frequency of the sweep.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Parameters:

<Center> float
Range: 300 kHz to RFmax
Increment: 0.01 Hz
*RST: 300E6
Default unit: Hz

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720

Manual operation: See ["Center Frequency"](#) on page 191

**[[:SOURce<hw>]:FREQUENCY:SPAN **

Sets the span of the frequency sweep range.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Parameters:

 float
Full frequency range
Increment: 0.01
*RST: 400E6

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720

Manual operation: See ["Span"](#) on page 192

[[:SOURce<hw>]:FREQUENCY:START <Start>

Sets the start frequency for the RF sweep.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Parameters:

<Start> float
 Range: 300kHz to RFmax
 Increment: 0.01Hz
 *RST: 100 MHz

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720

Manual operation: See ["Start Frequency/Stop Frequency"](#) on page 191

[[:SOURce<hw>]:FREQuency:STOP <Stop>

Sets the stop frequency range for the RF sweep.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Parameters:

<Stop> float
 Range: 300kHz to RFmax
 Increment: 0.01Hz
 *RST: 500 MHz
 Default unit: Hz

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720

Manual operation: See ["Start Frequency/Stop Frequency"](#) on page 191

[[:SOURce<hw>]:FREQuency:STEP:MODE <Mode>

Defines the type of step size to vary the RF frequency at discrete steps with the commands [FREQ UP](#) or [FREQ DOWN](#).

Parameters:

<Mode> DECimal | USER
DECimal
 Increases or decreases the level in steps of ten.
USER
 Increases or decreases the level in increments, set with the command [FREQ:STEP\[:INCR\]](#).
 *RST: DECimal

Example: // increasing the RF frequency with a step size of 50 KHz
 SOURce1:FREQuency:STEP 50E3
 SOURce1:FREQuency:STEP:MODE USER
 SOURce1:FREQuency:CW UP

Manual operation: See ["Variation Active"](#) on page 71

[[:SOURce<hw>]:FREQUENCY:STEP[:INCRement] <Increment>

Sets the step width.

You can use this value to vary the RF frequency with command [FREQ UP](#) or [FREQ DOWN](#), if you have activated [FREQ:STEP:MODE USER](#).

Note: This value also applies to the step width of the rotary knob on the instrument and, in user-defined step mode, increases or decreases the frequency.

Parameters:

<Increment> float
 Range: 0 Hz to RFmax - 100 kHz
 Increment: 0.01 Hz
 *RST: 1E6

Example: See [Example"Frequency configuration"](#) on page 664

Manual operation: See ["Variation Step"](#) on page 71

[[:SOURce<hw>]:FREQUENCY:PLL:MODE <Mode>

Selects the PLL (Phase Locked Loop) bandwidth of the main synthesizer.

Parameters:

<Mode> NORMal | NARRow
NORMal
 Maximum modulation bandwidth and FM/PhiM deviation.
NARRow
 Narrow PLL bandwidth
 *RST: NORMal

Example: `SOURce:FREQUENCY:PLL:MODE NORMal`

Manual operation: See ["Main PLL Bandwidth"](#) on page 71

[[:SOURce<hw>]:FREQUENCY:PHASE:CONTinuous:HIGh?

Queries the maximum frequency of the frequency range for phase continuous settings.

The maximum frequency of the frequency range depends on the mode selected with the command [\[:SOURce<hw>\]:FREQUENCY:PHASE:CONTinuous:MODE](#).

Return values:

<High> float
 Range: 1E5 to 6E9
 Increment: 0.01
 *RST: 1E9
 Default unit: Hz

Example: See [Example"Setting a phase continuous frequency range"](#) on page 665.

Usage: Query only

Options: R&S SMAB-B22

Manual operation: See ["Frequency Range From / To"](#) on page 78

[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:LOW?

Queries the minimum frequency of the frequency range for phase continuous settings.

The minimum frequency of the frequency range depends on the mode selected with the command `[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:MODE`.

Return values:

<Low> float
 Range: 1E5 to 6E9
 Increment: 0.01
 *RST: 1E9
 Default unit: Hz

Example: See [Example "Setting a phase continuous frequency range"](#) on page 665.

Usage: Query only

Options: R&S SMAB-B22

Manual operation: See ["Frequency Range From / To"](#) on page 78

[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:MODE <Mode>

Selects the mode that determines the frequency range for the phase continuity.

To query the frequency range, use the commands `[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:HIGH?` and `[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:LOW?`

Parameters:

<Mode> NARRow | WIDE
NARRow
 Small frequency range, asymmetrically around the RF frequency.
WIDE
 Large frequency range, symmetrically around the RF frequency.
 *RST: NARRow

Example: See `[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:LOW?` on page 672

Options: R&S SMAB-B711 (required for frequency range WIDE)
 R&S SMAB-B22

Manual operation: See ["Frequency Range"](#) on page 78

[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:STATe <State>

Activates phase continuity of the RF frequency.

The frequency range is limited and varies depending on the set RF frequency. You can query the range with the commands `[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:HIGH?` on page 671 and `[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:LOW?` on page 672.

Note: Restricted structure of command line.

In phase continuous mode, the R&S SMA100B only processes the first command of a command line and ignores further commands if they are on the same line.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example "Setting a phase continuous frequency range"](#) on page 665.

Options: R&S SMAB-B22

Manual operation: See ["Phase Continuous Active"](#) on page 77

14.17.5 SOURce:INPut subsystem

The `SOURce:INPut` subsystem contains the commands for configuring the inputs for external modulation signals. The instrument trigger setting influences all sweeps and is effective in the List mode (Instrument Trigger).

<code>[:SOURce<hw>]:INPut:MODext:COUPling<ch></code>	673
<code>[:SOURce<hw>]:INPut:MODext:IMPedance<ch></code>	674
<code>[:SOURce]:INPut:TRIGger:SLOPe</code>	674

[:SOURce<hw>]:INPut:MODext:COUPling<ch> <Coupling>

Selects the coupling mode for an externally applied modulation signal.

Parameters:

<Coupling> AC | DC
AC
 Passes the AC signal component of the modulation signal.
DC
 Passes the modulation signal with both components, AC and DC.
 For active external exponential AM, automatically sets `[:SOURce<hw>]:INPut:MODext:COUPling<ch>`DC.
 *RST: AC

Example: `INP:MOD:COUP AC`
 Selects the coupling mode AC for an externally applied modulation signal.

Manual operation: See ["Coupling \(AC/DC\)"](#) on page 116

[:SOURce<hw>]:INPut:MODext:IMPedance<ch> <Impedance>

Sets the impedance for the externally supplied modulation signal.

Parameters:

<Impedance> G50 | G600 | HIGH
 G50 = 50 Ohm to ground
 G600 = 600 Ohm to ground
 HIGH = 100 kOhm to ground
 *RST: HIGH

Example: See [\[:SOURce<hw>\]:INPut:MODext:COUPling<ch>](#)
 on page 673.

Manual operation: See ["Impedance"](#) on page 116

[:SOURce]:INPut:TRIGger:SLOPe <Slope>

Sets the polarity of the active slope of an applied instrument trigger.

Parameters:

<Slope> NEGative | POSitive
 *RST: POSitive

Example: INP:TRIG:SLOP NEG
 Activates the falling slope of the external trigger signal at the
 trigger input.

Manual operation: See ["Trigger Slope"](#) on page 190

14.17.6 SOURce:LFOutput subsystem

The `SOURce:LFOutput` subsystem contains the commands for setting the LF signal source in CW and Sweep mode and for analog modulation.

Example: Setup an LF sweep

The following example shows a command sequence to set up an LF sweep.

```
// Reset the instrument to start from an initial state
*RST; *CLS

// Set the trigger mode, the sweep mode and the sweep range
TRIGger1:LFFSweep:SOURce SINGLE
SOURce1:LFOutput1:SWEep:FREQuency:MODE AUTO
SOURce1:LFOutput1:FREQuency:START 1 kHz
SOURce1:LFOutput1:FREQuency:STOP 7 kHz

// Select linear spacing
```

```

// Select the waveform shape for the frequency sweep cycle
// Set the step width and the dwell time.
SOURcel:LFOutput1:SWEep:FREQuency:SPACing LINear
SOURcel:LFOutput1:SWEep:FREQuency:SHApe SAWtooth
SOURcel:LFOutput1:SWEep:FREQuency:STEP:LINear 100 Hz
SOURcel:LFOutput1:SWEep:FREQuency:DWELl 150 ms
// Alternatively to the step width set the number of steps
SOURcel:LFOutput1:SWEep:FREQuency:POINts 61

// Activate change to start frequency while waiting for next trigger
// Prerequisites: sweep mode single and sweep waveform sawtooth
SOURcel:LFOutput:SWEep:FREQuency:RETRace 1

// Activate the LF frequency sweep
SOURcel:LFOutput:FREQuency:MODE SWE

// Trigger the sweep (depending on the set mode) and query the status
// Perform a one-off LF sweep
SOURcel:LFOutput1:SWEep:FREQuency:EXECute
SOURcel:LFOutput1:SWEep:FREQuency:RUNning?
// 1
// the sweep is running

// *****
// For manual step LF sweep use the following commands
*RST; *CLS
SOURcel:LFOutput:SWEep:FREQuency:MODE MANual
// Activate the LF frequency sweep
SOURcel:LFOutput:FREQuency:MODE SWEep
// Activate LF Output1.
SOURcel:LFOutput1:STATe 1
// Input the frequency manually for each step
SOURcel:LFOutput1:FREQuency:MANual 2 kHz
SOURcel:LFOutput1:FREQuency:MANual 2.1 kHz
// Alternatively use UP or DOWN parameter with set step width.
SOURcel:LFOutput1:SWEep:FREQuency:STEP:LINear 500 Hz
SOURcel:LFOutput1:FREQuency:MANual UP

```

Example: Configuring the LF generator

The following is a simple example on how to configure the LF generator and output the generated signal.

```

// configure the signal of the LF1 generator
SOURcel:LFOutput1:SHApe SQU
SOURcel:LFOutput1:SHApe:PULSe:PERiod 0.001
SOURcel:LFOutput1:SHApe:PULSe:WIDTh 0.0005
SOURcel:LFOutput1:SHApe:PULSe:DCYCle 0.5
// configure the signal of the LF1 generator
SOURcel:LFOutput2:SHApe SINE
SOURcel:LFOutput2:FREQuency 1000000

```

```

SOURce1:LFOutput2:PERiod?
// 0.000001

// changing the LF signal shape
// SOURce1:LFOutput2:SHApe TRAP
// SOURce1:LFOutput2:SHApe:PULSe:PERiod 0.2
// SOURce1:LFOutput2:SHApe:TRAPeZe:RISE 0.0001
// SOURce1:LFOutput2:SHApe:TRAPeZe:FALL 0.001
// SOURce1:LFOutput2:SHApe:TRAPeZe:FALL 0.0001
// SOURce1:LFOutput2:SHApe:TRAPeZe:HIGH 0.0005
// SOURce1:LFOutput2:SHApe TRI
// SOURce1:LFOutput2:SHApe:PULSe:PERiod 0.1
// SOURce1:LFOutput2:SHApe:TRIangle:RISE 0.0001

// activate the LF output and select the LF1 as signal source
// configure the LF output signal
SOURce1:LFOutput1:FREQuency:MODE CW
SOURce1:LFOutput1:STATe 1
SOURce1:LFOutput1:SOURce LF1
SOURce1:LFOutput1:INTernal:VOLTage 1
SOURce1:LFOutput1:OFFSet 0.001

```

- [LF generator settings](#)..... 676
- [LF sweep settings](#)..... 683

14.17.6.1 LF generator settings

With the commands described in this section, you can configure the LF signal source.

[:SOURce]:LFOutput<ch>:BANDwidth?	677
[:SOURce]:LFOutput<ch>:FREQuency	677
[:SOURce<hw>]:LFOutput<ch>:PERiod?	677
[:SOURce<hw>]:LFOutput:FREQuency:MANual	678
[:SOURce<hw>]:LFOutput:FREQuency:MODE	678
[:SOURce<hw>]:LFOutput:FREQuency:STOP	679
[:SOURce<hw>]:LFOutput:FREQuency:STARt	679
[:SOURce]:LFOutput<ch>[:STATe]	679
[:SOURce]:LFOutput<ch>:INTernal:VOLTage	679
[:SOURce]:LFOutput:OFFSet	680
[:SOURce]:LFOutput<ch>:SOURce	680
[:SOURce]:LFOutput<ch>:SOURce:PATH	680
[:SOURce]:LFOutput:VOLTage	680
[:SOURce<hw>]:LFOutput<ch>:SHApe	681
[:SOURce<hw>]:LFOutput<ch>:SHApe:PULSe:DCYCLE	681
[:SOURce<hw>]:LFOutput<ch>:SHApe:PULSe:PERiod	681
[:SOURce<hw>]:LFOutput<ch>:SHApe:PULSe:WIDTh	682
[:SOURce<hw>]:LFOutput<ch>:SHApe:TRAPeZe:FALL	682
[:SOURce<hw>]:LFOutput<ch>:SHApe:TRAPeZe:HIGH	682
[:SOURce<hw>]:LFOutput<ch>:SHApe:TRAPeZe:PERiod	682

[:SOURce<hw>]:LFOOutput<ch>:SHAPE:TRAPeZe:RISE.....	683
[:SOURce<hw>]:LFOOutput<ch>:SHAPE:TRIangle:PERiod.....	683
[:SOURce<hw>]:LFOOutput<ch>:SHAPE:TRIangle:RISE.....	683

`[:SOURce]:LFOOutput<ch>:BANDwidth?`

Queries the bandwidth of the external LF signal.

Return values:

<Bandwidth> BW0M2 | BW10m
 *RST: BW10m

Example:

```
LFO:BAND?
// BW10m
// the bandwidth of the externally supplied LF signal is 10 MHz
```

Usage: Query only

Manual operation: See "[Bandwidth](#)" on page 116

`[:SOURce]:LFOOutput<ch>:FREQuency <Frequency>`

Sets the frequency of the LF signal in `[:SOURce<hw>]:LFOOutput:FREQuency:MODE` CW|FIXed mode.

Note

- If signal source "Internal" is set, the instrument performs the analog modulations (AM/FM/PhiM/PM) with this frequency.
- In sweep mode (`[:SOURce<hw>]:LFOOutput:FREQuency:MODE` SWE), the frequency is coupled with the sweep frequency.

Parameters:

<Frequency> float
 Range: depends on the installed options
 Increment: 0.01
 *RST: 1000
 Default unit: Hz

Example:

```
SOURce1:LFOOutput1:FREQuency 5 kHz
// sets the LF frequency
```

Manual operation: See "[Frequency](#)" on page 114

`[:SOURce<hw>]:LFOOutput<ch>:PERiod?`

Queries the repetition frequency of the sine signal.

Return values:

<LfSinePeriod> float
 Range: 1E-6 to 100
 Increment: 10E-9
 *RST: 0.001
 Default unit: s

Example: See [Example "Configuring the LF generator"](#) on page 675.

Usage: Query only

[:SOURce<hw>]:LFOutput:FREQuency:MANual <Manual>

Sets the frequency of the subsequent sweep step if [LFO:SWE:MODE MAN](#).

Use a separate command for each sweep step.

Parameters:

<Manual> float
 You can select any value within the setting range, where:
 START is set with [\[:SOURce<hw>\]:LFOutput:FREQuency:START](#)
 STOP is set with [\[:SOURce<hw>\]:LFOutput:FREQuency:STOP](#)
 Range: START to STOP
 Increment: 0.1
 *RST: 1000

Example: See [Example "Setup an LF sweep"](#) on page 674.

Manual operation: See ["Current Frequency"](#) on page 186

[:SOURce<hw>]:LFOutput:FREQuency:MODE <Mode>

Sets the mode for the output of the LF generator frequency, and determines the commands to be used for frequency settings.

Parameters:

<Mode> CW | FIXed | SWEep
CW|FIXed
 Sets the fixed-frequency mode. CW and FIXed are synonyms.
 To set the output frequency, use command [\[:SOURce\]:LFOutput<ch>:FREQuency](#)
SWEep
 Sets sweep mode.
 To set the frequency, use the commands:
[\[:SOURce<hw>\]:LFOutput:FREQuency:START](#) and [\[:SOURce<hw>\]:LFOutput:FREQuency:STOP](#)
 Or [\[:SOURce<hw>\]:LFOutput:FREQuency:MANual](#)
 *RST: CW

Example: See [Example"Setup an LF sweep"](#) on page 674.

Manual operation: See ["State \(LF frequency sweep\)"](#) on page 112

[:SOURce<hw>]:LFOutput:FREQuency:STOP <Stop>

[:SOURce<hw>]:LFOutput:FREQuency:START <Start>

Sets the start/stop frequency for [\[:SOURce<hw>\]:LFOutput:FREQuency:MODE](#) SWEEp.

Parameters:

<Start> float
 Range: 0.1 Hz to 1 MHz
 Increment: 0.1
 *RST: 1 KHz

Example: See [Example"Setup an LF sweep"](#) on page 674.

Manual operation: See ["Start Frequency/Stop Frequency"](#) on page 191

[:SOURce]:LFOutput<ch>[:STATE] <State>

Activates LF signal output.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example"Configuring the LF generator"](#) on page 675.

Manual operation: See ["State"](#) on page 118

[:SOURce]:LFOutput<ch>:INTernal:VOLTage <Voltage>

Sets the output voltage for the LF generators.

The sum of both values must not exceed the overall output voltage, set with command [\[:SOURce\]:LFOutput:VOLTage](#).

Suffix:

<ch> [1]|2
 LF1 and LF2

Parameters:

<Voltage> float
 Range: 0 to 4
 Increment: 0.001
 *RST: 1

Example: See [Example"Configuring the LF generator"](#) on page 675.

Manual operation: See ["Output Voltage"](#) on page 119

[:SOURce]:LFOutput:OFFSet <Offset>

Sets a DC offset at the LF Output.

Parameters:

<Offset>	float
Range:	depends on lfo voltage
Increment:	0.001
*RST:	0

Example: See [Example "Configuring the LF generator"](#) on page 675.

Manual operation: See ["DC-Offset"](#) on page 119

[:SOURce]:LFOutput<ch>:SOURce <Source>

Determines the LF signal to be synchronized, when monitoring is enabled.

Parameters:

<Source>	LF1 LF2 NOISe AM FMPM EXT1 EXT2
----------	-----------------------------------------------

LF1|LF2
Selects an internally generated LF signal.

NOISe
Selects an internally generated noise signal.

EXT1|EXT2
Selects an externally supplied LF signal

AM
Selects the AM signal.

FMPM
Selects the signal also used by the frequency or phase modulations.

*RST: LF1

Example: See [Example "Configuring the LF generator"](#) on page 675.

Manual operation: See ["Source"](#) on page 119

[:SOURce]:LFOutput<ch>:SOURce:PATH <SourPath>

Determines the path of the LF output source.

Parameters:

<SourPath>	A B
*RST:	A

Example: LFO:SOUR:PATH?
Queries the currently set path for the LF output signal source.

[:SOURce]:LFOutput:VOLTage <Voltage>

Sets the voltage of the LF output.

Parameters:

<Voltage> float
 Range: dynamic (see data sheet)
 Increment: 0.001
 *RST: 1

Example:

SOURce:LFOutput:VOLTage 1.5

[[:SOURce<hw>]:LFOutput<ch>:SHAPE <Shape>

Selects the waveform shape of the LF signal.

Parameters:

<Shape> SINE | SQUare | PULSe | TRIangle | TRAPeze
 *RST: SINE

Example:

See [Example"Configuring the LF generator"](#) on page 675.

Options:

TRIangle|TRAPeze require R&S SMAB-K24

Manual operation:

See ["Shape"](#) on page 112

[[:SOURce<hw>]:LFOutput<ch>:SHAPE:PULSe:DCYCLE <DCycle>

Sets the duty cycle for the shape pulse.

Parameters:

<DCycle> float
 Range: 1E-6 to 100
 Increment: 1E-6
 *RST: 50
 Default unit: PCT

Example:

See [Example"Configuring the LF generator"](#) on page 675.

Manual operation:

See ["Pulse Duty Cycle"](#) on page 114

[[:SOURce<hw>]:LFOutput<ch>:SHAPE:PULSe:PERiod <Period>

Sets the period of the generated pulse. The period determines the repetition frequency of the internal signal.

Parameters:

<Period> float
 Range: 1E-6 to 100
 Increment: 1E-8
 *RST: 1E-3

Example:

See [Example"Configuring the LF generator"](#) on page 675.

Manual operation:

See ["Period"](#) on page 114

[:SOURce<hw>]:LFOutput<ch>:SHAPE:PULSE:WIDTH <Width>

Sets the pulse width of the generated pulse.

Parameters:

<Width> float
 Range: 1E-6 to 100
 Increment: 1E-8
 *RST: 5E-4

Example: See [Example"Configuring the LF generator"](#) on page 675.

Manual operation: See ["Pulse Width"](#) on page 114

[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:FALL <Fall>

Selects the fall time for the trapezoid shape of the LF generator.

Parameters:

<Fall> float
 Range: 1E-6 to 100
 Increment: 10E-9
 *RST: 250E-6

Example: See [Example"Configuring the LF generator"](#) on page 675.

Manual operation: See ["Trapezoid Rise / Fall"](#) on page 115

[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:HIGh <High>

Sets the high time for the trapezoid signal of the LF generator.

Parameters:

<High> float
 Range: 1E-6 to 100
 Increment: 10E-9
 *RST: 250E-6

Example: See [Example"Configuring the LF generator"](#) on page 675.

Manual operation: See ["Trapezoid High"](#) on page 115

[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:PERiod <Period>

Sets the period of the generated trapezoid shape. The period determines the repetition frequency of the internal signal.

Parameters:

<Period> float
 Range: 1E-6 to 100
 Increment: 1E-8
 *RST: 1E-3

Example: See [Example"Configuring the LF generator"](#) on page 675.

Manual operation: See ["Period"](#) on page 114

[[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:RISE <Rise>

Selects the rise time for the trapezoid shape of the LF generator.

Parameters:

<Rise>	float
Range:	1E-6 to 100
Increment:	10E-9
*RST:	250E-6

Example: See [Example"Configuring the LF generator"](#) on page 675.

Manual operation: See ["Trapezoid Rise / Fall"](#) on page 115

[[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRIangle:PERiod <Period>

Sets the period of the generated pulse. The period determines the repetition frequency of the internal signal.

Parameters:

<Period>	float
Range:	1E-6 to 100
Increment:	10E-9
*RST:	0.001

Example: See [Example"Configuring the LF generator"](#) on page 675.

Manual operation: See ["Period"](#) on page 114

[[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRIangle:RISE <Rise>

Selects the rise time for the triangle single of the LF generator.

Parameters:

<Rise>	float
Range:	1E-6 to 100
Increment:	10E-9
*RST:	0.5E-3

Example: See [Example"Configuring the LF generator"](#) on page 675.

Manual operation: See ["Triangle Rise"](#) on page 115

14.17.6.2 LF sweep settings

With the commands described in this section, you can configure the sweep of the LF signal.

[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:DWELI	684
[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:EXECute	684
[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:MODE	684
[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:POINts	685
[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:RETRace	685
[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:RUNNing?	685
[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:SHAPE	686
[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:SPACing	686
[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:STEP:LOGarithmic	686
[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:STEP[LINear]	687

`[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:DWELI <Dwell>`

Sets the dwell time for each frequency step of the sweep.

Parameters:

`<Dwell>` float
 Range: 0.001 to 100
 Increment: 100E-6
 *RST: 0.01
 Default unit: s

Example: See [Example"Setup an LF sweep"](#) on page 674.

Manual operation: See ["Dwell Time"](#) on page 189

`[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:EXECute`

Immediately starts an LF sweep.

[\[:SOURce<hw>\]:LFOutput:SWEep\[:FREQUENCY\]:MODE](#) determines which sweep is executed, e.g. `SOURce:LFOutput:SWEep:FREQUENCY:MODE STEP`.

Example: See [Example"Setup an LF sweep"](#) on page 674.

Usage: Event

Manual operation: See ["Execute Single Sweep"](#) on page 190

`[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:MODE <Mode>`

Sets the cycle mode of the LF sweep.

Parameters:

`<Mode>` AUTO | MANual | STEP

AUTO

Performs a complete sweep cycle from the start to the end value when a trigger event occurs.

The dwell time determines the time period until the signal switches to the next step.

MANual

Performs a single sweep step when a manual trigger event occurs.

The trigger system is not active. To trigger each frequency step of the sweep individually, use the command `[:SOURce<hw>] :LFOutput:FREQUENCY:MANual` on page 678.

STEP

Each trigger command triggers one sweep step only.

The frequency increases by the value set with the commands:

`[:SOURce<hw>] :LFOutput:SWEep[:FREQUENCY]:STEP[:LINear]` (linear spacing)

`[:SOURce<hw>] :LFOutput:SWEep[:FREQUENCY]:STEP:LOGarithmic` (logarithmic spacing)

*RST: AUTO

Example: See [Example "Setup an LF sweep"](#) on page 674.

Manual operation: See ["Mode"](#) on page 186

[:SOURce<hw>] :LFOutput:SWEep[:FREQUENCY]:POINTs <Points>

Sets the number of steps in an LF sweep.

For information on how the value is calculated and the interdependency with other parameters, see [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178

Parameters:

<Points> integer
Range: 2 to POINTs
*RST: 50

Example: See [Example "Setup an LF sweep"](#) on page 674.

[:SOURce<hw>] :LFOutput:SWEep[:FREQUENCY]:RETRace <State>

Activates that the signal changes to the start frequency value while it is waiting for the next trigger event.

You can enable this feature, when you are working with sawtooth shapes in sweep mode "Single" or "External Single".

Parameters:

<State> 1 | ON | 0 | OFF
*RST: 0

Manual operation: See ["Retrace"](#) on page 187

[:SOURce<hw>] :LFOutput:SWEep[:FREQUENCY]:RUNNing?

Queries the current status of the LF frequency sweep mode.

Return values:

<State> 1 | ON | 0 | OFF

Example: See [Example"Setup an LF sweep"](#) on page 674.**Usage:** Query only**[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:SHAPE <Shape>**

Sets the cycle mode for a sweep sequence (shape).

Parameters:<Shape> SAWTooth | TRIangle
*RST: SAWTooth**Example:** See [Example"Setup an LF sweep"](#) on page 674.**Manual operation:** See ["Shape"](#) on page 188**[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:SPACing <Spacing>**

Selects linear or logarithmic sweep spacing.

Parameters:<Spacing> LINear | LOGarithmic
*RST: LINear**Example:** See [Example"Setup an LF sweep"](#) on page 674.**Manual operation:** See ["Spacing"](#) on page 189**[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:STEP:LOGarithmic
<Logarithmic>**

Sets the step width factor for logarithmic sweeps to calculate the frequencies of the steps.

For information on how the value is calculated and the interdependency with other parameters, see [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178**Parameters:**<Logarithmic> float
The unit is mandatory
Range: 0.01 to 100
Increment: 0.01
*RST: 1
Default unit: PCT**Example:** See [Example"Setup an LF sweep"](#) on page 674.**Manual operation:** See ["Step Linear/Step Logarithmic"](#) on page 192

[[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:STEP[:LINear] <Linear>

Sets the step width for the linear sweep.

For information on how the value is calculated and the interdependency with other parameters, see [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178

Parameters:

<Linear>	float
Range:	0.1 to STOP-START
Increment:	0.1
*RST:	1000

Example: See [Example "Setup an LF sweep"](#) on page 674.

Manual operation: See ["Step Linear/Step Logarithmic"](#) on page 192

14.17.7 SOURce:LIST subsystem

The SOURce:LIST subsystem contains all commands for defining lists and for handling of list files.

List files have the predefined file extension *.lsw.

Refer to [Chapter 14.5.2, "Accessing files in the default or in a specified directory"](#), on page 471 for general information on file handling in the default and in a specific directory.



- *RST does not affect data lists.
- SCPI refers to the individual lists as segments.

Example: Create an RF list and activate the list mode

The following example shows a command sequence to create an RF list and to activate the list mode. Further hardware settings are not considered.

```
// Reset the instrument to start from an initial state
// Query the available list files in the default
// directory /var/user
// Select the list file or create it (if not existing)
*RST; *CLS
SOUR1:LIST:CAT?
// Response:- shows the name of available list files (if applicable)
SOUR1:LIST:SEL "/var/user/list1.lsw"

// Write the frequency/level/dwell time values in the selected list file
// existing data is overwritten
// Query the number of frequency/power/dwell time entries in the selected list
// Query the amount of free memory (in bytes) for list mode lists
SOUR1:LIST:FREQ 58 MHz, 61 MHz, 73 MHz, 86 MHz, 91 MHz, 92 MHz, 98 MHz
SOUR1:LIST:POW 13 dBm, 12 dBm, 5 dBm, 3 dBm, 0 dBm, 4 dBm, 6 dBm
```

```

SOUR1:LIST:DWEL:LIST 10000, 100000, 200000, 19000, 10000, 150000, 220000
SOUR1:LIST:FREQ:POIN?
// 7
SOUR1:LIST:POW:POINT?
// 7
SOUR1:LIST:DWEL:LIST:POIN?
// 7
SOUR1:LIST:FREE?
// 2147483647 (bytes of free memory)

// Use dwell times from list
// Configure the list mode parameters
// Enable RF output
SOUR1:LIST:MODE AUTO
SOUR1:LIST:TRIG:SOUR AUTO
SOUR1:LIST:DWEL:MODE "LIST"

OUTP1:STAT ON

// Use global dwell time
// Set only a part of the list (value pairs 3 to 5) to be processed
// Configure the list mode parameters using global dwell time
// Enable RF output
SOUR1:LIST:IND:START 2
SOUR1:LIST:IND:STOP 4
SOUR1:LIST:MODE AUTO
SOUR1:LIST:TRIG:SOUR AUTO
SOUR1:LIST:DWEL:LIST 500 ms
OUTP1:STAT ON

// Enable the list mode
// Trigger the list (depending on the mode, not needed with trigger
// mode AUTO); query the current index
// Reset the list to the starting point
SOUR1:FREQ:MODE LIST
SOUR1:LIST:TRIG:EXEC
SOUR1:LIST:RUNN?
SOUR1:LIST:IND?
// 3
// value changes when the value is queried again
SOUR1:LIST:RES

// For list mode STEP use the following commands
*RST; *CLS
// Change list mode to STEP
SOUR1:LIST:MODE STEP
// Activate RF Output1
OUTP1:STAT 1
// Activate the list mode
SOUR1:FREQ:MODE LIST
// For each step: select frequency/powerlevel pair as index from the list

```



```

SOUR1:LIST:IND 2
SOUR1:LIST:IND 3
SOUR1:LIST:IND 4

// Use the selected list for path B (with List Mode B default settings)
SOUR2:LIST:SEL "/var/user/list1.lsw"
OUTP2:STAT ON
SOUR2:FREQ:MODE LIST
SOUR2:LIST:IND?
// 2
// value changes when the value is queried again

// Deactivate the list mode
SOUR1:FREQ:MODE CW

```

Example: List mode data exchange

The following example shows a command sequence to export a list (here the RF list created with the example before) into an ASCII file. Further hardware settings are not considered.

```

*RST; *CLS
LIST:DEXC:MODE EXP

// Set ASCII data parameters
// Set the ASCII file extension, the decimal separator
// and the column separator for the ASCII data
SOUR1:LIST:DEXC:AFIL:EXT CSV
SOUR1:LIST:DEXC:AFIL:SEP:DEC DOT
SOUR1:LIST:DEXC:AFIL:SEP:COL COMM

// Select source and destination path/directory
// Query available listfiles in default directory "/var/user"
SOUR1:LIST:CAT?
// list1
SOUR1:LIST:DEXC:AFIL:SEL "/var/user/list1ASCII"
SOUR1:LIST:DEXC:SEL "/var/user/list1"

// Export the list file data into the ASCII file
SOUR1:LIST:DEXC:EXEC

// Query the available ASCII files with extension .csv
SOUR1:LIST:DEXC:AFIL:CAT?
// Response: "list1ASCII"

// Deactivate the list mode
SOUR1:FREQ:MODE CW

```

- [List mode settings](#).....690
- [List mode file operation](#).....695
- [List mode data exchange](#).....697

14.17.7.1 List mode settings

With the following commands, you can create list mode data, select the trigger mode and determine the dwell time.

<code>[SOURce<hw>]:LIST:DWELI</code>	690
<code>[SOURce<hw>]:LIST:DWELI:MODE</code>	690
<code>[SOURce<hw>]:LIST:DWELI:LIST</code>	691
<code>[SOURce<hw>]:LIST:DWELI:LIST:POINTS?</code>	691
<code>[SOURce<hw>]:LIST:FREQuency</code>	691
<code>[SOURce<hw>]:LIST:FREQuency:POINTS?</code>	692
<code>[SOURce<hw>]:LIST:INDEx</code>	692
<code>[SOURce<hw>]:LIST:INDEx:START</code>	692
<code>[SOURce<hw>]:LIST:INDEx:STOP</code>	692
<code>[SOURce<hw>]:LIST:MODE</code>	693
<code>[SOURce<hw>]:LIST:POWEr</code>	693
<code>[SOURce<hw>]:LIST:POWEr:POINTS?</code>	694
<code>[SOURce<hw>]:LIST:TRIGger:EXECute</code>	694
<code>[SOURce<hw>]:LIST:TRIGger:SOURce</code>	694
<code>[SOURce<hw>]:LIST:RUNNing?</code>	695

`[SOURce<hw>]:LIST:DWELI <Dwell>`

Sets the global dwell time. The instrument generates the signal with the frequency / power value pairs of each list entry for that particular period.

See also [Significant parameters and functions](#).

Parameters:

<code><Dwell></code>	float
Range:	1E-3 to 100
Increment:	1E-6
*RST:	0.01

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Manual operation: See ["Global Dwell Time"](#) on page 200

`[SOURce<hw>]:LIST:DWELI:MODE <DwellMode>`

Selects the dwell time mode.

Parameters:

<code><DwellMode></code>	LIST GLOBal
LIST	Uses the dwell time, specified in the data table for each value pair individually.
GLOBal	Uses a constant dwell time, set with command <code>[SOURce<hw>]:LIST:DWELI</code> .

*RST: GLOBal

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Manual operation: See ["Dwell Time Mode"](#) on page 200

[:SOURce<hw>]:LIST:DWELI:LIST <Dwell>

Enters the dwell time values in the selected list in μ s.

Parameters:

<Dwell> <Dwell#1>{, <Dwell#2>, ...} | block data

You can either enter the data as a list of numbers, or as binary block data. The list of numbers can be of any length, with the list entries separated by commas.

In binary block format, 8 (4) bytes are always interpreted as a floating-point number with double accuracy. See also : [FORMat \[: DATA \]](#) on page 504 for more details.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Manual operation: See ["Edit List Mode Data"](#) on page 206

[:SOURce<hw>]:LIST:DWELI:LIST:POINTS?

Queries the number (points) of dwell time entries in the selected list.

Return values:

<Points> integer

Range: 0 to INT_MAX

*RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Usage: Query only

[:SOURce<hw>]:LIST:FREQuency <Frequency>

Enters the frequency values in the selected list.

Parameters:

<Frequency> <Frequency#1>{, <Frequency#2>, ...} | block data

You can either enter the data as a list of numbers, or as binary block data.

The list of numbers can be of any length, with the list entries separated by commas.

In binary block format, 8 (4) bytes are always interpreted as a floating-point number with double accuracy.

See also : [FORMat \[: DATA \]](#).

Range: 300 kHz to RFmax (depends on the installed options)

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Manual operation: See ["Edit List Mode Data"](#) on page 206

[SOURce<hw>]:LIST:FREQuency:POINts?

Queries the number (points) of frequency entries in the selected list.

Return values:

<Points> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Usage: Query only

[SOURce<hw>]:LIST:INDeX <Index>

Sets the list index in [LIST:MODE STEP](#).

After the trigger signal, the instrument processes the frequency and level settings of the selected index.

Parameters:

<Index> integer
 *RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Manual operation: See ["Current Index"](#) on page 199

[SOURce<hw>]:LIST:INDeX:STARt <Start>

[SOURce<hw>]:LIST:INDeX:STOP <Stop>

Sets the start and stop index of the index range which defines a subgroup of frequency/level value pairs in the current list.

Parameters:

<Stop> integer
 Index range
 Only values inside this range are processed in list mode
 Range: 0 to list length
 *RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Manual operation: See ["List Range from/to"](#) on page 202

[[:SOURce<hw>]:LIST:MODE <Mode>

Sets the list mode.

The instrument processes the list according to the selected mode and trigger source. See [LIST:TRIG:SOUR AUTO](#), [SING](#) or [EXT](#) for the description of the trigger source settings.

Parameters:

<Mode> AUTO | STEP | INDex

AUTO

Each trigger event triggers a complete list cycle.

STEP

Each trigger event triggers only one step in the list processing cycle. The list is processed in ascending order.

INDex

The trigger event triggers the entry of the selected index in the list.

*RST: AUTO

Example: See [Example"Create an RF list and activate the list mode"](#) on page 687.

Manual operation: See ["Mode"](#) on page 200

[[:SOURce<hw>]:LIST:POWer <Power>

Enters the level values in the selected list. The number of level values must correspond to the number of frequency values. Existing data is overwritten.

Parameters:

<Power> <Power#1>{, <Power#2>, ...} | block data

You can either enter the data as a list of numbers, or as binary block data.

The list of numbers can be of any length, with the list entries separated by commas.

In binary block format, 8 (4) bytes are always interpreted as a floating-point number with double accuracy.

See also [:FORMat \[:DATA\]](#).

Range: depends on the installed options

Default unit: dBm

Example: See [Example"Create an RF list and activate the list mode"](#) on page 687.

Manual operation: See ["Edit List Mode Data"](#) on page 206

[:SOURce<hw>]:LIST:POWer:POINts?

Queries the number (points) of level entries in the selected list.

Return values:

<Points> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Usage: Query only

[:SOURce<hw>]:LIST:TRIGger:EXECute

Starts the processing of a list in list mode.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Usage: Event

Manual operation: See ["Execute Single"](#) on page 201

[:SOURce<hw>]:LIST:TRIGger:SOURce <Source>

Selects the trigger source for processing lists.

The designation of the parameters correspond to those in sweep mode. SCPI standard uses other designations for the parameters, which are also accepted by the instrument. The SCPI designation should be used if compatibility is an important consideration. For an overview, see the following table:

Rohde & Schwarz parameter	SCPI parameter	Applies to the list mode parameters:
AUTO	IMMediate	[:SOURce<hw>]:LIST:MODE AUTO
SINGle	BUS	[:SOURce<hw>]:LIST:MODE AUTO or [:SOURce<hw>]:LIST:MODE STEP
EXTernal	EXTernal	[:SOURce<hw>]:LIST:MODE AUTO or [:SOURce<hw>]:LIST:MODE STEP

Parameters:

<Source> AUTO | IMMediate | SINGle | BUS | EXTernal

AUTO|IMMediate

The trigger is free-running, i.e. the trigger condition is fulfilled continuously. The selected list is restarted as soon as it is finished.

SINGle|BUS

The list is triggered by the command `[:SOURce<hw>]:LIST:TRIGger:EXECute`. The list is executed once.

EXternal

The list is triggered externally and executed once.

*RST: AUTO

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Manual operation: See ["Mode"](#) on page 200

[SOURce<hw>]:LIST:RUNNING?

Queries the current state of the list mode.

Return values:

<State> 1 | ON | 0 | OFF

1

Signal generation based on the list mode is active.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Usage: Query only

14.17.7.2 List mode file operation

The following section covers basic commands to file handling in list mode.

[SOURce<hw>]:LIST:CATalog?	695
[SOURce<hw>]:LIST:DELeTe	695
[SOURce<hw>]:LIST:DELeTe:ALL	696
[SOURce<hw>]:LIST:FREE?	696
[SOURce<hw>]:LIST:RESet	697
[SOURce<hw>]:LIST:SELeCt	697

[SOURce<hw>]:LIST:CATalog?

Queries the available list files in the specified directory.

Return values:

<Catalog> string
List of list filenames, separated by commas

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Usage: Query only

Manual operation: See ["List Mode Data"](#) on page 201

[SOURce<hw>]:LIST:DELeTe <Filename>

Deletes the specified list.

Setting parameters:

<Filename> string
 Filename or complete file path; file extension is optional.

Example: See [\[:SOURce<hw>\]:LIST:DELeTe:ALL](#) on page 696.

Usage: Setting only

Manual operation: See ["List Mode Data"](#) on page 201

[:SOURce<hw>]:LIST:DELeTe:ALL

Deletes all lists in the set directory.

This command can only be executed, if:

- No list file is selected.
- List mode is disabled.

Example:

```
SOUR1:LIST:CAT?
// list,my_list
SOUR1:LIST:DEL "/var/user/list1"
SOUR1:LIST:CAT?
// my_list
SOUR1:FREQ:MODE?
// LIST
SOUR1:LIST:SEL?
// /var/user/my_list.lsw
//deactivate list mode
SOUR1:FREQ:MODE CW
SOUR1:LIST:DELeTe:ALL
SOUR1:LIST:CAT?
// -
// all list files are deleted
```

Usage: Event

Manual operation: See ["List Mode Data"](#) on page 201

[:SOURce<hw>]:LIST:FREE?

Queries the amount of free memory (in bytes) for list mode lists.

Return values:

<Free> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example"Create an RF list and activate the list mode"](#) on page 687.

Usage: Query only

[SOURce<hw>]:LIST:RESet

Jumps to the beginning of the list.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Usage: Event

Manual operation: See ["Reset"](#) on page 201

[SOURce<hw>]:LIST:SElect <Filename>

Selects or creates a data list in list mode.

If the list with the selected name does not exist, a new list is created.

Parameters:

<Filename> string
Filename or complete file path; file extension can be omitted.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 687.

Manual operation: See ["List Mode Data"](#) on page 201
See ["Functions for handling of data lists"](#) on page 320

14.17.7.3 List mode data exchange

With the following commands, you can configure lists in ASCII format and export or import them accordingly.

[SOURce<hw>]:LIST:DEXChange:AFILe:CATalog?	697
[SOURce<hw>]:LIST:DEXChange:EXECute	698
[SOURce<hw>]:LIST:DEXChange:AFILe:EXTension	698
[SOURce<hw>]:LIST:DEXChange:AFILe:SElect	698
[SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:COLumn	698
[SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:DECimal	699
[SOURce<hw>]:LIST:DEXChange:MODE	699
[SOURce<hw>]:LIST:DEXChange:SElect	699

[SOURce<hw>]:LIST:DEXChange:AFILe:CATalog?

Queries the available ASCII files for export or import of list mode data in the current or specified directory.

Return values:

<Catalog> string
List of ASCII files *.txt or *.csv, separated by commas.

Example: See [Example "List mode data exchange"](#) on page 689.

Usage: Query only

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 108

[:SOURce<hw>]:LIST:DEXChange:EXECute

Executes the import or export of the selected list file, according to the previously set transfer direction with command `[:SOURce<hw>]:LIST:DEXChange:MODE`

Example: See [Example"List mode data exchange"](#) on page 689.

Usage: Event

Manual operation: See ["Import / Export"](#) on page 108

[:SOURce<hw>]:LIST:DEXChange:AFILe:EXTension <Extension>

Determines the extension of the ASCII file for import or export, or to query existing files.

Parameters:

<Extension> TXT | CSV
*RST: TXT

Example: See [Example"List mode data exchange"](#) on page 689.

Manual operation: See ["ASCII File Settings"](#) on page 107

[:SOURce<hw>]:LIST:DEXChange:AFILe:SELection <Filename>

Selects the ASCII file to be imported or exported.

Parameters:

<Filename> string
Filename or complete file path; file extension can be omitted.

Example: See [Example"List mode data exchange"](#) on page 689.

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 108

[:SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:COLumn <Column>

Selects the separator between the frequency and level column of the ASCII table.

Parameters:

<Column> TABulator | SEMicolon | COMMa | SPACe
*RST: COMMa

Example: See [Example"List mode data exchange"](#) on page 689.

Manual operation: See ["ASCII File Settings"](#) on page 107

[:SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:DECimal <Decimal>

Sets "." (decimal point) or "," (comma) as the decimal separator used in the ASCII data with floating-point numerals.

Parameters:

<Decimal> DOT | COMMa
 *RST: DOT

Example: See [Example"List mode data exchange"](#) on page 689.

Manual operation: See ["ASCII File Settings"](#) on page 107

[:SOURce<hw>]:LIST:DEXChange:MODE <Mode>

Determines the import or export of a list.

Specify the source or destination file with the command [\[:SOURce<hw>\]:LIST:DEXChange:SElect](#).

Parameters:

<Mode> IMPort | EXPort
 *RST: IMPort

Example: See [Example"List mode data exchange"](#) on page 689.

Manual operation: See ["Mode"](#) on page 107

[:SOURce<hw>]:LIST:DEXChange:SElect <Filename>

Selects the ASCII file for import or export, containing a list.

Parameters:

<Filename> string
 Filename or complete file path; file extension can be omitted.

Example: See [Example"List mode data exchange"](#) on page 689.

Manual operation: See ["Select Source/Select ASCII Destination"](#) on page 108

14.17.8 SOURce:NOISe subsystem

The SOURce:NOISe subsystem contains the commands for:

- Setting the noise modulation signal. The noise generator is optional.

Example: Configuring the noise generator

```

SOURce1:NOISe:DIStributioN GAUSS
SOURce1:NOISe:BANDwidth 10000000
SOURce1:NOISe:BANDwidth:STATe 1

SOURce1:LFOutput1:SOURce NOIS
SOURce1:LFOutput1:STATe 1

SOURce1:NOISe:LEVel:RELative?
// -83.86
SOURce1:NOISe:LEVel:ABSolute?
// -13.86

```

- [Noise generator](#).....700

14.17.8.1 Noise generator

[:SOURce<hw>]:NOISe:BANDwidth BWIDth	700
[:SOURce<hw>]:NOISe:BWIDth:STATe	700
[:SOURce<hw>]:NOISe:DIStributioN	701
[:SOURce<hw>]:NOISe:LEVel:RELative?	701
[:SOURce<hw>]:NOISe:LEVel[:ABSolute]?	701

[\[:SOURce<hw>\]:NOISe:BANDwidth|BWIDth <BWidth>](#)

Sets the noise level in the system bandwidth when bandwidth limitation is enabled.

Parameters:

<BWidth>	float
Range:	100E3 to 10E6
Increment:	100E3
*RST:	100E3

Example: See [Example"Configuring the noise generator"](#) on page 700.

Manual operation: See ["Bandwidth"](#) on page 117

[\[:SOURce<hw>\]:NOISe:BWIDth:STATe <State>](#)

Activates noise bandwidth limitation.

Parameters:

<State>	1 ON 0 OFF
*RST:	0

Example: See [Example"Configuring the noise generator"](#) on page 700.

Manual operation: See ["Bandwidth"](#) on page 117

[SOURce<hw>]:NOISe:DISTRibution <Distribution>

Sets the distribution of the noise power density.

Parameters:

<Distribution> GAUSs | EQUal
*RST: GAUSs

Example: See [Example"Configuring the noise generator"](#) on page 700.

Manual operation: See ["Distribution"](#) on page 117

[SOURce<hw>]:NOISe:LEVel:RELative?

Queries the level of the noise signal per Hz in the total bandwidth.

Return values:

<Relative> float
Range: -149.18 to -52.67
Increment: 0.1
*RST: -69.84

Example: See [Example"Configuring the noise generator"](#) on page 700.

Usage: Query only

Manual operation: See ["Noise Density"](#) on page 120

[SOURce<hw>]:NOISe:LEVel[:ABSolute]?

Queries the level of the noise signal in the system bandwidth within the enabled bandwidth limitation.

Return values:

<Absolute> float
Noise level within the bandwidth limitation
*RST: 3.84 MHz

Example: See [Example"Configuring the noise generator"](#) on page 700.

Usage: Query only

Manual operation: See ["Noise Level"](#) on page 120

14.17.9 SOURce:PGEN subsystem

The PG_{EN} subsystem contains the commands for setting output of the pulse modulation signal.

Example: Using pulse generator as source for pulse modulation

```
// select pulse generator as source for pulse modulation
// enable pulse modulation
SOURce1:PULM:SOURce INT
SOURce1:PULM:STATe 1
// pulse generator and signal output are also activated
SOURce1:PGENerator:STATe?
// 1
SOURce1:PGENerator:OUTPut:STATe?
// 1
PGENerator:OUTPut:POLarity NORMal
// to disable pulse generator
SOURce1:PGENerator:STATe 0
// activate the pulse modulation of the RF carrier
SOURce1:PULM:STATe 1
```

[SOURce<hw>]:PGENerator:OUTPut:POLarity..... 702
 [SOURce<hw>]:PGENerator:OUTPut[:STATe]..... 702
 [SOURce<hw>]:PGENerator:STATe..... 703

[SOURce<hw>]:PGENerator:OUTPut:POLarity <Polarity>

Sets the polarity of the pulse output signal.

Parameters:

<Polarity> NORMal | INVerted

NORMal

Outputs the pulse signal during the pulse width, that means during the high state.

INVerted

Inverts the pulse output signal polarity. The pulse output signal is suppressed during the pulse width, but provided during the low state.

*RST: NORMal

Example: See [Example"Using pulse generator as source for pulse modulation"](#) on page 702.

Manual operation: See ["Pulse Output Polarity"](#) on page 102

[SOURce<hw>]:PGENerator:OUTPut[:STATe] <State>

Activates the output of the pulse modulation signal.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: 0

Example: See [Example"Using pulse generator as source for pulse modulation"](#) on page 702.

Manual operation: See ["Pulse Output State"](#) on page 102

[:SOURce<hw>]:PGENerator:STATe <State>

Enables the output of the video/sync signal.

If the pulse generator is the current modulation source, activating the pulse modulation automatically activates the signal output and the pulse generator.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: 0

Example: See [Example"Using pulse generator as source for pulse modulation"](#) on page 702.

14.17.10 SOURce:PHASe subsystem

This subsystem contains the commands for adjusting the phase of the RF output signal relative to a reference signal of the same frequency.

Example: Programming Example

```
// change the phase relative to the current phase
SOURce1:PHASe 2 DEG
// adopt the setting as the current phase
SOURce1:PHASe:REFerence
```

The following commands are available:

[:SOURce<hw>]:PHASe	703
[:SOURce<hw>]:PHASe:REFerence	703

[:SOURce<hw>]:PHASe <Phase>

Sets the phase variation relative to the current phase.

Parameters:

<Phase> float
 Range: -36000 to 36000
 Increment: 0.001
 *RST: 0
 Default unit: DEG

Example: See [Example"Programming Example"](#) on page 703.

Manual operation: See ["Delta Phase"](#) on page 78

[:SOURce<hw>]:PHASe:REFerence

Assigns the value set with command [\[:SOURce<hw>\]:PHASe](#) as the reference phase.

Example: See [Example "Programming Example"](#) on page 703.

Usage: Event

Manual operation: See ["Reset Delta Phase Display"](#) on page 78

14.17.11 SOURce:POWer subsystem

The SOURce:POWer subsystem contains the commands for setting the output level, level control and level correction of the RF signal.

The default units are dBm. To change the units, perform one of the following:

- Enter the unit after the numerical value
Example: :POW 0.5V
- Set the unit with the command :UNIT:POWer.

Example: Configure the settings for external ALC

The example shows a command sequence to set the parameters of the external ALC mode. It is assumed that you have set up the measurement with the external coupler, detector diode and the R&S SMA100B as described in [Chapter 8.2.2, "How to set up an external ALC"](#), on page 217.

```
// Reset the instrument to start from an initial state
*RST; *CLS

// Select the external ALC mode
// configure the detector coupling factor
// and required RF generator level

SOURce:POWer:ALC[:STATe] EALC
SOURce:POWer:ALC:EDETEctor:FACTor 16
SOURce:POWer:ALC:EDETEctor:LEVel 20

// Execute the instrument detector offset compensation.
SOURce:POWer:ALC:SONCe
// This function recalculates and compensates internally detected offset voltages

// Activate RF Output1.
Output1:STATe 1

[:SOURce<hw>]:POWer:ALC:MODE?.....705
[:SOURce<hw>]:POWer:ALC[:STATe].....705
[:SOURce<hw>]:POWer:ALC:DSensitivity.....706
[:SOURce<hw>]:POWer:ALC:EDETEctor:FACTor.....706
[:SOURce<hw>]:POWer:ALC:EDETEctor:LEVel.....707
[:SOURce<hw>]:POWer:ALC:SONCe.....707
[:SOURce<hw>]:POWer:ATTenuation:PATTenuator.....707
[:SOURce<hw>]:POWer:ATTenuation:RFOff:MODE.....707
[:SOURce<hw>]:POWer:EMF:STATe.....708
[:SOURce<hw>]:POWer:LBEHaviour.....708
```


[SOURce<hw>]:POWer:LIMit[:AMPLitude].....	708
[SOURce<hw>]:POWer:MANual.....	709
[SOURce<hw>]:POWer:MODE.....	709
[SOURce<hw>]:POWer:POWer.....	710
[SOURce<hw>]:POWer:START.....	710
[SOURce<hw>]:POWer:STOP.....	710
[SOURce<hw>]:POWer:STEP:MODE.....	711
[SOURce<hw>]:POWer:STEP[:INCRement].....	711
[SOURce<hw>]:POWer[:LEVel][:IMMEDIATE]:OFFSet.....	711
[SOURce<hw>]:POWer[:LEVel][:IMMEDIATE]:RCL.....	712
[SOURce<hw>]:POWer[:LEVel][:IMMEDIATE]:AMPLitude.....	712
[SOURce<hw>]:POWer[:LEVel][:IMMEDIATE]:REFLevel.....	713
[SOURce<hw>]:POWer:RANGe:LOWer?.....	713
[SOURce<hw>]:POWer:RANGe:UPPer?.....	713
[SOURce<hw>]:POWer:RANGe:MIN?.....	714
[SOURce<hw>]:POWer:RANGe:MAX?.....	714
[SOURce]:POWer:WIGNore.....	714

[SOURce<hw>]:POWer:ALC:MODE?

Queries the currently set ALC mode.

See [[:SOURce<hw>]:POWer:ALC[:STATe]] on page 705.

Return values:

<PowAlcMode> 0 | AUTO | 1 | PRESet | OFFTable | ON | OFF | ONSample | ONTable

Example:

POW:ALC:MODE?

Response: ONTable"Table and On" is set automatically.

Usage:

Query only

[SOURce<hw>]:POWer:ALC[:STATe] <State>

Parameters:

<State> 0 | OFF | AUTO | 1 | ON | ONTable | PRESet | OFFTable | EALC

AUTO

Adjusts the output level to the operating conditions automatically.

1|ON

Activates internal level control permanently.

OFFTable

Controls the level using attenuation values of the internal ALC table.

0|OFF

Provided only for backward compatibility with other Rohde & Schwarz signal generators.

The R&S SMA100B accepts these values and maps them automatically as follows:

0|OFF = OFFTable

ONTable

Starts with the attenuation setting from the table and continues with automatic level control.

EALC

Activates external ALC mode.

*RST: AUTO

Example: See [Example "Configure the settings for external ALC"](#) on page 704

Manual operation: See ["State"](#) on page 216

[[:SOURce<hw>]:POWER:ALC:DSENSitivity <Sensitivity>

Sets the sensitivity of the ALC detector.

Parameters:

<Sensitivity> AUTO | FIXed

AUTO

Selects the optimum sensitivity automatically.

FIXed

Fixes the internal level detector.

*RST: AUTO

Example: POW:ALC:DSEN FIX

Manual operation: See ["Detector Sensitivity"](#) on page 216

[[:SOURce<hw>]:POWER:ALC:EDETector:FACTor <DetectorFact>

Sets the attenuation value of the RF coupler.

Parameters:

<DetectorFact> float
Range: -200 to 200
Increment: 0.01
*RST: 16

Example: See [Example "Configure the settings for external ALC"](#) on page 704

Options: R&S SMAB-K726

Manual operation: See ["Detector Coupling Factor"](#) on page 216

[[:SOURce<hw>]:POWER:ALC:EDETector:LEVel <ReqGenLev>

Sets the maximum power level at the RF output required for compensating the external ALC coupler and cable losses.

Parameters:

<ReqGenLev> float
 Range: -145 to 40
 Increment: 0.01
 *RST: 20

Example: See [Example "Configure the settings for external ALC"](#) on page 704

Options: R&S SMAB-K726

Manual operation: See ["Required Generator Level"](#) on page 216

[[:SOURce<hw>]:POWER:ALC:SONCe

Activates level control for correction purposes temporarily.

Example: POW:ALC OFF
 Deactivates automatic level control at the RF output.
 POW:ALC:SONC
 Executes level control (once).

Usage: Event

Manual operation: See ["Readjust"](#) on page 76

[[:SOURce<hw>]:POWER:ATTenuation:PATTenuator <StepAttSel>

Selects the type of step attenuator used below 20 GHz.

Parameters:

<StepAttSel> MECHANical | ELECTronic
 MECHANical
 Uses the mechanical step attenuator at all frequencies.
 ELECTronic
 Uses the electronic step attenuator up to 20 GHz.

Options: R&S SMAB-B35/-B37/-B39, not available for R&S SMAB-B36S

Manual operation: See ["Step Attenuator below 20 GHz"](#) on page 212

[[:SOURce<hw>]:POWER:ATTenuation:RFOff:MODE <Mode>

Selects the state the attenuator is to assume if the RF signal is switched off.

Parameters:

<Mode> UNCHanged | FATTenuation

FATTenuation

The step attenuator switches to maximum attenuation

UNCHanged

Retains the current setting and keeps the output impedance constant during RF off.

*RST: n.a. (factory preset: FATTenuation)

Example:

```
SOURce1:POWer:ATTenuation:RFOFF:MODE
FATTenuation
```

uses maximum attenuation when the RF output is turned off.

Manual operation: See ["RF OFF Mode"](#) on page 212

[:SOURce<hw>]:POWer:EMF:STATe <State>

Displays the signal level as voltage of the EMF. The displayed value represents the voltage over a 50 Ohm load.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: n.a. (factory preset: 0)

Example:

```
POW:EMF:STAT 1
```

Activates voltage level display.

Manual operation: See ["Display Level as Voltage of EMF"](#) on page 342

[:SOURce<hw>]:POWer:LBEHaviour <Behaviour>**Parameters:**

<Behaviour> AUTO | UNINterrupted | MONotone | CVSWr | HDUN

UNINterrupted|MONotone

Uninterrupted level settings and strictly monotone modes.

CVSWr

Constant VSWR

HDUN

High dynamic uninterrupted level settings.

*RST: AUTO

Example:

```
SOURce1:POWer:LBEHaviour AUTO
```

Options:

R&S SMAB-K724

Manual operation: See ["Setting Characteristics"](#) on page 74

[:SOURce<hw>]:POWer:LIMit[:AMPLitude] <Amplitude>

Limits the maximum RF output level in CW and sweep mode.

It does not influence the "Level" display or the response to the query `[:SOURce<hw>]:POWer[:LEVel] [:IMMediate] [:AMPLitude]`.

Parameters:

<Amplitude> float
 Range: depends on the installed options
 Increment: 0.01
 *RST: n.a. (factory preset: 30)

Example:

SOURce1:POWer:LIMit:AMPLitude 10

Manual operation: See ["Limit"](#) on page 74

[:SOURce<hw>]:POWer:MANual <Manual>

Sets the level for the subsequent sweep step if [SWE:POW:MODE MAN](#).

Use a separate command for each sweep step.

Parameters:

<Manual> float
 You can select any level within the setting range, where:
 START is set with [\[:SOURce<hw>\]:POWer:START](#)
 STOP is set with [\[:SOURce<hw>\]:POWer:STOP](#)
 OFFSet is set with [\[:SOURce<hw>\]:POWer\[:LEVel\]\[:IMMediate\]:OFFSet](#)
 Range: (START + OFFSet) to (STOP + OFFSet)
 Increment: 0.01
 Default unit: dBm

Example:

See [Example "Setup an RF frequency or power sweep"](#) on page 720

Manual operation: See ["Current Level"](#) on page 186

[:SOURce<hw>]:POWer:MODE <Mode>

Selects the operating mode of the instrument to set the output level.

Parameters:

<Mode> CW | FIXed | SWEep
CW|FIXed
 Operates at a constant level.
 CW and FIXed are synonyms.
 To set the output level value, use the command [\[:SOURce<hw>\]:POWer\[:LEVel\]\[:IMMediate\]:AMPLitude\]](#).
SWEep
 Sets sweep mode.
 Set the range and current level with the commands:
[\[:SOURce<hw>\]:POWer:START](#) and [\[:SOURce<hw>\]:POWer:STOP](#),
[\[:SOURce<hw>\]:POWer:MANual](#).

*RST: CW

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720

Manual operation: See ["State \(RF level sweep\)"](#) on page 186
See ["State \(RF frequency / level sweep\)"](#) on page 186

[:SOURce<hw>]:POWER:POWER <Power>

Sets the level **at the RF output** connector.

This value does not consider a specified offset.

The command `[:SOURce<hw>]:POWER[:LEVel][:IMMediate][:AMPLitude]` sets the level of the "Level" display, that means the level containing offset.

See ["RF frequency and level display with a downstream instrument"](#) on page 64.

Parameters:

<Power> float
Level at the RF output, without level offset
Range: See data sheet
Increment: 0.01
Default unit: dBm

Example: `SOURce1:POWER:POWER 15`
Sets the level at RF output

Manual operation: See ["Amplitude"](#) on page 73
See ["Used SMAB Settings For Measurement"](#) on page 227

[:SOURce<hw>]:POWER:START <Start>

[:SOURce<hw>]:POWER:STOP <Stop>

Sets the RF start/stop level in sweep mode.

Parameters:

<Stop> float
Sets the setting range calculated as follows:
 $(Level_min + OFFSET) \text{ to } (Level_max + OFFSET)$
Where the values are set with the commands:
`[:SOURce<hw>]:POWER[:LEVel][:IMMediate]:OFFSET`
`[:SOURce<hw>]:POWER:START`
`[:SOURce<hw>]:POWER:STOP`
Range: Minimum level to maximum level
*RST: -30 (Start)/ -10 (Stop)
Default unit: dBm

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720

Manual operation: See ["Start Level / Stop Level"](#) on page 193

[:SOURce<hw>]:POWER:STEP:MODE <Mode>

Defines the type of step width to vary the RF output power step-by-step with the commands `POW UP` or `POW DOWN`.

Parameters:

<Mode> DECimal | USER

DECimal

Increases or decreases the level in steps of ten.

USER

Increases or decreases the level in increments, determined with the command `[:SOURce<hw>]:POWER:STEP[:INCRement]`.

*RST: DECimal

Example:

```
SOURce1:POWER:STEP:INCRement 2
SOURce1:POWER:STEP:MODE USER
SOURce1:POWER:LEVel:IMMediate:AMPLitude UP
Increasing the RF level with a step size of 2 dB
```

Manual operation: See ["Variation Active"](#) on page 71

[:SOURce<hw>]:POWER:STEP[:INCRement] <Increment>

Specifies the step width in the appropriate path for `POW:STEP:MODE USER`.

To adjust the level step-by-step with this increment value, use the command `POW UP`, or `POW DOWN`.

Note: The command also sets "Variation Step" in the manual control, that means the user-defined step width for setting the level with the rotary knob or the [Up/Down] arrow keys.

Parameters:

<Increment> float
 Range: 0 to 200
 Increment: 0.01
 *RST: 1
 Default unit: dB

Example: See `[:SOURce<hw>]:POWER:STEP:MODE` on page 711.

Manual operation: See ["Variation Step"](#) on page 71

[:SOURce<hw>]:POWER[:LEVel][:IMMediate]:OFFSet <Offset>

Sets the level offset of a downstream instrument.

The level at the RF output is not changed.

To query the resulting level, as it is at the output of the downstream instrument, use the command `[:SOURce<hw>]:POWER[:LEVel][:IMMediate][:AMPLitude]`.

See ["RF frequency and level display with a downstream instrument"](#) on page 64.

Note: The level offset also affects the RF level sweep.

Parameters:

<Offset> float
 Range: -100 to 100
 Increment: 0.01
 *RST: 0
 Default unit: dB
 Level offset is always expressed in dB; linear units (V, W, etc.) are not supported

Example: POWer:OFFSet 10
 Sets the RF level offset to 10 dB

Manual operation: See ["Offset"](#) on page 74
 See ["Used SMAB Settings For Measurement"](#) on page 227

[:SOURce<hw>]:POWer[:LEVel][:IMMediate]:RCL <Rcl>

Determines whether the current level is retained or if the stored level setting is adopted when an instrument configuration is loaded.

Parameters:

<Rcl> INCLUDE | EXCLUDE
INCLUDE
 Takes the current level when an instrument configuration is loaded.
EXCLUDE
 Retains the current level when an instrument configuration is loaded.
 *RST: INCLUDE

Example: POW:RCL INCL
 Takes the level value from an instrument configuration loaded with command [*RCL](#).

Manual operation: See ["Exclude Level"](#) on page 317

[:SOURce<hw>]:POWer[:LEVel][:IMMediate]:AMPLitude] <Amplitude>

Sets the RF level applied to the DUT.

To activate the RF output use command [:OUTPut<hw>\[:STATe\]](#) ("RF On"/"RF Off").

The following applies $POWER = RF \text{ output level} + OFFSET$, where:

- POWER is the values set with [\[:SOURce<hw>\]:POWer\[:LEVel\]\[:IMMediate\]\[:AMPLitude\]](#)
- RF output level is set with [\[:SOURce<hw>\]:POWer:POWER](#)

- OFFSet is set with `[:SOURce<hw>] :POWer [:LEVel] [:IMMediate] :OFFSet`

Parameters:

<Amplitude>

float

The following settings influence the value range:

OFFSet set with the command `[:SOURce<hw>] :POWer [:LEVel] [:IMMediate] :OFFSet`**Numerical value**

Sets the level

UP|DOWN

Varies the level step by step.

The level is increased or decreased by the value set with the command `[:SOURce<hw>] :POWer :STEP [:INCRement]`.

Range: (Level_min + OFFSet) to (Level_max + OFFSet)

*RST: -30

Default unit: dBm

Example:`POWer -30`

Sets the RF level

Example:See also `[:SOURce<hw>] :POWer :STEP :MODE` on page 711.**Manual operation:**

See "Amplitude" on page 73

`[:SOURce<hw>] :POWer [:LEVel] [:IMMediate] :REFLevel` <ReferenceLevel>

Queries the reference level of the user correction.

The reference level is the sum of the amplitude and the level offset, set with the commands `[:SOURce<hw>] :POWer :POWer [:SOURce<hw>] :POWer [:LEVel] [:IMMediate] :OFFSet`.**Parameters:**

<ReferenceLevel>

float

Range: -245 to 120

Increment: 0.01

*RST: -30

Manual operation:

See "Used SMAB Settings For Measurement" on page 227

`[:SOURce<hw>] :POWer :RANGe :LOWer?`**`[:SOURce<hw>] :POWer :RANGe :UPPer?`**

Queries the current interruption-free range of the level.

Return values:

<Upper>

float

Increment: 0.01

Default unit: dBm

Example:

```
SOURce1:POWer:RANGe:UPPer?
// -15
SOURce1:POWer:RANGe:LOW?
// -50
```

Usage: Query only

Manual operation: See "[Level Range](#)" on page 75

[SOURce<hw>]:POWer:RANGe:MIN?
[SOURce<hw>]:POWer:RANGe:MAX?

Queries the current power range of the level sweep.

Return values:

<PowRangeMax> float
 Range: depends on settings
 Increment: 0.01
 *RST: -10
 Default unit: dBm

Example:

```
SOURce1:POWer:RANGe:MIN?
// -90
SOURce1:POWer:RANGe:MAX?
// 8
```

Usage: Query only

Manual operation: See "[Sweep Level Range](#)" on page 195

[SOURce]:POWer:WIGNore <State>

Ignores level range warnings.

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 0)

Example: SOURce:POWer:WIGNore 1

14.17.12 SOURce:ROSCillator subsystem

The SOURce:ROSCillator subsystem contains the commands for setting the external and internal reference frequency.



The commands of this subsystem are not affected by an instrument reset (*RST on page 466).

Example: Configuring the reference oscillator

```
// Using 100 MHz external reference source
SOURce:ROSCillator:PRESet
SOURce:ROSCillator:SOURce EXT
SOURce:ROSCillator:EXTErnal:RFOff:STATe 1
SOURce:ROSCillator:EXTErnal:FREQuency 100MHZ
SOURce:ROSCillator:EXTErnal:SBANDwidth WIDE
// 100 MHz (loop through) and 1 GHz output
SOURce:ROSCillator:OUTPut:FREQuency:MODE LOOP
SOURce:ROSCillator:OUTPut:ALTErnate:FREQuency:MODE DER1G
SOURce:ROSCillator:INTernAl:ADJust:STATe 0

// Variable external reference frequency
// SOURce:ROSCillator:EXTErnal:FREQuency VAR
// SOURce:ROSCillator:EXTErnal:FREQuency:VARiable 100000000

// Using the internal reference frequency
SOURce:ROSCillator:SOURce INT
SOURce:ROSCillator:INTernAl:TUNing:STATe 1
SOURce:ROSCillator:INTernAl:TUNing:SLOPe LOW
// 10 MHz and 1 GHz output
SOURce:ROSCillator:OUTPut:FREQuency:MODE DER10M
SOURce:ROSCillator:OUTPut:ALTErnate:FREQuency:MODE DER1G

// Query calibration value
CALibration:ROSCillator?
// 32767
// Set an internal source
// Activate user-defined adjustment value of 1000
SOURce:ROSCillator:SOURce INT
SOURce:ROSCillator:INTernAl:ADJust:STATe 1
SOURce:ROSCillator:INTernAl:ADJust:VALue 1000

// to resume calibrated state
SOURce:ROSCillator:INTernAl:ADJust:VALue 0
SOURce:ROSCillator:INTernAl:ADJust:STATe 0
// or
// SYSTem:FPreSt
```

[SOURce]:ROSCillator:PRESet.....	716
[SOURce]:ROSCillator:SOURce.....	716
[SOURce]:ROSCillator:INTernAl:TUNing[:STATe].....	716
[SOURce]:ROSCillator:INTernAl:TUNing:SLOPe.....	716
[SOURce]:ROSCillator:EXTErnal:RFOff[:STATe].....	717
[SOURce]:ROSCillator:EXTErnal:FREQuency.....	717
[SOURce]:ROSCillator:EXTErnal:FREQuency:VARiable.....	717
[SOURce]:ROSCillator:EXTErnal:SBANDwidth.....	717
[SOURce]:ROSCillator:EXTErnal:MLRange?.....	718
[SOURce]:ROSCillator:EXTErnal:NSBandwidth?.....	718
[SOURce]:ROSCillator:OUTPut:FREQuency:MODE.....	718

[:SOURce]:ROSCillator:OUTPut:ALternate:FREQuency:MODE.....	719
[:SOURce]:ROSCillator[:INTernal]:ADJust:VALue.....	719
[:SOURce]:ROSCillator[:INTernal]:ADJust[:STATe].....	720

[:SOURce]:ROSCillator:PRESet

Resets the reference oscillator settings.

Example: See [Example"Configuring the reference oscillator"](#) on page 715.

Usage: Event

Manual operation: See ["Set to Default"](#) on page 293

[:SOURce]:ROSCillator:SOURce <Source>

Selects between internal or external reference frequency.

Parameters:

<Source> INTernal | EXTernal
 *RST: n.a. (factory preset: INTernal)

Example: See [Example"Configuring the reference oscillator"](#) on page 715.

Manual operation: See ["Source"](#) on page 293

[:SOURce]:ROSCillator:INTernal:TUNing[:STATe] <State>

Activates the EFC (external frequency control).

Parameters:

<State> 1 | ON | 0 | OFF
 *RST: n.a. (factory preset: 1)

Example: See [Example"Configuring the reference oscillator"](#) on page 715.

Manual operation: See ["External Tuning Active"](#) on page 295

[:SOURce]:ROSCillator:INTernal:TUNing:SLOPe <State>

Sets the sensitivity of the external tuning volatge.

Parameters:

<State> LOW | HIGH
 *RST: n.a. (factory preset: LOW)

Example: See [Example"Configuring the reference oscillator"](#) on page 715.

Manual operation: See ["External Tuning Slope"](#) on page 295

[[:SOURce]:ROSCillator:EXTernal:RFOFF[:STATe]] <State>

Determines that the RF output is turned off when the external reference signal is selected, but missing.

Parameters:

<State> 1 | ON | 0 | OFF
*RST: n.a. (factory preset: 0)

Example: See [Example"Configuring the reference oscillator"](#) on page 715.

Manual operation: See ["Deactivate RF Output \(if external reference is missing\)"](#) on page 293

[[:SOURce]:ROSCillator:EXTernal:FREQuency] <Frequency>

Sets the frequency of the external reference.

Parameters:

<Frequency> 100MHZ | 1GHZ | VARiable | 10MHZ
*RST: n.a. (factory preset: 10MHZ)

Example: See [Example"Configuring the reference oscillator"](#) on page 715.

Options: VARiable requires R&S SMAB-K704
100MHZ|1GHZ require R&S SMAB-K703

Manual operation: See ["External Reference Frequency"](#) on page 293

[[:SOURce]:ROSCillator:EXTernal:FREQuency:VARiable] <Frequency>

Specifies the user-defined external reference frequency.

Parameters:

<Frequency> float
Range: 1E6 to 100E6
Increment: 0.1
*RST: n.a. (factory preset: 1E7)
Default unit: Hz

Example: See [Example"Configuring the reference oscillator"](#) on page 715.

Options: R&S SMAB-K704

Manual operation: See ["Variable Reference Frequency"](#) on page 294

[[:SOURce]:ROSCillator:EXTernal:SBANDwidth] <SBandwidth>

Selects the synchronization bandwidth for the external reference signal.

See [\[:SOURce\]:ROSCillator:SOURce > External](#).

Depending on the RF hardware version, and the installed options, the synchronisation bandwidth varies.

For more information, see data sheet.

Parameters:

<SBandwidth> WIDE | NARRow
NARRow
 The synchronization bandwidth is a few Hz.
WIDE
 Uses the widest possible synchronization bandwidth.
 *RST: n.a. (factory preset)

Example: See [Example "Configuring the reference oscillator"](#) on page 715.

Manual operation: See ["Synchronization Bandwidth"](#) on page 294

[[:SOURce]:ROSCillator:EXTernal:MLRange?

Queries the minimum locking range for the selected external reference frequency.

Depending on the RF hardware version, and the installed options, the minimum locking range vaies.

For more information, see data sheet.

Return values:

<MinLockRange> string

Example: SOUR:ROSC:EXT:MLR?

Usage: Query only

Manual operation: See ["Minimum Locking Range"](#) on page 295

[[:SOURce]:ROSCillator:EXTernal:NSBandwidth?

Queries the nominal synchronization bandwidth for the selected external reference frequency and synchronization bandwidth.

Return values:

<NomBandwidth> string

Example: SOUR:ROSC:EXT:NSB?

Usage: Query only

Manual operation: See ["Nominal Synchronization Bandwidth"](#) on page 294

[[:SOURce]:ROSCillator:OUTPut:FREQuency:MODE <OutpFreqMode>

Sets the output reference frequency.

Parameters:

<OutpFreqMode> DER10M | DER100M | OFF | LOOPthrough
OFF
 Disables the output.

DER10M|DER100M

Sets the output reference frequency to 10 MHz or 100 MHz.
The reference frequency is derived from the internal reference frequency.

LOOPthrough

This option is unavailable for

ROSCillator:EXTernal:FREQuency 1GHZ. Forwards the input reference frequency to the reference frequency output.

*RST: n.a. (factory preset: DER10M)

Example: See [Example"Configuring the reference oscillator"](#) on page 715.

Manual operation: See ["Reference Output/1 GHz Reference Output"](#) on page 296

[:SOURce]:ROSCillator:OUTPut:ALternate:FREQuency:MODE <OutpFreqMode>

Sets the output reference frequency.

Parameters:

<OutpFreqMode> LOOPthrough | DER1G | OFF

OFF

Disables the output.

DER1G

Sets the output reference frequency to 1 GHz.

The reference frequency is derived from the internal reference frequency.

LOOPthrough

If [:SOURce]:ROSCillator:EXTernal:FREQuency 1GHZ, forwards the input reference frequency to the reference frequency output.

*RST: n.a. (factory preset: OFF)

Example: See [Example"Configuring the reference oscillator"](#) on page 715.

Manual operation: See ["Reference Output/1 GHz Reference Output"](#) on page 296

[:SOURce]:ROSCillator[:INTernal]:ADJust:VALue <Value>

Specifies the frequency correction value (adjustment value).

Parameters:

<Value> integer

*RST: 0

Example: See [:SOURce]:ROSCillator[:INTernal]:ADJust[:STATe] on page 720

Manual operation: See ["Adjustment Value"](#) on page 297

[[:SOURce]:ROSCillator[:INTernal]:ADJust[:STATe] <State>

Determines whether the calibrated (off) or a user-defined (on) **adjustment value** is used for fine adjustment of the frequency.

Parameters:

<State> 1 | ON | 0 | OFF

0
Fine adjustment with the calibrated frequency value

1
User-defined adjustment value.
The instrument is no longer in the calibrated state.
The calibration value is, however, not changed. The instrument resumes the calibrated state if you send
SOURce:ROSCillator:INTernal:ADJust:STATe 0.

*RST: n.a. (factory preset: 0)

Example: See [Example "Configuring the reference oscillator"](#) on page 715.

Manual operation: See ["Adjustment Active"](#) on page 296

14.17.13 SOURce:SWEep subsystem

The SOURce:SWEep subsystem contains the commands for configuring RF sweep signals.



- The keyword [:FREQuency] can be omitted, then the commands are SCPI-compliant.
- To activate an RF sweep mode, use the following commands:
 - RF frequency sweep: SOURce:FREQuency:MODE SWEep (SOURce:FREQuency:MODE CW (off))
 - RF level sweep: SOURce:POWer:MODE SWEep (SOURce:POWer:MODE CW (off))
 - RF combined sweep: SOURce:FREQuency:MODE SWEep (SOURce:FREQuency:MODE CW (off))
- All sweeps, including the LF sweep, can be set independently of each other.
- All sweeps can be set independently of each other.

See [Chapter 7.1, "Signal generation and triggering in the sweep and list modes"](#), on page 170.

Example: Setup an RF frequency or power sweep

The following example shows a command sequence to set up an RF frequency sweep, triggered by the execute command. For an RF power sweep, replace FREQuency in the SWEep commands with POWer.

Exceptions are the power spacing (defined with LINear only) and the power step width (defined with LOGarithmic only).


```

// Reset the instrument to start from an initial state
// Switch off display update to improve performance
// (especially with short dwell times)
// Set the sweep mode (first two commands) and the sweep range
// Select linear spacing
// Select the waveform shape for the frequency sweep
*RST; *CLS
SYSTem:DISPlay:UPDate OFF
TRIGger1:FSWEEP:SOURce SINGLE
SOURcel:SWEep:FREQuency:MODE AUTO
SOURcel:FREQuency:SPAN 300 MHz
SOURcel:FREQuency:CENTer 200 MHz
// Alternatively use
// SOURcel:FREQuency:STARt 50 MHz
// SOURcel:FREQuency:STOP 350 MHz
SOURcel:SWEep:FREQuency:SPACing LINear
SOURcel:SWEep:FREQuency:SHApe SAWTooth

// Activate change to start frequency while waiting for next trigger
// Prerequisites: sweep mode single and sweep waveform sawtooth
SOURcel:SWEep:FREQuency:RETRace 1
// Alternatively reset all sweeps to their initial value
SOURcel:SWEep:RESet:ALL

// Set the step width and dwell time
SOURcel:SWEep:FREQuency:STEP:LINear 1 MHz
// Alternatively set the number of steps, then the sweep step width is
// set automatically
SOURcel:SWEep:FREQuency:POINts 301
SOURcel:SWEep:FREQuency:DWELL 500 ms
// With logarithmic spacing select the step width as follows
// (steps of 10 percent of the previous frequency in each instance)
SOURcel:SWEep:FREQuency:SPACing LOG
SOURcel:SWEep:FREQuency:STEP:LOGarithmic 10PCT

// Activate the sweep
// Trigger the sweep (depending on the set mode) and query the status
SOURcel:FREQuency:MODE SWEep
// Perform a one-off RF frequency sweep
SOURcel:SWEep:FREQuency:EXECute
SOURcel:SWEep:FREQuency:RUNning?
// 1
// the frequency sweep is running

// For manual step RF sweep use the following commands
*RST; *CLS
// Activate manual step RF sweep
SOURcel:SWEep:FREQuency:MODE MANual
// Activate the RF frequency sweep.
SOURcel:FREQuency:MODE SWEep

```

```

// Activate RF Output1.
Output1:STATe 1
// Input the frequency manually for each step
SOURcel:FREQuency:MANual 200 MHz
SOURcel:FREQuency:MANual 201 MHz
// Alternatively use the UP or DOWN commands with the set step width.
SOURcel:SWEep:FREQuency:STEP:LINear 1 MHz
SOURcel:FREQuency:MANual UP

// Activate a combined RF frequency / level sweep
*RST; *CLS
*RST; *CLS
SYSTem:DISPlay:UPDate OFF
TRIGger1:FSWEEP:SOURce SINGLE
SOURcel:SWEep:COMBined:MODE AUTO
SOURcel:SWEep:COMBined:COUNt 200
SOURcel:FREQuency:STARt 1000000000 Hz
SOURcel:FREQuency:STOP 5000000000 Hz
SOURcel:POWer:STARt -30 dBm
SOURcel:POWer:STOP -10 dBm
SOURcel:SWEep:COMBined:RETRace 1
SOURcel:SWEep:COMBined:SHAPE SAWT
SOURcel:SWEep:COMBined:DWELL 0.01
// Activate combined RF frequency/level sweep
SOURcel:FREQuency:MODE COMB
// Activate RF Output1.
Output1:STATe 1
// Execute combined frequency / level sweep
SOURcel:SWEep:COMBined:EXECute

// Configure an RF frequency ramp sweep
// Select a continuous analog frequency sweep,
// synchronized with the sweep time, repeating automatically
// set start and stop frequency
SOURcel:SWEep:GENeration ANAL
// TRIGger1:FSWEEP:SOURce AUTO
SOURcel:SWEep:FREQuency:MODE AUTO
SOURcel:SWEep:FREQuency:MODE:ADVanced AUTO
INITiatel:FSWEEP:CONTinuous 1
SOURcel:FSWEEP:TRIGger:SOURce:ADVanced IMM
// TRIGger1:FSWEEP:SOURce:ADVanced IMM
SOURcel:SWEep:FREQuency:STARt 100000000
SOURcel:SWEep:FREQuency:STOP 500000000
SOURcel:SWEep:FREQuency:CENter 300000000
SOURcel:SWEep:FREQuency:SPAN 400000000
SOURcel:SWEep:FREQuency:TIME 0.015
SOURcel:SWEep:FREQuency:SHAPE SAWT
SOURcel:FREQuency:MODE SWE
// Activate RF Output1.
Output1:STATe 1

```

```
// Query blanked frequency points
SOURce1:SWEep:FREQuency:ANALog:SWPoints?
// 8500,10000,12000,17000,100000,1000000,8000000,12500000,
// ...,75000000000,80000000000,150000000000,300000000000
```

:SWEep:TYPE.....	723
[:SOURce<hw>]:SWEep:POWer:DWELI.....	724
[:SOURce<hw>]:SWEep:GENeration.....	724
[:SOURce<hw>]:SWEep:POWer:MODE.....	724
[:SOURce<hw>]:SWEep:POWer:POINts.....	725
[:SOURce<hw>]:SWEep:POWer:SPACing:MODE?.....	725
[:SOURce<hw>]:SWEep:POWer:STEP[:LOGarithmic].....	725
[:SOURce<hw>]:SWEep[:FREQuency]:ANALog:SWPoints?.....	726
[:SOURce<hw>]:SWEep[:FREQuency]:DWELI.....	726
[:SOURce<hw>]:SWEep[:FREQuency]:MODE.....	726
[:SOURce<hw>]:SWEep[:FREQuency]:POINts.....	727
[:SOURce<hw>]:SWEep[:FREQuency]:SPACing.....	727
[:SOURce<hw>]:SWEep:POWer:SHAPE.....	728
[:SOURce<hw>]:SWEep[:FREQuency]:SHAPE.....	728
[:SOURce<hw>]:SWEep:POWer:EXECute.....	728
[:SOURce<hw>]:SWEep[:FREQuency]:EXECute.....	728
[:SOURce<hw>]:SWEep:POWer:RETRace.....	728
[:SOURce<hw>]:SWEep[:FREQuency]:RETRace.....	728
[:SOURce<hw>]:SWEep:POWer:RUNNing?.....	729
[:SOURce<hw>]:SWEep[:FREQuency]:RUNNing?.....	729
[:SOURce<hw>]:SWEep[:FREQuency]:STEP:LOGarithmic.....	729
[:SOURce<hw>]:SWEep[:FREQuency]:STEP[:LINear].....	729
[:SOURce<hw>]:COMBined:FREQuency:STARt.....	730
[:SOURce<hw>]:COMBined:FREQuency:STOP.....	730
[:SOURce<hw>]:COMBined:POWer:STARt.....	730
[:SOURce<hw>]:COMBined:POWer:STOP.....	731
[:SOURce<hw>]:SWEep:COMBined:COUNt.....	731
[:SOURce<hw>]:SWEep:COMBined:DWELI.....	731
[:SOURce<hw>]:SWEep:COMBined:EXECute.....	731
[:SOURce<hw>]:SWEep:COMBined:MODE.....	732
[:SOURce<hw>]:SWEep:COMBined:RETRace.....	732
[:SOURce<hw>]:SWEep:COMBined:SHAPE.....	733
[:SOURce<hw>]:SWEep:RESet[:ALL].....	733
[:SOURce<hw>]:SWEep[:FREQuency]:TIME.....	733
[:SOURce<hw>]:SWEep:MARKer:OUTPut:POLarity.....	733
[:SOURce<hw>]:SWEep[:FREQuency]:MARKer:ACTive.....	734
[:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FREQuency.....	734
[:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FState.....	734

:SWEep:TYPE <SweepType>

Provided for compatibility between SCPI and Rohde & Schwarz commands.

Parameters:

<SweepType> ADVanced | STANdard
 *RST: n.a. (factory preset: STANdard)

[:SOURce<hw>]:SWEep:POWer:DWELI <Dwell>

Sets the dwell time for a level sweep step.

Parameters:

<Dwell> float
 Range: 0.001 to 100
 Increment: 100E-6
 *RST: 0.01

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Dwell Time"](#) on page 189

[:SOURce<hw>]:SWEep:GENeration <SweepType>

Selects frequency sweep type.

Parameters:

<SweepType> STEPped | ANALog
STEPped
 Performs a frequency sweep.
ANALog
 Performs a continuous analog frequency sweep (ramp), synchronized with the sweep time [:SOURce<hw>]:SWEep[:FREQuency]:TIME.
 *RST: STEPped

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Sweep Type"](#) on page 185

[:SOURce<hw>]:SWEep:POWer:MODE <Mode>

Sets the cycle mode for the level sweep.

Parameters:

<Mode> AUTO | MANual | STEP
AUTO
 Each trigger triggers exactly one complete sweep.
MANual
 The trigger system is not active. You can trigger every step individually with the command [:SOURce<hw>]:POWer:MANual. The level value increases at each step by the value that you define with [:SOURce<hw>]:POWer:STEP[:INCRement]. Values directly entered with the command [:SOURce<hw>]:POWer:MANual are not taken into account.

STEP

Each trigger triggers one sweep step only. The level increases by the value entered with `[:SOURce<hw>] :POWER:STEP [:INCRement]`.

*RST: AUTO

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Mode"](#) on page 186

[:SOURce<hw>] :SWEep:POWER:POINTS <Points>

Sets the number of steps within the RF level sweep range.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Parameters:

<Points> integer
Range: 2 to Max

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720.

[:SOURce<hw>] :SWEep:POWER:SPACing:MODE?

Queries the level sweep spacing. The sweep spacing for level sweeps is always linear.

Return values:

<Mode> LINear
*RST: LINear

Example: `SWE:POW:SPAC:MODE?`
queries the sweep spacing for a level sweep at RF output.
Result: "LIN"
linear spacing

Usage: Query only

[:SOURce<hw>] :SWEep:POWER:STEP[:LOGarithmic] <Logarithmic>

Sets a logarithmically determined step size for the RF level sweep. The level is increased by a logarithmically calculated fraction of the current level.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Parameters:

<Logarithmic> float
 The unit dB is mandatory.
 Range: 0.01 to 139 dB
 Increment: 0.01
 *RST: 1
 Default unit: dB

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Step"](#) on page 194

[:SOURce<hw>]:SWEep[:FREQuency]:ANALog:SWPoints?

Queries blank points during the RF frequency sweep in ramp sweep mode.

At certain switchover frequency points, the R&S SMA100B shortly blanks the RF signal to adjust the settings accordingly.

This query returns all blanked frequency points within the entire frequency range, regardless of the set frequency sweep range.

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720.

Usage: Query only

[:SOURce<hw>]:SWEep[:FREQuency]:DWELI <Dwell>

Sets the dwell time for a frequency sweep step.

Parameters:

<Dwell> float
 Range: 0.001 to 100
 Increment: 100E-6
 *RST: 0.01

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Dwell Time"](#) on page 189

[:SOURce<hw>]:SWEep[:FREQuency]:MODE <Mode>

Sets the cycle mode for the frequency sweep.

Parameters:

<Mode> AUTO | MANual | STEP

AUTO

Each trigger event triggers exactly one complete sweep.

MANual

The trigger system is not active. You can trigger every step individually by input of the frequencies with the command [:

SOURce<hw>]:FREQuency:MANual.

STEP

Each trigger event triggers one sweep step. The frequency increases by the value entered with [:SOURce<hw>]:SWEep[:FREQuency]:STEP[:LINear] (linear spacing) or [:SOURce<hw>]:SWEep[:FREQuency]:STEP:LOGarithmic (logarithmic spacing).

*RST: AUTO

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Mode"](#) on page 186

[:SOURce<hw>]:SWEep[:FREQuency]:POINTs <Points>

Sets the number of steps within the RF frequency sweep range.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Two separate POINTs values are used for linear or logarithmic sweep spacing ([:SOURce<hw>]:SWEep[:FREQuency]:SPACing LIN | LOG). The command always affects the currently set sweep spacing.

Parameters:

<Points> integer
Range: 2 to Max

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

[:SOURce<hw>]:SWEep[:FREQuency]:SPACing <Spacing>

Selects the mode for the calculation of the frequency intervals, with which the current frequency at each step is increased or decreased.

The keyword [:FREQuency] can be omitted; then the command is SCPI-compliant.

Parameters:

<Spacing> LINear | LOGarithmic

LINear

Sets a fixed frequency value as step width and adds it to the current frequency.

The linear step width is entered in Hz, see [:SOURce<hw>]:SWEep[:FREQuency]:STEP[:LINear].

LOGarithmic

Sets a constant fraction of the current frequency as step width and adds it to the current frequency.

The logarithmic step width is entered in %, see [:

[SOURce<hw>\]:SWEep\[:FREQuency\]:STEP:LOGarithmic.](#)

*RST: LINear

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Spacing"](#) on page 189

[:SOURce<hw>]:SWEep:POWer:SHAPE <Shape>

[:SOURce<hw>]:SWEep[:FREQuency]:SHAPE <Shape>

Determines the waveform shape for a frequency sweep sequence.

Parameters:

<Shape> SAWTooth | TRlangle

*RST: SAWTooth

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Shape"](#) on page 188

[:SOURce<hw>]:SWEep:POWer:EXECute

[:SOURce<hw>]:SWEep[:FREQuency]:EXECute

Executes an RF frequency sweep.

The command performs a single sweep and is therefore only effective in manual sweep mode.

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

Usage: Event

Manual operation: See ["Execute Single Sweep"](#) on page 190

[:SOURce<hw>]:SWEep:POWer:RETRace <State>

[:SOURce<hw>]:SWEep[:FREQuency]:RETRace <State>

Activates that the signal changes to the start frequency value while it is waiting for the next trigger event.

You can enable this feature, when you are working with sawtooth shapes in sweep mode "Single" or "External Single".

Parameters:

<State> 1 | ON | 0 | OFF

*RST: 0

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Retrace"](#) on page 187

[:SOURce<hw>]:SWEep:POWer:RUNNing?
[:SOURce<hw>]:SWEep[:FREQuency]:RUNNing?

Queries the current sweep state.

Return values:

<State> 1 | ON | 0 | OFF

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

Usage: Query only

[:SOURce<hw>]:SWEep[:FREQuency]:STEP:LOGarithmic <Logarithmic>

Sets a logarithmically determined step width for the RF frequency sweep. The value is added at each sweep step to the current frequency.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Parameters:

<Logarithmic> float
 The unit is mandatory.
 Range: 0.01 to 100
 Increment: 1E-3
 *RST: 1
 Default unit: PCT

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Step Linear/Step Logarithmic"](#) on page 192

[:SOURce<hw>]:SWEep[:FREQuency]:STEP[:LINear] <Linear>

Sets the step width for linear sweeps.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Omit the optional keywords so that the command is SCPI-compliant.

Parameters:

<Linear> float
 Range: 0.001 Hz to (STOP - START)
 Increment: 0.01

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Step Linear/Step Logarithmic"](#) on page 192

[[:SOURce<hw>]:COMBined:FREQUENCY:START <CombFreqStart>

Sets the start frequency of the combined RF frequency / level sweep.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Parameters:

<CombFreqStart> float
 Range: -59999E5 to 12E9
 Increment: 0.01
 *RST: 100E6

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Start Frequency/Stop Frequency"](#) on page 191

[[:SOURce<hw>]:COMBined:FREQUENCY:STOP <CombFreqStop>

Sets the end frequency of the combined RF frequency / level sweep.

Parameters:

<CombFreqStop> float
 Range: -59999E5 to 12E9
 Increment: 0.01
 *RST: 500E6

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Start Frequency/Stop Frequency"](#) on page 191

[[:SOURce<hw>]:COMBined:POWER:START <CombPowStart>

Sets the start level value of the combined RF frequency / level sweep.

See [Chapter 7.2.1, "Correlating parameters in sweep mode"](#), on page 178.

Parameters:

<CombPowStart> float
 Range: -245 to 120
 Increment: 0.01
 *RST: -30

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Start Level / Stop Level"](#) on page 193

[:SOURce<hw>]:COMBined:POWER:STOP <CombPowStop>

Sets the stop level value of the combined RF frequency / level sweep.

Parameters:

<CombPowStop>	float
Range:	-245 to 120
Increment:	0.01
*RST:	-10

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Start Level / Stop Level"](#) on page 193

[:SOURce<hw>]:SWEep:COMBined:COUNT <StepCount>

Defines the number of sweeps you want to execute.

This parameter applies to `[:SOURce<hw>]:SWEep:COMBined:MODE > SINGLE`. To start the sweep signal generation, use the command `[:SOURce<hw>]:SWEep:COMBined:EXECute` on page 731.

Parameters:

<StepCount>	integer
Range:	1 to SeMAX_INT_STEP-1
*RST:	501

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Step Count"](#) on page 194

[:SOURce<hw>]:SWEep:COMBined:DWELL <Dwell>

Sets the dwell time for the combined frequency / level sweep.

Parameters:

<Dwell>	float
Range:	0.01 to 100
Increment:	100E-6
*RST:	0.01

Example: See [Example"Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Dwell Time"](#) on page 189

[:SOURce<hw>]:SWEep:COMBined:EXECute

Executes an RF frequency / level sweep cycle.

The command triggers one single sweep manually. Therefore, you can use it in manual sweep mode, selected with the command `[:SOURce<hw>] :SWEep:COMBined:MODE > MANual`.

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720.

Usage: Event

Manual operation: See ["Execute Single Sweep"](#) on page 190

[:SOURce<hw>] :SWEep:COMBined:MODE <SweepCombMode>

Sets the cycle mode for the combined frequency / level sweep.

Parameters:

<SweepCombMode> AUTO | MANual | STEP

AUTO

Each trigger event triggers exactly one complete sweep.

MANual

The trigger system is not active. You can trigger every step individually by input of the frequencies with the commands `[:SOURce<hw>] :FREQuency:MANual` and `[:SOURce<hw>] :POWer:MANual`.

STEP

Each trigger event triggers one sweep step.

*RST: AUTO

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Mode"](#) on page 186

[:SOURce<hw>] :SWEep:COMBined:RETRace <RetraceState>

Activates that the signal changes to the start level value while it is waiting for the next trigger event.

You can enable this feature, when you are working with sawtooth shapes in sweep mode "Single" or "External Single".

Parameters:

<RetraceState> 1 | ON | 0 | OFF

*RST: 0

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Retrace"](#) on page 187

[:SOURce<hw>]:SWEep:COMBined:SHAPE <Shape>

Selects the waveform shape for the combined frequency / level sweep sequence.

Parameters:

<Shape> SAWTooth | TRlangle
*RST: SAWTooth

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 720.

Manual operation: See ["Shape"](#) on page 188

[:SOURce<hw>]:SWEep:RESet[:ALL]

Resets all active sweeps to the starting point.

Usage: Event

Manual operation: See ["Reset Sweep"](#) on page 190

[:SOURce<hw>]:SWEep[:FREQuency]:TIME <Time>

Sets the duration of a frequency ramp sweep step.

Parameters:

<Time> float
Range: 0.01 to 100
Increment: 1E-4
*RST: 0.015
Default unit: s

Example: SOURce1:SWEep:FREQuency:SPACing RAMP
SOURce1:SWEep:FREQuency:TIME 0.020

Options: R&S SMAB-B28

Manual operation: See ["Sweep Time"](#) on page 189

[:SOURce<hw>]:SWEep:MARKer:OUTPut:POLarity <Polarity>

Selects the polarity of the marker signal.

Parameters:

<Polarity> NORMal | INVerted
NORMal
Marker level is high when after reaching the mark.
INVerted
Marker level is low after reaching the mark.
*RST: NORMal

Example: See [\[:SOURce<hw>\]:SWEep\[:FREQuency\]:MARKer<ch>:FREQuency](#) on page 734.

Options: R&S SMAB-B28

Manual operation: See ["Marker Polarity"](#) on page 198

[:SOURce<hw>]:SWEep[:FREQuency]:MARKer:ACTive <Active>

Defines the marker signal to be output with a higher voltage than all other markers.

Parameters:

<Active> NONE | M01 | M02 | M03 | M04 | M05 | M06 | M07 | M08 | M09 | M10
 *RST: NONE

Example: See [\[:SOURce<hw>\]:SWEep\[:FREQuency\]:MARKer<ch>:FREQuency](#) on page 734.

Options: R&S SMAB-B28

Manual operation: See ["Active Marker"](#) on page 198

[:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FREQuency <Frequency>

Sets the frequency of the selected marker.

Suffix:

<ch> 1 to 10
 Marker

Parameters:

<Frequency> float
 Increment: 0.01
 *RST: $100 + n \cdot 100$

Example:

```
SOURce1:SWEep:MARKer:OUTPut:POLarity NORMal
three markers at 1 GHz, 2 GHz and 3 GHz
SOURce1:SWEep:FREQuency:MARKer1:FREQuency
1000000000
SOURce1:SWEep:FREQuency:MARKer2:FREQuency
2000000000
SOURce1:SWEep:FREQuency:MARKer3:FREQuency
3000000000
SOURce1:SWEep:FREQuency:MARKer1:FSTate 1
SOURce1:SWEep:FREQuency:MARKer2:FSTate 1
SOURce1:SWEep:FREQuency:MARKer3:FSTate 1
SOURce1:SWEep:FREQuency:MARKer:ACTive M03
```

Options: R&S SMAB-B28

Manual operation: See ["Frequency x"](#) on page 197

[:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FSTate <FState>

Activates the selected marker.

Suffix:

<ch> 1 to 10
Marker

Parameters:

<FState> 1 | ON | 0 | OFF
*RST: 0

Example:

See [:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:
FREQuency on page 734.

Options:

R&S SMAB-B28

Manual operation: See "State" on page 197

14.18 SYSTem subsystem

The SYSTem subsystem contains a series of commands for general functions which do not directly affect signal generation.

Example: Retrieving instrument specification

Note: The following values are merely an example.

```
// Retrieve information on data sheet versions.
// Query all data sheet versions saved on the instrument:
SYSTem:SPECification:VERSion:CATalog?
"04.03,04.02,04.01,04.00,03.04,03.03,03.02,03.01,03.00,02.96,02.95,02.94,
02.02,02.01,02.00,01.03,01.02,01.01,01.00"

// Query the initial data sheet version on delivery
SYSTem:SPECification:VERSion:FACTory?
// Response: "04.00"

// Select a specific data sheet version:
SYSTem:SPECification:VERSion "04.01"

// Retrieve information on parameters that belong to a particular data sheet.
// Query the IDs of all parameters listed in the selected version:
SYSTem:SPECification:VERSion "04.03"
SYSTem:SPECification:IDEntification:CATalog?
"ID_RF_FREQ_SETTING_TIME_ALC_ON_MS,ID_RF_FREQ_SETTING_TIME_MS,..."

// Query data sheet information on a specific parameter by its ID.
SYSTem:SPECification? "ID_RF_FREQ_SETTING_TIME_ALC_ON_MS"
// Returns the specified value of the parameter.
```

Example: Retrieving information on network-related settings

```
SYSTem:COMMunicate:NETWork:STATus?
// 1
SYSTem:PROTection1:STATe 0,123456
```

```
SYSTem:COMMunicate:NETWork:IPAdDress:MODE STAT
SYSTem:COMMunicate:NETWork:IPAdDress "10.113.0.104"
SYSTem:COMMunicate:NETWork:IPAdDress:DNS "10.0.2.166"
SYSTem:COMMunicate:NETWork:COMMon:HOSTname?
// "SMA100B-102030"
SYSTem:COMMunicate:NETWork:COMMon:WORKgroup "instrument"
SYSTem:COMMunicate:NETWork:COMMon:DOMain "rsint.net"
SYSTem:COMMunicate:NETWork:IPAdDress:GATeway "10.113.0.1"
SYSTem:COMMunicate:NETWork:IPAdDress:SUBNet:MASK "255.255.252.0"
SYSTem:COMMunicate:NETWork:MACAdDress "08 00 27 a3 a1 70"
SYSTem:PROTection1:STATe 1
```

Example: Restarting the network

```
SYSTem:COMMunicate:NETWork:REStArt
// terminates the network connection and sets it up again
```

Example: Finding out VISA resource strings

```
SYSTem:COMMunicate:NETWork:RESource?
// Response: "TCPIP::10.113.0.104::inst0::INSTR"

SYSTem:COMMunicate:HISLip:RESource?
// Response: "TCPIP::10.113.0.104::hislip0::INSTR"

SYSTem:COMMunicate:SOCKet:RESource?
// Response: "TCPIP::10.113.0.104::5025::SOCKET"

SYSTem:COMMunicate:USB:RESource?
// "USB::0x0AAD::0x01DD::100001::INSTR"

SYSTem:COMMunicate:GPIB:RESource?
// Response: "GPIB::28::INSTR"
SYSTem:COMMunicate:GPIB:SELF:ADDResS?
// Response: 28
SYSTem:COMMunicate:GPIB:LTERminator?
// Response: STAN

SYSTem:COMMunicate:SERial:RESource?
// Response: "ASRL1::INSTR"
SYSTem:COMMunicate:SERial:SBITs?
// Response: 1
SYSTem:COMMunicate:SERial:BAUD?
// Response: 115200
SYSTem:COMMunicate:SERial:PARity?
// Response: NONE
```


Example: Querying the error queue

```
SYSTem:ERRor:STATic?
// Response: -221,"Settings conflict", 153,"Input voltage out of range", ...
// Returns all static errors that are collected in the error queue.
```

```
SYSTem:ERRor:HISTory:CLear
// Deletes the history entries.
```

Example: Configuring date and time

```
// Query the date and time setting of the instrument
// Query the current timezone and setting
SYSTem:DATE?
// Response: 2023,1,16;1
SYSTem:TIME?
// Response: 18,15,17;1
SYSTem:TIME:ZONE?
// Response: "";1 //default UTC setting
SYSTem:TIME:PROTOcol?
// Response: "OFF";1 // no protocol selected
SYSTem:NTP:STATe?
// Response: 0;1 // NTP is disabled

// Setting the timezone and NTP time protocol
SYSTem:TIME:ZONE:CATalog?
// Response: "UTC,leap-seconds.list,leapseconds,Africa/Abidjan,..."
SYSTem:TIME:ZONE "Europe/Berlin"
SYSTem:NTP:HOST "timesource.net" // sets the NTP server address
SYSTem:NTP:STATe?
// Response: 1 // the NTP time server is enabled
```

Commands

:SYSTem:ERRor:ALL?	739
:SYSTem:ERRor:CODE:ALL?	739
:SYSTem:ERRor:CODE[:NEXT]?	740
:SYSTem:ERRor:COUNT?	740
:SYSTem:ERRor[:NEXT]?	741
:SYSTem:ERRor:GNEXt?	741
:SYSTem:ERRor:HISTory:CLear	741
:SYSTem:ERRor:STATic?	742
:SYSTem:DLOCK	742
:SYSTem:KLOCK	742
:SYSTem:NINformation?	742
:SYSTem:ULOCK	743
:SYSTem:LOCK:OWNer?	743
:SYSTem:LOCK:RELease:ALL	744
:SYSTem:LOCK:REQuest[:EXCLusive]?	744
:SYSTem:SAV	744
:SYSTem:RCL	744

:SYSTem:PROTect<ch>[:STATe].....	745
:SYSTem:SECurity:VOLMode[:STATe].....	745
:SYSTem:COMMunicate:GPIB:LTERminator.....	746
:SYSTem:COMMunicate:GPIB:RESource?.....	746
:SYSTem:COMMunicate:GPIB[:SELF]:ADDRess.....	746
:SYSTem:COMMunicate:HISLip:RESource?.....	747
:SYSTem:COMMunicate:NETWork:IPADdress.....	747
:SYSTem:COMMunicate:NETWork:IPADdress:MODE.....	747
:SYSTem:COMMunicate:NETWork:MACAddress.....	747
:SYSTem:COMMunicate:NETWork:RESource?.....	748
:SYSTem:COMMunicate:NETWork:REStart.....	748
:SYSTem:COMMunicate:NETWork:STATus?.....	748
:SYSTem:COMMunicate:NETWork[:COMMon]:DOMain.....	748
:SYSTem:COMMunicate:NETWork[:COMMon]:HOSTname.....	749
:SYSTem:COMMunicate:NETWork[:COMMon]:WORKgroup.....	749
:SYSTem:COMMunicate:NETWork[:IPADdress]:DNS.....	749
:SYSTem:COMMunicate:NETWork[:IPADdress]:GATeway.....	749
:SYSTem:COMMunicate:NETWork[:IPADdress]:SUBNet:MASK.....	750
:SYSTem:COMMunicate:SERial:BAUD.....	750
:SYSTem:COMMunicate:SERial:PARity.....	750
:SYSTem:COMMunicate:SERial:RESource?.....	750
:SYSTem:COMMunicate:SERial:SBITs.....	750
:SYSTem:COMMunicate:SOCKet:RESource?.....	751
:SYSTem:COMMunicate:USB:RESource?.....	751
:SYSTem:HELP:EXPort.....	751
:SYSTem:IDENtification.....	751
:SYSTem:IDENtification:PRESet.....	752
:SYSTem:IRESponse.....	752
:SYSTem:ORESponse.....	752
:SYSTem:LANGuage.....	753
:SYSTem:INFormation:SCPI.....	753
:SYSTem:SECurity:SANitize[:STATe].....	753
:SYSTem:SECurity:SUPolicy.....	753
:SYSTem:SPECification?.....	754
:SYSTem:SPECification:VERsion.....	754
:SYSTem:SPECification:IDENtification:CATalog?.....	754
:SYSTem:SPECification:PARAmeter?.....	755
:SYSTem:SPECification:VERsion:CATalog?.....	755
:SYSTem:SPECification:VERsion:FACTory?.....	755
:SYSTem:SRData?.....	756
:SYSTem:STARtup:COMPLete?.....	756
:SYSTem:DATE.....	756
:SYSTem:NTP:HOSTname.....	757
:SYSTem:NTP:STATe.....	757
:SYSTem:TIME.....	757
:SYSTem:TIME:ZONE.....	757
:SYSTem:TIME:ZONE:CATalog?.....	758
:SYSTem:TIME:PROTocol.....	758
:SYSTem:UPTime?.....	758
:SYSTem:BIOS:VERsion?.....	758

:SYSTem:VERSion?	759
:SYSTem:OSYStem?	759
:SYSTem:MMEMory:PATH:USER?	759
:SYSTem:DFPR?	759
:SYSTem:REBoot	760
:SYSTem:REStart	760
:SYSTem:SHUTdown	760
:SYSTem:WAIT	760
:SYSTem:FILEs:TEMPorary:DELeTe	761

:SYSTem:ERRor:ALL?

Queries the error/event queue for all unread items and removes them from the queue.

Return values:

<All> string
 Error/event_number,"Error/event_description>[;Device-depend-ent info]"
 A comma separated list of error number and a short description of the error in FIFO order.
 If the queue is empty, the response is 0, "No error"
 Positive error numbers are instrument-dependent. Negative error numbers are reserved by the SCPI standard.
 Volatile errors are reported once, at the time they appear. Identical errors are reported repeatedly only if the original error has already been retrieved from (and hence not any more present in) the error queue.

Example:

SYST:ERR:ALL?
 Queries all entries in the error queue.
 Response: 0, 'no error'
 No errors have occurred since the error queue was last read out.

Usage:

Query only

Manual operation: See ["Clear History"](#) on page 774

:SYSTem:ERRor:CODE:ALL?

Queries the error numbers of all entries in the error queue and then deletes them.

Return values:

<All> string
 Returns the error numbers. To retrieve the entire error text, send the command [:SYSTem:ERRor:ALL?](#).
 0
 "No error", i.e. the error queue is empty
Positive value
 Positive error numbers denote device-specific errors

Negative value

Negative error numbers denote error messages defined by SCPI.

Example:

SYST:ERR:CODE:ALL

Queries all entries in the error queue.

Response: 0

No errors have occurred since the error queue was last read out.

Usage:

Query only

:SYSTem:ERRor:CODE[:NEXT]?

Queries the error number of the oldest entry in the error queue and then deletes it.

Return values:

<Next>

string

Returns the error number. To retrieve the entire error text, send the command :SYSTem:ERRor:ALL?.

0

"No error", i.e. the error queue is empty

Positive value

Positive error numbers denote device-specific errors

Negative value

Negative error numbers denote error messages defined by SCPI.

Example:

SYST:ERR:CODE

Queries the oldest entry in the error queue.

Response: 0

No errors have occurred since the error queue was last read out.

Usage:

Query only

:SYSTem:ERRor:COUNt?

Queries the number of entries in the error queue.

Return values:

<Count>

integer

0

The error queue is empty.

Example:

SYST:ERR:COUN

Queries the number of entries in the error queue.

Response: 1

One error has occurred since the error queue was last read out.

Usage:

Query only

:SYSTem:ERRor[:NEXT]?

Queries the error/event queue for the oldest item and removes it from the queue.

Return values:

<Next> string

Error/event_number,"Error/event_description>[;Device-dependent info]"

Error number and a short description of the error.

If the queue is empty, the response is 0, "No error"

Positive error numbers are instrument-dependent. Negative error numbers are reserved by the SCPI standard.

Volatile errors are reported once, at the time they appear. Identical errors are reported repeatedly only if the original error has already been retrieved from (and hence not any more present in) the error queue.

Example:

SYST:ERR?

Queries the oldest entry in the error queue.

Response: 0, 'no error'

No errors have occurred since the error queue was last read out.

Usage: Query only

Manual operation: See ["Static Notifications/History"](#) on page 774

:SYSTem:ERRor:GNEXt?

Similar to [:SYSTem:ERRor\[:NEXT\]?](#), but queries the next entry from the global persistent error/event queue.

Return values:

<NextGlobalError> string

Error/event number, "Error/event description> [;Device dependent info]"

An error number and a short description of the error.

Positive error numbers are instrument-dependent. Negative error numbers are reserved by the SCPI standard.

Example:

SYST:ERR:GNEX?

Returns the next error message from the global error queue.

Usage: Query only

:SYSTem:ERRor:HISTory:CLEar

Clears the error history.

Example: See [Example"Querying the error queue"](#) on page 737

Usage: Event

Manual operation: See ["Clear History"](#) on page 774

:SYSTem:ERRor:STATic?

Returns a list of all errors existing at the time when the query is started. This list corresponds to the display on the info page under manual control.

Return values:

<StaticErrors> string

Example: See [Example "Querying the error queue"](#) on page 737

Usage: Query only

Manual operation: See ["Static Notifications/History"](#) on page 774

:SYSTem:DLOCk <DispLockStat>

Disables the manual operation over the display, including the front panel keyboard of the instrument.

Parameters:

<DispLockStat> 1 | ON | 0 | OFF

*RST: n.a. (factory preset: 0)

Example: SYST:DLOC ON

Activates the display lock. The instrument cannot be operated via the display until it has been enabled with SYST:DLOC OFF.

Manual operation: See ["User Interface"](#) on page 366
 See ["Enabling a locked user interface for manual operation"](#)
 on page 367

:SYSTem:KLOCk <State>

Disables the front panel keyboard of the instrument.

Parameters:

<State> 1 | ON | 0 | OFF

*RST: n.a. (factory preset: 0)

Example: SYST:KLOC ON

Locks the front panel and external controls.
 To enable the controls, send SYST:KLOC OFF.

Manual operation: See ["User Interface"](#) on page 366
 See ["Enabling a locked user interface for manual operation"](#)
 on page 367

:SYSTem:NINformation?

Queries the oldest information message ("Error History > Level > Info") in the error/event queue.

Return values:**<NextInfo>** string**Example:**`:SYSTem:NINFormation?`

Queries the oldest entry in the info message queue.

Response: 90,"Info;=== Instrument startup...
==="

Information message containing error number 90, that states, that the instrument startup is complete.

Usage:

Query only

:SYSTem:ULOCK <Mode>

Locks or unlocks the user interface of the instrument.

Parameters:**<Mode>** ENABLEd | DONLy | DISabled | TOFF | VNConly**ENABLEd**

Unlocks the display, the touchscreen and all controls for the manual operation.

DONLy

Locks the touchscreen and controls for the manual operation of the instrument. The display shows the current settings.

VNConly

Locks the touchscreen and controls for the manual operation, and enables remote operation over VNC. The display shows the current settings.

TOFF

Locks the touchscreen for the manual operation of the instrument. The display shows the current settings.

DISabled

Locks the display, the touchscreen and all controls for the manual operation.

***RST:** n.a. (factory preset: ENABLEd)**Example:**`:SYST:ULOC DIS`

Activates the user interface lock, including display and controls.

Manual operation:See ["User Interface"](#) on page 366See ["Enabling a locked user interface for manual operation"](#) on page 367

:SYSTem:LOCK:OWNer?

Queries the sessions that have locked the instrument currently.

If an exclusive lock is set, the query returns the owner of this exclusive lock, otherwise it returns NONE.

Return values:

<Owner> string

Example:

SYST:LOCK:OWN?

Returns the owner of locking.

Response: NONE

The instrument is not locked.

Usage:

Query only

:SYSTem:LOCK:RELease:ALL

Revokes the exclusive access to the instrument.

Usage:

Setting only

:SYSTem:LOCK:REQuest[:EXCLusive]?

Queries whether a lock for exclusive access to the instrument via ethernet exists. If successful, the query returns a 1, otherwise 0.

Return values:

<Success> integer

Example:

SYST:LOCK:REQ?

Queries the state of exclusive locking.

Response: 1

The exclusive locking is active.

Usage:

Query only

:SYSTem:SAV <Pathname>

Saves the current R&S SMA100B settings into a file with defined filename and into a specified directory. The file extension (*.savrc1txt) is assigned automatically.

Setting parameters:

<Pathname> string

Example:

SYSTem:SAV "/var/user/temp/Test"

Saves the file Test.savrc1txt into the directory /var/user/temp/.

Usage:

Setting only

:SYSTem:RCL <Pathname>

Loads a file with previously saved R&S SMA100B settings.

Loads the selected file with previously saved R&S SMA100B settings from the default or the specified directory. Loaded are files with extension *.savrc1txt.

Setting parameters:**<Pathname>** string**Example:**

SYSTem:RCL "/var/user/temp/Test"
 Loads the file Test.savrc1txt from the directory /var/user/temp/.

Usage:

Setting only

:SYSTem:PROTect<ch>[:STATe] <State>[, <Key>]

Activates and deactivates the specified protection level.

Suffix:

<ch> Indicates the protection level.
 See also ["Protection"](#) on page 360

Parameters:

<State> 1 | ON | 0 | OFF
***RST:** n.a. (factory preset: 1)

Setting parameters:

<Key> integer
 The respective functions are disabled when the protection level is activated. No password is required for activation of a level. A password must be entered to deactivate the protection level. The default password for the first level is 123456. This protection level is required to unlock internal adjustments for example.

Example:

To activate protection level:
 SYSTem:PROTect1:STATe 1
 Internal adjustments or hostname cannot be changed.
 To unlock protection level 1:
 SYSTem:PROTect1:STATe 0,123456
 Internal adjustments are accessible.

Manual operation: See ["Protection Level/Password"](#) on page 362**:SYSTem:SECurity:VOLMode[:STATe] <SecPassWord>, <MmemProtState>**

Activates volatile mode, so that no user data can be written to the internal memory permanently.

To enable volatile mode, reboot the instrument. Otherwise the change has no effect.

Parameters:

<MmemProtState> 0 | 1 | OFF | ON
***RST:** 0

Setting parameters:

<SecPassWord> string
 Current security password
 The default password is 123456.

Example: SYSTem:SECurity:VOLMode:STATe "123456", 1
 SYSTem:REBoot

Manual operation: See ["Volatile Mode"](#) on page 364

:SYSTem:COMMunicate:GPIB:LTERminator <LTerminator>

Sets the terminator recognition for remote control via GPIB interface.

Parameters:

<LTerminator> STANDard | EOI

EOI
 Recognizes an LF (Line Feed) as the terminator only when it is sent with the line message EOI (End of Line). This setting is recommended particularly for binary block transmissions, as binary blocks may coincidentally contain a character with value LF (Line Feed), although it is not determined as a terminator.

STANDard
 Recognizes an LF (Line Feed) as the terminator regardless of whether it is sent with or without EOI.

*RST: n.a. (factory preset: STANDard)

Example: See [Example "Finding out VISA resource strings"](#) on page 736.

:SYSTem:COMMunicate:GPIB:RESource?

Queries the visa resource string for remote control via the GPIB interface.

To change the GPIB address, use the command `:SYSTem:COMMunicate:GPIB[:SELF]:ADDRess`.

Return values:

<Resource> string

Example: See [Example "Finding out VISA resource strings"](#) on page 736.

Usage: Query only

:SYSTem:COMMunicate:GPIB[:SELF]:ADDRess <Address>

Sets the GPIB address.

Parameters:

<Address> integer
 Range: 0 to 30
 *RST: n.a. (factory preset: 28)

Example: See [Example"Finding out VISA resource strings"](#) on page 736.

Manual operation: See ["GPIB Channel Address"](#) on page 404

:SYSTem:COMMunicate:HISLip:RESource?

Queries the VISA resource string. This string is used for remote control of the instrument with HiSLIP protocol.

Return values:

<Resource> string

Example: See [Example"Finding out VISA resource strings"](#) on page 736.

Usage: Query only

Manual operation: See ["HISLIP"](#) on page 402
See ["GPIB"](#) on page 403

:SYSTem:COMMunicate:NETWork:IPAdDress <IpAddress>

Sets the IP address.

Parameters:

<IpAddress> string
Range: 0.0.0.0. to ff.ff.ff.ff

Example: See [Example"Retrieving information on network-related settings"](#) on page 735.

Manual operation: See ["IP Address"](#) on page 400

:SYSTem:COMMunicate:NETWork:IPAdDress:MODE <Mode>

Selects manual or automatic setting of the IP address.

Parameters:

<Mode> AUTO | STATic
*RST: n.a. (factory preset: AUTO)

Example: See [Example"Retrieving information on network-related settings"](#) on page 735.

Manual operation: See ["Address Mode"](#) on page 400

:SYSTem:COMMunicate:NETWork:MACaddress <MacAddress>

Queries the MAC address of the network adapter.

This is a password-protected function. Unlock the protection level 1 to access it.

Parameters:

<MacAddress> string

Example: See [Example"Retrieving information on network-related settings"](#) on page 735.

Manual operation: See ["MAC Address"](#) on page 401

:SYSTem:COMMunicate:NETWork:RESource?

Queries the visa resource string for Ethernet instruments.

Return values:

<Resource> string

Example: See [Example"Finding out VISA resource strings"](#) on page 736.

Usage: Query only

Manual operation: See ["VXI11"](#) on page 402

:SYSTem:COMMunicate:NETWork:REStart

Restarts the network.

Example: See [Example"Restarting the network"](#) on page 736.

Usage: Event

Manual operation: See ["Restart Network"](#) on page 399

:SYSTem:COMMunicate:NETWork:STATus?

Queries the network configuration state.

Return values:

<State> 1 | ON | 0 | OFF

Example: See [Example"Retrieving information on network-related settings"](#) on page 735.

Usage: Query only

Manual operation: See ["Network Status"](#) on page 399

:SYSTem:COMMunicate:NETWork[:COMMON]:DOMain <Domain>

Determines the primary suffix of the network domain.

Parameters:

<Domain> string

Example: See [Example"Retrieving information on network-related settings"](#) on page 735.

Manual operation: See ["DNS Suffix"](#) on page 401

:SYSTem:COMMunicate:NETWork[:COMMON]:HOSTName <Hostname>

Sets an individual hostname for the Signal Generator.

Note: We recommend that you do not change the hostname to avoid problems with the network connection. If you change the hostname, be sure to use a unique name.

This is a password-protected function. Unlock the protection level 1 to access it.

Parameters:

<Hostname> string

Example: See [Example "Retrieving information on network-related settings"](#) on page 735.

Manual operation: See ["Hostname"](#) on page 399

:SYSTem:COMMunicate:NETWork[:COMMON]:WORKgroup <Workgroup>

Sets an individual workgroup name for the instrument.

Parameters:

<Workgroup> string

Example: See [Example "Retrieving information on network-related settings"](#) on page 735.

Manual operation: See ["Workgroup"](#) on page 400

:SYSTem:COMMunicate:NETWork[:IPAddress]:DNS <DNS>

Determines or queries the network DNS server to resolve the name.

Parameters:

<DNS> string

Example: See [Example "Retrieving information on network-related settings"](#) on page 735.

Manual operation: See ["DNS Server"](#) on page 401

:SYSTem:COMMunicate:NETWork[:IPAddress]:GATeway <Gateway>

Sets the IP address of the default gateway.

Parameters:

<Gateway> string
Range: 0.0.0.0 to ff.ff.ff.ff

Example: See [Example "Retrieving information on network-related settings"](#) on page 735.

Manual operation: See ["Default Gateway"](#) on page 401

:SYSTem:COMMunicate:NETWork[:IPAdDress]:SUBNet:MASK <Mask>

Sets the subnet mask.

Parameters:

<Mask> string

Example: See [Example"Retrieving information on network-related settings"](#) on page 735.

Manual operation: See ["Subnet Mask"](#) on page 400

:SYSTem:COMMunicate:SERial:BAUD <Baud>

Defines the baudrate for the serial remote control interface.

Parameters:

<Baud> 2400 | 4800 | 9600 | 19200 | 38400 | 57600 | 115200

*RST: n.a. (factory preset: 115200)

Example: See [Example"Finding out VISA resource strings"](#) on page 736.

Manual operation: See ["Baud Rate"](#) on page 404

:SYSTem:COMMunicate:SERial:PARity <Parity>

Enters the parity for the serial remote control interface.

Parameters:

<Parity> NONE | ODD | EVEN

*RST: n.a. (factory preset: NONE)

Example: See [Example"Finding out VISA resource strings"](#) on page 736.

Manual operation: See ["Parity"](#) on page 404

:SYSTem:COMMunicate:SERial:RESource?

Queries the visa resource string for the serial remote control interface. This string is used for remote control of the instrument.

Return values:

<Resource> string

Example: See [Example"Finding out VISA resource strings"](#) on page 736.

Usage: Query only

Manual operation: See ["SERIAL"](#) on page 403

:SYSTem:COMMunicate:SERial:SBITs <SBits>

Defines the number of stop bits for the serial remote control interface.

Parameters:

<SBits> 1 | 2
 *RST: n.a. (factory preset: 1)

Example: See [Example "Finding out VISA resource strings"](#) on page 736.

Manual operation: See ["Stop Bits"](#) on page 404

:SYSTem:COMMunicate:SOCKet:RESource?

Queries the visa resource string for remote control via LAN interface, using TCP/IP socket protocol.

Return values:

<Resource> string

Example: See [Example "Finding out VISA resource strings"](#) on page 736.

Usage: Query only

Manual operation: See ["Socket"](#) on page 403

:SYSTem:COMMunicate:USB:RESource?

Queries the visa resource string for remote control via the USB interface.

Return values:

<Resource> string

Example: See [Example "Finding out VISA resource strings"](#) on page 736.

Usage: Query only

Manual operation: See ["USB"](#) on page 403

:SYSTem:HELP:EXPort

Saves the online help as zip archive in the user directory.

Example:

```
:SYSTem:HELP:EXPort
MMEM:CDIR?
// "/var/user"
MMEM:CAT?
// ..,"Log,DIR,4096","help.tgz,BIN,69836600"
// confirms that help zip archive is saved.
```

Usage: Event

Manual operation: "Setup > Help > Export Help to User Path"

:SYSTem:IDENTification <Identification>

Selects the mode to determine the "IDN String" and the "OPT String" for the instrument, selected with command [:SYSTem:LANGuage](#).

Note: While working in an emulation mode, the R&S SMA100B specific command set is disabled, that is, the SCPI command `SYST:IDEN` is discarded.

Parameters:

<Identification> AUTO | USER

AUTO
Automatically determines the strings.

USER
User-defined strings can be selected.

*RST: n.a. (factory preset: AUTO)

Example: `SYST:IDEN AUTO`
Automatically assigns the OPT and IDN strings according to the selected instrument language.

Manual operation: See "[Mode](#)" on page 405

:SYSTem:IDENtification:PRESet

Sets the *IDN and *OPT strings in user defined mode to default values.

Example: `SYST:IDEN USER`
 `SYST:IDEN:PRES`

Usage: Event

Manual operation: See "[Set to Default](#)" on page 406

:SYSTem:IRESpone <IdnResponse>

Defines the user defined identification string for *IDN.

Note: While working in an emulation mode, the instrument's specific command set is disabled, i.e. the SCPI command `SYST:IRES` is discarded.

Parameters:

<IdnResponse> string

Example: `SYST:IDEN USER`
 `// Selects a user-defined identification`
 `SYST:IRES "Test Device"`
 `// Defines identification string 'test device'`
 `*IDN?`
 `// Response: 'test device'`

Manual operation: See "[IDN String](#)" on page 406

:SYSTem:ORESpone <OResponse>

Defines the user defined response string for *OPT.

Note: While working in an emulation mode, the instrument's specific command set is disabled, i.e. the SCPI command `SYST:ORES` is discarded.

Parameters:**<OResponse>** string**Example:**

```

SYST:IDEN USER
// Selects a user-defined identification
SYST:ORES "Test Option"
// Defines the OPT string 'test option'
*OPT?
// Response: 'test option'

```

Manual operation: See ["OPT String"](#) on page 406**:SYSTem:LANGUage <Language>**

Sets the remote control command set.

Parameters:**<Language>** string**Example:**

```

SYSTem:LANGUage "SCPI"
// selects SCPI command set

```

Manual operation: See ["Language"](#) on page 405**:SYSTem:INFormation:SCPI <InfoString>**

Inserts system information in recorded SCPI command lists, for example information on a missing command.

Parameters:**<InfoString>** string**Example:**

```

SYST:INF:SCPI "missing command"

```

enters the information into a recorded SCPI command list.

:SYSTem:SECurity:SANitize[:STATe] <SecPassWord>, <MmemProtState>

Sanitizes the internal memory.

Parameters:

<MmemProtState> 0 | 1 | OFF | ON

***RST:** 0

Setting parameters:**<SecPassWord>** string**Example:**

```

SYSTem:SECurity:SANitize[:STATe] 1

```

Manual operation: See ["Sanitize"](#) on page 365**:SYSTem:SECurity:SUPolicy <SecPassWord>, <UpdatePolicy>**

Configures the automatic signature verification for firmware installation.

Parameters:

<UpdatePolicy> STRict | CONFirm | IGNore
 *RST: n.a. (factory preset: CONFirm)

Setting parameters:

<SecPassWord> string

Manual operation: See ["Secure Update Policy"](#) on page 363

:SYSTem:SPECification? <Id>

Retrieves data sheet information for a specific parameter.

Setting parameters:

<Id> string
 Identifies the name of the entry in the data sheet, as queried with the command [:SYSTem:SPECification:IDENTification:CATalog?](#) on page 754

Return values:

<ValList> float
 Comma-separated list with the specified and, if available, the typical value of the parameter, as specified in the data sheet. See also [Chapter 13.6.2.3, "Datasheet"](#), on page 426.

Example: See [Example "Retrieving instrument specification"](#) on page 735.

Usage: Query only

:SYSTem:SPECification:VERSion <Version>

Selects a data sheet version from the data sheets saved on the instrument.

Further queries regarding the data sheet parameters (<Id>) and their values refer to the selected data sheet.

To query the list of data sheet versions, use the command [:SYSTem:SPECification:VERSion:CATalog?](#) on page 755.

Parameters:

<Version> string

Example: See [:SYSTem:SPECification?](#) on page 754.

:SYSTem:SPECification:IDENTification:CATalog?

Queries the parameter identifiers (<Id>) available in the data sheet.

Return values:

<IdList> string
 Comma-separated string of the parameter identifiers (<Id>)

Example: See [:SYSTem:SPECification?](#) on page 754.

Usage: Query only

:SYSTem:SPECification:PARameter? <Id>[, <Parameter>]

Retrieves data sheet information for a specific parameter.

Setting parameters:

<Id> string
Identifies the name of the entry in the data sheet.
Query the data sheet parameters with the command **:SYSTem:SPECification:IDENtification:CATalog?**.

<Parameter> float
An additional value the result (ValList) depends on.

Return values:

<ValList> float
Comma-separated list with the specified and, if available, the typical value of the parameter, as specified in the data sheet.

Example:

Note: The following values are merely an example. Your instrument may not support the same parameters.

```
SYST:SPEC:PAR? "ID_RF_FREQ_SETTING_TIME_MS",0.1
SYST:SPEC:PAR? "ID_RF_LEVEL_MAX_GENERAL_DBM",
0.1
```

Usage: Query only

:SYSTem:SPECification:VERSion:CATalog?

Queries all data sheet versions stored in the instrument.

Return values:

<VersCatalog> string

Example: See **:SYSTem:SPECification?** on page 754.

Usage: Query only

:SYSTem:SPECification:VERSion:FACTory?

Queries the data sheet version of the factory setting.

Return values:

<Version> string

Example: See **:SYSTem:SPECification?** on page 754.

Usage: Query only

Manual operation: See **"Versions"** on page 779

:SYSTem:SRData?

Queries the SCPI recording data from the internal file.

This feature enables you to transfer an instrument configuration to other test environments, as e.g. laboratory virtual instruments.

Return values:

<FileData> block data

Example:

```
SYSTem:SRData?
// #3118:SOURce1:ROSCillator:SOURce EXT
// :SOURce1:FREQuency:CW 4000000000
// :SOURce1:FREQuency:OFFSet 1000000
// :SOURce1:AM1:STATe 1
// :OUTPut1:STATe 1
```

Usage: Query only

:SYSTem:STARup:COMPlEte?

Queries if the startup of the instrument is completed.

Return values:

<Complete> 1 | ON | 0 | OFF
*RST: 0

Example:

```
SYST:STAR:COMP?
Response: 1
the startup of the instrument is completed.
```

Usage: Query only

:SYSTem:DATE <Year>, <Month>, <Day>

Queries or sets the date for the instrument-internal calendar.

This is a password-protected function. Unlock the protection level 1 to access it.

Parameters:

<Year> integer

<Month> integer
Range: 1 to 12

<Day> integer
Range: 1 to 31

Example: See [Example"Configuring date and time"](#) on page 737.

Manual operation: See ["Date"](#) on page 792

:SYSTem:NTP:HOSTName <NTPName>

Sets the address of the NTP server. You can enter the IP address, or the hostname of the time server, or even set up an own vendor zone. See the Internet for more information on NTP.

Parameters:

<NTPName> string

Manual operation: See ["NTP Address"](#) on page 793

:SYSTem:NTP:STATe <UseNtpState>

Activates clock synchronization via NTP.

Parameters:

<UseNtpState> 1 | ON | 0 | OFF

*RST: n.a. (factory preset: 0)

Example: See [Example"Configuring date and time"](#) on page 737.

Manual operation: See ["NTP Address"](#) on page 793

:SYSTem:TIME <Hour>, <Minute>, <Second>

Queries or sets the time for the instrument-internal clock.

This is a password-protected function. Unlock the protection level 1 to access it.

Parameters:

<Hour> integer

Range: 0 to 23

<Minute> integer

Range: 0 to 59

<Second> integer

Range: 0 to 59

Example: See [Example"Configuring date and time"](#) on page 737.

Manual operation: See ["Time"](#) on page 792

:SYSTem:TIME:ZONE <TimeZone>

Sets the timezone. You can query the list of the available timezones with [:SYSTem:TIME:ZONE:CATalog?](#).

Parameters:

<TimeZone> string

Example: See [Example"Configuring date and time"](#) on page 737.

Manual operation: See ["Timezone"](#) on page 793

:SYSTem:TIME:ZONE:CATalog?

Querys the list of available timezones.

Return values:

<Catalog>

Example: See [Example"Configuring date and time"](#) on page 737.

Usage: Query only

Manual operation: See ["Timezone"](#) on page 793

:SYSTem:TIME:PROTOcol <TimeProtocol>

Sets the date and time of the operating system.

Parameters:

<TimeProtocol> OFF | NONE | 0 | NTP | ON | 1

NONE

Sets the date and time according to the selected timezone, see [:SYSTem:TIME:ZONE:CATalog?](#) on page 758 and [:SYSTem:TIME:ZONE](#) on page 757.

NTP

Sets the date and time derived from the network time protocol. To select the NTP time server, use the commands [:SYSTem:NTP:HOSTname](#) on page 757 and [:SYSTem:NTP:STATe](#) on page 757.

*RST: n.a. (factory preset: NONE)

Example: See [Example"Configuring date and time"](#) on page 737.

Manual operation: See ["Time Protocol"](#) on page 793

:SYSTem:UPTime?

Queries the up time of the operating system.

Return values:

<UpTime> "<ddd.hh:mm:ss>"

Example:

SYSTem:UPTime?

Response: "0.08:11:00"

Usage: Query only

:SYSTem:BIOS:VERSion?

Queries the BIOS version of the instrument.

Return values:

<Version> string

Example: SYST:BIOS:VERS?
 queries the BIOS version.
 Response: 123456

Usage: Query only

:SYSTem:VERsion?

Queries the SCPI version the instrument's command set complies with.

Return values:

<Version> string

Example: SYST:VERS
 queries the SCPI version.
 Response: "1996"
 The instrument complies with the SCPI version from 1996.

Usage: Query only

:SYSTem:OSYStem?

Queries the operating system of the instrument.

Return values:

<OperSystem> string

Example: SYSTem:OSYStem?
 Response: "Linux"

Usage: Query only

:SYSTem:MMEMory:PATH:USER?

Queries the user directory, that means the directory the R&S SMA100B stores user files on.

Return values:

<PathUser> string

Example: SYSTem:MMEMory:PATH:USER?
 Response: "/var/user/"

Usage: Query only

:SYSTem:DFPR?

Queries the device footprint of the instrument. The retrieved information is in machine-readable form suitable for automatic further processing.

Return values:

<DeviceFootprint> string
Information on the instrument type, device identification and details on the installed FW version, hardware and software options.

Example: :SYSTem:DFPR?

Usage: Query only

:SYSTem:REBoot

Reboots the instrument including the operating system.

Usage: Event

:SYSTem:REStart

Restarts the instrument without restarting the operating system.

Usage: Event

:SYSTem:SHUTdown

Shuts down the instrument.

Usage: Event

Manual operation: See ["Shut down"](#) on page 799

:SYSTem:WAIT <TimeMs>

Delays the execution of the subsequent remote command by the specified time.

This function is useful, for example to execute an SCPI sequence automatically but with a defined time delay between some commands.

See [Chapter 12.2.4, "How to assign actions to the \[★ \(User\)\] key"](#), on page 350.

Setting parameters:

<TimeMs> integer
Wait time in ms
Range: 0 to 10000
*RST: 0

Example: SYSTem:WAIT 10000
// Waits 10s before resetting the instrument.
*RST

Usage: Setting only

:SYSTem:FILEs:TEMPorary:DELeTe

Deletes the temporary files from the internal memory or, if installed, from the SD card slot.

Example: :SYSTem:FILEs:TEMPorary:DELeTe
 // temporary files are removed

Usage: Event

14.19 STATus subsystem

This system contains the commands for the status reporting system. See also [Chapter 13.4, "Status reporting system"](#), on page 388 for detailed information.

*RST on page 466 has no effect on the status registers.

Value ranges

- Queries return the current value of the respective register, which permits a check of the device status.
Return values: A decimal value in the range 0 to 32767 ($=2^{15}-1$)
- The configuration commands set the respective register thus determining which status changes of the R&S SMA100B cause the status registers to be changed.
Setting values: A decimal value in the range 0 to 32767 ($=2^{15}-1$)

:STATus:OPERation:CONDition?	761
:STATus:OPERation:ENABle	762
:STATus:OPERation[:EVENT]	762
:STATus:OPERation:NTRansition	762
:STATus:OPERation:PTRansition	762
:STATus:PRESet	763
:STATus:QUEStionable:CONDition	763
:STATus:QUEStionable:ENABle	763
:STATus:QUEStionable[:EVENT]	764
:STATus:QUEStionable:NTRansition	764
:STATus:QUEStionable:PTRansition	764
:STATus:QUEue[:NEXT]?	764

:STATus:OPERation:CONDition?

Queries the content of the CONDition part of the STATus:OPERation register.

This part contains information on the action currently being performed in the instrument. The content is not deleted after being read out because it indicates the current hardware status.

Return values:

<Condition> string

Example: :STATus:OPERation:CONDition?

Usage: Query only

:STATus:OPERation:ENABLE <Enable>

Sets the bits of the ENABLE part of the STATus:OPERation register. This setting determines which events of the Status-Event part are forwarded to the sum bit in the status byte. These events can be used for a service request.

Parameters:

<Enable> string

Example:

:STAT:OPER:ENAB 32767

all events are forwarded to the sum bit of the status byte.

:STATus:OPERation[:EVENT] <Event>

Queries the content of the EVENT part of the STATus:OPERation register. This part contains information on the actions performed in the instrument since the last readout. The content of the EVENT part is deleted after being read out.

Parameters:

<Event> string

Example:

:STAT:OPER:EVEN?

queries the STATus:OPERation:EVENT register.

:STATus:OPERation:NTRansition <Ntransition>

Sets the bits of the NTRansition part of the STATus:OPERation register. If a bit is set, a transition from 1 to 0 in the condition part causes an entry to be made in the EVENT part of the register. The disappearance of an event in the hardware is thus registered, for example the end of an adjustment.

Parameters:

<Ntransition> string

Example:

:STAT:OPER:NTR 0

a transition from 1 to 0 in the condition part of the Status:Operation register does not cause an entry to be made in the EVENT part.

:STATus:OPERation:PTRansition <Ptransition>

Sets the bits of the PTRansition part of the STATus:OPERation register. If a bit is set, a transition from 0 to 1 in the condition part causes an entry to be made in the EVENT part of the register. A new event in the hardware is thus registered, for example the start of an adjustment.

Parameters:

<Ptransition> string

Example: `:STAT:OPER:PTR 32767`
all transitions from 0 to 1 in the condition part of the Status:Operation register cause an entry to be made in the EVENT part.

:STATus:PRESet <Preset>

Resets the status registers. All PTRansition parts are set to FFFFh (32767), i.e. all transitions from 0 to 1 are detected. All NTRansition parts are set to 0, i.e. a transition from 1 to 0 in a CONDition bit is not detected. The ENABle parts of STATus:OPERation and STATus:QUEStionable are set to 0, i.e. all events in these registers are not passed on.

Parameters:

<Preset> string

Example: `STAT:PRES`
resets the status registers.

:STATus:QUEStionable:CONDition <Condition>

Queries the content of the CONDition part of the STATus:QUEStionable register. This part contains information on the action currently being performed in the instrument. The content is not deleted after being read out since it indicates the current hardware status.

Parameters:

<Condition> string

Example: `:STATus:QUEStionable:CONDition?`
queries the Status:Questionable:Condition register.

:STATus:QUEStionable:ENABle <Enable>

Sets the bits of the ENABle part of the STATus:QUEStionable register. The enable part determines which events of the STATus:EVENT part are enabled for the summary bit in the status byte. These events can be used for a service request.

If a bit in the ENABle part is 1, and the corresponding EVENT bit is true, a positive transition occurs in the summary bit. This transition is reported to the next higher level.

Parameters:

<Enable> string

Example: `STAT:QUES:ENAB 1`
Problems when performing an adjustment cause an entry to be made in the sum bit.

:STATus:QUESTionable[:EVENT] <Event>

Queries the content of the EVENT part of the STATus:QUESTionable register. This part contains information on the actions performed in the instrument since the last readout. The content of the EVENT part is deleted after being read out.

Parameters:

<Event> string

Example:

STAT:QUES:EVEN?

queries the Status:Questionable:Event register.

:STATus:QUESTionable:NTRansition <Ntransition>

Sets the bits of the NTRansition part of the STATus:QUESTionable register. If a bit is set, a transition from 1 to 0 in the condition part causes an entry to be made in the EVENT part of the register.

Parameters:

<Ntransition> string

Example:

STAT:QUES:NTR 0

a transition from 1 to 0 in the condition part of the STATus:QUESTionable register does not cause an entry to be made in the EVENT part

:STATus:QUESTionable:PTRansition <PTransition>

Sets the bits of the PTRansition part of the STATus:QUESTionable register. If a bit is set, a transition from 1 to 0 in the condition part causes an entry to be made in the EVENT part of the register.

Parameters:

<PTransition> string

Example:

STAT:QUES:PTR 32767

all transitions from 0 to 1 in the condition part of the STATus:QUESTionable register cause an entry to be made in the EVENT part

:STATus:QUEue[:NEXT]?

Queries the oldest entry in the error queue and then deletes it. Positive error numbers denote device-specific errors, and negative error numbers denote error messages defined by SCPI. If the error queue is empty, 0 ("No error") is returned.

The command is identical to :SYSTem:ERRor[:NEXT]? on page 741.

Return values:

<Next> string

Example: `:STATus:QUEue?`
 queries the oldest entry in the error queue.
 Response: 0, 'no error'
 no errors have occurred since the error queue was last read out

Usage: Query only

14.20 TEST subsystem

The **TEST** subsystem contains the commands for performing test routines directly at the hardware assemblies.

The selftest responses with a 0 if the test is performed successfully, otherwise a value other than 0 is returned. None of the commands of this system has a *RST value.

`:TEST<hw>:ALL:START`..... 765
`:TEST<hw>:ALL:RESult?`..... 765

`:TEST<hw>:ALL:START`

Usage: Event

Starts the selftest. Use the command `:TEST<hw>:ALL:RESult?` to query the result.

`:TEST<hw>:ALL:RESult?`

Queries the result of the performed selftest. Start the selftest with `:TEST<hw>:ALL:START`.

Return values:

<Result> 0 | 1 | RUNning | STOPped
 *RST: STOPped

Usage: Query only

14.21 TRIGger subsystem

The **TRIGger** system contains the commands for selecting the trigger source for the RF and LF sweep.

You can work with an internal or with an externally applied trigger signal. In this case, use the commands in the **SOURCE:INPut** subsystem to configure the signal.

The trigger system of the R&S SMA100B is a simplified implementation of the SCPI trigger system. The **TRIGger** system differs from the SCPI system as follows:

- No **INITiate** command; the instrument behaves as if **INITiate:CONTinuous ON** were set.
- Under **TRIGger** several sweep subsystems exist.

- The trigger source names correspond directly to the various settings of manual control. SCPI uses different names which are also accepted by the instrument. The SCPI names should be used if compatibility is an important consideration.

In addition to these commands, see more trigger-related commands in the modulation and RF signal subsystems.

Table 14-1: Cross-reference between the manual and remote control

R&S proprietary value name	SCPI conform value name	Parameter in manual control
AUTO	IMMediate	"Auto" mode
SINGle	BUS	"Single" mode.
EXTeRnal	EXTeRnal	"Ext Single" and "Ext Step" mode. Use command <code>LFO:SWEep:MODE</code> to select between the two sweep modes.
EAUTo	-	"Ext Start/Stop" mode.

:TRIGger<hw>:FSWeep:SOURce.....	766
:TRIGger<hw>:LFFSweep:SOURce.....	766
:TRIGger<hw>:PSWeep:SOURce.....	766
:TRIGger<hw>[:SWEep]:SOURce.....	766
:TRIGger<hw>:FPSWeep:SOURce.....	767
:TRIGger<hw>:FSWeep[:IMMediate].....	768
:TRIGger<hw>:LFFSweep:IMMediate.....	768
:TRIGger<hw>:PSWeep[:IMMediate].....	768
:TRIGger<hw>[:SWEep][:IMMediate].....	768
:TRIGger<hw>:LFFSweep.....	768

```
:TRIGger<hw>:FSWeep:SOURce <Source>
:TRIGger<hw>:LFFSweep:SOURce <Source>
:TRIGger<hw>:PSWeep:SOURce <Source>
:TRIGger<hw>[:SWEep]:SOURce <Source>
```

Selects the trigger source for the corresponding sweeps:

- FSWeep - RF frequency
- LFFSweep - LF frequency
- PSWeep - RF level
- SWEep - all sweeps

The source names of the parameters correspond to the values provided in manual control of the instrument. They differ from the SCPI-compliant names, but the instrument accepts both variants.

Use the SCPI name, if compatibility is an important issue. Find the corresponding SCPI-compliant commands in [Cross-reference between the manual and remote control](#).

Setting parameters:

<Source> AUTO | IMMediate | SINGle | BUS | EXTeRnal | EAUTo

AUTO [IMMediate]

Executes a sweep automatically.

In this free-running mode, the trigger condition is met continuously. I.e. when a sweep is completed, the next one starts immediately.

SINGle [BUS]

Executes one complete sweep cycle.

The following commands initiate a trigger event:

*TRG on page 467

```
[ :SOURce<hw> ] :SWEep:POWer:EXECute
[ :SOURce<hw> ] :SWEep [ :FREQuency ] :EXECute
:TRIGger<hw> [ :SWEep ] [ :IMMediate ], :TRIGger<hw>:
PSWep [ :IMMediate ] and :TRIGger<hw>:FSWep [ :
IMMediate ].
```

Set the sweep mode with the commands:

```
[ :SOURce<hw> ] :SWEep:POWer:MODEAUTO | STEP
[ :SOURce<hw> ] :SWEep [ :FREQuency ] :MODEAUTO | STEP
[ :SOURce<hw> ] :LFOutput:SWEep [ :FREQuency ] :MODE
AUTO | STEP
```

In step mode (STEP), the instrument executes only one step.

EXternal

An external signal triggers the sweep.

EAUTO

An external signal triggers the sweep. When one sweep is finished, the next sweep starts.

A second trigger event stops the sweep at the current frequency, a third trigger event starts the trigger at the start frequency, and so on.

*RST: AUTO

Example: See [Example "Setup an LF sweep"](#) on page 674

Usage: Setting only

:TRIGger<hw>:FPSWep:SOURce <FpTrigSource>

Selects the trigger source for the combined RF frequency / level sweep.

The parameter names correspond to the manual control. If needed, see [table Table 14-1](#) for selecting the trigger source with SCPI compliant parameter names.

Parameters:

<FpTrigSource> AUTO | IMMediate | SINGle | BUS | EXternal | EAUTO

AUTO|IMMediate

Executes the combined RF sweep automatically. In this free-running mode, the trigger condition is met continuously. I.e. as soon as a sweep is completed, the next one starts immediately.

SINGLE|BUS

Executes one complete sweep cycle triggered by the GPIB commands `[:SOURce<hw>] :SWEep:COMBined:EXECute` or `*TRG`. The mode has to be set to `[:SOURce<hw>] :SWEep:COMBined:MODE > AUTO`.

EXternal

An external signal triggers the sweep.

EAUTO

An external signal triggers the sweep. As soon as one sweep is finished, the next sweep starts. A second trigger event stops the sweep at the current frequency and level value pairs, a third trigger event starts the trigger at the start values, and so on.

*RST: No enum range assigned!

Manual operation: See "[Mode](#)" on page 186

```
:TRIGger<hw>:FSWeep[:IMMediate]
:TRIGger<hw>:LFFSweep:IMMediate
:TRIGger<hw>:PSWeep[:IMMediate]
:TRIGger<hw>[:SWEep][:IMMediate]
```

Performs a single sweep and immediately starts the activated, corresponding sweep:

- FSWeep - RF frequency
- PSWeep - RF level
- LFFSweep - LF frequency
- SWEep - all sweeps

Effective in the following configuration:

- TRIG:FSW|LFFS|PSW| [:SWE] :SOUR **SING**
- SOUR:SWE:FREQ|POW:MODE **AUTO** or SOUR:LFO:SWE: [FREQ:] MODE **AUTO**

Alternatively, you can use the `IMMediate` command instead of the respective `SWEep: [FREQ:] | POW:EXECute` command.

Example: TRIG
Starts all active sweeps.

Usage: Event

Manual operation: See "[Execute Single Sweep](#)" on page 190

```
:TRIGger<hw>:LFFSweep
```

Executes an LF frequency sweep in the following configuration:

- TRIG:LFFS:SOUR **SING**
- LFO:SWE:MODE **AUTO**

Example:

LFO:SWE:MODE AUTO
TRIG:LFFS:SOUR SING
TRIG:LFFSweep

Usage:

Event

14.22 UNIT subsystem

The UNIT subsystem is used to set default units for parameters if no unit is indicated in a command. These settings are valid for the entire instrument.

Example: Setting default units for remote control

UNIT:POW V
UNIT:ANGL DEG

Sets V (volts) as unit of all power parameters, DEG (degrees) for the phase modulation angle and KMH for the speed.

:UNIT:ANGLE.....	769
:UNIT:POWer.....	769

:UNIT:ANGLE <Angle>

Sets the default unit for phase modulation angle. The command affects no other parameters, such as RF phase, or the manual control or display.

Parameters:

<Angle>

DEGree | DEGRee | RADian

*RST: RADian

:UNIT:POWer <Power>

Sets the default unit for all power parameters. This setting affects the GUI, as well as all remote control commands that determine power values.

Parameters:

<Power>

V | DBUV | DBM

*RST: DBM

15 Troubleshooting and notifications

Handling R&S SMA100B start-up issues

If the product does not start, a blown fuse in the power supply can be the cause. Contact the Rohde & Schwarz customer service to confirm the fault symptoms. If the power supply has a blown fuse, you must return the product to the Rohde & Schwarz customer service to have the power supply replaced. Follow the instructions from the Rohde & Schwarz customer service.

If you need to transport or ship the instrument, see [Chapter 16, "Transporting"](#), on page 784.

Understanding R&S SMA100B notifications

The R&S SMA100B distinguishes between various notifications caused by events or functions. It displays a notification in the "Info" line on the screen temporarily, and saves all notifications in a history list. In addition, an event initiates an entry in the event/error queue of the status reporting system.

See:

- [Chapter 13.4, "Status reporting system"](#), on page 388
- [Chapter 15.4, "Querying notifications"](#), on page 773

15.1 Notifications

Notifications inform about operation states of the instrument, and point out deviations, deficiencies or imperfection of functions that initiate an event in the instrument. The instrument distinguishes the notifications according to the significance of the events by different icons.



Some events require that you eliminate the deviation to make sure that the instrument operates correctly.

To access the notifications and history list dialog, see [Chapter 15.4, "Querying notifications"](#), on page 773. In remote control mode, you can query the notifications using the command `:SYSTem:ERRor:ALL?` on page 739.

15.1.1 Volatile notifications

Volatile notifications report automatic settings in the instrument (e.g. switching off incompatible types of modulation) or on entries that are not accepted by the instrument (e.g. range violations).

Volatile notifications do not normally demand user actions and disappear automatically after a short period of time. They are saved in the history list, however.

Remote command:

```
:SYSTem:ERRor:ALL? or  
:SYSTem:ERRor:CODE[:NEXT]?
```

15.1.2 Permanent notifications

Permanent notifications are displayed if an error occurs that impairs further instrument operation, e.g. a hardware fault. The error signaled by a permanent notification must be eliminated before correct instrument operation can be continued.

The message is displayed until the error is eliminated. It covers the status display in the info line. After error elimination, the message automatically disappears and is also recorded in the history.

Remote command:

```
:SYSTem:ERRor:STATic?
```

15.2 SCPI notifications


The SCPI notifications are similar for all SCPI instruments. Detailed information and an overview of all notifications as defined in SCPI standard can be found in the corresponding documentation.

SCPI notifications have negative codes (numbers). The error text being entered into the error/event queue or being displayed is printed in bold face on the left together with the error code. Below the error text, there is an explanation to the respective error.

15.3 Device-specific notifications

Start-up error

If device-specific notifications occur during operation, the R&S SMA100B issues corresponding error messages, as listed under [Errors during operation](#). However, problems can also occur during start-up.



If your instrument prompts this notification when starting up, some information during initialization is missing. This error can occur when the power supply was interrupted during the last boot-up, e.g. due to power failure.

Remedy

- ▶ Select "Reset this error".
 - If the operating system and the firmware boot successfully, the functionality is restored.
 - If the notification reappears, a hardware error has occurred.
- We recommend that you contact the Rohde & Schwarz customer support (<https://www.rohde-schwarz.com/support>), or ship your R&S SMA100B directly to the service center experts for troubleshooting (<http://www.services.rohdeschwarz.com>).

Errors during operation

The following table contains all error messages specific for the instrument in alphabetical order and an explanation of the error situation. The positive error codes mark the errors specific to the instrument.

The device-specific error messages set bit 3 in the ESR register.



The index provides a list of the error messages sorted according to their error codes.

Error code	Error	Description	Remedy
50	Extern reference out of range or disconnected	External reference is selected but no external signal is applied or the signal is out of range.	<ul style="list-style-type: none"> • Check the selected reference signal source (internal or external) in the "Setup > Reference Oscillator" dialog. • Change setting to 'internal' if no appropriate external source is available.
140	This modulation forces other modulations off	A modulation has been switched on which cannot be used at the same time as an already active modulation. The previous modulation has been switched off.	
180	Adjustment failed	Adjustment could not be executed.	Generate the adjustment data and load it into the device
182	Adjustment data missing	Adjustment data is missing.	Generate the adjustment data and load it into the device
183	Adjustment data invalid	Adjustment data is invalid and must be restored.	Generate the adjustment data and load it into the device
200	Cannot access hardware	The data transmission to a module was unsuccessful.	The module is not installed, not properly installed or missing.
201	Hardware revision out of date	A later version of certain parts of the instrument is necessary to execute the function selected.	The driver does not support the installed version of a module.
202	Cannot access the EEPROM	An error occurs when writing or reading a EEPROM.	The EEPROM is possibly defect. Replace it.
203	Invalid EEPROM data	Reading a EEPROM is possible, however the data are inconsistent.	

Error code	Error	Description	Remedy
204	Driver initialization failed	Initialization of a driver fails when booting the instrument firmware.	The driver is not compatible with the hardware or software configuration of the instrument.
241	No current list	There is no list selected. To execute the required operation, a list has to be selected in the related dialog. If no list is available, a new list must be created.	
242	Unknown list type specified	The list type selected is not valid for the required operation.	Check the selected list type.
460	Cannot open the file	The selected file cannot be opened.	Check the path and file name.
461	Cannot write file	The file cannot be written.	Check if the file is read-only.
462	Cannot read file	The file cannot be read.	Check if the file contents are compatible with the file type.
463	Filename missing	The required operation cannot be executed because the file name is not specified.	Enter file name when creating list.
464	Invalid filename extension	The file extension is not valid for the required operation.	Check the file extension.
465	File contains invalid data	The selected file contains data that is not valid for the file type. The file extension determines the data that is valid for this file type. If the file extension is changed, the lists are no longer recognized and the data is therefore invalid.	Check the file extension.

15.4 Querying notifications


The R&S SMA100B monitors the functions performed and automatically detects irregularities. The instrument displays corresponding notifications in the "Info" line and collects all notifications in a history with a detailed description.

Find details to the system notifications in [Chapter 15, "Troubleshooting and notifications"](#), on page 770.

To display information on static notifications and history

1. In the taskbar, select the "Info" icon.
2. For some notifications, the information line appears briefly on the home screen.


Selecting the info line also opens the dialog.



- The "Static Notifications" dialog lists the recently monitored notifications chronologically and displays additional information on the highlighted message.
- The "History" dialog lists the accumulated messages with a short description. Volatile notifications are reported once. If identical errors occur subsequently, they are not reported repeatedly. In the "Info" line, identical errors are displayed repeatedly only if the original error has already disappeared from the display. If queried by SCPI command, identical errors are only reported if the original error has already been retrieved from (and hence not any more present in) the error queue.



Indication and handling of permanent notifications

If any critical error occurs, the R&S SMA100B automatically shows the  icon in the taskbar. Select the icon to obtain information on the error and the number of occurrences.

The icon is assigned to permanent notifications. The notification and icon are displayed until the error is eliminated.

Static Notifications/History

Toggles between "Static Notifications" and the "History" tab in the info dialog.

Remote command:

`:SYSTem:ERRor[:NEXT]?` on page 741

Each time a `SYST:ERR:NEXT?` query is sent, the eldest entry in the error queue is returned and at the same time cleared in the list.

`:SYSTem:ERRor:STATic?` on page 742

Queries the list of all errors.

Clear History

Clears all messages in the "History" tab.

Remote command:

[:SYSTem:ERRor:ALL?](#) on page 739

Each time a `SYST:ERR:ALL?` query is sent, the error queue is returned and at the same time cleared.

[:SYSTem:ERRor:HISTory:CLEar](#) on page 741

Clears the messages in the "History" view.

15.5 Resolving network connection failures

Several issues may cause failures in the network connection to the instrument. This section lists the most likely reasons and the recommended solutions.

Common reasons for network connection failures

- Network connecting cables and cable connectors of poor quality
- Incompatibility between the network interface of the R&S SMA100B and certain switches or routers available on the market
- An invalid IP address assigned to the instrument

Possible solutions to network connection failures

1. **NOTICE!** Risk of network failure. Connecting to the network can cause network failure. Errors can affect the entire network.

Consult your network administrator before performing the following tasks:

- Connecting the instrument to the network
- Configuring the network
- Changing IP addresses

2. Try out the following to resolve network connection failures:

- Check the network infrastructure. Exchange connecting cables, if obvious damage is visible.
See also ["Cable selection and electromagnetic interference \(EMI\)"](#) on page 26.
- Observe the link status LED on the R&S SMA100B or the connected network device. The link status LED is located next to the LAN connector.
If a link failure is detected, connect the instrument to a different device port or to a different network device.
- Check whether the LAN interface and the required LAN services are enabled.
See [Chapter 12.4.3, "Configuring LAN services"](#), on page 367.
- If the IP address is set manually (no DHCP) or obtained with the Zeroconf (Avahi) protocol:
 - Check whether the IP address of the instrument is within the network's address range.
 - Check whether the IP address is valid.

See also ["IP Address"](#) on page 400.

15.6 Measuring USB cable quality

To check the quality of the USB cable, see the service manual of the R&S SMA100B.

15.7 Requesting instrument configuration and specifications

The R&S SMA100B is equipped with various hardware and software components. To get an overview of what your instrument is equipped with, you can request the assemblies, hardware and software options, and the firmware version. The components are structured according to the hardware configuration, software options, including the license management, and externally used Rohde & Schwarz equipment, like R&S NRP power sensors.



Software options purchased at a later stage can be activated with a keycode. The activation code is supplied with the software option. How to install options is described in chapter 4 of the R&S SMA100B service manual.

The installation of hardware options purchased at a later stage is also described in chapter 4 of the service manual. Most of the hardware options have to be installed at an authorized Rohde & Schwarz service center.

15.7.1 Hardware configuration settings

Access:

- Select "System Config > Setup > Instrument Assembly > Hardware Config".

General RF Assembly Counter				
Assembly	Part Number	Serial Number	Revision	Slot
SMA100B	1419.8888k02	0		
FRONT_AF	1419.9690.02	100000	01.00	PCI-E slot
PSU300	2118.2067.02	100000	01.00	
IFB.BV	1423.5009.02	100000	01.00	
MB2_AF	1420.1360.02	100000	01.00	
SMAF_COM			01.00	
ADAP_CPU_AF	1420.1960.02	100000	01.00	
DCDC2_AF	1420.1860.02	100000	01.00	
IPM21	1206.3122.02	100000	01.00	PCI-E slot
BIOS				

The "Hardware Config" dialog lists all installed assemblies and externally connected instruments with information on their part and serial numbers, and revision states. The BIOS version is also listed; firmware updates do not update the BIOS version.

The dialog is divided in tabs, according to the hardware components of the signal domains. The "Counter" tab provides information on the operation time and number of times the instrument was powered on.

The remote commands required to query the hardware configuration are described in [Chapter 14.8, "DIAGnostic subsystem"](#), on page 488.

Assembly

The tables in the tabs show characteristics of the installed assemblies.

"Assembly"	Assembly designation.
"Part Number"	Part number of the assembly.
"Serial Number"	Serial number of the assembly.
"Revision"	Revision state of the assembly.
"Slot"	Indicates whether the assembly is connected to the serial bus or PCI bus.

Remote command:

[:DIAGnostic<hw>:BGInfo?](#) on page 489

Counter

Displays information on the operation times of the R&S SMA100B.

Operation Time / h ← Counter

Displays the operation time in hours so far.

Remote command:

[:DIAGnostic:INFO:OTIME?](#) on page 490

Power On Count ← Counter

Displays the number the instrument has been turned on.

Remote command:

[:DIAGnostic:INFO:POCount?](#) on page 490

Last Factory Calibration ← Counter

Displays the date of the last factory calibration.

Remote command:

[:CALibration:DATA:FACTory:DATE?](#) on page 481

15.7.2 Versions/options settings

Access:

- Select "System Config > Setup > Instrument Assembly > Versions / Options".

Firmware	Hardware Options	Software Options	Versions	Conan Packages
Package	Version			
FW	5.00.113			
Service Pack	not installed			
BIOS Version	VirtualBox			
Downgrade Info				
Package	Version			
Factory Version	5.00.113			
Min. Version	4.30.005.26			
The Min. Version is the first version supporting all hardware modules installed in this instrument. Please read release notes carefully before downgrading, some software options and features may get lost.				
Show Open Source Acknowledgments	LucasFonts RSCorpid EULA			

The "Versions/Options" dialog shows the version of the installed instrument firmware, the hardware and software options, the data sheet and the software components of the firmware. The BIOS version is also listed; firmware updates do not update the BIOS version.

The remote commands required to query the hardware configuration are described in [Chapter 14.8, "DIAGnostic subsystem"](#), on page 488.

Firmware

Shows the firmware version and the version of the software platform.

Note: Your instrument is delivered with the latest firmware version available. You can download firmware updates and the "Release Notes" that describe the modifications and the firmware update procedure.

See www.rohde-schwarz.com/firmware/sma100b

Remote command:

n.a.

Downgrade Info

Shows downgrade information, like factory firmware version and minimum firmware version to that the instrument can be downgraded.

Remote command:

n.a.

Show Open Source Acknowledgments

Accesses the list of the used open-source software packages and the corresponding verbatim license texts.

LucasFonts RSCorpid EULA

Accesses copyright information on LucasFonts font type RSCorpid EULA.

Hardware Options/Software Options

The tables in the "Hardware" and "Software" tabs list the installed hardware and software options.

"Option" Short name of option

"Designation" Name of option

"Expiration Date"

For regular options, "Permanent" is indicated in this column.

Remote command:

*[OPT?](#) on page 465

*[IDN?](#) on page 464

Versions

The "Versions" tab shows the versions of the technical specification of the R&S SMA100B and of the software components that comprise the firmware.

"Package" Name of the component.

"Version" Current issue of the component.

E.g. the data sheet covers the technical data of the hardware components of the factory settings.

See also [Chapter 13.6.2.3, "Datasheet"](#), on page 426.

Remote command:

:[SYSTem:SPECification:VERSion:FACTory?](#) on page 755

15.7.3 How to query instrument configuration

To get information on the components and installed options of the R&S SMA100B, proceed as described in the following examples.

Checking the installed hardware options

To find out the installed options:

1. Select "System Config > Setup > Instrument Assembly > Versions/Options".

2. Select "Hardware Options".

Firmware	Hardware Options	Software Options	Versions	
Option	Designation			
SMAB-B28	Ramp Sweep			
SMAB-B29	Differential clock synthesizer			
SMAB-B86	Remote control GPIB USB			
SMAB-B92	Height Unit 2 HU			
SMAB-B106	Frequency range: 8 kHz to 6 GHz			

The dialog lists all hardware options that are installed on the R&S SMA100B.

Proceed the same way to get information for instance on the firmware, or the installed software options in the corresponding tab.

Checking the RF hardware assembly

To find out the installed RF hardware:

1. Select "System Config > Setup > Instrument Assembly > Hardware Config".
2. Select "RF Assembly".

General	RF Assembly	Counter			X
Assembly	Part Number	Serial Number	Revision	Slot	
RSYN1_AF	1420.0570.02	100000	01.00		
SMAF_REF			01.00		
MSYN6_AF	1420.0470.02	100000	01.00		
SMAF_MOD			01.00		
CSYN_AF	1420.0470.06	100000	01.00		
SMAF_MOD			01.00		
OPU6_AF	1420.0770.02	100000	01.00		
OPU6-CPLD			01.00		
			00.00		
ATT6HP_AF	1420.2050.02	100000	01.00		
ATT6HP-CPLD			01.00		
			00.00		

The dialog lists the RF hardware components that are installed on the R&S SMA100B.

Proceed the same way to get information for instance on general or baseband hardware modules, or on the operating times of the R&S SMA100B in the corresponding tab.

15.7.4 How to request the data sheet

You can access data sheet-related information via the LXI web browser, see [Chapter 13.6.2.3, "Datasheet"](#), on page 426.

15.8 Collecting information for technical support

If you encounter problems that you cannot solve yourself, contact your Rohde & Schwarz support center at www.rohde-schwarz.com/support. Our support center staff is optimally trained to assist you in solving problems.

The support center finds solutions more quickly and efficiently if you provide them with information on the instrument and an error description.


- The following dialog boxes in the "Setup > Instrument Assembly" menu provide useful information:
 - **Hardware Configuration:** hardware assemblies
 - **Software and Options:** the status of all software and hardware options installed on your instrument
- **System Messages:** displayed in the "Info" line and provide information on any errors that have occurred
- **Support file:** a special file (*.tar.gz file) with important support information that can be created automatically.
The support *.tar.gz file has a user-definable name and contains the following files and information:
 - SgErrors.txt: chronological record of errors
 - SystemRestorationSMAB.savrc1.txt: instrument settings at the last correct shutdown of the instrument
 - UndoHistSuppInfo.xml: list of the last user interactions
 - DeviceFootprint_<SerialNumber>_<Date>_<Time>.xml: service-related information on the instrument's configuration.
 - crashlog.txt, coredump: Postmortem debug info
 - Several files with information on the last performed adjustment and self-test.

See also the description of error messages [Chapter 15.1, "Notifications"](#), on page 770.

To collect error information in a support file

1. Connect a USB device to the R&S SMA100B.
2. Select "System Config > Setup > Maintenance > Create R&S Support Information".
3. In the "Create R&S Support Information" dialog, navigate to the /usb directory.

Enter the support filename, for example `RSSupport_DeviceInfo`.



The error information and further required data are collected automatically.

The support file `RSSupport_DeviceInfo.tar.gz` is created and stored in the `/usb` directory.

Collect the error information and attach it to an email in which you describe the problem. Send the email to the customer support address as listed on the Internet (www.rohde-schwarz.com/support).

To remove sensitive data

- For information on how to handle or remove the sensitive data from your instrument, refer to the description "R&S SMA100B Instrument Security Procedures".

To pack and transport the instrument

- If you need to transport or ship the instrument, see [Chapter 16, "Transporting"](#), on page 784.

15.9 Contacting customer support

Technical support – where and when you need it

For quick, expert help with any Rohde & Schwarz product, contact our customer support center. A team of highly qualified engineers provides support and works with you to find a solution to your query on any aspect of the operation, programming or applications of Rohde & Schwarz products.

Contact information

Contact our customer support center at www.rohde-schwarz.com/support, or follow this QR code:



Figure 15-1: QR code to the Rohde & Schwarz support page

16 Transporting

Lifting and carrying

See:

- ["Lifting and carrying the product"](#) on page 16
- [Chapter 3.1.1, "Lifting and carrying"](#), on page 23

Packing

Use the original packaging material. It consists of antistatic wrap for electrostatic protection and packing material designed for the product.

If you do not have the original packaging, use similar materials that provide the same level of protection. You can also contact your local Rohde & Schwarz service center for advice.

Securing

When moving the R&S SMA100B in a vehicle or using transporting equipment, make sure that the R&S SMA100B is properly secured. Only use items intended for securing objects.

Transport altitude

The maximum transport altitude without pressure compensation is specified in the data sheet.

17 Maintenance, storage and disposal

The product does not require regular maintenance. It only requires occasional cleaning. It is however advisable to check the nominal data from time to time.

17.1 Cleaning

How to clean the product is described in "[Cleaning the product](#)" on page 17.

Do not use any liquids for cleaning. Cleaning agents, solvents, acids and bases can damage the front panel labeling, plastic parts and display.

17.2 Storage

Protect the product against dust. Ensure that the environmental conditions, e.g. temperature range and climatic load, meet the values specified in the data sheet.

17.3 Performing maintenance tasks

The R&S SMA100B is accurate due to integrated adjustment procedures. Internal adjustments are integrated self-calibration routines, which you can execute directly on the instrument.

Self-calibration routines that require additional equipment are performed at an authorized Rohde & Schwarz service center. For description, see R&S SMA100B service manual.

When to start internal adjustments?

We recommend that you run internal adjustments in the following cases:

- Before starting any application, that requires a maximum of level accuracy
- When a long period of time has passed since the last adjustments
- If the ambient temperature of the instrument significantly differs from the one of the last adjustments

How to: See [Chapter 17.3.1.3, "How to use the internal adjustments"](#), on page 789.

17.3.1 Internal adjustments

Internal adjustments are integrated adjustment procedures, which you can execute directly on the instrument.

Minimum power rating required for internal adjustments

The following tables list the minimum power rating of external 50 Ω termination that is required to execute internal adjustments. The minimum power rating depends on the output power options, the instrument is equipped with.

Table 17-1: Standard (no option) or high output power (R&S SMAB-B35/-B37/-B39/-K31/-K33/)

Frequency option	R&S SMAB-B103/./-B120	R&S SMAB-B131/./-B167	R&S SMAB-B131/./-B167
Firmware version	not relevant	<4.60.112.29SP5	≥4.60.112.29SP5
Min. power rating	1 W (30 dBm)	1 W (30 dBm)	no termination required

Table 17-2: Ultra high output power (R&S SMAB-B32/-B34/-K36/-K38/-K40)

Frequency option	R&S SMAB-B103/./-B120	R&S SMAB-B131/./-B167	R&S SMAB-B131/./-B167
Firmware version	not relevant	<4.60.112.29SP5	≥4.60.112.29SP5
Min. power rating	2 W (33 dBm)	2 W (33 dBm)	no termination required

Table 17-3: Super ultra high output power (R&S SMAB-B36S)

Frequency option	not relevant		
Firmware version	not relevant		
Min. power rating	2 W (33 dBm)		

17.3.1.1 Internal adjustment settings

Access:

- Select "System Config > Setup > General > Internal Adjustments".



In this dialog, you can perform internal calibration routines, and get information on the last performed calibration.

The "Temperature Offset" indicates the deviation of the current temperature of the instrument, compared to the temperature of the last adjustment.

The remote commands required to define these settings are described in [Chapter 14.6, "CALibration subsystem"](#), on page 479.

How to: See [Chapter 17.3.1.3, "How to use the internal adjustments"](#), on page 789.

Settings

Adjust All

Performs all available internal calibration routines of the instrument.

How to: See [Chapter 17.3.1.3, "How to use the internal adjustments"](#), on page 789.

Remote command:

`:CALibration:ALL[:MEASure]?` on page 480

Last Full Adjustment

Displays the date of the last fully performed adjustment.

Remote command:

`:CALibration<hw>:ALL:DATE?` on page 480

Time

Displays the elapsed time since the last full adjustment.

Remote command:

`:CALibration<hw>:ALL:TIME?` on page 481

Temperature Offset

Displays the temperature difference, comparing the temperature of the last adjustment to the current instrument temperature.

A green checkmark indicates that the offset is within the permitted range. If the temperature deviates more than ± 5 K, the instrument indicates a warning icon.

Remote command:

`:CALibration<hw>:ALL:TEMP?` on page 481

Information

Displays information to the current adjustment state.

Remote command:

`:CALibration<hw>:ALL:INformation?` on page 481

Continue Adjustment on Error

Continues the calibration even though an error was detected. By default adjustments are aborted on error.

This function is password-protected. Unlock the protection level 1 to access it.


Remote command:

`:CALibration<hw>:CONTinueonerror` on page 482

17.3.1.2 Delayed adjustment settings

Access:

- ▶ Select "System Config > Setup > General > Delayed Adjustment".



In this dialog, you can set the internal adjustments to start automatically after the selected warm up time and to switch off the instrument after calibration.

The remote commands required to define these settings are described in [Chapter 14.6, "CALibration subsystem"](#), on page 479.

Settings

Adjust All Delayed	788
Warm Up Time	788
Shutdown After Adjustment	788

Adjust All Delayed

Performs all available internal calibration routines of the instrument.

How to: See [Starting the internal adjustments automatically](#).

Remote command:

[:CALibration:DElay\[:MEASure\]?](#) on page 483

Warm Up Time

Sets the time for warming up the instrument before the calibration starts automatically.

How to: See [Starting the internal adjustments automatically](#).

Remote command:

[:CALibration:DElay:MINutes](#) on page 482

Shutdown After Adjustment

Enables the automatic shutdown after internal adjustments.

How to: See [Starting the internal adjustments automatically](#).

Remote command:

[:CALibration:DElay:SHUTdown\[:STATe\]](#) on page 482


17.3.1.3 How to use the internal adjustments

Deciding whether to run internal adjustments

1. Select "System Config > Setup > Internal Adjustment".
2. Observe the status and color indication in the section "Since Last Full Adjustment".
Green: internal adjustments are not required.
Red: internal adjustments are required. Observe also the indication in the "Information" field.
3. We recommend that you run internal adjustments in the following cases:
 - Before starting any application, that requires a maximum of level accuracy
 - When a long period of time has passed since the last adjustments
 - If the ambient temperature of the instrument significantly differs from the one of the last adjustments
4. Proceed as described in ["Running internal adjustments"](#) on page 789.


Running internal adjustments

1. **NOTICE!** Adjustments can be invalid if performed when the instrument is not warmed-up.
Wait until the instrument has reached its operating temperature before you start the adjustment procedure.
The warm-up time is up to 30 minutes.
2. **NOTICE!** High power at the RF output applied during internal adjustment can destroy a connected DUT (device under test).
Disconnect the DUT.
3. Replace the DUT by a terminating resistor with adequate power rating.
The required power of the resistor varies depending on whether the instrument is equipped with a high-power option, see ["Minimum power rating required for internal adjustments"](#) on page 786.
4. Select "System Config > Setup > Internal Adjustment > Adjust All".
If a terminating resistor is required, a warning message prompts you to make sure that you have terminated the RF output.



5. Confirm with "Ok".

If the terminating resistor is missing, or you have not terminated the RF output with 50 Ω , a second warning message appears.



The adjustment process aborts.

If the internal adjustment has started, do not interrupt the process.

A progress indicator shows the status of the adjustment process. The extent of the adjustments depends on the installed options.

If any error occurs, the process aborts, and an error message appears in the "Info" line.

If there is an error:

- Select "Info".
Observe the error message.
- Continue the process.
See ["Continuing the adjustment process if an error appears"](#) on page 790.

Continuing the adjustment process if an error appears

Per default, if any error occurs during the adjustment process, the process aborts. An error message appears in the "Info" line.

If you prefer to finish the adjustments also if there is an error, proceed as follows:

1. Select "System Config > Setup > Security > Protection" and unlock the protection level 1.
See ["Protection Level/Password"](#) on page 362.
2. Select "System Config > Setup > Internal Adjustment > Configuration > Continue Adjustment on Error > On".
3. Proceed as described in ["Running internal adjustments"](#) on page 789.

Starting the internal adjustments automatically

The delayed adjustment function enables you, that the instrument executes the adjustments automatically. You can define the start by setting the warm-up time, and even cause the instrument to shut down after the adjustment process has finished. Using this function, you can execute adjustments without being on-site and start measurements directly when back.

1. Select "System Config > Setup > General > Internal Adjustment".
2. Select "Delayed Adjustment".
3. Set the "Warm Up Time", e.g., *40 min*.

The R&S SMA100B requires a warm-up time of at least 30 min.

4. Enable "Shut Down After Adjustment"
5. Select "Adjust All Delayed".

The process starts with warming up the instrument, indicating the progress in a status dialog. In this dialog, you can abort the process again, if necessary.

When the warm-up time has passed, the R&S SMA100B executes the internal adjustments and shuts down, when completed.

17.3.2 Date and time

The R&S SMA100B uses an internal real-time clock to determine the date and time. It adjusts the time and date to the timezone of your location automatically, by providing a selection list of continents and cities.

The instrument records the time whenever you create or modify files on your instrument or you use timed licenses. By default, the instrument is set to the UTC timezone, but you can select the timezone according to your location.

Moreover, the instrument supports NTP protocol for synchronizing all connected instruments and computer systems to minimize time delays in the network.

17.3.2.1 Date and time settings

Access:

- Select "System Config > Setup > Maintenance > Date / Time".

The "Date / Time" dialog contains the time and data settings of the operating system.

This function is password-protected. Unlock the protection level 1 to access it.

You can also set the time zone for your location, and select a time protocol controlled by a time server for synchronization.

The required remote commands are described in [Chapter 14.18, "SYSTem subsystem"](#), on page 735.

Settings:

Date	792
Time	792
Timezone	793
Time Protocol	793
NTP Address	793

Date

Displays the date set in the operating system in the format [yyyy.mm.dd].

Remote command:

:SYSTem:DATE on page 756

Time

Displays the time set in the operating system in the format [hh.mm.ss].

The time setting corresponds to the selected [Timezone](#).

Remote command:

:SYSTem:TIME on page 757

Timezone

Selects the timezone in the date and time settings of the operating system.

You can select the timezone according to the major cities on the respective continents.

Tip: By typing the first letter, you can quickly navigate through the lists to find the desired destination.

Remote command:

:SYSTem:TIME:ZONE on page 757

:SYSTem:TIME:ZONE:CATalog? on page 758

Time Protocol

Enables the instrument to refer to a network time protocol.

A network time protocol synchronizes the system clocks of all participating devices in a computer network (Ethernet). A time server in the network provides the time base for the connected devices that refer to this time to synchronize events.

You can select a high-precision time protocol to achieve high clock accuracy and thus reduce the impact of varying network delays.

"None" Refers to the selected timezone, see [Timezone](#).

"NTP" Uses the network time protocol (NTP).

Remote command:

:SYSTem:TIME:PROTOcol on page 758

NTP Address

Sets the IP address or host name of the NTP server.

When the server is detected and verified, the instrument enables the connection automatically.

Remote command:

:SYSTem:NTP:HOSTname on page 757

:SYSTem:NTP:STATe on page 757

17.3.2.2 How to set date and time**To select the timezone**

1. Press the [Setup] key.
2. Select "Maintenance > Date /Time > Timezone".
3. Select continent and city of your location.
Tip: By typing the first letter, you can quickly navigate through the lists to find the desired destination.
4. Close the dialogs.

The instrument adjusts the time according to the selected location.

To set the date and time**1. NOTICE!**

This function is password-protected. Unlock the protection level 1 to access it.

Since the date and time settings affect time-based options, changing the date and time can therefore lead to loss of access to the function of the options. We recommend that you only change the system time in urgent cases.

If the time is not displayed correctly, the internal CMOS battery can be discharged. To change the battery, contact your Rohde & Schwarz support center at www.rohde-schwarz.com/support.

Press the [Setup] key.

2. Select "Security > Protection".
3. Enable the "Protection Level 1".
The default password is 123456.
4. Select "Setup > Maintenance > Date / Time".
5. Adjust the settings.
6. Close the dialogs.

The instrument sets the new date and time.

17.3.3 Check front panel

Within this dialog, you can verify the functionality of the control keys.

How To: See [Chapter 17.3.3.2, "How to test the front panel"](#), on page 795

17.3.3.1 Check front panel settings

Access:

- Select "System Config > Setup > Maintenance > Check Front Panel".



Reflecting the front panel, the "Check Front Panel" dialog contains all functions to test the operating elements of the instrument.

17.3.3.2 How to test the front panel

See:

- ["Testing the key panel"](#) on page 795
- ["Testing the touchscreen"](#) on page 796
- ["Terminating the test"](#) on page 797
- ["Debugging"](#) on page 797

Testing the key panel

To perform the key panel test, you operate the keys at the front panel, and check the response of the instrument in the "Check Front Panel" dialog. To perform this test properly, check each key of the front panel. The test is only completed, when you have verified all keys.

During the test, the actual functions of the keys are disabled.

1. Press the [Setup] key.
2. Select "Maintenance > Check Front Panel"
The "Check Front Panel" dialog opens.
3. Press a key on the front panel.
Check if the corresponding key in the "Check Front Panel" dialog turns green.
4. Press the same key a second time.
Check that the key in the dialog turns red.


Note: Pressing the same key again has no further effect, except for the [Esc] key. Pressing this key a third time, terminates the test procedure.

- Continue with the next key on the front panel and repeat [step 3](#) to [step 5](#) until all keys are tested.

The test is completed, when each key is verified successfully, confirmed by a "Test passed" message.

Testing the touchscreen


- Press the [Setup] key.
- Select "Maintenance > Check Touch Panel"
The "Finger Paint" test window opens.




- Drag with your finger one or more lines, for example diagonally across the screen. The test traces the movements of your finger on the screen.

The following results are expected:

- If the lines are uninterrupted, the touchscreen works properly.



- If there are any gaps, the touch-sensitive functionality is damaged.



- To return to the "Check Front Panel" dialog, press [Esc].

Terminating the test

- ▶ Press the [Esc] key.
Exits the "Check Front Panel" dialog.


Debugging

1. If you detect a malfunction, for example, when you press the front panel key for the first time, and the color of the button in the dialog turns red (instead of green), the front panel key has probably stuck.
2. Contact the Rohde & Schwarz customer support, see [Chapter 15.8, "Collecting information for technical support"](#), on page 781.

17.3.4 FPGA/uC update settings

Access:

- ▶ Select "System Config > Setup > Maintenance > FPGA/μC Update".



This dialog enables you to check for internal assembly updates and perform updates.

Settings:

Check For Updates.....	798
Assembly.....	798
Install.....	798
Shut down.....	799
Update External Devices.....	799
L Check For Updates.....	799

Check For Updates

Check for updates of the FPGA/μC.
 Remote command:
 n.a.

Assembly

The table shows the installed assemblies and their states.
 "Assembly" Assembly designation.
 "State" Indicates the current state of installed assemblies.

Install

Install all available updates for the FPGA/μC.
 Remote command:
 n.a.

Shut down

For at least one assembly "State = Done" and no pending assemblies, shuts the instrument down to apply installed updates.

Remote command:

`:SYSTem:SHUTdown` on page 760

Update External Devices

This dialog shows the update options of external devices connected to the instrument.

Check For Updates ← Update External Devices

Check for updates of external devices.

Remote command:


n.a.

17.3.5 Delete temporary files

During signal processing, the R&S SMA100B creates and saves various temporary files in a predefined directory on its non-volatile memory. This predefined directory is a protected system directory you cannot access in the "File Manager", but you can delete all temporary files saved there.

To achieve more free disc space on the internal memory

1. Select "System Config > Setup > Maintenance > Delete Temporary Files".



2. Select "Delete Temporary Files".

Deletes the content of the predefined directory.



Another way to achieve more free disc space on the internal memory is to use the [Execute Factory Preset](#).

This function removes all temporary files, too, but also resets several parameters to their factory preset values.

Remote command:

`:SYSTem:FILEs:TEMPorary:DELeTe` on page 761

17.4 Disposal

Rohde & Schwarz is committed to making careful, ecologically sound use of natural resources and minimizing the environmental footprint of our products. Help us by disposing of waste in a way that causes minimum environmental impact.

Disposing electrical and electronic equipment

A product that is labeled as follows cannot be disposed of in normal household waste after it has come to the end of its service life. Even disposal via the municipal collection points for waste electrical and electronic equipment is not permitted.



Figure 17-1: Labeling in line with EU directive WEEE

Rohde & Schwarz has developed a disposal concept for the eco-friendly disposal or recycling of waste material. As a manufacturer, Rohde & Schwarz completely fulfills its obligation to take back and dispose of electrical and electronic waste. Contact your local service representative to dispose of the product.

Annex

A Reference information for remote control

A.1 Telnet program examples

The following program example shows a simple `TcpClient` class that is intended to explain on how to get started with programming of sockets.

The example sets up a socket communication to R&S SMA100B and opens a simple user interface, very similar to the telnet, which allows input of commands. To enable real automation, further development of the program is required.

TcpClient.h

```
#include <string>
//defines structs for socket handling
#include <netinet/in.h>
using namespace std;
typedef struct sockaddr_in SockAddrStruct;
typedef struct hostent      HostInfoStruct;
class TcpClient
{
public:
    TcpClient();
    ~TcpClient();
    void connectToServer( string &hostname, int port );
    void disconnect( );
    void transmit( string &txString );
    void receive( string &rxString );
    string getCurrentHostName( ) const;
    int    getCurrentPort( ) const;
private:
    string      currentHostName;
    int         currentPort;
    int         currentSocketDescr;
    SockAddrStruct  serverAddress;
    HostInfoStruct * currentHostInfo;
    bool        clientIsConnected;
    int         receiveBufferSize;
};
```

TcpClient.cpp

```
#include <string>
//defines structs for socket handling
#include <netinet/in.h>
```

```

using namespace std;
typedef struct sockaddr_in SockAddrStruct;
typedef struct hostent     HostInfoStruct;
class TcpClient
{
public:
    TcpClient();
    ~TcpClient();
    void connectToServer( string &hostname, int port );
    void disconnect( );
    void transmit( string &txString );
    void receive( string &rxString );
    string getCurrentHostName( ) const;
    int    getCurrentPort( ) const;
private:
    string      currentHostName;
    int         currentPort;
    int         currentSocketDescr;
    SockAddrStruct  serverAddress;
    HostInfoStruct * currentHostInfo;
    bool        clientIsConnected;
    int         receiveBufferSize;
};

#include <netdb.h>
#include <netinet/in.h>
#include <unistd.h>
#include "TcpClient.h"
TcpClient::TcpClient()
: currentHostName( "" )
, currentPort( 0 )
, currentSocketDescr( 0 )
, serverAddress ( )
, currentHostInfo( NULL )
, clientIsConnected( false )
, receiveBufferSize( 1024 )
{
}

TcpClient::~~TcpClient()
{
    currentHostInfo = NULL;
}

void TcpClient::connectToServer( string &hostname, int port )
{
    currentHostInfo = gethostbyname( hostname.c_str( ) );
    if( currentHostInfo == NULL )
    {
        currentHostName = "";
        currentPort      = 0;
    }
}

```

```

        currentHostInfo    = NULL;
        clientIsConnected = false;
        printf("error connecting host\n" );
    }
    currentHostName = hostname;
    currentPort     = port;
    currentSocketDescr = socket(AF_INET, SOCK_STREAM, 0);
    if( currentSocketDescr == 0 )
    {
        currentHostName    = "";
        currentPort        = 0;
        currentHostInfo    = NULL;
        clientIsConnected = false;
        printf("can't create socket\n" );
    }
    serverAddress.sin_family = currentHostInfo->h_addrtype;
    serverAddress.sin_port   = htons( currentPort );
    memcpy( (char *) &serverAddress.sin_addr.s_addr,
        currentHostInfo->h_addr_list[0], currentHostInfo->h_length );
    if( connect( currentSocketDescr, ( struct sockaddr *) &serverAddress,
        sizeof( serverAddress ) ) < 0 )
    {
        throw string("can't connect server\n" );
    }
    clientIsConnected = true;
}
void TcpClient::disconnect( )
{
    if( clientIsConnected )
    {
        close( currentSocketDescr );
    }
    currentSocketDescr = 0;
    currentHostName    = "";
    currentPort        = 0;
    currentHostInfo    = NULL;
    clientIsConnected = false;
}
void TcpClient::transmit( string &txString )
{
    if( !clientIsConnected )
    {
        throw string("connection must be established before any data can be sent\n");
    }
    char * transmitBuffer = new char[txString.length() +1];
    memcpy( transmitBuffer, txString.c_str(), txString.length() );
    transmitBuffer[txString.length()] = '\n'; //newline is needed!
    if( send( currentSocketDescr, transmitBuffer, txString.length() + 1, 0 ) < 0 )
    {
        throw string("can't transmit data\n");
    }
}

```

```

    }
    delete [] transmitBuffer;
}
void TcpClient::receive( string &rxString )
{
    if( !clientIsConnected )
    {
        throw string("connection must be established before any data can be received\n");
    }
    char * receiveBuffer = new char[receiveBufferSize];
    memset( receiveBuffer, 0, receiveBufferSize );
    bool receiving = true;
    while( receiving )
    {
        int receivedByteCount = recv( currentSocketDescr,
            receiveBuffer, receiveBufferSize, 0 );
        if( receivedByteCount < 0 )
        {
            throw string("error while receiving data\n");
        }
        rxString += string( receiveBuffer );
        receiving = ( receivedByteCount == receiveBufferSize );
    }
    delete [] receiveBuffer;
}
string TcpClient::getCurrentHostName( ) const
{
    return currentHostName;
}
int TcpClient::getCurrentPort( ) const
{
    return currentPort;
}

```

TelnetClient.cpp

```

#include <iostream>
#include "TcpClient.h"
void printUsage()
{
    cout<<"usage: EthernetRawCommand <server-ip> [scpi-command]"<<endl;
}
int main( int argc, char *argv[] )
{
    int errorCode          = 0; //no error
    bool useSingleCommand = false;
    string singleCommand   = "";
    string hostname        = "";
    int    port            = 5025;
    string input           = "";
}

```

```
TcpClient client;
switch( argc )
{
    case 3:
        useSingleCommand = true;
        singleCommand     = argv[2];
    case 2:
        hostname          = argv[1];
        break;
    default:
        printUsage();
        return(-1);
}
try
{
    client.connectToServer( hostname, port );
    bool terminate = false;
    while( !terminate )
    {
        char buffer[1024];
        if( useSingleCommand )
        {
            input = singleCommand; //send string
        }
        else
        {
            cin.getline( buffer, 1024 );
            input = buffer;
            if( input == "end" )
            {
                terminate = true;
            }
        }
        if( !terminate)
        {
            client.transmit( input ); //send string
            int qPos = input.find( "?", 0 );
            //receive string only when needed
            if( qPos > 0 )
            {
                string rcStr = "";
                client.receive( rcStr );
                cout << rcStr << endl;
            }
        }
        if( useSingleCommand )
        {
            terminate = true;
        }
    }
}
```

```

    }catch( const string errorString )
    {
        cout<<errorString<<endl;
    }
    client.disconnect( );
    return errorCode;
}

```

A.2 Hardware interfaces

This section covers hardware-related topics, like pin assignment of the IEC 625/IEEE 488 interface.

The remote control interfaces are described in details in [Chapter 13, "Network operation and remote control"](#), on page 378.

All other interfaces are described in [Chapter 3.2, "Instrument tour"](#), on page 32.

For more information, see data sheet.

A.2.1 GPIB-Bus interface

Option: R&S SMAB-B86.

Pin assignment




Figure A-1: Pin assignment of GPIB-bus (IEEE 488) interface

Bus lines

- Data bus with 8 lines D0 to D7:
The transmission is bit-parallel and byte-serial in the ASCII/ISO code. D0 is the least significant bit, D7 the most significant bit.
- Control bus with five lines:
IFC (Interface Clear): active LOW resets the interfaces of the instruments connected to the default setting.
ATN (Attention): active LOW signals the transmission of interface messages, inactive HIGH signals the transmission of device messages.
SRQ (Service Request): active LOW enables the connected device to send a service request to the controller.
REN (Remote Enable): active LOW permits switchover to remote control.
EOI (End or Identify): has two functions in connection with ATN:
 - ATN=HIGH active LOW marks the end of data transmission.
 - ATN=LOW active LOW triggers a parallel poll.
- Handshake bus with three lines:
DAV (Data Valid): active LOW signals a valid data byte on the data bus.
NRFD (Not Ready For Data): active LOW signals that one of the connected devices is not ready for data transfer.
NDAC (Not Data Accepted): active LOW signals that the instrument connected is accepting the data on the data bus.

Interface functions

Instruments which can be controlled via GPIB-bus interface can be equipped with different interface functions. [Table A-1](#) lists the interface functions for the R&S SMA100B.

Table A-1: GPIB-bus interface functions

Control character	Interface function
SH1	Handshake source function (source handshake), full capability
AH1	Handshake sink function (acceptor handshake), full capability
L4	Listener function, full capability, de-addressed by MTA.
T6	Talker function, full capability, ability to respond to serial poll, deaddressed by MLA
SR1	Service request function (Service Request), full capability
PP1	Parallel poll function, full capability
RL1	Remote/Local switch over function, full capability
DC1	Reset function (Device Clear), full capability
DT1	Trigger function (Device Trigger), full capability

B Extensions for user files

The [Table B-1](#) lists all available file extensions for user files. The currently available files on the instrument depend on the installed options.

Table B-1: List of the automatically assigned file extensions in the instrument

Function	List type	Contents	File suffix
Instrument State	Settings	Instrument settings	*.savrc1txt
User Menu	Settings	User-defined favorite settings	*.user_menu
License Key		License Key	*.xml
"User Correction"	List	User-defined level correction values	*.uco
"List Mode"	List	User-defined frequency/level value pairs	*.lsw
	Settings	Response file	*.txt
"Pulse Train"	Settings	Pulse train data	*.pulstrn
"NRP Settings"	Settings	R&S NRP Settings	*.nrp, *.rsu
SCPI command list	List	Export file containing list of SCPIs	*.iee
SCPI command script		SCPI script file formats: Plain SCPI, MATLAB, NICVI, Python3	*.txt, *.m, *.c, *.py
R&S Support Info Archive	Support File	Automatically collected support information	*.tar.gz
Tutorials	Tutorial files	Lists containing SCPIs and explanations	*.tut

C Unit shortcuts

When specifying units or quantities during data entry, the R&S SMA100B provides the following shortcuts for simplified input.

Shortcut	Designation	Context	Unit
a, A	ampere	Current	A
	atto-	Area, surface	am ²
c, C	centi-	Distance, length	cm
d, D	deci-	Distance, length	dm
		Level, power	dB, dBFS, dBm, dBu, dBW
	degree	Phase, polar/spherical coordinates	deg
e, E	exa-	Area, surface	em ²
f, F	femto-	Area, surface	fm ²
g, G	giga-	Area, surface	Gm ²
		Data rate, sample rate, symbol rate	Gbit/s, Gsample/s, Gsymbol/s, Gchip/s
		Frequency	GHz
		Impedance, resistance	GΩ
h, H	hertz	Frequency	Hz
k, K	kilo-	Area, surface	km ²
		Data rate, sample rate, symbol rate	kbit/s, ksample/s, ksymbol/s, kchip/s
		Distance, length	km
		Frequency	kHz
		Impedance, resistance	kΩ
		Velocity	km/h
m, M	milli-	Area, surface	mm ²
		Current	mA
		Distance, length	mm
		Electromagnetic force, level	mV
		Power	mW
		Time, period, etc.	ms
	mega-	Area, surface	Mm ²
		Data rate, sample rate, symbol rate	Mbit/s, Msample/s, Msym/s, Mchip/s
		Frequency	MHz
		Impedance, resistance	MΩ

Shortcut	Designation	Context	Unit
n, N	nano-	Area, surface Current Distance, length Electromagnetic force, level Power Time, period, etc.	nm ² nA nm nV nW ns
o, O	ohm	Impedance, resistance	Ω
p, P	peta-	Area, surface	pm ²
	percent	Level, ratio	%
	pico-	Area, surface Current Electromagnetic force, level Power Time, period, etc.	pm ² pA pV pW ps
r, R	radiant	Phase, polar/spherical coordinates	rad
s, S	second	Time, period, etc.	s
t, T	terra-	Area, surface Data rate, sample rate, symbol rate Frequency Impedance, resistance	Tm ² Tbit/s, Tsample/s, Tsym/s, Tchip/s THz TΩ
u, U	micro-	Current Distance, length Electromagnetic force, level Power Time, period, etc.	μA μm μV μW μs
v, V	volt	Level, voltage	V
w, W	watt	Level, power	W

D Morse code settings

The COM/ID tone is sent according to the selected code (see [Table D-1](#)). The length of the Morse code can be varied. For selected standard time scheme, the selected dot length determines the setting of all other length parameters of the Morse code (dash length, symbol space and letter space). For selected user time scheme, all length parameters of the code can be set independently. If no coding is entered, the COM/ID tone is sent uncoded (key down).



The following values are default values:

- A dot (.) has a tone duration of 100 ms
- A dash (-) has a tone duration of 300ms
- The time between two tones is 100ms
- The time between two letters is 300ms

After each word, a word space is entered. The word repetition rate is 7 words per minute. Since the word length can vary between 900 ms and 4500 ms, the word space between the words varies accordingly.

Example:

ID code = MUC

The word length =

$(300+100+300)+300+(100+100+100+100+300)+300+(300+100+100+100+300+100+100) = 3100 \text{ ms}$

Table D-1: Morse code

Letter	Morse code	Letter	Morse code
A	. -	N	- .
B	- . . .	O	- - -
C	- . . .	P	. - . .
D	- . .	Q	- - . -
E	.	R	. - .
F	S	. . .
G	- - .	T	-
H	U	. . -
I	. .	V	. . . -
J	. - - -	W	. - -
K	- . -	X	- . . -
L	. - . .	Y	- . - -
M	- -	Z	- - . .

Glossary: List of the often used terms and abbreviations

Symbols

1MA193: 1MA193_0e Application Note, "Aeronautical radio navigation measurement solutions"

A

Avahi: A licensed [Zeroconf](#) networking feature, including DNS service. The feature enables a device to self-configure an IP address and subnet mask automatically, when a [DHCP](#) server in the LAN is not available.

B

Base unit: This term describes a R&S SMA100B equipped with the option R&S SMAB-B103.

C

Clock: A mandatory internal or an external reference clock signal for generating the timing pulse in the instrument.

Complete file path: The complete file path specifies the root directory and all subdirectories that contain a file or folder.

Synonyms to this expression are "full file path" and "absolute file path".

See also [Chapter 14.5.2, "Accessing files in the default or in a specified directory"](#), on page 471.

Computer name: [Hostname](#)

D

daisy chain: A connection scheme in which instruments are connected together in sequence, i.e. an output of the first one is connected to an input of the second one, etc.

DHCP: Dynamic host configuration protocol

DNS: Domain name system server

E

e.g.: For example

External mass memory: External memory, connected to the instrument via USB connector (Type A female). It can hold stored files with user data.

See also [System drive](#) and [SD card](#)

F

File transfer: The transmission of files from or to the instrument by a remote client. The instrument supports the standard methods [FTP](#) and file sharing according to [SAMBA/SMB](#).

FTP: File transfer protocol

G

Glossary: List of the often used terms and abbreviations

GUI: Graphical user interface

H

HDD: Hard disk drive, see [System drive](#)

Hostname: An unambiguous indication of the instrument in a LAN that uses a [DNS](#) server.

The default hostname follows the syntax `SMAB-<serial number>`, e.g.

`SMA100B-102030`.

See [Serial number](#).

Synonym: [Computer name](#)

HUMS: Health and utilization monitoring system.

I

i.e.: That is

L

LF: Low frequency

LSB: Least significant bit

M

MIMO: Multiple input multiple output

MSB: Most significant bit

P

PC: Personal computer

Power: A term describing the signal level of the RF signal

product page: A designation of the R&S SMA100B product page <http://www.rohde-schwarz.com/product/SMA100B.html>

R

Remote access: [Remote operation](#)

Remote control: The operation of the R&S SMA100B by remote control commands or programs to perform automated tests.
The instrument is connected to a system controller via LAN/VXI-11, GPIB or USB using [VISA](#). The instrument is controlled directly or supported by instrument drivers.

Remote device: External device controls the R&S SMA100B in remote operation mode, see [Remote operation](#).
Synonyms: External controller, client device

Remote operation: Allows you to operate the R&S SMA100B from a remote device via VNC.
Both the R&S SMA100B and the remote device are connected in a LAN.
Synonym: Remote access

Removable memory: General term describing mass memory that can be unmounted from the instrument.
See also [SD card](#)

RF: Radio frequency

S

SAMBA/SMB: Server message protocol

SD card: Secure digital card is a type of removable memory storage, that can hold files with user data.
Support of this memory type is optional and requires option R&S SMAB-B85.
Throughout this description, the SD card is referred as a removable memory.
See also [System drive](#).

Serial number: Unique instrument identification, provided on the rear panel of the instrument and required to build the [Computer name](#).
The serial number are the last 6 digits in the string <stock no.>-<serial number>, e.g. SMA100B-102030

Smart device: A mobile, cordless device, such as a smartphone or tablet, capable of Internet browsing.
Synonyms: Smartphone, tablet

System drive: The system drive is a built-in internal memory that holds the operating system, the firmware, and the stored user data.
Throughout this description, the system drive is referred as an internal memory.
See also [SD card](#) and [Removable memory](#)

T

Trigger: Internally generated or externally supplied signal which starts signal generation at a particular point in time

Trigger event: A trigger event is caused by the received trigger signal or executed manual trigger.

U

UE: User equipment

USBTMC: (USB test & measurement class)

A protocol built on top of USB for communication with USB devices. Using [VISA](#) library, it supports service request, triggers, and other specific operations, similar to GPIB.

User directory: Describes the default file storage location for user data.

Depending on the installed options, the user directory is physically located on the [System drive](#) or on the [Removable memory](#)

In the file system, user directory is always indicated as `/var/user`

V

VISA: Virtual instrument software architecture

Z

Zeroconf: Zero-configuration, see [Avahi](#).

List of Commands

:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:STATe.....	516
:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:SUBTract.....	516
:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:XVAL.....	517
:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:YVAL.....	517
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:STATe.....	517
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:SUBTract.....	518
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:XVAL.....	518
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:YVAL.....	518
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:AVERAge?.....	519
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:FEED.....	519
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:MAXimum?.....	519
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:START.....	520
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:STATe.....	520
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:STOP.....	520
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:STATe.....	521
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:SUBTract.....	521
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:XVAL.....	521
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:YVAL.....	522
:CALibration:ALL[:MEASure]?.....	480
:CALibration:DATA:FACTory:DATE?.....	481
:CALibration:DELay:MINutes.....	482
:CALibration:DELay:SHUTdown[:STATe].....	482
:CALibration:DELay[:MEASure]?.....	483
:CALibration<hw>:ALL:DATE?.....	480
:CALibration<hw>:ALL:INformation?.....	481
:CALibration<hw>:ALL:TEMP?.....	481
:CALibration<hw>:ALL:TIME?.....	481
:CALibration<hw>:CONTinueonerror.....	482
:CSYNthesis:FREQuency.....	485
:CSYNthesis:FREQuency:STEP.....	488
:CSYNthesis:FREQuency:STEP:MODE.....	487
:CSYNthesis:OFFSet.....	486
:CSYNthesis:OFFSet:STATe.....	486
:CSYNthesis:OTYPE.....	485
:CSYNthesis:PHASe.....	486
:CSYNthesis:PHASe:REFerence.....	487
:CSYNthesis:POWer.....	485
:CSYNthesis:POWer:STEP:MODE.....	487
:CSYNthesis:POWer:STEP[:INCRement].....	487
:CSYNthesis:STATe.....	484
:CSYNthesis:VOLTagE.....	486
:DEvice:PRESet.....	468
:DIAGnostic:INFO:OTIME?.....	490
:DIAGnostic:INFO:POCount?.....	490
:DIAGnostic<hw>:BGInfo:CATalog?.....	489
:DIAGnostic<hw>:BGInfo?.....	489
:DIAGnostic<hw>:POINT:CATalog?.....	491

:DIAGnostic<hw>[:MEASure]:POINT?	491
:DISPlay:ANNotation:AMPLitude	501
:DISPlay:ANNotation:FREQuency	501
:DISPlay:ANNotation[:ALL]	502
:DISPlay:BRIGhtness	500
:DISPlay:BUtTon:BRIGhtness	501
:DISPlay:DIALog:CLOSe	503
:DISPlay:DIALog:CLOSe:ALL	503
:DISPlay:DIALog:ID?	502
:DISPlay:DIALog:OPEN	503
:DISPlay:PSAVe:HOLDoff	500
:DISPlay:PSAVe[:STATe]	500
:DISPlay:UPDate[:STATe]	501
:DISPlay[:WINDow][:POWer]:SWEep:BACKground:COLor	522
:DISPlay[:WINDow][:POWer]:SWEep:GRID:STATe	522
:FORMat:BORDER	504
:FORMat:SREGister	504
:FORMat[:DATA]	504
:HCOPy:DATA?	506
:HCOPy:DEViCe:LANGUage	506
:HCOPy:FILE[:NAME]	507
:HCOPy:FILE[:NAME]:AUTO:DIRectory	508
:HCOPy:FILE[:NAME]:AUTO:DIRectory:CLear	508
:HCOPy:FILE[:NAME]:AUTO:FILE?	508
:HCOPy:FILE[:NAME]:AUTO:STATe	509
:HCOPy:FILE[:NAME]:AUTO?	508
:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY:STATe	509
:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe	509
:HCOPy:FILE[:NAME]:AUTO[:FILE]:NUMBer?	509
:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix	510
:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe	510
:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe	509
:HCOPy:IMAGe:FORMat	506
:HCOPy:REGion	507
:HCOPy[:EXECute]	507
:INITiate<hw>[:POWer]:CONTinuous	523
:KBOard:LAYout	510
:MEMory:HFRee?	479
:MMEMory:CATalog:LENGth?	475
:MMEMory:CATalog?	474
:MMEMory:CDIRectory	475
:MMEMory:COpy	475
:MMEMory:DATA	476
:MMEMory:DCATalog:LENGth?	477
:MMEMory:DCATalog?	476
:MMEMory:DELeTe	477
:MMEMory:LOAD:STATe	477
:MMEMory:MDIRectory	478
:MMEMory:MOVE	478
:MMEMory:MSIS	478

:MMEMory:RDIRectory.....	478
:MMEMory:STORe:STATe.....	479
:OUTPut:ALL[:STATe].....	511
:OUTPut:FPRoportional:SCALe.....	513
:OUTPut:USER:MARKer.....	513
:OUTPut<hw>:AFIXed:RANGe:LOWer?.....	513
:OUTPut<hw>:AFIXed:RANGe:UPPer?.....	513
:OUTPut<hw>:AMODE.....	512
:OUTPut<hw>:FILTer:MODE.....	512
:OUTPut<hw>:IMPedance?.....	512
:OUTPut<hw>:PROTection:CLear.....	514
:OUTPut<hw>:PROTection:TRIPped?.....	514
:OUTPut<hw>[:STATe].....	511
:OUTPut<hw>[:STATe]:PON.....	511
:READ<ch>[:POWer]?.....	523
:SENSe[:POWer]:SWEep:ABORt.....	534
:SENSe[:POWer]:SWEep:FREQuency:REFeRence:DATA:COpy.....	534
:SENSe[:POWer]:SWEep:FREQuency:REFeRence:DATA:POINts?.....	535
:SENSe[:POWer]:SWEep:FREQuency:REFeRence:DATA:XVALues.....	535
:SENSe[:POWer]:SWEep:FREQuency:REFeRence:DATA:YVALues.....	535
:SENSe[:POWer]:SWEep:FREQuency:RMODE.....	535
:SENSe[:POWer]:SWEep:FREQuency:SPACing[:MODE].....	536
:SENSe[:POWer]:SWEep:FREQuency:STARt.....	536
:SENSe[:POWer]:SWEep:FREQuency:STEPs.....	536
:SENSe[:POWer]:SWEep:FREQuency:STOP.....	536
:SENSe[:POWer]:SWEep:FREQuency:TIMing[:MODE].....	537
:SENSe[:POWer]:SWEep:FREQuency:YSCale:AUTO.....	537
:SENSe[:POWer]:SWEep:FREQuency:YSCale:AUTO:RESet.....	538
:SENSe[:POWer]:SWEep:FREQuency:YSCale:MAXimum.....	538
:SENSe[:POWer]:SWEep:FREQuency:YSCale:MINimum.....	538
:SENSe[:POWer]:SWEep:HCOPy:DATA?.....	538
:SENSe[:POWer]:SWEep:HCOPy:DEVIce.....	539
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage.....	540
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:DPOint.....	540
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:HEADer.....	540
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:ORientation.....	541
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:COLumn]:SEPArator.....	541
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:SIZE.....	541
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME].....	542
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory.....	542
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory:CLear.....	542
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:FILE?.....	543
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:STATe.....	543
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY:STATe.....	544
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY?.....	544
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe.....	544
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH?.....	544
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:NUMBer?.....	545
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix.....	545
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe.....	545

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe.....	546
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR?.....	546
:SENSe[:POWer]:SWEep:HCOPy[:EXECute].....	546
:SENSe[:POWer]:SWEep:INITiate.....	546
:SENSe[:POWer]:SWEep:MODE.....	547
:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:COpy.....	547
:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:POINts?.....	547
:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:XVALues.....	547
:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:YVALues.....	548
:SENSe[:POWer]:SWEep:POWer:RMODE.....	548
:SENSe[:POWer]:SWEep:POWer:SPACing[:MODE].....	548
:SENSe[:POWer]:SWEep:POWer:STARt.....	548
:SENSe[:POWer]:SWEep:POWer:STEPs.....	549
:SENSe[:POWer]:SWEep:POWer:STOP.....	549
:SENSe[:POWer]:SWEep:POWer:TIMing[:MODE].....	549
:SENSe[:POWer]:SWEep:POWer:YSCale:AUTO.....	550
:SENSe[:POWer]:SWEep:POWer:YSCale:AUTO:RESet.....	550
:SENSe[:POWer]:SWEep:POWer:YSCale:MAXimum.....	551
:SENSe[:POWer]:SWEep:POWer:YSCale:MINimum.....	551
:SENSe[:POWer]:SWEep:RMODE.....	551
:SENSe[:POWer]:SWEep:TIME:AVERAge[:COUNT].....	551
:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:COpy.....	552
:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:POINts?.....	552
:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:XVALues.....	552
:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:YVALues.....	553
:SENSe[:POWer]:SWEep:TIME:RMODE.....	553
:SENSe[:POWer]:SWEep:TIME:SPACing[:MODE].....	553
:SENSe[:POWer]:SWEep:TIME:STARt.....	553
:SENSe[:POWer]:SWEep:TIME:STEPs.....	554
:SENSe[:POWer]:SWEep:TIME:STOP.....	554
:SENSe[:POWer]:SWEep:TIME:TEVents.....	554
:SENSe[:POWer]:SWEep:TIME:YSCale:AUTO.....	555
:SENSe[:POWer]:SWEep:TIME:YSCale:AUTO:RESet.....	555
:SENSe[:POWer]:SWEep:TIME:YSCale:MAXimum.....	556
:SENSe[:POWer]:SWEep:TIME:YSCale:MINimum.....	556
:SENSe<ch>[:POWer].....	574
:SENSe<ch>[:POWer]:APERTure:DEFault:STATe.....	575
:SENSe<ch>[:POWer]:APERTure:TIME.....	575
:SENSe<ch>[:POWer]:CORRection:SPDevice:LIST?.....	576
:SENSe<ch>[:POWer]:CORRection:SPDevice:SElect.....	576
:SENSe<ch>[:POWer]:CORRection:SPDevice:STATe.....	576
:SENSe<ch>[:POWer]:DISPlay:PERManent:PRiority.....	576
:SENSe<ch>[:POWer]:DISPlay:PERManent:STATe.....	576
:SENSe<ch>[:POWer]:FILTer:LENGth:AUTO?.....	577
:SENSe<ch>[:POWer]:FILTer:LENGth[:USER].....	577
:SENSe<ch>[:POWer]:FILTer:NSRatio.....	578
:SENSe<ch>[:POWer]:FILTer:NSRatio:MTIME.....	578
:SENSe<ch>[:POWer]:FILTer:SONCe.....	578
:SENSe<ch>[:POWer]:FILTer:TYPE.....	579
:SENSe<ch>[:POWer]:FREQuency.....	579

:SENSe<ch>[:POWER]:LOGGing:STATe.....	580
:SENSe<ch>[:POWER]:OFFSet.....	580
:SENSe<ch>[:POWER]:OFFSet:STATe.....	580
:SENSe<ch>[:POWER]:SNUMber?.....	580
:SENSe<ch>[:POWER]:SOURce.....	581
:SENSe<ch>[:POWER]:STATus[:DEVice]?.....	581
:SENSe<ch>[:POWER]:SVERsion?.....	581
:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:OFFSet.....	526
:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:OFFSet:STATe.....	526
:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:SRANge:STARt.....	526
:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:SRANge:STOP.....	527
:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:SRANge[:STATe].....	527
:SENSe<ch>[:POWER]:SWEep:POWER[:SENSor]:OFFSet.....	528
:SENSe<ch>[:POWER]:SWEep:POWER[:SENSor]:OFFSet:STATe.....	528
:SENSe<ch>[:POWER]:SWEep:POWER[:SENSor]:SFRequency.....	528
:SENSe<ch>[:POWER]:SWEep:POWER[:SENSor]:SFRequency:STATe.....	529
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:OFFSet.....	529
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:OFFSet:STATe.....	529
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:STATe.....	530
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:THReshold:BASE.....	530
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWER:HREFerence.....	530
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWER:LREFerence.....	531
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWER:REFerence.....	531
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:SFRequency.....	532
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:SFRequency:STATe.....	532
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:AUTO.....	532
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:DTIME.....	532
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:HYSTeresis.....	533
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:LEVel.....	533
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:SLOPe.....	533
:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:SOURce.....	534
:SENSe<ch>[:POWER]:TYPE?.....	582
:SENSe<ch>[:POWER]:ZERO.....	534
:SENSe<ch>[:POWER]:ZERO.....	582
:SLISt:CLEar:LAN.....	573
:SLISt:CLEar:USB.....	573
:SLISt:CLEar[:ALL].....	574
:SLISt:ELEMent<ch>:MAPPing.....	574
:SLISt:SCAN:LSENsor.....	572
:SLISt:SCAN:USENsor.....	573
:SLISt:SCAN[:STATe].....	572
:SLISt:SENSor:MAP.....	574
:SLISt[:LIST]?.....	572
:SOURce<hw>:PRESet.....	468
:STATus:OPERation:CONDition?.....	761
:STATus:OPERation:ENABle.....	762
:STATus:OPERation:NTRansition.....	762
:STATus:OPERation:PTRansition.....	762
:STATus:OPERation[:EVENT].....	762
:STATus:PRESet.....	763

:STATus:QUESTionable:CONDition.....	763
:STATus:QUESTionable:ENABle.....	763
:STATus:QUESTionable:NTRansition.....	764
:STATus:QUESTionable:PTRansition.....	764
:STATus:QUESTionable[:EVENT].....	764
:STATus:QUEue[:NEXT]?.....	764
:SWEep:TYPE.....	723
:SYSTem:BIOS:VERSion?.....	758
:SYSTem:COMMunicate:GPIB:LTERminator.....	746
:SYSTem:COMMunicate:GPIB:RESource?.....	746
:SYSTem:COMMunicate:GPIB[:SELF]:ADDReSS.....	746
:SYSTem:COMMunicate:HISLip:RESource?.....	747
:SYSTem:COMMunicate:NETWork:IPADdress.....	747
:SYSTem:COMMunicate:NETWork:IPADdress:MODE.....	747
:SYSTem:COMMunicate:NETWork:MACaddress.....	747
:SYSTem:COMMunicate:NETWork:RESource?.....	748
:SYSTem:COMMunicate:NETWork:REStart.....	748
:SYSTem:COMMunicate:NETWork:STATus?.....	748
:SYSTem:COMMunicate:NETWork[:COMMON]:DOMain.....	748
:SYSTem:COMMunicate:NETWork[:COMMON]:HOSTname.....	749
:SYSTem:COMMunicate:NETWork[:COMMON]:WORKgroup.....	749
:SYSTem:COMMunicate:NETWork[:IPADdress]:DNS.....	749
:SYSTem:COMMunicate:NETWork[:IPADdress]:GATeway.....	749
:SYSTem:COMMunicate:NETWork[:IPADdress]:SUBNet:MASK.....	750
:SYSTem:COMMunicate:SERial:BAUD.....	750
:SYSTem:COMMunicate:SERial:PARity.....	750
:SYSTem:COMMunicate:SERial:RESource?.....	750
:SYSTem:COMMunicate:SERial:SBITs.....	750
:SYSTem:COMMunicate:SOCKet:RESource?.....	751
:SYSTem:COMMunicate:USB:RESource?.....	751
:SYSTem:DATE.....	756
:SYSTem:DFPR?.....	759
:SYSTem:DLOCK.....	742
:SYSTem:ERRor:ALL?.....	739
:SYSTem:ERRor:CODE:ALL?.....	739
:SYSTem:ERRor:CODE[:NEXT]?.....	740
:SYSTem:ERRor:COUNT?.....	740
:SYSTem:ERRor:GNEXt?.....	741
:SYSTem:ERRor:HISTory:CLEar.....	741
:SYSTem:ERRor:STATic?.....	742
:SYSTem:ERRor[:NEXT]?.....	741
:SYSTem:FILEs:TEMPorary:DELeTe.....	761
:SYSTem:FPReset.....	469
:SYSTem:HELP:EXPort.....	751
:SYSTem:IDENtification.....	751
:SYSTem:IDENtification:PRESet.....	752
:SYSTem:INFormation:SCPI.....	753
:SYSTem:IRESPonse.....	752
:SYSTem:KLOCK.....	742
:SYSTem:LANGUage.....	753

:SYSTem:LOCK:OWNer?	743
:SYSTem:LOCK:RELease:ALL	744
:SYSTem:LOCK:REQuest[:EXCLusive]?	744
:SYSTem:MMEMory:PATH:USER?	759
:SYSTem:NINformation?	742
:SYSTem:NTP:HOSTname	757
:SYSTem:NTP:STATe	757
:SYSTem:ORESpOse	752
:SYSTem:OSYSem?	759
:SYSTem:PRESet	469
:SYSTem:PROTect<ch>[:STATe]	745
:SYSTem:RCL	744
:SYSTem:REBooT	760
:SYSTem:REStArT	760
:SYSTem:SAV	744
:SYSTem:SECurity:SANitize[:STATe]	753
:SYSTem:SECurity:SUPolicy	753
:SYSTem:SECurity:VOLMode[:STATe]	745
:SYSTem:SHUTdown	760
:SYSTem:SPECification:IDENtification:CATalog?	754
:SYSTem:SPECification:PARAmeter?	755
:SYSTem:SPECification:VERSion	754
:SYSTem:SPECification:VERSion:CATalog?	755
:SYSTem:SPECification:VERSion:FACTory?	755
:SYSTem:SPECification?	754
:SYSTem:SRData?	756
:SYSTem:STARtup:COMPLetE?	756
:SYSTem:TIME	757
:SYSTem:TIME:PROTocol	758
:SYSTem:TIME:ZONE	757
:SYSTem:TIME:ZONE:CATalog?	758
:SYSTem:ULOCK	743
:SYSTem:UPTime?	758
:SYSTem:VERSion?	759
:SYSTem:WAIT	760
:TEST<hw>:ALL:RESult?	765
:TEST<hw>:ALL:StArT	765
:TRACe[:POWer]:SWEep:MEASurement:FULLscreen:DISPlay:ANNotation[:STATe]	566
:TRACe[:POWer]:SWEep:MEASurement:GATE:DISPlay:ANNotation[:STATe]	567
:TRACe[:POWer]:SWEep:MEASurement:MARKer:DISPlay:ANNotation[:STATe]	567
:TRACe[:POWer]:SWEep:MEASurement:PULSe:DISPlay:ANNotation[:STATe]	567
:TRACe[:POWer]:SWEep:MEASurement:STANdard:DISPlay:ANNotation[:STATe]	568
:TRACe<ch>:FREQ:SWEep:SRC	558
:TRACe<ch>:POW:SWEep:SRC	558
:TRACe<ch>:TIME:SWEep:SRC	559
:TRACe<ch>[:POWer]:SWEep:COLor	559
:TRACe<ch>[:POWer]:SWEep:COPY	560
:TRACe<ch>[:POWer]:SWEep:DATA:POINts?	560
:TRACe<ch>[:POWer]:SWEep:DATA:XVALues?	560
:TRACe<ch>[:POWer]:SWEep:DATA:YSValue?	561

:TRACe<ch>[:POWer]:SWEep:DATA:YVALues?	561
:TRACe<ch>[:POWer]:SWEep:FEED	561
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERage:DISPlay:ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERage?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence:DISPlay:ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence:DISPlay:ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum:DISPlay:ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum:DISPlay:ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE:DISPlay:ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP:DISPlay:ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence:DISPlay:ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:ALL:DISPlay:ANNotation[:STATe]	564
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYClE:DISPlay:ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYClE?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation:DISPlay:ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod:DISPlay:ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEPARation:DISPlay:ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEPARation?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:STATe?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation:DISPlay: ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence:DISPlay: ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot:DISPlay: ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation:DISPlay: ANNotation[:STATe]	563
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence:DISPlay: ANNotation[:STATe]	564
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence?	562
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot:DISPlay: ANNotation[:STATe]	564
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot?	562
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:BASE?	564
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:HREFerence	565
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:LREFerence	565
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:REFerence	565

:TRACe<ch>[:POWer]:SWEep:STATe.....	566
:TRIGGer<hw>:FPSWeep:SOURce.....	767
:TRIGGer<hw>:FSWeep:SOURce.....	766
:TRIGGer<hw>:FSWeep[:IMMediate].....	768
:TRIGGer<hw>:LFFSweep.....	768
:TRIGGer<hw>:LFFSweep:IMMediate.....	768
:TRIGGer<hw>:LFFSweep:SOURce.....	766
:TRIGGer<hw>:PSWeep:SOURce.....	766
:TRIGGer<hw>:PSWeep[:IMMediate].....	768
:TRIGGer<hw>[:SWEep]:SOURce.....	766
:TRIGGer<hw>[:SWEep][:IMMediate].....	768
:UNIT:ANGLE.....	769
:UNIT:POWer.....	769
[:SOURce]:CORRection:CSET:CATalog?.....	661
[:SOURce]:CORRection:CSET:DELeTe.....	662
[:SOURce]:INPut:TRIGGer:SLOPe.....	674
[:SOURce]:LFOutput:OFFSet.....	680
[:SOURce]:LFOutput:VOLTage.....	680
[:SOURce]:LFOutput<ch>:BANDwidth?.....	677
[:SOURce]:LFOutput<ch>:FREQuency.....	677
[:SOURce]:LFOutput<ch>:INTErnal:VOLTage.....	679
[:SOURce]:LFOutput<ch>:SOURce.....	680
[:SOURce]:LFOutput<ch>:SOURce:PATH.....	680
[:SOURce]:LFOutput<ch>[:STATe].....	679
[:SOURce]:PM<ch>[:DEVIation].....	603
[:SOURce]:POWer:WIGNore.....	714
[:SOURce]:PULM[:INTErnal][:TRAIn]:TRIGGer:IMMediate.....	605
[:SOURce]:ROSCillator:EXTErnal:FREQuency.....	717
[:SOURce]:ROSCillator:EXTErnal:FREQuency:VARIABLE.....	717
[:SOURce]:ROSCillator:EXTErnal:MLRange?.....	718
[:SOURce]:ROSCillator:EXTErnal:NSBandwidth?.....	718
[:SOURce]:ROSCillator:EXTErnal:RFOff[:STATe].....	717
[:SOURce]:ROSCillator:EXTErnal:SBANDwidth.....	717
[:SOURce]:ROSCillator:INTErnal:TUNing:SLOPe.....	716
[:SOURce]:ROSCillator:INTErnal:TUNing[:STATe].....	716
[:SOURce]:ROSCillator:OUTPut:ALTErnate:FREQuency:MODE.....	719
[:SOURce]:ROSCillator:OUTPut:FREQuency:MODE.....	718
[:SOURce]:ROSCillator:PRESet.....	716
[:SOURce]:ROSCillator:SOURce.....	716
[:SOURce]:ROSCillator[:INTErnal]:ADJust:VALue.....	719
[:SOURce]:ROSCillator[:INTErnal]:ADJust[:STATe].....	720
[:SOURce<hw>]:ADF:COMid:CODE.....	622
[:SOURce<hw>]:ADF:COMid:DASH.....	622
[:SOURce<hw>]:ADF:COMid:DEPTTh.....	623
[:SOURce<hw>]:ADF:COMid:DOT.....	623
[:SOURce<hw>]:ADF:COMid:FREQuency.....	623
[:SOURce<hw>]:ADF:COMid:LETTEr.....	623
[:SOURce<hw>]:ADF:COMid:PERiod.....	624
[:SOURce<hw>]:ADF:COMid:SYMBol.....	624
[:SOURce<hw>]:ADF:COMid:TSCHEMA.....	624

[SOURce<hw>]:ADF:COMid[:STATe].....	625
[SOURce<hw>]:ADF:PRESet.....	620
[SOURce<hw>]:ADF:SETTing:CATalog.....	620
[SOURce<hw>]:ADF:SETTing:DELeTe.....	620
[SOURce<hw>]:ADF:SETTing:LOAD.....	620
[SOURce<hw>]:ADF:SETTing:STORe.....	621
[SOURce<hw>]:ADF:STATe.....	621
[SOURce<hw>]:AM:DEPTTh:SUM.....	588
[SOURce<hw>]:AM:DEVIation:MODE.....	589
[SOURce<hw>]:AM:MODE.....	588
[SOURce<hw>]:AM:RATio.....	589
[SOURce<hw>]:AM:TYPE.....	590
[SOURce<hw>]:AM<ch>:DEPTTh:EXPOntial.....	588
[SOURce<hw>]:AM<ch>:DEPTTh:LINear.....	587
[SOURce<hw>]:AM<ch>:SENSitivity:EXPOntial.....	589
[SOURce<hw>]:AM<ch>:SENSitivity[:LINear].....	590
[SOURce<hw>]:AM<ch>:SOURce.....	587
[SOURce<hw>]:AM<ch>:STATe.....	586
[SOURce<hw>]:AM<ch>[:DEPTTh].....	587
[SOURce<hw>]:CHIRp:BANDwidth.....	592
[SOURce<hw>]:CHIRp:COMPreSSion:RATio?.....	592
[SOURce<hw>]:CHIRp:DIRection.....	592
[SOURce<hw>]:CHIRp:PULSe:PERiod.....	592
[SOURce<hw>]:CHIRp:PULSe:WIDTh.....	593
[SOURce<hw>]:CHIRp:STATe.....	593
[SOURce<hw>]:CHIRp:TRIGger:IMMediate.....	593
[SOURce<hw>]:CHIRp:TRIGger:MODE.....	593
[SOURce<hw>]:COMBined:FREQuency:STARt.....	730
[SOURce<hw>]:COMBined:FREQuency:STOP.....	730
[SOURce<hw>]:COMBined:POWeR:STARt.....	730
[SOURce<hw>]:COMBined:POWeR:STOP.....	731
[SOURce<hw>]:CORRection:CSET:DATA:FREQuency.....	659
[SOURce<hw>]:CORRection:CSET:DATA:FREQuency:POINts?.....	660
[SOURce<hw>]:CORRection:CSET:DATA:POWeR.....	659
[SOURce<hw>]:CORRection:CSET:DATA:POWeR:POINts?.....	660
[SOURce<hw>]:CORRection:CSET:DATA[:SENSor<ch>][:POWeR]:SONCe.....	660
[SOURce<hw>]:CORRection:CSET:DATA[:SENSor<ch>][:POWeR]:SONCe.....	661
[SOURce<hw>]:CORRection:CSET[:SELeCt].....	660
[SOURce<hw>]:CORRection:DEXChange:AFILe:CATalog?.....	662
[SOURce<hw>]:CORRection:DEXChange:AFILe:EXTension.....	662
[SOURce<hw>]:CORRection:DEXChange:AFILe:SELeCt.....	663
[SOURce<hw>]:CORRection:DEXChange:AFILe:SEParator:COLUMN.....	663
[SOURce<hw>]:CORRection:DEXChange:AFILe:SEParator:DECimal.....	663
[SOURce<hw>]:CORRection:DEXChange:EXECute.....	663
[SOURce<hw>]:CORRection:DEXChange:MODE.....	664
[SOURce<hw>]:CORRection:DEXChange:SELeCt.....	664
[SOURce<hw>]:CORRection:VALue?.....	660
[SOURce<hw>]:CORRection:ZERoing:STATe.....	661
[SOURce<hw>]:CORRection[:STATe].....	661
[SOURce<hw>]:FM:DEVIation:MODE.....	597

[SOURce<hw>]:FM:DEVIation:SUM.....	597
[SOURce<hw>]:FM:MODE.....	598
[SOURce<hw>]:FM:RATio.....	598
[SOURce<hw>]:FM:SENSitivity?.....	598
[SOURce<hw>]:FM<ch>:SOURce.....	596
[SOURce<hw>]:FM<ch>:STATe.....	596
[SOURce<hw>]:FM<ch>[:DEVIation].....	596
[SOURce<hw>]:FREQuency:CENTer.....	669
[SOURce<hw>]:FREQuency:MANual.....	668
[SOURce<hw>]:FREQuency:MODE.....	665
[SOURce<hw>]:FREQuency:MULTiplier.....	668
[SOURce<hw>]:FREQuency:OFFSet.....	668
[SOURce<hw>]:FREQuency:PHASe:CONTInuous:HIGH?.....	671
[SOURce<hw>]:FREQuency:PHASe:CONTInuous:LOW?.....	672
[SOURce<hw>]:FREQuency:PHASe:CONTInuous:MODE.....	672
[SOURce<hw>]:FREQuency:PHASe:CONTInuous:STATe.....	673
[SOURce<hw>]:FREQuency:PLL:MODE.....	671
[SOURce<hw>]:FREQuency:SPAN.....	669
[SOURce<hw>]:FREQuency:STARt.....	669
[SOURce<hw>]:FREQuency:STEP:MODE.....	670
[SOURce<hw>]:FREQuency:STEP[:INCRement].....	671
[SOURce<hw>]:FREQuency:STOP.....	670
[SOURce<hw>]:FREQuency[:CW FIXed].....	666
[SOURce<hw>]:FREQuency[:CW FIXed]:RCL.....	667
[SOURce<hw>]:ILS:GS GSLope:PRESet.....	632
[SOURce<hw>]:ILS:LOCalizer:COMid:CODE.....	633
[SOURce<hw>]:ILS:LOCalizer:COMid:DASH.....	633
[SOURce<hw>]:ILS:LOCalizer:COMid:DEPT.....	634
[SOURce<hw>]:ILS:LOCalizer:COMid:DOT.....	634
[SOURce<hw>]:ILS:LOCalizer:COMid:FREQuency.....	634
[SOURce<hw>]:ILS:LOCalizer:COMid:LETter.....	635
[SOURce<hw>]:ILS:LOCalizer:COMid:PERiod.....	635
[SOURce<hw>]:ILS:LOCalizer:COMid:SYMBol.....	635
[SOURce<hw>]:ILS:LOCalizer:COMid:TSCHEMA.....	635
[SOURce<hw>]:ILS:LOCalizer:COMid[:STATe].....	636
[SOURce<hw>]:ILS:LOCalizer:DDM:COUPLing.....	636
[SOURce<hw>]:ILS:LOCalizer:DDM:CURREnt.....	636
[SOURce<hw>]:ILS:LOCalizer:DDM:DIRection.....	637
[SOURce<hw>]:ILS:LOCalizer:DDM:LOGarithmic.....	637
[SOURce<hw>]:ILS:LOCalizer:DDM:PCT.....	638
[SOURce<hw>]:ILS:LOCalizer:DDM:POLarity.....	638
[SOURce<hw>]:ILS:LOCalizer:DDM:STEP.....	638
[SOURce<hw>]:ILS:LOCalizer:DDM[:DEPT].....	639
[SOURce<hw>]:ILS:LOCalizer:FREQuency.....	639
[SOURce<hw>]:ILS:LOCalizer:FREQuency:MODE.....	639
[SOURce<hw>]:ILS:LOCalizer:FREQuency:SYNChronize[:STATe].....	621
[SOURce<hw>]:ILS:LOCalizer:FREQuency:SYNChronize[:STATe].....	640
[SOURce<hw>]:ILS:LOCalizer:ICAO:CHANnel.....	640
[SOURce<hw>]:ILS:LOCalizer:LLOBe[:FREQuency].....	640
[SOURce<hw>]:ILS:LOCalizer:MODE.....	641

[SOURce<hw>]:ILS:LOCalizer:PHASe.....	641
[SOURce<hw>]:ILS:LOCalizer:PRESet.....	641
[SOURce<hw>]:ILS:LOCalizer:RLOBe[:FREQuency].....	642
[SOURce<hw>]:ILS:LOCalizer:SDM.....	642
[SOURce<hw>]:ILS:LOCalizer:SOURce.....	642
[SOURce<hw>]:ILS:PRESet.....	620
[SOURce<hw>]:ILS:SETTing:CATalog?.....	620
[SOURce<hw>]:ILS:SETTing:DELeTe.....	620
[SOURce<hw>]:ILS:SETTing:LOAD.....	620
[SOURce<hw>]:ILS:SETTing:STORe.....	621
[SOURce<hw>]:ILS:STATe.....	621
[SOURce<hw>]:ILS:TYPE.....	626
[SOURce<hw>]:ILS[:GS GSLope]:DDM:COUPling.....	627
[SOURce<hw>]:ILS[:GS GSLope]:DDM:CURREnt.....	627
[SOURce<hw>]:ILS[:GS GSLope]:DDM:DIRection.....	627
[SOURce<hw>]:ILS[:GS GSLope]:DDM:LOGarithmic.....	628
[SOURce<hw>]:ILS[:GS GSLope]:DDM:PCT.....	628
[SOURce<hw>]:ILS[:GS GSLope]:DDM:POLarity.....	628
[SOURce<hw>]:ILS[:GS GSLope]:DDM:STEP.....	629
[SOURce<hw>]:ILS[:GS GSLope]:DDM[:DEPT].....	629
[SOURce<hw>]:ILS[:GS GSLope]:FREQuency.....	629
[SOURce<hw>]:ILS[:GS GSLope]:FREQuency:MODE.....	630
[SOURce<hw>]:ILS[:GS GSLope]:FREQuency:SYNChronize[:STATe].....	621
[SOURce<hw>]:ILS[:GS GSLope]:FREQuency:SYNChronize[:STATe].....	630
[SOURce<hw>]:ILS[:GS GSLope]:ICAO:CHANnel.....	630
[SOURce<hw>]:ILS[:GS GSLope]:LLOBe[:FREQuency].....	631
[SOURce<hw>]:ILS[:GS GSLope]:MODE.....	631
[SOURce<hw>]:ILS[:GS GSLope]:PHASe.....	631
[SOURce<hw>]:ILS[:GS GSLope]:SDM.....	632
[SOURce<hw>]:ILS[:GS GSLope]:SOURce.....	632
[SOURce<hw>]:ILS[:GS GSLope]:ULOBe[:FREQuency].....	633
[SOURce<hw>]:INPut:MODext:COUPling<ch>.....	673
[SOURce<hw>]:INPut:MODext:IMPedance<ch>.....	674
[SOURce<hw>]:LFOutput:FREQuency:MANual.....	678
[SOURce<hw>]:LFOutput:FREQuency:MODE.....	678
[SOURce<hw>]:LFOutput:FREQuency:START.....	679
[SOURce<hw>]:LFOutput:FREQuency:STOP.....	679
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:DWELL.....	684
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:EXECute.....	684
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:MODE.....	684
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:POINts.....	685
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:RETRace.....	685
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:RUNNing?.....	685
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:SHAPE.....	686
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:SPACing.....	686
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:STEP:LOGarithmic.....	686
[SOURce<hw>]:LFOutput:SWEep[:FREQuency]:STEP[:LINear].....	687
[SOURce<hw>]:LFOutput<ch>:PERiod?.....	677
[SOURce<hw>]:LFOutput<ch>:SHAPE.....	681
[SOURce<hw>]:LFOutput<ch>:SHAPE:PULSe:DCYCLE.....	681

[SOURce<hw>]:LFOutput<ch>:SHApe:PULSe:PERiod.....	681
[SOURce<hw>]:LFOutput<ch>:SHApe:PULSe:WIDTh.....	682
[SOURce<hw>]:LFOutput<ch>:SHApe:TRAPeZe:FALL.....	682
[SOURce<hw>]:LFOutput<ch>:SHApe:TRAPeZe:HIGH.....	682
[SOURce<hw>]:LFOutput<ch>:SHApe:TRAPeZe:PERiod.....	682
[SOURce<hw>]:LFOutput<ch>:SHApe:TRAPeZe:RISE.....	683
[SOURce<hw>]:LFOutput<ch>:SHApe:TRlangle:PERiod.....	683
[SOURce<hw>]:LFOutput<ch>:SHApe:TRlangle:RISE.....	683
[SOURce<hw>]:LIST:CATalog?.....	695
[SOURce<hw>]:LIST:DELeTe.....	695
[SOURce<hw>]:LIST:DELeTe:ALL.....	696
[SOURce<hw>]:LIST:DEXChange:AFILe:CATalog?.....	697
[SOURce<hw>]:LIST:DEXChange:AFILe:EXTension.....	698
[SOURce<hw>]:LIST:DEXChange:AFILe:SELeCt.....	698
[SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:COLumn.....	698
[SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:DECimal.....	699
[SOURce<hw>]:LIST:DEXChange:EXECute.....	698
[SOURce<hw>]:LIST:DEXChange:MODE.....	699
[SOURce<hw>]:LIST:DEXChange:SELeCt.....	699
[SOURce<hw>]:LIST:DWELI.....	690
[SOURce<hw>]:LIST:DWELI:LIST.....	691
[SOURce<hw>]:LIST:DWELI:LIST:POINts?.....	691
[SOURce<hw>]:LIST:DWELI:MODE.....	690
[SOURce<hw>]:LIST:FREE?.....	696
[SOURce<hw>]:LIST:FREQuency.....	691
[SOURce<hw>]:LIST:FREQuency:POINts?.....	692
[SOURce<hw>]:LIST:INDeX.....	692
[SOURce<hw>]:LIST:INDeX:STARt.....	692
[SOURce<hw>]:LIST:INDeX:STOP.....	692
[SOURce<hw>]:LIST:MODE.....	693
[SOURce<hw>]:LIST:POWer.....	693
[SOURce<hw>]:LIST:POWer:POINts?.....	694
[SOURce<hw>]:LIST:RESeT.....	697
[SOURce<hw>]:LIST:RUNNing?.....	695
[SOURce<hw>]:LIST:SELeCt.....	697
[SOURce<hw>]:LIST:TRIGGer:EXECute.....	694
[SOURce<hw>]:LIST:TRIGGer:SOURce.....	694
[SOURce<hw>]:MODulation[:ALL][:STATe].....	583
[SOURce<hw>]:NOISe:BANDwidth BWIDTh.....	700
[SOURce<hw>]:NOISe:BWIDTh:STATe.....	700
[SOURce<hw>]:NOISe:DISTRibution.....	701
[SOURce<hw>]:NOISe:LEVel:RELative?.....	701
[SOURce<hw>]:NOISe:LEVel[:ABSolute]?.....	701
[SOURce<hw>]:PGENerator:OUTPut:POLarity.....	702
[SOURce<hw>]:PGENerator:OUTPut[:STATe].....	702
[SOURce<hw>]:PGENerator:STATe.....	703
[SOURce<hw>]:PHASe.....	703
[SOURce<hw>]:PHASe:REFerence.....	703
[SOURce<hw>]:PM:DEViation:MODE.....	602
[SOURce<hw>]:PM:DEViation:SUM.....	602

[SOURce<hw>]:PM:MODE.....	601
[SOURce<hw>]:PM:RATio.....	602
[SOURce<hw>]:PM:SENSitivity?.....	602
[SOURce<hw>]:PM<ch>:SOURce.....	601
[SOURce<hw>]:PM<ch>:STATe.....	600
[SOURce<hw>]:POWer:ALC:DSENSitivity.....	706
[SOURce<hw>]:POWer:ALC:EDETector:FACTor.....	706
[SOURce<hw>]:POWer:ALC:EDETector:LEVel.....	707
[SOURce<hw>]:POWer:ALC:MODE?.....	705
[SOURce<hw>]:POWer:ALC:SONCe.....	707
[SOURce<hw>]:POWer:ALC[:STATe].....	705
[SOURce<hw>]:POWer:ATTenuation:PATTenuator.....	707
[SOURce<hw>]:POWer:ATTenuation:RFOff:MODE.....	707
[SOURce<hw>]:POWer:EMF:STATe.....	708
[SOURce<hw>]:POWer:LBEHaviour.....	708
[SOURce<hw>]:POWer:LIMit[:AMPLitude].....	708
[SOURce<hw>]:POWer:MANual.....	709
[SOURce<hw>]:POWer:MODE.....	709
[SOURce<hw>]:POWer:POWer.....	710
[SOURce<hw>]:POWer:RANGe:LOWer?.....	713
[SOURce<hw>]:POWer:RANGe:MAX?.....	714
[SOURce<hw>]:POWer:RANGe:MIN?.....	714
[SOURce<hw>]:POWer:RANGe:UPPer?.....	713
[SOURce<hw>]:POWer:START.....	710
[SOURce<hw>]:POWer:STEP:MODE.....	711
[SOURce<hw>]:POWer:STEP[:INCRement].....	711
[SOURce<hw>]:POWer:STOP.....	710
[SOURce<hw>]:POWer[:LEVel][:IMMediate]:OFFSet.....	711
[SOURce<hw>]:POWer[:LEVel][:IMMediate]:RCL.....	712
[SOURce<hw>]:POWer[:LEVel][:IMMediate]:REFLevel.....	713
[SOURce<hw>]:POWer[:LEVel][:IMMediate][:AMPLitude].....	712
[SOURce<hw>]:PULM:DELay.....	606
[SOURce<hw>]:PULM:DOUBle:DELay.....	606
[SOURce<hw>]:PULM:DOUBle:STATe.....	607
[SOURce<hw>]:PULM:DOUBle:WIDTh.....	607
[SOURce<hw>]:PULM:IMPedance.....	608
[SOURce<hw>]:PULM:MODE.....	605
[SOURce<hw>]:PULM:PERiod.....	605
[SOURce<hw>]:PULM:POLarity.....	608
[SOURce<hw>]:PULM:SOURce.....	607
[SOURce<hw>]:PULM:STATe.....	607
[SOURce<hw>]:PULM:THReshold.....	608
[SOURce<hw>]:PULM:TRAIin:CATalog?.....	610
[SOURce<hw>]:PULM:TRAIin:DELeTe.....	610
[SOURce<hw>]:PULM:TRAIin:DEXChange:AFILe:CATalog?.....	613
[SOURce<hw>]:PULM:TRAIin:DEXChange:AFILe:EXTension.....	612
[SOURce<hw>]:PULM:TRAIin:DEXChange:AFILe:SELEct.....	613
[SOURce<hw>]:PULM:TRAIin:DEXChange:AFILe:SEParator:COLUMN.....	613
[SOURce<hw>]:PULM:TRAIin:DEXChange:AFILe:SEParator:DECimal.....	613
[SOURce<hw>]:PULM:TRAIin:DEXChange:EXECute.....	614

[SOURce<hw>]:PULM:TRAI:DEXChange:MODE.....	612
[SOURce<hw>]:PULM:TRAI:DEXChange:SElect.....	614
[SOURce<hw>]:PULM:TRAI:OFFTime.....	610
[SOURce<hw>]:PULM:TRAI:OFFTime:POINts?.....	611
[SOURce<hw>]:PULM:TRAI:ONTime.....	610
[SOURce<hw>]:PULM:TRAI:ONTime:POINts?.....	611
[SOURce<hw>]:PULM:TRAI:REPetition.....	611
[SOURce<hw>]:PULM:TRAI:REPetition:POINts?.....	611
[SOURce<hw>]:PULM:TRAI:SElect.....	611
[SOURce<hw>]:PULM:TRIGger:MODE.....	605
[SOURce<hw>]:PULM:TTYPe.....	607
[SOURce<hw>]:PULM:WIDTh.....	606
[SOURce<hw>]:SWEep:COMBined:COUNT.....	731
[SOURce<hw>]:SWEep:COMBined:DWELl.....	731
[SOURce<hw>]:SWEep:COMBined:EXECute.....	731
[SOURce<hw>]:SWEep:COMBined:MODE.....	732
[SOURce<hw>]:SWEep:COMBined:RETRace.....	732
[SOURce<hw>]:SWEep:COMBined:SHAPE.....	733
[SOURce<hw>]:SWEep:GENeration.....	724
[SOURce<hw>]:SWEep:MARKer:OUTPut:POLarity.....	733
[SOURce<hw>]:SWEep:POWer:DWELl.....	724
[SOURce<hw>]:SWEep:POWer:EXECute.....	728
[SOURce<hw>]:SWEep:POWer:MODE.....	724
[SOURce<hw>]:SWEep:POWer:POINts.....	725
[SOURce<hw>]:SWEep:POWer:RETRace.....	728
[SOURce<hw>]:SWEep:POWer:RUNNing?.....	729
[SOURce<hw>]:SWEep:POWer:SHAPE.....	728
[SOURce<hw>]:SWEep:POWer:SPACing:MODE?.....	725
[SOURce<hw>]:SWEep:POWer:STEP[:LOGarithmic].....	725
[SOURce<hw>]:SWEep:RESet[:ALL].....	733
[SOURce<hw>]:SWEep[:FREQuency]:ANALog:SWPoints?.....	726
[SOURce<hw>]:SWEep[:FREQuency]:DWELl.....	726
[SOURce<hw>]:SWEep[:FREQuency]:EXECute.....	728
[SOURce<hw>]:SWEep[:FREQuency]:MARKer:ACTive.....	734
[SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FREQuency.....	734
[SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FSTate.....	734
[SOURce<hw>]:SWEep[:FREQuency]:MODE.....	726
[SOURce<hw>]:SWEep[:FREQuency]:POINts.....	727
[SOURce<hw>]:SWEep[:FREQuency]:RETRace.....	728
[SOURce<hw>]:SWEep[:FREQuency]:RUNNing?.....	729
[SOURce<hw>]:SWEep[:FREQuency]:SHAPE.....	728
[SOURce<hw>]:SWEep[:FREQuency]:SPACing.....	727
[SOURce<hw>]:SWEep[:FREQuency]:STEP:LOGarithmic.....	729
[SOURce<hw>]:SWEep[:FREQuency]:STEP[:LINear].....	729
[SOURce<hw>]:SWEep[:FREQuency]:TIME.....	733
[SOURce<hw>]:VOR:COMid:CODE.....	649
[SOURce<hw>]:VOR:COMid:DASH.....	650
[SOURce<hw>]:VOR:COMid:DEPTh.....	650
[SOURce<hw>]:VOR:COMid:DOT.....	650
[SOURce<hw>]:VOR:COMid:FREQuency.....	650

[SOURce<hw>]:VOR:COMid:LETter.....	651
[SOURce<hw>]:VOR:COMid:PERiod.....	651
[SOURce<hw>]:VOR:COMid:SYMBol.....	651
[SOURce<hw>]:VOR:COMid:TSCHEMA.....	652
[SOURce<hw>]:VOR:COMid[:STATe].....	652
[SOURce<hw>]:VOR:FREQuency.....	652
[SOURce<hw>]:VOR:FREQuency:MODE.....	653
[SOURce<hw>]:VOR:ICAO:CHANnel.....	653
[SOURce<hw>]:VOR:MODE.....	654
[SOURce<hw>]:VOR:PRESet.....	620
[SOURce<hw>]:VOR:REFerence[:DEViation].....	655
[SOURce<hw>]:VOR:SETTing:CATalog?.....	620
[SOURce<hw>]:VOR:SETTing:DELeTe.....	620
[SOURce<hw>]:VOR:SETTing:LOAD.....	620
[SOURce<hw>]:VOR:SETTing:STORe.....	621
[SOURce<hw>]:VOR:SOURce.....	648
[SOURce<hw>]:VOR:STATe.....	621
[SOURce<hw>]:VOR:SUBCarrier:DEPTh.....	655
[SOURce<hw>]:VOR:SUBCarrier[:FREQuency].....	655
[SOURce<hw>]:VOR:VAR:FREQuency.....	656
[SOURce<hw>]:VOR:VAR[:DEPTh].....	656
[SOURce<hw>]:VOR[:BANGLE].....	648
[SOURce<hw>]:VOR[:BANGLE]:DIRection.....	649
[SOURce<hw>][:ILS]:MBEacon:COMid:CODE.....	643
[SOURce<hw>][:ILS]:MBEacon:COMid:DASH.....	643
[SOURce<hw>][:ILS]:MBEacon:COMid:DEPTh.....	643
[SOURce<hw>][:ILS]:MBEacon:COMid:DOT.....	644
[SOURce<hw>][:ILS]:MBEacon:COMid:FREQuency.....	644
[SOURce<hw>][:ILS]:MBEacon:COMid:LETter.....	644
[SOURce<hw>][:ILS]:MBEacon:COMid:PERiod.....	645
[SOURce<hw>][:ILS]:MBEacon:COMid:SYMBol.....	645
[SOURce<hw>][:ILS]:MBEacon:COMid:TSCHEMA.....	645
[SOURce<hw>][:ILS]:MBEacon:COMid[:STATe].....	646
[SOURce<hw>][:ILS]:MBEacon:FREQuency.....	646
[SOURce<hw>][:ILS]:MBEacon:FREQuency:MODE.....	646
[SOURce<hw>][:ILS]:MBEacon:MARKer:FREQuency.....	646
[SOURce<hw>][:ILS]:MBEacon:PRESet.....	647
[SOURce<hw>][:ILS]:MBEacon[:MARKer]:DEPTh.....	647
[SOURce<hw>][:ILS]:MBEacon[:MARKer]:PULSed.....	647
*CLS.....	464
*ESE.....	464
*ESR?.....	464
*IDN?.....	464
*IST?.....	465
*OPC.....	465
*OPT?.....	465
*PRE.....	465
*PSC.....	465
*RCL.....	466
*RST.....	466

*SAV.....	466
*SRE.....	467
*STB?.....	467
*TRG.....	467
*TST?.....	467
*WAI.....	467
<subsystem>:FREQuency:SYNChronize:STATe.....	621
<subsystem>:PRESet.....	620
<subsystem>:SETTing:CATalog.....	620
<subsystem>:SETTing:DELeTe.....	620
<subsystem>:SETTing:LOAD.....	620
<subsystem>:SETTing:STORe.....	621
<subsystem>:STATe.....	621
DIAGnostic:HUMS:DELeTe:ALL.....	492
DIAGnostic:HUMS:DEvice:HISTory:DELeTe:ALL.....	493
DIAGnostic:HUMS:DEvice:HISTory?.....	492
DIAGnostic:HUMS:FORMat.....	493
DIAGnostic:HUMS:SAVE.....	493
DIAGnostic:HUMS:STATe.....	494
DIAGnostic:HUMS:TAGS:ALL?.....	494
DIAGnostic:HUMS:TAGS:DELeTe.....	494
DIAGnostic:HUMS:TAGS:DELeTe:ALL.....	495
DIAGnostic:HUMS:TAGS[:VALue].....	495
SYSTem:COMMunicate:REST:ENABle.....	495
SYSTem:COMMunicate:SNMP:COMMunity:RO.....	495
SYSTem:COMMunicate:SNMP:COMMunity:RW.....	496
SYSTem:COMMunicate:SNMP:CONtact.....	496
SYSTem:COMMunicate:SNMP:LOCation.....	496
SYSTem:COMMunicate:SNMP:USM:USER.....	497
SYSTem:COMMunicate:SNMP:USM:USER:ALL?.....	497
SYSTem:COMMunicate:SNMP:USM:USER:DELeTe.....	498
SYSTem:COMMunicate:SNMP:USM:USER:DELeTe:ALL.....	498
SYSTem:COMMunicate:SNMP:VERSion.....	498

Index

Symbols

/var/user directory	469
/var/volatile directory	469
>L	442
&LLO	442
&NREN	442
50 - Extern reference out of range or disconnected	772
140 - This modulation forces other modulations off	772
180 - Adjustment failed	772
182 - Adjustment data missing	772
183 - Adjustment data invalid	772
200 - Cannot access hardware	772
201 - Hardware revision out of date	772
202 - Cannot access the EEPROM	772
203 - Invalid EEPROM data	772
204 - river initialization failed	773
241 - No current list	773
242 - Unknown list type specified	773
460 - Cannot open the file	773
461 - Cannot write file	773
462 - Cannot read file	773
463 - Filename missing	773
464 - Invalid filename extension	773
465 - File contains invalid data	773

A

About	
ALC states and their effects	214
Attenuator	210
External ALC	214
Internal adjustments	785
Power-On/EMF	342
Reference oscillator	291
Selftests	785
UCOR	218
Accept	
Security settings	370
Active connections	
Remote access	406
Active elements	55
Add LAN sensor	
NRP sensor mapping	233
Add sensor	
NRP sensor mapping	233
Add USBTMC sensor	
NRP sensor mapping	233
Add, change, delete	
User key action	349
Address	
GPIO interface	404
ADF	
About	162
Adjust	
Display and keyboard	340
Display settings	339
Keyboard settings	339
Adjustment frequency	
Reference oscillator	291
Adjustments	
All	787
All delayed	788

Continue	787
Delay settings	788
Information	787
Last full adjustment	787
Settings	786
Shutdown	788
Warm up time	788
Advanced configuration	
LXI	422
ALC	
Detector coupling factor	216
Detector sensitivity	216
Required generator level	216
Settings	215
State	216
ALC states and their effects	214
All packages	
Secure update policy	363
Alphanumeric parameters	58
AM	79
Deviation mode	90
Overview	122
Ratio	91
Subsystem	584
Total deviation	90
Amplitude modulation	88
Depth	90
Deviation mode	90
Mode	89
Ratio	91
Sensitivity	90
Subsystem	584
Type	89
Analog modulation	
Options	79
Overview	120
Signal source	79
Annotation	
Disable amplitude display	366
Disable frequency display	365
Disable level	366
Aperture time	
Power sensors	241
Application cards	22
Application notes	22
ATN	807
Attention	807
Attenuator	
About	210
RF signal	210
Settings	211
Attenuator settings	
Level range	212
Mode	212
RF OFF mode	212
Step attenuator below 20 GHz	212
Auto once	
Power sensors	240
Power viewer	240
Automatic level control	
Detector coupling factor (ext. ALC)	216
Detector sensitivity	216
How to: set external ALC	217

Readjust internal switch position	76
Required generator level (ext. ALC)	216
Settings	215
State	216
Automation	378
Autonegotiation	
Failed	775
Avahi	
LAN services	368
Average	
Power analysis	255
Average level	
Power viewer	238
Avionics standards	
Overview	125

B

Bandwidth	
Chirp modulation	94
Modulation input	116
Noise generator	117
Basics	
Editor	105, 206, 224
Export list files	106, 227
Fill with sensor list files	226
Import list files	106, 227
Baud rate	
RS232 interface	404
Bench top, placing	24
Brochures	21
Browser settings	
LXI	420
Bytes order	
Definition	504

C

CALibration subsystem	479
Carrier frequency	
ILS localizer	149
ILS marker beacons	158
VOR	130
Carrier frequency mode	
ILS localizer	149
ILS marker beacons	158
VOR	130
Carrying the instrument	23
Central storage	
Accessing	332
Change	
GPIO address	431, 440
Change password	
Setup (security)	372
Change user password	
Setup (security)	372
Check front panel	
Key panel test	795
Performing	795
Settings	794
Check touch panel	
Touchscreen test	796
Checking the instrument	23
Chirp	
Modulation	92
CHIRp	
Subsystem	590

Chirp modulation	79, 91
Bandwidth	94
Compression ratio	95
Direction	93
Gated signal	95
Pulse external settings	95
Pulse period	94
Pulse width	95
Remoote control commands	590
Settings	93
Single trigger	95
State	93
Subsystem	590
Trigger mode	95
Trigger settings	95
Cleaning	785
Clear	
NRP sensor mapping	233
RF output protection	213
User menu	345
Clear history	
Undo/Redo	376
Clear status	
Remote	464
Clk Syn connector	39, 42
Clock	
Amplitude	303
DC offset	304
Frequency	303
Phase, reset	304
Phase, set	304
Shape	302
Clock synthesis	483
Clock synthesis inverted output	301
Clock synthesis output	301
Close	
Show SCPI command	445
Configuring external ALC	217
Color	
Power analysis	248
COM/ID code	
ADF	166
COM/ID dash length	
ADF	167
COM/ID depth	
ADF	166
COM/ID dot length	
ADF	166
COM/ID frequency	
ADF	166
COM/ID letter space	
ADF	167
COM/ID period	
ILS localizer	166
COM/ID settings	
ADF	165
COM/ID state	
ADF	166
COM/ID symbol space	
ADF	167
COM/ID time schema	
ADF	166
Combined RF frequency / level sweep	
Step count	194
Combined sweep	
Spacing	189, 192

Command sequence		
Remote	467	
Commands of all settings		
SCPI list	316	
Compression ratio		
Chirp modulation	95	
Computer name		
see hostname	428	
CONDition	391	
Configuration		
Restoring	317	
Restoring instrument settings	314	
Configure		
Power analysis	246	
Configure diagram		
Power analysis	260	
Configure gate mode		
Power analysis	271	
Configure measurement		
Power analysis	252	
Configure sensor		
Power analysis	256	
Configure time mode		
Power analysis	261	
Configuring LAN services	367	
Confirm unsigned		
Secure update policy	363	
Confirm user password		
Setup (security)	371, 372	
Connecting		
Keyboard	28	
LAN	27	
Memory stick	28	
Mouse	28	
Power	27	
To Ref In/Ref Out	31	
To RF	30	
To RF coaxial connectors	29	
USB devices	28	
Connecting external ALC	215, 217	
Connecting to RF coaxial connectors		
To connect to pluggable connectors	30	
To connect to screwable connectors	29	
To prepare for connecting	29	
Connection fault		
169.254.*.*	775	
Connector		
AC power supply	43	
Clk Syn N	39, 42	
EFC	42	
Ext	39, 43	
GPIO	41	
IEC/IEEE	41	
Inst Trig	42	
LAN	41	
LF	39, 43	
Marker User1	42	
Pulse Ext	39, 42	
Pulse Sync	39, 43	
Pulse Video	39, 42	
Ref In	41	
Ref Out	41	
RF 50 Ω	38, 43	
Sensor	38	
Signal Valid	42	
Stop	42	
USB	37, 41	
USB In	41	
V/GHz X-Axis	42	
Z-Axis	42	
Connectors		
RF signal	66	
Context-sensitive menu	55	
Continue		
Internal adjustments	787	
Control bus	807	
Copy		
Instrument settings	323	
Several files	321, 329, 330	
Show SCPI command	445	
Counter	777	
Coupling mode		
AM, FM, PhiM	116	
External modulation input	116	
Create		
New directory	323	
Current frequency		
Sweep	186	
Current index		
List mode	199	
Current level		
Sweep	186	
Customer support	782	
Cut		
Instrument settings	323	
CW		
Frequency	70	
CW mode		
Output level	73	
CW signal		
Settings	63	
D		
Data entry	57	
Data format		
Definition	504	
Data list		
Access	318	
How to access	471	
Select, edit, new	320	
Data sheets	21	
Data valid	807	
Datasheet		
LXI	426	
Date	792	
DAV	807	
Deactivate RF output	293	
Deactivated licenses	353	
Declassification	365	
Default directory		
Mass memory	469	
User data	306, 470	
Default settings	129, 141, 164	
Default values		
Remote	466	
Define		
User key action	349	
Delay		
Double pulse (PULM)	102	
PULM	102	
Delete		
Instrument settings	323	
List mode file	201	

Delete instrument settings	477
Delete temporary files	799
Delta phase	
RF frequency	78
Detector coupling factor	
Automatic level control (ext. ALC)	216
Detector sensitivity	
Automatic level control	216
Deviation	
Fixed total deviation	86, 88
PhiM	87
Deviation mode	
AM	90
Amplitude modulation	90
FM	86
Frequency modulation	86
Phase modulation	87
PhiM	87
Device ID	353, 759
NRP sensor mapping	233
Device reset	468
Device-specific notifications	771
DHCP	427
Dialog boxes	56
Direction	
Chirp modulation	93
Directory	
Temporary data	469
User data	469
Disable	
Frequency display	365
Level display	366
Display	
Active elements	55
Brightness	341
Context-sensitive menu	55
Info line	55
Information	53
Keyboard layout	341
Lock	366
On-screen keypad	55
Overview	34
Power sensors	239
SCPI list	445
Screen saver	341
Settings	340
Setup	340
Status bar	54
Tab labels	55
Taskbar	54
Tile diagram	54
Wait time (screen saver)	341
Display correction file data	
UCOR	222
Display correction value	
UCOR	221
DISPlay subsystem	499
Disposal	785
Distribution	
Noise generator	117
DNS server	401
DNS suffix	401
Documentation overview	20
Double pulse delay	
PULM	102
Double pulse width	
PULM	102

Downgrade information	778
Factory version	778
Min. version	778
Dwell time	
Sweep	189
Dwell time mode	
List mode	200

E

Edit	
Editor	105, 207, 225
List mode data	202
UCOR data	222
Editor	
Basics	105, 206, 224
Edit	105, 207, 225
Fill with sensor	207, 225
Goto	105, 206, 224
Save	105, 207, 225
Save as	105, 207, 225
EFC	
Activate	295
Sensitivity	295
EMF display	
RF level	342
Emulating front panel keys	61
Emulation	
IDN string	406
Language	405
Mode	405
Set IDN and OPT to default	406
Enable	
LAN interface	368
ENABLE	391
Enable registers	
Remote	465
Enter license key	353
Enter password	
Setup (security)	370
EOI	807
Error log	781
Error messages	773
Adjustment data invalid (183)	772
Adjustment data missing (182)	772
Adjustment failed (180)	772
Cannot access hardware (200)	772
Cannot access the EEPROM (202)	772
Cannot open file (460)	773
Cannot read file (462)	773
Cannot write file (461)	773
Driver initialization failed (204)	773
Extern reference out of range or disconnected (50)	772
File contains invalid data (465)	773
Filename missing (463)	773
Hardware revision out of date (201)	772
Invalid EEPROM data (203)	772
Invalid filename extension (464)	773
No current list (241)	773
SCPI	771
See notifications	770
This modulation forces other modulations off (140)	772
Unknown list type specified (242)	773
Error queue	392
Error queue query	739, 740, 741
ESE (event status enable register)	393
ESR	389

ESR (event status register)	393
EVENT	391
Event status enable register (ESE)	393
Remote	464
Event status register (ESR)	393
Remote	464
Exclude frequency	317
Exclude level	317
Execute	
Single sweep	190
Trigger (list mode)	201
Expiration date of option	779
Export	
Execute	108, 204, 229
SCPI	320
SCPI export	447
SCPI list	446
SCPI settings	446
Export deactivation response	353
Export license key	354
Export list files	
Basics	106, 227
Express level in	
Volts	704
Ext AM	
VOR	130
External ALC	214
How to: setting up	217
Remote command sequence	704
External frequency	
Reference oscillator	293
F	
Factory	
Preset	311
Factory preset	
Change GPIB address	431
GPIB address	440
Factory version	
Firmware	778
File	
SCPI export	447
File catalog	
List mode	201
File handling	307
File list	474
File manager	321
File name	334
File select	
Dialog	318
File server	
Data exchange	332
File sharing	327
File storage location	469
File system	305
Accessing	327
File transfer	307
From file server	332
FTP/SAMBA	378
How to	327
File type selection	322
Filename	
Pulse graph	109
Files	
User data	305

Fill	
User correction data	105, 207, 225
Fill table	
Automatically	105, 207, 225
UCOR	222
Fill with sensor	
Basics	226
Editor	207, 225
Filter	
Power sensors	240
Filter length	
Auto	240
User-defined	240
Finding out the default directory	306, 470
Firmware	
Factory version	778
Min. version	778
Version	778
Fixed	
Frequency	70
Floating licenses	779
FM	79
Deviation	86
Deviation mode	86
Ratio	86
Subsystem	594
Total deviation	86
Format	
SCPI Export	447
FORMat subsystem	503
FPGA/μC	
Check for updates	798
Check for updates of external	799
Shut down after update internal	799
Update installation internal assembly	798
Update table	798
Free space	
internal memory	799
Frequency	
Annotation disable	365
CW, fixed	70
LF generator	114
LF sweep	114
Multiplier	71
Offset	71
Power sensors	239
RF signal	69
UCOR	222
Frequency marker	
Activate	197
Boost marker x	198
Duration	198
Polarity	198
State	197
Frequency modulation	86
Deviation mode	86
Ratio	86
Subsystem	594
Frequency range	
Phase continuous signal	78
Frequency range from	
Phase continuous signal	78
Frequency range to	
Phase continuous signal	78

Frequency sweep	
Sweep type	185, 196
V/GHz	196
X-Axis	196
Frequency, internal	
AM	114
FM	114
Front panel	
Checking	794
Front panel test	
Performing	795
Front panel tour	32
FTP	
How to access the instrument	327
LAN services	368
Function keys	
Overview	35

G

Gated signal	
Chirp modulation	95
Gateway	401
General configuration of instrument	339
General instrument functions	
User key	344
User menu	344
General instrument settings	339
General settings	
ADF	163
ILS	140
Generating an unmodulated signal	63
Getting started	21
Global dwell time	
List mode	200
Goto	
Editor	105, 206, 224
GPIB	
Address	404
Change address	431, 440
Channel address	403
Characteristics	384
Interface	384
Set up remote control	440
Visa resource string	403
GPIB address	
Factory preset	440
GUI	
Setting	343
GUI update	
Setup	339

H

Hard copy	
Create, how to	337
File format	335
Print, how to	337
Hard disk	
Deleting temp files	799
Hardcopy	333
Options	335
Help	21, 59
HiSLIP	
Visa resource string	402
HiSLIP	
Resource string	382

History	
Undo/Redo	376
Host name	
NRP sensor mapping	233
see hostname	428
Hostname	399
Changing	428
LXI	420
Syntax	428
Use instead of IP address	428
How to	
Change the default directory	471
Configuring external ALC	217
Connecting external ALC	215, 217
Query hardware options	779
Query RF assembly	780
Run delayed adjustments	791
Set external ALC	217
Use an complete file path	471
Use the hostname instead of IP address	428
User key	350
User menu	346
HTTP	
LAN services	368
HUMS	408
About	397
Add device tags	418
Delete device tag entry	418
Delete device tags	418
Delete history	410
Device ID	417
Device tag key	417
Device tag value	417
Device tags	416
Enhanced settings	409, 410
Export history	410
Protocol settings	411
REST	411
SNMP protocol	411
SNMPv2 access	412
SNMPv2 community	412
SNMPv2 configuration	412
SNMPv3 user	412
State	409

I

ICAO channel	
ILS localizer	150
VOR	130
Identification	
Emulation mode	405
Remote	464
IDN string	
Emulation mode	406
IEC/IEEE bus interface	
Channel address	403
IFC	807
ILS	
About	136
Configuration and settings	139
Glide slope settings	142
Localizer	148
Marker beacons settings	157
ILS component	
Component	141

ILS glide slope		Letter space	162
Amplitude settings	146	Period	161
Carrier frequency	143	State	161
Carrier frequency mode	143	Symbol space	162
Ext AM	144	Time schema	161
General settings	142	ILS marker beacons signal	
ICAO channel	143	Marker depth	159
Signal settings	144	Marker frequency	159
Sync with localizer	143, 150	Pulsed marker	159
ILS glide slope amplitude	146	Impedance	
DDM - SDM coupling	148	External modulation source	116
DDM current	147	Import	
DDM depth	147	Execute	108, 204, 229
DDM logarithmic	147	SCPI	320
DDM percent	148	Import license key	353
DDM step	147	Import list files	
Fly mode	147	Basics	106, 227
Sum of depth	146	Import/Export	
ILS glide slope signal		Lists	202
DDM polarity	145	Select file	108, 203, 204, 229
Down frequency	145	Inactive licenses	353
Operating mode	145	Index	
Up frequency	145	List mode	199
Up/Down phase	145	Info line	55, 773
ILS localizer		Information	
Amplitude settings	152	Internal adjustments	787
COM/ID settings	155	Input	
Ext AM	150	Impedance external modulations	116
General settings	149	Pulse Ext	91
Signal settings	151	Pulse polarity	110
Sync with glide slope	143, 150	Pulse threshold	110
ILS localizer amplitude		Trigger impedance	110
DDM - SDM coupling	154	Input connector	39, 42, 43
DDM current	154	Input connectors	
DDM depth	154	Stop	42
DDM logarithmic	155	Installed assembly	777
DDM percent	155	Instrument	
DDM step	154	Carrying	23
Fly mode	153	Checking	23
Sum of depth	153	Lifting	23
ILS localizer COM/ID		Operating site	23, 24
Code	156	Unpacking	23
Dash length	157	Instrument control	51
Depth	156	Instrument emulations	396, 405
Dot length	157	Instrument help	21
Frequency	156	Instrument security procedures	21
Letter space	157	Instrument settings	
Period	156	Recall	466, 477
State	156	Save	466, 479
Symbol space	157	Instrument tour	32
Time schema	157	Interface	
ILS localizer signal		functions (GPIB bus)	807
DDM polarity	152	GPIB	384
Left frequency	152	Interface clear	807
Left/right phase	152	Interfaces	
Operating mode	151	GPIB	384
Right frequency	152	RS232	383
ILS marker beacons		USB	383
COM/ID settings	160	Internal adjustments	
General settings	158	About	785
Signal settings	159	internal memory	
ILS marker beacons COM I/D		Deleting temp files	799
Code	161	Interrupt	394
Dash length	162	IP address	382
Depth	161	Changing	428
Dot length	162	Dynamic	400
Frequency	161	LXI	420

Not recognized	775	HTTP	368
NRP sensor mapping	233	LAN over SCPI	368
Zeroconf	400	SMB (Samba)	368
IP address mode	400	SSH	368
IP configuration		VNC	368
LXI	422	LAN status	
IST	389	LXI	419
IST flag		Landing systems	
Remote	465	Overview	125
K		Language	
Key		Emulation	405
★ (User)	37	Last factory calibration	777
Access on a remote computer	61	Last full adjustment	
Arrow	36	Internal adjustments	787
Backspace	36	Layout	
Down	36	Keyboard	341
Emulation	61	Level	
Enter	36	Annotation disable	366
Esc	36	Behavior (RF)	74, 194
Freq	35	Noise generator	120
Help	35	Level default unit	
Home	37	Change	704
Left	36	Level in SCPI in V	704
Level	35	Level limit	74
Local	35	Level offset	
Mod on/off	35, 82	Power sensors	239
Next window	37	RF level	74
On/Off	37	State (power sensors)	239
On/Standby	35	Level range	
Preset	35	Attenuator settings	212
Resize window	37	Level settings	
RF on/off	35	On start-up	342
Right	36	LF frequency sweep	
Setup	35	State	112, 186
Up	36	LF generator	
Key panel test		Shape	112
Check front panel	795	LF Out	
Keyboard		Overview	121
On-screen	57	LF output	118
Setting	343	Load impedance	119
Settings	340	Offset	119
Setup	340	Period	114
Subsystem	510	Pulse duty cycle	114
Usage	52	Pulse width	114
Keypad		Shape	112
On-screen	57	Source	119, 122
Overview	35	Sweep reset	190
L		Trapezoid high	115
LAN		Trapezoid rise, fall	115
Connecting	27	Triangle rise	115
Environment	27	Voltage	119
Interface	381	LF sweep	
IP address	382	Frequency	114
Main services	368	License	
Reset	420	Keys	351
Samba services	369	License for software option	779
Services	367	Infos	779
LAN configuration	426	Licenses	351
LXI	421	Server	354
LAN interface		Settings	351
Avahi	368	Lifting the instrument	23
Enable	368	Limit	
FTP	368	RF level	74
		List	
		Define	202
		Range	202

State	199
Values, defining	206, 224
List file	
Catalog	201
List mode	
Create list automatically	105, 207, 225
Current index	199
Dwell time mode	200
Edit	202
Execute trigger	201
Export user data	108, 204, 229
File settings, import/export	107, 203, 228
Global dwell time	200
Import/export	107, 202, 203, 228
Load from file	108, 203, 229
Load user data	202
Reset	201
Select file	201
Settings	198
State	199
Trigger execute	201
Trigger source	200
Load	
Impedance	119
See recall	315
Load instrument settings	466, 477
Loading	
Trying out	49
Local to remote switch over	442
Lock	
Display	366
LSB/MSB order	
Definition	504
LucasFonts	
RSCorpid EULA	779
LVD-M transporting MAN altitude TEMPLATE	784
LXI	
Advanced configuration	422
Browser settings	420
Configuration	458
Datasheet	426
Hostname	420
IP address	420
IP configuration	422
LAN configuration	421
LAN status	419
MAC address	420
Ping	423
Remote trace (SCPI)	424
Reset (LXI)	420
Status settings	419
Tracing	441
LXI settings	419
M	
Mac address	401
MAC address	
LXI	420
Maintenance	785
Managing license keys	351
Managing licenses	351
Manual interaction	52
Map network share	
Settings	322, 323
Mapping network drives/folders	
How to	325

Mark frequency	
Sweep	197
Marker	
Power analysis	246
Marker settings	
Power analysis	251
Marker User1	42
Mass storage location	469
Max	
RF level sweep	195
Maximal deviation	
Frequency modulation	86
PhiM	87
Measurement window	
Power analysis	245
Min	
RF level sweep	195
Min. version	
Firmware	778
Min/max Y scale	
Power analysis	260
Minimum locking range	295
Mode	
AM	89
Attenuator settings	212
Emulation	405
Frequency modulation	87
IP address	400
List	200
PhiM	88
PULM	98
Pulse modulation	98
Sweep	186
User variation	71, 76
Modulation	
AM	82
Analog	79
Bandwidth, external input	116
Chirp modulation	91, 92
Chirp modulation settings	93, 95
External coupling	116
FM	82
Input impedance	116
Overview	120
Phase	82
PhiM	82
PM	82
Pulse	82
Source	85
State	85
Modulation depth	
AM	90
Modulation sensitivity	
AM	90
Modulations state	
Toggle	82
More free disc space	
Deleting temp files	799
Mount network drive	
How to	325
Mounting, in a rack	25
Mouse	
Usage	52
Multiple files	
Copy	321, 329, 330
Multiplier	
Frequency	71

N

Naming conventions	
Allowed file names	305
Navigation	
Keys	36
Navigation controls	
Overview	36
NDAC	807
Network	
Connection fails	775
Environment	27
Settings	398
Network share	
Mapping	323
Mapping, how to	325
Network status	399
New password	
Setup (security)	372
New user password	
Setup (security)	371
Noise	
Distribution	117
Noise bandwidth limitation	
System bandwidth	117
Noise generator	
Bandwidth	117
Noise level	
Absolute system bandwidth	120
Relative system bandwidth	120
Noise ratio	
Power sensors	240
Notifications	770, 773
Device-specific	771
NRFDR	807
NRP	
see Power analysis	242
NRP power viewer	
Settings	236
Use S-Parameter	241
NRP sensor mapping	231
Add LAN sensor	233
Add sensor	233
Add USBTMC sensor	233
Clear	233
Connector	232
Device ID	233
Host name	233
IP address	233
Protocol	232
Scan	233
Sensor name	232, 233
Serial number	233
Settings	232
NTP	
Address	793
NTRansition	391
Number of licenses	779
Numeric data entry	57
Numeric parameters	58

O

Offset	
Frequency	71
Old password	
Setup (security)	372

Old user password	
Setup	371
On-screen keyboard	58
On-screen keypad	55
Open source acknowledgment (OSA)	22
Open-source acknowledgments	778
Operating site	
Choosing	23
Setting up the instrument	24
Operation	
Manual	52
Operation complete	
Remote	465
Operation hours	777
Operation mode	315
Option	
Expiration date	779
Option: expiration date	779
Options	
Analog modulation	79
Identification (remote)	465
Oscillator	
Reference	291
Output	
Clk Syn	301
LF	119
SCPI list (select file)	447
Source (LF output)	122
OUTPut	
Subsystem	510
Output connector	39, 42
Output connectors	
Clk Syn	39, 42
Marker User1	42
Pulse Sync	39, 43
RF 50 Ω	38, 43
Stop	42
V/GHz X-Axis	42
Z-Axis	42
Output queue	389
Output, LF	
Offset	119
Voltage	119
Overview	
AM	122
LF Out	121

P

Parallel poll register enable	
Remote	465
Parameters	
Entering	58
Parity	
RS232 interface	404
Password	
Change (security password)	372
Change (user password (security))	372
Confirm (security password)	372
Confirm (user password (security))	371
Enter (security password)	370
New (security password)	372
New (user password (security))	371
Old (security password)	372
Old user password	371
Protection level	362

Password management		
Security	370	
Paste		
Instrument settings	323	
PCI bus	777	
Phase		
Subsystem	703	
Phase continuous active		
RF frequency	77	
Phase continuous mode		
RF signal	65	
Phase continuous signal		
Frequency range	78	
Frequency range from	78	
Frequency range to	78	
Phase modulation	87	
Deviation	87	
Deviation mode	87	
Mode	88	
Ratio	88	
Subsystem	599	
Phase reference	78	
Phase settings		
RF signal	76	
PhiM		
Deviation mode	87	
Mode	88	
Ratio	88	
Settings	87	
Total deviation	88	
Ping		
LXI	423	
Placing, on a bench top	24	
PLL bandwidth	71	
PM	79	
Subsystem	599	
Polarity		
Pulse generator output	102	
Pulse modulation	110	
Power		
Connecting the instrument	27	
UCOR	222	
Power analysis	242	
Access	244	
Example	246	
Marker settings	251	
Options	242	
Trace reference settings	249	
Trace settings	248	
Traces	246	
Power Analysis Diagram		
Power analysis	245	
Power On	35	
Power sensors		
Activation	238	
Aperture time	241	
Auto once	240	
Filter	240	
Filter length	240	
Frequency	239	
Level (average)	238	
Level (peak)	238	
Level offset	239	
Noise ratio	240	
Serial number	238	
Source	239	
State	238	
State (level offset)	239	
Timeout	241	
Unit	238	
Update	236	
Use default aperture time	241	
Zero	238	
Power Sensors		
Display	239	
Power supply		
Connector	43	
Power viewer		
Auto once	240	
Power-On		
Settings	342	
Power-On count	777	
Power-On state		
RF level	342	
Power-On/EMF		
About	342	
RF signal	342	
PPE	389	
Prefix, year, month, Day	336	
Preparing for use	23	
Preset		
Factory preset	311	
Print		
Hard copy	337	
Protection		
Settings	361	
Setup	360	
Protection level		
1	360	
2	360	
3, 4, 5	360	
Adjustments	360	
Calibration	360	
Factory only	360	
Protection level	362	
Service department	360	
PTRansition	391	
PULM		
Delay	102	
Double pulse delay	102	
Double pulse width	102	
Impedance (trigger input)	110	
Mode	98	
Period	101	
Pulse polarity (input)	110	
Repetition frequency	102	
see PM	82	
Source	83	
State	83	
Subsystem	603	
Threshold (pulse input)	110	
Transition type	84	
Width	101	
Pulse		
Duty cycle	114	
Length (PULM)	101	
Period	114	
Width	114	
Width (PULM)	101	
Pulse generator		
Delay	102	
Output polarity	102	
Output state	102	
Single Trigger	102	

Subsystem	701
Width	101
Pulse graph	
Filename	109
Zoom In/Out	109
Zoom position	109
Zooming	109
Pulse modulation	82
Double pulse delay	102
Double pulse width	102
Mode	98
Period	101
Pulse input threshold	110
Pulse polarity (input)	110
Repetition frequency	101, 102
see PM	82
Select pulse train file	104
Source	83
State	83, 84
Subsystem	603
Trigger input impedance	110
Trigger mode	99
Pulse period	
Chirp modulation	94
Pulse Sync connector	39, 43
Pulse train	
File catalog	104
Import/export	107, 203, 228
On/off time	105
Repetition	105
Select	104
Pulse width	
Chirp modulation	95

Q

QR code	418
Queries	
Status	395
Questionable status register	393, 394

R

R&S signed packages	
Secure update policy	363
Rack installation	43
Rack, mounting	25
Radio navigation systems	
Overview	125
Ratio	
AM	91
Amplitude modulation	91
FM	86
Frequency modulation	86
Phase modulation	88
PhiM	88
Readjust	
Automatic level control	76
Recall	
Instrument settings	317
User menu	345
Recall instrument settings	466, 477
Recall intermediate	317, 466
Recorded SCPI commands	
SCPI list	446

Redo	375
Clear history	376
History	376
Settings	376
State	376
Reference frequency output	
1 GHz	296
10 MHz, 100 MHz	296
Loop through	296
Reference oscillator	291
Adjustment	296
Adjustment frequency	297
External frequency	293
Output frequency	296
Preset	293
Reference frequency, variable	294
RF off state	293
Source	293
Synchronization bandwidth	294
Use external tuning	295
Registers	389
Release notes	22
Reload	
SCPI list	447
Remote access	378
Active connections	406
DNS server	401
DNS suffix	401
GPIB address	403
GPIB resource (VISA resource string)	403
HISLIP resource (VISA resource string)	402
HUMS	408
Identification	405
IDN string	406
IEC/ IEEE bus address	403
Instrument emulations	405
IP address mode	400
Language	405
Network gateway	401
Network hostname	399
Network IP address	400
Network Mac address	401
Network resource (Ethernet resource string)	402
Network settings	398
Network status	399
OPT string	406
QR code	418
RS232	404
see Remote operation from a computer	52
Serial resource (VISA resource string)	403
Set IDN and OPT to default	406
Settings	396
Socket resource (VISA resource string)	403
Subnet mask	400
USB resource (VISA resource string)	403
Visa resource strings	402
VXI11 resource (VISA resource string)	402
Workgroup name	400
Remote control	60
Access modes	379
GPIB	440
GPIB interface	384
Programming examples	463
SCPI	378
Source subsystem	582
Remote operation	61
VNC	378

Remote trace	
LXI	424
Removing sensitive data	781
REN	807
Rename	
File	478
Instrument settings	323
Repetition frequency	
Pulse modulation	102
Required generator level	
Automatic level control (ext. ALC)	216
Reset	
List mode	201
RF frequency (delta phase)	78
Sweep	190
Reset device parameters	468
Reset values	
Remote	466
Resource string	
RS232	384
USB	384
VISA	382
Restoring configuration	310
Resulting file name	336
Retrace	
Sweep	187
RF 50 Ω connector	38, 43
RF combined sweep	
State	186
RF frequency	
Configuring	63
RF frequency sweep	
State	185
RF level	
Configuring	63
EMF display	342
Offset	74
Power-On state	342
Setting characteristics	74, 194
Settings	72
RF level sweep	
State	186
RF OFF mode	
Attenuator settings	212
RF off state	
Reference oscillator	293
RF ON, RF OFF, RF ON/OFF	63
RF output	
Amplitude	73
Harmonic filter	75
Impedance	63
Protection	213
State	63
RF Output	
Level range	75
RF output signal	
Phase	78
Phase continuous active	77
Phase continuous frequency range	78
Phase continuous frequency range from	78
Phase continuous frequency range to	78
Phase reference	78
RF phase	
Configuring	63
RF signal	
Analog modulation	79
Attenuator	210

Connectors	66
Frequency	69
Phase continuous mode	65
Phase settings	76
Power-On/EMF	342
User correction	218
Rotary knob	36
User step	304
User variation	71, 76
RS232	
Baud rate	404
Interfaces	383
Parity	404
Remote access	404
Resource string	384
Serial (VISA resource string)	403
Stop bits	404

S

S-Parameter	
Activate corrections	241
Safety instructions	15, 21
Samba services	
SMB client	369
SMB server	369
SAMBA/SMB	
How to access the instrument	327
Sanitize	365
save	
Save	315
Save	
Editor	105, 207, 225
Instrument settings	316
Power analysis	277
User menu	345
Save and load	314
Save as	
Editor	105, 207, 225
Save hard copy as	
bmp, jpg, png	335
Save immediate	316
Save instrument settings	466, 479
Save intermediate	466
Save to Red	
Power analysis	248
Save/Recall	314
ADF	129, 141, 164
Dialog	315
How to	317
ILS	129, 141, 164
SCPI-Export	449
VOR	129, 141, 164
Saving	48
Saving files	471
Scan	
NRP sensor mapping	233
SCPI	
Error messages	771
Export	320
Export settings	446
Import	320
LAN services	368
Output file	447
SCPI export	447
Select file	447
Show file content	447

SCPI Export	
Format	447
SCPI list	
Commands of all settings	316
Display	445
Export	446
Recorded SCPI commands	446
Show all commands	316
SCPI remote trace	
LXI	424
SCPI script	
Select	349
SCPI-Export	
Save/Recall	449
Screen saver	
Activate	343
State	341
Wait time	341
SD card slot	37
Secure update policy	
All packages	363
Confirm unsigned	363
R&S signed packages	363
Security	
Accept settings	370
Change password (setup)	372
Change user password (setup)	372
Confirm password (setup)	372
Confirm user password (setup)	371
Display lock	366
Enter password (setup)	370
New password (setup)	372
New user password (setup)	371
Old password (setup)	372
Old user password	371
Password management	370
Sanitize	365
Secure update policy	363
Security password	372
Settings	362
Setup	360
USB storage (setup)	364
User name (setup)	371
User password	371
Volatile memory	364
Security password	
Security	372
Setup	372
Security procedures	21
Security settings	360
Select	
List mode data file	201
Setup file	349
User correction data file	222
Select file	320
Self-test	
Remote	467
Selftests	
About	785
Sensitive information	
Protecting	306, 313
Sensor name	
NRP sensor mapping	233
Serial	
Visa resource string	403
Serial bus	777

Serial number	429
NRP sensor mapping	233
Power sensors	238
Service manual	21
Service request (SRQ)	392, 394
Service request enable register (SRE)	392
Remote	467
Services	
LAN	367
Set IDN and OPT to default	
Emulation mode	406
Set to default	129, 141, 164
Set up remote control	
GPIB	440
Settings	
Active connections	406
ALC	215, 217
AM	88
Attenuator	211
Automatic level control	215
Check front panel	794
Delayed adjustment	788
Display	340
Instrument emulations	405
Internal adjustments	786
Keyboard	340
Licenses	351
List mode	198
Managing	305
NRP power viewer	236
NRP sensor mapping	232
On power-on	342
Phase	76
Protection	361
Remote access	396
RF level	72
SCPI export	446
Security	362
UCOR	220
Undo/Redo	376
User key	348
Setup	
Accept security settings	370
Adjusting display	339
Adjusting keyboard	339
Annotation frequency	365
Annotation level	366
Change password	372
Change password (security)	372
Confirm password	371
Confirm password (security)	372
Display lock	366
Enter password (security)	370
GUI update	339
Keyboard settings	340
Layout (keyboard)	341
New password	371
New password (security)	372
Old password (security)	372
Password (protection)	362
Performing the front panel test	795
Protection level	362
Screen saver	341
Secure update policy	363
Security password	372
USB storage (security)	364
User name (security)	371

User password 371
 Wait time 341
 Setup files
 Data exchange 332
 Setup key 339
 Shape
 LF generator 112
 LF output 112
 Period 114
 Pulse duty cycle 114
 Pulse width 114
 Sweep 188
 Trapeze high 115
 Trapezoid rise, fall 115
 Triangle rise 115
 Shortcut to a network drives
 How to 325
 Show
 SCPI list 316
 Show file content
 SCPI export 447
 Show SCPI command 445
 Close 445
 Copy 445
 Signal output
 LF 118
 Signal source
 Analog modulation 79
 Single
 Execute (list mode) 201
 Single trigger
 Chirp modulation 95
 SMB (Samba)
 LAN services 368
 Socket
 Visa resource string 403
 Softkey bar
 See Taskbar 54
 Source
 AM, FM, Φ M 85
 Analog modulation 79
 LF output 119, 122
 Power sensors 239
 Pulse modulation 83
 Reference oscillator 293
 Sweep trigger 186
 Source subsystem
 Remote control commands 582
 Spacing
 Frequency sweep 189, 192
 RF frequency / level sweep 189, 192
 RF level sweep 194
 Span
 Frequency sweep 192
 SRE 389
 SRE (service request enable register) 392
 SRQ 807
 SRQ (service request) 392, 394
 SSH
 LAN services 368
 Standard settings 129, 141, 164
 Standby 35
 Start
 Frequency sweep 191
 Power analysis 246
 RF level sweep 193

State
 ADF 129, 141, 164
 Adjustment (reference oscillator) 296
 AM, FM, Φ iM 85
 Automatic level control 216
 Chirp modulation 93
 Clock synthesis 302
 DC offset 303
 ILS 129, 141, 164
 LF frequency sweep 112, 186
 List mode 199
 Power sensors 238
 Pulse generator output 102
 Pulse modulation 83
 RF frequency / level sweep 186
 RF frequency sweep 185
 RF level sweep 186
 RF output 63
 RF output protection 213
 Screen saver 341
 UCOR 221
 Undo/Redo 376
 VOR 129, 141, 164
 Status
 Queries 395
 Status bar
 Display 54
 Status byte
 Remote 464, 467
 Status byte (STB) 392
 Status information 353
 Status register
 Response format deinition 504
 Status registers 389
 CONDition 391
 ENABLE 391
 EVENT 391
 Model 390
 NTRansition 391
 Parts 390
 PTRansition 391
 Status reporting system 388
 Application 394
 Common commands 463
 Status settings
 LXI 419
 STB 389
 Step
 Frequency sweep 192
 Linear (frequency sweep) 192
 Logarithmic (frequency sweep) 192
 RF level sweep 194
 Step attenuator below 20 GHz
 Attenuator settings 212
 Step count
 Combined RF frequency / level sweep 194
 Step width
 User variation 71, 76, 304
 Stop
 Frequency sweep 191
 Power analysis 246
 RF level sweep 193
 Stop bits
 RS232 interface 404
 Stop connector 42
 Storage 785

Storage location	
/usb/	305
/var/user	305
/var/volatile	305
Mass memory	469
Subnet mask	400
Subsystem	
AM	584
CHIRp	590
FM	594
Keyboard	510
Phase	703
PM	599
Power	704
PULM	603
Pulse generator	701
Support	781
Sweep	
Center frequency	191
Current frequency	186
Current level	186
Dwell time	189
Execute single	190
Frequency span	192
Level range	195
Mode	186
Reset	190
Retrace	187
Shape	188
Spacing	189, 192, 194
Start/stop frequency	191
Start/stop level	193
State (LF frequency)	112, 186
State (RF combined)	186
State (RF frequency)	185
State (RF level)	186
Step	192, 194
Trigger manually	190
Sweep time	
RF sweep	189
Sweep type	
Frequency sweep	185, 196
Switching	
On or off	31
Synchronization bandwidth	
Reference oscillator	294
Synthesizer	
PLL bandwidth	71
System	
Factory preset	311
System bandwidth	
Noise level (absolute)	120
Noise level (relative)	120

T

Tab labels	55
Temperature offset	
Internal adjustments	787
Temporary files	306, 313
Test	
Check front panel	795
Text entry	57
Threshold	
Pulse modulation	110
Tile diagram	
Display	54

Time	
UTC	792
Time protocol	
Settings	793
Timeout	
Filter (power sensors)	241
Tooltips	
Show	59
Touchscreen	34
Compared with mouse	52
Usage	52
Touchscreen test	
Perform	796
Trace	
Power analysis	246
Trace indication	
Power analysis	248
Trace reference settings	
Power analysis	249
Trace settings	
Power analysis	248, 262
Traces	
Power analysis	246
Tracing	
Messages	441
SCPI commands	441
Transition	
PULM	84
Pulse modulation	84
Trapezoid	
High (LF generator)	115
Rise, fall	115
Triangle	
Rise	115
Trigger	
Event (remote)	467
Execute (list mode)	201
Power Sensors	269
Sweep, manually	190
Trigger mode	
Chirp modulation	95
Trigger source	
List mode	200
Sweep	186
Tripped	
RF output protection	213
Type	
AM	89

U

UCOR	
About	218
Data	222
Display correction file data	222
Display correction value	221
Edit data	222
Export user data	108, 204, 229
File catalog	222
File settings, import/export	107, 203, 228
Fill with sensor	226
Import/export	107, 202, 203, 228
Load from file	108, 203, 229
RF signal	218
Select file	222
Settings	220

- State 221
- Values, defining 206, 224
- Undo 375
 - Clear history 376
 - History 376
 - Settings 376
 - State 376
- Unpacking the instrument 23
- USB
 - Interfaces 383
 - Resource string 384
 - Storage (security) 364
 - Visa resource string 403
- Use default aperture time
 - Power sensors 241
- User correction
 - see UCOR 218
- User data
 - Access 318
 - Load from a specific directory 471
- User files 305
- User interface
 - Lock 366
- User key 344
 - Action name 348
 - Add, change, delete action 349
 - Assign actions 350
 - Define action 348, 349
 - SCPI command 349
 - Select dialog ID 349
 - Settings 348
 - Toggle between define and execute mode 349
- User manual 21
- User menu 344
 - Access 346
 - Clear 345
 - Create 346
 - Recall 345
 - Save 345
 - Settings 345
- User name
 - Setup (security) 371
- User password
 - Security 371
 - Setup 371
- User preset 310
- User variation
 - Activating 71, 76, 304
 - Clock synthesis 304
 - Level 71, 76
 - RF 71, 76
- User-definable preset
 - Recall 345
- Utility keys
 - Overview 34

V

- V/GHz
 - Frequency sweep 196
- V/GHz X-Axis connector 42
- Variable reference frequency 294
- Varying
 - RF frequency and level 71, 76
- Version
 - Firmware 778
- Videos 22

- VISA 381
 - Resource string 382
- Visa resource string
 - Ethernet 402
 - GPIO 403
 - HISLIP 402
 - Serial 403
 - Socket 403
 - USB 403
 - VXI11 402
- Visa resource strings 402
- VNC
 - LAN services 368
 - Using in a LAN 61
- Volatile memory 306, 313
- Volatile mode
 - Activate 364
- VOR
 - About 126
 - COM/ID settings 134
 - General settings 128
 - Position settings 133
 - Signal settings 131
- VOR COM/ID
 - Code 134
 - Dash length 135
 - Depth 135
 - Dot length 135
 - Frequency 135
 - Letter space 136
 - Period 135
 - State 134
 - Symbol space 136
 - Time schema 135
- VOR position
 - Bearing angle 133
 - Direction 133
- VOR signal
 - Mode 131
 - REF deviation 132
 - Subcarrier depth 132
 - Subcarrier frequency 132
 - VAR depth 132
 - VAR/REF frequency 132
- VXI11
 - Visa resource string 402

W

- Wait
 - Remote 467
- Wait time
 - Screen saver 341
- Warnings 770, 773
- What's new 20
- White papers 22
- Wi-Fi
 - WLAN 455
- Width
 - Double pulse (PULM) 102
 - PULM 101
 - Pulse modulation 101
- Workgroup name 400

X

X-Axis	
Frequency sweep	196

Y

y-axis	
Power analysis	260

Z

Z-Axis connector	42
Zero	
Power Sensors	238
Zero - Power Sensors	534
Zeroconf	
IP address	775
Zeroconf (Avahi) protocol	427
Zoom In/Out	
Pulse graph	109
Zoom position	
Pulse graph	109
Zooming	
Pulse graph	109