

# CTP10

## Component Test Platform



## Copyright Information

Copyright © 2018–2021 EXFO Inc. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, be it electronically, mechanically, or by any other means such as photocopying, recording or otherwise, without the prior written permission of EXFO Inc.(EXFO).

Information provided by EXFO is believed to be accurate and reliable. However, no responsibility is assumed by EXFO for its use nor for any infringements of patents or other rights of third parties that may result from its use. No license is granted by implication or otherwise under any patent rights of EXFO.

EXFO's Commerce And Government Entities (CAGE) code under the North Atlantic Treaty Organization (NATO) is 0L8C3.

The information contained in this publication is subject to change without notice.

### ***Trademarks***

EXFO's trademarks have been identified as such. However, the presence or absence of such identification does not affect the legal status of any trademark.

### ***Units of Measurement***

Units of measurement in this publication conform to SI standards and practices.

### ***Patents***

The exhaustive list of patents is available at [www.EXFO.com/patent](http://www.EXFO.com/patent).

Version number: 9.0.0.1

Information in this document applies to the CTP10 embedded software package version 2.4.x.x

# Contents

Copyright Information .....	ii
Regulatory Information .....	vi
<b>1 Introducing the CTP10 .....</b>	<b>1</b>
Technical Specifications .....	3
CTP10 Mainframe Overview .....	7
CTP10 Modules Overview .....	13
CTP10 Graphical User Interface Overview .....	20
Conventions .....	21
Abbreviations Used .....	23
<b>2 Safety Information .....</b>	<b>25</b>
Other Safety Symbols on Your Unit .....	26
Optical Safety Information .....	26
Electrical Safety Information .....	27
<b>3 Getting Started with Your CTP10 .....</b>	<b>29</b>
Unpacking and Installing the CTP10 .....	29
Installing FOA on Detectors .....	32
Handling CTP10 Modules Into the CTP10 Mainframe .....	33
Connecting the CTP10 to a Power Source .....	38
Connecting and Configuring External Screens to the CTP10 .....	39
Connecting a Mouse and Keyboard to the CTP10 .....	43
Turning on the CTP10 and Accessing the GUI .....	44
Updating the CTP10 System Version .....	46
Updating the Operating System Version .....	48
Turning off the CTP10 .....	49
<b>4 Setting Up Your CTP10 .....</b>	<b>51</b>
Defining the GUI Colors .....	51
Setting the Date and Time .....	52
Connecting the CTP10 to your Company Network .....	53
Renaming the Instrument .....	54
Installing Your Test Setup .....	55
<b>5 Operating CTP10 Modules .....</b>	<b>65</b>
Displaying Information on Modules .....	66
Controlling the IL RL OPM2 Module .....	67
Controlling the IL PDL or IL PDL OPM2 Module .....	72
Controlling the SCAN SYNC Module .....	78
Controlling OPMx Modules .....	79
Controlling the FBC Module .....	81
Triggering Power Level Data Acquisition .....	82
Zeroing the Dark Current on Detectors .....	84
Restoring the Factory Settings of a Module .....	85
Updating a Module System Version .....	86
<b>6 Defining and Controlling Your Laser(s) .....</b>	<b>87</b>
Adding and Connecting the Laser(s) .....	87
Controlling the Lasers .....	91
Controlling the Laser Output .....	93
Sharing the Lasers with Several CTP10s .....	94

<b>7</b>	<b>Defining Your Subsystem .....</b>	<b>99</b>
	Creating a Subsystem .....	100
	Setting up Your Subsystem .....	101
	Using Additional OPMs (Daisy Chaining mode) .....	107
	Handling Subsystem Data .....	112
	Defining Subsystem Spectral and Power Units .....	113
<b>8</b>	<b>Performing Measurement Scans .....</b>	<b>115</b>
	Defining the Scan Parameters .....	115
	Referencing the Subsystem .....	123
	Selecting the Traces to Acquire .....	129
	Performing Acquisition Scans .....	133
	Retrieving Raw TF Data from a Detector .....	136
	Generating Output Trigger Signals .....	137
	Generating Output Analog Signals .....	141
<b>9</b>	<b>Displaying and Handling Traces .....</b>	<b>143</b>
	Handling Traces Displayed on Graph .....	143
	Saving/Loading Traces .....	145
	Adjusting the Graph Display .....	148
	Displaying Coordinates of Sampling Points .....	151
	Performing Manual Measurements With Markers .....	152
<b>10</b>	<b>Analyzing Traces .....</b>	<b>155</b>
	Configuring and Starting the Trace Analysis .....	156
	Setting up Peak Trough Search Analysis .....	159
	Selecting the Component Under Test (Component Selector) .....	161
	Setting Up Channel Detection .....	162
	Setting up PDL Analysis .....	167
	Setting up Spectral Width 1/2/3 Analysis .....	169
	Setting up Notch Width 1/2/3 Analysis .....	175
	Setting Up Pass Band Test Analysis .....	178
	Setting Up Stop Band Test Analysis .....	184
	Setting Up WDM Filter Test Analysis .....	190
	Setting Up Loss Measurement Analysis .....	192
	Saving Analysis Results .....	192
<b>11</b>	<b>Handling Files and User Data .....</b>	<b>193</b>
	Connecting/Disconnecting USB Storage Devices .....	193
	Adding/Removing a Network Drive .....	194
	Opening a File from the File Explorer .....	195
	Handling Folders and Files .....	196
	Deleting all User Data from the CTP10 Internal Drive .....	197
	Restoring Factory Settings .....	197
<b>12</b>	<b>Remotely Controlling the CTP10 .....</b>	<b>199</b>
	Setting the Communication Port .....	199
	Entering/Exiting the Remote Mode .....	201
	Communication Principle .....	202
	Writing Remote Control Code .....	209
<b>13</b>	<b>Maintenance .....</b>	<b>213</b>
	Cleaning the CTP10 .....	213
	Cleaning Optical Connectors .....	216
	Replacing Fuses .....	220
	Carrying the CTP10 .....	221
	Recalibrating the SCAN SYNC Module .....	221
	Recycling and Disposal .....	221



---

<b>14 Troubleshooting .....</b>	<b>223</b>
Solving Common Problems .....	223
Abruptly Turning off the CTP10 (Emergency Shutdown) .....	226
Using Assistance Tools .....	227
Viewing System Information .....	228
Displaying the User Documentation .....	229
Contacting the Technical Support Group .....	230
Transportation .....	230
<b>15 Warranty .....</b>	<b>231</b>
General Information .....	231
Gray Market and Gray Market Products .....	231
Liability .....	232
Exclusions .....	232
Certification .....	232
Service and Repairs .....	233
EXFO Service Centers Worldwide .....	234
<b>A IEEE 488.2 and SCPI Command Reference .....</b>	<b>235</b>
IEEE 488.2 Commands .....	235
CTP10 Specific Commands .....	245
<b>B SCPI-Based Errors .....</b>	<b>535</b>

## Regulatory Information

### Canada and USA Electromagnetic Interference Regulatory Statement

Electronic test and measurement equipment is exempt from FCC part 15, subpart B compliance in the United States of America and from ICES-003 compliance in Canada. However, EXFO Inc. makes reasonable efforts to ensure compliance to the applicable standards.

The limits set by these standards are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the user documentation, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

### European Electromagnetic Compatibility Regulatory Statement

Warning: This is a class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures. Your product is compliant with industrial electromagnetic environments.

### European Declaration of Conformity

The full text of the EU declaration of conformity is available at the following Internet address: [www.exfo.com/en/resources/legal-documentation](http://www.exfo.com/en/resources/legal-documentation).

# 1 **Introducing the CTP10**

The CTP10 is a modular measurement platform designed for passive component testing. It is composed of the following elements:

## ➤ **The CTP10 mainframe**

The CTP10 mainframe contains 10 module slots that can host up to ten pluggable measurement modules for passive component testing.

The CTP10 mainframe presentation is available in *CTP10 Mainframe Overview* on page 7.

The mainframe's CPU embedded software enables you to configure and control all system operations and all plugged modules individually, through the graphical user interface (GUI). You can also control external lasers connected to the mainframe.

The presentation of the CTP10 GUI is available in *CTP10 Graphical User Interface Overview* on page 20.

## ➤ **The CTP10 modules**

The following modules are available to perform IL, RL or PDL measurements:


- IL RL OPM2: insertion loss and return loss measurement system with two optical detectors.
- IL PDL: insertion loss and polarization dependent loss measurement system over the CL band.
- IL PDL OPM2: insertion loss and polarization dependent loss measurement system over 1260-1620 nm, with two optical detectors.
- SCAN SYNC: optical sampling of swept wavelength lasers.
- OPMx: optical detectors (x= 2; 4 or 6 detectors per unit).
- FBC: full band combiner, to use up to four sweeping laser sources for full-band DUT characterization.

The presentation of CTP10 modules is available in *CTP10 Modules Overview* on page 13.

### Typical Test Setup

The following figure illustrates a typical IL/RL test setup using the CTP10 platform with T100S-HP lasers. To operate, the CTP10 requires one IL RL OPM2 module and a SCAN SYNC module. Full band operation is obtained by adding an FBC module.

More examples of typical setups are available in *Installing Your Test Setup* on page 55.



## Technical Specifications

This section describes the CTP10 technical specifications and requirements:

- *Optical Measurement Specifications* on page 3
- *Hardware Specifications* on page 5
- *TLS Requirements* on page 6
- *CTP10 Module Compatibilities* on page 6

### Optical Measurement Specifications



#### IMPORTANT

The following technical specifications can change without notice. The information presented in this section is provided as a reference only. To obtain this product's most recent technical specifications, visit the EXFO Web site at [www.exfo.com](http://www.exfo.com).

Optical Measurement <sup>a</sup>			with IL PDL module	with IL PDL OPM2 module	with IL RL OPM2 module
Wavelength	Specified wavelength range		1510–1620 nm	1260–1620 nm	1250–1630 nm
	Operating wavelength range <sup>b</sup>		1440–1640 nm	1240–1680 nm	
	Absolute wavelength uncertainty (typ.)		±5 pm		
	Wavelength repeatability (typ.) <sup>c</sup>		±1 pm		
	Wavelength display resolution		1 pm to 250 pm		
Optical detectors	Sensor type		InGaAs		
	Compatible fiber type		SMF28		
	Compatible optical adapters		FC or SC connectors		
	Maximum safe power		+11 dBm		
	Optical power acquisition resolution		< 0.0001 dB		
	Averaging time		Manual: 1 μs to 1 s / Automatic		
	Return loss (typical)		> 56 dB		
Optical interfaces	Optical connectors		FC type		
	Maximum safe power	TLS IN	+15 dBm		
		SCAN SYNC	+14 dBm		

## Introducing the CTP10

### Technical Specifications

Optical Measurement <sup>a</sup>		with IL PDL module	with IL PDL OPM2 module	with IL RL OPM2 module
<b>Insertion loss<sup>d</sup></b>	Dynamic range (typical at 10 nm/s)	> 80 dB		
	Dynamic range (typical at 100 nm/s)	> 70 dB		
	Insertion loss uncertainty (typical at 10 nm/s) <sup>e</sup>	±0.005 dB		
	Noise 2 σ (typical at 10 nm/s)	0 dB to 20 dB: ± 0.005 dB 20 dB to 40 dB: ± 0.005 dB 40 dB to 50 dB: ± 0.010 dB 50 dB to 60 dB: ± 0.035 dB		
	Noise 2 σ (typical at 100 nm/s)	0 dB to 20 dB: ± 0.005 dB 20 dB to 40 dB: ± 0.01 dB 40 dB to 50 dB: ± 0.05 dB 50 dB to 60 dB: ± 0.400 dB		
<b>Polarization dependent loss</b>	PDL measurement method	4-states Mueller		n/a
	PDL uncertainty (typical at 100 nm/s) <sup>f</sup>	±0.06 dB + 2% PDL	±0.06 dB + 1% PDL <sup>g</sup>	n/a
<b>Return loss</b>	Dynamic range (typical at 10 nm/s)	n/a		>55 dB
	Return loss uncertainty (typical) <sup>h</sup>	n/a		±0.5 dB
<b>Swept measurement</b>	Measurable power variation (typical) <sup>i</sup>	>10,000 dB/nm at 100 nm/s		
	Optimum tunable laser sweep speed range	10 nm/s to 100 nm/s		

- After a 1-hour warm-up time (for the CTP10 mainframe and modules), at a constant temperature of 23 °C +/-1 °C, SMF28 patchcord, FC/APC connector, T100S-HP laser used with SCAN SYNC module, unless otherwise specified.
- When using the SCAN SYNC module, the first and last 2.5 nm of the laser(s) wavelength scanning range are not usable.
- Over one minute, within optimum tunable laser sweep speed range and with laser optical power +10 dBm.
- Wavelength range: 1250 nm–1630 nm, tunable laser power +10 dBm, after zeroing of optical detector, averaging time set to Automatic.
- For IL <20 dB, after power referencing, not including connector uncertainty, degree of polarization < 5%.
- For PDL <2 dB and IL <20 dB; 10 dBm TLS, auto avg. time, FC/PC connector to OPM.  
Higher PDL values can be displayed depending on measurement conditions.
- ±0.04 dB + 1% PDL over spectral range 1490 nm–1620 nm.
- For RL < 40 dB, degree of polarization < 5%.
- For IL < 45 dB, tunable laser power +10 dBm.

## Hardware Specifications

Hardware			
<b>Interfaces for External Devices</b>	HDMI + Displayport (x2)		Screens (2 active at a time) to display the CTP10 GUI. GUI optimized for 1920x1080 (16:9 ratio) screen resolution (recommended resolution)
	USB-A 2.0 (x5)		Devices such as mouse, keyboard, hard disk, GPIB-USB converter...
	USB-A 3.0 (x2)		
	Maximum cable length		3 m (9.8 ft)
<b>Remote Interfaces</b>	Ethernet	RJ45 (x1)	1 Gbit/s (max.) A shielded Ethernet cable is required.
	GPIB (optional)	IEEE 488 (x1)	7.2 Mbit/s (max.)
	USB	USB-B (x1)	300 Mbit/s (max.)
	Maximum cable length (GPIB & USB)		3 m (9.8 ft)
<b>Data Storage</b>	Internal hard drive		HDD, 1.75 TB available
<b>Electrical Interfaces</b>	In (BNC)	Trig in (x8)	5 V TTL (1 MHz max.) <ul style="list-style-type: none"> <li>➤ High level: &gt;2 V</li> <li>➤ Low level: &lt;0.8 V</li> <li>➤ Input maximum range: 0–5.5 V</li> <li>➤ Hold function (actual state held when unplugged)</li> </ul>
		Sync in (x1)	5 V TTL (10 MHz typ.) (hardware ready, reserved for future use).
		Interlock (x1)	5 V TTL (hardware ready, reserved for future use)
	Out (BNC)	Trig out (x4)	5 V TTL (1 MHz max.) <ul style="list-style-type: none"> <li>➤ High level: 4 V typ. on high-impedance load (&gt; 10 kΩ)</li> <li>➤ Low level: 0 to 0.5 V on high-impedance load (&gt; 10 kΩ)</li> <li>➤ Source resistance: 50 Ω</li> </ul>
		Sync out (x1)	5 V TTL (10 MHz typ.) (hardware ready, reserved for future use).
		Analog out (x2)	0-5 V Source resistance: 450 Ω
	Maximum cable length		10 m (32.8 ft)
<b>Electrical Specifications</b>	Input power		see <i>Electrical Safety Information</i> on page 27.
	Fuses (x2)		T4AH250V
	Maximum power consumption		300 W
<b>Physical Specifications</b>	Dimensions (H x W x D)		178 mm x 482 mm x 435 mm (7 in x 19 in x 17 in) 4U full rack with rackmount fixtures
	Weight	Mainframe	8.5 kg (18.7 lb)
		Module	1 to 2.8 kg (2.2 lb to 6.2 lb)

### TLS Requirements

Supported TLS are:

- EXFO T100S-HP
- VIAVI mSWS-A1SLS

The CTP10 is expected to work with TLS sweeping sources having the following performances:

- No mode hops during the wavelength scan.  
If a mode hop is detected during the scan, no correction is applied and a warning is issued.
- Speed between 5 nm/s and 1000 nm/s.  
For sweep speed under 5 nm/s, an inaccuracy may appear on the wavelength value in the area of this low speed, so speed below 5 nm/s is not available.
- Multiple lasers: overlap of 5 nm.  
For continuous traces, specified wavelength limits of multiple TLS (physical characteristics) must overlap by at least 5 nm: the maximum wavelength limit of a laser must overlap by 5 nm the minimum wavelength limit of the next laser.
- TLS with PMF output fiber type for use with the IL PDL and IL PDL OPM2 modules.

### CTP10 Module Compatibilities

The following table details the CTP10 module compatibilities with CTP10 specific modes:

		IL RL OPM2	IL PDL OPM2	IL PDL
Supported modules	SCAN SYNC (mandatory module)	✓	✓	✓
	FBC	✓	✗	✗
	FBC with M option	✓	✓	✗
	OPM2	✓	✓	✓
	OPM4	✓	✓	✓
	OPM6	✓	✓	✓
Supported CTP10 modes	Standalone	✓	✓	✓
	Daisy Chaining	✗	✓	✓
	Laser Sharing	✓	✗	✓

The Laser sharing mode cannot be used in combination with the Daisy chaining mode. In Laser sharing mode, all CTP10s must be equipped with the same measurement module: IL RL OPM2 module for IL and RL measurements or IL PDL module for IL and PDL measurements.

For more details on Laser sharing, see *Sharing the Lasers with Several CTP10s* on page 94. For more details on Daisy chaining, see *Using Additional OPMs (Daisy Chaining mode)* on page 107.




## CTP10 Mainframe Overview

The CTP10 is delivered with the following accessories:

- 1 power supply cable
- Cover plates for empty module slots
- 1 manual *Getting Started with CTP10*
- 1 USB key containing the system package version installed on the CTP10 and the available drivers, examples (if any), reports and user documentation.


### Front panel



#### On/Off button

The On/Off button enables you to turn on or off the CTP10 (see *Turning on the CTP10 and Accessing the GUI* on page 44 and *Turning off the CTP10* on page 49).

#### USB ports (protected by a flap)

The  label identifies the three USB 2.0 type-A ports located on the front panel; they are protected by a flap.

These ports enable you to:

- Connect USB devices such as:
  - A keyboard and mouse if needed
  - A USB key or hard disk to export your measurement results
  - An external multi-touch screen
- Control a laser through an adapter (GPIB, RS232).  
The CTP10 is compatible with National Instrument USB-GPIB adapters.

#### **Status LEDs**

- The green **Ready** LED indicates the startup status of the CTP10:
  - Slow flashing: the GUI software is initializing
  - Fixed: the GUI software is ready to be used
- The **Error** LED lights red for 1 minute if an error or warning occurs:
  - Flashing: a warning occurred.
  - Fixed: an error occurred.

The GUI displays the corresponding message. You can display the last error and warning messages as explained in *Displaying the List of Errors and Warnings* on page 228.


#### **Module slots**

Any CTP10 module can be placed in any of the ten slots (for more details, see *Handling CTP10 Modules Into the CTP10 Mainframe* on page 33).

## Rear panel

The rear panel of the CTP10 contains:

- A complete set of communication ports and interfaces for remote control and export of data. All ports and interfaces are SELV classified (except for the power connector) and must only be connected to interfaces of the same type.
- Two fans for air output.



### External Screen Connectors

The **|O|** label identifies the ports to connect external screens. You can connect two external screens to the following ports:

- **DisplayPort** port (x2)
- **HDMI** port (x2)

For more details on how to configure the external screen settings, see *Connecting and Configuring External Screens to the CTP10* on page 39.

### BNC Connectors

The BNC connectors enable you to synchronize scans or measurements (see *Hardware Specifications* on page 5 for more details on signal levels).

- **TRIG IN (x8):** input BNC connector for starting scan in synchronization with an external trigger input signal, event, sampling strobe or modulation input.

The TRIG IN connectors of the CTP10 can handle the following modes of TTL trigger signals:

- **Sampling trigger:**

In Daisy chaining mode, the signal coming out of the Primary CTP10 (through its TRIG OUT port) enables data sampling on the Secondary CTP10 through its TRIG IN port. For more details, see *Using Additional OPMs (Daisy Chaining mode)* on page 107.

- **Event trigger:**

The external signal triggers an event such as the scan start (see *Triggering the Acquisition* on page 135) or data acquisition (see *Triggering Power Level Data Acquisition* on page 82).



- **Window trigger:**

To output Pulse triggers during the acquisition, the CTP10 needs the electrical trigger from the laser (for more details, see *Generating Pulse Trigger Signals* on page 139).

When unplugged, the trigger holds the actual state of the connector.

- **SYNC IN/OUT:** reserved for future use.
- **ANLG OUT (x2):** BNC analog output connector to send an internal measurement as an analog signal to be displayed on an external analog instrument. For more details, see *Generating Output Analog Signals* on page 141.
- **TRIG OUT (x4):** BNC connector for outputting a trigger signal during scan. For more details, see *Generating Output Trigger Signals* on page 137.  
In Daisy chaining mode, the signal coming out of the Primary CTP10 through its TRIG OUT port enables data sampling on the Secondary CTP10 (through its TRIG IN port). For more details, see *Using Additional OPMs (Daisy Chaining mode)* on page 107.
- **INTERLOCK:** reserved for future use.

### USB-A Ports

The **SS**  label identifies the USB-A 3.0 ports, the  identifies the USB-A 2.0 ports. These ports enable you to:

- Connect USB devices such as:
  - A keyboard and mouse if needed
  - A USB key or hard disk to export your measurement results
  - An external multi-touch screen
- Control a laser through an adapter (GPIB, RS232).  
The CTP10 is compatible with National Instrument USB-GPIB adapters.  
For more details, see *Adding and Connecting the Laser(s)* on page 87.

For more details on USB connections, see *Connecting a Mouse and Keyboard to the CTP10* on page 43 and *Connecting/Disconnecting USB Storage Devices* on page 193.

### **Ethernet Port**

The  label identifies the Ethernet port, which enables you to:

- Connect the CTP10 to your network. For more details, see *Connecting the CTP10 to your Company Network* on page 53.
- Control a laser from the CTP10. For more details, see *Adding and Connecting the Laser(s)* on page 87.
- Perform remote control operations on the CTP10. For more details, see *Remotely Controlling the CTP10* on page 199.

### **GPIB Port (optional)**

This port enables you to perform IEEE 488 remote control operations on the CTP10 (slave mode only). For more details, see *Remotely Controlling the CTP10* on page 199.

### **USB-B 2.0**

This port enables you to perform remote control operations on the CTP10. For more details, see *Remotely Controlling the CTP10* on page 199.

### **Cooling Fans**

The two cooling fans extract warm air from inside (air enters under the CTP10). A cover grid protects the fans.

### **Power Input**

The power input part includes the following elements:

- **Power Switch**
- **Power Cable Connector**

The CTP10 is equipped with a self-regulating power supply.

- **Fuse Drawer**










The fuse drawer contains two fuses to protect the CTP10 from overcurrent (for fuse type, see *Technical Specifications* on page 3).

For details on how to replace the fuses, see *Replacing Fuses* on page 220.

## Introducing the CTP10

### CTP10 Mainframe Overview

#### Labels and Markings

Label	Description
	<p>Identification of the product</p> <p>Indicates serial number, model, options (if any), hardware version (if any) and date of manufacture.</p>
	<p>Manufacturer identification</p> <p>Contact information of the manufacturer.</p>
<p>2x T4AH250V </p>	<p>Fuse type (x2)</p>
 ~ 100 - 240 V; 50/60 Hz; 3 - 1.3 A	<p>Input power requirements: alternating current; input voltage range; frequency range; input current range</p>
	<p>WEEE symbol for recycling:</p> <p>See <i>Recycling and Disposal</i> on page 221.</p>
	<p>Safety certification label.</p>
	<p>EFUP label (RoHS China)</p> <p>The CTP10 has an environment friendly use period of 10 years.</p>
	<p>Windows license label</p> <p>The CTP10 embeds Windows 10.</p>
	<p>Warranty seal</p> <p>The CTP10 cover must not be open, otherwise the warranty is not valid anymore.</p>

## CTP10 Modules Overview


The CTP10 available modules are:

- *IL RL OPM2 Module* on page 13
- *IL PDL Module* on page 15
- *IL PDL OPM2 Module* on page 16
- *SCAN SYNC Module* on page 17
- *OPMx Modules* on page 18
- *FBC Module* on page 19

### IL RL OPM2 Module

The IL RL OPM2 module is an insertion loss and return loss measurement system with one laser input linked to two outputs and two optical detectors.

You cannot use the IL RL OPM2 module in combination with an IL PDL or IL PDL OPM2 module in a single mainframe. To perform proper measurements with the IL RL OPM2 module, do not insert an IL PDL or IL PDL OPM2 module in the same mainframe.



#### **Optical Connectors**

##### ➤ **Detectors**

The **IN1** and **IN2** connectors are optical detector inputs to connect the devices under test (DUT) for power measurement.

##### ➤ **Laser input**

The **TLS IN** is a laser input port to connect the tunable laser source that you want the CTP10 to control, or the FBC OUT port of the FBC module if you want to use several laser sources.

Early versions of the IL RL OPM2 module had two laser inputs (**TLS IN1** and **TLS IN2**). Only the **TLS IN1** input is available for use.

##### ➤ **Output ports**

The **OUT TO SCAN SYNC** (**OUT1** on earlier version) and **OUT TO DUT** (**OUT2** on earlier version) are signal outputs to connect a DUT and the SCAN SYNC module (for more details, see *Installing Your Test Setup* on page 55).

➤ **OUT TO SCAN SYNC** (**OUT1** on earlier version): APC connector (PC connector on earlier version) that enables optical sampling by being connected to the SCAN SYNC module.

➤ **OUT TO DUT** (**OUT2** on earlier version): APC connector that enables transfer function (TF) and back reflection (BR) measurement by being connected to a DUT.

#### **Insert/Extractor handle**

The module handle enables you to lock or unlock the module into the mainframe slot.


For more details, see *Handling CTP10 Modules Into the CTP10 Mainframe* on page 33.



## IL PDL Module

The IL PDL module is a double-slot module for insertion loss and polarization dependent loss measurements, with one laser input linked to two outputs.

You cannot use the IL PDL module in combination with an IL RL OPM2 or IL PDL OPM2 module in a single mainframe. To perform proper measurements with the IL PDL module, do not insert an IL RL OPM2 or IL PDL OPM2 module in the same mainframe.



### Optical Connectors

#### ► Output ports

The **OUT TO SCAN SYNC** and **OUT TO DUT** are signal outputs to connect a SCAN SYNC and a DUT (for more details, see *Installing Your Test Setup* on page 55).

- **OUT TO SCAN SYNC:** APC connector that enables optical sampling by being connected to the SCAN SYNC module.
- **OUT TO DUT:** APC connector that enables transfer function (TF) and polarization dependent loss (PDL) measurements over the CL band by being connected to a DUT.

#### ► Laser input

The **TLS IN (PM)** is a laser input port to connect the tunable laser source that you want the CTP10 to control.

### Inserter/Extractor handle


The module handle enables you to lock or unlock the module into the mainframe slot.

For more details, see *Handling CTP10 Modules Into the CTP10 Mainframe* on page 33.

## IL PDL OPM2 Module

The IL PDL OPM2 module is a double-slot module for insertion loss and polarization dependent loss measurements, with one laser input linked to two outputs and two optical detectors.

You cannot use the IL PDL OPM2 module in combination with an IL RL OPM2 or IL PDL module in a single mainframe. To perform proper measurements with the IL PDL OPM2 module, do not insert an IL RL OPM2 or IL PDL module in the same mainframe.



### Optical Connectors

#### ► Laser input

The **TLS IN (PM)** is a laser input port to connect the tunable laser source that you want the CTP10 to control, or the FBC OUT port of the FBC module (with M option) if you want to use several laser sources.

#### ► Output ports

The **OUT TO SCAN SYNC** and **OUT TO DUT** are signal outputs to connect a SCAN SYNC and a DUT (for more details, see *Installing Your Test Setup* on page 55).

- **OUT TO SCAN SYNC:** APC connector that enables optical sampling by being connected to the SCAN SYNC module.
- **OUT TO DUT:** APC connector that enables transfer function (TF) and polarization dependent loss (PDL) measurements over the entire band by being connected to a DUT.

**Insert/Extractor handle**


The module handle enables you to lock or unlock the module into the mainframe slot. For more details, see *Handling CTP10 Modules Into the CTP10 Mainframe* on page 33.

**SCAN SYNC Module**

The SCAN SYNC module is a wavelength scan synchronization module, to use in combination with the IL RL OPM2, IL PDL or IL PDL OPM2 module. It enables you to perform optical sampling of a swept wavelength laser.

It provides high wavelength accuracy and removes the need of electrical triggering of the instrument.

It triggers data acquisition at the frequency given in *Technical Specifications* on page 3.

**Optical Connectors**


The **TLS IN** is a laser input port to connect the **OUT TO SCAN SYNC (or OUT1)** output port of the IL RL OPM2, IL PDL or IL PDL OPM2 module for optical sampling. For more details, see *Installing Your Test Setup* on page 55.

**Insert/Extractor handle**

The module handle enables you to lock or unlock the module into the mainframe slot. For more details, see *Handling CTP10 Modules Into the CTP10 Mainframe* on page 33.

## OPMx Modules

The OPM module is a detection module for power measurement with two, four or six photo-detectors.



### Detector inputs

On all models of OPM, the IN connectors are optical detector inputs to connect the devices under test (DUT) for power measurement.

For more details, see *Installing Your Test Setup* on page 55.

### Inserter/Extractor handle

The module handle enables you to lock or unlock the module into the mainframe slot.


For more details, see *Handling CTP10 Modules Into the CTP10 Mainframe* on page 33.

## FBC Module

The FBC module enables you to connect up to four tunable lasers to the CTP10. It switches between the available laser sources from one port to the next to direct the signal through a common output port so that multiple TLS can be used as a unique full band source.

You cannot use the FBC module with an IL PDL module. The FBC module (any option) is compatible with the IL RL OPM2 module and the FBC with M option is compatible with the IL PDL OPM2 module: see *CTP10 Module Compatibilities* on page 6.

The FBC with M option must be used with PM lasers and connected with PM fibers.



### Optical Connectors

#### ► Laser inputs

The **TLS IN1**, **TLS IN2**, **TLS IN3**, and **TLS IN4** are laser input ports to connect the tunable laser sources that you want the CTP10 to control.

If you use an FBC with M option, the lasers must be PM and connected to the module with PM fibers.

#### ► Output port

**FBC OUT** is the signal output port to connect to the **TLS IN** port of the IL RL OPM2 or IL PDL OPM2 module for measurements (for more details, see *Installing Your Test Setup* on page 55). The FBC module is not compatible with the IL PDL module.

If you use an FBC with M option in combination with an IL PDL OPM2, the FBC to the **TLS IN** port of the IL PDL OPM2 module with a PM fiber.

### Inserter/Extractor handle

The module handle enables you to lock or unlock the module into the mainframe slot.

For more details, see *Handling CTP10 Modules Into the CTP10 Mainframe* on page 33.

### CTP10 Graphical User Interface Overview


The CTP10 GUI has two main windows:

- The **Modules and Lasers** window for static measurement and control of the CTP10 modules and connected lasers: see *Modules and Lasers Window* on page 20.
- The **Subsystem** window for dynamic measurement: scanning of transfer function (TF) and back reflection (BR): see *Subsystem Window* on page 21.

### Modules and Lasers Window

The upper part of the **Modules and Lasers** window displays all the modules plugged into the CTP10, with their related information and measured values. From this window, you can control and monitor the modules individually: for more details, see *Operating CTP10 Modules* on page 65.

The lower part of the **Modules and Lasers** window enables you to add, configure and control the lasers connected to the CTP10: for more details, see *Defining and Controlling Your Laser(s)* on page 87.



## Subsystem Window

The **Subsystem** window enables you to perform dynamic TF, BR or PDL measurements using modules and instruments connected to the CTP10.

This window enables you to:

- Configure your test setup by graphically connecting all instruments: for more details, see *Defining Your Subsystem* on page 99.
- Define and start scanning operation: for more details, see *Performing Measurement Scans* on page 115.
- Display and handle the scan traces: for more details, see *Displaying and Handling Traces* on page 143.
- Analyze measurement traces: for more details, see *Analyzing Traces* on page 155.



## Conventions

Before using the product described in this guide, you should understand the following conventions:



### **WARNING**

Indicates a potentially hazardous situation which, if not avoided, could result in *death or serious injury*. Do not proceed unless you understand and meet the required conditions.



### **CAUTION**

Indicates a potentially hazardous situation which, if not avoided, may result in *minor or moderate injury*. Do not proceed unless you understand and meet the required conditions.



### **CAUTION**

Indicates a potentially hazardous situation which, if not avoided, may result in *component damage*. Do not proceed unless you understand and meet the required conditions.



### **IMPORTANT**

Refers to information about this product you should not overlook.



## Abbreviations Used

Abbreviation	Meaning
AC	alternating current
APC	angled physical contact
BR	back reflection
CPU	central processing unit
CTP	component test platform
CW	continuous wave
DP	DisplayPort
DUT	device under test
FOA	fiber optic adapter
GPIB	general purpose interface bus
GUI	graphical user interface
IL	insertion loss
LAN	local area network
PC	physical contact
PDL	polarization dependent loss
PM	polarization maintaining
PSG	polarization state generator
RL	return loss
RMS	root mean square
SCPI	standard commands for programmable instruments
SELV	safety extra-low voltage
SOP	state of polarization
TF	transfer function
WEEE	waste electrical and electronic equipment



## 2 **Safety Information**



### **WARNING**

Do not install or terminate fibers while a light source is active. Never look directly into a live fiber and ensure that your eyes are protected at all times.



### **WARNING**

The use of controls, adjustments and procedures, namely for operation and maintenance, other than those specified herein may result in hazardous radiation exposure or impair the protection provided by this unit.



### **WARNING**

If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.



### **WARNING**

Use only accessories designed for your unit and approved by EXFO. For a complete list of accessories available for your unit, refer to its technical specifications or contact EXFO.




### **IMPORTANT**

Refer to the documentation provided by the manufacturers of any accessories used with your EXFO product. It may contain environmental and/or operating conditions limiting their use.




### **IMPORTANT**

When you see the following symbol on your unit , make sure that you refer to the instructions provided in your user documentation. Ensure that you understand and meet the required conditions before using your product.



### **IMPORTANT**

When you see the following symbol on your unit , it indicates that the unit is equipped with a laser source, or that it can be used with instruments equipped with a laser source. These instruments include, but are not limited to, modules and external optical units.













### **IMPORTANT**

Other safety instructions relevant for your product are located throughout this documentation, depending on the action to perform. Make sure to read them carefully when they apply to your situation.

### Other Safety Symbols on Your Unit

One or more of the following symbols may also appear on your unit.

Symbol	Meaning
	Direct current
	Alternating current
	The unit is equipped with an earth (ground) terminal.
	The unit is equipped with a protective conductor terminal.
	The unit is equipped with a frame or chassis terminal.
	On (Power)
	Off (Power)
 OR 	On/off (Power)
	Fuse

### Optical Safety Information



#### WARNING

- The modules and instruments that you use with your unit may have different laser classes. Refer to their user documentation for exact information.
- Do not install or terminate fibers while a light source is active.
- Never look directly into a live fiber and ensure that your eyes are protected at all times.
- Laser radiation may be encountered at the optical output port.

## Electrical Safety Information

This unit uses an international safety standard three-wire power cable. This cable serves as a ground when connected to an appropriate AC power outlet.



### **WARNING**

- If you need to ensure that the unit is completely turned off, disconnect the power cable.
- Use only the certified power cord that is suitably rated for the country where the unit is used.
- Replacing detachable MAINS supply cords by inadequately RATED cords may result in overheating of the cord and create a risk of fire.

The color coding used in the electric cable depends on the cable. New plugs should meet the local safety requirements and include:

- adequate load-carrying capacity
- ground connection
- cable clamp



### **WARNING**

- Use this unit indoors only.
- Do not remove unit covers during operation.
- Operation of any electrical instrument around flammable gases or fumes constitutes a major safety hazard.
- To avoid electrical shock, do not operate the unit if any part of the outer surface (covers, panels, etc.) is damaged.
- Only authorized personnel should carry out adjustments, maintenance or repair of opened units under voltage. A person qualified in first aid must also be present. Do not replace any components while the power cable is connected.
- Your unit is equipped with an internal replaceable clock battery to keep time and date accurate. Only authorized personnel can replace this battery. Attempting to replace it yourself could seriously compromise your safety.
- Use only fuses with the required rated current and specified type. Do not use repaired fuses or short-circuited fuse holders. For more information, see the section about replacing the fuses in this user documentation.
- Unless otherwise specified, all interfaces are intended for connection to Safety Extra Low Voltage (SELV) circuits only.
- Capacitors inside the unit may be charged even if the unit has been disconnected from its electrical supply.



## CAUTION

Position the unit so that the air can circulate freely around it.

Equipment Ratings		
Temperature	Operation	+5 °C to +40 °C (+41 °F to +104 °F)
	Storage	-20 °C to +65 °C (-4 °F to +149 °F)
Relative humidity <sup>a</sup>		80 % for temperatures up to 31°C decreasing linearly to 50 % relative humidity at 40°C
Maximum operation altitude		2000 m (6562 ft)
Pollution degree		2
Overvoltage category		II
Measurement category		Not rated for measurement categories II, III, or IV
Input power <sup>b</sup>		100–240 V ~ ; 50/60 Hz; 3–1.3 A

a. Measured in 0 °C to 31 °C (32 °F to 87.8 °F) range, decreasing linearly to 50 % at 40 °C (104 °F).

b. Not exceeding  $\pm 10$  % of the nominal voltage.



## CAUTION

- The use of voltages higher than those indicated on the label affixed to your unit may damage the unit.
- The operation and storage temperatures, as well as the altitude and relative humidity values of some modules may differ from those specified for your unit. In this case, always ensure that you comply with the most restrictive conditions (either module or unit).

# 3 Getting Started with Your CTP10

This section explains how to properly install and connect your CTP10 to build a test set-up:

- Unpack and install the CTP10:
  - *Unpacking and Installing the CTP10* on page 29.
  - *Connecting the CTP10 to a Power Source* on page 38.
- Install the CTP10 modules:
  - *Installing FOA on Detectors* on page 32.
  - *Handling CTP10 Modules Into the CTP10 Mainframe* on page 33
- Connect the CTP10 to external instruments:
  - *Connecting and Configuring External Screens to the CTP10* on page 39.
  - *Connecting a Mouse and Keyboard to the CTP10* on page 43.
- Start/stop the CTP10:
  - *Turning on the CTP10 and Accessing the GUI* on page 44.
  - *Turning off the CTP10* on page 49.
- Update the CTP10 system version:
  - *Updating the Operating System Version* on page 48.
  - *Updating the CTP10 System Version* on page 46.

## Unpacking and Installing the CTP10

The CTP10 is designed for indoor use only, and is not dedicated to wet locations. It must be operated under proper environment conditions, as explained in the following procedure.

You can use the CTP10 as a bench-top instrument or you can install it in a 19" rack.



### CAUTION

- Make sure the location where the CTP10 will be installed meets the environmental characteristics listed in *Electrical Safety Information* on page 27.
- Do not install the CTP10 near any source of heat or cold.
- To ensure proper ventilation and cooling, make sure there is sufficient clearance below and at the rear of the CTP10 in the place where it will be installed.

#### To unpack and install the CTP10:

1. Open the package with care and remove the protective foam.



### IMPORTANT

When unpacking, handle the device with care and do not damage the original shipping container in case the CTP10 needs to be returned to EXFO.


2. Pull out the CTP10 vertically from its packaging: hold it by its two retractable handles located on the side panels and keep it horizontal.
3. Do one of the following:

## Getting Started with Your CTP10

### *Unpacking and Installing the CTP10*

---


- To use the CTP10 as a bench-top instrument, set it on a flat stable surface free of excessive vibration.
  - To install the CTP10 in a 19-inch rack, follow the instruction detailed in on page 30.
4. Allow the flow of air to circulate freely under and at the rear of the CTP10 and remove any equipment or paper that could block the air flow. Ventilation holes are located on the bottom and rear sides of the CTP10.
  5. On the rear panel (see *Rear panel* on page 9), make sure the power switch is set to **O**.
  6. To tilt the CTP10 upward (bench-top use only), deploy the two retractable legs located below it, as illustrated in the following figure.





**To Install the CTP10 in a 19-inch rack:**

- 1.** Make sure that:
  - You have a 4U space in your rack
  - You have four rack mounting screws and cage nuts (no rack fastening kit is provided).
  - There is enough empty space underneath the space reserved for the CTP10, to be able to hold it from below.
- 2.** Install 4 cage nuts at the desired height on the rack, as illustrated below:



- 3.** With assistance, lift the CTP10 to its position in the rack by holding it from below.
- 4.** Use the rack mounting screws to attach the CTP10 rack mounting brackets to the front of the rack.


## Installing FOA on Detectors

The fiber optic adapters (FOA) are delivered with your CTP10 modules; you must install them on the detector connectors to be able to use them.



Only use CTP10-specific fiber optic adapters.

### **To install an FOA on a detector:**

1. On the module front panel, use your fingers to unscrew the dust cap from the connector. Keep the dust cap in safe place in case you need to use it to ship the module.



2. Take the FOA (and its protective cap) out of its packaging; do not remove the protective cap from the FOA.
3. Use your fingers to screw the fiber optic adapter (FOA) with its protective cap on the connector.



## Handling CTP10 Modules Into the CTP10 Mainframe

You can install the CTP10 modules in the CTP10 mainframe in any of the available 10 slots and in any combination alongside other types of modules supported by the CTP10.

CTP10 modules are hot-swappable: you do not need to turn off the unit before inserting or removing a module.

- To install/remove a cover plate, see *Removing/Installing a Cover Plate* on page 33
- To install a module, see *Installing a Module Into the CTP10 Mainframe* on page 35
- To remove a module, see *Removing a Module From the CTP10 Mainframe* on page 37

### Removing/Installing a Cover Plate




#### CAUTION

Do not operate the CTP10 mainframe if a slot is left open. Always put back the protection cover plate on an empty slot. Failure to reinstall protective covers over empty slots will result in ventilation problems.

#### **To remove a cover plate from an empty slot:**

1. Loosen the bottom and top captive screws using a slot head or Phillips head (recommended) screwdriver (size #1).
2. Remove the plate.




## Getting Started with Your CTP10

### *Handling CTP10 Modules Into the CTP10 Mainframe*

---

#### ***To install a cover plate on an empty slot:***

Place the cover plate on the empty slot and tighten the top and bottom captive screws of the module using the slot head or Phillips head (recommended) screwdriver (size #1).



## Installing a Module Into the CTP10 Mainframe

This section explains how to install a CTP10 module into an empty slot of the CTP10 mainframe. You cannot connect an other module type in the CTP10 mainframe. All CTP10 modules can be installed in any of the available 10 slots of the CTP10 mainframe and in any combination alongside other types of CTP10 modules.

### Before starting:

- To ensure compatibility between the module and the CTP10 mainframe, please make sure that the latest system version is installed on the mainframe: see *Updating the CTP10 System Version* on page 46.
- Make sure you have a slot head or Phillips head (recommended) screwdriver (size #1).

### To insert a module into the CTP10 mainframe:


1. Unpack the CTP10 module by opening the package with care and remove the CTP10 module from its packaging.



## IMPORTANT

When unpacking, handle the device with care and do not damage the original shipping container in case the module needs to be returned to EXFO.

2. If a cover plate or a module is installed on the slot where you want to install the module, remove it as explained in *Removing/Installing a Cover Plate* on page 33 or *Removing a Module From the CTP10 Mainframe* on page 37.
3. Lower the module inserter/extractor handle as follows: use your thumb to press the grey button and hold the button pressed while you lower the black handle.



4. Hold the module with both hands by its top and bottom edges in front of the open slot to align the top and bottom edges of the module with the slot grooves on the CTP10 chassis, and insert the module into the open slot.


## Getting Started with Your CTP10

### Handling CTP10 Modules Into the CTP10 Mainframe




## CAUTION

To avoid damaging the internal optical components, do not squeeze the module sideplates.



5. Push the module into the slot until the black handle touches the mainframe.
6. Lift the handle up until the grey button clicks into position.



The module is correctly inserted when its front panel is flush with the front panel of the unit. If the module is not properly locked into position, it will not be displayed on the GUI.

7. To secure the module in place, tighten the two captive screws of the module using the appropriate screwdriver.

## Removing a Module From the CTP10 Mainframe

This section explains how to remove a module from the CTP10 mainframe.



Removing a module from the CTP10 mainframe definitely removes it from the subsystem in which it is used. All measurements using the module are immediately stopped.

### **Before starting:**

Make sure you have a slot head or Phillips head (recommended) screwdriver (size #1).


### **To remove a module from the CTP10 mainframe:**

1. On the CTP10 mainframe front panel, loosen the captive screws of the module using the appropriate screwdriver.
2. Put your thumb on the grey button and press it while you lower the black handle.



The module is released from the mainframe slot.

3. Pull the module out by sliding it out from the slot.





#### CAUTION

Pulling out a module by its connectors could seriously damage both the module and connectors. Always pull out a module by its casing.

4. Hold the module with both hands by its top and bottom edges and put it in its original container.
5. Cover the empty slots with the supplied cover plates as explained in *Removing/Installing a Cover Plate* on page 33.



#### CAUTION

Do not operate the CTP10 mainframe if a slot is left open. Always put back the protection cover plate on an empty slot. Failure to reinstall protective covers over empty slots will result in ventilation problems.

## Connecting the CTP10 to a Power Source

The CTP10 has a chassis connected to ground via the power supply cable. A protective ground connection by way of the grounding conductor in the power cable is essential for safe operation.



#### WARNING

- Make sure the wall socket on which the CTP10 will be plugged is protected by a 16 A max circuit breaker.
- Make sure the CTP10 power source does not apply more than 265 Volts RMS between the supply conductors and the ground.
- To avoid the possibility of injury, make sure the socket outlet in which the power supply cable will be plugged is equipped with a protective ground contact, and that the electrical installation fulfills the local safety requirements.

#### **To connect the CTP10 to a wall socket:**

1. Make sure the power switch is set to **O**.
2. On the rear panel, connect the power supply cable provided with the instrument to the mains socket located on the rear panel of the CTP10.
3. Plug the other end of the power supply cable to the proper voltage wall socket outlet (to know the voltage requirement, see *Technical Specifications* on page 3).
4. On the rear panel, set the power switch to **I**.



## Connecting and Configuring External Screens to the CTP10

You must connect at least one external screen to the CTP10 to display the CTP10 GUI and control the instrument (two screens at most).

External screen connectors are all located on the rear panel of the CTP10. For more details, see *Rear panel* on page 9.


### Before starting:

- Make sure the screens you want to connect to the CTP10 meet the requirements detailed in **Interfaces for External Devices** on page 5.
- Make sure the screen you want to connect to the CTP10 can connect to an HDMI port or a DisplayPort directly or through an adapter.
- Make sure you have the appropriate connection cable(s) to connect your external screen.


## Connecting an External Screen to the CTP10

You must connect at least one external screen to the CTP10 to display the CTP10 GUI that enables you to operate the instrument.

### To connect an external screen to the CTP10:

1. Connect the screen to one of the two available display connectors of the **Display 1** group of connectors located on the rear panel of the CTP10 (see *Rear panel* on page 9) with the appropriate cable.
2. Turn on the CTP10 as explained in *Turning on the CTP10 and Accessing the GUI* on page 44.
3. In the CTP10 task bar, click the  button to display the **Settings** window.

The **Display** area enables you to set the screen resolution.



4. In the **Screen 1 resolution** list, set your screen resolution. The recommended value is the screen native resolution.


## Connecting a Secondary Screen to the CTP10




### IMPORTANT

If you want to connect two screens to the CTP10, you must connect one screen to one of the connectors marked as "Display 1" and the other screen to one of the connectors marked as "Display 2". You cannot connect the two screens to the same group of connectors.

#### To connect a second screen to the CTP10

1. Connect the second screen to one of the two available display connectors of the **Display 2** group of connectors (on the rear panel) with the appropriate cable.
2. Turn on the CTP10 as explained in *Turning on the CTP10 and Accessing the GUI* on page 44.
3. In the CTP10 task bar, click the  button to display the **Settings** window.

The **Display** area enables you to set the screen, resolution and position parameters.



4. Click the **Identify screens** button to clearly identify Screen 1 and Screen 2, with their corresponding set resolution.
5. In the **Screen 2 resolution** list, set your second screen resolution. The recommended value is the screen native resolution.

6. In the **Display mode** list, select the wanted mode for your screen(s):
- **Display 1 only:** all windows of the CTP10 GUI are displayed on the same display 1.
  - **Display 2 only:** all windows of the CTP10 GUI are displayed on the same display 2.
  - **Duplicate:** displays the same window on the two different connected screens.
  - **Extend** (default): displays a different window on each connected screen simultaneously. Recommended setting to fully use the two screens simultaneously.

In this case, you can set Screen 1 to Screen 2 and the Screen 2 to Screen 1 by clicking the **Switch screens** button.

7. In the **Secondary screen position** list, select the physical position of your second screen relative to the Screen 1. This enable you to intuitively move the mouse from one screen to another.

**To change screen:**

- To send the window displayed on Screen 1 to Screen 2 (only applies if **Display mode** is set to **Extend** in the **Settings** window):

On the top right of the open window, click the  button.

The window appears on Screen 2, which enables you to open a new window on Screen 1.


- To open a window directly on Screen 2 (if available):

In the task bar, right-click the corresponding window button.


## Configuring a Touchscreen

If your external screen is a touchscreen, you can operate the CTP10 from the connected screen with multi-touch gestures.

### To connect and configure a touchscreen:

1. Connect the USB-B port of your touchscreen to one of the USB-A ports of the CTP10.
2. Turn on the CTP10 as explained in *Turning on the CTP10 and Accessing the GUI* on page 44.
3. In the CTP10 task bar, click the  button.

In the **Settings** window, two buttons in the **Display** area enable you to set the touchscreen parameters.



4. Click the **Touchscreen setup...** button and follow the instructions displayed on screen to clearly identify the touchscreen display.
5. If you detect a problem in the touchscreen accuracy, click the **Touchscreen calibrate...** button to calibrate the touchscreen display.



## IMPORTANT

Before calibrating a touchscreen, make sure to set the screen to its highest resolution to be able to calibrate it properly.

## Connecting a Mouse and Keyboard to the CTP10

To operate the CTP10 GUI, you can connect a USB mouse and keyboard to the USB-A 2.0 and USB-A 3.0 ports located on the front and rear panels of the CTP10 (see *CTP10 Mainframe Overview* on page 7).

### **To connect a mouse and keyboard:**

Do one of the following:


- Connect the USB mouse and keyboard to one of the available USB-A ports of the CTP10 mainframe (you do not need to restart the CTP10).
- Connect one of the screens to the USB-A port of the CTP10 and directly connect the USB mouse and keyboard to the USB-A ports of the screen.

All operations available using the multi-touch screen are also accessible using the mouse and keyboard.


If a keyboard is connected, the Windows keyboard shortcuts Ctrl + C, Ctrl + X and Ctrl + V are only available in text entry areas.

### **To configure your keyboard using the GUI:**

If you connect an external keyboard to the CTP10, you can set the language layout corresponding to the external keyboard you have connected.

1. Turn on the CTP10 as explained in *Turning on the CTP10 and Accessing the GUI* on page 44.
2. In the CTP10 task bar, click the  button to display the **Settings** window.

The **Keyboard** area enables you to switch between QWERTY and AZERTY keyboard.



Date & Time

Set time automatically ☒

Date Jan 22, 2020 Time 16 : 27

Zone (UTC+01:00) Brussels, Copenhagen, Madrid, Paris ▼

Keyboard (external)

Layout French (France) ▼

3. Select the appropriate keyboard in the **Layout** list:

- French (France): AZERTY keyboard
- English (United States): QWERTY keyboard

### **To rapidly switch the keyboard from one language to the other:**

On your keyboard, press Alt + Shift.

### Turning on the CTP10 and Accessing the GUI

At startup, the CTP10 GUI appears on the connected screens. The task bar enables you to access all the CTP10 functions.

#### To access the CTP10 graphical user interface:

1. Make sure the CTP10 is properly installed: see *Unpacking and Installing the CTP10* on page 29.

2. On the CTP10 front panel, press the on/off button (see *Front panel* on page 7).


After a few seconds, the button lights up.











The startup procedure takes approximately 90 s; the startup time depends on the number of modules to load.

3. If you start the CTP10 for the first time, accept the license agreement.

Once started, the **Modules and Lasers** window appears on screen and the last user configuration is loaded.

Access the wanted CTP10 function by using the task bar:



Task Bar Button	Description
	Turns off the CTP10. For more details, see <i>Turning off the CTP10</i> on page 49.
 Modules and Lasers	Displays the <b>Modules and Lasers</b> window, to perform static measurement and control the CTP10 modules and connected lasers. For more details, see <i>Operating CTP10 Modules</i> on page 65 and <i>Defining and Controlling Your Laser(s)</i> on page 87.
 Subsystem	Displays the <b>Subsystem</b> window, which enables you to perform dynamic measurement: transfer function (TF), polarization dependent loss (PDL) and back reflection (BR) scanning and analysis. For more details, see <i>Defining Your Subsystem</i> on page 99.
 Daisy chaining	Displays the <b>Daisy chaining</b> menu, which enables you to connect the current CTP10 to another, in order to increase the number of optical detectors on your setup by using those of the other CTP10 for measurements. For more details, see <i>Using Additional OPMs (Daisy Chaining mode)</i> on page 107.
 Laser sharing	Displays the <b>Laser sharing</b> menu, which enables you to connect the current CTP10 to seven CTP10s so that they can benefit from the tunable lasers connected to the current CTP10 for their acquisition. For more details, see <i>Sharing the Lasers with Several CTP10s</i> on page 94.
 Analog outputs	Enables you to output internal measurements as analog signals. For more details, see <i>Generating Output Analog Signals</i> on page 141.
	Displays the <b>File Explorer</b> window, to access the drives available from the CTP10 and handle corresponding files. For more details, see <i>Handling Files and User Data</i> on page 193.
	Displays the <b>Settings</b> window, to define the CTP10 general parameters, connect the CTP10 or manage CTP10 data.
	Displays the last 100 main errors and/or warnings that occurred on the CTP10. For more details, see <i>Displaying the List of Errors and Warnings</i> on page 228.
	<ul style="list-style-type: none"> <li>➤ The <b>Help</b> command displays the <i>CTP10 User Guide</i>.</li> <li>➤ The <b>About</b> command displays information about the CTP10, the license agreement and a customer support contact list.</li> </ul>

## Updating the CTP10 System Version

The CTP10 embedded software package is a .pkg file available on the EXFO website. You can install it from a USB device or by directly copying it on the CTP10 internal drive (only available from software package version 2.1.x.x).

It contains the following components:

- The latest CTP10 GUI, mainframe FPGA and CTP10 application versions, which are automatically installed on your system during the updating process
- The CTP10 module version updates, that you can apply to your modules as explained in *Updating a Module System Version* on page 86


Updating the CTP10 system version does not affect referencing data nor user data. It takes less than 10 minutes.



### IMPORTANT

If you want to update the CTP10 system version from your CTP10 internal drive, make sure your current version is version 2.1.x.x or above.

#### **To update the CTP10 system version:**

1. From the EXFO website ([www.EXFO.com/en/exfo-apps](http://www.EXFO.com/en/exfo-apps)), download the last CTP10 update package (compressed into a \*.zip file).
2. Do one of the following:
  - To install the update package from a USB device:
    - Unzip the package to a USB device, so that the necessary \*.pkg file is located at the USB device root.
    - Connect the USB device to one of the available USB ports.
  - To install the update package from the CTP10 internal drive (only available from software package version 2.1.x.x):
    - Unzip the package to a network drive.
    - From the CTP10 File Explorer, connect the CTP10 to the network drive where the package is located: see *Adding/Removing a Network Drive* on page 194.
    - From the CTP10 File Explorer, copy the \*.pkg file to root of the CTP10 internal drive D:\.
3. Turn off the CTP10 (see *Turning off the CTP10* on page 49).
4. On the front panel, press the  button to turn on the CTP10.

The CTP10 automatically detects the \*.pkg file on the USB device or on the CTP10 internal drive and starts the update wizard (if several \*.pkg files are detected, the last copied on the USB device or on the internal drive is taken into account).





## CAUTION

To avoid serious system problems:

- Do not turn the CTP10 off during the update.
- Do not remove the USB device before the end of the upgrade process.


5. Follow the instructions displayed on screen to update the system version.  
Once the update is finished, the CTP10 starts normally.
6. If necessary, safely remove the USB device as explained in *Connecting/Disconnecting USB Storage Devices* on page 193.

## Updating the Operating System Version

You should check for updates regularly to keep the CTP10 operating system version up to date for security reasons.

Updating the operating system may take a significant amount of time.

### **To update the operating system version:**

1. Make sure that your CTP10 is connected to the Internet.
2. Turn on the CTP10 as explained in *Turning on the CTP10 and Accessing the GUI* on page 44.
3. In the CTP10 task bar, click the  button to display the **Settings** window.

The **Operating System** area enables you to update the operating system.



4. Click the **Check for updates** button.

The CTP10 verifies if your system is up to date. This operation might take time. If updates are available, a message gives the list of available updates and prompts you to install them.

5. Click the **Download, install and restart** button to install the update(s).

The CTP10 downloads and installs the updates, and then restarts automatically.

6. Once the CTP10 has restarted: in the **Settings** window, click the **Check for updates** button again to make sure that all updates have been installed.  
If all updates have not been installed, perform steps 1 to 5 again to install all the available updates.

## Turning off the CTP10


If you turn off the CTP10, the last user configuration is kept in memory to be loaded at next startup.



### CAUTION

Never turn the CTP10 off by directly setting the power switch to **O**.

#### **To turn the CTP10 off:**

1. Make sure that no scan or analyze is in progress. You cannot shut down the system if a subsystem is busy.
2. Do one of the following:
  - In the CTP10 GUI task bar, click the  button.  
A confirmation message appears: click **Yes**.
  - On the CTP10 front panel, shortly press the on/off button.  
The CTP10 stops.
3. On the rear panel, set the power switch to **O**.



## 4 Setting Up Your CTP10


### Defining the GUI Colors



You can change the theme of the GUI and modify its brightness as explained in the following procedures.

**To modify the GUI brightness and theme:**

1. In the CTP10 task bar, click the  button to display the **Settings** window.

The **Display** area enables you to define the colors of the CTP10 GUI.



2. To increase or decrease the brightness of the CTP10 GUI, slide the **Brightness** cursor or use the following keyboard shortcuts: Ctrl +  and Ctrl + .
3. To shift the light colors on screen to darker colors, select the **Dark theme** check box or use the following keyboard shortcut: Ctrl + D.  
This operation takes approximately 10 seconds.

## Setting the Date and Time

The date and time set here will be used for all measurements of the subsystem: the date and time of trace scans are saved with the traces and the date and time of trace analysis are saved with the analysis results.

If the CTP10 is connected to a network, it can automatically set the date and time depending on your time zone. You can also choose to manually set the date and time.

### To set the date and time:

1. In the CTP10 task bar, click the  button to display the **Settings** window.

The **Date & Time** area enables you to set the date and time of the CTP10.



2. To manually set the date and time:
  - 2a. Clear the **Set time automatically** check box.
  - 2b. Click the **Date** and **Time** fields to enter the date and time of your location.
  - 2c. In the **Zone** list, select the time zone of your location.
3. If your CTP10 is connected to a network and you want the date and time to be automatically set by the CTP10:
  - 3a. Select the **Set time automatically** check box.
  - 3b. In the **Zone** list, select the time zone of your location.

The date and time is automatically set.

## Connecting the CTP10 to your Company Network


The Ethernet port enables you to connect your CTP10 to your company network.




It also allows you to perform remote control operations on the CTP10. For more details, see *Remotely Controlling the CTP10* on page 199.

### To connect the CTP10 to your company network:

1. In the CTP10 task bar, click the  button to display the **Settings** window.

The **Ethernet** area enables you to configure the Ethernet connection of the CTP10.



- : indicates that the connection is established and displays the connection speed.
  - : indicates that the connection to the network is not established, or that the CTP10 is directly connected to a computer (see *Setting the CTP10 Ethernet Port* on page 199).
  - : indicates that the port is not connected to any external device.
2. In the **Port** field, set the TCP destination port of the CTP10, to allow data transmission between the CTP10 and an external computer for remote control.  
Default value: 5025 (SCPI-RAW)  
The value is automatically taken into account.



### IMPORTANT

- Make sure that the firewall of your computer allows communication on this port.
- Do not use this port to connect CTP10s for laser sharing purposes (for more details on laser sharing, see *Sharing the Lasers with Several CTP10s* on page 94).

## Setting Up Your CTP10

### Renaming the Instrument

---

3. To manually set the connection parameters:
  - 3a. Clear the **Obtain an IP address automatically** check box.
  - 3b. Set the IP address, subnet mask and gateway to identify your CTP10.
4. To automatically retrieve the connection parameters (IP address, subnet mask and default gateway) from the connected network (DHCP), select the **Obtain an IP address automatically** check box.

The connection is automatically established. You cannot modify the connection values.
5. Click **Apply** to validate the set connection parameters.
6. If you want to retrieve the previously applied connection parameters, click the **Refresh** button.

## Renaming the Instrument

The default instrument name is "CTP10<serial number>". The following procedure explains how to change the instrument name.

### To change the instrument name:

1. In the CTP10 task bar, click the  button to display the **Settings** window.

The **PC name** area enables you to rename the CTP10.



The screenshot shows a window titled "PC name" with a text input field containing the serial number "CTP10193110246". To the right of the text field is a button labeled "Rename". The entire window is outlined with a red border.

2. Click the **Rename** button.
3. Modify the instrument name and click **Rename**.

The instrument name will be modified at next startup.



## Installing Your Test Setup


This section gives an overview of the DUT characterization steps using the CTP10 and gives examples of typical subsystem setups:

- *Overview Diagram* on page 55
- *Typical Test Setups* on page 57

### Overview Diagram

The following diagram gives an overview of the DUT characterization procedure using the CTP10.

#### Connect and configure your laser(s) to the CTP10




1. Physically connect the laser(s) to your CTP10.
2. Configure the laser connection from the GUI.

#### Related section:

*Defining and Controlling Your Laser(s)* on page 87.

#### Configure your test setup



Configure your test setup from the subsystem setup menu.

If you need more detectors, you can use the Daisy chaining function (not available with the IL RL OPM2 module).


#### Related section:

*Setting up Your Subsystem* on page 101  
*Using Additional OPMs (Daisy Chaining mode)* on page 107

## Setting Up Your CTP10

### Installing Your Test Setup

#### Share the lasers with other CTP10s if needed (not compatible with Daisy chaining)




If needed, enter the laser sharing mode by connecting the Controller CTP10 to Distributed CTP10s.

#### Related section:

*Sharing the Lasers with Several CTP10s on page 94.*

#### Configure the scan parameters and reference the subsystem




- TF and BR referencing (with the IL RL OPM2 module).
- TF and PDL referencing (with the IL PDL or IL PDL OPM2 module).
- Wavelength referencing.
- Dark current referencing.

#### Related sections:

- *Defining the Scan Parameters on page 115.*
- *Referencing the Subsystem on page 123.*

#### Test your DUT



- Scan.
- Trace display.
- Analysis.
- Data management.

#### Related sections:

- *Performing Acquisition Scans on page 133.*
- *Displaying and Handling Traces on page 143.*
- *Analyzing Traces on page 155.*
- *Handling Subsystem Data on page 112.*

## Typical Test Setups


### Typical IL/RL test setup with one laser

The following figure illustrates an example of test setup with one T100S-HP laser.

The CTP10 controls the laser via RS-232 with a USB-RS232 adapter or via GPIB with a USB-GPIB adapter. The laser output is directly connected to the TLS IN input connector of the IL RL OPM2 module.

The IL RL OPM2 module is connected to the SCAN SYNC module for optical sampling and to the DUT for TF/BR measurements.

The CTP10 uses the laser optical trigger for data acquisition with the help of the SCAN SYNC module, which performs optical sampling.



## Setting Up Your CTP10

### Installing Your Test Setup


#### Typical IL/PDL test setup

The following figure illustrates the typical test setup with an IL PDL module.

The CTP10 controls the T100S-HP laser via RS-232 with a USB-RS232 adapter or via GPIB with a USB-GPIB adapter.

The laser used must be a PM tunable laser, The laser output is directly connected to the TLS IN input connector of the IL PDL module with a PM patchcord.

The IL PDL module is connected to the SCAN SYNC module for optical sampling and to the DUT for TF and PDL measurements.




**Typical IL/RL test setup with multiple lasers (full-band characterization)**

The following figure illustrates a test setup with three T100S-HP lasers.

The CTP10 controls the lasers via GPIB with a USB-GPIB adapter, or via RS-232 with USB-RS232 adapters (one per laser). The three laser outputs are connected to the FBC module input connectors. The signal coming from the FBC output connector is connected to the IL RL OPM2 module for measurements.

The IL RL OPM2 module is connected to the SCAN SYNC module for optical sampling and to the DUT for TF/BR measurements.

The CTP10 uses the laser optical trigger for data acquisition with the help of the SCAN SYNC module, which performs optical sampling.





## Setting Up Your CTP10

### Installing Your Test Setup


#### Typical IL/PDL test setup with multiple lasers (full-band characterization)

The following figure illustrates a test setup with three T100S-HP lasers.

The CTP10 controls the lasers via GPIB with a USB-GPIB adapter, or via RS-232 with USB-RS232 adapters (one per laser). The three laser outputs are connected to the FBC module input connectors. The signal coming from the FBC output connector is connected to the IL PDL OPM2 module for measurements.

The IL PDL OPM2 module is connected to the SCAN SYNC module for optical sampling and to the DUT for TF/PDL measurements.

The CTP10 uses the laser optical trigger for data acquisition with the help of the SCAN SYNC module, which performs optical sampling.



**Typical IL/RL test setup with multiple lasers shared between several CTP10**


The **Laser Sharing** function enables you to perform simultaneous measurement scans on eight CTP10s using the tunable lasers connected to a single CTP10.

The Controller CTP10 controls the lasers via GPIB with a USB-GPIB adapter, or via RS-232 with USB-RS232 adapters (one per laser). The three laser outputs are connected to the FBC module input connectors.

The signal coming from the FBC output connector is directed to a 1x8 splitter to share the laser signal with seven other CTP10s (called Distributed CTP10s).

On each CTP10, the IL RL OPM2 module receives the signal and is connected to the SCAN SYNC module for optical sampling and to the DUT for TF/BR measurements.

For more details on laser sharing, see *Sharing the Lasers with Several CTP10s* on page 94.



## Installing Your Test Setup

The **Daisy chaining** function enables you to perform IL/PDL measurements on DUT of more than 42 ports (44 with an IL PDL OPM2 module), by using the detectors of another CTP10.


The Primary CTP10 is connected to the Secondary CTP10 with a BNC cable, which enables data sampling of all external detectors located on the Secondary CTP10.

The Primary CTP10 displays the results of all measurements performed on the connected Secondary CTP10.

- 
- The diagram illustrates the CTP10 detector system architecture. A Tunable Laser (PM) is connected to the Primary CTP10 (up to 42 detectors) via a PM fiber. The Primary CTP10 is connected to the Secondary CTP10 (up to 60 detectors). The DUT (Device Under Test) is connected to the Primary CTP10 via an IN port. The Primary CTP10 has up to 102 outputs, with 42 outputs connected to the Secondary CTP10. The Primary CTP10 is also connected to a LAN network via TRIG OUT and TRIG IN ports. Two displays, Display 1 and Display 2, are shown at the top, connected to the Primary CTP10.



- Example of setup with an IL PDL OPM2 module and three lasers:





## 5 Operating CTP10 Modules

The CTP10 mainframe hosts up to 10 modules that you can control individually from the CTP10 user interface or use in a subsystem to perform TF/BR or TF/PDL measurements.

The modules plugged into the CTP10 are all displayed on the upper part of the **Modules and Lasers** window, with their related information and measured values.

This window enables you to statically control the available modules, without the use of a subsystem (for more details on subsystems, see *Defining Your Subsystem* on page 99).




### IMPORTANT

- The displayed measurement values are only valid on continuous wave signals. If your signal is pulsed or modulated, the displayed values cannot be considered as reliable.
- The parameters defined individually for the modules in this window are not taken into account in subsystem measurements.

#### To access the module control window:

1. In the task bar, click the  **Modules and Lasers** button.

All modules plugged into the CTP10 mainframe are represented in the top part of the window and display the defined module parameters and measured values for each connector.



2. Operate the wanted modules from this window, as explained in the following sections:

- *Displaying Information on Modules* on page 66
- *Controlling the IL RL OPM2 Module* on page 67
- *Controlling the IL PDL or IL PDL OPM2 Module* on page 72
- *Controlling the SCAN SYNC Module* on page 78
- *Controlling OPMx Modules* on page 79

- *Controlling the FBC Module* on page 81
- *Zeroing the Dark Current on Detectors* on page 84
- *Restoring the Factory Settings of a Module* on page 85
- *Updating a Module System Version* on page 86


## Displaying Information on Modules

For each module, the **Information** area displays information on the module version. It also enables you to update the module version, reset the module settings and run a self-test.

### To display general information on a module:

1. In the **Modules and Lasers** window, click a module.

The module details appear at the right of the window.



The screenshot shows a window titled "Module" with a tab labeled "Information". The window contains a table with the following data:

Field	Value
Model	OPM2
Options	FC
Serial	E0182010149
Manufacturing	December 2, 2018
Calibration	December 2, 2018
Firmware version	0.2.45
Hardware version	A
CTP10 rack position	10

Below the table, there are two buttons: "Restore factory settings" and "Run self-test".


2. The module **Information** area enables you to control the module version and general parameters, as explained in the following table:

Button	Description
Update...	If an update is available for the module, this button enables you to install the updated version. For more details on the update procedure, see <i>Updating a Module System Version</i> on page 86.
Restore factory settings	Deletes all the user customized settings on the module (units, parameters, dark current zeroing). For more details on the restore procedure, see <i>Restoring the Factory Settings of a Module</i> on page 85.
Run self-test	Enables you to detect possible errors on the module (for remote assistance). If an error occurs, the module becomes unavailable. For more details, see <i>Performing a Self-test</i> on page 227.

## Controlling the IL RL OPM2 Module

The IL RL OPM2 module enables you to measure the insertion loss and the return loss of connected devices. The module plugged into the CTP10 mainframe is represented in the top part of the **Modules and Lasers** window.

The IL RL OPM2 module panel displays all the module connectors with the corresponding measured values (expressed at their nearest round number) and defined parameters.



You can display and update the module version (see *Displaying Information on Modules* on page 66) and modify the parameters of each module connector individually, as explained in the following procedures.



### IMPORTANT


- The displayed measurement values are only valid on continuous wave signals. If your signal is pulsed or modulated, the displayed values cannot be considered as reliable.
- The parameters defined individually for the modules in this window are not taken into account in subsystem measurements.

### Controlling the Detector Ports

The detector inputs of the IL RL OPM2 module enable you to measure the optical power of connected devices.

#### To define the detector (IN1/IN2) port parameters:

1. In the **Modules and Lasers** window, click the IL RL OPM2 module.
2. Click the detector connector you want to modify.



3. Click the parameter value you want to modify as explained in the following table.


Settings		Description
<b>Power units</b>		Select the unit to use for the measured input power.
<b>Spectral units</b>		Select the unit to use for the defined wavelength/frequency.
<b>Parameters</b>	<b>Wavelength /Frequency</b>	Enter the wavelength/frequency value of the signal received by the module input connector.  If the module connector is used in a subsystem, the value is applied to all the connectors used in that same subsystem.
	<b>Averaging Time</b>	Period of time during which you want the power signal to be averaged; increasing the averaging time reduces noise level on the measured power.  If the module connector is used in a subsystem, the value is applied to all the connectors used in that same subsystem.
	<b>Power Offset</b>	Compensation value you want to apply to the detected power.  If the module connector is used in a subsystem, the value is applied to all the connectors used in that same subsystem.
<b>Input power</b>		Instant input power measured on the port, according to the parameters set in the <b>Parameters</b> area.
<b>Zeroing</b> button		Performs dark current zeroing on the connector: see <i>Zeroing the Dark Current on Detectors</i> on page 84.

## Controlling the TLS Input Port

The laser input port of the IL RL OPM2 module enables you to measure the optical input power of connected devices.

### To define the TLS input (TLS IN) parameters:

1. In the **Modules and Lasers** window, click the IL RL OPM2 module.
2. Click the TLS input connector.



3. Click the parameter value you want to modify as explained in the following table.


Settings		Description
<b>Parameters</b>	<b>Wavelength/Frequency</b>	Enter the wavelength/frequency value of the signal received by the module input connector.  The value set also applies to the module "Out to SCAN SYNC" and "Out to DUT" connectors, and to all detectors used in the subsystem.
	<b>Averaging Time</b>	Period of time during which you want the power signal to be averaged; increasing the averaging time reduces noise level on the measured power.  The value set also applies to the module "Out to SCAN SYNC" and "Out to DUT" connectors, and to all detectors used in the subsystem.
	<b>Power Offset</b>	Compensation value you want to apply to the detected power.  The value set also applies to the module "Out to SCAN SYNC" and "Out to DUT" connectors, and to all detectors used in the subsystem.
<b>Power units</b>		Select the unit to use for the measured input power.
<b>Spectral units</b>		Select the unit to use for the defined wavelength/frequency.
<b>Input Power</b>		Instant input power measured on the port, according to the parameters set in the <b>Parameters</b> area.

### Controlling the Output Ports

The output ports of the IL RL OPM2 module enable you to perform output power and back reflection measurements.

#### To define the Out to SCAN SYNC output parameters:

1. In the **Modules and Lasers** window, click the IL RL OPM2 module.
2. Click the Out to SCAN SYNC connector.



3. Click the parameter value you want to modify as explained in the following table.

Settings		Description
<b>Power units</b>		Select the unit to use for the measured input power.
<b>Spectral units</b>		Select the unit to use for the measured input power.
<b>Parameters</b>	<b>Wavelength/ Frequency</b>	Enter the wavelength/frequency value of the signal received by the module input connector.  The value set also applies to the module "TLS IN" and "Out to DUT" connectors, and to all detectors used in the subsystem.
	<b>Averaging Time</b>	Period of time during which you want the power signal to be averaged; increasing the averaging time reduces noise level on the measured power.  The value set also applies to the module "TLS IN" and "Out to DUT" connectors, and to all detectors used in the subsystem.
	<b>Power Offset</b>	Compensation value you want to apply to the detected power.  The value set also applies to the module "TLS IN" and "Out to DUT" connectors, and to all detectors used in the subsystem.
<b>Output power</b>		Output optical power measured on the port.



**To define the Out to DUT output parameters:**

1. In the **Modules and Lasers** window, click the IL RL OPM2 module.
2. Click the Out to DUT connector.

3. Click the parameter value you want to modify as explained in the following table.


Parameter		Description
<b>Power units</b>		Select the unit to use for the measured input power.
<b>Spectral units</b>		Select the unit to use for the measured input power.
<b>Parameters</b>	<b>Wavelength/ Frequency</b>	Enter the wavelength/frequency value of the signal received by the module input connector.  The value set also applies to the TLS input and Out to SCAN SYNC connectors.
	<b>Averaging Time</b>	Period of time during which you want the power signal to be averaged; increasing the averaging time reduces noise level on the measured power.  The value set also applies to the TLS input and Out to SCAN SYNC connectors.
	<b>Power Offset</b>	Compensation value you want to apply to the detected power.  The value set also applies to the TLS input and Out to SCAN SYNC connectors.
<b>Output power</b>		Output optical power measured on the port.  Select the value if you want it to be displayed in the overall view of modules, in the <b>Modules and Lasers</b> window.
<b>Back Reflection</b>		Back reflection value measured on the port.  Select the value if you want it to be displayed in the overall view of modules, in the <b>Modules and Lasers</b> window. If no power is detected on the TLS input port(s), no value is displayed.
<b>Reference zeroing button</b>		Performs dark current zeroing of the monitoring detector used for TF and BR measurements: see <i>Zeroing the Dark Current on Detectors</i> on page 84.
<b>BR zeroing button</b>		Performs dark current zeroing on the connector for BR measurements: see <i>Zeroing the Dark Current on Detectors</i> on page 84.


## Controlling the IL PDL or IL PDL OPM2 Module

The IL PDL and IL PDL OPM2 modules enable you to measure the insertion loss and the polarization dependent loss of connected devices. The module plugged into the CTP10 mainframe is represented in the top part of the **Modules and Lasers** window.

The IL PDL and IL PDL OPM2 modules are double-slot modules, which are displayed as single-slot modules in the upper part of the **Modules and Lasers** window.

The IL PDL or IL PDL OPM2 module panel displays the module connectors with the corresponding measured values (expressed at their nearest round number) and defined parameters.





You can display and update the module version (see *Displaying Information on Modules* on page 66) and modify the parameters of each module connector individually, as explained in the following procedures.



## IMPORTANT


- The displayed measurement values are only valid on continuous wave signals. If your signal is pulsed or modulated, the displayed values cannot be considered as reliable.
- The parameters defined individually for the modules in this window are not taken into account in subsystem measurements.

### Controlling the Detector Ports (IL PDL OPM2 module only)

The detector inputs of the IL PDL OPM2 module enable you to measure the optical power of connected devices.

#### To define the detector (IN1/IN2) port parameters:

1. In the **Modules and Lasers** window, click the IL PDL OPM2 module.
2. Click the detector connector you want to modify.



3. Click the parameter value you want to modify as explained in the following table.


Settings		Description
<b>Power units</b>		Select the unit to use for the measured input power.
<b>Spectral units</b>		Select the unit to use for the defined wavelength/frequency.
<b>Parameters</b>	<b>Wavelength /Frequency</b>	Enter the wavelength/frequency value of the signal received by the module input connector.  If the module connector is used in a subsystem, the value is applied to all the connectors used in that same subsystem.
	<b>Averaging Time</b>	Period of time during which you want the power signal to be averaged; increasing the averaging time reduces noise level on the measured power.  If the module connector is used in a subsystem, the value is applied to all the connectors used in that same subsystem.
	<b>Power Offset</b>	Compensation value you want to apply to the detected power.  If the module connector is used in a subsystem, the value is applied to all the connectors used in that same subsystem.
<b>Input power</b>		Instant input power measured on the port, according to the parameters set in the <b>Parameters</b> area.
<b>Zeroing</b> button		Performs dark current zeroing on the connector: see <i>Zeroing the Dark Current on Detectors</i> on page 84.

## Controlling the TLS Input Port

The laser input port of the IL PDL or IL PDL OPM2 module enables you to measure the optical input power of connected devices.

### To define the TLS input (TLS IN) parameters:

1. In the **Modules and Lasers** window, click the IL PDL or IL PDL OPM2 module.
2. Click the TLS input connector.



3. Click the parameter value you want to modify as explained in the following table.


Settings		Description
<b>Parameters</b>	<b>Wavelength/Frequency</b>	Enter the wavelength/frequency value of the signal received by the module input connector.  The value set also applies to the module "Out to SCAN SYNC" and "Out to DUT" connectors, and to all detectors used in the subsystem.
	<b>Averaging Time</b>	Period of time during which you want the power signal to be averaged; increasing the averaging time reduces noise level on the measured power.  The value set also applies to the module "Out to SCAN SYNC" and "Out to DUT" connectors, and to all detectors used in the subsystem.
	<b>Power Offset</b>	Compensation value you want to apply to the detected power.  The value set also applies to the module "Out to SCAN SYNC" and "Out to DUT" connectors, and to all detectors used in the subsystem.
<b>Power units</b>		Select the unit to use for the measured input power.
<b>Spectral units</b>		Select the unit to use for the defined wavelength/frequency.
<b>Input Power</b>		Instant input power measured on the port, according to the parameters set in the <b>Parameters</b> area.

### Controlling the Output Ports

The output ports of the IL PDL or IL PDL OPM2 module enable you to perform output power measurements.

#### To define the Out to SCAN SYNC output parameters:

1. In the **Modules and Lasers** window, click the IL PDL or IL PDL OPM2 module.
2. Click the Out to SCAN SYNC connector.



3. Click the parameter value you want to modify as explained in the following table.

Settings		Description
<b>Power units</b>		Select the unit to use for the measured input power.
<b>Spectral units</b>		Select the unit to use for the measured input power.
<b>Parameters</b>	<b>Wavelength/ Frequency</b>	Enter the wavelength/frequency value of the signal received by the module input connector.  The value set also applies to the module "TLS IN" and "Out to DUT" connectors, and to all detectors used in the subsystem.
	<b>Averaging Time</b>	Period of time during which you want the power signal to be averaged; increasing the averaging time reduces noise level on the measured power.  The value set also applies to the module "TLS IN" and "Out to DUT" connectors, and to all detectors used in the subsystem.
	<b>Power Offset</b>	Compensation value you want to apply to the detected power.  The value set also applies to the module "TLS IN" and "Out to DUT" connectors, and to all detectors used in the subsystem.
<b>Output power</b>		Output optical power measured on the port.

### To define the Out to DUT output parameters:

1. In the **Modules and Lasers** window, click the IL PDL or IL PDL OPM2 module.
2. Click the Out to DUT connector.

Module 5 - IL PDL

Output

Module rack position: 5

Output number: 2

Used in subsystem: Yes

Power units: ☒ dBm ☐ mW

Spectral units: ☒ nm ☐ THz

Parameters:

Wavelength: 1550.0000, nm

Averaging Time: 10.000, ms

Power Offset: 2.00, dB

Output power: -3.3 dBm

Last reference zeroing: Dec 20, 2019 - 13:48

Reference zeroing

3. Click the parameter value you want to modify as explained in the following table.


Parameter		Description
<b>Power units</b>		Select the unit to use for the measured input power.
<b>Spectral units</b>		Select the unit to use for the measured input power.
<b>Parameters</b>	<b>Wavelength/ Frequency</b>	Enter the wavelength/frequency value of the signal received by the module input connector.  The value set also applies to the TLS input and Out to SCAN SYNC connectors.
	<b>Averaging Time</b>	Period of time during which you want the power signal to be averaged; increasing the averaging time reduces noise level on the measured power.  The value set also applies to the TLS input and Out to SCAN SYNC connectors.
	<b>Power Offset</b>	Compensation value you want to apply to the detected power.  The value set also applies to the TLS input and Out to SCAN SYNC connectors.
<b>Output power</b>		Output optical power measured on the port.  Select the value if you want it to be displayed in the overall view of modules, in the <b>Modules and Lasers</b> window.
<b>Reference zeroing button</b>		Performs dark current zeroing of the monitoring detector used for TF and PDL measurements: see <i>Zeroing the Dark Current on Detectors</i> on page 84.

## Controlling the SCAN SYNC Module

The SCAN SYNC module plugged into the CTP10 mainframe is represented in the top part of the **Modules and Lasers** window.

The SCAN SYNC module perform optical sampling of swept wavelength lasers. No measurement is displayed in the **Modules and Lasers** window.

You can restore factory settings or run a self test as explained in *Restoring the Factory Settings of a Module* on page 85 and *Performing a Self-test* on page 227.



Indicates that the connector is used in a subsystem.  
It flashes when the subsystem is scanning.




## Controlling OPMx Modules

In the **Modules and Lasers** window, OPM modules enable you to control the optical power of connected devices. The OPM modules plugged into the CTP10 mainframe are represented in the top part of the **Modules and Lasers** window.

All values are displayed as their nearest round number.

Each OPM module panel displays all the module connectors with the corresponding measured values and defined parameters.



You can control the module version (see *Displaying Information on Modules* on page 66) and modify the parameters of each module connector individually, as explained in the following procedure.



### IMPORTANT

- The displayed measurement values are only valid on continuous wave signals. If your signal is pulsed or modulated, the displayed values cannot be considered as reliable.
- The parameters defined individually for the modules in this window are not taken into account in subsystem measurements.

### To define the detector port parameters:

1. In the **Modules and Lasers** window, click the module you want to modify.
2. Click the detector port you want to modify.
3. Click the parameter value you want to modify as explained below.


The screenshot shows a software interface for configuring an OPM6 module. On the left, a list of detector ports (IN1 to IN6) is shown with their current settings: 5.0 dBm, 4.1 dBm, 3.6 dBm, 3.8 dBm, 4.3 dBm, and 3.4 dBm, all at 1550 nm, 1 ms, and 1 dB. The 'Detector' tab is selected, displaying configuration options for a specific detector (Module rack position: 4, Detector number: 1, Used in subsystem: Yes). The 'Parameters' section includes Wavelength (1550.0000 nm), Averaging Time (1.000 ms), and Power Offset (1.00 dB). The 'Power units' section has radio buttons for dBm (selected) and mW. The 'Spectral units' section has radio buttons for nm (selected) and THz. The 'Input power' section shows a value of 5.0 dBm. A 'Zeroing' button is located at the bottom right.

Settings		Description
<b>Power units</b>		Select the unit to use for the measured input power.
<b>Spectral units</b>		Select the unit to use for the defined wavelength/frequency.
<b>Parameters</b>	<b>Wavelength /Frequency</b>	Enter the wavelength/frequency value of the signal received by the module input connector. If the module connector is used in a subsystem, the value is applied to all the connectors used in that same subsystem.
	<b>Averaging Time</b>	Period of time during which you want the power signal to be averaged; increasing the averaging time reduces noise level on the measured power. If the module connector is used in a subsystem, the value is applied to all the connectors used in that same subsystem.
	<b>Power Offset</b>	Compensation value you want to apply to the detected power. If the module connector is used in a subsystem, the value is applied to all the connectors used in that same subsystem.
<b>Input power</b>		Instant input power measured on the port, according to the parameters set in the <b>Parameters</b> area.
<b>Zeroing</b> button		Performs dark current zeroing on the connector: see <i>Zeroing the Dark Current on Detectors</i> on page 84.

## Controlling the FBC Module

The FBC module enables you to combine up to four tunable laser sources.


In the **Modules and Lasers** window, you can select the TLS to use for static measurements.




### To select the laser input:

From the **Modules and Lasers** window, do one of the following:

- On the wanted TLS IN port, click the TLS input selection button.
- On the **FBC OUT** port, use the up and down arrow buttons to select the wanted TLS input port.
- Click the **FBC OUT** port and in the **Selection** area, click the laser input you want to activate.


The  icon appears on the selected port, to indicate that it is selected for static measurements and the selected port name is displayed on the **FBC OUT** port.



## Triggering Power Level Data Acquisition

The **logging** and **stability** functions enable you to acquire a definite number of power level samples from the wanted detector ports, upon receipt of an electrical or software trigger. These two functions are available by using a set of remote commands.

- The **logging** function enables you to continuously acquire a defined number of data points (for a given wavelength), according to a specified averaging time for each measurement.




This function can be triggered by an external trigger generator or by command.

If an external trigger is selected, the acquisition starts when the CTP10 receives a rising edge pulse (the function must have previously been armed by command).

- The **stability** function enables you to acquire data points (for a given wavelength) during a defined period of time with a specified dwell time between measurements, and according to a specified averaging time for each measurement. It is specifically adapted to long measurements.

This function can only be triggered by command.



In Daisy chaining mode, these functions are only available on detector ports located on the Primary CTP10.

The following procedure explains how to use the available commands to activate and execute the logging or stability functions.

**To execute the logging or stability measurement function:**

1. Make sure that:
  - The module(s) on which you want to activate the logging or stability function is updated to the last system version (see *Updating a Module System Version* on page 86).
  - The CTP10 is in idle state.
2. Select the detector(s) on which you want to activate the logging or stability function by using the command `:CTP:SENSe[1...10]:CHANnel[1...6]:FUNctIon:ACTivate` on page 291.
3. If you want to use the logging function, select the data acquisition trigger for the module by using the command `:CTP:SENSe[1...10]:CHANnel[1...6]:FUNctIon:TRIGGer` on page 294.

This command does not apply to the stability function, which can only be triggered by command (see `:CTP:FUNctIon:STATe` on page 270).

You can select one trigger by module used for the logging function. The detectors of a same module cannot have different triggers.
4. If you want to use a physical trigger (for the logging function only), connect the external trigger generator to the wanted **TRIG IN** BNC connector of the CTP10 rear panel.
5. Configure the function you want to use (logging or stability):
  - To configure the logging function, use the command `:CTP:FUNctIon:PARAmeter:LOGGing` on page 266.
  - To configure the stability function, use the command `:CTP:FUNctIon:PARAmeter:STABility` on page 268.
6. Start the data acquisition by using the command `:CTP:FUNctIon:STATe` on page 270.
  - If you have selected an external trigger (`:CTP:SENSe[1...10]:CHANnel[1...6]:FUNctIon:TRIGGer` on page 294), the function waits for the trigger to start the acquisition.
  - If you have selected a software trigger or no trigger (stability function), the acquisition starts immediately.


During acquisition, the GUI is not available. The function stops automatically when the acquisition is completed.
7. Display the status of the data acquisition function on a detector by using the query `:CTP:SENSe[1...10]:CHANnel[1...6]:FUNctIon:STATe?` on page 293.
8. Once the data acquisition is completed, return the data acquisition results by using the query `:CTP:SENSe[1...10]:CHANnel[1...6]:FUNctIon:RESult?` on page 292.
9. Deactivate the function on the detector by using the command `:CTP:SENSe[1...10]:CHANnel[1...6]:FUNctIon:ACTivate` on page 291.

### Zeroing the Dark Current on Detectors


Temperature and humidity variations affect the performance of electronic circuits and optical detectors, which can offset results on low power measurements. To compensate for this offset and improve power accuracy, you can zero the dark current on each module detector.

#### To zero the dark current on a connector:

1. Do one of the following:
  - Cover the connector with the provided protective cap (see *Installing FOA on Detectors* on page 32).
  - Connect a fiber with absolutely no light source.
2. In the **Modules and Lasers** window, click the module connector for which you want to zero the dark current.
3. Click the following button:
  - On detectors, click the **Zeroing** button.



- On signal output connectors used for TF, PDL or BR measurements (OUT TO DUT or OUT2 on IL RL OPM2, IL PDL and IL PDL OPM2 modules), click the following buttons:



**Reference zeroing** button to zero the dark current of the monitoring detector used during TF, PDL or BR measurements. The correction will apply to the TLS and OUT TO SCAN SYNC (or OUT1) power measurements.

**BR zeroing** button (on IL RL OPM2 modules only) to zero the dark current on BR measurements.

A confirmation window appears.

The date and time of the dark current measurement is displayed above the button. The connector dark current measured will be subtracted from the next power measurements.

## Restoring the Factory Settings of a Module


Restoring factory settings deletes all the user customized settings on the module (units, parameters, dark current zeroing) and restores the original default settings.

On SCAN SYNC module, it cancels the referencing performed on the module (if any). For more details on wavelength referencing, see *Performing Wavelength Referencing* on page 127.

### **To restore factory settings of a module:**

1. In the **Modules and Lasers** window, click the module for which you want to restore factory settings.

At the right of the window, the **Information** area enables you to restore the factory settings.



The screenshot shows a window titled 'Module' with a tab labeled 'Information'. Inside the 'Information' tab is a table with the following data:


Model	IL RL OPM2
Options	FC
Serial	E0182010147
Manufacturing	May 17, 2018
Calibration	May 17, 2018
Firmware version	0.2.45
Hardware version	A
CTP10 rack position	1

Below the table are two buttons: 'Restore factory settings' and 'Run self-test'. The 'Restore factory settings' button is highlighted with a red rectangle.

2. In the module **Information** area, click the **Restore factory settings** button.

### Updating a Module System Version


When you install a new version of the CTP10 firmware package (see *Updating the CTP10 System Version* on page 46), it may include module version updates. Also, the version installed on a module may not correspond to the firmware package version installed on the CTP10 mainframe.

In these cases, the  icon appears on the module overview window and you must manually update the modules, as explained in the following procedure.

#### To update a module system version:

1. In the **Modules and Lasers** window, click the module you want to update.
2. In the module **Information** area, click the **Update...** button.

The Modules update window appears, enabling you to select the modules to update.



1	2	3	4	5	6	7	8	9	10
FBC	IL RL OPM2	SCAN SYNC	OPM6	OPM4	OPM2	OPM2	OPM2	OPM2	OPM2
Version 0.2.49	Version 0.2.49	Version 0.2.49	Version 0.2.45	Version 0.2.45	Version 0.2.49	Version 0.2.49	Version 0.2.49	Version 0.2.49	Version 0.2.49


Available version: 0.2.49 0.2.49 0.2.49 0.2.49 0.2.49 0.2.49 0.2.49 0.2.49 0.2.49 0.2.49

Apply update: ☐ ☐

☐ Update all  
☐ Check update integrity

Update now

3. Select the wanted check box according to the instructions given in the following table.

Button	Description
Apply update	Select the check boxes corresponding to the modules you want to update.
Update all	Select this check box to automatically select all the available module updates.
Check update integrity	Select this check box to make sure that the module update is properly installed: after installation, the CTP10 verifies that the update is perfectly applied to the module.   Integrity checking takes time, it approximately doubles the module update time. The update time is indicated on the Update now button.
Update now	The button indicates the approximate update time. Click this button to start the update process.

4. Click the **Update now** button.  
A confirmation window appears.
5. Click **Start update**.



## 6 Defining and Controlling Your Laser(s)

The CTP10 embedded software (GUI) enables you to add and configure the external lasers you want to control from the CTP10.

You can directly control up to 10 tunable lasers from the CTP10 (static control of lasers from the **Modules and Lasers** window).

The CTP10 can connect to the following lasers:

- EXFO T100S-HP
- VIAVI mSWS-A1SLS

For more details on TLS requirements and compatibilities, see *TLS Requirements* on page 6.

The lower part of the **Modules and Lasers** window enables you to add, configure and control the lasers connected to the CTP10, as explained in the following sections:

- *Adding and Connecting the Laser(s)* on page 87
- *Controlling the Lasers* on page 91
- *Controlling the Laser Output* on page 93

Once created, you can select the lasers to setup a subsystem (for more details, see *Defining Your Subsystem* on page 99).

### **Laser Sharing**

In laser sharing mode, you define and control the lasers from the Controller CTP10. The Distributed CTP10s use the lasers defined on the Controller CTP10, so a CTP10 used as "Distributed" cannot add, configure nor control lasers. For more details on laser sharing, see *Sharing the Lasers with Several CTP10s* on page 94.

## **Adding and Connecting the Laser(s)**

To properly control the laser(s) you want to use with the CTP10, you must first connect your laser(s) to the CTP10 and set the communication connection as explained in the following procedures.



### **CAUTION**

- To achieve optimum system performance, keep fiber-optic connectors clean at all times (see *Cleaning Optical Connectors* on page 216).
- Make sure you have the appropriate fiber connector type corresponding to the module connectors you want to connect. Never connect another type of connector to the optical output. For details on the appropriate optical fiber type, see the *Technical Specifications* on page 3.

In laser sharing mode (see *Sharing the Lasers with Several CTP10s* on page 94), you can connect the lasers to the Controller CTP10 as you would do in a standard configuration.

On the Distributed CTP10s, the laser(s) connected to the Controller automatically appear in the **Laser** pane. They cannot be modified nor controlled from the Distributed CTP10s.

## Defining and Controlling Your Laser(s)


### Adding and Connecting the Laser(s)

#### To connect a laser to the CTP10:


1. Physically connect your tunable laser source(s) to the CTP10 as described below and illustrated in the following figures (examples with IL RL OPM2 module):

The tunable laser must be equipped with a PMF fiber output type to be connected to an IL PDL or IL PDL OPM2 module (with a PM fiber).


- Connection of one tunable laser to the CTP10 (no FBC module):



- Connection of four tunable lasers to the CTP10, with the use of an FBC module:



- Connection of four tunable lasers to a Controller CTP10 used in laser sharing mode:



For static control of lasers from the **Modules and Lasers** window (without the use of a subsystem), you can connect up to 10 tunable lasers to the CTP10.

For dynamic measurements from the **Subsystem** window (with the use of a subsystem), you can connect up to four tunable lasers to the CTP10, by using an FBC module.

**1a.** Connect the CTP10 to the laser(s) using one of the following methods:

**GPIOB**, using a GPIOB-USB adapter: use the GPIOB-USB-HS+ adapter from National Instrument (only available with EXFO T100S-HP).

In case of multiple TLS, do not use multiple adapters: connect one GPIOB-USB-HS+ adapter to the CTP10 and connect all the lasers with a GPIOB cable.

**Ethernet**, with an Ethernet cable.

**RS232**, using a USB-RS232 adapter (only available with EXFO T100S-HP and VIAVI mSWS-A1SLS lasers). In case of multiple TLS, use one USB-RS232 adapter per TLS.

**1b.** Connect the optical output of the laser(s) to one of the following connectors, depending on your setup:

**TLS IN** port of the IL RL OPM2 or IL PDL (with PM fiber) or IL PDL OPM2 (with PM fiber) module, or

**TLS IN** ports of the FBC module (only compatible with an IL RL OPM2 or IL PDL OPM2 module).

In case of multiple TLS, the CTP10 will sweep all lasers selected for the scan (see *Defining the Scanning Lasers* on page 116) from TLS1 to TLS4 (if any), whatever the wavelength ranges defined for each laser.

**1c.** If you use an FBC module, connect the **FBC OUT** port to the **TLS IN** port of the IL RL OPM2 or IL PDL OPM2 module.


**1d.** For data sampling, connect the **OUT TO SCAN SYNC** (or **OUT1**) port of the IL RL OPM2 or IL PDL or IL PDL OPM2 module to the **TLS IN** port of the SCAN SYNC module.

**2.** Turn on the laser and wait until it is fully initialized and ready to use.

**3.** In the task bar, click the  **Modules and Lasers** button.

**4.** In the lower part of the **Modules and Lasers** window, click the  icon to add a new laser.

The laser menu appears.



**5.** In the **Model** list, select the laser you have connected to the CTP10.

A default color is used for each laser model.

## Defining and Controlling Your Laser(s)

### Adding and Connecting the Laser(s)


6. Click the colored square and select a color to associate with the laser. The color enables you to distinguish two lasers of the same model.
7. In the **Communication** area, in the **Type** list, select the communication port you use to connect the CTP10 to the laser and configure the connection parameters as explained in the following table.

Communication Type	Parameter	Description
GPIB	Interface	GPIB interface ID of the laser GPIB controller.
	Address	GPIB address of the laser.
USB	Port	COM port on which the laser is connected.
	Parity	Configure the USB (serial port) settings according to the instructions given in your laser's user guide.
	Flow control	
	Speed	
	Stop bit	

8. Click the **Open connection** button.

The CTP10 retrieves available information from the connected laser: the **Information** area appears and displays the laser characteristics.

The laser is fully connected when its model appears in the **Identification** field.



In laser sharing mode, the laser added from the Controller CTP10 appears in the **Laser** pane of all the Distributed CTP10s and cannot be modified from the Distributed CTP10s.

9. Perform steps 2 to 8 with all the lasers you have connected to the CTP10.

## Controlling the Lasers

Once you have connected the laser to the CTP10 and opened the connection, the laser settings are available for configuration and control.

### To control the laser settings:

1. In the laser menu: in the **Laser** area under the model picture, make sure the laser connection status is set to **Connected**.

Once connected to the laser, the CTP10 retrieves available information from the laser: the **Laser information** area appears and displays the laser characteristics.

2. On some models of T100S-HP and mSWS-A1SLS lasers, enter the wavelength and power limits of the laser model: for some models of these lasers, the CTP10 cannot retrieve the model information directly from the instrument so you must enter manually the wavelength and power limits of the connected laser model, as explained in the following figure.

The screenshot shows the 'Information' section of the laser interface. It includes a table with the following data:

	Minimum	Maximum
Wavelength	1460.0000 nm	1625.0000 nm
Speed	1 nm/s	100 nm/s
Power	-6.9900 dBm	10.0000 dBm

Below the table is a row of buttons: 'O', 'E', 'S', 'C', 'L', 'U'. A 'Reset custom limits' button is located at the bottom left. Annotations with arrows point to the 'Wavelength' and 'Power' rows, stating 'Click the values to enter the wavelength and power specifications corresponding to the connected laser.' and to the 'Reset custom limits' button, stating 'Cancels the entered wavelength and power values.'

3. Configure and control your lasers.

Laser settings are not the same for all laser types. The following table details all possible parameters.

Parameter	Description
<b>Power/Spectral units</b>	Power and wavelength units to use in the laser settings.
<b>Mode</b>	<ul style="list-style-type: none"> <li>➤ <b>Fixed wavelength:</b> sets the laser emission wavelength/frequency to a fixed value defined in the <b>Parameters</b> area (see <i>Parameters</i> below).</li> <li>➤ <b>Sweep continuous:</b> sets the laser to perform continuous wavelength/frequency sweep according to the parameters set in the <b>Parameters</b> area (see <i>Parameters</i> below).</li> </ul>

## Defining and Controlling Your Laser(s)

### Controlling the Lasers

---

Parameter		Description
<b>Parameters</b>		The laser parameters depend on the selected sweep mode.
	<b>Wavelength/ Frequency</b>	Fixed wavelength mode only. Click the value to enter the wanted fixed laser emission wavelength/frequency.
	<b>Start wav./freq.</b>	Sweep continuous mode only. Click the value to enter the wanted lower wavelength/frequency sweep limit.
	<b>Stop wav./freq.</b>	Sweep continuous mode only. Click the value to enter the wanted upper wavelength/frequency sweep limit.
	<b>Speed</b>	Sweep continuous mode only. Click the value to enter the wanted sweep speed of the laser.
	<b>Output power</b>	Click the value to enter the wanted output power.
	<b>Coherence control</b>	For more details on these functions, refer to the user manual delivered with the laser.
	<b>Backlash suppression control</b>	
	<b>Cavity control</b>	
<b>Repeat Mode</b>		Sweep continuous mode only. <ul style="list-style-type: none"><li>➤ <b>Cycles:</b> number of sweep cycles in case of continuous sweep. Enter 0 for limitless sweep (if supported by the connected laser).</li><li>➤ <b>Delay:</b> pause between two sweep cycles. This parameter defines the period of time during which the laser stays at the upper wavelength of the sweep range before it returns to the lower wavelength to restart a new sweep cycle.</li></ul>

## Controlling the Laser Output

The laser menu enable you to control the laser sweep and to enable/disable the optical output.

Two buttons are available to control the laser:

- The **Enable** button controls the laser output. If the laser is set to sweep mode, you must also activate the sweep.
- The **Sweep** button controls the laser sweep independently from the optical output.

In laser sharing mode, the laser state is handled by the Controller CTP10 only and displayed in the **Laser** pane of all the Distributed CTP10s.

### **Before starting:**

Make sure the laser is connected and properly configured (see *Controlling the Lasers* on page 91).

### **To enable/disable the laser output:**

- To enable the laser output, click the **Enable** button located at the bottom left of the **Laser** menu.

The button lights in yellow and a red light flashes to indicate that the laser is emitting.

- If the **Sweep** button is selected, the laser sweeps according to the parameters set in the laser menu.
  - If the **Sweep** button is not selected, the laser emits at the last set wavelength.
- To disable the laser output, click the yellow **Enable** button

### **To start/stop the laser sweep:**

1. Set the laser to **Sweep continuous** or **Sweep stepped** mode.

The **Sweep** button appears.

2. To enable the laser sweep, click the **Sweep** button located at the bottom left of the **Laser** menu.

The button flashed in yellow to indicate that the laser is sweeping according to the parameters set in the laser menu.

3. To stop the laser sweep, click the yellow **Sweep** button.

## Sharing the Lasers with Several CTP10s

The **Laser Sharing** function enables you to perform simultaneous measurement scans on eight CTP10s using the tunable lasers connected to a single CTP10, as illustrated in *Typical IL/RL test setup with multiple lasers shared between several CTP10* on page 61.

The CTP10 controlling the lasers is defined as the **Controller** CTP10 and the seven other CTP10s are defined as the **Distributed** CTP10s.

Once a CTP10 is defined as the Controller, it controls the lasers and scanning parameters for all the Distributed CTP10s.

A Distributed CTP10 uses the lasers and scan parameters defined on the Controller. These parameters cannot be modified from the Distributed CTP10s.

### **Requirements:**

- All CTP10 mainframes must be connected to the LAN network, with different names (see *Renaming the Instrument* on page 54).
- All CTP10 mainframes must be equipped with the same software package version.
- All CTP10 mainframes (Controller and Distributed CTP10) must be equipped with a SCAN SYNC module for optical sampling
- All CTP10 mainframes (Controller and Distributed CTP10) must be equipped with the same measurement module: an IL RL OPM2 module for IL and RL measurements or an IL PDL module for IL and PDL measurements.
- Laser sharing is not compatible with the IL PDL OPM2 module.
- You cannot use the Laser sharing function in combination with the Daisy chaining function.



### Connecting the CTP10 Laser Controller to Distributed CTP10s

As soon as you connect a CTP10 to another CTP10 in the **Laser sharing** menu, you enter the laser sharing mode: the CTP10 from which you have open the connection becomes the Controller and the CTP10 connected to the Controller is immediately set to Distributed.

Before starting, make sure that all the CTP10 you want to use are connected by LAN, with different names (see *Renaming the Instrument* on page 54).

The **Laser sharing** menu enables you to connect the current CTP10 to up to seven CTP10s with which you want to share the lasers.

#### To enter the laser sharing mode:

1. In the task bar, click the **Laser sharing** menu.

The lower part of the menu enables you to connect to remote CTP10s.

Opening a connection to a CTP10 will remove all its existing lasers.  
The current CTP10 lasers will then be shared to the connected CTP10.

Distributed CTP10s	
<div>1 Distributed CTP10</div> <div>Disconnected</div>	Distributed port <input type="text" value="50000"/> <input type="button" value="Open connection"/> IP <input type="text" value="10"/> <input type="text" value="95"/> <input type="text" value="0"/> <input type="text" value="15"/> <input type="button" value="Close connection"/>
<div>2 Distributed CTP10</div> <div>Disconnected</div>	Distributed port <input type="text" value="50129"/> <input type="button" value="Open connection"/> IP <input type="text" value="10"/> <input type="text" value="95"/> <input type="text" value="0"/> <input type="text" value="114"/> <input type="button" value="Close connection"/>

2. In the **Laser sharing** menu, in the **Distributed CTP10s** area, enter the Distributed port and IP address of the CTP10 with which you want to share the lasers:

- **Distributed port:** enter the laser sharing distributed port of the CTP10 to which you want to connect. The Distributed port of a CTP10 is displayed in the **Laser sharing** menu, in the **Current laser sharing Distributed port** field.  
Default value: 50000.
- **IP:** enter the IP address of the CTP10 to which you want to connect. The IP address of a CTP10 is displayed in the **Laser sharing** menu, in the **Current CTP10 IP** field.

3. Make sure that the CTP10 with which you want to share the lasers is not busy (not scanning nor analyzing) and is not already a Controller or a Distributed CTP10.

4. Click the **Open connection** button.

The current CTP10 is automatically set to Controller and the connected CTP10 is immediately set to Distributed:

- On the Distributed CTP10, in the lower part of the **Modules and Lasers** window, the local laser(s) (if any) are replaced by the shared lasers and cannot be modified from the Distributed CTP10.
- In the **Subsystem setup** menu, the laser configuration made on the Controller subsystem is automatically applied to the Distributed CTP10 and cannot be modified from the Distributed CTP10.
- In the **Scan** menu, the scan parameters defined on the Controller are applied to the Distributed CTP10 and cannot be modified from the Distributed CTP10.

5. Perform steps 2 to 4 with all the CTP10s with which you want to share the lasers.

## Defining and Controlling Your Laser(s)

### Sharing the Lasers with Several CTP10s

#### To modify the laser sharing ports:


The laser sharing ports enable the Controller CTP10 to set the communication with the Distributed CTP10s.

You can use the default laser sharing ports to set the communication between the Controller CTP10 and Distributed CTP10s. These ports can be identical on all CTP10s involved in the laser sharing configuration.

You should modify the default laser sharing ports only in case a specific network inconsistency occurs (firewall restriction or application already running on the same port).

1. Make sure that the CTP10 is not busy (not scanning nor analyzing).
2. In the task bar, click the **Laser sharing** menu.

The upper part of the menu enables you to modify the laser sharing ports.



The screenshot shows a software window titled 'Information'. It contains a table with the following data:

Information	
Current CTP10 laser sharing status	No laser sharing detected
Current CTP10 laser sharing Distributed port	50000
Current CTP10 laser sharing Controller port	60000
Current CTP10 IP	10.95.0.61

Below the table, there is a warning icon and text: 'Opening a connection to a CTP10 will remove all its existing lasers. The current CTP10 lasers will then be shared to the connected CTP10.'

At the bottom, there is a section titled 'Distributed CTP10s' with a list box containing 'Distributed CTP10' and a '50000' value next to it.

3. To modify the Controller port of the current CTP10, click the **Current CTP10 laser sharing Controller port** field (default value: 60000).
4. To modify the Distributed port of the current CTP10, click the **Current CTP10 laser sharing Distributed port** field (default value: 50000).

## **Disconnecting the CTP10 Laser Controller from Distributed CTP10s**

You can stop sharing lasers with a Distributed CTP10 from the Controller, or directly from a Distributed CTP10.

When you disconnect a Distributed CTP10 from the Controller, the laser configuration that was retrieved from the Controller is immediately removed from the CTP10.

### ***To stop laser sharing from the Controller CTP10:***

1. On the Controller CTP10: in the task bar, click the **Laser sharing** menu.

The menu displays all the connected CTP10s.

2. Click the **Close connection** button corresponding to the Distributed CTP10 with which you want to stop sharing lasers.

The CTP10 is immediately disconnected from the Controller CTP10. The Controller still shares its lasers with the remaining Distributed CTP10s. If there is not more Distributed CTP10 connected to the Controller, the laser sharing function is automatically stopped on the Controller CTP10.

### ***To stop laser sharing from a Distributed CTP10:***

1. On the Distributed CTP10: in the task bar, click the **Laser sharing** menu.

2. Click the **Close connection** button.

The CTP10 is immediately disconnected from the Controller CTP10. The laser configuration is removed from the CTP10. The Controller still shares its lasers with the remaining Distributed CTP10s. If there is not more Distributed CTP10 connected to the Controller, the laser sharing function is automatically stopped on the Controller CTP10.

## Operating CTP10s in Laser Sharing Mode

Once you have entered the laser sharing mode, you can operate the Controller CTP10 as you would do in standalone mode (without laser sharing), as illustrated in *Overview Diagram* on page 55. The Distributed CTP10s can use the lasers shared by the Controller for their acquisition scans.

### **To operate CTP10s in laser sharing mode:**

1. Connect the Controller CTP10 to the lasers as explained in *Defining and Controlling Your Laser(s)* on page 87.

The Controller CTP10 controls the lasers for all Distributed CTP10s. You cannot modify the laser configuration from the Distributed CTP10s.

2. Define your subsystems (on the Controller CTP10 and on the Distributed CTP10s) as explained in *Setting up Your Subsystem* on page 101.

You select the lasers you want to use on the Controller CTP10. The laser configuration made on the Controller subsystem is automatically applied to the Distributed CTP10s and cannot be modified from the Distributed CTP10s.

Any other element of the subsystem (OPMx, DUT) can be configured independently on the Controller and on Distributed CTP10s.

All CTP10s must be equipped with the same measurement module: IL RL OPM2 module for IL and RL measurements or IL PDL module for IL and PDL measurements.

3. Define the scan parameters as explained in *Defining the Scan Parameters* on page 115.

On the Controller CTP10, the scan parameters that you define are applied to all the Distributed CTP10s.

On the Distributed, you can only select the scan mode and the scan trigger output. All other parameters are defined by the Controller CTP10.

4. Reference the subsystem as explained in *Referencing the Subsystem* on page 123.

You can perform the wavelength referencing operation independently on the Controller CTP10 and on the Distributed CTP10s.

On the Distributed CTP10s, you can only perform the referencing scan if the Controller is scanning (measurement scan or referencing scan). If the Controller is not scanning, the Distributed CTP10s wait for the next sweep from the Controller CTP10 to synchronize with it and perform the referencing scan.

5. Perform measurement scans as explained in *Performing Acquisition Scans* on page 133.

The acquisition scans you perform on the Controller CTP10 synchronize with all the Distributed CTP10s and enable them to perform acquisition scans.

On the Distributed CTP10s, you can start and stop single or continuous measurement scans. The acquisition on Distributed CTP10s is only possible if a scan is in progress on the Controller CTP10.

6. Configure, display and analyze traces: see *Displaying and Handling Traces* on page 143, *Analyzing Traces* on page 155 and *Handling Subsystem Data* on page 112.

You can configure, display and analyze traces on Controller and Distributed CTP10s as you would do in standalone mode (without laser sharing). There is no difference between Controller and Distributed CTP10s on these operations.


# 7 Defining Your Subsystem

A subsystem is a measurement system made of:

- One to four laser source(s) that the CTP10 will sweep,
- One device under test (DUT),
- One IL RL OPM2 or IL PDL or IL PDL OPM2 module to perform measurements,
- One SCAN SYNC module for optical sampling,
- OPMx modules providing detectors for measurements.

If your IL/PDL test setup requires more than 42 detectors, the daisy chaining mode enables you to use additional detectors from another CTP10 (up to 60 additional detectors) for simultaneous measurements. For more details, see *Using Additional OPMs (Daisy Chaining mode)* on page 107.


The **Subsystem** window enables you to configure, display and analyze your measurements:



### Creating a Subsystem

The following procedure gives all the steps to create an entire subsystem.

#### To create an entire subsystem:

1. In the task bar, click the  **Subsystem** button.

The **Subsystem** main window appears, it enables you to configure, display and analyze your measurements.

2. Configure your subsystem as follows:




- a Only if needed: if your test setup requires more than 42 detectors, enter the Daisy chaining mode as explained in *Using Additional OPMs (Daisy Chaining mode)* on page 107.
- b Graphically configure your test setup using the **Subsystem setup** menu as explained in *Setting up Your Subsystem* on page 101.
- c Define the scan measurement parameters and reference your subsystem: see *Defining the Scan Parameters* on page 115 and *Referencing the Subsystem* on page 123.
- d Configure the wanted trace settings: see *Selecting the Traces to Acquire* on page 129.
- e Test your DUT: see *Performing Acquisition Scans* on page 133.
- f Adapt the graph display to your needs: see *Adjusting the Graph Display* on page 148.
- g Analyze the traces: *Analyzing Traces* on page 155.

3. Handle traces and subsystem data: see *Handling Subsystem Data* on page 112 and *Handling Traces Displayed on Graph* on page 143.

The **Subsystem setup** menu enables you to graphically configure your physical test set-up and define all the modules and instruments that are part of your setup.

The following figure gives an example of a subsystem setup with one laser.



The diagram illustrates a 12-channel photonic quantum circuit. The input section consists of four lasers (TLS1, TLS2, TLS3, TLS4) and a central 'DUT' block. The output section shows a 12-channel array of detectors (DUT1 to DUT22). The circuit is designed to route signals from the lasers through various components (beam splitters, waveguides) to the detectors. The output channels are labeled with their respective detector numbers and the corresponding input laser.

**Input Lasers:**

- TLS1:** Laser 1, EXFO® T100S-HP
- TLS2:** Laser 3, EXFO® T100S-HP
- TLS3:** Laser 4, EXFO® T100S-HP
- TLS4:** Laser 2, VIAVI® mSWS-A1SLS

**Output Detectors:**

- DUT1:** 1, TLS IN1
- DUT2:** 2, TLS IN2
- DUT3:** 3, TLS IN3
- DUT4:** 4, TLS IN4
- DUT5:** 5, TLS IN5
- DUT6:** 6, TLS IN6
- DUT7:** 7, TLS IN7
- DUT8:** 8, TLS IN8
- DUT9:** 9, TLS IN9
- DUT10:** 10, TLS IN10
- DUT11:** 11, TLS IN11
- DUT12:** 12, TLS IN12


**Output Channels:**

- Channel 1:** 1, TLS IN1
- Channel 2:** 2, TLS IN2
- Channel 3:** 3, TLS IN3
- Channel 4:** 4, TLS IN4
- Channel 5:** 5, TLS IN5
- Channel 6:** 6, TLS IN6
- Channel 7:** 7, TLS IN7
- Channel 8:** 8, TLS IN8
- Channel 9:** 9, TLS IN9
- Channel 10:** 10, TLS IN10
- Channel 11:** 11, TLS IN11
- Channel 12:** 12, TLS IN12

## Defining Your Subsystem

### Setting up Your Subsystem

The following figure gives an example of a subsystem setup in Daisy chaining mode (see *Using Additional OPMs (Daisy Chaining mode)* on page 107 for details): the Primary CTP10 is connected to an additional CTP10 (Secondary) through a BNC cable to be able to use its OPMs for measurements. An additional tab is available for the Secondary CTP10. The following figure displays the Secondary tab.







## Selecting/Removing the Laser(s)

This section explains how to select the laser(s) that you want to add to the subsystem.

With the FBC module, you can add up to four lasers in the subsystem; once added to the subsystem, the lasers become available for scanning (see *Performing Measurement Scans* on page 115).

In laser sharing mode (see *Sharing the Lasers with Several CTP10s* on page 94), you select the lasers you want to use on the Controller CTP10. The laser configuration made on the Controller subsystem is automatically applied to the Distributed CTP10s and cannot be modified from the Distributed CTP10s.

### To add a laser to the subsystem:

1. In the task bar, click the  Subsystem button.
2. Make sure the lasers you want to add to the subsystem are connected to the CTP10 and properly configured (see *Controlling the Lasers* on page 91).
3. In the **Subsystem** window, click the **Subsystem setup** button.
4. In the TLS1 rectangle, click the  button.

The **Laser** menu displays all lasers that have been added to the laser window (see *Adding and Connecting the Laser(s)* on page 87).

If a laser is already selected, the trigger method and destination is also displayed in the menu: it depends on the links set for the laser and it is automatically selected.

5. Select the laser you want to add to the subsystem.

If you add multiple lasers: the CTP10 will sweep all lasers selected for the scan (see *Defining the Scanning Lasers* on page 116) from TLS1 to TLS4 (if any), whatever the wavelength/frequency limits set for the lasers.


The selected laser appears as TLS1 of the subsystem, with its corresponding output ports. It is also automatically selected for scanning in the **Scan** menu (see *Defining the Scan Parameters* on page 115).

In laser sharing mode the laser selected on the Controller CTP10 automatically appears on the Distributed CTP10s subsystem setup.

6. If needed, perform step 4 and 5 with TLS2, TLS3 and TLS4.

For continuous traces, make sure that the maximum wavelength physical limit of a laser overlaps by 5 nm the minimum wavelength limit of the next laser.

### To remove a laser:

To remove a selected laser from the subsystem, click the laser  button and click the **Clear Selection** button.

## Defining your DUT



The DUT has one laser input and up to 120 output ports. You can define the number of outputs and the way to display them.

In laser sharing mode, you can perform this operation independently on the Controller CTP10 and on the Distributed CTP10s.

In daisy chaining mode, the Secondary tab displays the available DUT outputs.

### To define the DUT of your subsystem:

1. In the Subsystem window, click the  button.
2. In the DUT rectangle, click the  button and define your DUT as explained in the following table.

Parameter	Description
<b>Name</b>	Click the field to modify the DUT name in the <b>Subsystem setup</b> menu.
<b>Number of outputs</b>	Number of output ports of your DUT. Click the value to modify it. You can also use the  and  buttons at the left of the DUT output ports to increase/decrease the number of ports.
<b>Outputs per line</b>	Display setting: number of output ports you want to display in the visible line of the DUT panel. Click the value to modify it.
<b>Automatic output links</b>	Automatically links all the output ports of the DUT to the available detectors of the modules plugged into the CTP10 mainframe. In daisy chaining mode, this button only applies to the module detectors displayed in the current tab.
<b>Disconnect output links</b>	Automatically disconnect all the existing links between the output ports of the DUT and the CTP10 connectors. In daisy chaining mode, this button only applies to the module detectors displayed in the current tab.

## Linking Instruments of the Subsystem

Once all instruments are defined and selected, you can graphically link the instruments to each others to set-up your subsystem and have it ready for measurements.

If a laser is selected for scanning in the **Scan** menu (see *Defining the Scan Parameters* on page 115) but is not connected to another instrument of the subsystem, the scan won't be able to start.

For each measuring connector (detector or TF/BR output) used in the subsystem, a trace group is created in the **Trace setup** pane.

If you physically remove a module from the mainframe, all corresponding subsystem links and traces are deleted.

- In laser sharing mode (see *Sharing the Lasers with Several CTP10s* on page 94), you define the links between the TLS, the FBC (if any) and the IL RL OPM2 or IL PDL modules on the Controller CTP10. These links are automatically applied to all the Distributed CTP10s and cannot be modified from the Distributed CTP10s (synchronization between the Controller CTP10 and Distributed CTP10s may take a few seconds).  
All Distributed CTP10s must use the same measurement module as the Controller CTP10 (IL RL OPM2 module or IL PDL module).  
You can define any other link (between the IL RL OPM2 or IL PDL module, the SCAN SYNC module and the DUT) independently on the Controller CTP10 and on Distributed CTP10s.
- In daisy chaining mode (see *Using Additional OPMs (Daisy Chaining mode)* on page 107), an additional tab is available in the **Subsystem setup** menu for the Secondary CTP10 that is connected to the Primary CTP10. This tab enables you to define the trigger ports used to link the Primary and Secondary CTP10s, and to define the measuring detectors that you want to use in your test setup.

### To define links between instruments:

1. Make sure you have physically connected your instruments to each others: see *Installing Your Test Setup* on page 55.
2. In the Subsystem window, click the **Subsystem setup** button.
3. Link the instruments by drag & drop so that it reflects your physical test setup: click the output port icon of an instrument, drag the link to the input port of the instrument to which you want to connect it, and release it to create the link.
  - 3a. Link the laser(s) to the **TLS IN** port of the IL RL OPM2, IL PDL or IL PDL OPM2 module, or to the **TLS IN** ports of the FBC module, depending on your setup.  
  
If you use an FBC module, link the **FBC OUT** port to the **TLS IN** port of the IL RL OPM2 or IL PDL OPM2 module (the FBC module is not compatible with the IL PDL module).
  - 3b. For data sampling: link the **OUT TO SCAN SYNC** (or **OUT1**) port of the IL RL OPM2 or IL PDL or IL PDL OPM2 module to the **TLS IN** port of the SCAN SYNC module to use the optical trigger.

## Defining Your Subsystem

### Setting up Your Subsystem

---

- 3c.** If you use the daisy chaining mode: in the Secondary tab, link a **TRIG OUT** port of the Primary to the **TRIG IN** port used on the Secondary.
- 3d.** Link the **OUT TO DUT** port of the IL RL OPM2 or IL PDL or IL PDL OPM2 module to the **Input** port of the DUT.
- 3e.** Link the output ports of the DUT to the **IN** detector ports of the OPMx modules or of the IL RL OPM2 or IL PDL OPM2 module if it is used for acquisition.


In daisy chaining mode, link all the output ports of your DUT to the **IN** ports of the OPMx modules in the Secondary CTP10 tab.

Impossible connections are greyed and the color of the links depends on the source of the links:

- If the link source is a laser, the link is blue.
- If the link source is the DUT, the link is yellow.
- If the link source is a CTP10 module, the link is green.
- If the link source is a CTP10 trigger (in daisy chaining mode), the link is grey.
- A selected link is red.

The connection between two instruments is created and configured.

#### **To modify/remove links:**

- To modify a link, re-define the link by drag & drop.  
The existing link is automatically replaced by the new one.
- To remove a link between two instruments, do one of the following:
  - Right-click the link and select **Remove Link**.
  - Click the input or output port for which you want to remove the link, drag the link to a blank area of the subsystem setup menu and release it to remove the link.
- To remove all the output links of a DUT: in the DUT rectangle, click the  button and click the **Disconnect output links** button.

## Using Additional OPMs (Daisy Chaining mode)

The **Daisy chaining** function enables you to use additional detectors to perform your IL/PDL measurements by using the OPM modules located into another CTP10 mainframe, as illustrated in *Typical IL/PDL test setup with 2 CTP10s connected in a daisy chain* on page 62.

The CTP10 displaying measurement results is defined as the **Primary** CTP10 and the other CTP10 from which the optical detectors are used is defined as the **Secondary** CTP10.

Once you have entered the daisy chaining mode and defined a CTP10 as Primary, you control all detectors located on Secondary CTP10s from the Primary CTP10 and you cannot perform any configuration or measurement operation from the Secondary CTP10s.

The following sections gives details on how to use the daisy chaining function:

- *Connecting the Primary CTP10 to a Secondary CTP10* on page 108.
- *Disconnecting the Primary CTP10 from the Secondary CTP10* on page 110
- *Operating CTP10s in Daisy Chaining Mode* on page 110.

### **Requirements:**

- All CTP10 mainframes must be connected to the LAN network, with different names (see *Renaming the Instrument* on page 54).
- All CTP10 mainframes must be equipped with the same software package version.
- The Primary CTP10 mainframe must be equipped with a SCAN SYNC module for optical sampling and an IL PDL or IL PDL OPM2 module for measurements.
- Daisy chaining is not compatible with the IL RL OPM2 module.
- The Secondary CTP10 mainframe must be equipped with OPM modules.
- You cannot use the Daisy chaining function in combination with the Laser sharing function.

## Connecting the Primary CTP10 to a Secondary CTP10

As soon as you connect a CTP10 to another in the **Daisy chaining** menu, you enter the daisy chaining mode: the CTP10 from which you have open the connection becomes the Primary and the CTP10 connected to the Primary is immediately set to Secondary.

Before starting, make sure that the CTP10s you want to use are connected by LAN, with different names (see *Renaming the Instrument* on page 54).

### To enter the daisy chaining mode:

1. In the task bar, click the **Daisy chaining** menu.

The lower part of the menu enables you to connect to remote CTP10s.

Information

Current CTP10 daisy chaining status	No daisy chaining detected
Current CTP10 daisy chaining Primary port	53000
Current CTP10 daisy chaining Secondary port	53002
Current CTP10 IP	169.254.81.73

⚠ Opening a connection to a CTP10 removes all its existing subsystem configuration. The current CTP10 scan setup will be applied to the connected CTP10.

Secondary CTP10s

1 Secondary CTP10 Disconnected	Secondary port 53002	Open connection
	IP 192.168.1.44	Close connection

**Daisy chaining**

2. In the **Daisy chaining** menu, in the **Secondary CTP10s** area, enter the Secondary port and IP address of the CTP10 with which you want to share the lasers:
  - **Secondary port:** enter the daisy chaining secondary port of the CTP10 to which you want to connect. The Secondary port of a CTP10 is displayed in the **Daisy chaining** menu, in the **Current daisy chaining Secondary port** field. Default value: 53002.
  - **IP:** enter the IP address of the CTP10 to which you want to connect. The IP address of a CTP10 is displayed in the **Daisy chaining** menu, in the **Current CTP10 IP** field.
3. Make sure that the CTP10 from which you want to use the detectors is not busy (not scanning nor analyzing) and is not already a Primary or a Secondary CTP10, or used in laser sharing mode (see *Sharing the Lasers with Several CTP10s* on page 94).
4. Click the **Open connection** button.

The current CTP10 is automatically set to Primary and the connected CTP10 is immediately set to Secondary:

- On the Secondary CTP10, the GUI is not available (except the **Close connection** button, see *Disconnecting the Primary CTP10 from the Secondary CTP10* on page 110).
- The subsystem configuration made on the Primary is automatically applied to the Secondary CTP10 and cannot be modified from the Secondary CTP10.

### To modify the daisy chaining ports:

The daisy chaining ports enable the Primary CTP10 to set the communication with the Secondary CTP10s.

You can use the default daisy chaining ports to set the communication between the Primary CTP10 and Secondary CTP10s. These ports can be identical on all CTP10s involved in the daisy chaining configuration.


You should modify the default daisy chaining ports only in case a specific network inconsistency occurs (firewall restriction or application already running on the same port).

1. Make sure that the CTP10 is not busy (not scanning nor analyzing).
2. In the task bar, click the **Daisy chaining** menu.

The upper part of the menu enables you to modify the daisy chaining ports.

Information

Current CTP10 daisy chaining status	No daisy chaining detected
Current CTP10 daisy chaining Primary port	53000
Current CTP10 daisy chaining Secondary port	53002
Current CTP10 IP	169.254.81.73



Opening a connection to a CTP10 removes all its existing subsystem configuration. The current CTP10 scan setup will be applied to the connected CTP10.

Secondary CTP10s

1

Secondary CTP10

Disconnected

Secondary port


53002

Open connection

IP

192.168.1.44

Close connection


Daisy chaining

3. To modify the Primary port of the current CTP10, click the **Current CTP10 daisy chaining Primary port** field (default value: 53000).
4. To modify the Secondary port of the current CTP10, click the **Current CTP10 daisy chaining Secondary port** field (default value: 53002).

### Disconnecting the Primary CTP10 from the Secondary CTP10

You can close the Daisy chaining connection from the Primary CTP10, or directly from the Secondary CTP10. Closing the Daisy chaining connection clears the analysis data.

When you disconnect the Secondary CTP10 from the Primary, the entire configuration used by the Primary CTP10 is immediately removed from the CTP10.

#### **To close the daisy chaining connection from the Primary CTP10:**

1. On the Primary CTP10: in the task bar, click the **Daisy chaining** menu.

The menu displays the connected CTP10.

2. Click the **Close connection** button corresponding to the Secondary CTP10 from which you want to stop using detectors.

The CTP10 is immediately disconnected from the Secondary CTP10, and the daisy chaining function is automatically stopped on the Primary CTP10.

#### **To close the daisy chaining connection from a Distributed CTP10:**

On the Secondary CTP10, click the **Close connection** button.

The CTP10 is immediately disconnected from the Primary CTP10. The configuration used by the Primary CTP10 is removed from the CTP10.

### Operating CTP10s in Daisy Chaining Mode

Once you have entered the daisy chaining mode, you can operate the Primary CTP10 as you would do in standalone mode (without daisy chaining), and include the detectors located into the Secondary CTP10 mainframe in your acquisition scans and measurements, as if the detectors were all located into the same mainframe.

#### **To operate CTP10s in daisy chaining mode:**

1. Connect the laser to the Primary CTP10 (as explained in *Defining and Controlling Your Laser(s)* on page 87).
2. From the Primary CTP10, define your subsystem as explained in *Setting up Your Subsystem* on page 101.

In the Subsystem setup menu, in the Secondary CTP10 tab:

- define the additional detectors located into the Secondary CTP10 mainframe that you want to include in your acquisition scans and measurements.
- define the triggers used for daisy chaining by linking a **TRIG OUT** port of the Primary to the **TRIG IN** port used on the Secondary.

3. From the Primary CTP10, define the scan parameters as explained in *Defining the Scan Parameters* on page 115.

On the Primary CTP10, the scan parameters that you define are applied to all the detectors selected on the Secondary CTP10s.

4. From the Primary CTP10, reference the subsystem as explained in *Referencing the Subsystem* on page 123.
  - You can reference all the detectors located on the Secondary CTP10 from the Primary CTP10.



- You cannot use a detector located on the Secondary CTP10 to perform the wavelength referencing operation.
- 5. From the Primary CTP10, perform measurement scans as explained in *Performing Acquisition Scans* on page 133.

The acquisition scans you perform on the Primary CTP10 includes all the detectors located on the Secondary CTP10.
- 6. From the Primary CTP10: configure, display and analyze traces (see *Displaying and Handling Traces* on page 143, *Analyzing Traces* on page 155 and *Handling Subsystem Data* on page 112).

All traces acquired from detectors located on the Primary and on the Secondary CTP10 are displayed on the same graph on the Primary CTP10. The traces acquired from detectors located on the Secondary CTP10 are displayed on graph underneath the traces acquired from detectors located on the Primary CTP10.

You cannot analyze live traces acquired from detectors located on the Secondary CTP10.

## Handling Subsystem Data

You can save the entire subsystem configuration, the screenshots of the subsystem and the analysis results. See the following sections for details:

- *Saving a Subsystem* on page 112
- *Loading an Existing Subsystem* on page 113

In daisy chaining mode, you can save the entire subsystem configuration, including all data retrieved from the detectors located on the Secondary CTP10. To load a subsystem saved in daisy chaining mode, make sure to enter the daisy chaining mode before loading the subsystem.

### Saving a Subsystem

You can save the entire subsystem configuration into a \*.CTP10 file, screenshots of the subsystem in \*.jpg or \*.png files and analysis results in \*.csv format.

See the following procedure for details.

#### **To save a subsystem:**

1. In the **Subsystem** window, click the **Save** button located at the bottom right of the window.
2. Select the type of file to save:
  - **Settings (\*.CTP10)**: saves the whole subsystem setup, all the measurement and display parameters set for the subsystem. It also saves in a separate folder (same name as the settings file: <filename>.CTP10 Traces) all the traces in their current state (in \*.tra format), analysis parameters (\*.ana format file), analysis results (\*.anaresu format file), detectors reference data (.trc format file) and detectors quick reference data (.trc format file).
  - **Analysis Results (\*.csv)**: saves the analysis results in a .csv file. You cannot load analysis results back to the system.
  - **Screenshot (\*.jpg)**: saves the displayed window in .jpg format.
  - **Screenshot (\*.png)**: saves the displayed window in .png format.
3. Select a location and type a name for the file to save.
4. Click the **Save** button.

A confirmation message appears.

### Loading an Existing Subsystem

A \*.CTP10 file contains the subsystem setup, all the referencing, measurement and analysis parameters set for the subsystem and analysis results. When you open a \*.CTP10 file on a subsystem, all this configuration and the traces associated with the subsystem are retrieved.

#### To open an existing subsystem:

1. In the Subsystem window, stop the scanning process (see *Performing Acquisition Scans* on page 133).
2. In the **Subsystem** window, click the **Open** button located at the bottom right of the window.
3. Select the location of the subsystem.
4. Select the type of file to open
  - **Settings (\*.CTP10)**: to open a previously saved subsystem.
  - **Default Settings**: to open a new blank subsystem.
5. Click the **Open** button.

A confirmation window appears.

6. Click **Continue**.

The subsystem setup is loaded, with all the configuration settings and associated traces.

If an element is missing (the lasers connected to the CTP10 have changed, instruments are unavailable, the trace folder is missing), the subsystem is still loaded but some parts may be missing. A message informs you of the incompleteness of the loaded subsystem.

### Defining Subsystem Spectral and Power Units

You can change the spectral and power units for the whole subsystem: graph scales, scan and analysis settings, measured values, analysis results as explained in the following procedure.

In laser sharing mode (see *Sharing the Lasers with Several CTP10s* on page 94), the subsystem units are defined on the Controller CTP10 and apply to all the Distributed CTP10s (synchronization between the Controller CTP10 and Distributed CTP10s may take a few seconds). You cannot modify the subsystem units from the Distributed CTP10s.

#### To define the spectral and power units:

In the **Subsystem** window, click one of the following option located at the top-right of the window:

- Select **dB/Ratio** to modify the power unit.
- Select **nm/THz** to modify the spectral unit.



## 8 Performing Measurement Scans

Once your subsystem is properly configured, you can start to test the DUT scanning, as explained in this section.

### **Measurement requirements for optimum system performance:**

- Reference the optical path to every detector prior to connect the DUT to the setup: after each module removal and module insertion, or after any change in environmental conditions (see *Referencing the Subsystem* on page 123).
- Keep fiber optic connectors clean at all times (see *Cleaning Optical Connectors* on page 216).
- Avoid tight bends of fibers.
- For IL and RL measurements: if you use an SMF patchcord to link the laser to the IL RL OPM2 module (or SMF patchcords if you use an FBC module), maintain static these fibers between the referencing scan and the measurement scans.
- For RL measurements: use APC connectors on the OPMs.
- For PDL measurements:
  - Use PC connectors on the OPMs.
  - Maintain static the fibers during the four sweeps of the IL/PDL reference or measurement.

## Defining the Scan Parameters

You can access the scan parameters from the subsystem main window. The scan parameters you select to perform the acquisition must be similar to the one selected for the referencing measurements.


In laser sharing mode (see *Sharing the Lasers with Several CTP10s* on page 94), the following scan parameters defined on the Controller CTP10 are applied to all the Distributed CTP10s: **TLS parameters**, **Sweep** parameters (range, span, center and sampling), **Scan start** and **TLS outputs**. Modifying a shared parameter on the Controller CTP10 aborts the scanning operations in progress on all Distributed CTP10s.


On the Distributed CTP10s, you can only select the scan mode and output trigger. All other parameters are defined by the Controller CTP10.

### **Before starting:**

- Make sure your instruments are physically connected to each others (see *Installing Your Test Setup* on page 55).
- Make sure your subsystem is properly configured in the **Subsystem Setup** panel (see *Defining Your Subsystem* on page 99) and reflects the physical connections.

### **To set scan parameters:**

1. In the **Subsystem** window, click the  button located at the left of the **Scan** button. The scan menu appears.
2. Set the scan parameters for you measurement according to the instructions given in the following sections:
  - *Defining the Scanning Lasers* on page 116
  - *Defining the Sweep Parameters* on page 119
  - *Defining the General Scan Settings* on page 121

3. Reference your subsystem using the parameters selected for measurement: see *Referencing the Subsystem* on page 123.
4. Click the  button or anywhere on the screen outside the menu to exit.

## Defining the Scanning Lasers

The lasers displayed in the **Scan** menu are the one that have been added to the CTP10 in the **Subsystem setup** menu. The **Scan** menu enables you to select and configure the lasers you want to use for scanning.


The CTP10 will sweep the lasers you select for the scan from TLS1 to TLS4 (if any), whatever the wavelength/frequency limits set for the lasers.

In laser sharing mode (see *Sharing the Lasers with Several CTP10s* on page 94), you must define the scanning lasers and TLS output settings on the Controller CTP10. These parameters are automatically applied to all the Distributed CTP10s (this operation may take a few seconds) and cannot be modified from the Distributed CTP10s.

### To define the lasers parameters for scanning:

1. In the **Scan** menu, select the check box of the laser(s) you want to use for scanning.

Make sure the selected lasers are connected to the appropriate module of the subsystem in the **Subsystem setup** menu. Otherwise the scan won't be able to start.



The screenshot shows the CTP10 Scan menu interface. It features four panels for TLS parameters (Laser 1 to Laser 4). Each panel includes a laser icon, model (EXFO T100S-HP), wavelength range (Low wav. to High wav.), speed (nm/s), power (dBm), and averaging time (Automatic/Manual). Lasers 1 and 2 are selected with checkmarks. Below these is a 'Sweep' section with start, stop, span, and center wavelength values, and a 'Scan start' section with Manual/Triggered options and source/slope settings. To the right is a 'TLS outputs' section with stabilization time and a 'Keep enabled after scan stop' checkbox. At the bottom, there are 'Scan mode' (Single/Continuous) and 'Scan trigger output' (Destination/Type) settings. A status bar at the very bottom shows 'O', 'E', 'S', 'C', 'L', 'U'.

- For each selected laser, define the scanning parameters according to the instructions given in the following table:

Setting	Description
<b>Low wav./freq.</b> <b>High wav./freq.</b>	<p>Wavelength/Frequency sweeping range of the laser: the <b>Low wav.</b> value must be 2.5 nm higher than the minimum wavelength limit of the laser, and the <b>High wav.</b> value must be 2.5 nm lower than the maximum wavelength limit of the laser.</p> <p>In case of multiple lasers, the minimum and maximum physical wavelength limits of each laser cannot be reached: for a continuous trace, make sure that the maximum wavelength limit of a laser overlaps by 5 nm the minimum wavelength limit of the next laser.</p> <p>If sweeping ranges of lasers overlap, the first laser sweeps until it reaches the center wavelength of the overlapping range (between the low wavelength of the second laser and the high wavelength of the first laser).</p>
<b>Speed</b>	<p>Laser sweeping speed. The value set here replaces the speed value set in the laser configuration menu (see <i>Controlling the Lasers</i> on page 91).</p> <p>If you use multiple TLS, you can set a different speed value for each laser.</p>
<b>Power</b>	<p>Optical output power of the laser used for the scan. The value set here replaces the power set in the laser configuration menu (see <i>Controlling the Lasers</i> on page 91).</p> <p>Recommended values are:</p> <ul style="list-style-type: none"> <li>➤ EXFO T100S-HP O and CL models: +10 dBm</li> <li>➤ EXFO T100S-HP O+, ES, SCL and CLU models: +8 dBm</li> <li>➤ VIAVI mSWS-A1SLS: +3 dBm</li> </ul>
<b>Averaging Time</b>	<p>Period of time during which you want the laser power to be averaged on all the detectors of the subsystem:</p> <ul style="list-style-type: none"> <li>➤ <b>Automatic:</b> the averaging time is automatically set regarding the laser <b>Speed</b> value. The higher you set the speed, the shorter the automatic averaging time is.</li> <li>➤ <b>Manual:</b> enter the wanted time value.</li> </ul> <p>If you use multiple TLS, you can set a different averaging time value for each laser.</p>

## Performing Measurement Scans

### Defining the Scan Parameters

---

3. Define the optical output settings of the lasers used for the scan, as follows:

Setting	Description
<b>Stabilization Time</b>	<p>Period of time during which you want the laser to stabilize before starting the acquisition. This period of time only applies if the laser output is disabled at the beginning of the scan.</p> <p>In case of multiple lasers selected for the scan, each laser stabilizes one after the other before the first laser sweep.</p> <p>If the laser output is already enabled at scan start, this parameter is not taken into account.</p>
<b>Keep enabled after scan stop</b>	<p>➤ <input checked="" type="checkbox"/>: the laser optical output stays enabled after scan stop. The laser stabilization time will not be applied for the next scan. In case of multiple lasers selected for the scan, this parameter applies to all lasers.</p> <p>➤ <input type="checkbox"/> (default): the laser optical output is disabled when the scan stops.</p>





### Defining the Sweep Parameters

In the **Scan** menu, the **Sweep** area enables you to specify the sweep range and sampling for your measurements. It also enables you to reference your test setup with the parameters defined. The sweep settings you use to perform the power referencing must be the same as the one you intend to use for measurements.


In laser sharing mode (see *Sharing the Lasers with Several CTP10s* on page 94), you define the sweep parameters on the Controller CTP10. These parameters are automatically applied to all the Distributed CTP10s and cannot be modified from the Distributed CTP10s.

#### To set the sweep parameters:

1. In the **Subsystem** window, click the  button located at the left of the **Scan** button to access the sweep parameters.



The screenshot displays the 'Subsystem' window with four TLS parameter panels (TLS1, TLS2, TLS3, TLS4) and a central Sweep panel. The Sweep panel is highlighted with a red box. The Sweep panel includes the following fields and options:





- Sweep**
  - Start: 1265.0000 nm
  - Stop: 1505.0000 nm
  - Span: 240.0000 nm
  - Center: 1385.0000 nm
  - Sampling: 1.0 pm
- Scan start**
  - ☒ Manual
  - ☐ Triggered
- Scan mode**
  - ☐ Single
  - ☒ Continuous
- Scan trigger output**
  - Destination: None
  - Type: Window
  - Inverted logic: ☐
- TLS outputs**
  - Stabilization time: 0.0 s
  - Keep enabled after scan stop: ☒
- Wavelength reference**
  - Wavelength reference: 

The bottom status bar is also highlighted with a red box and contains the following text: ... O E S C L U ...

## Performing Measurement Scans

### Defining the Scan Parameters

2. In the **Scan** menu, set the sweep range by using one of the available range parameters described in the following table.

Setting	Description
<b>Start/Stop</b>	Wavelength/frequency overall sweeping range. The max/min wavelength or frequency range is defined in <i>Technical Specifications</i> on page 3). The sweep start wavelength must be 2.5 nm higher than the minimum wavelength limit of your lowest wavelength laser; and the sweep stop wavelength must be 2.5 nm lower than the maximum wavelength limit of your highest wavelength laser.
<b>Span/Center</b>	Wavelength/frequency sweeping span.
	Sets the sweeping range to the maximum possible wavelength range (see <i>Technical Specifications</i> on page 3).
	Sets the sweeping range to the zoom parameters displayed on graph.
	Sets the sweeping range to the limits specified by the positions of A and B markers (for more details on markers, see <i>Performing Manual Measurements With Markers</i> on page 152).
<b>O/E/S/C/L/U buttons</b>	Wavelength sweeping range, defined by ITU band selection. The blue line pictures the selected bandwidth. <ul style="list-style-type: none"> <li>➤ To select a single band, click the corresponding button twice.</li> <li>➤ To select several bands, click the corresponding adjacent buttons one after another.</li> <li>➤ To modify the boundaries of a band, use the <b>Sweep</b> area of the scan menu.</li> </ul> <div style="text-align: center;">  <p>1240–1260 nm                      1675–1680 nm</p> </div> <p>Selecting a band modifies the values defined in the <b>Sweep</b> area.</p>

3. Define the sampling parameter using the instruction given in the following table.

Setting	Description
<b>Sampling</b>	Spectral sampling resolution: the value sets the sampling resolution of the SCAN SYNC module.


Defining the General Scan Settings

The following procedure explains how to set the general scan parameters.

In laser sharing mode, all the general settings are available on the Controller CTP10, and some of them are not applied to the Distributed CTP10s: **Scan start**, **Scan mode** and **Scan trigger output** (for more details on **Scan trigger output**, see *Generating Output Trigger Signals* on page 137).


On the Distributed CTP10, the **Scan start** can only be manual. You can select the **Scan mode** and **Scan trigger output** independently from the Controller.

To set the general scan parameters:

- 1. In the Subsystem window, click the  button located at the left of the **Scan** button to access the scan parameters.

TLS1 parameters

Laser 1



EXFO® T100S-HP

Low wav. 1260.000 nm

High wav. 1360.000 nm

Speed 100 nm/s


Power 10.00 dBm

Averaging time

☒ Automatic (0.01 ms)

☐ Manual 0.001 ms

Laser 2



EXFO® T100S-HP

Low wav. 1350.000 nm

High wav. 1510.000 nm

Speed 100 nm/s


Power 8.00 dBm

Averaging time

☒ Automatic (0.01 ms)

☐ Manual 0.001 ms

Laser 3



EXFO® T100S-HP

Low wav. 1500.000 nm

High wav. 1680.000 nm

Speed 100 nm/s

Power 8.00 dBm

Averaging time

☐ Automatic (0.01 ms)

☐ Manual 0.001 ms

Laser 4



EXFO® T100S-HP

Low wav. 1240.000 nm

High wav. 1380.000 nm

Speed 100 nm/s

Power 8.00 dBm

Averaging time

☐ Automatic (0.01 ms)

☐ Manual 0.001 ms

Sweep

Start 1265.0000 nm

Stop 1505.0000 nm

Span 240.0000 nm

Center 1385.00000 nm

Full

Zoom

Fit

Sampling 1.0 pm

☐ Reference...

☐ Quick reference...

Scan start

☒ Manual

☐ Triggered

Source None

Slope Positive

Scan mode

☐ Single

☒ Continuous

Scan trigger output

Destination None

Type Window

Inverted logic

TLS outputs

Stabilization time 0.0 s

Keep enabled after scan stop ☒

Wavelength reference



Wavelength reference...

...

O

E

S

C

L

U

...

## Performing Measurement Scans

### Defining the Scan Parameters

---

2. In the **Scan** menu, configure the scan by using the parameters described in the following table.

Setting	Description
Scan start	<ul style="list-style-type: none"><li>➤ <b>Manual</b> You perform the acquisition manually, by following the procedure detailed in <i>Performing Acquisition Scans</i> on page 133.</li><li>➤ <b>Triggered</b> The CTP10 waits for the defined trigger signal to perform the optical acquisition. In laser sharing mode (see <i>Sharing the Lasers with Several CTP10s</i> on page 94), this function is not available on Distributed CTP10s.<ul style="list-style-type: none"><li>➤ <b>Source</b>: select the TRIG IN port that provides the triggered signal.</li><li>➤ <b>Slope</b>: slope of the signal that triggers the scan:<ul style="list-style-type: none"><li>- <b>Positive</b>: the scan is performed when the received signal rises.</li><li>- <b>Negative</b>: the scan is performed when the received signal falls.</li></ul></li></ul></li></ul>
Scan mode	<ul style="list-style-type: none"><li>➤ <b>Single</b> The CTP10 performs a single sweep of the transfer function (according to the defined measurement traces) and then stops.</li><li>➤ <b>Continuous</b> The CTP10 performs a continuous series of sweeps until you click the <b>Abort</b> button.</li></ul>

## Referencing the Subsystem



### CAUTION

- To achieve optimum system performance, keep fiber-optic connectors clean at all times (see *Cleaning Optical Connectors* on page 216).
- Make sure you have the appropriate fiber connector type corresponding to the module connectors you want to connect. Never connect another type of connector to the optical output. For details on the appropriate optical fiber type, see the *Technical Specifications* on page 3.

Before performing acquisition scans, you must first reference your subsystem, as explained in the following sections.

In laser sharing mode (see *Sharing the Lasers with Several CTP10s* on page 94), you can perform the referencing operation independently on the Controller CTP10 and on the Distributed CTP10s.

- On the Controller CTP10, you can reference the subsystem as you would do in a standard configuration, as explained in this section.
- On the Distributed CTP10s, you can reference the subsystem as you would do in a standard configuration, but the referencing scan can only be performed if the Controller is scanning (measurement scan or referencing scan). If the Controller is not scanning, the Distributed CTP10 waits for the next sweep from the Controller CTP10 to synchronize with it and perform the referencing scan.

In daisy chaining mode (see *Using Additional OPMs (Daisy Chaining mode)* on page 107), you perform all referencing operations from the Primary CTP10.

## Performing TF/BR or TF/PDL Referencing

The subsystem referencing function enables you to eliminate from the results the contribution of connection elements (patchcord, splitter) between the OUT TO DUT (or OUT2) output and the detector inputs, to only display the TF, PDL or BR of the tested device.

Referencing every single detector of the subsystem is required before performing test scans, using the following functions:

- **Reference:** enables you to perform a reference measurement on each detector used in the subsystem:
  - If you use the IL RL OPM2 module in the subsystem, this function enables you to perform a TF/BR reference measurement. The BR reference is automatically performed on the first detector (from the left) of the subsystem.
  - If you use the IL PDL or IL PDL OPM2 module in the subsystem, this function enables you to perform a TF/PDL reference measurement: the CTP10 performs 4 sweeps to reference a detector.

You must perform a new referencing every time you perform a change in the subsystem setup that could alter the referencing. For example, you must perform a new referencing if you replace a module or if you change a module position into the CTP10 mainframe.

## Performing Measurement Scans

### Referencing the Subsystem

- **Quick reference:** this function is only available once all detectors of the subsystem have already been referenced. It adjusts the TF reference offset measured on one detector and applies the adjustment offset to all other detectors at once. This function is not available if you use an IL PDL or IL PDL OPM2 module.


You can use the quick reference function if you change the DUT patchcord, if you restart the CTP10 without any change in the subsystem or if you open an existing subsystem.

For BR reference, this function performs a BR reference measurement on the selected detector.

The referencing is performed on the defined wavelength/frequency range and referencing information is saved in the subsystem (\*.CTP10 file).

#### To perform TF/BR or TF/PDL referencing:

1. Connect the patchcord that you intend to use for the DUT to one of the detectors used in the subsystem, as illustrated in the following figure.




2. In the **Subsystem** window, open the **Scan** menu:
  - 2a. Verify that the scan parameters are properly configured for your test setup and are the one you intend to use to test the DUT.
  - 2b. For laser safety, verify that the **Keep enabled after scan stop** check-box is cleared.
3. Click the **Reference** button.

The **Reference** window displays all the connectors used in the subsystem and indicates the connections required to reference the system.

- ☐: the detector is not referenced.
- ☒: the detector reference is completed.
- ☒: an error occurred on the detector.

4. In the **Reference** window, click the first detector to reference.

The link is automatically created.




5. Verify that the selected detector is physically connected to the OUT TO DUT (or OUT2 port), as indicated in the Reference window.

6. Click **Run reference**.

The CTP10 performs a scan: 1 sweep with the IL RL OPM2 module, 4 sweeps with the IL PDL or IL PDL OPM2 module.

In laser sharing mode, the Distributed CTP10 waits for the next sweep (TF/BR or TF/PDL referencing sweep or measurement sweep) of the Controller CTP10 to synchronize with it and perform the referencing scan.

Once completed, the  icon appears on the referenced detector, indicating that the reference was performed successfully on the detector.

If you want to stop the referencing operation, close the **Reference** window and in the subsystem window, click the **Abort** button to abort the referencing scan.

7. Perform steps 4 to 6 for all detectors of the subsystem.

The BR reference is automatically performed when you reference the first detector (from the left) of the subsystem.

In daisy chaining mode, click the **Secondary CTP10** tab and perform steps 4 to 6 on all detectors located on the Secondary CTP10.

## Performing Measurement Scans

### Referencing the Subsystem


#### To perform quick referencing:

Quick referencing is not available with an IL PDL or IL PDL OPM2 module.

1. In the **Scan** menu, click the **Quick reference** button.

The **Quick reference** window displays all the referenced detectors used in the subsystem.


2. In the **Quick reference** window, select the detector you want to use for BR and TF adjustment.



3. Physically connect the patchcord that you intend to use for the DUT to the selected detector (in the **Quick reference** window).
4. Click the **Run quick reference** button.

The CTP10 performs a scan.

In laser sharing mode, the Distributed CTP10 waits for the next sweep (TF/BR referencing sweep or measurement sweep) of the Controller CTP10 to synchronize with it and perform the referencing scan.

Once completed, the  icon appears on the detector used to perform the TF adjustment offset and the BR referencing.

If you want to stop the referencing operation, close the **Quick reference** window and in the subsystem window, click the **Abort** button to abort the referencing scan.



## Performing Wavelength Referencing

In the subsystem **Scan** menu, the **Wavelength reference** menu enables you to improve the accuracy of the wavelength referencing if needed by referencing the SCAN SYNC module, in case of temperature variation or environmental condition change.

You can perform a wavelength referencing on all detectors included in the subsystem.

In daisy chaining mode, you can only perform wavelength referencing on a detector located on the Primary CTP10. The wavelength referencing function is not available on detectors located on the Secondary CTP10.

In laser sharing mode (see *Sharing the Lasers with Several CTP10s* on page 94), you can perform the wavelength referencing operation independently on the Controller CTP10 and on the Distributed CTP10s.

- On the Controller CTP10, you can reference the subsystem as you would do in a standard configuration, as explained in this section (the wavelength referencing sweep on the Controller is not shared with the Distributed CTP10s).
- On the Distributed CTP10s, the sweep range set on the Controller CTP10 must cover the sweep range of the gas cell used for referencing on the Distributed CTP10. Then you can reference the subsystem as you would do in a standard configuration, but the referencing scan can only be performed if the Controller is scanning (measurement scan or referencing scan). If the Controller is not scanning, the Distributed CTP10 waits for the next sweep from the Controller CTP10 to synchronize with it and perform the referencing scan.

### **To perform wavelength referencing:**

1. Make sure you have one of the following gas cell (the necessary sweep range is indicated in parentheses for each gas cell):
  - Acetylene  $^{12}\text{C}_2\text{H}_2$  50 Torr (1512–1543 nm)
  - Acetylene  $^{12}\text{C}_2\text{H}_2$  200 Torr (1512–1543 nm)
  - Hydrogen Fluoride HF (1253–1363 nm)
  - Hydrogen Cyanide HCN 25 Torr (1528–1563 nm)
  - Hydrogen Cyanide HCN 100 Torr (1528–1563 nm)
  - Carbon Monoxide  $^{12}\text{C}^{16}\text{O}$  1000 Torr (1561–1595 nm)
  - Carbon Monoxide  $^{13}\text{C}^{16}\text{O}$  1000 Torr (1595–1637 nm)
2. Connect your instruments as follows:
  - 2a. Electrically connect your tunable laser source to the CTP10 (see *Defining and Controlling Your Laser(s)* on page 87). Make sure that the wavelength limits of the connected laser cover the sweep range of the selected gas cell.
  - 2b. Connect the TLS IN port of the IL RL OPM2 or IL PDL or IL PDL OPM2 module to the optical output of the laser (or the TLS OUT port of the FBC module, if you are using several laser sources).
  - 2c. Connect the OUT TO SCAN SYNC (or OUT1) port of the IL RL OPM2 or IL PDL or IL PDL OPM2 module to the TLS IN port of the SCAN SYNC module.

### Referencing the Subsystem

- The **Wavelength** reference window appears.

- The link is automatically created between the gas cell and the detector.



In laser sharing mode, the Distributed CTP10 waits for the next sweep performed on the Controller CTP10 (TF/BR or TF/PDL referencing sweep or measurement sweep) to perform the referencing scan.

If the referencing fails (no absorption lines were detected), the referencing value is reset to 0.

## Selecting the Traces to Acquire

For each optical detector used in the subsystem, a trace group is created in the **Trace setup** pane.

The trace groups displayed in the **Trace setup** pane correspond to the measuring connectors that you have defined in the **Subsystem setup** menu.

An additional group corresponds to stored traces (for more details, see *Storing a Trace* on page 144).

For each detector, you can activate and display several trace types corresponding to various measurements, depending on the measuring module used.

➤ With the IL RL OPM2 module:

- For each optical detector, a trace group is created for insertion loss measurements.
- For the OUT TO DUT (or OUT2) port (internal RL detector), a trace group is created for return loss measurements. To perform a BR measurement, you must also activate at least one TF trace (for the reference to be taken into account).

➤ With the IL PDL or IL PDL OPM2 module:





For each optical detector, a trace group is created for insertion loss and polarization dependent loss measurements.

### Trace setup Pane Description

Trace handling buttons				
Open   Save   Store   Clear   Remove				
#	Name	Analysis	Color	Visible <input checked="" type="checkbox"/>
<b>Module 2 - OUT TO DUT</b>				
1	BR live	<input type="radio"/>		<input checked="" type="checkbox"/>
2	BR max	<input type="radio"/>		<input checked="" type="checkbox"/>
3	BR min	<input type="radio"/>		<input checked="" type="checkbox"/>
4	BR average	<input type="radio"/>		<input checked="" type="checkbox"/>
5	BR roll average	<input type="radio"/>		<input checked="" type="checkbox"/>
<b>Module 2 - IN1</b>				
6	TF live	<input type="radio"/>		<input checked="" type="checkbox"/>
7	TF max	<input checked="" type="radio"/>		<input checked="" type="checkbox"/>
8	TF min	<input type="radio"/>		<input checked="" type="checkbox"/>
9	TF average	<input type="radio"/>		<input checked="" type="checkbox"/>
10	TF roll average	<input type="radio"/>		<input checked="" type="checkbox"/>
<b>Module 3 - IN2</b>				
11	TF live	<input type="radio"/>		<input checked="" type="checkbox"/>
12	TF max	<input type="radio"/>		<input checked="" type="checkbox"/>
13	TF min	<input type="radio"/>		<input checked="" type="checkbox"/>


## Performing Measurement Scans

### Selecting the Traces to Acquire

Command		Description
<div> <input type="button" value="Open"/> <input type="button" value="Save"/> <input type="button" value="Store"/> <input type="button" value="Clear"/> <input type="button" value="Remove"/> </div>		Trace handling buttons. For more details, see <i>Displaying and Handling Traces</i> on page 143.
		Trace configuration button. For more details, see the procedure below this table.
		Trace comment button. For more details, see <i>Adding a Comment to a Trace</i> on page 143.
		Trace analysis selection button in PCT analysis mode. For more details, see <i>Analyzing Traces</i> on page 155.
Analysis column	<input checked="" type="checkbox"/> <input type="checkbox"/>	Trace analysis selection button in PCT WDM analysis mode. For more details, see <i>Analyzing Traces</i> on page 155.
		Trace color. For more details, see <i>Defining the Trace Color</i> on page 143.
Visible column	<input checked="" type="checkbox"/> <input type="checkbox"/>	Trace display/hide check box. For more details, see <i>Displaying/Hiding Traces</i> on page 143.

For each connector used in the subsystem, you can select the trace types you want to acquire. The selected traces will be added to the trace list. You can add a maximum of 330 measured traces in a subsystem.

To select the trace types to acquire:

- 1. Make sure your subsystem is properly configured in the **Subsystem setup** menu (see *Defining Your Subsystem* on page 99) and reflects the physical connections.
- 2. Expand the trace pane by clicking the **Trace setup** title bar.
- 3. In the **Trace setup** pane, click the  button corresponding to the connector you want to configure.

The available traces depend on the selected connector.

IL RL OPM2 module

Selection of trace types to acquire on detectors of the subsystem:

Module 4 - In3

TF measured traces

TF live

☒

TF max

☐

TF min

☐

TF average

☐

TF roll average

☐

10

Apply to all detectors of this subsystem

Selection of trace types to acquire on the OUT TO DUT connector of the IL RL OPM2 module:

Module 2 - OUT TO DUT

BR measured traces

BR live

☒

BR max

☐

BR min

☐

BR average

☐

BR roll average

☐

10

IL PDL or IL PDL OPM2 module

Selection of trace types to acquire on detectors of the subsystem:

Module 10 - In1

TF measured traces

TF live

☒

TF max

☐

TF min

☐

TF average

☐

TF roll average

☐

10

PDL measured traces

PDL live

☒

PDL max

☐

PDL min

☐

PDL average

☐

PDL roll average

☐

10

Apply to all detectors of this subsystem

- 4. Select the traces you want to acquire and display on graph, as explained in the following table.

If you want to perform a BR measurement, you must also select at least one TF trace (for the reference to be taken into account).

With the IL PDL or IL PDL OPM2 module, the trace selection determines the number of sweeps that will be performed during the scanning operation:

- If you only select TF trace types, one sweep will be performed to acquire the selected traces.

## Performing Measurement Scans


### Selecting the Traces to Acquire

- If you select one or more PDL traces, four sweeps will be performed to acquire the selected traces. In this case, the 4 sweeps are used to calculate TF traces (if any): the displayed TF traces correspond to the depolarized IL.

Parameter	Description
<b>TF/BR/PDL Measured traces</b>	<p>Trace type you want to display on graph. The measured value depends on the measuring module used and on the selected connector (TF, BR or PDL):</p> <ul style="list-style-type: none"><li>➤ <b>live</b>: the trace represents the TF/BR/PDL of the last scan.</li><li>➤ <b>max</b>: the trace represents all the maximum scanned values point to point from the first scan.</li><li>➤ <b>min</b>: the trace represents all the minimum scanned values point to point from the first scan.</li><li>➤ <b>average</b>: the trace represents the average of all scans performed from the first scan. This trace type is useful to reduce the noise level if necessary.</li><li>➤ <b>roll average</b>: the trace represents the rolling average of a defined number of previous scans. This trace type is useful to reduce the noise level if necessary. To set the number of scans to take into account to calculate the average, click the roll average numeric field. Maximum value: 10 scans</li></ul> <p>For average trace types, make sure the scan mode parameter is set to <b>Continuous</b> (see <i>Defining the Scan Parameters</i> on page 115).</p>
<b>Apply to all detectors of this subsystem</b> button	<p>Detector connectors only.</p> <p>Click this button to apply the settings defined for the connector to all connectors of the same type.</p>

#### To remove a trace type:

To remove a selected trace type from the **Trace setup** pane and from the graph (and its associated analysis results), do one of the following:

- Click the appropriate  button and clear the trace type check box.
- OR
- In the **Trace setup** pane, select the trace type and click the **Remove** button.

## Performing Acquisition Scans

The transfer function (TF), polarization dependent loss (PDL) and back reflection (BR) acquisition (depending on the module used for measurements) is performed according to the scanning parameters defined in *Defining the Sweep Parameters* on page 119, on selected trace types.

The number of sweeps per scan depend on the trace selection (see *Selecting the Traces to Acquire* on page 129):

- With the IL PDL or IL PDL OPM2 module:
  - If you only select TF trace types, one sweep will be performed to acquire the selected traces.  
You can select the state of polarization for the IL-only measurements by using the following command: `:INITiate:SOP` (see `:INITiate:SOP` on page 466).
  - If you select one or more PDL traces, four sweeps will be performed to acquire the selected traces.  
In this case, if you also select TF traces, the four sweeps are used to calculate the TF traces: the displayed TF trace corresponds to the depolarized IL.
- With the IL RL OPM2 module, one sweep will be performed to acquire TF and/or BR traces.

See the following sections for details:

- *Manually Starting/Stopping the Acquisition* on page 133.
- *Triggering the Acquisition* on page 135.

## Manually Starting/Stopping the Acquisition

This section explains how to manually start and stop acquisition scans. You can also trigger the acquisition, as explained in *Triggering the Acquisition* on page 135.

In laser sharing mode (see *Sharing the Lasers with Several CTP10s* on page 94), you can perform acquisition scans independently on the Controller CTP10 and on the Distributed CTP10s.

- On the Controller CTP10, you can perform measurement scans as you would do in a standard configuration, as explained in this section. The acquisition scans synchronize with all the Distributed CTP10 and enable them to perform acquisition scans.
- On the Distributed CTP10s, you can start and stop single or continuous measurement scans. The acquisition on Distributed CTP10 is only possible if a scan is in progress on the Controller CTP10. If the Controller is not scanning, the Distributed CTP10 waits for the next sweep from the Controller CTP10 to synchronize with it and to perform the scan. If you modify a shared scan parameter on the Controller while the Distributed CTP10s are waiting for a scan, the waiting state is stopped.


### **To manually perform test measurement scans:**

1. Make sure that all the detectors you intend to use are properly referenced, with the same scan parameters than the one you intend to use for DUT test measurement.

## Performing Measurement Scans

### Performing Acquisition Scans

2. Connect your DUT to the CTP10 as illustrated in the following figure (example with one laser source and an IL RL OPM2 module):



- 2a. Connect the input port of the DUT to the OUT TO DUT (or OUT2) port of the IL RL OPM2, IL PDL or IL PDL OPM2 module.
- 2b. Connect the output port(s) of the DUT to the referenced detector ports of the OPMx modules, or of the IL RL OPM2 module if it is used for acquisition.
3. If you want to output trigger signals when the CTP10 performs a scan, connect the external instrument to one of the TRIG OUT port of the CTP10 rear panel.
4. If you want to output CTP10 measurements as analog signals, connect your external analog instrument to the output ANLG OUT1 and/or ANLG OUT2 of the CTP10 rear panel.
5. Make sure you have select the traces you want to acquire, as explained in *Selecting the Traces to Acquire* on page 129.
6. In the **Scan** menu, set the **Scan Start** parameter to **Manual**.
7. Click the **Scan** button.

The **Scan** button label displays **Abort** and the acquisition starts using the selected parameters (see *Defining the Scan Parameters* on page 115).

In the scan parameters area above the graph, you can follow the scan progress (in percent) and number of scans.

The CTP10 performs 1 or 4 sweeps per scan, depending on the traces selected for acquisition (1 sweep for TF and BR acquisition, 4 sweeps for PDL acquisition).

In laser sharing mode, the Distributed CTP10 waits for the next sweep performed on the Controller CTP10 to perform the scan.

If the **Single** scan mode is selected, the acquisition stops automatically.



### **To stop the acquisition:**

- To stop the acquisition, click the **Abort** button.

The acquisition does not finish the scan and stops as quickly as possible.

In laser sharing mode:

- Aborting a scan on the Controller aborts the scan on all Distributed CTP10s. The Distributed CTP10s do not enter the waiting state even if their scan mode was set to Continuous.
- Modifying a shared scan parameter on the Controller aborts the scan on all Distributed CTP10s.

## **Triggering the Acquisition**

The **TRIG IN** BNC connectors (see *Rear panel* on page 9) allow you to externally trigger the acquisition, as explained in the following procedure.

In laser sharing mode (see *Sharing the Lasers with Several CTP10s* on page 94), this function is not available on Distributed CTP10. You can only trigger the acquisition on the Controller CTP10.

### **To trigger the acquisition:**

1. Physically connect the external trigger generator to the wanted **TRIG IN** BNC connector of the CTP10 rear panel.
2. In the **Scan** menu, in the **Scan start** area:
  - 2a. Select **Triggered**.
  - 2b. Select the **Source** and **Slope** of the trigger (for more details, see *Defining the Scan Parameters* on page 115).

The CTP10 scans as soon as it received the defined trigger signal, according to the parameters set in the scan menu.

If you click the **Scan** button, the CTP10 performs a manual scan.

## Retrieving Raw TF Data from a Detector

You can retrieve the traces corresponding to the unreferenced transfer function received on the OPM detector during the scan. This function is only available by using remote commands.

The following traces are available:

- "Raw Live" trace (trace type #11) is the unreferenced "TF live" or "PDL live" trace:
  - After an IL measurement (1 sweep): you retrieve the unreferenced IL trace.
  - After a 4-state IL-PDL measurement (4 sweeps): you retrieve the four unreferenced IL traces.
- "Raw Reference" trace (trace type #12) is the reference trace:
  - With the IL RL OPM2 module, you retrieve the reference trace of the "TF live" trace.
  - With the IL PDL or IL PDL OPM2 module, you retrieve the four IL reference traces of the "TF live" trace or of the "PDL live" trace .
- "Raw Quick Reference" trace (trace type #13, only available with the IL RL OPM2 module) is the quick reference trace of the "TF live" trace.

### **To retrieve raw data from a trace:**

1. Configure your test setup (see *Defining Your Subsystem* on page 99).
2. Configure the scan parameters and reference the subsystem (see *Performing Measurement Scans* on page 115).
3. Perform a scan to acquire the wanted "TF live" or "PDL live" trace on the detector.
4. Use the following commands to retrieve raw data, using TYPE11 (for "Raw Live" trace), TYPE12 (for "Raw Reference" trace) or TYPE13 (for "Raw Quick Reference" trace):
  - `:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:DATA [:Y][:IMMEdiate]? on page 511.`
  - `:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:DATA :START? on page 509.`
  - `:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:DATA :LENGth? on page 509.`
  - `:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:DATA :SAMPLing? on page 510.`
  - `:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:SAVE on page 508 (only in .csv format).`

## Generating Output Trigger Signals

The **TRIG OUT** BNC connectors (see *Rear panel* on page 9) allow you to output electrical trigger signals when the CTP10 performs a scan.


Two types of output triggers are available: Window trigger and Pulse triggers (see the following sections for details).

### Generating Window Trigger Signals

If the Window trigger output is activated on a CTP10, the trigger signal is output during the time of the scan (not only during the acquisition sweep(s)).

In laser sharing mode, if the scan trigger output function is activated on a Distributed CTP10s, the signal is output when the Distributed CTP10s is "Waiting for the Controller CTP10" for scanning.

#### **To output Window trigger signals:**

1. Make sure that the instrument to which you want to output the signal meets the electrical requirements detailed for the TRIG OUT connector in *Technical Specifications* on page 3.
2. Physically connect the external instrument to the wanted **TRIG OUT** BNC connector.
3. In the Subsystem window, click the  button located at the left of the **Scan** button to access the scan parameters.

## Performing Measurement Scans

### Generating Output Trigger Signals

The screenshot displays the TLS software interface with four laser parameter panels (Laser 1 to Laser 4) and a central control panel. The 'Scan trigger output' section is highlighted with a red box. The 'Destination' field is set to 'None', the 'Type' field is set to 'Window', and the 'Inverted logic' checkbox is unchecked. The 'Scan start' section shows 'Manual' selected, 'Source' set to 'None', and 'Slope' set to 'Positive'. The 'Sweep' section shows 'Start' at 1265.0000 nm, 'Stop' at 1505.0000 nm, 'Span' at 240.0000 nm, and 'Center' at 1385.00000 nm. The 'TLS outputs' section shows 'Stabilization time' at 0.0 s and 'Keep enabled after scan stop' checked. The 'Wavelength reference' section shows a 'Wavelength reference...' button. The bottom status bar shows 'O', 'E', 'S', 'C', 'L', 'U', and '...'.

4. In the **Scan trigger output** area, in the **Destination** field, select the TRIG OUT port that outputs the signal.
5. In the **Type** field, select **Window**.
6. Select or clear the **Inverted logic** check box as follows:

☒: the CTP10 outputs a low level signal during the time of the scan.

☐ (default): the CTP10 outputs a high level signal during the time of the scan.

The scanning operation will trigger an output signal (during the time of the scan) according to the selected parameters.

## Generating Pulse Trigger Signals

If the Pulse trigger output is activated on a CTP10, pulse triggers are generated during the acquisition sweep(s) at a regular time interval calculated from the laser sweep speed and sampling resolution.

The time interval (t) between pulse triggers is calculated as follow:

$$t \text{ (in } \mu\text{s)} = \text{sampling (in pm)} \times 1000 / \text{sweep speed (in nm/s)}$$


For example, a 100 nm/s sweep with a sampling of 10 pm will generate a pulse every 100  $\mu\text{s}$ . No pulse triggers are generated during the reference sweeps.

You can retrieve the wavelength array corresponding to the pulse triggers generated during the acquisition sweep(s) by using the following remote query at the end of the sweep: `:TRIGger:OUT:LLOG?` on page 531.

As the CTP10 needs an electrical trigger from the laser to provide Pulse triggers, this trigger type is not available with the VIAVI mSWS-A1SLS laser.

Pulse trigger is not available in laser sharing and daisy chaining modes, and if multiple lasers are used to perform a scan.

### **To output Pulse trigger signals:**

1. Make sure that the instrument to which you want to output the signal meets the electrical requirements detailed for the TRIG OUT connector in *Technical Specifications* on page 3.
2. Physically connect the external instrument to the wanted **TRIG OUT** BNC connector of the CTP10.
3. Physically connect the laser to one of the **TRIG IN** port of the CTP10: on the T100S-HP laser, connect the **Sync** output port to one of the **TRIG IN** port of the CTP10.
4. In the **Subsystem setup** menu, link the **Sync** port of the laser to the **TRIG IN** port of the CTP10 on which you have physically connected the laser, so that it reflects your physical setup.
5. In the Subsystem window, click the  button located at the left of the **Scan** button to access the scan parameters.

## Performing Measurement Scans

### Generating Output Trigger Signals

The screenshot displays the TLS software interface for configuring measurement scans. It features four panels for Laser 1, Laser 2, Laser 3, and Laser 4, each with parameters for wavelength range, speed, power, and averaging time. Below these panels are sections for Sweep parameters, Scan start settings, TLS outputs, and a Scan trigger output section. The Scan trigger output section is highlighted with a red box and contains the following fields:

- Destination: None
- Type: Window
- Inverted logic: ☐

At the bottom of the interface is a row of buttons labeled O, E, S, C, L, U, and ....

6. In the **Scan trigger output** area, in the **Destination** field, select the TRIG OUT port that outputs the signal.

7. In the **Type** field, select **Pulse**.

The scanning operation will generate pulse triggers according to the selected parameters.


## Generating Output Analog Signals

The **ANLG OUT** BNC connectors (see *Rear panel* on page 9) allow you to output internal measurements as analog signals to be displayed on external analog instruments.

You can output two signals coming from two different CTP10 modules detectors. Any detector (except monitoring and BR detectors) can be used, even if it is not part of a subsystem. The analog voltage is output as soon as you select a connector, even if no measurement is running.

### **To output analog signals**

1. Make sure that the instrument to which you want to output the signal meets the electrical requirements detailed for the Analog out connector in *Technical Specifications* on page 3 (*Analog out (x2)*).
2. Physically connect the external instrument to the wanted **ANLG OUT** BNC connector.
3. In the CTP10 task bar, click the **Analog outputs** button and in the **Source** list, select the detector from which you want to output the signal.



The selected signal(s) are output as analog signals and can be read on the connected instruments.

#### **To calibrate the analog output**

- 1.** Connect an optical signal to the detector from which you want to output the analog signal.
- 2.** Connect an external analog instrument to one of the **ANLG OUT** BNC connector and associate it to the detector as described in the above procedure.
- 3.** In the **Modules and Lasers** window, set the unit to **dBm** and select the wanted parameters for the detector (wavelength/frequency, averaging time).
- 4.** Make the following measurements:
  - 4a.** Adjust the optical power to display a first power value (P1) on the detector.
  - 4b.** Measure the corresponding analog output voltage (V1).
  - 4c.** Adjust the optical power to display the second power value (P2) on the detector.
  - 4d.** Measure the corresponding analog output voltage (V2).

These measurements give the  $\alpha$  parameter:  $\alpha = \frac{P_2 - P_1}{V_2 - V_1}$

The power difference between two points whose corresponding voltage are Va and Vb

is:  $\Delta P^{dB} = \alpha \cdot (V_a - V_b)$

(applicable if  $V_1 \leq V_a$ ;  $V_b \leq V_2$ ).

To get the best homogeneity over an extended range, the recommended values are P1= 0 dBm and P2= -50 dBm.



## 9 **Displaying and Handling Traces**


All traces selected for acquisition are measured after each scan and can be displayed in the graph area.

### **Handling Traces Displayed on Graph**

#### **Defining the Trace Color**

You can define the color of each available trace, as explained in the following procedure.

##### **To modify the trace color:**

1. In the **Trace setup** pane, click the **Color** menu  corresponding to the trace you want to configure.
2. Select the wanted color for the trace.

The appearance of the selected traces automatically changes on graph.

#### **Adding a Comment to a Trace**

You can associate a comment or description (maximum 240 characters) to a trace by using the trace note field. If you save the trace, the content of the note field is saved with the trace.

##### **To associate a comment with a trace:**

1. In the **Trace setup** pane, click the  button of the trace to which you want to add a comment.

The note field appears.

2. Type your comment in the field.

The comment is automatically associated with the trace.

3. To hide the comment, click the  button

#### **Displaying/Hiding Traces**

By default, all traces are displayed on graph (the **Visible** check box is selected).

##### **To display a trace:**

In the **Trace setup** pane, select the corresponding **Visible** ☐ check box.

The trace is displayed on graph.

##### **To hide a trace:**

In the **Trace setup** pane, clear the corresponding **Visible** ☒ check box.

The trace disappears from the graph.

## Selecting Traces

Selecting a trace on the graph automatically selects it in the **Trace setup** pane.

In Daisy chaining mode, you cannot select a trace on the graph.

### **To select a displayed trace:**

Click the trace on the graph or in the **Trace setup** pane.

- In the **Trace setup** pane, the trace is highlighted in blue
- On the graph, the power level scale is highlighted with the trace color and the trace width is thicker.

### **To select multiple traces:**

To select multiple traces simultaneously on the graph or in the **Trace setup** pane, you need to use a keyboard:

- Ctrl + click on traces: to make multiple individual selections.
- Shift + click on traces: to make a continuous selection (only available in the **Trace setup** pane).
- Ctrl + a in the **Trace setup** pane: selects all traces.

### **To unselect traces:**

Click anywhere on the graph background.

## Storing a Trace

Storing a trace duplicates it (on the graph and in the **Trace setup** pane) and freezes the duplicate, which won't be modified by next scans. You cannot have more than 20 traces of type Store in the subsystem.

### **To store a trace:**

In the **Trace setup** pane, select the trace you want to store and click the **Store** button.

The trace is added to the **Store** trace group as it is.

At the next scan, traces of type Store won't be modified.

## Deleting Traces

If you physically remove a module from the mainframe or if you remove links in the **Subsystem setup** menu, all corresponding traces are deleted.

To delete traces, two command buttons are available as explained in the following procedures.

### **To delete trace data from the graph (except Store traces) and all analysis results:**

1. Click the **Clear** button.  
A confirmation window appears.
2. Click **Yes**.

### **To delete the selected trace from the graph and from the Trace setup pane:**

- To delete the selected trace type from the graph and from the **Trace setup** pane, and all the associated analysis results, click the **Remove** button.

## Saving/Loading Traces

You can save traces in \*.tra (CTP10 specific format) or \*.csv formats on the internal CTP10 drive (D:\), on an external USB key or hard drive, or on a network drive (if any: see *Adding/Removing a Network Drive* on page 194).

You can save traces as follows:

- Save each traces individually in \*.tra (CTP10 specific format) or \*.csv formats.  
You cannot load traces in \*.csv format, so if you want to be able to load a trace at a later date, you must save it in \*.tra format.
- Save all traces at once (except traces of type **Store**) in a single \*.csv file.  
To save all traces at once in individual \*.tra files, you can save the entire configuration as explained in *Saving a Subsystem* on page 112.

### To save traces:


1. If necessary, connect to one of the USB ports the device on which you want to save the trace.
2. In the **Trace setup** pane, do one of the following:


To save a single trace, select the trace you want to save and click the **Save** button.

OR

To save all traces at once, do no select any trace and click the **Save** button.

The saving window appears. All connected drives are displayed.



3. Click the wanted drive and folder.  
If you want to create a new folder: touch the  **New folder** button and type a name for the folder (using the on-screen keyboard or a normal keyboard if connected to the CTP10) and click the **Create** button.
4. Type a name for the trace: click the text box at the left of the **Save** button to display the keyboard.
5. If you have selected a single trace to save, select a format for the trace (if you have not selected any trace, the \*.csv format is automatically selected to save all traces):
  - **Single selected trace Binary (\*.tra)**: binary CTP10-specific format (smaller size than .csv format).

## Displaying and Handling Traces

### *Saving/Loading Traces*

---

- **Single selected trace CSV (\*.csv):** ASCII file for export in Excel or similar program. The data unit in the file is the unit set on the graph when the trace is saved. You cannot load a trace in \*.csv format back to the system.
- **All traces CSV (\*.csv):** in case you want to save all traces (except for **Store** traces) instead of the selected one.

The selected format is kept in memory for the next trace saving.

**6.** Click the **Save** button.

A confirmation message appears.

The .csv ASCII file contains a header providing information about the trace acquisition conditions.

Example header of a .csv trace file:

```
EXFO CTP10
Format,3.6
SystemPackageVersion,2.x.x
S/N,EO123456789
Time,11:57:23.368 dd/mm/yyyy
Module,5
Detector,1
Start,1522.0000,nm
Stop,1630.0000,nm
Sampling,0.0010,nm
Type,TF live
Unit,nm,dB
Length,108001
WithGap,0
GapBounds,
SweepSpeed,100.000000 ,nm/s
AveragingTime,0.010000 ,ms
LaserPower,3.000000 ,dBm
LaserOptions,CavityControl BacklashControl PowerControl
ScanCount,1
Reference,EO987654321 dd/mm/yyyy
Note,
Wavelength      Level
1522.0000       -2.25075
1522.0010       -2.25295
...
```

**To open a trace:**

- 1.** If necessary, connect to one of the USB ports the device from which you want to load the trace.
- 2.** In the **Trace setup** pane, click the **Open** button.  
  
The **Open** window appears. All connected drives are displayed, with the available files in the selected format.
- 3.** Click the wanted drive and folder and select the trace file (in \*.tra format) that you want to load.
- 4.** Click **Open**.

In the **Trace setup** pane, the trace is added to the **Store** trace group with its associated comment (if any). You cannot have more than 20 traces of type Store in the subsystem.

## Adjusting the Graph Display


The graph displays the visible acquired traces. You can customize the graph layout, and adjust the scale, as explained in the following sections:


- *Defining the Graph Layout* on page 148
- *Adjusting the Scale* on page 149

### Defining the Graph Layout

The **Graph Settings** window allows you to customize the display of scales and graph units, and add a title and a legend to the graph.


**To define the graph settings:**

1. In the **Subsystem** window, in the top left corner of the window, click the  button.
2. If you want to add a title to your graph, select the corresponding option, then enter the title you want to use.



The image shows the 'Graph settings' window. A red rectangle highlights the 'Show title' checkbox, which is checked, and the adjacent text input field containing the word 'Title'. Below this, there are three sliders for 'Title font size' (set to 25), 'Units font size' (set to 11), and 'Axis font size' (set to 10). A 'Reset style' button is located at the bottom right of the window.

3. Set the font size for the various items of the graph using the sliders.



The image shows the 'Graph settings' window with the same 'Show title' checkbox and text field as before. A red rectangle now highlights the three font size sliders: 'Title font size' (set to 25), 'Units font size' (set to 11), and 'Axis font size' (set to 10). The 'Reset style' button remains at the bottom right.






4. To restore the default graph settings, click the **Reset style** button.

## Adjusting the Scale

Zoom commands enable you to adapt the scale of the graph to your needs. You can activate the zoom function by using multi-touch screen gestures (if available on the screen you use), mouse clicks on graphs or zoom command buttons.

### To adjust the graph display using multi-touch screen gestures:

To adjust the graph display using multi-touch screen gestures, do one of the following:










Gesture	Description
	<p>To zoom in or out, pinch two fingers together or move them apart.</p> <p>Maximum vertical zoom: 0.02 dB</p>
	<p>To move in the graph, drag your finger across the screen.</p> <p>You can move in the graph and zoom in or out at the same time.</p>
	<ul style="list-style-type: none"> <li>➤ To browse a scale, drag your finger across the horizontal or vertical scale.</li> <li>➤ To zoom in or out on an axis, pinch two fingers together or move them apart on the horizontal or vertical scale.</li> </ul>
	<p>To select the exact region of the graph that you want to display, hold you finger on the graph until a complete rectangle appears and draw a rectangle by dragging your finger across the graph on the region you want to zoom in (from left to right).</p> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>If you draw a rectangle from right to left, it cancels the last rectangle selection you have made.</p> </div> </div>

## Displaying and Handling Traces

### Adjusting the Graph Display

#### To adjust the graph display using command buttons:

To adjust the graph display using command buttons, touch the wanted button located in the graph display settings area.

Command Button	Description
	Opens a menu that enables you to specify the minimum and maximum values of the following scales: <ul style="list-style-type: none"><li>➤ <b>Horizontal wavelength/frequency scale:</b> used for spectral measurements.</li><li>➤ <b>Vertical transfer function scale:</b> used for TF and BR measurements.</li></ul>
	Enables you to select the exact region of the graph that you want to display: Click the button to activate the rectangle zoom and drag the mouse across the graph to draw a rectangle corresponding to the region you want to zoom in. To deactivate the rectangle zoom, click the button again.
	Automatically sets the display to the maximum wavelength and power range (defined in the technical specifications, see <i>Technical Specifications</i> on page 3).
	Fits the wavelength/frequency and power ranges to the total range covered by the selected trace. The colored flag on the corner of the button indicates the color of the trace on which the zoom applies.
	Fits the wavelength/frequency range to the total range covered by all displayed traces.
	Fits the power range to the to the total range covered by all displayed traces.
	Undoes the last zoom action.
	Disables/Enables all multi-touch screen gestures and move clicks on the graph.
	Disables/Enables markers: for more details, see <i>Performing Manual Measurements With Markers</i> on page 152.



**To adjust the graph display using mouse clicks and keyboard:**

- To zoom in and out: use the scroll wheel.
- To zoom in and out on the Y axis only: press **Ctrl** and use the scroll wheel.
- To zoom in and out on the X axis only: press **Shift** and use the scroll wheel.
- To move in the graph, click and drag you mouse across the graph.
- To select the exact region of the graph that you want to display: right-click the graph and drag the mouse across the graph to draw a rectangle corresponding to the region you want to zoom in (from left to right).  
If you draw a rectangle from right to left, it cancels the last rectangle selection you have made.

## Displaying Coordinates of Sampling Points


You need a mouse to display the X and Y values of specific points of a trace.

This function is not available in Daisy chaining mode.

**To display the coordinates of a sampling point:**

On the graph, drag you mouse on a trace until it reaches a measured point.


A point appears on graph with its corresponding coordinates.



## Performing Manual Measurements With Markers

You can perform measurements directly on the graph with markers. Four markers are available:

- Two vertical markers (A and B): associated with the selected trace, to indicate the detected power at the wavelength/frequency on which they are positioned.
- Two horizontal markers (C and D) to indicate the optical power.



### To perform measurements using markers:


1. Select the trace on which you want to position markers by clicking it on the graph or by selecting it from the **Trace setup** pane.

The trace is highlighted on graph and the power scale is highlighted with the same color, indicating that the trace is brought to front and activated.

2. Click the  button to display markers.

The button icon turns black, the markers appears on the graph, and their corresponding values on a line below the graph.

If you do not see a marker on the graph, it is because it is located outside the zoom area. You can select the markers letter button below the graph and then click

the  button to automatically place the marker to the center of the zoom area.

3. Place the markers at the wanted position on the graph using one of the following methods:









On the graph, click the letter corresponding to the marker you want to move and slide it to the wanted position.

To make it easier to move markers without moving the graph, you can lock the graph by

clicking the  button.

OR



Below the graph, click the button corresponding to the marker letter you want to set and use the following commands to position the marker more precisely:

Button	Description
 	<p>A and B markers only.</p> <p>Moves the selected marker to the right or left direction, as follows:</p> <ul style="list-style-type: none"> <li>➤ If no trace is selected or if the marker is not on a trace, it moves 0.1 pm (or 0.00001 THz) to the right or left direction. A long click on the right or left arrow button speeds up the move to 1 pm (or 0.0001 THz).</li> <li>➤ If the marker is on a selected trace, it moves according to the trace sampling resolution, point by point. A long click on the right or left arrow button speeds up the move by multiplying it by 10.</li> </ul>
 	<p>A and B markers only.</p> <p>Moves the selected marker to the right or left direction, as follows:</p> <ul style="list-style-type: none"> <li>➤ If no trace is selected or if the marker is not on a trace, it moves 10 pm (or 0.001 THz) to the right or left direction. A long click on the right or left arrow button speeds up the move to 100 pm (or 0.01 THz).</li> <li>➤ If the marker is on a selected trace, it moves 100 times the trace sampling resolution. A long click on the right or left arrow button speeds up the move by multiplying the trace sampling resolution by 1000.</li> </ul>
 	<p>C and D markers only.</p> <p>Moves the selected marker 0.0001 dB (or 0.0001 e-6 ratio) to the top or bottom direction (independently of the selected trace). A long click on the arrow button speeds up the move to 0.001 dB (or 0.001 e-6 ratio).</p>
 	<p>C and D markers only.</p> <p>Moves the selected marker 0.01 dB (or 0.01 e-6 ratio) to the top or bottom direction (independently of the selected trace). A long click on the arrow button speeds up the move to 0.1 dB (or 0.1 e-6 ratio).</p>


## Displaying and Handling Traces

### Performing Manual Measurements With Markers

---

Button	Description
	Opens a numeric keypad allowing you to type the exact marker position value (wavelength/frequency value or power value).
	Automatically places the selected marker to the center of the graph, so that you can immediately see them. For <b>B-A</b> and <b>D-C</b> , this button automatically places the center of B-A or D-C to the center of the graph

On non-contiguous traces, you cannot place a marker on the non-contiguous area of the trace: the marker is linked to the selected trace.

4. To hide markers, touch the  button.

The marker positions are kept in memory.

# 10 Analyzing Traces

The lower part of the **Subsystem** window displays the analysis parameters and results.

The analysis feature offers two modes:

- **PCT mode:** provides a series of tools for single peak analysis on a single trace. In Daisy chaining mode, the PCT mode is not available on live traces acquired on detectors located on the Secondary CTP10. To analyze a trace from a detector located on the Secondary CTP10, you must first store the trace to be able to analyze it.
- **PCT WDM mode:** provides a series of tools for multi-channel analysis on one or several traces.

The analysis setup consists of tools aimed at studying special aspects of the displayed traces.

In Daisy chaining mode, closing the Daisy chaining connection clears the analysis results.




## Configuring and Starting the Trace Analysis


To perform an analysis, you must first select the wanted analysis mode: PCT or PCT WDM, as described in the following procedures.

The **Analyze** menu enables you to select the perimeter and the general settings of the analysis, as explained in the following procedures.

Once the analysis perimeter defined, you can configure the analysis tools and immediately see the results in the analysis pane below the graph.


### To select the analysis mode and the traces to analyze:


1. In the **Subsystem** window, click the  button located at the left of the **Analyze** button to display the Analyze menu.



2. Select the wanted analysis **Mode**:
  - PCT mode: provides a series of tools for single channel analysis on a single trace.
  - PCT WDM mode: provides a series of tools for multi-channel analysis on one or several traces.
3. In the **Trace setup** pane, select the trace(s) you want to analyze by selecting the corresponding **Analysis** check box.


### To start the analysis of the selected trace(s):

1. In the **Subsystem** window, click the  button located at the left of the **Analyze** button.



Set the wanted parameters according to the following instructions:

Parameter	Description
<b>Mode</b>	<ul style="list-style-type: none"> <li>➤ PCT: provides a series of tools for single channel analysis on a single trace. In Daisy chaining mode, the PCT mode is not available on live traces acquired on detectors located on the Secondary CTP10.</li> <li>➤ PCT WDM: provides a series of tools for multi-channel analysis on one or several traces.</li> </ul>
<b>Auto analyze</b>	<ul style="list-style-type: none"> <li>➤ <input checked="" type="checkbox"/>: the analysis is automatically performed at the end of each scan and after the change of an analysis parameter. If the <b>Between Markers Only</b> parameter is activated and you have moved a marker, the analysis is also automatically performed.</li> <li>➤ <input type="checkbox"/>: the analysis is performed when you click the <b>Analyze</b> button and if you change the power and/or spectral unit of the whole subsystem (see <i>Defining Subsystem Spectral and Power Units</i> on page 113).</li> </ul>
<b>Noise level @ 1575 nm</b>	<p>Detection threshold of the analysis tools.</p> <p>Sets the level at 1575 nm of the noise detection curve (displayed as a dotted orange line on the graph if the <b>Noise level visible</b> check box is selected), calculated from the noise trace and dependent on wavelength below which the signal is not analyzed (this avoids the detection of unwanted peaks in the noisy regions of the trace).</p>
<b>Noise level visible</b>	<p>Only available in PCT analysis mode.</p> <ul style="list-style-type: none"> <li>➤ <input checked="" type="checkbox"/>: the noise detection curve is displayed on graph as a dotted orange line.</li> <li>➤ <input type="checkbox"/>: the noise detection curve is not displayed on graph, but is taken into account for analysis.</li> </ul>
<b>Between markers only</b>	<p>Two specific markers are available for the analysis (different from the A and B markers), colored in blue:</p> <ul style="list-style-type: none"> <li>➤ <input checked="" type="checkbox"/>: the analysis is only performed on the part of the trace located between the two blue markers.  In case you want to analyze a non-contiguous trace, use the markers to define the part of the trace to analyze: you cannot analyze an entire non-contiguous trace all at once.  The area outside the analysis area is greyed.</li> </ul> <p>The <input type="checkbox"/> button automatically places the markers at the center of the graph, so that you can see them.</p> <ul style="list-style-type: none"> <li>➤ <input type="checkbox"/>: the analysis is performed on the wavelength/frequency range of the trace to analyze. If the analyzed trace has non-contiguous parts, only the first contiguous part will be analyzed. If the measurement is made in THz, the analyzed part is the first from the right.</li> </ul>

2. Click the  button or anywhere on the screen outside the menu to exit.

The trace number to analyze appears on the **Analyze** button.

If you have activated the automatic analysis, the "Auto" flag appears on the top right corner of the **Analyze** button.

3. Make sure the trace to analyze is not empty. If so, perform a scan to get data on the trace.

For PDL analysis, make sure the PDL trace corresponding to the IL trace you want to analyze is enabled and available on graph.

4. If the **Auto Analysis** check box is cleared, click the **Analyze** button.

The analysis is performed on the selected trace(s) according to the parameters set in the **Analysis** pane and in the analysis menu.

Analysis results are displayed below the graph, in the Analysis pane (in nm or THz, and in dB or ratio, depending on the measurement unit selected in the graph

**Power/Spectral units** settings):

- In PCT mode, analysis results are displayed in boxes grouped by analysis tool.
- In PCT WDM mode, analysis results are displayed as a table, with one line per detected channel.



### IMPORTANT

The analysis is restricted to 1000 peaks. If more than 1000 peaks are detected, no result is displayed.

If the **Display on graph** option (available in some analysis tools) is activated, graphical display items are displayed on the graph.

#### To configure the analysis tools:

1. In the lower part of the **Subsystem** window, expand the analysis pane by clicking the **Analysis** title bar.
2. In the **Analysis setup** pane, select the **Peak Trough Search** analysis tool and define the wanted parameters as described in *Setting up Peak Trough Search Analysis* on page 159.
3. Select the component under test in the **Component Selector** analysis tool (see *Selecting the Component Under Test (Component Selector)* on page 161).
4. In PCT WDM analysis mode, select the channel detection method you want to use as described in *Setting Up Channel Detection* on page 162.
5. Define the parameters of the analysis tools corresponding to the selected component and analysis mode as described in the appropriate analysis tool section:

*Setting Up PDL Analysis* on page 167

*Setting up Spectral Width 1/2/3 Analysis* on page 169

*Setting up Notch Width 1/2/3 Analysis* on page 175

*Setting Up Pass Band Test Analysis* on page 178

*Setting Up Stop Band Test Analysis* on page 184

*Setting Up WDM Filter Test Analysis* on page 190

*Setting Up Loss Measurement Analysis* on page 192



## Setting up Peak Trough Search Analysis

The **Peak Trough Search** tool allows you to identify in a spectral trace all high and low values separated from the detected local noise by a given threshold.

Peaks and troughs are only detected above the dotted orange line of **Noise Level @ 1575 nm** defined in the **Analysis** menu (see *Configuring and Starting the Trace Analysis* on page 156).

The tool is automatically activated as all other tool results are calculated from the values detected from this **Peak Trough Search** tool.

The screenshot shows the 'Peak Trough Search' dialog box. It has a 'Search Settings' tab. Inside, there are three settings: 'PT Threshold' set to 0.50 dB, 'Mode Threshold' set to 20.00 dB, and 'Auto Noise Threshold' which is checked. To the right, there is a 'Display on Graph' checkbox which is also checked, and a 'Show' dropdown menu currently set to 'Peaks'.

### To define the Peak Trough Search analysis parameters:

In the **Analysis** pane, click the **Peak Trough Search** tool and modify the parameters using the instructions given below.


#### Search Settings

##### ➤ PT Threshold

Threshold value for the discrimination of peaks and troughs in the trace.

Default value: 0.50 dB

##### ➤ Mode Threshold



The only peaks retained are the ones with power level higher than: [Max power level]-[Mode Threshold].


Default value: 20 dB

#### ➤ Auto Noise Threshold

- ☒ (default): the algorithm automatically detects the localized root mean square (RMS) noise of the measurement (over 10 points surrounding the point of interest) and deduces a value of noise threshold, below which a peak or trough cannot be effectively detected.

This input has been introduced due to the strong dependence of spectral noise to detected power level (see the following figure, in which **Noise Level @1575nm** is represented by Calculation Threshold). This noise threshold is then added to the PT threshold for the peak and trough search.

- ☐: the algorithm does not filter the local noise.





#### Display on Graph

- ☒ (default): analysis graphical items are displayed on the graph.
  - **Peaks** (default): graphical items are displayed on peaks.
  - **Troughs**: graphical items are displayed on troughs.
  - **Both**: graphical items are displayed on peaks and troughs.
- ☐: no graphical item is displayed on the graph.

#### To analyze PT Search results:

The results of Peak Trough Search tool are visible on the graph, if you have selected the **Display on Graph** option:

- : graphical display item displayed on peaks.
- : graphical display item displayed on troughs.

Result values are displayed for each detected peak, in accordance with the value set for the **Mode Threshold** parameter.
















## Selecting the Component Under Test (Component Selector)

The **Component Selector** tool enables you to select the component to test and automatically adapts the list of available analysis tools.

### To select the component under test:

In the **Analysis** pane, click the **Component Selector** tool and select the type of component under test. The availability of components depends on the selected analysis mode (see *Mode* on page 157).

The **Component Selector** tool makes available the analysis tools adapted to the selected component.

	PCT Analysis Mode				PCT WDM Analysis Mode	Related Section
	Pass Band Filter	Stop Band Filter	Isolator	Fiber	Pass Band Filter	
PT Search						<i>Setting up Peak Trough Search Analysis on page 159</i>
Channel Detection						<i>Setting Up Channel Detection on page 162</i>
PDL Analysis						<i>Setting Up PDL Analysis on page 167</i>
Spectral Width 1 Spectral Width 2 Spectral Width 3						<i>Setting up Spectral Width 1/2/3 Analysis on page 169</i>
Notch Width 1 Notch Width 2 Notch Width 3						<i>Setting up Notch Width 1/2/3 Analysis on page 175</i>
Pass Band Test						<i>Setting Up Pass Band Test Analysis on page 178</i>
Stop Band Test						<i>Setting Up Stop Band Test Analysis on page 184</i>
WDM Filter Test						<i>Setting Up WDM Filter Test Analysis on page 190</i>
Loss Measurement						<i>Setting Up Loss Measurement Analysis on page 192</i>



This icon means that the analysis tool is available for the component and can be modified: you can modify the analysis parameters, and view the corresponding results.



This icon means that the analysis tool is available and cannot be modified: the analysis is performed automatically according to preset parameters, and you can view the results.

## Setting Up Channel Detection

The **Channel Detection** tool is only available in PCT WDM analysis mode, for **Pass Band Filter** component type. It enables you to define a grid for the channel analysis.

See the following sections for details:

- *Defining Channel Detection Parameters* on page 162
- *Analyzing Channel Detection Results* on page 166

## Defining Channel Detection Parameters

The **Channel Detection** tool allows you to identify in one or more spectral trace(s) the number, wavelength and power of WDM channels.

### To use the **Channel Detection analysis tool**:

1. In the Analyze menu, select the PCT WDM analysis mode.
2. In the **Analysis** pane, click the **Channel Detection** tool and modify the parameters using the instructions given in *To define the Channel Detection parameters*: on page 163 below.

Channel Detection

Channel Detection Settings

Display on Graph ☒

WDM Display Mode Custom Grid

Empty Channels Hide

Bandwidth Threshold 3.00 dB

Grid Spacing 12.50 GHz

Reference Frequency 193.100 THz

Start Wavelength 1520.00 nm

Stop Wavelength 1620.00 nm

3. To make graphical display items of the analysis visible on the graph, select the **Display on Graph** check box.


### To define the Channel Detection parameters:

#### Channel Detection Settings

The **Peaks Trough Search** tool (see section *Setting up Peak Trough Search Analysis* on page 159) allows the identification of all candidate channels.

#### WDM Display Mode

Method used to calculate the results of the WDM channels detection algorithm.



#### ► Custom Grid (default)

The grid channel array is first calculated based on the **Start Wavelength**, the **Stop Wavelength** and the **Grid Spacing**.

The reference frequency can be set to any frequency with the **Reference Frequency** parameter (see below, **Reference Frequency on page 164**). All other channels are then calculated from that reference channel labeled "Channel 0".

In this process, some of the detected peaks are rejected, either because they are not within the range of the grid, or they are duplicate peaks within a single grid channel. In the latter case, the peak with the highest power is set as the mode.

#### ► Empty Channels

To avoid slowing the acquisition, empty channels are not displayed on graph.

**Show:** all available channels are displayed in the table of results.



### IMPORTANT

Depending on the number of empty channels, selecting this option can slow acquisition and column sorting.

**Hide** (default): empty channels (i.e. with no detected power) are not displayed in the table of results.

➤ **Bandwidth Threshold**

Threshold used in the calculation of the central wavelength/frequency of the signal, that defines two wavelengths  $\lambda_-$  and  $\lambda_+$  with Power **P = P<sub>peak</sub> – Bandwidth Threshold**.

For correct identification of channels, it is recommended that this threshold be less than **PT Threshold** (see **PT Threshold** on page 159).

Central wavelength/frequency =  $(\lambda_+ + \lambda_-)/2$

Default value: 3 dB

➤ **Grid Spacing**

Spacing value for the grid.

Default value: 12.5 GHz

➤ **Reference Frequency**

Center frequency value of the channel number 0. The center frequency of channel N is calculated from the Reference Frequency f, and the Grid Spacing. All other channels are calculated from this frequency as:

$f(\text{channelnumber}N) = f(\text{reference}) + N * \text{GridSpacing}$

Default value: 193.1 THz (ITU standard)

➤ **Start Wavelength/Frequency**

Center wavelength or frequency value (depending on the selected measurement unit, see *Defining Subsystem Spectral and Power Units* on page 113) of the first channel on the grid.

Default value: 1520 nm / 197.232 THz

➤ **Stop Wavelength/Frequency**

Center wavelength or frequency value (depending on the selected measurement unit, see *Defining Subsystem Spectral and Power Units* on page 113) of the last channel on the grid.

Default value: 1620 nm / 185.057 THz

➤ **CWDM**

Generates a CWDM grid: 20 nm spacing and center wavelength of 1270 nm to 1610 nm or 1271 nm to 1611 nm.

➤ **Empty Channels**

To avoid slowing the acquisition, empty channels are not displayed on graph.

**Show:** all available channels are displayed in the table of results.



### IMPORTANT

Depending on the number of empty channels, selecting this option can slow acquisition and column sorting.

**Hide** (default): empty channels (i.e. with no detected power) are not displayed in the table of results.

➤ **Bandwidth Threshold**

Threshold used in the calculation of the central wavelength/frequency of the signal, that defines two wavelengths  $\lambda_-$  and  $\lambda_+$  with Power **P = Ppeak – Bandwidth Threshold**.

For correct identification of channels, it is recommended that this threshold be less than **PT Threshold** (see **PT Threshold on page 159**).

Central wavelength/frequency =  $(\lambda_+ + \lambda_-)/2$

Default value: 3 dB

➤ **First Channel**

Wavelength of the first channel of the CWDM grid:

**1270 nm**: the first CWDM channel is centered on 1270 nm.

**1271 nm** (default): the first CWDM channel is centered on 1271 nm.

➤ **ITU Grid**

Generates an ITU grid.

➤ **Empty Channels**

To avoid slowing the acquisition, empty channels are not displayed on graph.

**Show**: all available channels are displayed in the table of results.



## IMPORTANT

Depending on the number of empty channels, selecting this option can slow acquisition and column sorting.

**Hide** (default): empty channels (i.e. with no detected power) are not displayed in the table of results.

➤ **Bandwidth Threshold**

Threshold used in the calculation of the central wavelength/frequency of the signal, that defines two wavelengths  $\lambda_-$  and  $\lambda_+$  with Power **P = Ppeak – Bandwidth Threshold**.

For correct identification of channels, it is recommended that this threshold be less than **PT Threshold** (see **PT Threshold on page 159**).

Central wavelength/frequency =  $(\lambda_+ + \lambda_-)/2$

Default value: 3 dB

➤ **Spacing**

Spacing value of the ITU grid.

Default value : 25 GHz

➤ **Band**

Band on which the grid should be generated.

Default value: C-Band

## Analyzing Channel Detection Results

Analysis results are displayed on graph and below the graph, in the Analysis pane.

### To analyze results displayed on graph:

If you have selected the **Display on Graph** check box, the following graphical items are displayed on graph:

- Areas alternately pink and grey (brown and grey in dark mode) identify the channels.
- Channel numbers are displayed at the top of the graph.

### To analyze results displayed in the Analysis pane:

#### ➤ Table header

If no peaks are detected at the end of the scan, no value is displayed.

- **Nbr of channels:** total number of detected channels.
- **Slope (dB/nm or dB/THz):** linear fit slope of all central wavelength/frequency measured on all analyzed trace channels.
- **Uniformity (dB):** difference between the maximum and minimum IL value measured at the central wavelength/frequency of all analyzed trace channels.

#### ➤ Table results

Column Name	Meaning
<b>Ch</b>	Channel number, according to the grid channel numbering (even if <b>Empty Channels</b> is set to <b>Hide</b> ).
<b>Trace #</b>	Trace number as displayed in the <b>Trace setup</b> pane.
<b><math>\lambda_{\text{Grid}}</math> (nm) / <math>\nu_{\text{Grid}}</math> (THz)</b>	Wavelength/Frequency of the channel of the grid.
<b><math>\lambda_{\text{Chan}}</math> (nm) / <math>\nu_{\text{Chan}}</math> (THz)</b>	Central wavelength/frequency of the trace channel, calculated from the selected <b>Bandwidth Threshold</b> .
<b><math>\Delta\lambda</math> (nm) / <math>\Delta\nu</math> (GHz)</b>	Wavelength/Frequency offset of the channel compared to the nearest grid channel.
<b>IL<sub>Grid</sub> (dB)</b>	Measured IL at central wavelength/frequency of the grid channel.
<b>IL<sub>Chan</sub> (dB)</b>	Measured IL at central wavelength/frequency of the trace channel.



## Setting Up PDL Analysis

PDL analysis is only available on IL traces acquired together with PDL traces using an IL PDL or IL PDL OPM2 module.

The **PDL Analysis** tool is only available in PCT WDM analysis mode, for **Pass Band Filter** component type. It enables you to get PDL levels of IL traces.

See the following sections for details:


- *Defining PDL Analysis Parameters* on page 167
- *Analyzing PDL Analysis Results* on page 168

### Defining PDL Analysis Parameters

The **PDL Analysis** tool enables you to set the wanted channel window from which you want to identify the maximum PDL level (PDL<sub>Max</sub>).

#### **To use the PDL Analysis tool:**

1. In the **Analyze** menu, select the PCT WDM analysis mode.
2. In the **Analysis** pane, click the **PDL Analysis** tool and modify the parameters using the instructions given in *To define the PDL Analysis parameters* on page 167 below.



3. Activate the analysis calculation for the next analysis run by selecting the **Activate** check box.
4. Make sure that PDL traces corresponding to the IL traces you want to analyze are enabled and available on graph.

#### **To define the PDL Analysis parameters**

##### **PDL<sub>Max</sub> Calculation Settings**

##### ➤ **Frequency Range**

Method used to define the spectral range from which the maximum PDL level (PDL<sub>Max</sub>) of selected traces is measured.

##### ➤ **Fixed Range**

Sets the range to a fixed calculation span in nm or THz, depending on the unit setting. The range is centered on the grid wavelength/frequency defined by the **Channel Detection** tool (see *Analyzing Channel Detection Results* on page 166).

➤ **% Bandwidth 1**

Sets the range to a fraction of the bandwidth measured from the **Spectral Width 1** tool. The range is centered on the grid wavelength/frequency defined by the **Channel Detection** tool (see *Analyzing Channel Detection Results* on page 166).

➤ **% Channel spacing**

Sets the range to a fraction of the grid channel spacing defined in the **Channel Detection** tool.

➤ **Calculation Span** (only if Frequency Range is set to **Fixed Range**)

Fixed range centered on the central wavelength (in nm or THz) over which the maximum PDL level is measured.

Default value: 0.1 nm

➤ **% Bandwidth** (only if Frequency Range is set to **% Bandwidth 1**)

Fraction (in %) of the bandwidth (measured from the **Spectral Width 1** tool) over which the maximum PDL level is measured.

Default value: 50 %

➤ **% Channel** (only if Frequency Range is set to **% Channel spacing**)

Fraction (in %) of the channel width over which the maximum PDL level is measured.

Default value: 20 %

## Analyzing PDL Analysis Results

PDL Analysis results are available on a selected IL trace only if the corresponding PDL trace is available. For example, to display analysis results on a "TF min" trace type, the corresponding "PDL min" trace type must be enabled and available.

If the PDL trace is not available, the results are empty; if the trace is available but without enough data points to measure the PDL level, the result table display a dash,

Result	Meaning
<b>PDL<sub>Grid</sub> (dB)</b>	PDL level measured at the grid wavelength $\lambda_{\text{Grid}}$ or frequency $\nu_{\text{Grid}}$ (for more details on the grid wavelength/frequency, see <i>Analyzing Channel Detection Results</i> on page 166).
<b>PDL<sub>Chan</sub> (dB)</b>	PDL level measured at the channel wavelength $\lambda_{\text{Chan}}$ or frequency $\nu_{\text{Chan}}$ (for more details on the channel wavelength/frequency, see <i>Analyzing Channel Detection Results</i> on page 166).
<b>PDL<sub>Max</sub> (dB)</b>	Maximum PDL level measured within the defined calculation range (see <b>PDLMax Calculation Settings</b> on page 167).

## Setting up Spectral Width 1/2/3 Analysis

The **Spectral Width 1/2/3** tools are available in PCT and PCT WDM analysis modes, for **Pass Band Filter** component type.

See the following sections for details:

- *Defining Spectral Width 1/2/3 Parameters* on page 169
- *Analyzing Spectral Width Results* on page 174

### Defining Spectral Width 1/2/3 Parameters

- In PCT analysis mode, the **Spectral Width 1/2/3** tools allow you to identify in a spectral trace the width of the main peak at a given threshold below the peak power level and the central wavelength.

This tool applies only on peaks. For trough width measurement, see *Setting up Notch Width 1/2/3 Analysis* on page 175.

- In PCT WDM analysis mode, the **Spectral Width 1/2/3** tools allow you to identify in a spectral trace the spectral width at a given threshold below the peak power (same calculation as PCT mode) or following the ITU-T G.671 recommendation.

#### To use the Spectral Width analysis tool:

1. In the **Analysis** pane, click the **Component Selector** tool and set the **Type** parameter to **Pass Band Filter**,

The **Spectral Width 1**, **Spectral Width 2** and **Spectral Width 3** analysis tools become available.

2. Click the wanted **Spectral Width** tool and modify the parameters using the instructions given in *To define the Spectral Width parameters in PCT Analysis mode:* on page 170 below.

#### Spectral Width tool in PCT analysis mode

Spectral Width 1

Spectral Width Detection Settings

Algorithm Threshold

Multiplier 1.000

Width Threshold 3.00 dB

Display on Graph ☒

Fitting Options

Modal Analysis ☒

Fit to Mode ☐

## Analyzing Traces

### Setting up Spectral Width 1/2/3 Analysis

#### Spectral Width tool in PCT WDM analysis mode

Spectral Width 1

Spectral Width Detection Settings

Method Width at Threshold ☐ Display on Graph

Width Threshold 1.00 dB


3. Activate the analysis calculation for the next analysis run by selecting the **Activate** check box (only available on **Spectral Width 2** and **Spectral Width 3**). **Spectral Width 1** is automatically activated.
4. To make graphical display items of the analysis visible on the graph, select the **Display on Graph** check box.

#### To define the Spectral Width parameters in PCT Analysis mode:

##### Spectral Width Detection Settings (PCT analysis mode)


- **Algorithm:** method used for the calculation of the width.
- **Threshold (default)**

The Threshold algorithm detects the wavelengths  $\lambda_-$  and  $\lambda_+$  at which the power level falls below [Peak Power level]-[Width Threshold]. Several options are available for this algorithm (see **Fitting Options on page 172**), illustrated in the following figure.




### ► Envelope

The Envelope algorithm defines an envelope from the peaks of the trace above **Mode Threshold** (linear fit between each peak on log scale) and deduces the width based on that envelope, as shown in the following figure.



### ► RMS/RMS Peak

The RMS and RMS Peak algorithms calculate the root mean square value  $\sigma$  of the power level data above a given **Width Threshold**, taking the full power level data (RMS) or simply the Power level at Peak (RMS Peak) for the calculation.




### ► Gaussian Fit/Lorentzian Fit

The Gaussian Fit and Lorentzian Fit algorithms fit a curve to the data and calculate the spectral parameters using **Width Threshold** from this fit.

If **Modal Analysis** is set to OFF (see **Fitting Options on page 172**), the curve fits a Gaussian or Lorentzian to the main peak.

If **Modal Analysis** is set to ON, the curve fits a Gaussian or Lorentzian to all peaks above **Mode Threshold**.



#### ➤ Multiplier

Factor to scale the measured width.

Default value: 1

#### ➤ Width Threshold

Threshold level used in the calculation of the width. It defines two wavelengths  $\lambda_-$  and  $\lambda_+$  with Power  $P = P_{\text{peak}} - \text{Width Threshold}$ .

Default value: 1 dB (Spectral Width 1) or 3 dB (Spectral Width 2) or 20 dB (Spectral Width 3)

#### ➤ Mode Threshold (only for **Envelope**, **Gaussian Fit** and **Lorentzian Fit** algorithms).

Retains peaks with power level  $P > P_{\text{peak}} - \text{Mode Threshold}$ .

Default value: 50 dB

### Fitting Options

#### ➤ Modal Analysis (only for **Threshold**, **Gaussian Fit** and **Lorentzian Fit** algorithms).

➤ ☒: the measurement includes all detected peaks above **Width Threshold** (Threshold algorithm) or **Mode Threshold** (Gaussian Fit/Lorentzian Fit algorithms).

➤ ☐ (default): the measurement includes a single peak (the main peak).

#### ➤ Fit to Mode (only for **Threshold** algorithm, if **Modal Analysis** check-box is selected).

➤ ☒: the calculation of width is fitted to the nearest detected peaks.

➤ ☐ (default): the calculation of width is fitted to the curve-threshold crossing (see the figure in *Threshold (default)* on page 170).

**To define the Spectral Width parameters in PCT WDM Analysis mode:****Spectral Width Detection Settings** (PCT WDM analysis mode)**➤ Method**

Bandwidth calculation method:

**➤ Width at Threshold**

The bandwidth is calculated at the **Width Threshold** value, using the following parameters (from PCT analysis mode): Algorithm Threshold, Multiplier 1, Width Threshold 1 dB, 3 dB, and 20 dB, no Modal Analysis, no Fit to Mode.

**➤ ITU-T G.671**

The bandwidth is calculated at the **Width Threshold** value, following the ITU-T G.671 recommendation for the calculation of the bandwidth.

**➤ Width Threshold**

Threshold level used in the calculation of the width. It defines two wavelengths  $\lambda^-$  and  $\lambda^+$  with Power  $P = P_{\text{peak}} - \text{Width Threshold}$ .




Default value: 1 dB (Spectral Width 1) or 3 dB (Spectral Width 2) or 20 dB (Spectral Width 3)

## Analyzing Spectral Width Results

Analysis results are displayed below the graph, in the Analysis pane.

### To analyze results displayed on graph:

If you have selected the **Display on Graph** check box, the following graphical items are displayed on graph:

-  is displayed on the mean wavelength/frequency
-  is displayed on  $\lambda+$  and  $\lambda-$ .
-  is displayed between  $\lambda-$  and  $\lambda+$ .

### To analyze the PCT analysis results displayed in the Analysis pane:

Result	Meaning
$\lambda_{\text{mean}}/\nu_{\text{mean}}$	Calculated central wavelength/frequency and its associated power level. For <b>RMS</b> , <b>RMS Peak</b> and <b>Gaussian</b> algorithms, the central wavelength is the mean wavelength.
$\text{Level}_{\text{mean}}$	
$\lambda_{\text{peak}}/\nu_{\text{peak}}$	Calculated peak wavelength/frequency and its associated power level.
$\text{Level}_{\text{peak}}$	
$\Delta\lambda@xx\text{dB}/\Delta\nu@xx\text{dB}$	Width at <b>Width Threshold</b> using the selected algorithm method. For <b>RMS</b> and <b>RMS Peak</b> algorithms, the width is the standard deviation ( $\sigma$ ).
$\sigma$	Only for <b>RMS</b> and <b>RMS Peak</b> algorithms. Standard deviation value of the measured peak.

### To analyze the PCT WDM results displayed in the Analysis pane:

Result	Meaning
$\Delta\lambda1@xx\text{dB (nm)}/\Delta\nu1@xx\text{dB (GHz)}$	Spectral width at <b>Width Threshold</b> using the selected calculation method.
$\Delta\lambda2@xx\text{dB (nm)}/\Delta\nu2@xx\text{dB (GHz)}$	
$\Delta\lambda3@xx\text{dB (nm)}/\Delta\nu3@xx\text{dB (GHz)}$	



## Setting up Notch Width 1/2/3 Analysis

The **Notch Width 1/2/3** tool is only available in PCT analysis mode, for stop-band filter and isolator component types.

See the following sections for details:

- *Defining Notch Width Analysis Parameters* on page 175
- *Analyzing Notch Width Results* on page 177

### Defining Notch Width Analysis Parameters

The **Notch Width** tool allows you to identify in a spectral trace the width of a trough at a given threshold above the trough power level (see "Bottom" in **Width Reference** on page 177) or below the surrounding peaks (see "Top" in **Width Reference** on page 177).

#### To use the Notch Width analysis tool:

1. In the **Analyze** menu, select the PCT analysis mode.
2. In the **Analysis** pane, click the **Component Selector** tool and set the **Type** parameter to **Stop Band Filter** or **Isolator**.

The **Notch Width 1**, **Notch Width 2** and **Notch Width 3** analysis tools become available.

3. Click the wanted **Notch Width** tool and modify the parameters using the instructions given in *To define Notch Width analysis parameters:* on page 176 below.

Notch Width 1

Notch Width Detection Settings

Algorithm Threshold ☐ Display on Graph

Multiplier 1.000

Width Threshold 3.00 dB

Notch Selection Options

Notch Selection Minimum Trough

Width Reference Top

4. Activate the analysis calculation for the next analysis run by selecting the **Activate** check box (only available on **Notch Width 2** and **Notch Width 3**). **Notch Width 1** is automatically activated.
5. To make graphical display items of the analysis visible on the graph, select the **Display on Graph** check box.


#### To define Notch Width analysis parameters:

##### Notch Width Detection Settings

- **Algorithm:** fit to apply for the determination of the width.  
The fitting is mono-modal (the **Modal Analysis** option is not available).
- **Threshold** (default): no fit is applied.
- **Gaussian/Lorentzian Fit:** the Gaussian Fit and Lorentzian Fit algorithms fit a curve to the data and calculate the spectral parameters using **Width Threshold** from this fit. The curve is fitted to the main trough.
- **Multiplier**  
Factor to scale the measured width.  
Default value: 1
- **Width Threshold**  
Threshold level used in the calculation of the width. It defines two wavelengths  $\lambda_-$  and  $\lambda_+$  with Power  $P = P_{\text{peak}} - \text{Width Threshold}$ .  
Default value: 1 dB (Notch Width 1) or 3 dB (Notch Width 2) or 20 dB (Notch Width 3)

##### Notch Selection Options


- **Notch Selection:** method used for the selection of the trough to analyze.
  - **Deepest Notch:** selection of the feature with biggest difference between trough and adjacent peaks.
  - **Minimum Trough** (default): selection of the lowest level trough.



### ➤ Width Reference

Method used for the measurement of the width.

- **Bottom** (default): the width is calculated from the trough.
- **Top**: the width is calculated from the two surrounding peaks on either side of the notch to be analyzed.





### Analyzing Notch Width Results

Analysis results are displayed below the graph, in the Analysis pane.

If no peaks are detected at the end of the scan, no value is displayed.

#### To analyze results displayed on graph:

If you have selected the **Display on Graph** check box, the following graphical items are displayed on graph:

-  displayed on the notch wavelength.
-  is displayed on  $\lambda+$  and  $\lambda-$ .

#### To analyze results displayed in the Analysis pane:

To be detected correctly, the trough must not be below the **Noise Level @1575 nm** value (see *Configuring and Starting the Trace Analysis* on page 156).

Result	Meaning
$\lambda_{\text{notch}}/v_{\text{mean}}$	Calculated central wavelength/frequency and its associated power level.
$\text{Level}_{\text{notch}}$	
$\lambda_{\text{trough}}/v_{\text{trough}}$	<b>Notch Width 1/2/3 tool only.</b> Calculated trough wavelength/frequency and its associated power level.
$\text{Level}_{\text{trough}}$	
$\Delta\lambda_{\text{notch}}/\Delta v_{\text{notch}}$	Spectral notch width at <b>Width Threshold</b> using the selected algorithm method.

## Setting Up Pass Band Test Analysis

The **Pass Band Test** analysis tool is only available in PCT analysis mode, for **Pass Band Filter** component type.

See the following sections for details:

- *Defining Pass Band Test Analysis Parameters* on page 178
- *Analyzing Pass Band Test Results* on page 183

## Defining Pass Band Test Analysis Parameters

The **Pass Band Test** tool allows you to get cross-talk, average loss, ripple and roll-off characteristics for a pass band filter.

### To use the Pass Band Test analysis tool:

1. In the **Analyze** menu, select the PCT analysis mode.
2. In the **Analysis** pane, click the **Component Selector** tool and set the **Type** parameter to **Pass Band Filter**.
3. Click the **Pass Band Test** tool and modify the parameters using the instructions given in *To define the Pass Band Test analysis parameters:* on page 179 below.

Pass Band Test
Display on Graph ☒

---

CrossTalk Settings

Reference Peak  $\lambda$

IN/OUT Band Method Bandwidth 1

---

Average Loss & Ripple Settings

Averaging Range Fixed Range

Calculation Span 0.10 nm

---

Roll-Off & Transition Band Settings

Transition Reference In-Band

Min Exclusion Thresh. 3.00 dB

Max Exclusion Thresh. 20.00 dB

4. Activate the analysis calculation for the next analysis run by selecting the **Activate** check box.
5. To make graphical display items of the analysis visible on the graph, select the **Display on Graph** check box.


### To define the Pass Band Test analysis parameters:

#### CrossTalk Settings

##### ➤ Reference

Reference point taken for the analysis of the characteristics of the filter:


- **Peak  $\lambda$**  (default): peak wavelength found in the **Spectral Width 1** tool results (see *Analyzing Spectral Width Results* on page 174).
- **Center  $\lambda$** : center wavelength found in the **Spectral Width 1** tool results (see *Analyzing Spectral Width Results* on page 174).



##### ➤ IN/OUT Band Method

Method used in crosstalk calculation for the estimate of the spectral spacing between in and out bands:

- **Bandwidth 1** (default): selects the out band reference points to be exactly a bandwidth away from the in-band point, using the result in **Spectral Width 1** tool (see *Analyzing Spectral Width Results* on page 174).
- **Set Distance**: enables you to set the spacing via the **In/Out Band Distance** parameter.



## Analyzing Traces

### Setting Up Pass Band Test Analysis

- **IN/OUT Band Distance** (only if **In/Out Band Method** is set to **Set Distance**)


Spectral spacing in nm/THz between the in-band reference point and the out-band reference points to be used for the crosstalk calculation. Default value: 1 nm

### Average Loss & Ripple Settings


- **Averaging Range**

Spectral range used in the analysis of in-band and out-band average loss and ripple.


- **Fixed Range:** provides a fixed calculation span (see **Calculation Span (only if Averaging Range is set to Fixed Range)** on page 181).



- **% Bandwidth 1:** sets the range to a fraction of the bandwidth measured from the **Spectral Width 1** tool (see *Analyzing Spectral Width Results* on page 174).



- **PT Detection:** detects all peaks and troughs within the Bandwidth 1 using **Detection Threshold**. The span is then set to the distance between the first and last peak detected for a pass band filter.



In-band and out-band average loss and ripple/slope calculations are performed across a given calculation span centered on their respective reference points as defined in crosstalk settings.

- **Calculation Span (only if Averaging Range is set to Fixed Range)**

Fixed range in nm/THz over which calculations are done. The range is centered on the reference points for in-band and out-band (set in **CrossTalk Settings on page 179**). A range of 0 takes a single point for the calculation.

Default value: 0.1 nm

- **% Bandwidth (only if Averaging Range is set to % 3dB Bandwidth)**

Fraction (in %) of the bandwidth calculated in **Spectral Width 1** over which calculations are done. The range is centered on the reference points for in-band and out-band (set in **CrossTalk Settings on page 179**).

Default value: 50 %

- **Detection Threshold (only if Averaging Range is set to PT Detection)**

Threshold in dB for the detection of in-band extreme peaks over which calculations are done. The range is centered on the reference points for out-band (set in **CrossTalk Settings on page 179**).


Default: 0.1 dB

#### Roll-Off & Transition Band Settings


##### ► Transition Reference

Reference to be used in the transition calculation:

- **In-Band** (default): the transition band is defined as the part of the trace between **Level@ Transition Reference - Min Exclusion Threshold** and **Level@ Transition Reference - Max Exclusion Threshold**.



- **Out-Band**: the transition band is defined as the part of the trace between **Level@ Transition Reference + Min Exclusion Threshold** and **Level@ Transition Reference + Max Exclusion Threshold**



##### ► Min Exclusion Threshold.

(in dB) Minimum threshold for the exclusion of data outside of the transition band.

Default value: 3 dB

##### ► Max Exclusion Threshold.

(in dB) Maximum threshold for the exclusion of data outside of the transition band.




Default value: 20 dB



## Analyzing Pass Band Test Results

Analysis results are displayed below the graph, in the Analysis pane.

### To analyze results displayed on graph:

-  are displayed on the reference points (in- and out-band).
-  are displayed on the maximum roll off wavelength within transition range.
-  are display on the transition range.

### To analyze results displayed in the Analysis pane:

The **RollOff** measurement is performed on the CTP10 trace.

#### ➤ In-Band Results

Result	Meaning
<b>Avg Loss</b>	Average loss in dB measured across <b>Averaging Range</b> around the in-band reference point.
<b>Ripple</b>	Uniformity in dB as the min/max level difference measured within <b>Averaging Range</b> around the <b>In-Band</b> reference point.
<b>Slope</b>	Linear fit slope calculated within <b>Averaging Range</b> around the <b>In-Band</b> reference point.

#### ➤ Out-Band Side 1 Results and Out-Band Side 2 Results

Result	Meaning
<b>Avg Loss</b>	Average loss in dB measured across <b>Averaging Range</b> around the <b>Out-Band</b> reference point.
<b>Ripple</b>	Uniformity in dB as the min/max level difference measured within <b>Averaging Range</b> around the <b>Out-Band</b> reference point.
<b>CrossTalk</b>	Crosstalk (pass band) in dB measured between the <b>In-Band</b> Reference point and the <b>Out-Band</b> reference point. The crosstalk is given as difference between points, not between <b>Avg Losses</b> .
<b>RollOff@XdB<sup>1</sup></b>	Roll off in dB/nm (or dB/THz) measured at XdB (set by the <b>Spectral Width 1</b> tool) from the <b>Transition Reference</b> point.
<b>RollOffmax<sup>1</sup></b>	Maximum roll off in dB/nm (or dB/THz), within the transition band.
<b><math>\lambda</math>@RollOffmax</b>	Wavelength of maximum roll off in nm.
<b>Transition Band<sup>1</sup></b>	Wavelength region between <b>Transition Reference</b> +/- <b>Minimum Threshold</b> and Reference point +/- <b>Maximum Threshold</b> .

1.: This result is calculated between the two reference points set in **CrossTalk Settings** on page 179.

## Setting Up Stop Band Test Analysis

The **Stop Band Test** analysis tool is only available in PCT analysis mode, for **Stop Band Filter** component type.

See the following sections for details:

- *Defining Stop Band Test Analysis Parameters* on page 184
- *Analyzing Stop Band Test Results* on page 189

## Defining Stop Band Test Analysis Parameters

The **Stop Band Test** tool allows you to get isolation depth, average loss, ripple and roll-off characteristics for a pass band filter

### To use the Stop Band Test analysis tool:

1. In the **Analyze** menu, select the PCT analysis mode.
2. In the **Analysis** pane, click the **Component Selector** tool and set the **Type** parameter to **Stop Band Filter**.
3. Click the **Stop Band Test** tool and modify the parameters using the instructions given in *To define the Stop Band Test parameters:* on page 185 below.

Stop Band Test

Activate ☒  
 Display on Graph ☒

---

Isolation Depth Settings

Reference Trough  $\lambda$   
 IN/OUT Band Method Bandwidth 1

---

Average Loss & Ripple Settings

Averaging Range Fixed Range  
 Calculation Span 0.10 nm

---

Roll-Off & Transition Band Settings

Transition Reference In-Band  
 Min Exclusion Thresh. 3.00 dB  
 Max Exclusion Thresh. 20.00 dB

4. Activate the analysis calculation for the next analysis run by selecting the **Activate** check box.
5. To make graphical display items of the analysis visible on the graph, select the **Display on Graph** check box.


**To define the Stop Band Test parameters:**

**Isolation Depth Settings**

➤ **Reference**

Reference point taken for the analysis of the characteristics of the filter:


- **Trough  $\lambda$**  (default): peak wavelength found in the **Notch Width 1** tool results (see *Analyzing Notch Width Results* on page 177).
- **Center  $\lambda$** : center wavelength found in the **Notch Width 1** tool results (see *Analyzing Notch Width Results* on page 177).



➤ **IN/OUT Band Method**

Method used in isolation depth calculation for the estimate of the spectral spacing between in and out bands:

- **Bandwidth 1** (default): selects the out band reference points to be exactly a bandwidth away from the in-band point, using the result in **Notch Width 1** tool (see *Analyzing Notch Width Results* on page 177).
- **Set Distance**: enables you to set the spacing via the **In/Out Band Distance** parameter.



## Analyzing Traces

### Setting Up Stop Band Test Analysis

#### ► IN/OUT Band Distance (only if In/Out Band Method is set to Set Distance)

Spectral spacing in nm/THz between the in-band reference point and the out-band reference points to be used for the isolation depth calculation.


Default value: 1 nm

#### Average Loss & Ripple Settings


##### ► Averaging Range

Spectral range used in the analysis of in-band and out-band average loss and ripple.


##### ► Fixed Range: provides a fixed calculation span (see **Calculation Span** (*only if Averaging Range is set to Fixed Range*) on page 181).



##### ► % Bandwidth: sets the range to a fraction of the bandwidth measured from the **Notch Width 1** tool (see *Analyzing Notch Width Results* on page 177).



- **PT Detection:** detects all peaks and troughs within the Bandwidth 1 using **Detection Threshold**. The span is then set to the distance between the first and last trough detected for a stop band filter.



In-band and out-band average loss and ripple/slope calculations are performed across a given calculation span centered on their respective reference points as defined in isolation depth settings.

- **Calculation Span** (only if **Averaging Range** is set to **Fixed Range**)

Fixed Range in nm/THz over which calculations are done. The range is centered on the reference points for in-band and out-band (set in isolation depth settings). A range of 0 takes a single point for the calculation.

Default value: 0.1 nm

- **% Bandwidth** (only if **Averaging Range** is set to **% 3dB Bandwidth**)

Fraction (in %) of the bandwidth calculated in **Notch Width 1** over which calculations are done. The range is centered on the reference points for in-band and out-band (set in isolation depth settings).

Default value: 50 %

- **Detection Threshold** (only if **Averaging Range** is set to **PT Detection**)

Threshold in dB for the detection of in-band extreme troughs over which calculations are done. The range is centered on the reference points for in-band (set in isolation depth settings).


Default: 0.1 dB

#### Roll-Off & Transition Band Settings


##### ► Transition Reference

Reference to be used in the transition calculation:

- **In-Band** (default): the transition band is defined as the part of the trace between **Level@ Transition Reference + Min Exclusion Thresh.** and **Level@ Transition Reference + Max Exclusion Thresh.**



- **Out-Band**: the transition band is defined as the part of the trace between **Level@ Transition Reference - Min Exclusion Thresh.** and **Level@ Transition Reference - Max Exclusion Thresh.**



##### ► Min Exclusion Thresh.

(in dB) Minimum threshold for the exclusion of data outside of the transition band.

Default value: 3 dB

##### ► Max Exclusion Thresh.

(in dB) Maximum threshold for the exclusion of data outside of the transition band.




Default value: 20 dB.

## Analyzing Stop Band Test Results

Analysis results are displayed below the graph, in the Analysis pane.

### To analyze results displayed on graph:

If you have selected the **Display on Graph** check box, the following graphical items are displayed on graph:

-  are displayed on the reference points (in- and out-band).
-  are displayed on the maximum roll off wavelength within transition range.
-  are display on the transition range.

### To analyze results displayed in the Analysis pane:

#### ➤ In-Band Results

Result	Meaning
<b>Avg Loss</b>	Average loss in dB measured across <b>Averaging Range</b> around the in-band reference point.
<b>Ripple</b>	Uniformity in dB as the min/max level difference measured within <b>Averaging Range</b> around the <b>In-Band</b> reference point.
<b>Slope</b>	Linear fit slope calculated within <b>Averaging Range</b> around the <b>In-Band</b> reference point.

#### ➤ Out-Band Side 1 Results and Out-Band Side 2 Results

Result	Meaning
<b>Avg Loss</b>	Average loss in dB measured across <b>Averaging Range</b> around the <b>Out-Band</b> reference point.
<b>Ripple</b>	Uniformity in dB as the min/max level difference measured within <b>Averaging Range</b> around the <b>Out-Band</b> reference point.
<b>Isolation Depth</b>	Isolation depth in dB measured between the <b>In-Band</b> Reference point and the <b>Out-Band</b> reference point. The isolation depth is given as difference between points, not between <b>Avg Losses</b> .
<b>RollOff@XdB</b>	Roll off in dB/nm (or dB/THz) measured at X dB (set by the <b>Notch Width 1</b> tool) from the <b>Transition Reference</b> point.
<b>RollOffmax</b>	Maximum roll off in dB/nm (or dB/THz), within the transition band.
<b><math>\lambda</math>@RollOffmax</b>	Wavelength of maximum roll off in nm.
<b>Transition Band</b>	Wavelength region between <b>Transition Reference</b> +/- <b>Minimum Threshold</b> and Reference point +/- <b>Maximum Threshold</b> .

## Setting Up WDM Filter Test Analysis

The **WDM Filter Test** tool is only available in PCT WDM analysis mode, for **Pass Band Filter** component type. It enables you to calculate the adjacent isolation, non-adjacent isolation, total crosstalk, ripple and slope of selected traces.

See the following sections for details:

- *Defining WDM Filter Test Parameters* on page 190
- *Analyzing WDM Filter Test Results* on page 191

### Defining WDM Filter Test Parameters

The **WDM Filter Test** tool enables you to set the wanted channel window size for calculation of adjacent isolation, non-adjacent isolation, total crosstalk, ripple and slope.

#### To use the WDM Filter Test analysis tool:

1. In the **Analyze** menu, select the PCT WDM analysis mode.
2. In the **Analysis** pane, click the **WDM Filter Test** tool and modify the parameters using the instructions given in *To define the WDM Filter Test parameters:* on page 190 below.

3. Activate the analysis calculation for the next analysis run by selecting the **Activate** check box.

#### To define the WDM Filter Test parameters:

##### Calculation Settings

##### ➤ Frequency Range

Method used to define the spectral range to use for the calculation of isolation, total crosstalk, ripple and slope of selected traces.

##### ➤ Fixed Range

Sets the range to a fixed calculation span in nm or THz, depending on the unit setting. The range is centered on the grid wavelength/frequency defined by the **Channel Detection** tool (see *Analyzing Channel Detection Results* on page 166).

##### ➤ % Bandwidth 1

Sets the range to a fraction of the bandwidth measured from the **Spectral Width 1** tool. The range is centered on the grid wavelength/frequency defined by the **Channel Detection** tool (see *Analyzing Channel Detection Results* on page 166).



### ➤ % Channel spacing

Sets the range to a fraction of the grid channel spacing defined in the **Channel Detection** tool.

### ➤ Calculation Span (only if Frequency Range is set to **Fixed Range**)

Fixed range centered on the central wavelength, (in nm or THz) over which calculations are done.

Default value: 0.1 nm

### ➤ % Bandwidth (only if Frequency Range is set to **% Bandwidth 1**)

Fraction (in %) of the bandwidth (measured from the **Spectral Width 1** tool) over which calculations are done.

Default value: 50 %

### ➤ % Channel (only if Frequency Range is set to **% Channel spacing**)

Fraction (in %) of the channel width over which calculations are done.

Default value: 20 %

## Analyzing WDM Filter Test Results

Analysis results are displayed below the graph, in the Analysis pane.

All WDM Filter Test results are calculated over the window defined using the *Frequency Range* parameter.

Result	Meaning
<b>Slope (dB/nm or db/THz)</b>	Linear fit slope calculated within the defined calculation range.
<b>Ripple (dB)</b>	Uniformity as the as the difference between IL min and IL max measured within the defined calculation range.
<b>Adj. Iso. (dB)</b>	Minimum (worst case) of the two isolation measurements performed on either side of the filter on the adjacent channels.
<b>Non-adj. Iso. (dB)</b>	Minimum (worst case) of the isolation measurements performed on either side of the filter on any channels except the adjacent channels
<b>Total Xtalk (dB)</b>	Cumulated isolation measurement performed on all channels on either side of the filter.

## Setting Up Loss Measurement Analysis

The **Loss Measurement** analysis tool is only available in PCT analysis mode, for **Fiber** component type. The analysis settings cannot be modified.

The **Loss Measurement** tool allows you to get the average attenuation and the uniformity of a spectral trace obtained from a fiber-type passive component.

### To use the Loss Measurement analysis tool:

1. In the **Analysis** pane, click the **Component Selector** tool and set the **Type** parameter to **Fiber**.
2. The **Loss Measurement** tool will automatically be calculated on the next analysis.

The analysis settings cannot be modified.

- **Noise Suppression:** disabled
- **Offset:** 0 dB
- **Full Span:** activated

### To analyze Loss Measurement results:

Analysis results are displayed below the graph, in the **Analysis** pane.

Result	Meaning
Average Loss	Measured fiber attenuation, in dB.
Uniformity	Difference between minimum and maximum loss within the analysis range, in dB.

## Saving Analysis Results

You can save the analysis results in a \*.csv file. You cannot load analysis results back to the system.

### To save the analysis results:

1. In the **Subsystem** window, in the measurement control area, click the **Save** button.
2. Select the **Analysis Results (\*.csv)** file type.
3. Select a location and type a name for the analysis result file.
4. Click the **Save** button.

# 11 Handling Files and User Data

The **File Explorer** window allows you to access the drives available from the CTP10:

- CTP10 internal drive (for details on data storage capacity, see *Technical Specifications* on page 3).
- USB drives connected to the CTP10 (for details on how to connected external storage devices, see *Connecting/Disconnecting USB Storage Devices* on page 193).
- Network drives connected to the CTP10 using the Ethernet port and added to the CTP10 file explorer (see *Adding/Removing a Network Drive* on page 194).

From this window, you can:


- Browse the available drives
- Display \*.jpg and \*.png images
- Open traces in \*.tra format in a subsystem
- Open a subsystem (\*.ctp10 file)
- Create, delete, copy/cut/paste and rename folders
- Copy/cut/paste, delete and rename files
- Connect/disconnect network drives

## Connecting/Disconnecting USB Storage Devices

You can connect storage USB devices to the USB-A 2.0 and USB-A 3.0 ports located on the front and rear panels of the CTP10 (see *CTP10 Mainframe Overview* on page 7).

### To connect USB storage devices:


Connect the USB storage device to one of the available USB ports (you do not need to restart the CTP10).

- The first time you connect a USB storage device, the driver is installed and can take some time (depending on the connected device).
- The  icon appears at the left of the date and time and the device becomes available for loading or saving data.

### To disconnect USB storage devices from the CTP10:

If you connect one or more USB storage device(s) to the CTP10, an icon appears in the task bar, at the left of the date and time.



This icon enables you to safely remove USB storage devices from the CTP10, as explained in the following procedure.


1. On the CTP10 screen, touch the  icon located at the left of the date and time.  
The list of all connected USB storage devices appears.
2. Click the **Safely remove...** menu corresponding to the device you want to disconnect.  
A confirmation message appears.
3. Remove the USB device from the CTP10.

# Adding/Removing a Network Drive

By default, the **File Explorer** window displays the content of the CTP10 internal drive. If the CTP10 is connected to a network through the Ethernet port, you can then map available network drives, as explained in this section.

### To add a network drive:

1. Connect the Ethernet port of the CTP10 to the wanted network using an Ethernet cable.
2. In the task bar, click the  button to open the **File Explorer** window.
3. Click the  **Add network drive...** button to open the menu.



4. Enter the required values in the fields as described in the following table:

Parameter	Description
<b>Folder</b>	Click the field to enter the server folder pathname.
<b>Drive</b>	Select the wanted drive letter.
<b>Reconnect this drive at CTP10 startup</b>	<ul style="list-style-type: none"> <li>➤ <input checked="" type="checkbox"/>: the mapped network drive will be available in the file explorer the next time you start the CTP10.</li> <li>➤ <input type="checkbox"/>: the mapped network drive will not be available in the file explorer the next time you start the CTP10.</li> </ul>
<b>Connect using different credentials</b>	<ul style="list-style-type: none"> <li>➤ <input checked="" type="checkbox"/>: the previously entered credentials used for the connection to the folder (if any) won't be used. You will be prompted to enter login and password.</li> <li>➤ <input type="checkbox"/>: the previously entered credentials used for the connection to the folder (if any) will be used to connect to the folder.</li> </ul>



5. Click the **Add network drive** button.

If the system requires credentials, a window prompts you to enter a login and password for the connection.

6. Enter your login (using the `<domain name>\<user name>` format), your password and click **OK**.

When connected, the drive appears in the navigation pane.



**To remove a network drive:**

1. In the **File Explorer** window, click the  to open the menu.
2. In the **Network drive to remove** list, select the wanted network drive or **All network drives**.
3. Click the  button.

A confirmation window appears.

4. Click **Yes**.

**To delete all saved credentials:**


1. In the **File Explorer** window, click the  to open the menu.
2. In the **Network drive to remove** list, select the wanted network drive and click the  button.

A confirmation window appears.

3. Click **Yes**.

You will be prompted to enter credentials to connect to the mapped drives.

**To retrieve a network drive:**

If a previously mapped network drive is unavailable, the  icon is displayed next to the drive name.


To try again to connect to the drive, click the drive name in the navigation pane.

## Opening a File from the File Explorer

From the **File Explorer** window, you can see all files and folders of the connected network drives and you can open the following types of files:

- \*.jpg and \*.png images
- Traces in \*.tra format
- Subsystem files (\*.ctp10)


**To open a file:**

1. In the task bar, click the  button to open the **File Explorer** window.
2. If you want to open a subsystem file (\*.ctp10), stop the scanning process.
3. Double-click the file you want to open:
  - \*.jpg and \*.png files are directly displayed in the **File Explorer** window.
  - \*.ctp10 files and trace files cannot be open outside a subsystem: they will be displayed in the subsystem.

## Handling Folders and Files









The **File Explorer** window enables you to copy/cut/paste, delete and rename folders and files from the available drives, and also to create new folders.

### To handle files and folders:

1. In the task bar, click the  button to open the **File Explorer** window.
2. Select the folder or file you want to handle and click the button corresponding to the action you want to perform, as explained in the following table.

To select multiple files or folders simultaneously, you need to use a keyboard:

- Ctrl + click on files/folders: to make multiple individual selections.
- Shift + click on files/folders: to make a continuous selection.
- Ctrl + a: to select all files/folders.

Button	Description
 Up	Browses the folder one step up in the folder hierarchy.
 New folder	Opens a window to enter the name of the new folder.
 Rename	Opens a window to enter the new name of the selected folder or file.
 Copy	Copies the selected folder or file.
 Cut	Cuts the selected folder or file.
 Paste	Pastes the selected folder or file.
 Delete	Deletes the selected folder or file.
	Refreshes the content of the displayed folder.


## Deleting all User Data from the CTP10 Internal Drive

You can delete all data saved by a user on the internal CTP10 drive D:\. All user customized settings, parameters and traces displayed on screen will not be deleted.

### To delete all user data from the CTP10 internal drive:

1. In the CTP10 task bar, click the  button to display the **Settings** window.

The **Settings and Data Management** area enables you to delete user data on drive.



2. Click the **Delete all user data on drive** button.

## Restoring Factory Settings


Restoring factory settings deletes all the user customized settings, lasers, subsystems and traces displayed on screen in the entire CTP10 system and restores the original default parameters.

This operation can take several minutes.

### To restore factory settings:

1. In the CTP10 task bar, click the  button to display the **Settings** window.

The **Settings and Data Management** area enables you to restore the factory settings.



2. Click the **Restore factory settings** button and wait until the confirmation message appears. This operation takes several minutes.





## 12 Remotely Controlling the CTP10

You can remotely control the CTP10 by using the Ethernet port, the USB-B port or the GPIB port (optional) located on the rear panel (see *Rear panel* on page 9).

Maximum transfer rates are available in *Technical Specifications* on page 3.

This section explains how to connect the CTP10 to an external device such as PC for remote control and set the remote control parameters.

### Setting the Communication Port

#### Setting the CTP10 Ethernet Port

You can remotely control the CTP10 from a computer connected to the CTP10 directly or through your company's network.

If you do not know how to configure this port or if the connection does not work, contact your company network administrator.

##### **To directly control the CTP10 from a remote computer:**

1. In the CTP10 task bar, click the  button to display the **Settings** window.


The **Ethernet** area enables you to configure the Ethernet connection of the CTP10.

2. In the **Port** field, set the TCP destination port of the CTP10, to allow data transmission between the CTP10 and external equipments.

Default value: 5025 (SCPI-RAW)

3. Connect an RJ45 cable from your computer to the CTP10 Ethernet port.
4. In the **Settings** window, clear the **Obtain an IP address automatically** check box and define a static IP address (e.g. 192.168.64.10), subnet mask (e.g. 255.255.255.0) and gateway to identify your CTP10.
5. Click **Apply** to validate the connection parameters.
6. On your computer:
  - Define a static IP address (e.g. 192.168.64.5, the three first number must be identical to the ones set for the CTP10), subnet mask (e.g. 255.255.255.0) and gateway to identify your computer.
  - Use the Ethernet parameters defined in the CTP10 Settings window to set the communication with your CTP10 in your application.

#### **To remotely control the CTP10 through your company network:**

1. In the CTP10 task bar, click the  button to display the **Settings** window.  
The **Ethernet** area enables you to configure the Ethernet connection of the CTP10.
2. In the **Port** field, set the TCP destination port of the CTP10, to allow data transmission between the CTP10 and external equipments.  
Default value: 5025 (SCPI-RAW)



### **IMPORTANT**

**Make sure that the firewall of your computer allows communication on this port.**

3. Connect an RJ45 cable from your company network to the CTP10 Ethernet port.
4. In the **Settings** window, set the IP address, subnet mask and gateway to identify your CTP10 (see *Connecting the CTP10 to your Company Network* on page 53).
5. Click **Apply** to validate the connection parameters.
6. On your computer, use the Ethernet parameters defined in the CTP10 Settings window to set the communication with your CTP10 in your application.

## **Setting the CTP10 USB-B Port**

The USB-B port located on the rear panel enables you to directly control the CTP10 from a connected computer on which the appropriate USB driver is installed.

To remotely control the CTP10 through the USB-B port, you must install the EXFO USB driver on the computer from which you want to control the CTP10.

The EXFO USB driver is available on the USB key provided with the CTP10, or can be downloaded from the EXFO website. It runs on operating system Windows 7 to Windows 10.

#### **To install the EXFO USB driver on your computer:**

1. Do one of the following:
  - Connect the CTP10 USB key to your computer.
  - From the EXFO website, download the CTP10 USB driver.
2. Unzip the CTP10 USB Driver to a temporary folder on your computer.
3. Connect your computer to the CTP10 by using a USB-A to USB-B cable.
4. On your computer, in the Windows Device Manager: under Other Devices, right-click **CTP10** and select **Update driver**.  
Windows prompts you to select a driver.
5. Browse your computer and select the CTP10 USB Driver folder; then follow the instructions displayed on screen to install the selected driver.

## Setting the CTP10 GPIB Port

If you want to remotely control the CTP10 through the GPIB port (optional), you can modify the CTP10 GPIB address.

The default GPIB address is 10. You can set it between 0 and 30.

### To set the CTP10 GPIB address:

1. In the CTP10 task bar, click the  button to display the **Settings** window.

The **GPIB** area enables you to configure the GPIB connection of the CTP10.

2. In the **Address** field, enter the wanted value to set the GPIB address of the CTP10.

## Entering/Exiting the Remote Mode

The CTP10 enters the remote mode when it receives a command from an external controller. When the remote mode is activated, you cannot use the CTP10 GUI to control the CTP10.

EXFO provides a set of program examples in C#, LabVIEW and Python, to help you communicate with the CTP10. The examples are available on the USB key provided with the CTP10, or can be downloaded from the EXFO website.

In remote mode, the CTP10 GUI displays the **Local** mode button on the main screen.

### To enter the remote mode:

1. Use the appropriate cable to connect the external controller to the CTP10:
  - Ethernet port: RJ45 cable
  - USB-B port: USB-A to USB-B cable.
  - GPIB port: IEEE 488 cable.
2. Make sure the port is properly configured for remote control:
  - For Ethernet: see *Setting the CTP10 Ethernet Port* on page 199.
  - For USB-B: see *Setting the CTP10 USB-B Port* on page 200.
  - For GPIB: see *Setting the CTP10 GPIB Port* on page 201.
3. Send a command from the remote controller. All available commands are described in *IEEE 488.2 and SCPI Command Reference* on page 235.

When the CTP10 receives a command from an external controller, it enters the remote mode: the GUI is deactivated and the **Local** button appears on the main screen.

### To exit the remote mode:

To get back to the local control of the CTP10, touch the **Local** button.

The GUI is now available and you can use it. The local operations performed will be taken into account when another remote command will be received by the CTP10.

## Communication Principle

EXFO supplies commands that follow the guidelines determined by the SCPI consortium for your CTP10.

The present section gives you information to help you use the provided commands, to remotely control your instrument.


### Standard Status Reporting

Each device has four status registers with a structure complying with the IEEE 488.2 standard. These registers allow the controller to monitor events and get useful information on the status of the devices it controls.

- Standard Event Status Register (ESR)
- Standard Event Status Enable Register (ESE)
- Status Byte Register (STB)
- Service Request Enable Register (SRE)

The following diagram is a useful aid in understanding the general commands and how a service request (SRQ) is generated.

Using a service request, a device notifies the controller that an event requiring special attention occurred. The controller will then find which device generated a SRQ (its RQS bit is set) and the causes of it.



### Standard Event Status Enable Register (ESE) and Standard Event Status Register (ESR)

The following table shows the content of the Standard Event Status Enable Register (ESE) and Standard Event Status Register (ESR):

Bit	Weight	Meaning
PON	128	Power ON Enable
N.U	64	Not used
CMD	32	CoMmanD Error Enable
EXE	16	Execution Error Enable

Bit	Weight	Meaning
DDE	8	Device Dependent Error Enable
QRY	4	QueRy Error Enable
N.U.	2	Not used
OPC	1	Operation Complete Enable

#### ***Service Request Enable Register (SRE)***

The following table shows the content of the Service Request Enable Register (SRE):

Bit	Weight	Meaning
OSB	128	Operational Status Register Bit Enable
N.U.	64	Not used
ESB	32	Event Summary Bit Enable
MAV	16	Message AAvailable Enable
QSB	8	Questionable Status Bit Enable
ERR	4	Error Message in Queue Enable
N.U.	2	Not used
N.U.	1	Not used


#### ***Status Byte Register (STB)***

The following table shows the content of the Status Byte Register (STB):

Bit	Weight	Meaning
OSB	128	Not used
MSS	64	MaSter Summary Status
ESB	32	Event Status Byte Enable
MAV	16	Message AAvailable Enable
QSB	8	Questionable Status Byte
ERR	4	Error Message in Queue
N.U.	2	Not used
N.U.	1	Not used

## Operational / Questionable Status Reporting

The following diagram show the operational and questionable status reporting structure.



### Legend

OSB: Operational Status Register Byte

QSB: Questionable Status Byte

- A rising bit in the Operational/Questionable Status Condition Register is copied to the Operational/Questionable Event Status Register.
- A falling bit in the Operational/Questionable Status Condition Register has no effect.
- Read effects:
  - Reading the Operational/Questionable Status Condition Register has no effect on the registers.
  - Reading the Operational/Questionable Event Status Register clears the register.
- The summary of Operational/Questionable Event Status Register is available in STB.

The following table shows the content of the Operational Status Condition Register:

Bit	Weight	Meaning
15	32768	Not used.
14	16384	Not used.
13	8192	Not used.
12	4096	Loading/Saving.
11	2048	Laser referencing.
10	1024	Updating setup for Daisy chaining.
9	512	Updating setup from Controller CTP10.
8	256	Waiting for Controller CTP10.
7	128	Quick referencing.
6	64	Referencing.
5	32	Armed.
4	16	Aborting.
3	8	Analyzing.
2	4	Scanning.
1	2	Calibrating.
0 (LSB)	1	Zeroing.

The following table shows the content of the Questionable Status Condition Register:

Bit	Weight	Meaning
15	32768	Not used.
14	16384	Not used.
13	8192	Not used.
12	4096	Not used.
11	2048	Not used.
10	1024	Not used.
9	512	Not used.
8	256	Not used.
7	128	Not used.
6	64	Not used.
5	32	Not used.
4	16	Not used.
3	8	Not used.
2	4	Not used.
1	2	Not used.
0 (LSB)	1	Temperature error.



## SCPI Command Structure and Syntax


The information presented in this section provides an overview of SCPI programming. If you need detailed information, refer to:

- The International Institute of Electrical and Electronics Engineers. IEEE Standard 488.2-1992, IEEE Standard Codes, Formats, Protocols and Common Commands For Use with ANSI/IEEE Std. 488.1-1987. New York, 1992.
- Standard Commands for Programmable Instruments (SCPI). Volume 1: Syntax and Style. Vers. 1999.0 May, U.S.A, 1999.

### Syntax of Messages

The provided commands follow the guidelines determined by the Standard Commands for Programmable Instruments (SCPI) consortium. A program message consists of one or more commands (and/or queries) with their appropriate parameters.

For example, a program message could contain a command used to activate or deactivate a source. The corresponding command syntax would be:



When sending a message containing the previous command, you would actually type:  
SOUR:POW ON.

The following table shows elements that are commonly used in the commands or queries syntax.

Item	Meaning
[ ]	Enclose optional keywords or parameters. <i>Do not include square brackets in your program message.</i>
[1..n]	Indicates that the instrument provides multiple capabilities and that you have to specify which one you want to use. If you omit the value, the command will take effect on the first capability.  Multiple capabilities can be found at any branch of the command tree (root, intermediate node or terminal node).  Example: If the command is :SENSe[1..n]:CORRection:COLLect:ZERO and you want it to take effect on the second SENSe (sensor) capability of the instrument, you may send this: :SENSe2:CORRection:COLLect:ZERO.  <i>Do not include square brackets in your program message; simply enter the number.</i>
<wsp>	Indicates that a space is required ("wsp" stands for "white space"). Corresponds to ASCII character codes (0 to 9 and 11 to 32, in decimal). <i>Do not include "&lt;wsp&gt;" in your program message; simply type a space.</i>

Item	Meaning
< >	Text appearing between angled brackets specifies the command parameter to be sent or the response you will receive from an instrument. <i>Do not include angled brackets in your program message.</i>
	Indicates that one, and only one, value must be selected from the available choices. Example: If the list is 0 1, you can only select 0 or 1. <i>Do not include the pipe character in your program message.</i>
{ }	Indicates that the enclosed parameters can appear 0 to n times when the command is used. <i>Do not include braces in your program message.</i>
:	Mandatory to separate keywords. Can be omitted at the beginning of a program message. For example, you can use either :SYST:ERR or SYST:ERR.
;	<ul style="list-style-type: none"> <li>➤ Mandatory to separate the different commands of a program message when more than one command is sent at a time. If an error occurs in a command of a program message, the program does not stop: all the commands of the program message are still executed.</li> <li>➤ Also used to separate responses when multiple queries were sent in a single program message.</li> </ul>
,	<ul style="list-style-type: none"> <li>➤ Mandatory to separate parameters in a command or a query.</li> <li>➤ Also used to separate the various responses from a query.</li> </ul>

There are also several conventions regarding command syntax:

- Spelling errors cancel the command or query.
- The unit of received numerical values is always the base unit.
- Numerical values are entered in decimal format.  
Result format for float is +1.12345678E-123.
- If a transmitted value has a higher precision than expected, the value is rounded off to the nearest accepted value.
- Commands and queries are not case-sensitive. You can type your program messages using either lower-case or upper-case letters.
- The command or query can be written using only the three- or four-letter shortcuts, only full words, or a combination of both.

The example below shows the long and the short forms of a same query.

:SYSTem:ERRor?	_____	Long form
:SYST:ERR?	}	Short form (small words represented by the capital letters of the long form)
:syst:err?		

- A message must end with the following characters: CR LF
- The CTP10 uses the ISO-8859-1:1998 (Latin-1, West Europe) character set. Make sure to configure your remote client with the same character set and to use supported characters while giving names to files or to other items.


### Command Types

The CTP10 uses the following types of commands and queries:

- Sequential: these commands are executed one after the other, in sequential order. A sequential command always finishes before the next command is implemented.
- Overlapped: these commands allow execution of overlapping commands while execution of the overlapped commands is still in progress.
- Overlapping: these commands can be executed during execution of an overlapped command.

### Error Messages

System and device-specific errors are managed by your unit. The generic format for error messages is illustrated in the following figure.



As shown in the above figure, the message contains three parts:

- error number
- error description
- device-dependent information

Error messages ending in a negative number are SCPI-based errors. The list of possible error codes is available in *SCPI-Based Errors* on page 535.



### IMPORTANT

If an error occurs in a command of a program message (several commands separated by ";"), the program does not stop: all the commands of the program message are executed. As a consequence, several errors may be present in the error queue. You need to check the error bit to make sure that the error queue is empty.

## Writing Remote Control Code

Your unit offers a set of commands permitting remote control of the CTP10. You can find all the commands and queries supported by the CTP10 in *IEEE 488.2 and SCPI Command Reference* on page 235.


EXFO provides a set of program examples in C#, LabVIEW and Python, to help you communicate with the CTP10. The examples are available on the USB key provided with the CTP10, or can be downloaded from the EXFO website.

The following diagram gives an overview of the steps and necessary commands required to remotely perform a DUT characterization using the CTP10.

## Remotely Controlling the CTP10


### Writing Remote Control Code

#### Create and connect your laser(s) to the CTP10




1. Connect laser(s) to CTP10:
  - `:CTP:RLASer[1...10]:TYPE` on page 287.
  - `:CTP:RLASer[1...10]:CPARameters` on page 280.
  - `:CTP:RLASer[1...10]:LINK` on page 283.
2. Configure laser parameters with commands `:CTP:RLASer` (see p. 287).

#### Configure your test setup



1. Define the location and connections of your modules and lasers in the subsystem, in the following order:
  - `:INITiate:TLS[1...4]:` (see p. 451).
  - `:INITiate:FBC:` (if any, see p. 451).
  - `:INITiate:ILRL[:SENSe]` (see p. 458).
  - `:INITiate:ILRL:TLSin` (see p. 459).
  - `:INITiate:SCANsync[:SENSe]` (see p. 463).
2. If needed, configure the Daisy chaining function and open the connection to another CTP10 for Daisy chaining:
  - `:CTP:DCHAINing commands` (see p. 263).
  - `:CTP:DCHAINing:ID1:LINK` (see p. 261).Once entered in the Daisy chaining mode, you must execute all commands and queries on the Primary CTP10. You cannot send any commands or queries to the Secondary CTP10, except:
  - `:STATus:OPERation[:EVENT]?` on page 250,
  - `:STATus:OPERation:CONDition?` on page 251,
  - `:SYSTem:ERRor[:NEXT]?` on page 249,
  - `:STATus:PRESet` on page 255,
  - `:CTP:DLOG` on page 265,
  - `:CTP:DCHAINing:STATus?` on page 265,
  - `:CTP:DCHAINing:CLOSe` on page 259, `*RST` on page 241, `*IDN?` on page 239.
3. Define the detectors connections to the DUT and the wanted traces:
  - `:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10]` / `[14...18]:ACTive` on page 515.


### Share the lasers with other CTP10s if needed (not compatible with Daisy chaining)



Before entering the laser sharing mode, make sure that the CTP10s that you want to set as Distributed are properly configured:


- On CTP10s that you want to set as Distributed, define the location and connections of the modules:
  - `:INITiate:ILRL[:SENSe]` on page 458
  - `:INITiate:SCANsync[:SENSe]` on page 463.
- On CTP10s that you want to set as Distributed, define the detectors connections to the DUT and the wanted traces:
  - `:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10] | [14...18]:ACTiVe` on page 515.
- Enter the laser sharing mode by connecting the Controller CTP10 to Distributed CTP10s:
  - `:CTP:LSHARing` (see p. 272).

### Configure the scan parameters and reference the subsystem



- Configure the scan parameters:
  - *INITiate Commands and Queries* on page 451.
  - *UNIT Commands and Queries* on page 533.
  - *TRIGger Commands and Queries* on page 526.
- Reference the subsystem:
  - TF/BR or TF/PDL referencing (depending on the module used) and wavelength referencing: *REference Commands and Queries* on page 497.
  - Dark current referencing: `:CTP:SENSe[1...20]:CHANnel[1...6]:ZEROing` on page 300.

#### Test your DUT



1. Perform scan:
  - *:INITiate[:IMMEDIATE]* on page 452.
2. Manage traces:
  - *TRACe Commands and Queries* on page 504.
3. Perform analysis:
  - *CALCulate Commands and Queries* on page 306.
  - *CALCulate:DATA Queries* on page 332.
4. Manage data files:
  - *MMEMemory Commands and Queries* on page 488.

## 13 Maintenance

To help ensure long, trouble-free operation:

- Always inspect fiber-optic connectors before using them and clean them if necessary.
- Keep the unit free of dust.
- Clean the unit casing and front panel with a cloth slightly dampened with water.
- Store unit at room temperature in a clean and dry area. Keep the unit out of direct sunlight.
- Avoid high humidity or significant temperature fluctuations.
- Avoid unnecessary shocks and vibrations.
- If any liquids are spilled on or into the unit, turn off the power immediately, disconnect from any external power source and let the unit dry completely.



### WARNING

The use of controls, adjustments and procedures, namely for operation and maintenance, other than those specified herein may result in hazardous radiation exposure or impair the protection provided by this unit.

## Cleaning the CTP10

### Cleaning the Cover of the CTP10

If the external cover of the CTP10 becomes dirty or dusty, clean it by following the instruction below.



### CAUTION

Do not use chemically active or abrasive materials to clean the CTP10.

Material needed:

- Cleaning cloth
- Isopropyl alcohol

#### **To clean the external cover of the CTP10:**

1. Turn the CTP10 off (see *Turning off the CTP10* on page 49) and unplug the power supply cable from the wall socket.
2. Slightly damp the cloth with an isopropyl alcohol liquid and gently swipe dirt and dust on the external cover of the CTP10, without applying excessive force onto it.

## Cleaning the Fan Grids

To ensure proper cooling of the CTP10 from the fan, the cooling fan grids located on the rear panel (see *Rear panel* on page 9) must not be dusty, you must clean it regularly.



### CAUTION

Do not use a vacuum cleaner to clean the fan as this may apply excessive force to it and cause damage to the fan.

#### To clean the fan grids:

1. Turn the CTP10 off (see *Turning off the CTP10* on page 49) and unplug the power supply cable from the wall socket.
2. Using a duster or a slightly moist cloth, gently clean the external grid of the fan without pressing it.


## Replacing the Air Filter

To ensure proper ventilation of the CTP10, the air input filter must not be too dusty, you must replace it as soon as you notice that dust accumulates on it.

The air filter is affixed with velcro tape to the bottom side of the instrument, you do not need to open the case to replace it.


#### To replace the air filter:

1. Make sure you have a replacement filter: contact your EXFO sales representative.
2. Turn the CTP10 off (see *Turning off the CTP10* on page 49) and unplug the power supply cable from the wall socket.
3. Lift the instrument and flip it over gently on a stable soft surface to make visible the air filter.
4. Separate the filter grid from the instrument by pulling out each corner of the grid: it is fastened with velcro tape at the four corners of the filter grid.





- 5.** Remove the dusty filter from the filter grid and replace it by the new one.



- 6.** Fasten back the filter grid on the instrument.

## Cleaning Optical Connectors

To ensure measurement accuracy and prevent loss of optical power, you must regularly verify that the optical connectors of the CTP10 modules are clean. Follow the cleaning instructions corresponding to the type of connector to clean:

- *Cleaning Detector Ports* on page 216
- *Cleaning TLS Input and Output Connectors* on page 218

## Cleaning Detector Ports

To ensure measurement accuracy and prevent loss of optical power, you must regularly verify that the optical detectors located on the OPMx, IL RL OPM2 and IL PDL OPM2 modules are clean.

Handle optical fiber with appropriate care and preserve the integrity of optical connectors by keeping them free of contamination.



### IMPORTANT

To reduce the need for cleaning, immediately replace protective caps on the optical connectors when not in use.

#### **Before starting:**

- Turn off all the laser sources connected to the CTP10 and make sure that no optical power is coming in or out the connector you want to clean.
- Make sure you have the following material:



### IMPORTANT

Use only high quality cleaning supplies that are non-abrasive and leave no residue.

- Clean compressed air
- Fiberscope or similar


**To clean the detector ports:**

- 1.** On the module front panel, use your fingers to unscrew the fiber optic adapter (FOA) with its protective cap from the connector.



**CAUTION**

Do not touch the black part inside the FOA.



- 2.** Clean the connector as follows:
  - 2a.** Hold the can of compressed air upright and spray the can into the air to purge any propellant.
  - 2b.** Spray the clean compressed air on the detector to remove any loose particles or moisture.
- 3.** Screw back the FOA on the connector.

## Cleaning TLS Input and Output Connectors

To ensure measurement accuracy and prevent loss of optical power, you must regularly verify that the optical connectors located on the SCAN SYNC and IL RL OPM2 modules are clean.

Handle optical fiber with appropriate care and preserve the integrity of optical connectors by keeping them free of contamination.



### IMPORTANT

To reduce the need for cleaning, immediately replace protective caps on the optical connectors when not in use.

#### ***Before starting:***

- Turn off all the laser sources connected to the CTP10 and make sure that no optical power is coming in or out the connector you want to clean.
- Make sure you have the following material:




### IMPORTANT

Use only high quality cleaning supplies that are non-abrasive and leave no residue.

- Clean compressed air
- Optical grade cleaning swabs
- Connector cleaner pen
- Fiberscope or similar if available

**To clean the connectors:**

- 1.** On the module front panel, use your fingers to unscrew the metallic protective cap from the connector. Do not disassemble the bulkhead adapter.



- 2.** Gently clean the connector end, with the following instructions:
  - 2a.** Hold the can of compressed air upright and spray the can into the air to purge any propellant.
  - 2b.** Spray the clean compressed air on the connector to remove any loose particles or moisture.
- 3.** Clean the fiber end using your cleaning tool.
- 4.** Spray the clean compressed air on the connector again to remove any loose particles or isopropyl alcohol.
- 5.** Check that the connector is clean with a fiberscope (or similar).

## Replacing Fuses

You must verify the power fuses in case you cannot turn on the CTP10.



### WARNING

To avoid fire hazard, only use the correct fuse type, voltage and current ratings.

The unit contains two fuses (see *Technical Specifications* on page 3 for details). The fuse holder is located at the back of the unit, just above the power inlet.


#### **Before starting:**

Make sure you have the following equipment:


- 1 small flat-head screwdriver.
- 1 or 2 replacement fuses (for fuse type, see *Technical Specifications* on page 3).

#### **To replace a fuse:**

1. Turn off the unit and unplug the power cord.
2. Using a flat-head screwdriver as a lever, pull the fuse holder out of the unit.



3. Check and replace the fuses if necessary.
4. Insert the new fuse into the fuse holder.



5. Make sure the fuses are placed firmly in the holder prior to reinsertion.
6. Firmly push the fuse holder into place.

## Carrying the CTP10

The two flexible handles located on both sides of the CTP10 allow you to carry it from one location to another, as explained in the following procedure.

The weight of the CTP10 mainframe and modules is detailed in *Technical Specifications* on page 3.

### **To carry the CTP10:**

1. Turn the CTP10 off normally (see *Turning off the CTP10* on page 49).
2. Unplug the power cable from the wall socket outlet.
3. Disconnect all external devices, cables and patchcords connected to the CTP10 mainframe and modules.
4. Make sure that all the modules are secured in their slot by tightening the captive screws of all the modules
5. Carry the CTP10 with two hands using the two handles located on both side or the two rack-mounting handles.

## Recalibrating the SCAN SYNC Module

The validity of specifications depends on operating conditions. For example, the calibration validity period can be longer or shorter depending on the intensity of use, environmental conditions and unit maintenance, as well as the specific requirements for your application. All of these elements must be taken into consideration when determining the appropriate calibration interval of this particular EXFO unit.

Under normal use, the recommended interval for your SCAN SYNC module is: 1 year.

## Recycling and Disposal



This symbol on the product means that you should recycle or dispose of your product (including electric and electronic accessories) properly, in accordance with local regulations. Do not dispose of it in ordinary garbage receptacles.

For complete recycling/disposal information, visit the EXFO Web site at [www.exfo.com/recycle](http://www.exfo.com/recycle).





# 14 Troubleshooting

This section explains how to handle common problems that can occur with your instrument, and how to ask for support.

## Solving Common Problems

The following table lists problems that can occur and their possible solution.

Trouble	Possible cause	Possible resolution
The CTP10 is stuck at "Initializing Hardware" or "Loading".	The CTP10 cannot load the user configuration.	See <i>Restoring Factory Settings at Startup</i> on page 224
The GUI is frozen.	The system has encountered a problem.	See <i>Forcing the CTP10 to Shutdown &amp; Restart</i> on page 225.
A part of the GUI window is not visible on screen.	Your screen resolution is too low for the CTP10 GUI.	See <i>Changing Your Screen Resolution</i> on page 225.
	The highest possible resolution of your screen is too low to display the CTP10 GUI.	Use a screen with a better resolution. The recommended screen resolution for the CTP10 GUI is given in <i>Technical Specifications</i> on page 3.
Temperature error on a module	Lack of ventilation in the CTP10 mainframe	<ul style="list-style-type: none"> <li>➤ Make sure the location where the CTP10 is installed meets the environmental characteristics listed in <i>Electrical Safety Information</i> on page 27.</li> <li>➤ Make sure the CTP10 is not located near a source of heat.</li> <li>➤ Make sure there is sufficient clearance below and at the rear of the CTP10 in the place where it is installed.</li> </ul>
	Dusty input or output air filters	<ul style="list-style-type: none"> <li>➤ See <i>Replacing the Air Filter</i> on page 214.</li> <li>➤ See <i>Cleaning the Fan Grids</i> on page 214.</li> </ul>
	Defective fans	<ul style="list-style-type: none"> <li>➤ CTP10 turned on: remove the module and verify by looking into the empty slot that the internal fan of the slot rotates properly.</li> <li>➤ CTP10 turned on: verify that the two cooling fans located on the rear panel rotate properly.</li> </ul> <p>If one fan does not rotate properly, contact the EXFO support: see <i>Contacting the Technical Support Group</i> on page 230.</p>

Trouble	Possible cause	Possible resolution
Impossible to open connection to a laser through GPIB.	The GPIB-USB adapter has been disconnected while a GPIB connection was open with a laser.	Connect the GPIB-USB adapter and restart the CTP10.
A module firmware update has been suddenly interrupted (power failure or abrupt shutdown of the CTP10); at startup, the module displays an error in the <b>Modules &amp; Lasers</b> window.	The module has not been fully initialized at startup.	Remove the module from the CTP10 mainframe (see <i>Removing a Module From the CTP10 Mainframe</i> on page 37) and insert it again (see <i>Installing a Module Into the CTP10 Mainframe</i> on page 35).

## Restoring Factory Settings at Startup

If the CTP10 stays stuck at initialization time during startup, it may be due to the user configuration that cannot be retrieved. In this case, follow the instructions below to restore the factory settings at startup time (the system and module versions won't be modified).

### **To restore default settings at startup:**

1. If the CTP10 is indefinitely "Initializing hardware" or "Loading" at startup time, stop the system by pressing the On/Off button during 4 seconds.
2. Connect a keyboard to one of the USB ports of the CTP10.
3. Press the On/Off button to turn on the CTP10 and wait for the white EXFO logo to appear on screen.
4. As soon as the white EXFO logo disappears from screen, press the **Delete** key on the keyboard and hold it down until the **Restore Factory Settings** window appears on screen.
5. Release the **Delete** key and click **Yes**.
6. Accept the license agreement and wait until the startup procedure is completed and the **Modules and Lasers** window appear on screen.

The CTP10 is started with the default settings, the user customized settings has been deleted.

## Forcing the CTP10 to Shutdown & Restart

In case of system crash and frozen screen, you can abruptly turn the CTP10 off as explained in the following procedure.



### CAUTION

Do not stop the CTP10 with this procedure if you can turn it off normally as explained in *Turning on the CTP10 and Accessing the GUI* on page 44.

#### **To force the CTP10 to shutdown and restart:**

1. If the touchscreen is frozen: connect a mouse to one of the USB ports and try to shutdown the CTP10 as explained in *Turning off the CTP10* on page 49.

If this does not work, follow the rest of these instructions.


2. Press the On/Off button during 4 seconds.  
The system abruptly stops.
3. On the rear panel, set the power switch to **O**.
4. Wait 10 seconds and set the power switch back to **I**.
5. Restart the CTP10 as explained in *Turning on the CTP10 and Accessing the GUI* on page 44.

After an abrupt shutdown and restart, the subsystem that was running when the system crashed is not retrieved. The loaded subsystem is the one that was up and running at the last proper shutdown (as explained in *Turning on the CTP10 and Accessing the GUI* on page 44).

## Changing Your Screen Resolution

In case a part of the GUI window is not visible on screen, it may be due to the screen resolution setting, which is not adapted to the CTP10 GUI.

#### **To modify the screen resolution:**

1. In the CTP10 task bar, click the  button to display the **Settings** window.  
The **Display** area enables you to set the screen resolution.
2. In the **Screen 1 resolution** or **Screen 2 resolution** list (depending on the affected screen), modify your screen resolution to a higher resolution setting.

## Abruptly Turning off the CTP10 (Emergency Shutdown)

In case of emergency (presence of smoke flame or any immediate hazard), you can abruptly turn the CTP10 off as explained in the following procedure.



### CAUTION

Do not stop the CTP10 with this procedure if you can turn it off normally as explained in *Turning off the CTP10* on page 49.

#### ***To abruptly turn off the CTP10:***

Unplug the CTP10 by pulling the power cable off the CTP10 power cable connector on the rear panel (see *Rear panel* on page 9).

## Using Assistance Tools


The CTP10 provides tools for remote or self assistance, as explained in the following sections:

- *Sending Debug Data to EXFO Support Service* on page 227
- *Performing a Self-test* on page 227
- *Displaying the List of Errors and Warnings* on page 228

### Sending Debug Data to EXFO Support Service

Saving debug data and sending it to the EXFO customer support service can be useful for remote assistance.


#### **To save and send debug data:**

1. In the CTP10 task bar, click the  button to display the **Settings** window.
2. In the **Self-test and Debug data** area, click the **Save Debug Data** button.
3. Enter a name for the \*.dbgexfo file and save it on the wanted location.
4. Send the saved file to the EXFO customer support service (for contact details, see *Contacting the Technical Support Group* on page 230).

### Performing a Self-test

Performing a self-test enables you to detect possible errors on the system or on a CTP10 module, and may be used for remote assistance from the EXFO customer support service.

#### **To perform a self-test on the CTP10 mainframe:**

1. In the CTP10 task bar, click the  button to display the **Settings** window.
2. In the **Self-test and Debug data** area, click the **Run self-test** button and wait for its execution.

The result of the test is displayed on screen.

#### **To perform a self-test on a CTP10 module:**

1. In the **Modules and Lasers** window, click the wanted module.
2. In the module **Information** area, click the **Run self-test** button.


The result of the test is displayed on screen. If an error is detected, the module becomes unavailable and displays an error.

## Displaying the List of Errors and Warnings

The following procedure explains how to display the last main errors and warnings that occurred on the CTP10. Only errors/warnings of the following types are displayed:


- File loading (excluding traces) and file saving errors/warnings
- Platform communication errors/warnings
- Module communication errors/warnings
- Auto-test errors/warnings
- Scanning errors/warnings
- Module configuration errors/warnings
- Module upgrade errors/warnings

### **To display the last error/warning messages:**

In the CTP10 task bar, click the  button.

The last 100 errors or warnings that occurred are displayed in order of appearance, with their corresponding date and time.

### **To clear the list of error/warning messages:**


1. In the CTP10 task bar, click the  button.
2. At the bottom of the list, click the **Clear error list** button.

If the red Error LED was lit, it immediately turns off.

## Viewing System Information

You can see information about your product, such as the serial number, options, version numbers, license agreement and contact information at all times.

### **To view product information:**

1. In the task bar, click the  button and select **About**.
2. Do one of the following:
  - To display contact information, click the **Technical Support** tab
  - To display product information, click the **System Information** tab
3. To see the license agreements, click the **View License Agreement** button.
4. To go back to the About window, click again the **View License Agreement** button.
5. Click the **OK** button to exit.


## Displaying the User Documentation

You can access the user guide at all times from your unit. Multi-touch screen gestures are available to zoom in or out on the help pages. If a keyboard is connected, you can also use it to zoom in or out and browse the help pages.

The user guide is also available in PDF format on the USB key delivered with the instrument and from the EXFO website:

[EXFO.com/en/resources/](http://EXFO.com/en/resources/)

### ***To open the user documentation from the GUI:***

In the task bar, click the  button and select **Help**.

The user guide appears in the main window.

### ***To zoom in/out:***

- To zoom in/out using multi-touch screen gestures: pinch two fingers together or move them apart.

- To zoom in/out using a keyboard (and mouse):

Press **Ctrl** and use the mouse scroll wheel.

OR

Press **Ctrl + + / Ctrl + -**

- To reset page zoom, press **Ctrl + 0**

### ***To browse the help pages using keyboard commands:***

- To go back, press **Shift + Back** key.
- To go forward, press the **Back** key.
- To reload the help pages, press **F5**.

## Contacting the Technical Support Group

To obtain after-sales service or technical support for this product, contact EXFO at one of the following numbers. The Technical Support Group is available to take your calls from Monday to Friday, 8:00 a.m. to 7:00 p.m. (Eastern Time in North America).

### Technical Support Group

400 Godin Avenue  
Quebec (Quebec) G1M 2K2  
CANADA

1 866 683-0155 (USA and Canada)  
Tel.: 1 418 683-5498  
Fax: 1 418 683-9224  
support@exfo.com

For detailed information about technical support, and for a list of other worldwide locations, visit the EXFO Web site at [www.exfo.com](http://www.exfo.com).

If you have comments or suggestions about this user documentation, you can send them to [customer.feedback.manual@exfo.com](mailto:customer.feedback.manual@exfo.com).

To accelerate the process, please have information such as the name and the serial number (see the product identification label), as well as a description of your problem, close at hand.

## Transportation

Maintain a temperature range within specifications when transporting the unit. Transportation damage can occur from improper handling. The following steps are recommended to minimize the possibility of damage:

- Pack the unit in its original packing material when shipping.
- Avoid high humidity or large temperature fluctuations.
- Keep the unit out of direct sunlight.
- Avoid unnecessary shocks and vibrations.

For instructions on returning the CTP10, please contact EXFO (see *Contacting the Technical Support Group* on page 230).

### **To package a CTP10 module for shipment:**

1. On the module front panel, unscrew all the FOA with their protective cap from the connectors and pack them in a protective plastic bag.
2. Screw a dust cap (originally provided with the module) on all the connectors.
3. Make sure that the extractor handle is in upright position.
4. Place the module in its original packaging with all the FOA.
5. Close the box.



# 15 **Warranty**

## **General Information**

EXFO Inc. (EXFO) warrants this equipment against defects in material and workmanship for a period of 1 year from the date of original shipment. EXFO also warrants that this equipment will meet applicable specifications under normal use.

During the warranty period, EXFO will, at its discretion, repair, replace, or issue credit for any defective product, as well as verify and adjust the product free of charge should the equipment need to be repaired or if the original calibration is erroneous. If the equipment is sent back for verification of calibration during the warranty period and found to meet all published specifications, EXFO will charge standard calibration fees.



### **IMPORTANT**

The warranty can become null and void if:

- unit has been tampered with, repaired, or worked upon by unauthorized individuals or non-EXFO personnel.
- warranty sticker has been removed.
- case screws, other than those specified in this guide, have been removed.
- case has been opened, other than as explained in this guide.
- unit serial number has been altered, erased, or removed.
- unit has been misused, neglected, or damaged by accident.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL EXFO BE LIABLE FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

## **Gray Market and Gray Market Products**

Gray market is a market where products are traded through distribution channels that are legal but remain unofficial, unauthorized, or unintended by the original manufacturer. Intermediaries using such channels to distribute products are considered to be part of the gray market (hereafter unauthorized intermediary).

EXFO considers that a product originates from the gray market (hereafter gray market product) in the following situations:

A product is sold by an unauthorized intermediary.

A product is designed and destined for a particular market and sold on a second market.

A product is resold, despite being reported lost or stolen.

When products are purchased on the gray market, rather than through an authorized EXFO distribution channel, EXFO is unable to guarantee the source and quality of those products nor the local safety regulations and certifications (CE, UL, etc.).

EXFO will not honor warranty, install, maintain, repair, calibrate, provide technical support nor make any support contracts available for gray market products.

For complete information, refer to EXFO's policy regarding gray market products at [www.exfo.com/en/how-to-buy/sales-terms-conditions/gray-market/](http://www.exfo.com/en/how-to-buy/sales-terms-conditions/gray-market/)

## Warranty

### Liability

---

## Liability

EXFO shall not be liable for damages resulting from the use of the product, nor shall be responsible for any failure in the performance of other items to which the product is connected or the operation of any system of which the product may be a part.

EXFO shall not be liable for damages resulting from improper usage or unauthorized modification of the product, its accompanying accessories and software.

## Exclusions

EXFO reserves the right to make changes in the design or construction of any of its products at any time without incurring obligation to make any changes whatsoever on units purchased. Accessories, including but not limited to fuses, pilot lamps, batteries and universal interfaces (EUI) used with EXFO products are not covered by this warranty.

This warranty excludes failure resulting from: improper use or installation, normal wear and tear, accident, abuse, neglect, fire, water, lightning or other acts of nature, causes external to the product or other factors beyond the control of EXFO.



### IMPORTANT

In the case of products equipped with optical connectors, EXFO will charge a fee for replacing connectors that were damaged due to misuse or bad cleaning.

## Certification

EXFO certifies that this equipment met its published specifications at the time of shipment from the factory.

## Service and Repairs

EXFO commits to providing product service and repair for five years following the date of purchase.

**To send any equipment for service or repair:**

1. Call one of EXFO's authorized service centers (see *EXFO Service Centers Worldwide* on page 234). Support personnel will determine if the equipment requires service, repair, or calibration.
2. If equipment must be returned to EXFO or an authorized service center, support personnel will issue a Return Merchandise Authorization (RMA) number and provide an address for return.
3. If possible, back up your data before sending the unit for repair.
4. Pack the equipment in its original shipping material. Be sure to include a statement or report fully detailing the defect and the conditions under which it was observed.
5. Return the equipment, prepaid, to the address given to you by support personnel. Be sure to write the RMA number on the shipping slip. *EXFO will refuse and return any package that does not bear an RMA number.*

**Note:** *A test setup fee will apply to any returned unit that, after test, is found to meet the applicable specifications.*

After repair, the equipment will be returned with a repair report. If the equipment is not under warranty, you will be invoiced for the cost appearing on this report. EXFO will pay return-to-customer shipping costs for equipment under warranty. Shipping insurance is at your expense.

Routine recalibration is not included in any of the warranty plans. Since calibrations/verifications are not covered by the basic or extended warranties, you may elect to purchase FlexCare Calibration/Verification Packages for a definite period of time. Contact an authorized service center (see *EXFO Service Centers Worldwide* on page 234).

## Warranty

EXFO Service Centers Worldwide

---

### EXFO Service Centers Worldwide

If your product requires servicing, contact your nearest authorized service center.

#### EXFO Headquarters Service Center

400 Godin Avenue  
Quebec (Quebec) G1M 2K2  
CANADA

1 866 683-0155 (USA and Canada)  
Tel.: 1 418 683-5498  
Fax: 1 418 683-9224  
support@exfo.com

#### EXFO Europe Service Center

Winchester House, School Lane  
Chandlers Ford, Hampshire S053 4DG  
ENGLAND

Tel.: +44 2380 246800  
Fax: +44 2380 246801  
support.europe@exfo.com

#### EXFO Telecom Equipment (Shenzhen) Ltd.

3rd Floor, Building C,  
FuNing Hi-Tech Industrial Park, No. 71-3,  
Xintian Avenue,  
Fuhai, Bao'An District,  
Shenzhen, China, 518103

Tel: +86 (755) 2955 3100  
Fax: +86 (755) 2955 3101  
support.asia@exfo.com

To view EXFO's network of partner-operated Certified Service Centers nearest you, please consult EXFO's corporate website for the complete list of service partners:

[http://www.exfo.com/support/services/instrument-services/  
exfo-service-centers.](http://www.exfo.com/support/services/instrument-services/exfo-service-centers)

# A **IEEE 488.2 and SCPI Command Reference**

This section presents detailed information about the command and queries supplied with your CTP10. For more details on CTP10 remote control parameters and procedures, see *Remotely Controlling the CTP10* on page 199.

## IEEE 488.2 Commands

### Quick Reference

The CTP10 recognizes the required commands identified in IEEE 488.2. The table below summarizes these commands. These commands are fully explained on the following pages.

Command	Function	Section
*CLS	Clear status command	*CLS on page 236
*ESE	Standard event status enable command	*ESE on page 236
*ESE?	Standard event status enable query	*ESE? on page 237
*ESR?	Standard event status register query	*ESR? on page 238
*IDN?	Identification query	*IDN? on page 239
*OPC	Operation complete command	*OPC on page 240
*OPC?	Operation complete query	*OPC? on page 240
*RST	Reset command	*RST on page 241
*SRE	Service request enable command	*SRE on page 242
*SRE?	Service request enable query	*SRE? on page 242
*STB?	Read status byte query	*STB? on page 243
*TST?	Self-test query	*TST? on page 244
*WAI	Wait for pending operations to be completed	*WAI on page 244

## IEEE 488.2 Required Commands

*CLS	
<b>Description</b>	The *CLS command clears the Standard Event Status Register, the Status Byte Register and the Error Queue.
<b>Type</b>	Overlapping, no query.
<b>Syntax</b>	*CLS
<b>Parameter(s)</b>	None.
*ESE	
<b>Description</b>	<p>The *ESE command sets the Standard Event Status Enable Register bits, as defined in <i>Standard Event Status Enable Register (ESE)</i> and <i>Standard Event Status Register (ESR)</i> on page 203.</p> <p>This register contains a mask value for the bits to be enabled in the Standard Event Status Register.</p>
<b>Type</b>	Overlapping.
<b>Syntax</b>	*ESE<wsp> <register value>
<b>Parameter(s)</b>	<p><i>register value:</i></p> <p>The &lt;register value&gt;, expressed in base 2 (binary), represents the bit values of the Standard Event Status Enable Register, in the range of 0 through 255.</p> <p>See the content of this register in <i>Standard Event Status Enable Register (ESE)</i> and <i>Standard Event Status Register (ESR)</i> on page 203.</p> <p>A value of 1 in the Enable Register enables the corresponding bit in the Status Register, a value of 0 disables the bit.</p>
<b>Example(s)</b>	<p>*ESE 25 where 25 = (bit EXE, bit DDE and bit OPC)</p> <p>*ESE 0 clears the content of the Standard Event Status Enable register</p>
<b>See Also</b>	<p>*ESE?</p> <p>*ESR?</p>

*ESE?	
Description	The *ESE? query returns the current contents of the Standard Event Status Enable Register, as defined in <i>Standard Event Status Enable Register (ESE)</i> and <i>Standard Event Status Register (ESR)</i> on page 203.
Type	Overlapping.
Syntax	*ESE?
Parameter(s)	None.
Response Syntax	<register value>
Response(s)	<p><i>register value:</i></p> <p>The &lt;register value&gt; value expressed in base 2 (binary) represents the bit values of the Standard Event Status Enable register.</p> <p>The &lt;register value&gt; ranges from 0 through 255.</p> <p>See the content of this register in <i>Standard Event Status Enable Register (ESE)</i> and <i>Standard Event Status Register (ESR)</i> on page 203.</p>
Example(s)	<p>*ESE? returns 133 where 133 = (bit PON, bit QYE and bit OPC)</p>
See Also	<p>*ESE *ESR?</p>

*ESR?	
Description	<p>The *ESR? query returns the current contents of the Standard Event Status Register, as defined in <i>Standard Event Status Enable Register (ESE) and Standard Event Status Register (ESR)</i> on page 203.</p> <p>Reading the Standard Event Status Register clears it.</p>
Type	Overlapping, query only.
Syntax	*ESR?
Parameter(s)	None.
Response Syntax	<register value>
Response(s)	<p><i>register value:</i></p> <p>The &lt;register value&gt; value expressed in base 2 (binary) represents the bit values of the Standard Event Status register.</p> <p>The &lt;register value&gt; ranges from 0 through 255.</p> <p>See the content of this register in <i>Standard Event Status Enable Register (ESE) and Standard Event Status Register (ESR)</i> on page 203.</p>
Example(s)	<p>*ESR? returns 33                      where 33 = (bit CME and bit OPC)</p>
See Also	<p>*ESE</p> <p>*ESE?</p>



**\*IDN?**

<b>Description</b>	The *IDN? query returns the unique identification of the device over the system interface.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	*IDN?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<Identification>
<b>Response(s)</b>	<p><i>Identification:</i></p> <p>The response is organized into four fields separated by commas. The field definitions are as follows:</p> <p>Field 1 (Manufacturer): EXFO</p> <p>Field 2 (Model): Instrument model</p> <p>Field 3 (Serial number): ASCII character (0 if not available)</p> <p>Field 4 (Firmware level): ASCII character (0 if not available)</p> <p>ASCII character 0 represents a single ASCII-encoded byte with a value of 30 (48 decimal).</p> <p>The presence of data in all fields is mandatory. If either field 3 or 4 is not available, the ASCII character 0 shall be returned for that field. A field may contain any 7-bit ASCII-encoded bytes in the range of 20 through 7E (32 through 126 decimal) except commas (2C, 44 decimal) and semicolons (3B, 59 decimal).</p>
<b>Example(s)</b>	*IDN? returns EXFO,CTP10,EO182110146,1.0.0
<b>Notes</b>	The overall length of the *IDN? response is less than or equal to 72 characters.

**\*OPC**

<b>Description</b>	<p>The *OPC command makes synchronization between the instrument and an external controller possible; it causes the instrument to set bit-0 (Operation Complete) in the Standard Event Status Register to the TRUE (logic 1) state when the instrument completes all pending operations.</p> <p>Detection of the Operation Complete message can be accomplished by continuous polling of the Standard Event Status Register using the *ESR? common query command. However, using a service request eliminates the need to poll the Standard Event Status Register thereby freeing the controller to do other useful work.</p>
<b>Type</b>	Overlapping.
<b>Syntax</b>	*OPC
<b>Parameter(s)</b>	None.
<b>See Also</b>	*OPC? *WAI

---

**\*OPC?**

<b>Description</b>	<p>The *OPC? query makes possible the synchronization between the instrument and an external controller by reading the Output Queue or by waiting for a service request on the Message Available (MAV) bit in the Status Byte Register.</p> <p>The *OPC? query causes the instrument to place an ASCII character, 1, into its Output Queue when the device completes all pending operations. A consequence of this action is that the MAV bit in the Status Byte Register is set to state 1.</p>
<b>Type</b>	Overlapping.
<b>Syntax</b>	*OPC?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<Acknowledge>
<b>Response(s)</b>	<p><i>Acknowledge:</i></p> <p>The &lt;Acknowledge&gt; response is a single ASCII-encoded byte corresponding to 1.</p> <p>The receipt of an &lt;Acknowledge&gt; response indicates that all pending selected device operations have been completed.</p>
<b>Example(s)</b>	*OPC? returns 1
<b>See Also</b>	*OPC *WAI

---

**\*RST**

<b>Description</b>	<p>The *RST command performs a reset of the instrument.</p> <p>The command sets the instrument settings to default values (user customized settings, lasers, subsystems and traces). It restores the original default parameters.</p> <p>It also clear the error queue, status byte and event register.</p> <p>This operation can take several minutes: to know if the reset operation is completed, use the <i>:RST?</i> query (<i>:RST?</i> on page 255).</p> <p>The command does not affect the following:</p> <ul style="list-style-type: none"><li>➤ the state and address of the communication interfaces of the device</li><li>➤ the calibration data</li><li>➤ the module settings</li></ul>
<b>Type</b>	Overlapping.
<b>Syntax</b>	*RST
<b>Parameter(s)</b>	None.

---

<b>*SRE</b>	
<b>Description</b>	<p>The *SRE command sets the Service Request Enable Register bits, as defined in <i>Service Request Enable Register (SRE)</i> on page 204</p> <p>This register contains a mask value to enable the bits in the Status Byte Register.</p>
<b>Type</b>	Overlapping.
<b>Syntax</b>	*SRE<wsp> <register value>
<b>Parameter(s)</b>	<p><i>register value:</i></p> <p>The &lt;register value&gt;, expressed in base 2 (binary), represents the bit values of the Service Request Enable Register.</p> <p>The &lt;register value&gt; value ranges from 0 through 255.</p> <p>See the content of this register in <i>Service Request Enable Register (SRE)</i> on page 204.</p> <p>A bit value of zero shall indicate a disabled condition.</p>
<b>Example(s)</b>	<p>*SRE 52</p> <p>where 52 = (bit ESB, bit MAV and bit ERR)</p>
<b>See Also</b>	<p>*SRE?</p> <p>*STB?</p>

---

<b>*SRE?</b>	
<b>Description</b>	<p>The *SRE? query returns the current content of the Service Request Enable Register.</p> <p>See the content of this register in <i>Service Request Enable Register (SRE)</i> on page 204.</p>
<b>Type</b>	Overlapping.
<b>Syntax</b>	*SRE?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<register value>
<b>Response(s)</b>	<p><i>register value:</i></p> <p>The &lt;register value&gt; represents the current bit values of the Service Request Enable Register.</p> <p>The &lt;register value&gt; ranges from 0 through 255.</p>
<b>Example(s)</b>	*SRE returns 32 (bit ESB)
<b>See Also</b>	<p>*SRE</p> <p>*STB?</p>

---

*STB?	
Description	The *STB? query returns the status byte and Master Summary Status bit, as defined in <i>Status Byte Register (STB)</i> on page 204.
Type	Overlapping, query only.
Syntax	*STB?
Parameter(s)	None.
Response Syntax	<register value>
Response(s)	<i>register value:</i> The <register value> value, expressed in base 2 (binary) represents the bit values of the Status Byte Register. The <register value> ranges from 0 through 255. See the content of this register in <i>Status Byte Register (STB)</i> on page 204.
Example(s)	*STB? returns 68 where 68 = (bit MSS and bit ERR)
See Also	*SRE *SRE?

<b>*TST?</b>	
<b>Description</b>	<p>The *TST? query causes an internal system self-test and places a response into the output queue indicating whether or not the device completed the self-test without any detected errors.</p> <p>Upon successful completion of *TST?, the device settings is restored to their values prior to the *TST?.</p>
<b>Type</b>	Sequential, query only.
<b>Syntax</b>	*TST?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<result>
<b>Response(s)</b>	<p><i>result:</i></p> <p>The &lt;result&gt; value ranges from -32767 through +32767. Possible values are:</p> <ul style="list-style-type: none"> <li>➤ 0: no error was found on the system.</li> <li>➤ &lt;error code&gt;: the self-test was not completed or an error occurred. In this case, if the error appears again, contact the EXFO customer support. Possible error values are: <ul style="list-style-type: none"> <li>➤ -1017: registry access error.</li> <li>➤ -1018: hard disk SMART status error.</li> <li>➤ -1019: internal GPIB error.</li> </ul> </li> </ul>
<b>Example(s)</b>	<p>*TST? returns 0 (self-test was completed with success)</p>

<b>*WAI</b>	
<b>Description</b>	The *WAI command prevents the device from executing any further commands or queries until the no-operation-pending flag becomes TRUE.
<b>Type</b>	Overlapping, no query.
<b>Syntax</b>	*WAI
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	*WAI
<b>See Also</b>	<p>*OPC</p> <p>*OPC?</p>

## CTP10 Specific Commands

### Quick Reference

The table below contains a summary of the CTP10 specific commands. These commands are fully explained on the following pages.

Command/Query category	Corresponding section
:ABORt	<i>Root Layer Commands and Queries</i> on page 256
:CALCulate	<i>CALCulate Commands and Queries</i> on page 306
:CALCulate:DATA?	<i>CALCulate:DATA Queries</i> on page 332
:CALCulate:PARAmeters	<i>CALCulate:PARAmeters Commands and Queries</i> on page 354
:CLEAr	<i>Root Layer Commands and Queries</i> on page 256
:CTP	<i>Root Layer Commands and Queries</i> on page 256
:DISPlay	<i>DISPlay Commands and Queries</i> on page 448
:INITiate	<i>INITiate Commands and Queries</i> on page 451
:MMEMory	<i>MMEMory Commands and Queries</i> on page 488
:REFerence	<i>REFerence Commands and Queries</i> on page 497
:STATus	<i>STATus Commands and Queries</i> on page 250
:SYSTem	<i>SYSTem Commands and Queries</i> on page 246
:TRACe	<i>TRACe Commands and Queries</i> on page 504
:TRIGger	<i>TRIGger Commands and Queries</i> on page 526
:UNIT	<i>UNIT Commands and Queries</i> on page 533

## SYSTem Commands and Queries

### Quick Reference

Command Overview				Parameter(s)	Section
SYSTem	ANLG	OUT[1 2]	SOURce	<module> <detector>	see p. 246
			SOURce?		see p. 247
	COMMunicate	GPIB	[:ADDRess]	<value>	see p. 248
			[:ADDRess?]		see p. 248
	ERRor	[:NEXT]?			see p. 249
	VERSion?				see p. 249

### Commands and Queries

:SYSTem:ANLG:OUT[1 2]:SOURce	
<b>Description</b>	This command sets the OPM source for the given electrical analog output.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:SYSTem:ANLG:OUT[1 2]:SOURce<wsp><module>,<detector>
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>module</i>: Module identification number in the range 1 to 10, which is the position of the module in the mainframe from left to right. If you set this value to 0, it clears the OPM selection for the analog output.</li> <li>➤ <i>detector</i>: Detector identification number in the range 1 to 6, which is the detector position on the module from top to bottom.</li> </ul>
<b>Example(s)</b>	SYST:ANLG:OUT1:SOUR 5,2



**:SYSTem:ANLG:OUT[1|2]:SOURce?**

<b>Description</b>	This query returns the OPM source selected for the given electrical analog output.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:SYSTem:ANLG:OUT[1 2]:SOURce?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<module>,<detector>
<b>Response(s)</b>	<ul style="list-style-type: none"><li>➤ <i>module</i>: Identification number (in the range 1 to 10) of the module selected for the given electrical analog output.</li><li>➤ <i>detector</i>: Identification number (in the range 1 to 6) of the module detector selected for the given electrical analog output. If no OPM source is attached to the given analog output, the return value is "0,0"</li></ul>
<b>Example(s)</b>	SYST:ANLG:OUT1:SOUR? returns 5,2

---

**:SYSTem:COMMunicate:GPIB[:ADDRess]**

<b>Description</b>	This command sets the address of the GPIB port.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:SYSTem:COMMunicate:GPIB[:ADDRess] <wsp> <value>
<b>Parameter(s)</b>	<i>value</i> : Unique integer in the range 0 to 30, which sets the GPIB address of the CTP10.
<b>Example(s)</b>	SYSTem:COMMunicate:GPIB 10

---

**:SYSTem:COMMunicate:GPIB[:ADDRess]?**

<b>Description</b>	This query returns the GPIB address of the CTP10.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:SYSTem:COMMunicate:GPIB[:ADDRess]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Unique integer in the range 0 to 30, which represents the GPIB address of the CTP10.
<b>Example(s)</b>	:SYSTem:COMMunicate:GPIB 10 :SYSTem:COMMunicate:GPIB:ADDRess? returns 10

---

**:SYSTem:ERRor[:NEXT]?**

<b>Description</b>	This query returns the error queue for the next item and removes it from the queue.  SYSTem:ERRor[:NEXT]? is a query only and, therefore, does not have an associated *RST state.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:SYSTem:ERRor[:NEXT]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<code>,<description[,Info]>
<b>Response(s)</b>	<p>➤ <i>code:</i></p> <p>Error code as a unique integer in the range -32768 to 32767. All positive numbers are instrument-dependent.</p> <p>All negative numbers are reserved by the SCPI standard with certain standard error/event codes described in <i>SCPI-Based Errors</i> on page 535.</p> <p>The zero value indicates that no error or event has occurred.</p> <p>➤ <i>description:</i></p> <p>Quoted string containing a description. Each &lt;code&gt; has a unique and fixed &lt;description&gt; associated with it.</p> <p>For standard defined error &lt;code&gt;, the &lt;description&gt; is sent exactly as indicated in <i>SCPI-Based Errors</i> on page 535.</p>
<b>Example(s)</b>	SYST:ERR:NEXT? returns -222,"Data out of range"

**:SYSTem:VERSion?**

<b>Description</b>	This query returns the SCPI revision to which the instrument complies.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:SYSTem:VERSion?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<version>
<b>Response(s)</b>	<p><i>version:</i></p> <p>The year followed by the revision number of the SCPI standard to which the instrument complies.</p>
<b>Example(s)</b>	SYST:VER? returns 1999.0

## STATus Commands and Queries

### Quick Reference

Command Overview			Parameter(s)	Section
STATus	OPERation	[EVENT]?		see p. 250
		CONDition?		see p. 251
		ENABle	<value>	see p. 252
		ENABle?		see p. 252
	QUESTionable	[EVENT]?		see p. 253
		CONDition?		see p. 253
		ENABle	<value>	see p. 254
		ENABle?		see p. 254
	PRESet			see p. 255
	RST?			see p. 255

### Commands and Queries

#### :STATus:OPERation[:EVENT]?

<b>Description</b>	<p>This query returns the value of the Operational Status Event Register for the current subsystem.</p> <p>This event register is cleared after reading.</p>
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:STATus:OPERation[:EVENT]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<p><i>value:</i></p> <p>Unique integer in the range 0 to 65535, which represents the bit values of the Operational Status Event Register.</p> <p>See the content of this register in <i>Operational / Questionable Status Reporting</i> on page 205.</p> <p>The zero value is used to indicate the idle state.</p>
<b>Example(s)</b>	<p>:STAT:OPER? returns 4</p> <p>where 4 = Scanning</p>

**:STATus:OPERation:CONDition?**

<b>Description</b>	This query returns the value of the Operational Status Condition Register for the current subsystem.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:STATus:OPERation:CONDition?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Unique integer in the range 0 to 65535, which represents the bit values of the Operational Status Condition Register. See the content of this register in <i>Operational / Questionable Status Reporting</i> on page 205. The zero value is used to indicate the idle state.
<b>Example(s)</b>	:STAT:OPER:COND? returns 4 where 4 = Scanning

---

**:STATus:OPERation:ENABle**

<b>Description</b>	This command sets the value of the Operational Status Enable Register.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:STATus:OPERation:ENABle<wsp> <value>
<b>Parameter(s)</b>	<p><i>value:</i></p> <p>Unique integer in the range 0 to 65535, which sets the value of the Operational Status Enable Register bit.</p> <p>See the content of this register in <i>Operational / Questionable Status Reporting</i> on page 205.</p> <p>Setting a bit in the register enables the corresponding bit in the Operational Status Event Register.</p>
<b>Example(s)</b>	<p>:STAT:OPER:ENAB 4</p> <p>where 4 = scanning.</p>

---

**:STATus:OPERation:ENABle?**

<b>Description</b>	This query returns the value of the Operational Status Enable Register bits.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:STATus:OPERation:ENABle?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<p><i>value:</i></p> <p>Unique integer in the range 0 to 65535, which represents the value of the Operational Status Enable Register bit.</p> <p>See the content of this register in <i>Operational / Questionable Status Reporting</i> on page 205.</p> <p>A bit set in the register enables the corresponding bit in the Operational Status Event Register.</p>
<b>Example(s)</b>	<p>:STAT:OPER:ENAB? returns 12</p> <p>where 12 = scanning and analyzing.</p>

---

**:STATus:QUEStionable[:EVENT]?**

<b>Description</b>	This query returns the value of the Questionable Status Event Register for the current subsystem.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:STATus:QUEStionable[:EVENT]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value:</i> Unique integer in the range 0 to 65535, which represents the bit values of the Questionable Status Event Register. See the content of this register in <i>Operational / Questionable Status Reporting</i> on page 205.
<b>Example(s)</b>	:STAT:QUES? returns 1

**:STATus:QUEStionable:CONDition?**

<b>Description</b>	This query returns the value of the Questionable Status Condition Register for the current subsystem.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:STATus:QUEStionable:CONDition?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value:</i> Unique integer in the range 0 to 65535, which represents the bit values of the Questionable Status Condition Register. See the content of this register in <i>Operational / Questionable Status Reporting</i> on page 205.
<b>Example(s)</b>	:STAT:QUES:COND? returns 1

**:STATus:QUESTionable:ENABle**

<b>Description</b>	This command sets the value of the Questionable Status Enable Register.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:STATus:QUESTionable:ENABle<wsp> <value>
<b>Parameter(s)</b>	<p><i>value:</i></p> <p>Unique integer in the range 0 to 65535, which sets the value of the Questionable Status Enable Register bit.</p> <p>See the content of this register in <i>Operational / Questionable Status Reporting</i> on page 205.</p> <p>Setting a bit in the register enables the corresponding bit in the Questionable Status Event Register.</p>
<b>Example(s)</b>	:STAT:QUES:ENAB 4

**:STATus:QUESTionable:ENABle?**

<b>Description</b>	This query returns the value of the Questionable Status Enable Register bits.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:STATus:QUESTionable:ENABle?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<p><i>value:</i></p> <p>Unique integer in the range 0 to 65535, which represents the value of the Questionable Status Enable Register bit.</p> <p>See the content of this register in <i>Operational / Questionable Status Reporting</i> on page 205.</p> <p>A bit set in the register enables the corresponding bit in the Questionable Status Event Register.</p>
<b>Example(s)</b>	:STAT:QUES:ENAB? returns 12



**:STATus:PRESet**

<b>Description</b>	This command clears the Operational Event Status Register register for the current subsystem and sets all bits of the Enable registers (ESE, OSE, SRE, QSE). The command does not affect the instrument settings.
<b>Type</b>	Overlapping, no query.
<b>Syntax</b>	:STATus:PRESet
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:STAT:PRES

---

**:RST?**

<b>Description</b>	This query returns the system resetting state: it enables you to know if the reset operation set with the *RST command (see *RST on page 241) is in progress.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:RST?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response</b>	<i>state:</i> State of the reset (see *RST on page 241) operation: 0: the system is not resetting. 1: the system is resetting.
<b>Example(s)</b>	:RST? returns 0

---

## Root Layer Commands and Queries

- In CTP:SENSe[1...20]:CHANnel[1...6]:
  - [1...20] (or [1...10]) designates the module identification number, which is the position of the module in the mainframe from left to right.  
In Daisy chaining mode, the modules located on the Primary mainframe are identified using positions 1 to 10, and the modules located on the Secondary mainframe are identified using positions 11 to 20. Once entered in the Daisy chaining mode, you must execute all commands and queries on the Primary CTP10. You cannot send any commands or queries to the Secondary CTP10, except: :SYSTem:ERRor[:NEXT]? on page 249, :STATus:PRESet on page 255, :CTP:DCHAINing:STATus? on page 265, :CTP:DCHAINing:CLOSe on page 259, \*RST on page 241, \*IDN? on page 239.
  - [1...6] designates the detector identification number, which is the detector position on the module from top to bottom. This number is not taken into account for BR traces.
- In CTP:RLASER[1...10]:
  - [1...10] designates the laser identification number, which is defined with the command :CTP:RLASer[1...10]:TYPE on page 287 (in the GUI, it corresponds to the position of the laser in the **Modules & Lasers** window from left to right).

### Quick Reference

Command Overview					Parameter(s)	Section
ABORt						see p. 259
CLear						see p. 259
CTP	DCHAINing	CLOSe				see p. 259
		ID1	CPARameters		<IP address>: <Secondary port>	see p. 260
			CPARameters?			see p. 260
			LINK		<connection state>	see p. 261
			LINK?			see p. 262
		PPORt			<port>	see p. 263
		PPORt?			[MIN MAX]	see p. 263
		SPORt			<port>	see p. 264
		SPORt?			[MIN MAX]	see p. 264
		STATus?				see p. 265
	DLOG				<filename>	see p. 265
	FUNction	PARameter	LOGGing		<points>, <averaging time> [<unit>], <wavelength/frequency> [<unit>]	see p. 266
			LOGGing?			see p. 267

Command Overview				Parameter(s)	Section
			STABility	<total time>,<period time>,<averaging time>[<unit>],<wavelength/frequency>[<unit>]	see p. 268
			STABility?		see p. 269
		STATe		<function>,<state>	see p. 270
	LOCal				see p. 270
	LSHARing	CLOSe			see p. 271
		CPORt		<port>	see p. 272
		CPORt?		[MIN MAX]	see p. 272
		DPORt		<port>	see p. 273
		DPORt?		[MIN MAX]	see p. 273
		ID[1...7]	CPARameters	<IP address>: <Distributed port>	see p. 274
			CPARameters?		see p. 274
			LINK	<connection state>	see p. 275
			LINK?		see p. 276
		STATus?			see p. 276
	RLASER[1...10]	ACTRL		<state>	see p. 277
		ACTRL?			see p. 277
		BSUPPR		<state>	see p. 278
		BSUPPR?			see p. 278
		COHErence		<state>	see p. 279
		COHErence?			see p. 279
		CPARameters		<type>,<parameters>	see p. 280
		CPARameters?			see p. 281
		IDN?			see p. 282
		LINK		<status>	see p. 283
		LINK?			see p. 283
		POWER		<power>[<unit>]	see p. 284
		POWER?			see p. 284
			STATe	<state>	see p. 285
			STATe?		see p. 285
		REFerencing			see p. 286
		TYPE		<model>	see p. 287

Command Overview					Parameter(s)	Section
		TYPE?				see p. 288
		WAVelength			<value> [ <unit> ]	see p. 289
		WAVelength?				see p. 289
	SENSe[1...10]	CHANnel[1...6]	AVG		<value>	see p. 290
			AVG?			see p. 290
			FUNcTion	ACTivate	<state>	see p. 291
				ACTivate?		see p. 291
				RESult?	<format>	see p. 292
				STATe?		see p. 293
				TRIGGer	<trigger>	see p. 294
				TRIGGer?		see p. 294
			OFFset		<offset>	see p. 295
			OFFset?			see p. 295
			POWER?			see p. 296
			UNIT	X	<unit>	see p. 297
				X?		see p. 297
				Y	<unit>	see p. 298
				Y?		see p. 298
			WAVelength		<value> [ <unit> ]	see p. 299
			WAVelength?			see p. 299
	SENSe[1...20]	CHANnel[1...6]	ZEROing			see p. 300
			ZEROing?			see p. 300
		IDN?				see p. 301
		FBC			<input>	see p. 302
		FBC?				see p. 302
		OPTion?				see p. 303
		RST				see p. 303
		TYPE?				see p. 305
		TST?				see p. 304

**Commands and Queries****:ABORt**

<b>Description</b>	This command immediately aborts a scan that is currently in progress.
<b>Type</b>	Overlapping, no query.
<b>Syntax</b>	:ABORt
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:ABOR

---

**:CLEAr**

<b>Description</b>	This command definitely clears all trace content and analysis results (except Store traces).
<b>Type</b>	Sequential, no query.
<b>Syntax</b>	:CLEAr
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:CLE

---

**:CTP:DCHAINing:CLOSe**

<b>Description</b>	This command closes the connection to the Primary CTP10 (from the Secondary CTP10). For more details on daisy chaining, see <i>Using Additional OPMs (Daisy Chaining mode)</i> on page 107.
<b>Applicability</b>	This command is only available if the current CTP10 daisy chaining status is Secondary (response 2 to :CTP:DCHAINing:STATus? on page 265).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:DCHAINing:CLOSe
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:CTP:DCHAIN:CLOSe

---

**:CTP:DCHAINing:ID1:CPARameters**

<b>Description</b>	This command sets the daisy chaining connection parameters of a given CTP10 to which you want to connect for daisy chaining. For more details on daisy chaining, see <i>Using Additional OPMs (Daisy Chaining mode)</i> on page 107.
<b>Applicability</b>	In Daisy chaining mode, this command is not available on Secondary CTP10s (response 2 to <i>:CTP:DCHAINing:STATus?</i> on page 265).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:DCHAINing:ID1:CPARameters<wsp> <IP address>:<Secondary port>
<b>Parameter(s)</b>	1 designates the Secondary CTP10 number. <ul style="list-style-type: none"> <li>➤ <i>IP address:</i> IP address of the CTP10 to which you want to connect.</li> <li>➤ <i>Distributed port:</i> Daisy chaining secondary port of the CTP10 to which you want to connect. Default value: 53002</li> </ul>
<b>Example(s)</b>	:CTP:DCHAIN:ID1:CPAR 172.31.5.10:53002

**:CTP:DCHAINing:ID1:CPARameters?**

<b>Description</b>	This query returns the daisy chaining connection parameters of a given Secondary CTP10.
<b>Applicability</b>	In Daisy chaining mode, this query is not available on Secondary CTP10s (response 2 to <i>:CTP:DCHAINing:STATus?</i> on page 265).
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:DCHAINing:ID1:CPARameters?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<IP address>:<Distributed port>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>IP address:</i> IP address of the given CTP10.</li> <li>➤ <i>Distributed port:</i> Laser sharing Secondary port of the given CTP10.</li> </ul>
<b>Example(s)</b>	:CTP:DCHAIN:ID1:CPAR? returns 172.31.5.10:53002

**:CTP:DCHAINing:ID1:LINK**

<b>Description</b>	<p>This command opens or closes the connection of the current CTP10 to a given CTP10 for Daisy chaining. For more details on daisy chaining, see <i>Using Additional OPMs (Daisy Chaining mode)</i> on page 107.</p> <p>Before opening a connection to another CTP10 for daisy chaining, you must have defined the location of modules and detectors on the CTP10s that you want to set as Secondary, and the connection parameters.</p> <p>The connection parameters are available using the following command: <i>:CTP:DCHAINing:ID1:CPARameters?</i> on page 260</p>
<b>Applicability</b>	In Daisy chaining mode, this command is not available on Secondary CTP10s (response 2 to <i>:CTP:DCHAINing:STATus?</i> on page 265).
<b>Type</b>	<p>Overlapped.</p> <p>When the system executes this command, the bit 10 "Updating setup for Daisy chaining" is set in the Operational Status Condition Register (see <i>:STATus:OPERation:CONDition?</i> on page 251 and <i>Operational / Questionable Status Reporting</i> on page 205).</p>
<b>Syntax</b>	:CTP:DCHAINing:ID1:LINK<wsp><connection state>
<b>Parameter(s)</b>	<p>1 designates the Secondary CTP10 number.</p> <p><i>connection state:</i></p> <p>Connection state of the given Secondary CTP10. The allowed values are:</p> <p>0 CLOSE: closes the connection to the given Secondary CTP10.</p> <p>1 OPEN: opens the connection to the given CTP10.</p>
<b>Example(s)</b>	:CTP:DCHAIN:ID1:LINK 1

---

**:CTP:DCHAINing:ID1:LINK?**

<b>Description</b>	This query returns the Daisy chaining connection state of a given Secondary CTP10.
<b>Applicability</b>	In daisy chaining mode, this query is not available on Secondary CTP10s (response 2 to <i>:CTP:DCHAINing:STaTus?</i> on page 265).
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:DCHAINing:ID1:LINK?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<connection state>
<b>Response(s)</b>	<i>connection state:</i> Connection state of the given Secondary CTP10: 0: the connection to the given CTP10 is closed. 1: the connection to the given CTP10 is open. 2: the given CTP10 is connecting.
<b>Example(s)</b>	:CTP:DCHAIN:ID1:LINK? returns 1

---



**:CTP:DCHAINing:PPORt**

<b>Description</b>	This command sets the daisy chaining Primary port of the current CTP10.  For more details on daisy chaining, see <i>Using Additional OPMs (Daisy Chaining mode)</i> on page 107.
<b>Applicability</b>	This command is only available if the CTP10 has not entered the daisy chaining mode (response 0 to <i>:CTP:DCHAINing:STaTus?</i> on page 265).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:DCHAINing:PPORt<wsp><port>
<b>Parameter(s)</b>	<i>port</i> :  Integer corresponding to the Primary port of the current CTP10 (for daisy chaining), in the range 1 to 65535.  The default value is 53000.
<b>Example(s)</b>	:CTP:DCHAIN:PPORt 53001

**:CTP:DCHAINing:PPORt?**

<b>Description</b>	This query returns the Primary port (for daisy chaining) set for the current CTP10.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:DCHAINing:PPORt?[MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<port>
<b>Response(s)</b>	<i>port</i> :  Integer corresponding to the Primary port of the current CTP10 (for daisy chaining), in the range 1 to 65535.
<b>Example(s)</b>	:CTP:DCHAIN:PPORt? returns 53001

**:CTP:DCHAINing:SPORT**

<b>Description</b>	This command sets the daisy chaining Secondary port of the current CTP10.  For more details on daisy chaining, see <i>Using Additional OPMs (Daisy Chaining mode)</i> on page 107.
<b>Applicability</b>	This command is only available if the CTP10 has not entered the daisy chaining mode (response 0 to :CTP:DCHAINing:STATus? on page 265).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:DCHAINing:SPORT<wsp> <port>
<b>Parameter(s)</b>	<i>port</i> :  Integer corresponding to the Secondary port of the current CTP10 (for daisy chaining), in the range 1 to 65535.  The default value is 53002.
<b>Example(s)</b>	:CTP:DCHAIN:SPOR 53003

**:CTP:DCHAINing:SPORT?**

<b>Description</b>	This query returns the Secondary port (for daisy chaining) set for the current CTP10.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:DCHAINing:SPORT?[MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<port>
<b>Response(s)</b>	<i>port</i> :  Integer corresponding to the Secondary port of the current CTP10 (for daisy chaining), in the range 1 to 65535.
<b>Example(s)</b>	:CTP:DCHAINing:SPORT? returns 53003

**:CTP:DCHAINing:STATus?**

<b>Description</b>	This query returns the daisy chaining status of the current CTP10. For more details on daisy chaining, see <i>Using Additional OPMs (Daisy Chaining mode)</i> on page 107.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CTP:DCHAINing:STATus?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<status>
<b>Response(s)</b>	<i>status:</i> Integer corresponding to the daisy chaining status of the current CTP10: <ul style="list-style-type: none"> <li>➤ 0: the daisy chaining mode is disabled.</li> <li>➤ 1: the CTP10 is set as Primary</li> <li>➤ 2: the CTP10 is set as Secondary. In this case, additional information is returned:            &lt;IP address of Primary&gt;:&lt;Primary port of the Primary CTP10&gt;,&lt;Secondary number, as viewed by the Primary&gt;</li> </ul>
<b>Example(s)</b>	:CTP:DCHAIN:STAT? returns 2,172.31.5.10:53000,1

**:CTP:DLOG**

<b>Description</b>	This command saves log data into a file in the current directory.
<b>Type</b>	Overlapped.  When the system executes this command, the bit 12 "Loading/Saving" is set in the Operational Status Condition Register (see :STATus:OPERation:CONDition? on page 251 and <i>Operational / Questionable Status Reporting</i> on page 205).
<b>Syntax</b>	:CTP:DLOG<wsp> <filename>
<b>Parameter(s)</b>	<i>filename:</i> Name of the file into which you want to save log data, with or without quotes.  The .exfodbg extension will be automatically added to the file name.
<b>Example(s)</b>	:CTP:DLOG "theDebugLog"

**:CTP:FUNCTION:PARAMeter:LOGGing**

<b>Description</b>	This command sets the parameters for the logging function. For more details on this function, see <i>Triggering Power Level Data Acquisition</i> on page 82.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:FUNCTION:PARAMeter:LOGGing<wsp><points>, <averaging time>[<unit avg>], <wavelength/frequency>[<unit wavelength/frequency>]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>points</i>: Integer corresponding to the number of data points to record to complete the logging, in the range 1 to 1000000.</li> <li>➤ <i>averaging time</i>: Averaging time of each measurement, in the range 1 <math>\mu</math>s to 500 ms.</li> <li>➤ <i>unit avg</i>: Unit of the averaging time value. The allowed units are US (microsecond) or MS (millisecond). The default unit is microsecond (US).</li> <li>➤ <i>wavelength/frequency</i>: Wavelength or frequency value of the signal received by the module input connector.</li> <li>➤ <i>unit wavelength/frequency</i>: Unit of the wavelength/frequency value. The allowed units are PM NM M HZ GHZ THZ. The default unit is meter (M).</li> </ul>
<b>Example(s)</b>	:CTP:FUNC:PAR:LOGGing 1000,10us,1550nm

**:CTP:FUNCTION:PARAMeter:LOGGing?**

<b>Description</b>	This query returns the parameters set for the logging function.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:FUNCTION:PARAMeter:LOGGing?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<points>,<averaging time>,<wavelength>
<b>Response(s)</b>	<ul style="list-style-type: none"><li>➤ <i>points</i>: Number of data points to record to complete the logging.</li><li>➤ <i>averaging time</i>: Averaging time of each measurement as float value in seconds.</li><li>➤ <i>wavelength</i>: Wavelength of the signal received by the module input connector as float value in meters.</li></ul>
<b>Example(s)</b>	:CTP:FUNCTION:PARAMeter:LOGGing 1000,10us,1550nm :CTP:FUNCTION:PARAMeter:LOGGing? returns 1000,+1.00000000E-005,+1.55000000E-006

---

**:CTP:FUNCTION:PARAMeter:STABility**

<b>Description</b>	<p>This command sets the parameters for the stability function.</p> <p>For more details on this function, see <i>Triggering Power Level Data Acquisition</i> on page 82.</p>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:FUNCTION:PARAMeter:STABility<wsp><total time>,<period time>,<averaging time>[<unit avg>],<wavelength/frequency>[<unit wavelength/frequency>]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>total time</i>: Total time in seconds from the start of the stability data acquisition until its entire completion, in the range 1 to 86400 s.</li> <li>➤ <i>period time</i>: Period of time in seconds between the start of two consecutive measurements, in the range 1 to 3600 s. A new measurement is started after the end of each period time. This value must be lower than the total time.</li> <li>➤ <i>averaging time</i>: Averaging time of each measurement, in the range 1 <math>\mu</math>s to 500 ms.</li> <li>➤ <i>unit avg</i>: Unit of the averaging time value. The allowed units are US (microsecond) or MS (millisecond). The default unit is microsecond (US).</li> <li>➤ <i>wavelength/frequency</i>: Wavelength or frequency value of the signal received by the module input connector.</li> <li>➤ <i>unit wavelength/frequency</i>: Unit of the wavelength/frequency value. The allowed units are PM NM M HZ GHZ THZ. The default unit is meter (M).</li> </ul>
<b>Example(s)</b>	:CTP:FUNC:PARAMeter:STABility 30,1,25US,1550NM

**:CTP:FUNCTION:PARAMeter:STABility?**

<b>Description</b>	This query returns the parameters set for the stability function.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:FUNCTION:PARAMeter:STABility?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<total time>,<period time>,<averaging time>,<wavelength>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>total time:</i> Total time in seconds from the start of the stability data acquisition until its entire completion.</li> <li>➤ <i>period time:</i> Period of time in seconds between the start of two consecutive measurements. A new measurement is started after the end of each period time.</li> <li>➤ <i>averaging time:</i> Averaging time in seconds of each measurement.</li> <li>➤ <i>wavelength:</i> Wavelength of the signal received by the module input connector as float value in meters.</li> </ul>
<b>Example(s)</b>	:CTP:FUNCTION:PARAMeter:STABility 30,1,25us,1550nm :CTP:FUNC:PAR:STAB? returns 30.000000,1.000000,+2.50000000E-005,+1.55000000E-006

:CTP:FUNCTION:STATE	
<b>Description</b>	<p>This command starts/stops the logging or stability measurement function.</p> <p>For more details on these functions, see <i>Triggering Power Level Data Acquisition</i> on page 82.</p>
<b>Type</b>	Sequential, no query.
<b>Syntax</b>	:CTP:FUNCTION:STATE<wsp><function>,<state>
<b>Parameter(s)</b>	<p>➤ <i>function</i>:</p> <p>Function that you want to start or stop. The allowed values are:</p> <p>0 STABILITY: sets the stability function.</p> <p>1 LOGGING: sets the logging function.</p> <p>➤ <i>state</i>:</p> <p>State of the function selected with the &lt;function&gt; parameter. The allowed values are:</p> <p>0 STOP: stops the selected function.</p> <p>1 START: starts the selected function on all detectors for which the command :CTP:SENSE[1...10]:CHANNEL[1...6]:FUNCTION:ACTivate on page 291 is set to ACTIVE.</p> <p>➤ For the stability function: data acquisition starts immediately.</p> <p>➤ For the logging function: the data acquisition start depends on the trigger defined for the detector: see :CTP:SENSE[1...10]:CHANNEL[1...6]:FUNCTION:TRIGGER on page 294.</p>
<b>Example(s)</b>	:CTP:FUNCTION:STATE LOGG,STAR

:CTP:LOCAL	
<b>Description</b>	This command exits the remote mode and enables you to get back to the local control of the CTP10.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:LOCAL
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:CTP:LOCAL



**:CTP:LSHARing:CLOSE**

<b>Description</b>	This command closes the connection to the Controller CTP10 (from the Distributed CTP10). For more details on laser sharing, see <i>Sharing the Lasers with Several CTP10s</i> on page 94.
<b>Applicability</b>	This command is only available if the current CTP10 laser sharing status is Distributed (response 2 to <code>:CTP:LSHARing:STATus?</code> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:LSHARing:CLOSE
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:CTP:LSHAR:CLOSE

---

**:CTP:LSHARing:CPOrt**

<b>Description</b>	This command sets the laser sharing Controller port of the current CTP10.  For more details on laser sharing, see <i>Sharing the Lasers with Several CTP10s</i> on page 94.
<b>Applicability</b>	This command is only available if the CTP10 has not entered the laser sharing mode (response 0 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:LSHARing:CPOrt<wsp><port>
<b>Parameter(s)</b>	<i>port</i> :  Integer corresponding to the Controller port of the current CTP10 (for laser sharing), in the range 1 to 65535.  The default value is 60000.
<b>Example(s)</b>	:CTP:LSHAR:CPOrt 60001

---

**:CTP:LSHARing:CPOrt?**

<b>Description</b>	This query returns the Controller port (for laser sharing) set for the current CTP10.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:LSHARing:CPOrt?[MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<port>
<b>Response(s)</b>	<i>port</i> :  Integer corresponding to the Controller port of the current CTP10 (for laser sharing), in the range 1 to 65535.
<b>Example(s)</b>	:CTP:LSHAR:CPOrt? returns 60001

---

**:CTP:LSHARing:DPORT**

<b>Description</b>	This command sets the laser sharing Distributed port of the current CTP10.  For more details on laser sharing, see <i>Sharing the Lasers with Several CTP10s</i> on page 94.
<b>Applicability</b>	This command is only available if the CTP10 has not entered the laser sharing mode (response 0 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:LSHARing:DPORT<wsp><port>
<b>Parameter(s)</b>	<i>port</i> :  Integer corresponding to the Distributed port of the current CTP10 (for laser sharing), in the range 1 to 65535.  The default value is 50000.
<b>Example(s)</b>	:CTP:LSHAR:DPORT 50001

**:CTP:LSHARing:DPORT?**

<b>Description</b>	This query returns the Distributed port (for laser sharing) set for the current CTP10.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:LSHARing:DPORT?[MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<port>
<b>Response(s)</b>	<i>port</i> :  Integer corresponding to the Distributed port of the current CTP10 (for laser sharing), in the range 1 to 65535.
<b>Example(s)</b>	:CTP:LSHAR:DPORT? returns 50001

**:CTP:LSHARing:ID[1...7]:CPARameters**

<b>Description</b>	This command sets the laser sharing connection parameters of a given CTP10 to which you want to connect for laser sharing. For more details on laser sharing, see <i>Sharing the Lasers with Several CTP10s</i> on page 94.
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATus? on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:LSHARing:ID[1...7]:CPARameters<wsp> <IP address>:<Distributed port>
<b>Parameter(s)</b>	[1...7] designates the Distributed CTP10 number. <ul style="list-style-type: none"> <li>➤ <i>IP address:</i> IP address of the CTP10 to which you want to connect.</li> <li>➤ <i>Distributed port:</i> Laser sharing distributed port of the CTP10 to which you want to connect. Default value: 50000</li> </ul>
<b>Example(s)</b>	:CTP:LSHAR:ID1:CPARameters 172.31.5.10:50000

**:CTP:LSHARing:ID[1...7]:CPARameters?**

<b>Description</b>	This query returns the laser sharing connection parameters of a given Distributed CTP10.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATus? on page 276).
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:LSHARing:ID[1...7]:CPARameters?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<IP address>:<Distributed port>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>IP address:</i> IP address of the given CTP10.</li> <li>➤ <i>Distributed port:</i> Laser sharing Distributed port of the given CTP10.</li> </ul>
<b>Example(s)</b>	:CTP:LSHARing:ID1:CPARameters? returns 172.31.5.10:50000

**:CTP:LSHARing:ID[1...7]:LINK**

<b>Description</b>	<p>This command opens or closes the connection of the current CTP10 to a given CTP10 for laser sharing. For more details on laser sharing, see <i>Sharing the Lasers with Several CTP10s</i> on page 94.</p> <p>Before opening a connection to another CTP10 for laser sharing, you must have defined the subsystem on the CTP10s that you want to set as Distributed.</p> <p>The connection parameters are available using the following command: <code>:CTP:LSHARing:ID[1...7]:CPARAmeters?</code> on page 274</p>
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <code>:CTP:LSHARing:STATus?</code> on page 276).
<b>Type</b>	<p>Overlapped.</p> <p>When the system executes this command, the bit 9 "Updating setup from Controller CTP10" is set in the Operational Status Condition Register (see <code>:STATus:OPERation:CONDition?</code> on page 251 and <i>Operational / Questionable Status Reporting</i> on page 205).</p>
<b>Syntax</b>	<code>:CTP:LSHARing:ID[1...7]:LINK&lt;wsp&gt;&lt;connection state&gt;</code>
<b>Parameter(s)</b>	<p>[1...7] designates the Distributed CTP10 number.</p> <p><i>connection state:</i></p> <p>Connection state of the given Distributed CTP10. The allowed values are:</p> <p>0 CLOSE: closes the connection to the given Distributed CTP10.</p> <p>1 OPEN: opens the connection to the given CTP10.</p>
<b>Example(s)</b>	<code>:CTP:LSHAR:ID1:LINK 1</code>

---

**:CTP:LSHARing:ID[1...7]:LINK?**

<b>Description</b>	This query returns the connection state of a given Distributed CTP10.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:LSHARing:ID[1...7]:LINK?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<connection state>
<b>Response(s)</b>	<i>connection state:</i> Connection state of the given Distributed CTP10: 0: the connection to the given CTP10 is closed. 1: the connection to the given CTP10 is open. 2: the given CTP10 is connecting.
<b>Example(s)</b>	:CTP:LSHARing:ID1:LINK? returns 1

---

**:CTP:LSHARing:STATus?**

<b>Description</b>	This query returns the laser sharing status of the current CTP10.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CTP:LSHARing:STATus?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<status>
<b>Response(s)</b>	<i>status:</i> Integer corresponding to the laser sharing status of the current CTP10: <ul style="list-style-type: none"> <li>➤ 0: the laser sharing mode is disabled.</li> <li>➤ 1: the CTP10 is set as Controller</li> <li>➤ 2: the CTP10 is set as Distributed. In this case, additional information is returned:                &lt;IP address of Controller&gt;:&lt;Controller port of the Controller&gt;,&lt;Distributed number&gt;</li> </ul>
<b>Example(s)</b>	:CTP:LSHAR:STAT? returns 2,172.31.5.10:5025,4

---

**:CTP:RLASer[1...10]:ACTRL**

<b>Description</b>	This command enables/disables the "active cavity control" mode for the given laser.  The corresponding GUI setting is <b>Cavity control</b> (see <b>Cavity control on page 92</b> ).
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATUs? on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:RLASer[1...10]:ACTRL<wsp> <state>
<b>Parameter(s)</b>	<i>state:</i>  Sets the state of the cavity control mode for the given laser. The allowed values are: 0 OFF: disables the active cavity control mode. 1 ON: enables the active cavity control mode.
<b>Example(s)</b>	:CTP:RLASer2:ACTRL ON

**:CTP:RLASer[1...10]:ACTRL?**

<b>Description</b>	This query returns the state of the "active cavity control" mode for the given laser.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATUs? on page 276).
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:RLASer[1...10]:ACTRL?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state:</i>  State of the active cavity control mode for the given laser: 0: the active cavity control mode is disabled. 1: the active cavity control mode is enabled.
<b>Example(s)</b>	:CTP:RLASer2:ACTRL ON :CTP:RLASer2:ACTRL? returns 1

**:CTP:RLASer[1...10]:BSUPpr**

<b>Description</b>	This command enables/disables the backlash suppression control for the given laser.  The corresponding GUI setting is <b>Backlash suppression control</b> (see <b>Backlash suppression control on page 92</b> ).
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:RLASer[1...10]:BSUPpr<wsp> <state>
<b>Parameter(s)</b>	<i>state</i> :  Sets the state of the backlash suppression control for the given laser. The allowed values are: 0 OFF: disables the backlash suppression control. 1 ON: enables the backlash suppression control.
<b>Example(s)</b>	:CTP:RLASer2:BSUP ON

---

**:CTP:RLASer[1...10]:BSUPpr?**

<b>Description</b>	This query returns the state of the backlash suppression control for the given laser.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:RLASer[1...10]:BSUPpr?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> :  State of the backlash suppression control for the given laser: 0: the backlash suppression control is disabled. 1: the backlash suppression control is enabled.
<b>Example(s)</b>	:CTP:RLASer2:BSUP OFF :CTP:RLASer2:BSUP? returns 0

---



**:CTP:RLASer[1...10]:COHErence**

<b>Description</b>	This command enables/disables the coherence control for the given laser. The corresponding GUI setting is <b>Coherence control</b> (see <b>Coherence control on page 92</b> ).
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STaTus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:RLASer[1...10]:COHErence<wsp><state>
<b>Parameter(s)</b>	<i>state</i> : Sets the state of the coherence control for the given laser. The allowed values are: 0 OFF: disables the coherence control. 1 ON: enables the coherence control.
<b>Example(s)</b>	:CTP:RLASer2:COHE ON

**:CTP:RLASer[1...10]:COHErence?**

<b>Description</b>	This query returns the state of the coherence control for the given laser.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STaTus?</i> on page 276).
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:RLASer[1...10]:COHErence?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : State of the coherence control for the given laser: 0: the coherence control is disabled. 1: the coherence control is enabled.
<b>Example(s)</b>	:CTP:RLASer2:COHE ON :CTP:RLASer2:COHE? returns 1

**:CTP:RLASer[1...10]:CPARameters**

<b>Description</b>	This command sets the laser communication parameters.
<b>Applicability</b>	<ul style="list-style-type: none"> <li>➤ This command is only available if the specified laser is disconnected.</li> <li>➤ In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATus? on page 276).</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:RLASer[1...10]:CPARameters<wsp><type>,<parameters>
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>type</i>: Integer corresponding to the type of connection to the laser: 1: GPIB 2: Ethernet 3: USB Serial</li> <li>➤ <i>parameters</i>: Connection type specific parameters, in the following format: GPIB: &lt;GPIB Interface ID&gt;_&lt;GPIB address&gt; Ethernet: &lt;IP1.IP2.IP3.IP4&gt;:&lt;Port&gt; USB: &lt;port&gt;,&lt;speed&gt;,&lt;parity (0: none 1: odd 2: even)&gt;,&lt;bit stop count (1 1.5 2)&gt;,&lt;flux control (0: none 2: rts/cts 4: dtr/dsr)&gt;</li> </ul>
<b>Example(s)</b>	GPIB: :CTP:RLASer3:CPARameters 1,GPIB0_16 Ethernet: :CTP:RLASer1:CPARameters 2,172.31.5.10:5025 USB: :CTP:RLASer2:CPARameters 3,COM5:115200_0_1_0

---

**:CTP:RLASer[1...10]:CPARameters?**

<b>Description</b>	This query returns the laser communication parameters.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATUS? on page 276).
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:RLASer[1...10]:CPARameters?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<type>,<parameters>
<b>Response(s)</b>	<p>➤ <i>type</i>:</p> <p>Integer corresponding to the connection type:</p> <p>1: GPIB</p> <p>2: Ethernet</p> <p>3: USB Serial</p> <p>➤ <i>parameters</i>:</p> <p>Connection type specific parameters, in the following format:</p> <p>GPIB: &lt;GPIB Interface ID&gt;_&lt;GPIB address&gt;</p> <p>Ethernet: &lt;IP1.IP2.IP3.IP4&gt;:&lt;Port&gt;</p> <p>USB: &lt;port&gt;,&lt;speed&gt;,&lt;parity (0: none   1: odd   2: even)&gt;,&lt;bit stop count (1   1.5   2)&gt;,&lt;flux control (0: none   2: rts/cts   4: dtr/dsr)&gt;</p>
<b>Example(s)</b>	<p>:CTP:RLASer2:CPARameters 1,GPIB0_16</p> <p>:CTP:RLASer2:CPARameters? returns 1,GPIB0_16</p>

<b>:CTP:RLASer[1...10]:IDN?</b>	
<b>Description</b>	This query returns the identification of the given laser.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATus? on page 276).
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CTP:RLASer[1...10]:IDN?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<manufacturer>,<model>,<serial>,<firmware>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>manufacturer:</i> Manufacturer of the laser.</li> <li>➤ <i>model:</i> Instrument model.</li> <li>➤ <i>serial:</i> Instrument serial number.</li> <li>➤ <i>firmware:</i> Instrument firmware version.</li> </ul>
<b>Example(s)</b>	:CTP:RLAS2:IDN? returns EXFO,T100S-HP,0,6.06

---

**:CTP:RLASer[1...10]:LINK**

<b>Description</b>	This command sets the status of the connection to the given laser.
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STaTus?</i> on page 276).
<b>Type</b>	Overlapped.
<b>Syntax</b>	:CTP:RLASer[1...10]:LINK<wsp><status>
<b>Parameter(s)</b>	<i>status</i> : Status of the connection to the given laser: 0 CLOSE: closes the connection to the laser. 1 OPEN: opens the connection to the laser.
<b>Example(s)</b>	:CTP:RLASer2:LINK 1

**:CTP:RLASer[1...10]:LINK?**

<b>Description</b>	This query returns the status of the connection to the given laser.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STaTus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:RLASer[1...10]:LINK?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<status>
<b>Response(s)</b>	<i>status</i> : Status of the connection to the given laser: 0: the connection to the given laser is closed. 1: the connection to the given laser is open. 2: the given laser is connecting.
<b>Example(s)</b>	:CTP:RLASer2:LINK OPEN :CTP:RLASer2:LINK? returns 1

**:CTP:RLASer[1...10]:POWer**

<b>Description</b>	This command sets the laser output power value in static control.
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATUs? on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:RLASer[1...10]:POWer<wsp><power>[<unit>]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>power</i>: Output power of the given laser as a float value. Possible values depend on the laser specifications.</li> <li>➤ <i>unit</i>: Unit of the power value. The allowed units are DBM (dBm) or MW (mW). The default unit is dBm.</li> </ul>
<b>Example(s)</b>	:CTP:RLASer2:POWer 1.5

---

**:CTP:RLASer[1...10]:POWer?**

<b>Description</b>	This query returns the power value set for the given laser in static control, or the actual laser power after an acquisition.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATUs? on page 276).
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:RLASer[1...10]:POWer?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<power>
<b>Response(s)</b>	<i>power</i> : Output power set for the laser in dBm as float value (in static control). If an acquisition has been made, the value returned is the actual laser power.
<b>Example(s)</b>	:CTP:RLASer2:POWer -2.1 :CTP:RLASer2:POWer? returns -2.10000000E+00

---

**:CTP:RLASer[1...10]:POWER:STATE**

<b>Description</b>	This command enables/disables the laser output
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATUS?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:RLASer[1...10]:POWER:STATE<wsp><state>
<b>Parameter(s)</b>	<i>state</i> : State of the laser output power: 0 OFF: disables the laser output. 1 ON: enables the laser output.
<b>Example(s)</b>	:CTP:RLASer2:POWER:STATE ON

**:CTP:RLASer[1...10]:POWER:STATE?**

<b>Description</b>	This query returns the state of the given laser output.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATUS?</i> on page 276).
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:RLASer[1...10]:POWER:STATE?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : State of the laser output power: 0 OFF: the laser output is disabled. 1 ON: the laser output is enabled.
<b>Example(s)</b>	:CTP:RLASer2:POWER:STATE OFF :CTP:RLASer2:POWER:STATE? returns 0

:CTP:RLASer[1...10]:REferencing	
<b>Description</b>	This command launches the internal wavelength referencing sequence of the T100S-HP laser.
<b>Applicability</b>	This command only applies to T100S-HP lasers. In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATus? on page 276).
<b>Type</b>	Overlapped. When the system executes this command, the bit 11 "Laser referencing" is set in the Operational Status Condition Register (see :STATus:OPERation:CONDition? on page 251 and <i>Operational / Questionable Status Reporting</i> on page 205). If the wavelength referencing has not been properly completed, the -316 error "Laser referencing error" is added to the error queue (see <i>SCPI-Based Errors</i> on page 535).
<b>Syntax</b>	:CTP:RLASer[1...10]:REferencing
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:CTP:RLASer1:REferencing

---



**:CTP:RLASer[1...10]:TYPE**

<b>Description</b>	<p>This command adds or removes the given laser and sets its model. If you connect several lasers to the CTP10, you must set the laser models one after the other, from 1 to 10 (you cannot set :CTP:RLASer2:TYPE if :CTP:RLASer1:TYPE is not set).</p> <p>If you remove a laser (using the 0 parameter), all the following lasers set are shifted: for example, if you have set 4 lasers and then remove RLASer2 (:CTP:RLASer2:TYPE 0), RLASer4 becomes RLASer3 and RLASer3 becomes RLASer2.</p>
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATus? on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:RLASer[1...10]:TYPE<wsp><model>
<b>Parameter(s)</b>	<p><i>model:</i></p> <p>Integer corresponding to the model of the given laser. The allowed values are:</p> <ul style="list-style-type: none"> <li>0: None (removes an existing laser).</li> <li>1: reserved.</li> <li>2: reserved.</li> <li>3: reserved.</li> <li>4: reserved.</li> <li>5: adds a T100S-HP laser model.</li> <li>6: adds an mSWS-A1SLS laser model.</li> <li>7: reserved.</li> </ul>
<b>Example(s)</b>	:CTP:RLASer2:TYPE 3

---

**:CTP:RLASer[1...10]:TYPE?**

<b>Description</b>	This query returns the given laser model.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATUS?</i> on page 276).
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:RLASer[1...10]:TYPE?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<model>
<b>Response(s)</b>	<i>model:</i> Integer corresponding to the model of the selected laser: 0: None. 1: reserved. 2: reserved. 3: reserved. 4: reserved. 5: T100S-HP model. 6: mSWS-A1SLS model. 7: reserved.
<b>Example(s)</b>	:CTP:RLASer2:TYPE 3 :CTP:RLASer2:TYPE? returns 3

---

**:CTP:RLASer[1...10]:WAVelength**

<b>Description</b>	This command sets the laser emission wavelength or frequency (static control).
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATus? on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:RLASer[1...10]:WAVelength<wsp><value>[<unit>]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Sets the laser emission wavelength or frequency as float value.</li> <li>➤ <i>unit</i>: Unit of the laser emission value. The allowed units are: PM NM M HZ GHZ THZ The default unit is meter (M).</li> </ul>
<b>Example(s)</b>	:CTP:RLASer2:WAV 1500NM

**:CTP:RLASer[1...10]:WAVelength?**

<b>Description</b>	This query returns the laser emission wavelength set for the given laser in static control, or the actual laser wavelength after an acquisition.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATus? on page 276).
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:RLASer[1...10]:WAVelength?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Emission wavelength of the given laser in meters. If an acquisition has been made, the value returned is the actual laser wavelength.
<b>Example(s)</b>	:CTP:RLASer2:WAV 1500NM :CTP:RLASer2:WAV? returns +1.50000000E-006

**:CTP:SENSe[1...10]:CHANnel[1...6]:AVG**

<b>Description</b>	<p>This command sets the averaging time on the given detector (static control).</p> <p>This command is not available if the detector is scanning.</p> <p>On IL RL OPM2 modules, if the command applies to one of the following connectors, the value set also applies to the two other connectors of the module: TLS IN, Out to SCAN SYNC or Out to DUT.</p>
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:AVG<wsp> <value>
<b>Parameter(s)</b>	<p><i>value</i>:</p> <p>Averaging time value to apply on the detector in millisecond (ms) in the range 0.001 and 1000.</p>
<b>Example(s)</b>	:CTP:SENS6:CHAN3:AVG 0.002

---

**:CTP:SENSe[1...10]:CHANnel[1...6]:AVG?**

<b>Description</b>	This query returns the averaging time applied on the given detector.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:AVG?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<p><i>value</i>:</p> <p>Averaging time applied on the detector in millisecond (ms).</p>
<b>Example(s)</b>	<p>:CTP:SENS6:CHAN3:AVG 0.002</p> <p>:CTP:SENS6:CHAN3:AVG? returns 0.002</p>

---

**:CTP:SENSe[1...10]:CHANnel[1...6]:FUNCTion:ACTivate**

<b>Description</b>	This command sets the activation state of the logging or stability function for the given detector.  For more details on these functions, see <i>Triggering Power Level Data Acquisition</i> on page 82.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:FUNCTion:ACTivate<wsp><state>
<b>Parameter(s)</b>	<i>state:</i>  Activation state of the logging or stability function on the given detector. The allowed values are: 0 INACTive: disables the function on the detector. 1 ACTive: enables the function on the detector.
<b>Example(s)</b>	:CTP:SENS6:CHAN3:FUNC:ACT 1

**:CTP:SENSe[1...10]:CHANnel[1...6]:FUNCTion:ACTivate?**

<b>Description</b>	This query returns the activation state of the logging or stability function for the given detector.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:FUNCTion:ACTivate?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state:</i>  Activation state of the logging or stability function on the given detector: 0: the function is disabled. 1: the function is enabled.
<b>Example(s)</b>	:CTP:SENS6:CHAN3:FUNC:ACT ACT :CTP:SENS6:CHAN3:FUNC:ACT? returns 1

292

**:CTP:SENSe[1...10]:CHANnel[1...6]:FUNCTion:STATe?**

<b>Description</b>	This query returns the measurement mode in use on the given detector and the progress status of the data acquisition on the detector.
<b>Type</b>	Sequential, query only.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:FUNCTion:STATe?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<function>,<status>
<b>Response(s)</b>	<ul style="list-style-type: none"><li>➤ <i>function</i>: Name of the measurement mode in use on the given detector: 0: the stability function is in use on the detector. 1: the logging function is in use on the detector.</li><li>➤ <i>status</i>: 0: data acquisition is completed. 1: data acquisition is in progress.</li></ul>
<b>Example(s)</b>	:CTP:SENS6:CHAN4:FUNC:STAT? returns 1,1

---

**:CTP:SENSe[1...10]:CHANnel[1...6]:FUNCTion:TRIGGer**

<b>Description</b>	This command sets the incoming trigger to use for the logging function on the given detector.  For more details on this function, see <i>Triggering Power Level Data Acquisition</i> on page 82.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:FUNCTion:TRIGGer<wsp><trigger>
<b>Parameter(s)</b>	<i>value:</i>  Integer corresponding to the trigger to use for the logging function, in the range 0 to 8:  0: software trigger, which means that the data acquisition is triggered with the command :CTP:FUNCTion:STATe on page 270.  1 to 8: sets the number of the TRIG IN port to use for the detectors of the module. When the logging function is started (see :CTP:FUNCTion:STATe on page 270), the detectors waits for the trigger signal coming from this port to start the acquisition.
<b>Example(s)</b>	:CTP:SENS6:CHAN3:FUNC:TRIGG 4

**:CTP:SENSe[1...10]:CHANnel[1...6]:FUNCTion:TRIGGer?**

<b>Description</b>	This query returns the incoming trigger used for the logging function on the given detector.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:FUNCTion:TRIGGer?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value:</i>  Integer corresponding to the trigger used for the logging function, in the range 0 to 8:  0: software trigger.  1 to 8: number of the TRIG IN port used.
<b>Example(s)</b>	:CTP:SENS6:CHAN4:FUNC:TRIGG 5 :CTP:SENS6:CHAN4:FUNC:TRIGG? returns 5



**:CTP:SENSe[1...10]:CHANnel[1...6]:OFFset**

<b>Description</b>	<p>This command sets the power offset of the given detector (static control).</p> <p>This command is not available if the detector is scanning.</p> <p>On IL RL OPM2 modules, if the command applies to one of the following connectors, the value set also applies to the two other connectors of the module: TLS IN, Out to SCAN SYNC or Out to DUT.</p>
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:OFFset<wsp><offset>
<b>Parameter(s)</b>	<p><i>offset:</i></p> <p>Power offset that you want to apply to the given detector, as float value in dB in the range -2 to 2.</p> <p>The default unit is 0.</p>
<b>Example(s)</b>	:CTP:SENS1:CHAN2:OFF 0.2

**:CTP:SENSe[1...10]:CHANnel[1...6]:OFFset?**

<b>Description</b>	This query returns the power offset set on the given detector.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:OFFset?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<offset>
<b>Response(s)</b>	<p><i>offset:</i></p> <p>Float value in dB corresponding to the offset set on the detector:</p>
<b>Example(s)</b>	<p>:CTP:SENS1:CHAN2:OFF 0.5</p> <p>:CTP:SENS1:CHAN2:OFF? returns 0.5</p>

<b>:CTP:SENSe[1...10]:CHANnel[1...6]:POWer?</b>	
<b>Description</b>	This query returns the power measured on the given detector.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:POWer?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<power>
<b>Response(s)</b>	<i>power:</i> Instant power in dBm measured on the given detector. On an IL RL OPM2 module, the response value for channel 3 is the instant power measured on the TLS IN port and the response value for channel 4 is the back reflection value measured on the port. On an IL PDL or IL PDL OPM2 module, the response value for channel 3 is the instant power measured on the TLS IN port.
<b>Example(s)</b>	:CTP:SENS2:CHAN2:POW? returns -3.1

**:CTP:SENSe[1...10]:CHANnel[1...6]:UNIT:X**

<b>Description</b>	This command sets the spectral unit of the given detector. This command is not available if the detector is scanning.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:UNIT:X<wsp><unit>
<b>Parameter(s)</b>	<i>unit</i> : Spectral unit for the given detector. The allowed values are: 0 WAVelength: sets the unit to nm. 1 FREQuency: sets the unit to THz.
<b>Example(s)</b>	:CTP:SENS1:CHAN2:UNIT:X FREQ

**:CTP:SENSe[1...10]:CHANnel[1...6]:UNIT:X?**

<b>Description</b>	This query returns the the spectral unit set for the given detector.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:UNIT:X?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<unit>
<b>Response(s)</b>	<i>unit</i> : Integer corresponding to the spectral unit set for the detector: 0: the unit is set to nm. 1: the unit is set to THz.
<b>Example(s)</b>	:CTP:SENS1:CHAN2:UNIT:X WAV :CTP:SENS1:CHAN2:UNIT:X? returns 0

**:CTP:SENSe[1...10]:CHANnel[1...6]:UNIT:Y**

<b>Description</b>	This command sets the power unit of the given detector. This command is not available if the detector is scanning.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:UNIT:Y<wsp><unit>
<b>Parameter(s)</b>	<i>unit:</i> Spectral unit for the given detector. The allowed values are: 0 DBM: sets the unit to dBm. 1 MW: sets the unit to mW. The default unit is DBM.
<b>Example(s)</b>	:CTP:SENS1:CHAN2:UNIT:Y DBM

---

**:CTP:SENSe[1...10]:CHANnel[1...6]:UNIT:Y?**

<b>Description</b>	This query returns the power unit set for the given detector.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:UNIT:Y?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<unit>
<b>Response(s)</b>	<i>unit:</i> Integer corresponding to the power unit set for the detector: 0: the unit is set to dBm. 1: the unit is set to mW.
<b>Example(s)</b>	:CTP:SENS1:CHAN2:UNIT:Y MW :CTP:SENS1:CHAN2:UNIT:Y? returns 1

---

**:CTP:SENSe[1...10]:CHANnel[1...6]:WAVelength**

<b>Description</b>	<p>This command sets the wavelength or frequency of the signal received on the given detector (static control).</p> <p>This command is not available if the detector is scanning.</p> <p>On IL RL OPM2 modules, if the command applies to the TLS IN, Out to SCAN SYNC or Out to DUT connector, the value set also applies to the two other connectors of the module.</p>
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:WAVelength<wsp><value>[<unit>]
<b>Parameter(s)</b>	<p>➤ <i>value</i>:</p> <p>Wavelength or frequency as float value, in the range 1240 to 1680 nm or 178.4479 to 241.7681 THz.</p> <p>➤ <i>unit</i>:</p> <p>Unit of the set value.</p> <p>The allowed units are PM NM M HZ GHZ THZ</p> <p>The default unit is meter or Hertz, depending on the unit setting (set with command :UNIT:X on page 533).</p>
<b>Example(s)</b>	:CTP:SENS1:CHAN2:WAV 1550NM

**:CTP:SENSe[1...10]:CHANnel[1...6]:WAVelength?**

<b>Description</b>	This query returns the wavelength or frequency set for the signal received on the given detector (static control)
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:SENSe[1...10]:CHANnel[1...6]:WAVelength?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<p><i>value</i>:</p> <p>Wavelength or frequency as float value in meters or Hertz depending on the unit settings (set with command :CTP:SENSe[1...10]:CHANnel[1...6]:UNIT:X on page 297).</p>
<b>Example(s)</b>	<p>:CTP:SENS6:CHAN2:WAV 1550NM</p> <p>:CTP:SENS1:CHAN2:WAV? returns +1.50000000E-006</p>

**:CTP:SENSe[1...20]:CHANnel[1...6]:ZEROing**

<b>Description</b>	<p>This command performs a dark current zeroing on the given detector (for more details, see <i>Zeroing the Dark Current on Detectors</i> on page 84).</p> <p>This command is not available if the detector is scanning.</p> <ul style="list-style-type: none"> <li>➤ use channels 1 and 2 to perform a zeroing on the first and second optical detectors (IL RL OPM2 or IL PDL OPM2 module only)</li> <li>➤ use channel 3 to perform a Reference zeroing.</li> <li>➤ use channel 4 to perform a BR zeroing (IL RL OPM2 only).</li> </ul>
<b>Type</b>	<p>Overlapped.</p> <p>When the system executes this command, the bit 0 "Zeroing" is set in the Operational Status Condition Register (see <i>:STATus:OPERation:CONDition?</i> on page 251 and <i>Operational / Questionable Status Reporting</i> on page 205).</p> <p>If the zeroing operation has not been properly completed, the -310 error "Zeroing error" is added to the error queue (see <i>SCPI-Based Errors</i> on page 535).</p>
<b>Syntax</b>	:CTP:SENSe[1...20]:CHANnel[1...6]:ZEROing
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:CTP:SENS2:CHAN2:ZERO

**:CTP:SENSe[1...20]:CHANnel[1...6]:ZEROing?**

<b>Description</b>	This query returns the date and time of the last dark current measurement on the given detector.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:SENSe[1...20]:CHANnel[1...6]:ZEROing?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<date>, <time>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>date</i>: Date of the last zeroing measurement, expressed as YYYYMMDD.</li> <li>➤ <i>time</i>: Time of the last zeroing measurement, expressed as HHMMSS.</li> </ul>
<b>Example(s)</b>	:CTP:SENS2:CHAN2:ZERO? returns 20190104,145623

**:CTP:SENSe[1...20]:IDN?**

<b>Description</b>	This query returns the identification of the module.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CTP:SENSe[1...20]:IDN?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<manufacturer>,<model>,<serial>,<FPGA>
<b>Response(s)</b>	<ul style="list-style-type: none"><li>➤ <i>manufacturer:</i> Manufacturer name.</li><li>➤ <i>model:</i> Module name.</li><li>➤ <i>serial number:</i> Module serial number.</li><li>➤ <i>FPGA:</i> Module FPGA version.</li></ul>
<b>Example(s)</b>	:CTP:SENSe4:IDN? returns EXFO,EXFO,OPM6,EX1405103XX,0.2.45

---

<b>:CTP:SENSe[1...10]:FBC</b>	
<b>Description</b>	This command only applies to an FBC module. It selects the TLS IN laser input to use for static measurements.
<b>Type</b>	Sequential if the module is scanning, overlapping if the module is not scanning.
<b>Syntax</b>	:CTP:SENSe[1...10]:FBC<wsp> <input>
<b>Parameter(s)</b>	<i>input:</i> Integer corresponding to the laser input to select. The allowed values are: 0: no input, all inputs are shut 1: IN 1 input 2: IN 2 input 3: IN 3 input 4: IN 4 input
<b>Example(s)</b>	:CTP:SENS1:FBC 3

<b>:CTP:SENSe[1...10]:FBC?</b>	
<b>Description</b>	This query only applies to an FBC module. It returns the selected laser input.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CTP:SENSe[1...10]:FBC?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<input>
<b>Response(s)</b>	<i>input:</i> Integer corresponding to the selected laser input: 0: no input, all inputs are shut 1: IN 1 input 2: IN 2 input 3: IN 3 input 4: IN 4 input.
<b>Example(s)</b>	:CTP:SENS1:FBC 3 :CTP:SENS1:FBC? 3



**:CTP:SENSe[1...20]:OPTion?**

<b>Description</b>	This query returns the option of the module.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CTP:SENSe[1...20]:OPTion?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<option>
<b>Response(s)</b>	<i>option</i> : String corresponding to the module option.
<b>Example(s)</b>	:CTP:SENSe5:OPT? returns SC (SC type FOA)

**:CTP:SENSe[1...20]:RST**

<b>Description</b>	This command restores the factory settings of the given module. The corresponding GUI button is <b>Restore factory settings</b> (see <i>Restoring the Factory Settings of a Module</i> on page 85).
<b>Type</b>	Sequential, no query.
<b>Syntax</b>	:CTP:SENSe[1...20]:RST
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:CTP:SENSe8:RST

**:CTP:SENSe[1...20]:TST?**

<b>Description</b>	This query performs the self-test of the given module and returns the test result.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CTP:SENSe[1...20]:TST?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<result>
<b>Response(s)</b>	<i>result:</i> Result of the self-test. Possible values are: <ul style="list-style-type: none"><li>➤ 0: no error was found on the module.</li><li>➤ &lt;error code&gt;: an error occurred. In this case, remove the module and insert it again. If the error appears again, contact the EXFO customer support. Possible error values are:<ul style="list-style-type: none"><li>➤ -3004: test registry error. The access to the module internal registry failed.</li><li>➤ -3005: clock error.</li><li>➤ -3010: error on the polarization state generator.</li><li>➤ -3011: temperature error.</li><li>➤ -6001: detector analog error.</li><li>➤ -6002: CTN error.</li></ul></li></ul>
<b>Example(s)</b>	:CTP:SENSe8:TST? returns 0 (self-test was completed with success)

---

**:CTP:SENSe[1...20]:TYPE?**

<b>Description</b>	This query returns the module type.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CTP:SENSe[1...20]:TYPE?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<type>
<b>Response(s)</b>	<i>type</i> : Integer corresponding to the module type. 0: no module in the slot. 1: OPM2 module. 2: OPM4 module. 3: OPM6 module. 4: IL RL OPM2 module. 5: IL PDL module 6: SCAN SYNC module. 7: FBC module. 8: IL PDL OPM2 module.
<b>Example(s)</b>	:CTP:SENSe9:TYPE? returns 2 (OPM4 module)

**:STOP (Deprecated)**

<b>Description</b>	This command is deprecated, and will be removed from the next version. Use :ABORT on page 259 instead.  This command stops a scan that is currently in progress. The scan stops when the wavelength stop is reached.  If a reference scan is in progress, this command aborts the scan.  This command is useful when scanning in continuous mode.
<b>Type</b>	Overlapping, no query.
<b>Syntax</b>	:STOP
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:STOP

## CALCulate Commands and Queries

### Quick Reference

Command Overview				Parameter(s)	Section
CALCulate	[:IMMediate]				see p. 307
		AUTO		<state>	see p. 308
		AUTO?			see p. 308
	DATA?				see p. 332
	MARKers	A	CENTer		see p. 308
			X	<value>[<unit>]   MIN   MAX	see p. 309
			X?	[MIN MAX]	see p. 309
			Y?		see p. 310
		ARANge		<state>	see p. 311
		ARANge?			see p. 311
			STARt	<value>[<unit>]   MIN   MAX	see p. 312
			STARt?	[MIN MAX]	see p. 312
			STOP	<value>[<unit>]   MIN   MAX	see p. 313
			STOP?	[MIN MAX]	see p. 313
		B	CENTer		see p. 314
			X	<value>[<unit>]   MIN   MAX	see p. 315
			X?	[MIN MAX]	see p. 315
			Y?		see p. 316
		BADiff	CENTer		see p. 316
			X	<value>   MIN   MAX	see p. 317
			X?	[MIN MAX]	see p. 317
			Y?		see p. 318
		C	CENTer		see p. 318
			Y	<value>[<unit>]   MIN   MAX	see p. 319
			Y?	[MIN MAX]	see p. 319
		D	CENTer		see p. 320
			Y	<value>[<unit>]   MIN   MAX	see p. 321
			Y?	[MIN MAX]	see p. 321
		DCDiff	CENTer		see p. 322
			Y	<value>   MIN   MAX	see p. 323
			Y?	[MIN MAX]	see p. 323
		STATe		<state>	see p. 324
		STATe?			see p. 324
	MODE			<mode>	see p. 325

Command Overview				Parameter(s)	Section
	MODE?				see p. 325
	NFLOor	[LVL]		<value>[ <unit> ]   MIN   MAX	see p. 326
		[LVL]?		[MIN   MAX]	see p. 326
		STATe		<state>	see p. 327
		STATe?			see p. 327
	PARameters				see p. 354
	SOURce			<category>,<trace>[,<channel>,<type>]	see p. 328
	SOURce?				see p. 329
		MULTitraces		<category>[,<trace>,<channel>,<type>]	see p. 330
		MULTitraces?			see p. 331

### Commands and Queries

:CALCulate[:IMMediate]	
<b>Description</b>	This command performs an analysis on the trace(s) selected for analysis (to set the trace to analyze, see :CALCulate:SOURce on page 328 or :CALCulate:SOURce:MULTitraces on page 330).
<b>Type</b>	Sequential, no query.  When the system performs an analysis, the bit 3 "Analyzing" is set in the Operational Status Condition Register (see :STATus:OPERation:CONDition? on page 251 and <i>Operational / Questionable Status Reporting</i> on page 205).  If the analysis takes more than 30 seconds, you will get a timeout error (code -302, see <i>SCPI-Based Errors</i> on page 535 for more details) in the error queue: this does not mean that the analysis did not complete, you should not take this error into account.
<b>Syntax</b>	:CALCulate[:IMMediate]
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:CALC


**:CALCulate[:IMMediate]:AUTO**

<b>Description</b>	This command sets the <b>Auto analyze</b> function. The corresponding GUI parameter is <b>Auto analyze</b> on page 157.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate[:IMMediate]:AUTO<wsp> <state>
<b>Parameter(s)</b>	<i>state:</i> State of the auto analysis. The allowed values are: 0 OFF: disables the <b>Auto analyze</b> function. 1 ON: enables the <b>Auto analyze</b> function and performs an analysis as described in :CALCulate[:IMMediate] on page 307.
<b>Example(s)</b>	:CALC:AUTO ON

**:CALCulate[:IMMediate]:AUTO?**

<b>Description</b>	This query returns the state of the <b>Auto analyze</b> function.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate[:IMMediate]:AUTO?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state:</i> State of the auto analysis function: 0: the <b>Auto analyze</b> function is disabled. 1: the <b>Auto analyze</b> function is enabled.
<b>Example(s)</b>	:CALC:AUTO ON :CALC:AUTO? returns 1

**:CALCulate:MARKers:A:CENTer**

<b>Description</b>	This command places the A marker at the center of the X axis of the graph zoom area. Corresponding command buttons on the GUI:  .
<b>Type</b>	Overlapping, no query.
<b>Syntax</b>	:CALCulate:MARKers:A:CENTer
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:CALC:MARK:A:CENt

**:CALCulate:MARKers:A:X**

<b>Description</b>	This command defines the A marker position on graph.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:A:X<wsp><value>[<unit>]   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Wavelength or frequency corresponding to the position of the A marker, followed by the wanted unit.</li> <li>➤ <i>unit</i>: Unit of the position value. The allowed units are PM NM M HZ GHZ THZ. The default unit is meter or hertz, depending on the unit setting (set with command :UNIT:X on page 533).</li> <li>➤ <i>MIN</i>: Minimum value: 1240 nm or 178.44789 THz.</li> <li>➤ <i>MAX</i>: Maximum value: 1680 nm or 241.76811 THz.</li> </ul>
<b>Example(s)</b>	:CALC:MARK:A:X 1300NM

**:CALCulate:MARKers:A:X?**

<b>Description</b>	This query returns the position of the A marker.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:A:X? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Wavelength or frequency corresponding to the A marker's position as float value in meters or Hertz depending on the unit setting (see :UNIT:X on page 533).
<b>Example(s)</b>	:CALC:MARK:A:X 1300NM :CALC:MARK:A:X? returns +1.30000000E-006

**:CALCulate:MARKers:A:Y?**

<b>Description</b>	This query returns the power/ratio value corresponding to the position of the A marker on the selected trace. To select the trace to which the marker applies, use the command <i>:DISPlay:FOCUS</i> on page 449.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:MARKers:A:Y?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Power level or ratio as float value corresponding to the position of the A marker on the selected trace The unit depends on the unit setting (see <i>:UNIT:Y</i> on page 534).
<b>Example(s)</b>	:CALC:MARK:A:Y? returns -7.350000000E+001

---



**:CALCulate:MARKers:ARANge**

<b>Description</b>	This command defines if the analysis should be performed on the part of the trace located between the two analysis markers. The corresponding GUI setting is <b>Between markers only</b> on <b>page 157</b> .
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:MARKers:ARANge<wsp><state>
<b>Parameter(s)</b>	<i>state</i> : State of the <b>Between markers only</b> analysis function. The allowed values are: 0 OFF: disables the <b>Between markers only</b> function. 1 ON: enables the <b>Between markers only</b> function.
<b>Example(s)</b>	:CALC:MARKers:ARAN ON

**:CALCulate:MARKers:ARANge?**

<b>Description</b>	This query returns the state of the <b>Between markers only</b> analysis function
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:ARANge?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : State of the <b>Between markers only</b> analysis function: 0 OFF: the analysis is not performed between analysis markers. 1 ON: the analysis is performed between analysis markers.
<b>Example(s)</b>	:CALC:MARKers:ARAN ON :CALC:MARKers:ARAN? returns 1

**:CALCulate:MARKers:ARANge:STARt**

<b>Description</b>	This command defines the wavelength or frequency of the start analysis marker.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:MARKers:ARANge:STARt<wsp> <value> [ <unit> ]   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Wavelength or frequency of the start analysis marker.</li> <li>➤ <i>unit</i>: Unit of the start value. The allowed units are PM NM M HZ GHZ THZ. The default unit is meter or hertz, depending on the unit setting (set with command :UNIT:X on page 533).</li> <li>➤ <i>MIN</i>: Minimum value: 1240 nm or 178.44789 THz.</li> <li>➤ <i>MAX</i>: Maximum value: 1680 nm or 241.76811 THz.</li> </ul>
<b>Example(s)</b>	:CALC:MARK:ARAN:STAR 1300NM

**:CALCulate:MARKers:ARANge:STARt?**

<b>Description</b>	This query returns the wavelength or frequency of the start analysis marker.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:ARANge:STARt? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Wavelength or frequency of the start analysis marker as a float value in meters or Hertz depending on the unit setting (set with command :UNIT:X on page 533).
<b>Example(s)</b>	:CALC:MARK:ARAN:STARt 1300NM :CALC:MARK:ARAN:STARt? returns +1.30000000E-006


**:CALCulate:MARKers:ARANge:STOP**

<b>Description</b>	This command defines the wavelength or frequency of the stop analysis marker.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:MARKers:ARANge:STOP<wsp><value>[<unit>]   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Wavelength or frequency of the stop analysis marker.</li> <li>➤ <i>unit</i>: Unit of the stop value. The allowed units are PM NM M HZ GHZ THZ. The default unit is meter or hertz, depending on the unit setting (set with command :UNIT:X on page 533).</li> <li>➤ <i>MIN</i>: Minimum value: 1240 nm or 178.44789 THz.</li> <li>➤ <i>MAX</i>: Maximum value: 1680 nm or 241.76811 THz.</li> </ul>
<b>Example(s)</b>	:CALC:MARK:ARAN:STOP 1300NM

**:CALCulate:MARKers:ARANge:STOP?**

<b>Description</b>	This query returns the wavelength or frequency of the stop analysis marker.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:ARANge:STOP? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Wavelength or frequency of the stop analysis marker as a float value in meters or Hertz depending on the unit setting (see :UNIT:X on page 533).
<b>Example(s)</b>	:CALC:MARK:ARAN:STOP 1300NM :CALC:MARK:ARAN:STOP? returns +1.30000000E-006

**:CALCulate:MARKers:B:CENTer**

<b>Description</b>	This command places the B marker at the center of the X axis of the graph zoom area. Corresponding command buttons on the GUI:  .
<b>Type</b>	Overlapping, no query.
<b>Syntax</b>	:CALCulate:MARKers:B:CENTer
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:CALC:MARK:B:CENT

---

**:CALCulate:MARKers:B:X**

<b>Description</b>	This command defines the B marker position on graph.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:B:X<wsp><value>[<unit>]   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Wavelength or frequency corresponding to the position of the B marker, followed by the wanted unit.</li> <li>➤ <i>unit</i>: Unit of the position value. The allowed units are PM NM M HZ GHZ THZ. The default unit is meter or hertz, depending on the unit setting (set with command :UNIT:X on page 533).</li> <li>➤ <i>MIN</i>: Minimum value: 1240 nm or 178.44789 THz.</li> <li>➤ <i>MAX</i>: Maximum value: 1680 nm or 241.76811 THz.</li> </ul>
<b>Example(s)</b>	:CALC:MARK:B:X 1400.520NM


**:CALCulate:MARKers:B:X?**

<b>Description</b>	This query returns the position of the B marker.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:B:X? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Wavelength or frequency corresponding to the B marker's position as float value in meters or Hertz depending on the unit setting (see :UNIT:X on page 533).
<b>Example(s)</b>	:CALC:MARK:B:X 1400.520NM :CALC:MARK:B:X? returns +1.40052000E-006

**:CALCulate:MARKers:B:Y?**

<b>Description</b>	This query returns the power/ratio value corresponding to the position of the B marker on the selected trace. To select the trace to which the marker applies, use the command <i>:DISPlay:FOCUS</i> on page 449.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:MARKers:B:Y?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> :  Power level or ratio as float value corresponding to the position of the B marker on the selected trace The unit depends on the unit setting (see <i>:UNIT:Y</i> on page 534).
<b>Example(s)</b>	:CALC:MARK:B:Y? returns -6.230000000E+001

**:CALCulate:MARKers:BADiff:CENTer**

<b>Description</b>	This command places the center of the distance between the A and B markers at the center of the X axis of the graph zoom area, without modifying the B-A value (difference between the B marker and the A marker). Corresponding command buttons on the GUI:  .
<b>Type</b>	Overlapping, no query.
<b>Syntax</b>	:CALCulate:MARKers:BADiff:CENTer
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:CALC:MARK:BAD:CENT

**:CALCulate:MARKers:BADiff:X**

<b>Description</b>	This command defines the B-A (difference between the B marker and the A marker) wavelength or frequency value.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:BADiff:X<wsp> <value>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Difference between the B marker and the A marker, in nm or THz depending on the unit setting (set with command :UNIT:X on page 533).</li> <li>➤ <i>MIN</i>: Minimum value: -440 nm or -63.32022 THz.</li> <li>➤ <i>MAX</i>: Maximum value: 440 nm or 63.32022 THz.</li> </ul>
<b>Example(s)</b>	:CALC:MARK:BAD:X 100.52


**:CALCulate:MARKers:BADiff:X?**

<b>Description</b>	This query returns the B-A (difference between the B marker and the A marker) wavelength or frequency value.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:BADiff:X? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Wavelength or frequency value corresponding to difference between the B marker and the A marker as float value in meters or Hertz depending on the unit setting (see :UNIT:X on page 533).
<b>Example(s)</b>	:CALC:MARK:BAD:X 100.52 :CALC:MARK:BAD:X? returns +1.00520000E-007

**:CALCulate:MARKers:BADiff:Y?**

<b>Description</b>	This query returns the power/ratio value corresponding to the B-A (difference between the B marker and the A marker) on the selected trace. To select the trace to which the markers apply, use the command <i>:DISPlay:FOCUS</i> on page 449.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:MARKers:BADiff:Y?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Power level or ratio as float value corresponding to the difference between the B marker and the A marker on the selected trace The unit depends on the unit setting (see <i>:UNIT:Y</i> on page 534).
<b>Example(s)</b>	:CALC:MARK:BAD:Y? returns -7.350000000E+001

**:CALCulate:MARKers:C:CENTer**

<b>Description</b>	This command places the C marker at the center of the Y axis of the graph zoom area. Corresponding command buttons on the GUI:  .
<b>Type</b>	Overlapping, no query.
<b>Syntax</b>	:CALCulate:MARKers:C:CENTer
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:CALC:MARK:C:CENT




**:CALCulate:MARKers:C:Y**

<b>Description</b>	This command defines the C marker position on graph.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:C:Y<wsp><value>[<unit>]  MIN MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Power level or ratio as float value corresponding to the position of the C marker</li> <li>➤ <i>unit</i>: Unit of the position value. The allowed units are DB (dB) or RATIO (ratio). The default unit is dB.</li> <li>➤ <i>MIN</i>: Minimum value: -110 dB or 0 ratio.</li> <li>➤ <i>MAX</i>: Maximum value: 20 dB or 100 ratio.</li> </ul>
<b>Example(s)</b>	:CALC:MARK:C:Y -35DB

**:CALCulate:MARKers:C:Y?**

<b>Description</b>	This query returns the position of the C marker.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:C:Y? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Power level or ratio as float value corresponding to the position of the C marker in dB or ratio depending on the unit setting (see :UNIT:Y on page 534).
<b>Example(s)</b>	:CALC:MARK:C:Y -35DB :CALC:MARK:C:Y? returns -3.50000000E+001

**:CALCulate:MARKers:D:CENTer**

<b>Description</b>	This command places the D marker at the center of the Y axis of the graph zoom area. Corresponding command buttons on the GUI:  .
<b>Type</b>	Overlapping, no query.
<b>Syntax</b>	:CALCulate:MARKers:D:CENTer
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:CALC:MARK:D:CENT

---


**:CALCulate:MARKers:D:Y**

<b>Description</b>	This command defines the D marker position on graph.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:D:Y<wsp><value>[<unit>] MIN MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Power level or ratio as float value corresponding to the position of the D marker</li> <li>➤ <i>unit</i>: Unit of the position value. The allowed units are DB (dB) or RATIO (ratio). The default unit is dB.</li> <li>➤ <i>MIN</i>: Minimum value: -110 dB or 0 ratio.</li> <li>➤ <i>MAX</i>: Maximum value: 20 dB or 100 ratio.</li> </ul>
<b>Example(s)</b>	:CALC:MARK:D:Y 3.5DB

**:CALCulate:MARKers:D:Y?**

<b>Description</b>	This query returns the position of the D marker.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:D:Y? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Power level or ratio as float value corresponding to the position of the D marker in dB or ratio depending on the unit setting (see :UNIT:Y on page 534).
<b>Example(s)</b>	:CALC:MARK:D:Y 3.5DB :CALC:MARK:D:Y? returns +3.50000000E+000

**:CALCulate:MARKers:DCDiff:CENTer**

<b>Description</b>	This command places the center of the distance between the C and D markers at the center of the Y axis of the graph zoom area, without modifying the D-C value (difference between the B marker and the A marker). Corresponding command buttons on the GUI:  .
<b>Type</b>	Overlapping, no query.
<b>Syntax</b>	:CALCulate:MARKers:DCDiff:CENTer
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:CALC:MARK:DCD:CENT

---



**:CALCulate:MARKers:DCDiff:Y**

<b>Description</b>	This command defines the D-C (difference between the D marker and the C marker) power/ratio value.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:DCDiff:Y<wsp><value> MIN MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Difference between the D marker and the C marker, in dB or Ratio depending on the unit setting (set with command :UNIT:Y on page 534).</li> <li>➤ <i>MIN</i>: Minimum value: -130 dB or -100 ratio.</li> <li>➤ <i>MAX</i>: Maximum value: 130 dB or 100 ratio.</li> </ul>
<b>Example(s)</b>	:CALC:MARK:DCD:Y -38.5

**:CALCulate:MARKers:DCDiff:Y?**

<b>Description</b>	This query returns the D-C (difference between the D marker and the C marker) wavelength or frequency value.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:DCDiff:Y? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Power or ratio value corresponding to the difference between the D marker and the C marker as float value (depending on the unit setting: see :UNIT:Y on page 534).
<b>Example(s)</b>	:CALC:MARK:DCD:Y -38.5 :CALC:MARK:DCD:Y? returns -3.85000000E+001

**:CALCulate:MARKers:STATe**

<b>Description</b>	This command makes the makers visible/invisible on graph. Corresponding command buttons on the GUI:   .
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:STATe<wsp> <state>
<b>Parameter(s)</b>	<i>state</i> : State of the makers visibility. The allowed values are: 0 OFF: makes the markers invisible on graph. 1 ON: displays the markers on graph.
<b>Example(s)</b>	:CALC:MARK:STAT ON

**:CALCulate:MARKers:STATe?**

<b>Description</b>	This query returns the markers visibility state on graph.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:MARKers:STATe?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : State of the markers visibility: 0: the markers are not displayed on graph. 1: the markers are displayed on graph.
<b>Example(s)</b>	:CALC:MARK:STAT ON :CALC:MARK:STAT? returns 1

**:CALCulate:MODE**

<b>Description</b>	This command sets the analysis mode. The corresponding GUI setting is <i>Mode</i> on page 157.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:MODE<wsp><mode>
<b>Parameter(s)</b>	<i>mode</i> : Analysis mode. The allowed values are: PCT: enables the <b>PCT</b> analysis mode. WPCT: enables the <b>PCT WDM</b> analysis mode.
<b>Example(s)</b>	:CALC:MODE PCT

---

**:CALCulate:MODE?**

<b>Description</b>	This query returns the state of the analysis mode.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:MODE?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<mode>
<b>Response(s)</b>	<i>mode</i> : Selected analysis mode: PCT: the <b>PCT</b> mode is enabled. WPCT: the <b>PCT WDM</b> analysis mode is enabled.
<b>Example(s)</b>	:CALC:MODE WPCT :CALCulate:MODE? returns WPCT

---

**:CALCulate:NFLOor[:LVL]**

<b>Description</b>	This command sets the noise floor for the analysis. The corresponding GUI setting is <b>Noise level @ 1575 nm on page 157</b> .
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:NFLOor[:LVL]<wsp><value>[<unit>] MIN MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Noise detection threshold of the analysis tools, in the range -110 to 20 dB or 0.00000000001 to 100 ratio.</li> <li>➤ <i>unit</i>: Unit of the noise detection threshold. The allowed units are DB (dB) or RATIO (Ratio). The default unit is dB.</li> <li>➤ <i>MIN</i>: Minimum value: -110 dB or 0.00000000001 ratio.</li> <li>➤ <i>MAX</i>: Maximum value: 20 dB or 100 ratio.</li> </ul>
<b>Example(s)</b>	:CALC:NFLO -55.0 DB

**:CALCulate:NFLOor[:LVL]?**

<b>Description</b>	This query returns noise floor defined for the analysis.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:NFLOor[:LVL]? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Noise detection threshold of the analysis tools.
<b>Example(s)</b>	:CALC:NFLO -55.0 DB :CALC:NFLO? returns -5.500000000E+001



**:CALCulate:NFLOor:STATe**

<b>Description</b>	This command makes the noise level visible/invisible on graph. The corresponding GUI setting is <b>Noise level visible on page 157</b> .
<b>Applicability</b>	This command is only available if :CALCulate:MODE on page 325 is set to PCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:NFLOor:STATe<wsp><state>
<b>Parameter(s)</b>	<i>state</i> : State of the noise level visibility. The allowed values are: 0 OFF: makes the noise level invisible on graph. 1 ON: makes the noise level visible on graph.
<b>Example(s)</b>	:CALC:NFLO:STAT ON

**:CALCulate:NFLOor:STATe?**

<b>Description</b>	This query returns the analysis noise floor visibility.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:NFLOor:STATe?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : State of the noise level visibility: 0: the noise level is not visible on graph. 1: the noise level is visible on graph.
<b>Example(s)</b>	:CALC:NFLO:STAT ON :CALC:NFLO:STAT? returns 1

:CALCulate:SOURce	
<b>Description</b>	This command selects the trace to analyze in PCT analysis mode.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:SOURce<wsp><category>[,<trace>,<channel>,<type>]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>category</i>: Category of the trace to analyze: 0 NONE: no trace is selected for analysis. 1 SENse: trace linked to a measuring connector. 2 STORE: stored trace.</li> <li>➤ <i>trace</i>: For SENse traces: integer corresponding to the module identification number, which is the position of the module in the mainframe from left to right, in the range 1 to 10. For STORE traces: integer corresponding to the store trace identifier, in the range 1 to 20. To know the store trace identifier, use the command :TRACE:LIST:STORE? on page 507.</li> <li>➤ <i>channel</i>: For SENse traces only: integer corresponding to the detector identification number, which is the detector position on the module from top to bottom, in the range 1 to 6. This number is not taken into account for BR traces.</li> <li>➤ <i>type</i>: For SENse traces only: integer corresponding to the trace type, in the range 1 to 10 and 14 to 18: 1: TF live 2: TF max 3: TF min 4: TF average 5: TF roll average 6: BR live (only available on an IL RL OPM2 module) 7: BR max (only available on an IL RL OPM2 module) 8: BR min (only available on an IL RL OPM2 module) 9: BR average (only available on an IL RL OPM2 module) 10: BR roll average (only available on an IL RL OPM2 module) 14: PDL live (only available on an IL PDL or IL PDL OPM2 module) 15: PDL max (only available on an IL PDL or IL PDL OPM2 module) 16: PDL min (only available on an IL PDL or IL PDL OPM2 module) 17: PDL average (only available on an IL PDL or IL PDL OPM2 module) 18: PDL roll average (only available on an IL PDL or IL PDL OPM2 module)</li> </ul>
<b>Example(s)</b>	:CALC:SOUR 1,2,5,3

**:CALCulate:SOURce?**

<b>Description</b>	This query returns the trace selected for PCT analysis.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:SOURce?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>[,<trace>,<channel>,<type>]
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>category</i>: Category of the trace to analyze: 0 NONE: no trace is selected for analysis. 1 SENse: trace linked to a measuring connector. 2 STORe: stored trace.</li> <li>➤ <i>trace</i>: For SENse traces: integer corresponding to the module identification number, which is the position of the module in the mainframe from left to right. For STORe traces: integer corresponding to the store trace identifier, in the range 1 to 20. The store trace name corresponding to the identifier is available with the command :TRACe:LIST:STORe? on page 507.</li> <li>➤ <i>channel</i>: Integer corresponding to the detector identification number, which is the detector position on the module from top to bottom, in the range 1 to 6. On BR traces, this number is not significant (empty). For STORe traces, this number is 0.</li> <li>➤ <i>type</i>: For SENSe traces: Integer corresponding to the trace type, in the range 1 to 10 and 14 to 18: 1: TF live 2: TF max 3: TF min 4: TF average 5: TF roll average 6: BR live (only available on an IL RL OPM2 module) 7: BR max (only available on an IL RL OPM2 module) 8: BR min (only available on an IL RL OPM2 module) 9: BR average (only available on an IL RL OPM2 module) 10: BR roll average (only available on an IL RL OPM2 module) 14: PDL live (only available on an IL PDL or IL PDL OPM2 module) 15: PDL max (only available on an IL PDL or IL PDL OPM2 module) 16: PDL min (only available on an IL PDL or IL PDL OPM2 module) 17: PDL average (only available on an IL PDL or IL PDL OPM2 module) 18: PDL roll average (only available on an IL PDL or IL PDL OPM2 module) For STORe traces: 0.</li> </ul>
<b>Example(s)</b>	:CALC:SOUR 2,15 :CALC:SOUR? returns 2,15,0,0

<b>:CALCulate:SOURce:MULTitraces</b>	
<b>Description</b>	This command enables you to select the trace(s) you want to analyze in PCT WDM analysis mode.
<b>Applicability</b>	This command is only available on TF and BR trace types; PDL traces cannot be selected for analysis in PCT WDM mode.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:SOURce:MULTitraces<wsp> <category>,<trace>,[<channel>,<type>]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>category</i>: Category of the trace to analyze: 0 NONE: clears all traces selected for analysis. 1 SENse: trace linked to a measuring connector. 2 STORE: stored trace.</li> <li>➤ <i>trace</i>: For SENse traces: integer corresponding to the module identification number, which is the position of the module in the mainframe from left to right, in the range 1 to 20. For STORE traces: integer corresponding to the store trace identifier, in the range 1 to 20. To know the store trace identifier, use the command :TRACE:LIST:STORE? on page 507.</li> <li>➤ <i>channel</i>: For SENse traces only: integer corresponding to the detector identification number, which is the detector position on the module from top to bottom, in the range 1 to 6. This number is not taken into account for BR traces.</li> <li>➤ <i>type</i>: For SENse traces only: integer corresponding to the trace type, in the range 1 to 10 (TF and BR traces only): 1: TF live 2: TF max 3: TF min 4: TF average 5: TF roll average 6: BR live (only available on an IL RL OPM2 module) 7: BR max (only available on an IL RL OPM2 module) 8: BR min (only available on an IL RL OPM2 module) 9: BR average (only available on an IL RL OPM2 module) 10: BR roll average (only available on an IL RL OPM2 module)</li> </ul>
<b>Example(s)</b>	:CALC:SOUR:MULT 1,2,5,2 :CALC:SOUR:MULT 1,2,5,3 :CALC:SOUR:MULT 1,2,3,4 :CALC:SOUR:MULT 2,42

**:CALCulate:SOURce:MULTitraces?**

<b>Description</b>	This query returns the trace selected for the PCT WDM analysis.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:CALCulate:SOURce:MULTitraces?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<category>,<trace>,<channel>,<type>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>category</i>: Category of the trace to analyze: 0 NONE: no trace is selected for analysis. 1 SENse: trace linked to a measuring connector. 2 STORe: stored trace.</li> <li>➤ <i>trace</i>: For SENse traces: integer corresponding to the module identification number, which is the position of the module in the mainframe from left to right. For STORe traces: integer corresponding to the store trace identifier, in the range 1 to 20. The store trace name corresponding to the identifier is available with the command :TRACe:LIST:STORe? on page 507.</li> <li>➤ <i>channel</i>: For SENse traces: integer corresponding to the detector identification number, which is the detector position on the module from top to bottom, in the range 1 to 6. On BR traces, this number is not significant (empty). For STORe traces, this number is 0.</li> <li>➤ <i>type</i>: For SENse traces: integer corresponding to the trace type, in the range 1 to 10 and 14 to 18: 1: TF live 2: TF max 3: TF min 4: TF average 5: TF roll average 6: BR live (only available on an IL RL OPM2 module) 7: BR max (only available on an IL RL OPM2 module) 8: BR min (only available on an IL RL OPM2 module) 9: BR average (only available on an IL RL OPM2 module) 10: BR roll average (only available on an IL RL OPM2 module) For STORe traces: 0.</li> </ul>
<b>Example(s)</b>	:CALC:SOUR:MULT 1,2,5,2 :CALC:SOUR:MULT 1,2,5,3 :CALC:SOUR:MULT 1,2,3,4 :CALC:SOUR:MULT 2,42 :CALC:SOUR:MULT? returns 1,2,5,2<lf>1,2,5,3<lf>1,2,3,4<lf>2,42,0,0<cr><lf>

## CALCulate:DATA Queries

### Quick Reference

Command Overview					Parameter(s)	Section
CALCulate	DATA	[ALL]?				see p. 333
		LOSS?				see p. 334
		NW1?				see p. 335
		NW2?				see p. 336
		NW3				see p. 336
		PBAND?				see p. 337
		PTSearch	[LIST]?			see p. 338
			MAIN	PEAK?		see p. 339
				TRO?		see p. 339
		SBAND?				see p. 340
		SW1?				see p. 341
		SW2?				see p. 342
		SW3?				see p. 343
		WDM	[:ALL]	CHANnel?		see p. 344
				IMEASurement?		see p. 349
				PDL?		see p. 346
				SW?		see p. 347
			CH	CHANnel?	<channel>	see p. 348
				IMEASurement?	<channel>	see p. 349
				PDL?		see p. 350
				SW?		see p. 351
			NCHannels?			see p. 352
			SLOPe?			see p. 353
			UNIFORMity?			see p. 353

The unit returned depends on the unit settings (see *UNIT Commands and Queries* on page 533). The results headers WL (in meter) becomes FREQ when in Hertz.

All results are expressed in base unit (e.g. M|HZ)

## Commands and Queries

<b>:CALCulate:DATA[:ALL]?</b>	
<b>Description</b>	This query collects all analysis results available in PCT or PCT WDM analysis mode, grouped by analysis tools.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA[:ALL]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<results from PTSearch tool>, <results from activated tools>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>results from PTSearch tool:</i> Result of the :CALC:DATA:PTS? query. See :CALCulate:DATA:PTSearch[:LIST]? on page 338 for more details.</li> <li>➤ <i>results from activated analysis tools:</i> Result from all analysis tools corresponding to the component under test that have been activated using the command :CALCulate:PARAMeters:CSElector:TYPE on page 360.</li> </ul>
<b>Example(s)</b>	:CALC:DATA? returns 2, 3, PEAKWAVELENGTH, M, PEAKPOWER, DBM, TROUGHWAVELENGTH, M, TROUGHPOWER, DBM, +1.53033000E-006, +1.52950600E-006, -1.14000000E+001, -1.15200000E+001, +1.53386800E-006, +1.53007200E-006, +1.52774400E-006, -6.40100000E+001, -6.42600000E+001, -6.45200000E+001, NBROFCHANNELS, 2, , SLOPE, +1.55800000E+008, DB/M, UNIFORMITY, +1.30000000E-001, DB, CH, NBR, WL_GRID, M, WL_MEAS, M, LVL_MEAS, DBM, DWLTOGRID, M, NOISE, DBM, OSNR, DB, 196, 197, +1.52995150E-006, +1.52917110E-006, +1.53033120E-006, +1.52950700E-006, -1.14200000E+001, -1.15500000E+001, +3.79700000E-010, +3.35900000E-010, -7.00700000E+001, -6.97500000E+001, +5.25400000E+001, +5.23400000E+001

**:CALCulate:DATA:LOSS?**

<b>Description</b>	This query returns the results of the Loss Measurement analysis tool (for more details, see <i>Setting Up Loss Measurement Analysis</i> on page 192).
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to PCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:LOSS?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	LOSS MEASUREMENT RESULTS, AVERAGELOSSDB<Value>,<Unit>,UNIFORMITY,<Value>,<Unit>
<b>Response(s)</b>	The analysis results are described in <i>Setting Up Loss Measurement Analysis</i> on page 192.
<b>Example(s)</b>	:CALC:DATA:LOSS? returns LOSS MEASUREMENT RESULTS , AVERAGELOSSDB , -7.00000000E-001 , DBM , UNIFORMITY , +1.10000000E-001, DB

---



**:CALCulate:DATA:NW1?**

<b>Description</b>	This query returns the results of the Notch Width 1 analysis tool (for more details, see <i>Analyzing Notch Width Results</i> on page 177).
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to PCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:NW1?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	NOTCH WIDTH 1 RESULTS, WL_TROUGH,<value>,<unit>,LEVEL_THOUGH,<value>,<unit>, WL_NOTCH,<value>,<unit>,LEVEL_NOTCH,<value>,<unit> DWL_NOTCH,<value>,<unit>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing Notch Width Results</i> on page 177.
<b>Example(s)</b>	:CALC:DATA:NW1? returns NOTCH WIDTH 1 RESULTS, WL_TROUGH,+1.54667800E-006,M,LEVEL_TROUGH,-3.65700000E+001,DBM, WL_NOTCH,+1.54669440E-006,M,LEVEL_NOTCH,-3.65600000E+001,DBM, DWL_NOTCH_3dB,+5.93161000E-008,M

---

**:CALCulate:DATA:NW2?**

<b>Description</b>	This query returns the results of the Notch Width 2 analysis tool (for more details, see <i>Analyzing Notch Width Results</i> on page 177).
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to PCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:NW2?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	NOTCH WIDTH 2 RESULTS, WL_NOTCH,<value>,<unit>,LEVEL_NOTCH,<value>,<unit>D WL_NOTCH,<value>,<unit>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing Notch Width Results</i> on page 177.
<b>Example(s)</b>	:CALC:DATA:NW2? returns NOTCH WIDTH 2 RESULTS,WL_NOTCH,+1.54669440E-006,M,LEVEL_NOTCH,-3.656 00000E+001,DBM,DWL_NOTCH_1dB,+5.93161000E-008,M

**:CALCulate:DATA:NW3?**

<b>Description</b>	This query returns the results of the Notch Width 3 analysis tool (for more details, see <i>Analyzing Notch Width Results</i> on page 177).
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to PCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:NW3?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	NOTCH WIDTH 3 RESULTS, WL_NOTCH,<value>,<unit>,LEVEL_NOTCH,<value>,<unit>D WL_NOTCH,<value>,<unit>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing Notch Width Results</i> on page 177.
<b>Example(s)</b>	:CALC:DATA:NW3? returns NOTCH WIDTH 3 RESULTS,WL_NOTCH,+1.54669440E-006,M,LEVEL_NOTCH,-3.656 00000E+001,DBM,DWL_NOTCH_20dB,+5.93161000E-008,M

**:CALCulate:DATA:PBAND?**

<b>Description</b>	This query returns the results of the Pass Band analysis tool (for more details, see <i>Analyzing Pass Band Test Results</i> on page 183).
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to PCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:PBAND?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<p>PASSBANDTESTRESULTS(NOISELIMITED), IN-BANDRESULTS, , , AVGLOSS, &lt;Value&gt;, &lt;Unit&gt;, RIPPLE, &lt;Value&gt;, &lt;Unit&gt;, SLOPE, &lt;Value&gt;, &lt;Unit&gt;, OUT-BANDSIDE1RESULTS, , , AVGLOSS, &lt;Value&gt;, &lt;Unit&gt;, RIPPLE, &lt;Value&gt;, &lt;Unit&gt;, CROSSTALK, &lt;Value&gt;, &lt;Unit&gt;, ROLLOFF@X.XDB&lt;Value&gt;, &lt;Unit&gt;, ROLLOFF_MAX_, &lt;Value&gt;, &lt;Unit&gt;, WL@ROLLOFF_MAX_, &lt;Value&gt;, &lt;Unit&gt;, TRANSITIONBAND, &lt;Value&gt;, &lt;Unit&gt;, OUT-BANDSIDE2RESULTS, , , AVGLOSS, &lt;Value&gt;, &lt;Unit&gt;, RIPPLE, &lt;Value&gt;, &lt;Unit&gt;, CROSSTALK, &lt;Value&gt;, &lt;Unit&gt;, ROLLOFF@X.XDB, &lt;Value&gt;, &lt;Unit&gt;, ROLLOFF_MAX_, &lt;Value&gt;, &lt;Unit&gt;, WL@ROLLOFF_MAX_, &lt;Value&gt;, &lt;Unit&gt;, TRANSITIONBAND, &lt;Value&gt;, &lt;Unit&gt;</p> <p>NOISELIMITED only appears if the measurement is limited by noise.</p>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing Pass Band Test Results</i> on page 183.
<b>Example(s)</b>	<p>:CALC:DATA:PBAND? returns</p> <p>PASSBANDTESTRESULTS, IN-BANDRESULTS, , , AVGLOSS, 1.92000000E+000, DB, RIPPLE, 0.00000000E+000, DB, SLOPE, 1.95000000E-002, DB/NM, OUT-BANDSIDE1RESULTS, , , AVGLOSS, 6.50900000E+001, DB, RIPPLE, 4.19000000E+000, DB, CROSSTALK, 6.31100000E+001, DB, ROLLOFF@3.00DB, 8.46260000E+000, DB/NM, ROLLOFF_MAX_, 1.14789000E+001, DB/NM, WL@ROLLOFF_MAX_, 1.56004200E-006, M, TRANSITIONBAND, 1.54600000E-009, M, OUT-BANDSIDE2RESULTS, , , AVGLOSS, 6.31000000E+001, DB, RIPPLE, 1.99000000E+000, DB, CROSSTALK, 6.07400000E+001, DB, ROLLOFF@3.00DB, -8.77800000E+000, DB/NM, ROLLOFF_MAX_, -1.17777000E+001, DB/NM, WL@ROLLOFF_MAX_, 1.57951910E-006, M, TRANSITIONBAND, 1.54400000E-009, M, , ,</p>

**:CALCulate:DATA:PTSearch[:LIST]?**

<b>Description</b>	This query returns the wavelength/frequency and power level of all found peaks and troughs.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:PTSearch[:LIST]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<p>&lt;number of peaks&gt;, &lt;number of troughs&gt;,  PEAKWAVELENGTH,&lt;unit&gt;,PEAKPOWER,&lt;unit&gt;,TROUHWAVELENGTH,&lt;unit&gt;,TROUHPPOWER,&lt;unit&gt;,{&lt;peak wavelength&gt;},{&lt;peak power level&gt;},{&lt;trough wavelength&gt;},{&lt;trough power level&gt;}</p> <p>OR (depending on the unit setting :UNIT:X on page 533):</p> <p>&lt;number of peaks&gt;, &lt;number of troughs&gt;,  PEAKFREQ,&lt;unit&gt;,PEAKPOWER,&lt;unit&gt;,TROUHFREQ,&lt;unit&gt;,TROUHPPOWER,&lt;unit&gt;,{&lt;peak frequency&gt;},{&lt;peak power level&gt;},{&lt;trough frequency&gt;},{&lt;trough power level&gt;}</p>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>number of peaks/troughs:</i>  Number of detected peaks/troughs, according to the parameters set for the PT Search tool.</li> <li>➤ <i>unit:</i>  Unit set (see <i>UNIT Commands and Queries</i> on page 533).</li> <li>➤ <i>peak/trough wavelength/frequency:</i>  Measured wavelength or frequency for each detected peak and trough.</li> <li>➤ <i>peak/trough power level:</i>  Measured power level for each detected peak and trough.</li> </ul>
<b>Example(s)</b>	<p>:CALC:DATA:PTS? returns</p> <p>2,3,PEAKWAVELENGTH,M,PEAKPOWER,DBM,TROUHWAVELENGTH,M,TROUHPPOWER,DBM,+1.53033000E-006,+1.52950600E-006,-1.14000000E+001,-1.15200000E+001,+1.53386800E-006,+1.53007200E-006,+1.52774400E-006,-6.40100000E+001,-6.42600000E+001,-6.45200000E+001</p>

**:CALCulate:DATA:PTSearch:MAIN:PEAK?**

<b>Description</b>	This query returns the wavelength/frequency and power level of the peak with the highest power.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:PTSearch:MAIN:PEAK?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<peak wavelength or frequency>, <peak power level>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>peak wavelength or frequency:</i> Wavelength (in meters) or frequency (in Hertz) of the peak with the highest power.</li> <li>➤ <i>peak power level:</i> Power level of the peak with the highest power in dB or Ratio, depending on the unit setting (set with command :UNIT:Y on page 534).</li> </ul>
<b>Example(s)</b>	:CALC:DATA:PTS:MAIN:PEAK? returns +1.52950600E-006,-1.15200000E+001

**:CALCulate:DATA:PTSearch:MAIN:TROugh?**

<b>Description</b>	This query returns the wavelength/frequency and power level of the trough with the lower power.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:PTSearch:MAIN:TROugh?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<trough wavelength or frequency>, <trough power level>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>peak wavelength or frequency:</i> Wavelength (in meters) or frequency (in Hertz) of the trough with the lowest power.</li> <li>➤ <i>peak power level:</i> Power level of the trough with the lowest power in dB or Ratio, depending on the unit setting (set with command :UNIT:Y on page 534).</li> </ul>
<b>Example(s)</b>	:CALC:DATA:PTS:MAIN:TRO? returns +1.52774400E-006,-6.45200000E+001

**:CALCulate:DATA:SBAND?**

<b>Description</b>	This query returns the results of the Stop Band analysis tool (for more details, see <i>Analyzing Stop Band Test Results</i> on page 189).
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to PCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:SBAND?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<p>STOPBANDTESTRESULTS(NOISELIMITED), IN-BANDRESULTS, , , AVGLOSS, &lt;Value&gt;, &lt;Unit&gt;, RIPPLE, &lt;Value&gt;, &lt;Unit&gt;, SLOPE, &lt;Value&gt;, &lt;Unit&gt;, OUT-BANDSIDE1RESULTS, , , AVGLOSS, &lt;Value&gt;, &lt;Unit&gt;, RIPPLE, &lt;Value&gt;, &lt;Unit&gt;, ISOLATIONDEPTH, &lt;Value&gt;, &lt;Unit&gt;, ROLLOFF@X.XDB&lt;Value&gt;, &lt;Unit&gt;, ROLLOFF_MAX_, &lt;Value&gt;, &lt;Unit&gt;, WL@ROLLOFF_MAX_, &lt;Value&gt;, &lt;Unit&gt;, TRANSITIONBAND, &lt;Value&gt;, &lt;Unit&gt;, OUT-BANDSIDE2RESULTS, , , AVGLOSS, &lt;Value&gt;, &lt;Unit&gt;, RIPPLE, &lt;Value&gt;, &lt;Unit&gt;, ISOLATIONDEPTH, &lt;Value&gt;, &lt;Unit&gt;, ROLLOFF@X.XDB, &lt;Value&gt;, &lt;Unit&gt;, ROLLOFF_MAX_, &lt;Value&gt;, &lt;Unit&gt;, WL@ROLLOFF_MAX_, &lt;Value&gt;, &lt;Unit&gt;, TRANSITIONBAND, &lt;Value&gt;, &lt;Unit&gt;</p> <p>NOISELIMITED only appears if the measurement is limited by noise.</p>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing Stop Band Test Results</i> on page 189.
<b>Example(s)</b>	<p>:CALC:DATA:SBAND? returns</p> <p>STOPBANDTESTRESULTS, IN-BANDRESULTS, , , AVGLOSS, 5.24300000E+001, DB, RIPPLE, 2.15000000E+000, DB, SLOPE, -2.58390000E+000, DB/NM, OUT-BANDSIDE1RESULTS, , , AVGLOSS, 3.17800000E+001, DB, RIPPLE, 0.00000000E+000, DB, ISOLATIONDEPTH, 6.63900000E+001, DB, ROLLOFF@3.00DB, -9.03320000E+000, DB/NM, ROLLOFF_MAX_, -1.94365000E+001, DB/NM, WL@ROLLOFF_MAX_, 1.53869150E-006, M, TRANSITIONBAND, 1.30300000E-009, M, OUT-BANDSIDE2RESULTS, , , AVGLOSS, 1.90600000E+001, DB, RIPPLE, 1.60000000E-001, DB, ISOLATIONDEPTH, 3.45400000E+001, DB, ROLLOFF@3.00DB, 1.37286000E+001, DB/NM, ROLLOFF_MAX_, 2.49708000E+001, DB/NM, WL@ROLLOFF_MAX_, 1.54124660E-006, M, TRANSITIONBAND, 8.45000000E-010, M, , , -,</p>

**:CALCulate:DATA:SW1?**

<b>Description</b>	This query returns the results of the Spectral Width 1 analysis toolused in PCT analysis mode (for more details, see <i>Analyzing Spectral Width Results</i> on page 174).
<b>Applicability</b>	This query is only available if :CALCulate:MODE on page 325 is set to PCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:SW1?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	For Threshold, Envelope, Gaussian Fit and Lorentzian Fit Algorithm: SPECTRAL WIDTH 1 RESULTS,WL_PEAK,<value>,<unit>, LEVEL_PEAK,<value>,<unit>,WL_MEAN,<value>,<unit>, LEVEL_MEAN,<value>,<unit>,DWL,<value>,<unit> For RMS and RMS Peak Algorithm: SPECTRAL WIDTH 1 RESULTS,WL_PEAK,<value>,<unit>, LEVEL_PEAK,<value>,<unit>,WL_MEAN,<value>,<unit>, LEVEL_MEAN,<value>,<unit>,SIGMA,<value>,<unit>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing Spectral Width Results</i> on page 174.
<b>Example(s)</b>	:CALC:DATA:SW1? returns SPECTRAL WIDTH 1 RESULTS, WL_PEAK,+1.54547800E-006,M,LEVEL_PEAK,-9.12000000E-001,DBM,WL_MEAN,+1.54547100E-006,M,LEVEL_MEAN,-9.10000000E-001,DBM,DWL@3.00DB,+1.02800000E-010,M

<b>:CALCulate:DATA:SW2?</b>	
<b>Description</b>	This query returns the results of the Spectral Width 2 analysis tool used in PCT analysis mode (for more details, see <i>Analyzing Spectral Width Results</i> on page 174).
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to PCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:SW2?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	For Threshold, Envelope, Gaussian Fit and Lorentzian Fit Algorithm: SPECTRAL WIDTH 2 RESULTS,WL_MEAN,<value>,<unit>, LEVEL_MEAN,<value>,<unit>,DWL,<value>,<unit> For RMS and RMS Peak Algorithm: SPECTRAL WIDTH 2 RESULTS,WL_MEAN,<value>,<unit>, LEVEL_MEAN,<value>,<unit>,SIGMA,<value>,<unit>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing Spectral Width Results</i> on page 174.
<b>Example(s)</b>	:CALC:DATA:SW2? returns SPECTRAL WIDTH 2 RESULTS,WL_MEAN,+1.54547100E-006,M,LEVEL_MEAN,-9.100000 00E-001,DBM,DWL@1.00DB,+1.02800000E-010,M



**:CALCulate:DATA:SW3?**

<b>Description</b>	This query returns the results of the Spectral Width 3 analysis tool used in PCT analysis mode (for more details, see <i>Analyzing Spectral Width Results</i> on page 174).
<b>Applicability</b>	This query is only available if :CALCulate:MODE on page 325 is set to PCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:SW3?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	For Threshold, Envelope, Gaussian Fit and Lorentzian Fit Algorithm: SPECTRAL WIDTH 2 RESULTS,WL_MEAN,<value>,<unit>, LEVEL_MEAN,<value>,<unit>,DWL,<value>,<unit> For RMS and RMS Peak Algorithm: SPECTRAL WIDTH 2 RESULTS,WL_MEAN,<value>,<unit>, LEVEL_MEAN,<value>,<unit>,SIGMA,<value>,<unit>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing Spectral Width Results</i> on page 174.
<b>Example(s)</b>	:CALC:DATA:SW3? returns SPECTRAL WIDTH 3 RESULTS,WL_MEAN,+1.54547100E-006,M,LEVEL_MEAN,-9.100000 00E-001,DBM,DWL@20.00DB,+1.02800000E-010,M

**:CALCulate:DATA:WDM[:ALL]:CHANnel?**

<b>Description</b>	This query returns the results of the Channel Detection analysis tool (for more details, see <i>Analyzing Channel Detection Results</i> on page 166) for all analyzed traces.
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:WDM[:ALL]:CHANnel?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	CH,NBR,TRACE#,ID,WL_GRID,<Unit>,WL_CHAN,<Unit>,DWL,<Unit>,<Unit>,IL_GRID,<Unit>,IL_CHAN,<Unit>,{<WDM Channel Number>},{<Trace ID value>},{<WL Grid Value>},{<WL chan value>},{<DWL value>},{<IL Grid value>},{<IL Chan value>} where <Trace ID value> consists of 4 digits separated by semicolons: <ul style="list-style-type: none"> <li>➤ First digit: 1 for measured trace, 2 for Store type trace.</li> <li>➤ Second digit: module identification number, which is the position of the module in the mainframe from left to right (if first digit is 1) or Store trace number (if first digit is 2). To know the store trace identifier, use the command <i>:TRACE:LIST:STORE?</i> on page 507.</li> <li>➤ Third digit: detector identification number, which is the detector position on the module from top to bottom (if first digit is 1) or 0 (if first digit is 2).</li> <li>➤ Fourth digit: trace type (if first digit is 1) or 0 (if first digit is 2).</li> </ul>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing Channel Detection Results</i> on page 166.
<b>Example(s)</b>	:CALC:DATA:WDM:CHAN? returns CH,NBR,TRACE#,ID,WL_GRID,M,WL_CHAN,M,DWL,M,IL_GRID,DB,IL_CHAN,DB,2,3,1;3;2;1,1;5;1;1,+1.29100000E-006,+1.31100000E-006,+1.28977000E-006,+1.30990380E-006,-1.23000000E-009,-1.09620000E-009,-6.50000000E-001,-6.80000000E-001,-6.50000000E-001,-6.50000000E-001 This response corresponds to the following table:

CH	TRACE#	WL_GRID	WL_CHAN	DWL	IL_GRID	IL_CHAN
NBR	ID	M	M	M	M	DB
2	1;3;2;1	+1.29100000E-006	+1.28977000E-006	-1.23000000E-009	-6.50000000E-001	-6.50000000E-001
3	1;5;1;1	+1.31100000E-006	+1.30990380E-006	-1.09620000E-009	-6.80000000E-001	-6.50000000E-001

**:CALCulate:DATA:WDM[:ALL]:IMEASurement?**

<b>Description</b>	This query returns the results of the WDM Filter Test analysis tool (for more details, see <i>Analyzing WDM Filter Test Results</i> on page 191) for all analyzed traces.
<b>Applicability</b>	This query is only available if <code>:CALCulate:MODE</code> on page 325 is set to WPCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	<code>:CALCulate:DATA:WDM[:ALL]:IMEASurement?</code>
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	CH,NBR,TRACE#,ID,SLOPE,<Slope unit>,RIPPLE,<Ripple unit>,ADJ.ISO.,<Adjacent Isolation unit>,NON-ADJ.ISO.,<Non Adjacent Isolation unit>,TOTALXTALK,<Total Crosstalk unit>,{<WDM Channel Number >},{<Trace ID value>},{<Slope value>},{<Ripple value>},{<Adjacent Isolation value>},{<Non Adjacent Isolation value>},{<Total Crosstalk value>} where <Trace ID value> consists of 4 digits separated by semicolons: <ul style="list-style-type: none"> <li>➤ First digit: 1 for measured trace, 2 for Store type trace.</li> <li>➤ Second digit: module identification number, which is the position of the module in the mainframe from left to right (if first digit is 1) or Store trace number (if first digit is 2). To know the store trace identifier, use the command <code>:TRACe:LIST:STORe?</code> on page 507.</li> <li>➤ Third digit: detector identification number, which is the detector position on the module from top to bottom (if first digit is 1) or 0 (if first digit is 2).</li> <li>➤ Fourth digit: trace type (if first digit is 1) or 0 (if first digit is 2).</li> </ul>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing WDM Filter Test Results</i> on page 191.
<b>Example(s)</b>	<code>:CALC:DATA:WDM:IMEAS?</code> returns CH, NBR, TRACE#, ID, SLOPE, DB/NM, RIPPLE, DB, ADJ.ISO., DB, NON-ADJ.ISO., DB, TOTALXTALK, DB, 2, 3, 1;3;2;1, 1;5;1;1, +1.2100000E-002, -1.0480000E-001, +0.0000000E+000, +1.0000000E-002, +6.2890000E+001, +6.4600000E+001, +6.2970000E+001, +6.4970000E+001, +5.6950000E+001, +5.9160000E+001

This response corresponds to the following table:

CH	TRACE#	SLOPE	RIPPLE	ADJ.ISO.	NON-ADJ.ISO.	TOTALXTALK
NBR	ID	DB/NM	DB/NM	DB	DB	DB
2	1;3;2;1	+1.2100000E-002	+0.0000000E+000	+6.2890000E+001	+6.2970000E+001	+5.6950000E+001
3	1;5;1;1	-1.0480000E-001	+1.0000000E-002	+6.4600000E+001	+6.4970000E+001	+5.9160000E+001

**:CALCulate:DATA:WDM[:ALL]:PDL?**

<b>Description</b>	This query returns the results of the <b>PDL Analysis</b> analysis tool (for more details, see <i>Analyzing PDL Analysis Results</i> on page 168) for all analyzed traces.
<b>Applicability</b>	This query is only available if <b>:CALCulate:MODE</b> on page 325 is set to WPCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:WDM[:ALL]:PDL?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	CH,NBR,TRACE#,ID,PDL_GRID,<PDL unit>,PDL_CHAN,<PDL unit>,PDL_MAX,<PDL unit>,{<WDM Channel Number>},{<Trace ID value>},{<PDLGrid value>},{<PDLChan value>},{<PDLMax value>} where <Trace ID value> consists of 4 digits separated by semicolons: <ul style="list-style-type: none"> <li>➤ First digit: 1 for measured trace, 2 for Store type trace.</li> <li>➤ Second digit: module identification number, which is the position of the module in the mainframe from left to right (if first digit is 1) or Store trace number (if first digit is 2). To know the store trace identifier, use the command <b>:TRACE:LIST:STORE?</b> on page 507.</li> <li>➤ Third digit: detector identification number, which is the detector position on the module from top to bottom (if first digit is 1) or 0 (if first digit is 2).</li> <li>➤ Fourth digit: trace type (if first digit is 1) or 0 (if first digit is 2).</li> </ul>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing PDL Analysis Results</i> on page 168.
<b>Example(s)</b>	:CALC:DATA:WDM:PDL? returns CH,NBR,TRACE#,ID,PDL_GRID,DB,PDL_CHAN,DB,PDL_MAX,DB,13,14,1;5;1;1,1;5;1;2,+8.00000000E-002,+8.00000000E-002,+3.80000000E-001,+7.00000000E-002,+8.00000000E-002,+8.00000000E-002 This response corresponds to the following table:

CH	TRACE#	PDL_GRID	PDL_CHAN	PDL_MAX
NBR	ID	DB	DB	DB
13	1;5;1;1	+8.00000000E-002	+3.80000000E-001	+8.00000000E-002
14	1;5;1;2	+8.00000000E-002	+7.00000000E-002	+8.00000000E-002

**:CALCulate:DATA:WDM[:ALL]:SW?**

<b>Description</b>	This query returns the results of the Spectral Width 1; Spectral Width 2 and Spectral Width 3 analysis tools used in PCT WDM analysis mode (for more details, see <i>To define the Spectral Width parameters in PCT WDM Analysis mode</i> : on page 173) for all analyzed traces.
<b>Applicability</b>	This query is only available if :CALCulate:MODE on page 325 is set to WPCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:WDM[:ALL]:SW?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	CH,NBR,TRACE#,ID,DWL1@xx.xxdB,<Unit>,DWL2@yy.yydB,<Unit>,<Unit>,DWL2@zz.zzdB,<Unit>,{<WDM Channel Number Value>},{<Trace ID Value>},{<WL1@xx.xxdB value>},{<WL2@yy.yydB value>},{<WL3@zz.zzdB value>} where <Trace ID value> consists of 4 digits separated by semicolons: <ul style="list-style-type: none"> <li>➤ First digit: 1 for measured trace, 2 for Store type trace.</li> <li>➤ Second digit: module identification number, which is the position of the module in the mainframe from left to right (if first digit is 1) or Store trace number (if first digit is 2). To know the store trace identifier, use the command :TRACe:LIST:STORe? on page 507.</li> <li>➤ Third digit: detector identification number, which is the detector position on the module from top to bottom (if first digit is 1) or 0 (if first digit is 2).</li> <li>➤ Fourth digit: trace type (if first digit is 1) or 0 (if first digit is 2).</li> </ul>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing WDM Filter Test Results</i> on page 191.
<b>Example(s)</b>	:CALC:DATA:WDM:SW? returns CH,NBR,TRACE#,ID,DWL1@1.00DB,M,DWL2@3.00DB,M,DWL3@20.00DB,M,2,3,1;3;2;1,1;5;1;1,+1.69607000E-008,+1.70329000E-008,+1.75082000E-008,+1.76346000E-008,+2.00912000E-008,+2.04797000E-008

This response corresponds to the following table:

CH	TRACE#	DWL1@1.00DB	DWL2@3.00DB	DWL3@20.00DB
NBR	ID	M	M	M
2	1;3;2;1	+1.69607000E-008	+1.75082000E-008	+2.00912000E-008
3	1;5;1;1	+1.70329000E-008	+1.76346000E-008	+2.04797000E-008

**:CALCulate:DATA:WDM:CH:CHANnel?**

<b>Description</b>	This query returns the results of the Channel Detection analysis tool (for more details, see <i>Analyzing Channel Detection Results</i> on page 166) for the given grid channel.
<b>Applicability</b>	This query is only available if <code>:CALCulate:MODE</code> on page 325 is set to WPCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	<code>:CALCulate:DATA:WDM:CH:CHANnel?&lt;wsp&gt;&lt;channel&gt;</code>
<b>Parameter(s)</b>	<i>channel</i>  Integer corresponding to the grid channel number from which you want to get the results.
<b>Response Syntax</b>	CH,NBR,TRACE#,ID,WL_GRID,<Unit>,WL_CHAN,<Unit>,DWL,<Unit>,IL_GRID,<Unit>,IL_CHAN,<Unit>,{<WDM Channel number>},{<Trace ID value>},{<WL Grid value>},{<WL chan value>},{<DWL value>},{<IL Grid value>},{<IL Chan value>} where <Trace ID value> consists of 4 digits separated by semicolons: <ul style="list-style-type: none"> <li>➤ First digit: 1 for measured trace, 2 for Store type trace.</li> <li>➤ Second digit: module identification number, which is the position of the module in the mainframe from left to right (if first digit is 1) or Store trace number (if first digit is 2). To know the store trace identifier, use the command <code>:TRACE:LIST:STORE?</code> on page 507.</li> <li>➤ Third digit: detector identification number, which is the detector position on the module from top to bottom (if first digit is 1) or 0 (if first digit is 2).</li> <li>➤ Fourth digit: trace type (if first digit is 1) or 0 (if first digit is 2).</li> </ul>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing Channel Detection Results</i> on page 166.
<b>Example(s)</b>	<code>:CALC:DATA:WDM:CH:CHAN? 194</code> returns CH,NBR,TRACE#,ID,WL_GRID,M,WL_CHAN,M,DWL,M,IL_GRID,DB,I L_CHAN,DB,2,1;3;2;1,+1.29100000E-006,+1.28977000E-006,-1.23000 000E-009,-6.50000000E-001,-6.50000000E-001  This response corresponds to the following table:

CH	TRACE#	WL_GRID	WL_CHAN	DWL	IL_GRID	IL_CHAN
NBR	ID	M	M	M	DB	DB
2	1;3;2;1	+1.291000 00E-006	+1.289770 00E-006	-1.2300000 0E-009	-6.5000000 0E-001	-6.5000000 0E-001

**:CALCulate:DATA:WDM:CH:IMEASurement?**

<b>Description</b>	This query returns the results of the WDM Filter Test analysis tool (for more details, see <i>Analyzing WDM Filter Test Results</i> on page 191) for the given grid channel.
<b>Applicability</b>	This query is only available if <code>:CALCulate:MODE</code> on page 325 is set to WPCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	<code>:CALCulate:DATA:WDM:CH:IMEASurement?&lt;wsp&gt;&lt;channel&gt;</code>
<b>Parameter(s)</b>	<i>channel</i>  Integer corresponding to the grid channel number from which you want to get the results.
<b>Response Syntax</b>	TRACE#,ID,SLOPE,<Slope Unit>,RIPPLE,<Ripple unit>,ADJ.ISO.,<Adjacent Isolation unit>,NON-ADJ.ISO.,<Non Adjacent Isolation unit>,TOTALXTALK,<Total Crosstalk unit>,{<WDM Channel Number>},{<Trace ID value>},{<Slope value>},{<Ripple value>},{<Adjacent Isolation value>},{<Non Adjacent Isolation value>},{<Total Crosstalk value>} where <Trace ID value> consists of 4 digits separated by semicolons: <ul style="list-style-type: none"> <li>➤ First digit: 1 for measured trace, 2 for Store type trace.</li> <li>➤ Second digit: module identification number, which is the position of the module in the mainframe from left to right (if first digit is 1) or Store trace number (if first digit is 2). To know the store trace identifier, use the command <code>:TRACe:LIST:STORe?</code> on page 507.</li> <li>➤ Third digit: detector identification number, which is the detector position on the module from top to bottom (if first digit is 1) or 0 (if first digit is 2).</li> <li>➤ Fourth digit: trace type (if first digit is 1) or 0 (if first digit is 2).</li> </ul>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing WDM Filter Test Results</i> on page 191.
<b>Example(s)</b>	<code>:CALC:DATA:WDM:CH:IMEAS?</code> 2 returns TRACE#,ID,SLOPE,DB/NM,RIPPLE,DB,ADJ.ISO.,DB,NON-ADJ.ISO.,DB ,TOTALXTALK,DB,1;3;2;1,+1.2100000E-002,+0.0000000E+000,+6.2890000E+001,+6.2970000E+001,+5.6950000E+001 This response corresponds to the following table:

CH	TRACE#	SLOPE	RIPPLE	ADJ.ISO.	NON-ADJ.ISO	TOTALXTALK
NBR	ID	DB/NM	DB/NM	DB	DB	DB
2	1;3;2;1	+1.210000 00E-002	+0.000000 00E+000	+6.2890000 0E+001	+6.29700000 E+001	+5.69500000 E+001

**:CALCulate:DATA:WDM:CH:PDL?**

<b>Description</b>	This query returns the results of the <b>PDL Analysis</b> analysis tool (for more details, see <i>Analyzing PDL Analysis Results</i> on page 168) for the given grid channel.
<b>Applicability</b>	This query is only available if <b>:CALCulate:MODE</b> on page 325 is set to WPCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:WDM:CH:PDL? <wsp> <channel>
<b>Parameter(s)</b>	<i>channel</i> Integer corresponding to the grid channel number from which you want to get the results.
<b>Response Syntax</b>	TRACE#,ID,PDL_GRID,<PDL unit>,PDL_CHAN,<PDL unit>,PDL_MAX,<PDL unit>,<Trace ID value>,<PDLGrid value>,<PDLChan value>,<PDLMax value> where <Trace ID value> consists of 4 digits separated by semicolons: <ul style="list-style-type: none"> <li>➤ First digit: 1 for measured trace, 2 for Store type trace.</li> <li>➤ Second digit: module identification number, which is the position of the module in the mainframe from left to right (if first digit is 1) or Store trace number (if first digit is 2). To know the store trace identifier, use the command <b>:TRACE:LIST:STORe?</b> on page 507.</li> <li>➤ Third digit: detector identification number, which is the detector position on the module from top to bottom (if first digit is 1) or 0 (if first digit is 2).</li> <li>➤ Fourth digit: trace type (if first digit is 1) or 0 (if first digit is 2).</li> </ul>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing PDL Analysis Results</i> on page 168.
<b>Example(s)</b>	:CALC:DATA:WDM:CH:PDL? 14 returns TRACE#,ID,PDL_GRID,DB,PDL_CHAN,DB,PDL_MAX,DB,1;5;1;1,+8.0000000E-002,+7.00000000E-002,+8.00000000E-002 This response corresponds to the following table:

CH	TRACE#	PDL_GRID	PDL_CHAN	PDL_MAX
NBR	ID	DB	DB	DB
14	1;5;1;2	+8.00000000E-002	+7.00000000E-002	+8.00000000E-002



**:CALCulate:DATA:WDM:CH:SW?**

<b>Description</b>	This query returns the results of the Spectral Width 1; Spectral Width 2 and Spectral Width 3 analysis tools used in PCT WDM analysis mode (for more details, see <i>To define the Spectral Width parameters in PCT WDM Analysis mode:</i> on page 173) for the given grid channel.
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:WDM:CH:SW? <wsp> <channel>
<b>Parameter(s)</b>	<i>channel</i>  Integer corresponding to the grid channel number from which you want to get the results.
<b>Response Syntax</b>	TRACE#,ID,DWL1@xx.xxdB,<Unit>,DWL2@yy.yydB,<Unit>,DWL2@zz.zzdB,<Unit>,{<WDM Channel Number>},{<Trace ID value>},{<WL1@xx.xxdB value>},{<WL2@yy.yydB value>},{<WL3@zz.zzdB value>}  where <Trace ID value> consists of 4 digits separated by semicolons: <ul style="list-style-type: none"> <li>➤ First digit: 1 for measured trace, 2 for Store type trace.</li> <li>➤ Second digit: module identification number, which is the position of the module in the mainframe from left to right (if first digit is 1) or Store trace number (if first digit is 2). To know the store trace identifier, use the command <i>:TRACe:LIST:STORe?</i> on page 507.</li> <li>➤ Third digit: detector identification number, which is the detector position on the module from top to bottom (if first digit is 1) or 0 (if first digit is 2).</li> <li>➤ Fourth digit: trace type (if first digit is 1) or 0 (if first digit is 2).</li> </ul>
<b>Response(s)</b>	The analysis results are described in <i>Analyzing WDM Filter Test Results</i> on page 191.
<b>Example(s)</b>	:CALC:DATA:WDM:CH:SW? 16 returns  TRACE#,ID,DWL1@1.00DB,M,DWL2@3.00DB,M,DWL3@20.00DB,M,1;3;2;1,+1.69607000E-008,+1.75082000E-008,+2.00912000E-008  This response corresponds to the following table:

CH	TRACE#	DWL1@1.00DB	DWL2@3.00DB	DWL3@20.00DB
NBR	ID	M	M	M
2	1;3;2;1	+1.69607000E-008	+1.75082000E-008	+2.00912000E-008

**:CALCulate:DATA:WDM:NCHannels?**

<b>Description</b>	This query returns the number of channels that have been detected (for more details, see <i>Analyzing Channel Detection Results</i> on page 166).
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:WDM:NCHannels?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	NBROFCHANNELS,<Value>,
<b>Response(s)</b>	The analysis result is described in <b>Table header on page 166</b> .
<b>Example(s)</b>	:CALC:DATA:WDM:NCHannels? returns NBROFCHANNELS,6,

---

**:CALCulate:DATA:WDM:SLOPe?**

<b>Description</b>	This query returns the slope of all detected peaks on all analyzed traces (for more details, see <i>Analyzing Channel Detection Results</i> on page 166).
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:WDM:SLOPe?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	SLOPE,<Value>,<Unit>
<b>Response(s)</b>	The analysis result is described in <b>Table header on page 166</b> .
<b>Example(s)</b>	:CALC:DATA:WDM:SLOPe? returns SLOPE,+3.95000000E+008,DB/M

**:CALCulate:DATA:WDM:UNIFormity?**

<b>Description</b>	This query returns the uniformity of all detected peaks (for more details, see <i>Analyzing Channel Detection Results</i> on page 166).
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:CALCulate:DATA:WDM:UNIFormity?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	UNIFORMITY,<Value>,<Unit>
<b>Response(s)</b>	The analysis result is described in <b>Table header on page 166</b> .
<b>Example(s)</b>	:CALC:DATA:WDM:UNIFormity? returns UNIFORMITY,+2.17000000E+000,DB

## CALCulate:PARameters Commands and Queries

### Quick Reference

Command Overview				Parameter(s)	Section
CALCulate	PARameters	CSElector	TYPE	<type>	see p. 360
			TYPE?		see p. 360
CALCulate	PARameters	IMEASurement	[ :ACTivate]	<state>	see p. 361
			[ :ACTivate]?		see p. 361
			BPERCentage	<percentage>   MIN   MAX	see p. 362
			BPERCentage?	[MIN MAX]	see p. 363
			CPERCentage	<Percentage>   MIN   MAX	see p. 364
			CPERCentage?	[MIN MAX]	see p. 365
			RANGe	<method>	see p. 366
			RANGe?		see p. 366
			SPAN	<span>[ <unit>]   MIN   MAX	see p. 367
			SPAN?	[MIN MAX]	see p. 368
CALCulate	PARameters	NW1	ALGorithm	<algorithm>	see p. 369
			ALGorithm?		see p. 369
			DISPlay	<state>	see p. 370
			DISPlay?		see p. 370
			MULTiplier	<value>   MIN   MAX	see p. 371
			MULTiplier?	[MIN MAX]	see p. 371
			NSElection	<method>	see p. 372
			NSElection?		see p. 372
			WREference	<method>	see p. 373
			WREference?		see p. 373
			WTHReshold	<value>   MIN   MAX	see p. 374
			WTHReshold?	[MIN MAX]	see p. 374
CALCulate	PARameters	NW2	[ :ACTivate]	<state>	see p. 375
			[ :ACTivate]?		see p. 375
			ALGorithm	<algorithm>	see p. 369
			ALGorithm?		see p. 369
			DISPlay	<state>	see p. 370
			DISPlay?		see p. 370
			MULTiplier	<value>   MIN   MAX	see p. 371

Command Overview				Parameter(s)	Section
			MULTiplier?	[MIN MAX]	see p. 371
			NSElection	<method>	see p. 372
			NSElection?		see p. 372
			WREference	<method>	see p. 373
			WREference?		see p. 373
			WTHReshold	<value>   MIN MAX	see p. 374
			WTHReshold?	[MIN MAX]	see p. 374
CALCulate	PARameters	NW3	[:ACTivate]	<state>	see p. 375
			[:ACTivate]?		see p. 375
			ALGorithm	<algorithm>	see p. 369
			ALGorithm?		see p. 369
			DISPlay	<state>	see p. 370
			DISPlay?		see p. 370
			MULTiplier	<value>   MIN MAX	see p. 371
			MULTiplier?	[MIN MAX]	see p. 371
			NSElection	<method>	see p. 372
			NSElection?		see p. 372
			WREference	<method>	see p. 373
			WREference?		see p. 373
			WTHReshold	<value>   MIN MAX	see p. 374
			WTHReshold?	[MIN MAX]	see p. 374
CALCulate	PARameters	PBAND	[:ACTivate]	<state>	see p. 376
			[:ACTivate]?		see p. 376
			ARANge	<method>	see p. 377
			ARANge?		see p. 378
			BDIStance	<value>[<unit>]   MIN   MAX	see p. 379
			BDIStance?	[MIN MAX]	see p. 380
			BMETHod	<method>	see p. 381
			BMETHod?		see p. 381
			DISPlay	<state>	see p. 382
			DISPlay?		see p. 382
			EXCLusion	MAXimum ?<value>   MIN MAX	see p. 384
				MAXimum ?	see p. 384
				MINimum ?<value>   MIN MAX	see p. 383

Command Overview					Parameter(s)	Section
				MINimum?	[MIN   MAX]	see <i>p. 383</i>
			PERCentage		<percentage>   MIN   MAX	see <i>p. 385</i>
			PERCentage?		[MIN   MAX]	see <i>p. 386</i>
			REFerence		<point>	see <i>p. 387</i>
			REFerence?			see <i>p. 387</i>
			SPAN		<value> [ <unit> ]   MIN   MAX	see <i>p. 388</i>
			SPAN?		[MIN   MAX]	see <i>p. 389</i>
			THReshold		<value>   MIN   MAX	see <i>p. 390</i>
			THReshold?		[MIN   MAX]	see <i>p. 391</i>
			TRANsition		<point>	see <i>p. 392</i>
			TRANsition?			see <i>p. 392</i>
CALCulate	PARameters	PDL	[ :ACTivate]		<state>	see <i>p. 393</i>
			[ :ACTivate]?			see <i>p. 393</i>
			BPERCentage		<percentage>   MIN   MAX	see <i>p. 394</i>
			BPERCentage?		[MIN   MAX]	see <i>p. 395</i>
			CPERCentage		<Percentage>   MIN   MAX	see <i>p. 396</i>
			CPERCentage?		<state>	see <i>p. 397</i>
			RANGe		<method>	see <i>p. 398</i>
			RANGe?			see <i>p. 398</i>
			SPAN		<span> [ <unit> ]   MIN   MAX	see <i>p. 399</i>
			SPAN?		[MIN   MAX]	see <i>p. 400</i>
CALCulate	PARameters	PTSearch	ANTHreshold		<state>	see <i>p. 401</i>
			ANTHreshold?			see <i>p. 401</i>
			DISPlay	[STATe]	<state>	see <i>p. 402</i>
				[STATe]?		see <i>p. 402</i>
				SHOW	<type>	see <i>p. 403</i>
				SHOW?		see <i>p. 403</i>
			MTHReshold		<value>   MIN   MAX	see <i>p. 404</i>
			MTHReshold?		[MIN   MAX]	see <i>p. 404</i>
			PTTHreshold		<value>   MIN   MAX	see <i>p. 405</i>
			PTTHreshold?		[MIN   MAX]	see <i>p. 405</i>
CALCulate	PARameters	SBANd	[ :ACTivate]		<state>	see <i>p. 406</i>

Command Overview				Parameter(s)	Section
			[ :ACTivate ]?		see p. 406
			ARANge	<method>	see p. 407
			ARANge?		see p. 408
			BDIStance	<value> [ <unit> ]   MIN   MAX	see p. 409
			BDIStance?	[ MIN   MAX ]	see p. 410
			BMETHod	<method>	see p. 411
			BMETHod?		see p. 411
			DISPlay	<state>	see p. 412
			DISPlay?		see p. 412
			EXCLusion	MAXimum	<value>   MIN   MAX
				MAXimum ?	[ MIN   MAX ]
				MINimum	<value>   MIN   MAX
				MINimum?	[ MIN   MAX ]
			PERCentage		<percentage>   MIN   MAX
			PERCentage?		[ MIN   MAX ]
			REFerence		<point>
			REFerence?		
			SPAN		<value> [ <unit> ]   MIN   MAX
			SPAN?		[ MIN   MAX ]
			THReshold		<value>   MIN   MAX
			THReshold?		[ MIN   MAX ]
			TRANsition		<point>
			TRANsition?		
CALCulate	PARameters	SW1	ALGorithm		<algorithm>
			ALGorithm?		
			DISPlay		<state>
			DISPlay?		
			FMODE		<state>
			FMODE?		
			MANalysis		<state>
			MANalysis?		
			METHod		<method>

Command Overview				Parameter(s)	Section
			METHod?		see p. 430
			MTHReshold	<value>   MIN   MAX	see p. 432
			MTHReshold?	[MIN   MAX]	see p. 432
			MULTiplier	<value>   MIN   MAX	see p. 431
			MULTiplier?	[MIN   MAX]	see p. 431
			WTHReshold	<value>   MIN   MAX	see p. 433
			WTHReshold?	[MIN   MAX]	see p. 433
CALCulate	PARAmeters	SW2	[ :ACTivate]	<state>	see p. 434
			[ :ACTivate]?		see p. 434
			ALGorithm	<algorithm>	see p. 424
			ALGorithm?		see p. 425
			DISPlay	<state>	see p. 426
			DISPlay?		see p. 426
			FMODE	<state>	see p. 427
			FMODE?		see p. 427
			MANalysis	<state>	see p. 428
			MANalysis?		see p. 428
			METHod	<method>	see p. 429
			METHod?		see p. 430
			MTHReshold	<value>   MIN   MAX	see p. 432
			MTHReshold?	[MIN   MAX]	see p. 432
			MULTiplier	<value>   MIN   MAX	see p. 431
			MULTiplier?	[MIN   MAX]	see p. 431
			WTHReshold	<value>   MIN   MAX	see p. 433
			WTHReshold?	[MIN   MAX]	see p. 433
CALCulate	PARAmeters	SW3	[ :ACTivate]	<state>	see p. 434
			[ :ACTivate]?		see p. 434
			ALGorithm	<algorithm>	see p. 424
			ALGorithm?		see p. 425
			DISPlay	<state>	see p. 426
			DISPlay?		see p. 426
			FMODE	<state>	see p. 427
			FMODE?		see p. 427
			MANalysis	<state>	see p. 428
			MANalysis?		see p. 428



Command Overview				Parameter(s)	Section
			METHod	<method>	see p. 429
			METHod?		see p. 430
			MTHReshold	<value>   MIN   MAX	see p. 432
			MTHReshold?	[MIN   MAX]	see p. 432
			MULTiplier	<value>   MIN   MAX	see p. 431
			MULTiplier?	[MIN   MAX]	see p. 431
			WTHReshold	<value>   MIN   MAX	see p. 433
			WTHReshold?	[MIN   MAX]	see p. 433
CALCulate	PARameters	WDMChannel	BAND	<band>	see p. 435
			BAND?		see p. 435
			BTHReshold	<threshold>   MIN   MAX	see p. 436
			BTHReshold?	[MIN   MAX]	see p. 436
			DISPlay	<state>	see p. 437
			DISPlay?		see p. 437
			ECHannels	<display>	see p. 438
			ECHannels?		see p. 438
			FCHannel	<channel>	see p. 439
			FCHannel?		see p. 439
			GSPacing	<spacing>   MIN   MAX	see p. 440
			GSPacing?	[MIN   MAX]	see p. 440
			MODE	<mode>	see p. 441
			MODE?		see p. 441
			RFRequency	<value>   MIN   MAX	see p. 442
			RFRequency?	[MIN   MAX]	see p. 442
			SPACing	<spacing>	see p. 443
			SPACing?		see p. 443
			STARt	<start> [ <unit> ]   MIN   MAX	see p. 444
			STARt?	[MIN   MAX]	see p. 445
			STOP	<stop> [ <unit> ]   MIN   MAX	see p. 446
			STOP?	[MIN   MAX]	see p. 447

**Commands and Queries**

<b>:CALCulate:PARameters:CSElector:TYPE</b>	
<b>Description</b>	This command selects the component under test and activates the corresponding analysis tools (for more details, see <i>Selecting the Component Under Test (Component Selector)</i> on page 161).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:CSElector:TYPE<wsp> <type>
<b>Parameter(s)</b>	<i>type</i> : Type of component under test. The allowed values are: 0 PASS: selects the pass band filter as component under test. 1 STOP: selects the stop band filter as component under test (only available if :CALCulate:MODE on page 325 is set to PCT). 2 ISOLator: selects the isolator or circulator as component under test (only available if :CALCulate:MODE on page 325 is set to PCT). 3 FIBer: selects the fiber component as component under test (only available if :CALCulate:MODE on page 325 is set to PCT).
<b>Example(s)</b>	:CALC:PAR:CSEL:TYPE ISOL

<b>:CALCulate:PARameters:CSElector:TYPE?</b>	
<b>Description</b>	This query returns the selected component under test.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:CSElector:TYPE?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<type>
<b>Response(s)</b>	<i>type</i> : Integer corresponding to the selected component under test: 0: the pass band filter is selected as component under test. 1: the stop band filter is selected as component under test. 2: the isolator or circulator is selected as component under test. 3: the fiber component is selected as component under test.
<b>Example(s)</b>	:CALC:PAR:CSEL:TYPE ISOL :CALC:PAR:CSEL:TYPE? returns 2

**:CALCulate:PARameters:IMEASurement[:ACTivate]**

<b>Description</b>	This command enables/disables the WDM Filter test analysis tool.
<b>Applicability</b>	This command is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:IMEASurement[:ACTivate] <wsp> <state>
<b>Parameter(s)</b>	<i>state</i> : Activation state of the WDM Filter test tool. The allowed values are: 0 OFF: disables the tool. 1 ON: enables the tool.
<b>Example(s)</b>	:CALC:PAR:IMEAS:ACT ON

**:CALCulate:PARameters:IMEASurement[:ACTivate]?**

<b>Description</b>	This query returns the activation state of the WDM Filter test analysis tool.
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:IMEASurement[:ACTivate]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : Integer corresponding to the activation state set for the WDM Filter test tool: 0: the tool is disabled. 1: the tool is enabled.
<b>Example(s)</b>	:CALC:PAR:IMEAS:ACT OFF :CALC:PAR:IMEAS:ACT? returns 0

**:CALCulate:PARameters:IMEASurement:BPERCentage**

<b>Description</b>	<p>This command defines the % <b>Bandwidth 1</b> parameter of the WDM Filter test analysis tool.</p> <p>The corresponding GUI setting is % <b>Bandwidth</b> (<i>only if Frequency Range is set to % Bandwidth 1</i>) on page 191.</p>
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to WPCT</li> <li>➤ :CALCulate:PARameters:IMEASurement:RANGe on page 366 is set to PBWidt</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:IMEASurement:BPERCentage<wsp><percentage>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>percentage</i>: Percentage of bandwidth calculated from Spectral Width 1 (centered on the grid wavelength/frequency) to use for calculations, in the range 0.1 to 100.</li> <li>➤ <i>MIN</i> Minimum programmable value: 0.1 %</li> <li>➤ <i>MAX</i>: Maximum programmable value: 100 %</li> </ul>
<b>Example(s)</b>	:CALC:PAR:IMEAS:BPERC 25.5

---

**:CALCulate:PARameters:IMEASurement:BPERCentage?**

<b>Description</b>	This query returns the % <b>Bandwidth 1</b> parameter set for the WDM Filter test analysis tool.
<b>Applicability</b>	<p>This query is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT</li> <li>➤ <i>:CALCulate:PARameters:IMEASurement:RANGe</i> on page 366 is set to PBWidth</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:IMEASurement:BPERCentage? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ MIN The query returns the minimum programmable value.</li> <li>➤ MAX The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<i>&lt;percentage&gt;</i>
<b>Response(s)</b>	<p><i>percentage:</i></p> <p>Percentage of bandwidth calculated from Spectral Width 1 (centered on the grid wavelength/frequency) used for calculations.</p>
<b>Example(s)</b>	<p>:CALC:PAR:IMEAS:BPERCentage 25.5</p> <p>:CALC:PAR:IMEAS:BPERCentage? returns +2.55000000E+001</p>

**:CALCulate:PARameters:IMEASurement:CPERCentage**

<b>Description</b>	<p>This command defines the % <b>Channel spacing</b> parameter of the WDM Filter test analysis tool.</p> <p>The corresponding GUI setting is % <b>Channel</b> (<i>only if Frequency Range is set to % Channel spacing</i>) on page 191.</p>
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"><li>➤ :CALCulate:MODE on page 325 is set to WPCT</li><li>➤ :CALCulate:PARameters:IMEASurement:RANGe on page 366 is set to PCWidth</li></ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:IMEASurement:CPERCentage<wsp> <percentage>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"><li>➤ <i>percentage</i>: Percentage of the channel width to use for calculations, in the range 0.1 to 100.</li><li>➤ <i>MIN</i> Minimum programmable value: 0.1 %</li><li>➤ <i>MAX</i>: Maximum programmable value: 100 %</li></ul>
<b>Example(s)</b>	:CALC:PAR:IMEAS:CPERC 30

---

**:CALCulate:PARameters:IMEASurement:CPERCentage?**

<b>Description</b>	This query returns the % <b>Channel spacing</b> parameter set for the WDM Filter test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"><li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT</li><li>➤ <i>:CALCulate:PARameters:IMEASurement:RANGe</i> on page 366 is set to PCWidth</li></ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:IMEASurement:CPERCentage? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"><li>➤ MIN The query returns the minimum programmable value.</li><li>➤ MAX The query returns the maximum programmable value.</li></ul>
<b>Response Syntax</b>	<i>&lt;percentage&gt;</i>
<b>Response(s)</b>	<i>percentage:</i> Percentage of the channel width used for calculations.
<b>Example(s)</b>	:CALC:PAR:IMEAS:CPERCentage 50 :CALC:PAR:IMEAS:CPERCentage? returns +5.00000000E+001

---

**:CALCulate:PARAmeters:IMEASurement:RANGe**

<b>Description</b>	This command defines the <b>Frequency Range</b> parameter for the WDM Filter test analysis tool.  The corresponding GUI setting is <b>Frequency Range on page 190</b> .
<b>Applicability</b>	This command is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:CALCulate:PARAmeters:IMEASurement:RANGe</i> <wsp> <method>
<b>Parameter(s)</b>	<i>method</i> :  Method used to define the spectral range used for the calculation of isolation, total crosstalk, ripple and slope of selected traces. The allowed values are:  0 FIXed: a fixed span is used to define the spectral range. It is set using the command <i>:CALCulate:PARAmeters:IMEASurement:SPAN</i> on page 367.  1 PBWidth: a percentage of bandwidth is used to define the spectral range, calculated using Spectral Width 1. It is set using the command <i>:CALCulate:PARAmeters:IMEASurement:BPERcentage</i> on page 362.  2 PCWidth: a percentage of the channel bandwidth is used to define the spectral range. It is set using the command <i>:CALCulate:PARAmeters:IMEASurement:CPERcentage</i> on page 364.
<b>Example(s)</b>	<i>:CALC:PAR:IMEAS:RANG PBW</i>

**:CALCulate:PARAmeters:IMEASurement:RANGe?**

<b>Description</b>	This query returns the <b>Frequency Range</b> parameter set for the WDM Filter test analysis tool.
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:CALCulate:PARAmeters:IMEASurement:RANGe?</i>
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> :  Integer representing the method used to define the spectral range used for the calculation of isolation, total crosstalk, ripple and slope.
<b>Example(s)</b>	<i>:CALC:PAR:IMEAS:RANG PBW</i>  <i>:CALC:PAR:IMEAS:RANG?</i> returns 1



**:CALCulate:PARAmeters:IMEASurement:SPAN**

<b>Description</b>	<p>This command defines the <b>Calculation Span</b> parameter of the WDM Filter test analysis tool.</p> <p>The corresponding GUI setting is <b>Calculation Span</b> (<i>only if Frequency Range is set to Fixed Range</i>) on page 191.</p>
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT</li> <li>➤ <i>:CALCulate:PARAmeters:IMEASurement:RANGe</i> on page 366 is set to FIXed</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:CALCulate:PARAmeters:IMEASurement:SPAN</i> <wsp> <span> [ <i>&lt;unit&gt;</i> ]   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>span</i>: Wavelength or frequency distance (centered on the grid wavelength/frequency) to use for calculation, as float value in the range 0.01 to 100 nm or 0.001 to 12.085 THz.</li> <li>➤ <i>unit</i> Unit of the set value. The allowed units are PM NM M HZ GHZ THZ The default unit is meter or Hertz, depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</li> <li>➤ <i>MIN</i> Minimum programmable value: 0.01 nm or 0.001 THz</li> <li>➤ <i>MAX</i>: Maximum programmable value: 100 nm or 12.085 THz</li> </ul>
<b>Example(s)</b>	<i>:CALC:PAR:IMEAS:SPAN 200PM</i>

**:CALCulate:PARAmeters:IMEASurement:SPAN?**

<b>Description</b>	This query returns the <b>Calculation span</b> parameter set for the WDM Filter test analysis tool.
<b>Applicability</b>	<p>This query is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT</li> <li>➤ <i>:CALCulate:PARAmeters:IMEASurement:RANGe</i> on page 366 is set to FIXed</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:IMEASurement:SPAN?[MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ MIN The query returns the minimum programmable value.</li> <li>➤ MAX The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<span>
<b>Response(s)</b>	<p><i>span:</i></p> <p>Wavelength or frequency distance in meters or Hertz depending on the unit setting (set with command <i>:UNIT:X</i> on page 533)..</p>
<b>Example(s)</b>	<p>:CALC:PAR:IMEAS:SPAN 200PM</p> <p>:CALC:PAR:IMEAS:SPAN? returns +2.00000000E-010</p>

---

**:CALCulate:PARAmeters:NW[1...3]:ALGorithm**

<b>Description</b>	This command sets the <b>Algorithm</b> setting for the Notch Width 1, Notch Width 2 or Notch Width 3 analysis tool (for more details, see <b>Notch Width Detection Settings on page 176</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to STOP or ISOL.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:NW[1...3]:ALGorithm<wsp> <algorithm>
<b>Parameter(s)</b>	<i>algorithm:</i> Algorithm to use for the Notch Width 1, Notch Width 2 or Notch Width 3 analysis tool. The allowed values are: 0 THReshold: sets the <b>Threshold</b> algorithm. 1 GFIT: sets the <b>Gaussian Fit</b> algorithm 2 LFIT: sets the <b>Lorentzian Fit</b> algorithm.
<b>Example(s)</b>	:CALC:PAR:NW1:ALG LFIT

**:CALCulate:PARAmeters:NW[1...3]:ALGorithm?**

<b>Description</b>	This query returns the algorithm used for the calculation of the Notch Width 1, Notch Width 2 or Notch Width 3 analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to STOP or ISOL.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:NW[1...3]:ALGorithm?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<algorithm>
<b>Response(s)</b>	<i>algorithm:</i> Integer corresponding to the algorithm used for calculation of the Notch Width 1, Notch Width 2 or Notch Width 3 analysis tool: 0: the <b>Threshold</b> algorithm is used. 1: the <b>Gaussian Fit</b> algorithm is used. 2: the <b>Lorentzian Fit</b> algorithm is used.
<b>Example(s)</b>	:CALC:PAR:NW1:ALG LFIT :CALC:PAR:NW1:ALG? returns 2

**:CALCulate:PARAmeters:NW[1...3]:DISPlay**

<b>Description</b>	This command sets the <b>Display on Graph</b> setting for the Notch Width 1, Notch Width 2 or Notch Width 3 analysis tool.
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to STOP or ISOL.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:NW[1...3]:DISPlay<wsp><state>
<b>Parameter(s)</b>	<i>state</i> : State of the analysis graphical items visibility on graph. The allowed values are: 0 OFF: makes the analysis graphical items invisible on graph. 1 ON: displays the analysis graphical items on graph.
<b>Example(s)</b>	:CALC:PAR:NW1:DISP ON :CALC:PAR:NW2:DISP ON :CALC:PAR:NW3:DISP OFF

**:CALCulate:PARAmeters:NW[1...3]:DISPlay?**

<b>Description</b>	This query returns the <b>Display on Graph</b> setting for the Notch Width 1, Notch Width 2 or Notch Width 3 analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to STOP or ISOL.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:NW[1...3]:DISPlay?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : State of the analysis graphical items visibility on graph: 0: the analysis graphical items are not displayed on graph. 1: the analysis graphical items are displayed on graph.
<b>Example(s)</b>	:CALC:PAR:NW2:DISP ON :CALC:PAR:NW2:DISP? returns 1

**:CALCulate:PARAmeters:NW[1...3]:MULTiplier**

<b>Description</b>	This command sets the <b>Multiplier</b> value for the Notch Width 1, Notch Width 2 or Notch Width 3 analysis tool (for more details, see <b>Notch Width Detection Settings on page 176</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP or ISOL.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:NW[1...3]:MULTiplier<wsp><value>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Multiplier factor as float value, in the range 1 to 10.</li> <li>➤ <i>MIN</i>: Minimum value: 1 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 10 dB.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:NW1:MULT 3

**:CALCulate:PARAmeters:NW[1...3]:MULTiplier?**

<b>Description</b>	This query returns the <b>Multiplier</b> value set for the Notch Width 1, Notch Width 2 or Notch Width 3 analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP or ISOL.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:NW[1...3]:MULTiplier? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Value set for the Multiplier parameter.
<b>Example(s)</b>	:CALC:PAR:NW1:MULT 3 :CALC:PAR:NW1:MULT? returns +3.00000000E+000

**:CALCulate:PARAmeters:NW[1...3]:NSElection**

<b>Description</b>	This command sets the <b>Notch Selection</b> method for the Notch Width 1, Notch Width 2 or Notch Width 3 analysis tool (for more details, see <b>Notch Selection Options on page 176</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP or ISOL.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:NW[1...3]:NSElection<wsp> <method>
<b>Parameter(s)</b>	<i>method:</i> Method to use for the <b>Notch Selection</b> parameter. The allowed values are: 0 MTrough: enables the <b>Minimum Trough</b> method. 1 DNOTch: enables the <b>Deepest Notch</b> method.
<b>Example(s)</b>	:CALC:PAR:NW1:NSEL LNOT

**:CALCulate:PARAmeters:NW[1...3]:NSElection?**

<b>Description</b>	This query returns the <b>Notch Selection</b> method set for the Notch Width 1, Notch Width 2 or Notch Width 3 analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP or ISOL.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:NW[1...3]:NSElection?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<method>
<b>Response(s)</b>	<i>method:</i> Integer corresponding to the method selected for the notch selection: 0: the <b>Minimum Trough</b> method is selected. 1: the <b>Deepest Notch</b> method is selected.
<b>Example(s)</b>	:CALC:PAR:NW1:NSEL LNOT :CALC:PAR:NW1:NSEL? returns 1

**:CALCulate:PARAmeters:NW[1...3]:WREference**

<b>Description</b>	This command sets the <b>Width Reference</b> parameter for the Notch Width 1, Notch Width 2 or Notch Width 3 analysis tool (for more details, see <b>Notch Selection Options on page 176</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to STOP or ISOL.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:NW[1...3]:WREference<wsp><method>
<b>Parameter(s)</b>	<i>method:</i> Method to use for the <b>Width Reference</b> . The allowed values are: 0 BOTTOm: enables the <b>Bottom</b> method. 1 TOP: enables the <b>Top</b> method.
<b>Example(s)</b>	:CALC:PAR:NW1:WREF TOP

**:CALCulate:PARAmeters:NW[1...3]:WREference?**

<b>Description</b>	This query returns the <b>Width Reference</b> method set for the Notch Width 1, Notch Width 2 or Notch Width 3 analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to STOP or ISOL.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:NW[1...3]:NSElection?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<method>
<b>Response(s)</b>	<i>method:</i> Integer corresponding to the method selected for the measurement of the width: 0: the <b>Bottom</b> method is selected. 1: the <b>Top</b> method is selected.
<b>Example(s)</b>	:CALC:PAR:NW1:WREF TOP :CALC:PAR:NW1:WREF? returns 1

**:CALCulate:PARAmeters:NW[1...3]:WTHReshold**

<b>Description</b>	This command sets the <b>Width Threshold</b> value for the Notch Width 1, Notch Width 2 or Notch Width 3 analysis tool (for more details, see <b>Notch Width Detection Settings on page 176</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP or ISOL.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:NW[1...3]:WTHReshold<wsp> <value>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Detection threshold for the measurement of width as float value in dB, in the range 0.01 to 50.</li> <li>➤ <i>MIN</i>: Minimum value: 0.01 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 50 dB.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:NW1:WTHR 3

**:CALCulate:PARAmeters:NW[1...3]:WTHReshold?**

<b>Description</b>	This query returns the <b>Width Threshold</b> value for the Notch Width 1, Notch Width 2 or Notch Width 3 analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP or ISOL.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:NW[1...3]:WTHReshold? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Value set for the Width threshold parameter in dB.
<b>Example(s)</b>	:CALC:PAR:NW1:WTHR 3 :CALC:PAR:NW1:WTHR? returns +3.00000000E+000



**:CALCulate:PARAmeters:NW2|NW3[:ACTivate]**

<b>Description</b>	This command enables/disables the Notch Width 2 or Notch Width 3 analysis tool.
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to STOP or ISOL.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:NW2 3[:ACTivate] <wsp> <state>
<b>Parameter(s)</b>	<i>state</i> : Activation state of the Notch Width 2 or Notch Width 3 tool. The allowed values are: 0 OFF: disables the tool. 1 ON: enables the tool.
<b>Example(s)</b>	:CALC:PAR:NW2:ACT ON

**:CALCulate:PARAmeters:NW2|NW3[:ACTivate]?**

<b>Description</b>	This query returns the activation state of the Notch Width 2 or Notch Width 3 analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to STOP or ISOL.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:NW2 3[:ACTivate]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : Integer corresponding to the activation state set for the Notch Width 2 or Notch Width 3 tool: 0: the tool is disabled. 1: the tool is enabled.
<b>Example(s)</b>	:CALC:PAR:NW3:ACT OFF :CALC:PAR:NW3:ACT? returns 0

**:CALCulate:PARAmeters:PBand[:ACTivate]**

<b>Description</b>	This command enables/disables the Pass Band analysis tool.
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBand[:ACTivate] <wsp> <state>
<b>Parameter(s)</b>	<i>state</i> : Activation state of the Pass Band tool. The allowed values are: 0 OFF: disables the tool. 1 ON: enables the tool.
<b>Example(s)</b>	:CALC:PAR:PBAN:ACT ON

**:CALCulate:PARAmeters:PBand[:ACTivate]?**

<b>Description</b>	This query returns the activation state of the Pass Band analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBand[:ACTivate]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : Integer corresponding to the activation state set for the Pass Band tool: 0: the tool is disabled. 1: the tool is enabled.
<b>Example(s)</b>	:CALC:PAR:PBAN:ACT OFF :CALC:PAR:PBAN:ACT? returns 0

<b>:CALCulate:PARAmeters:PBANd:ARANge</b>	
<b>Description</b>	This command sets the <b>Averaging Range</b> parameter for the Pass Band Test analysis tool (for more details, see <b>Average Loss &amp; Ripple Settings on page 180</b> ).
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:ARANge <wsp> <method>
<b>Parameter(s)</b>	<p><i>method</i>:</p> <p>Parameter set as <b>Averaging Range</b>, spectral range over which the average loss and ripple are calculated. The allowed values are:</p> <p>0 FIXed: sets the averaging range to <b>Fixed Range</b>. The corresponding fixed span value is defined with the following command :CALCulate:PARAmeters:PBANd:SPAN on page 388</p> <p>1 PBWidth: sets the averaging range to % <b>Bandwidth 1</b>. The corresponding percentage is defined with the following command :CALCulate:PARAmeters:PBANd:PERCentage on page 385.</p> <p>2 PTDetection: sets the averaging range to <b>PT Detection</b>. The corresponding value is defined with the following command :CALCulate:PARAmeters:PBANd:THReshold on page 390.</p>
<b>Example(s)</b>	:CALC:PAR:PBAN:ARAN PBW

**:CALCulate:PARAmeters:PBANd:ARANge?**

<b>Description</b>	This query returns the <b>Averaging Range</b> parameter set for the Pass Band Test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"><li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li><li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li></ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:ARANge?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<method>
<b>Response(s)</b>	<i>method:</i> Integer corresponding to the method used as <b>Averaging Range</b> : 0: the <b>Fixed Range</b> parameter is set as averaging range. 1: the <b>% Bandwidth 1</b> parameter is set as averaging range. 2: the <b>PT Detection</b> parameter is set as averaging range.
<b>Example(s)</b>	:CALC:PAR:PBAN:ARAN PBW :CALC:PAR:PBAN:ARAN? returns 1

---

<b>:CALCulate:PARAmeters:PBANd:BDIStance</b>	
<b>Description</b>	This command defines the <b>IN/OUT Band Distance</b> parameter for the Pass Band Test analysis tool (for more details, see <b>CrossTalk Settings on page 179</b> ).
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:PBANd:BMETHod</i> on page 381 is set to SET.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:CALCulate:PARAmeters:PBANd:BDIStance</i> <wsp> <value> [ <i>&lt;unit&gt;</i> ]   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Wavelength or frequency as float value corresponding to the distance between the in-band reference point and the out-band reference point.</li> <li>➤ <i>unit</i>: Unit of the distance. The allowed values are PM NM M HZ GHZ THZ The default unit is meter or hertz, depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</li> <li>➤ <i>MIN</i>: Minimum value: 0.05 nm or 0.006 THz.</li> <li>➤ <i>MAX</i>: Maximum value: 450 nm or 54.384 THz.</li> </ul>
<b>Example(s)</b>	<i>:CALC:PAR:PBAN:BDIS 5NM</i>

**:CALCulate:PARAmeters:PBANd:BDIStance?**

<b>Description</b>	This query returns the <b>IN/OUT Band Distance</b> parameter set for the Pass Band Test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:PBANd:BMETHod</i> on page 381 is set to SET.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:BDIStance? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Wavelength or frequency value corresponding to the distance between the in-band reference point and the out-band reference point, as float value in meters or Hertz depending on the unit setting (see <i>:UNIT:X</i> on page 533).
<b>Example(s)</b>	:CALC:PAR:PBAN:BDIS 5NM :CALC:PAR:PBAN:BDIS? returns +5.00000000E-009

---

<b>:CALCulate:PARAmeters:PBANd:BMETHOD</b>	
<b>Description</b>	This command sets the <b>IN/OUT Band Method</b> parameter for the Pass Band Test analysis tool (for more details, see <b>CrossTalk Settings on page 179</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:BMETHOD<wsp> <method>
<b>Parameter(s)</b>	<i>method:</i> Parameter set as <b>IN/OUT Band Method</b> . The allowed values are: 0 BWIDth: sets the <b>Bandwidth 1</b> method as in/out band method. The out-band reference points are calculated using the <b>Spectral Width 1</b> tool results (see <i>:CALCulate:DATA:SWI?</i> on page 341). 1 SET: sets the <b>Set Distance</b> method as in/out band method. The spacing value is the value defined using <i>:CALCulate:PARAmeters:PBANd:BDISance</i> on page 379.
<b>Example(s)</b>	:CALC:PAR:PBAN:BMET BWID

<b>:CALCulate:PARAmeters:PBANd:BMETHOD?</b>	
<b>Description</b>	This query returns the <b>IN/OUT Band Method</b> parameter set for the Pass Band Test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:BMETHOD?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<method>
<b>Response(s)</b>	<i>method:</i> Integer corresponding to the method used as <b>IN/OUT Band Method</b> : 0: <b>Bandwidth 1</b> is set as in/out band method. 1: <b>Set Distance</b> is set as in/out band method.
<b>Example(s)</b>	:CALC:PAR:PBAN:BMET BWID :CALC:PAR:PBAN:BMET? returns 0

**:CALCulate:PARAmeters:PBANd:DISPlay**

<b>Description</b>	This command sets the <b>Display on Graph</b> setting for the Pass Band Test analysis tool.
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:DISPlay<wsp> <state>
<b>Parameter(s)</b>	<i>state</i> : State of the analysis graphical items visibility on graph. The allowed values are: 0 OFF: makes the analysis graphical items invisible on graph. 1 ON: displays the analysis graphical items on graph.
<b>Example(s)</b>	:CALC:PAR:PBAN:DISP ON

---

**:CALCulate:PARAmeters:PBANd:DISPlay?**

<b>Description</b>	This query returns the <b>Display on Graph</b> setting for the Pass Band Test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:DISPlay?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : State of the analysis graphical items visibility on graph: 0: the analysis graphical items are not displayed on graph. 1: the analysis graphical items are displayed on graph.
<b>Example(s)</b>	:CALC:PAR:PBAN:DISP ON :CALC:PAR:PBAN:DISP? returns 1

---



**:CALCulate:PARAmeters:PBANd:EXCLusion:MINimum**

<b>Description</b>	This command defines the <b>Min Exclusion Thresh.</b> parameter for the Pass Band Test analysis tool (for more details, see <b>Roll-Off &amp; Transition Band Settings on page 182</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:EXCLusion:MINimum<wsp><value>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Minimum threshold in dB above which you want the roll-off to be calculated.</li> <li>➤ <i>MIN</i>: Minimum value: 0 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 19.99 dB.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:PBAN:EXCL:MIN 3

**:CALCulate:PARAmeters:PBANd:EXCLusion:MINimum?**

<b>Description</b>	This query returns the <b>Min Exclusion Thresh.</b> parameter set for the Pass Band Test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:EXCLusion:MINimum? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Minimum threshold in dB above which the roll-off is calculated.
<b>Example(s)</b>	:CALC:PAR:PBAN:EXCL:MIN 3 :CALC:PAR:PBAN:EXCL:MIN? returns +3.00000000E+000

**:CALCulate:PARAmeters:PBANd:EXCLusion:MAXimum**

<b>Description</b>	This command defines the <b>Max Exclusion Thresh.</b> parameter for the Pass Band Test analysis tool (for more details, see <b>Roll-Off &amp; Transition Band Settings on page 182</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:EXCLusion:MAXimum<wsp> <value>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Maximum threshold in dB under which you want the roll-off to be calculated.</li> <li>➤ <i>MIN</i>: Minimum value: 3.01 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 100 dB.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:PBAN:EXCL:MAX 20

**:CALCulate:PARAmeters:PBANd:EXCLusion:MAXimum?**

<b>Description</b>	This query returns the <b>Max Exclusion Thresh.</b> parameter set for the Pass Band Test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:EXCLusion:MAXimum? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Maximum threshold in dB under which the roll-off is calculated.
<b>Example(s)</b>	:CALC:PAR:PBAN:EXCL:MAX 20 :CALC:PAR:PBAN:EXCL:MAX? returns +2.00000000E+001

**:CALCulate:PARAmeters:PBANd:PERCentage**

<b>Description</b>	This command defines the % <b>Bandwidth</b> parameter for the Pass Band Test analysis tool (for more details, see <b>Average Loss &amp; Ripple Settings on page 180</b> ).
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> <li>➤ <i>:CALCulate:PARAmeters:PBANd:ARANge</i> on page 377 is set to PBWidth.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:PERCentage<wsp> <percentage>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>percentage</i>: Fraction in percent of <b>Bandwidth 1</b> calculated from Spectral Width 1 tool (see <i>:CALCulate:DATA:SW1?</i> on page 341) to be used as a range for average loss and ripple calculation.</li> <li>➤ <i>MIN</i>: Minimum value: 0 %.</li> <li>➤ <i>MAX</i>: Maximum value: 100 %.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:PBAN:PERC 25.5

**:CALCulate:PARAmeters:PBANd:PERCentage?**

<b>Description</b>	This query returns the % <b>Bandwidth</b> parameter set for the Pass Band Test analysis tool.
<b>Applicability</b>	<p>This query is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> <li>➤ <i>:CALCulate:PARAmeters:PBANd:ARANge</i> on page 377 is set to PBWidth.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:PERCentage? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<percentage>
<b>Response(s)</b>	<p><i>percentage</i>:</p> <p>Percentage of <b>Bandwidth 1</b> calculated from Spectral Width 1 tool used as a range for average loss and ripple calculation.</p>
<b>Example(s)</b>	<p>:CALC:PAR:PBAN:PERC 25.5</p> <p>:CALC:PAR:PBAN:PERC? returns +2.55000000E+001</p>

---

<b>:CALCulate:PARAmeters:PBANd:REference</b>	
<b>Description</b>	This command sets the <b>Reference</b> parameter for the Pass Band Test analysis tool (for more details, see <b>CrossTalk Settings</b> on page 179).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:REference<wsp> <point>
<b>Parameter(s)</b>	<i>point:</i> In-band point to use as <b>Reference</b> point, calculated from the <b>Spectral Width 1</b> tool results (see :CALCulate:DATA:SW1? on page 341). The allowed values are: 0 PEAK: sets the <b>Peak wavelength</b> as reference point. 1 CENTer: sets the <b>Center wavelength</b> as reference point.
<b>Example(s)</b>	:CALC:PAR:PBAN:REF CENT

<b>:CALCulate:PARAmeters:PBANd:REference?</b>	
<b>Description</b>	This query returns the <b>Reference</b> parameter set for the Pass Band Test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:REference?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<point>
<b>Response(s)</b>	<i>point:</i> Integer corresponding to the point used as <b>Reference</b> point: 0: the <b>Peak wavelength</b> is set as reference point. 1: the <b>Center wavelength</b> is set as reference point.
<b>Example(s)</b>	:CALC:PAR:PBAN:REF CENT :CALC:PAR:PBAN:REF? returns 1

<b>:CALCulate:PARAmeters:PBANd:SPAN</b>	
<b>Description</b>	This command defines the <b>Calculation Span</b> parameter for the Pass Band Test analysis tool (for more details, see <b>Average Loss &amp; Ripple Settings on page 180</b> ).
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> <li>➤ <i>:CALCulate:PARAmeters:PBANd:ARANge</i> on page 377 is set to FIXed.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:SPAN<wsp><value>[<unit>] MIN MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Wavelength or frequency as float value corresponding to the span over which average loss and ripple will be calculated.</li> <li>➤ <i>unit</i>: Unit of the span. The allowed units are PM NM M HZ GHZ THZ The default unit is meter or hertz, depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</li> <li>➤ <i>MIN</i>: Minimum value: 0 nm or 0 THz.</li> <li>➤ <i>MAX</i>: Maximum value: 100 nm or 12.085 THz.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:PBAN:SPAN 200PM

**:CALCulate:PARameters:PBANd:SPAN?**

<b>Description</b>	This query returns the <b>Calculation Span</b> parameter set for the Pass Band Test analysis tool.
<b>Applicability</b>	<p>This query is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARameters:CSElector:TYPE</i> on page 360 is set to PASS.</li> <li>➤ <i>:CALCulate:PARameters:PBANd:ARANge</i> on page 377 is set to FIXed.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:PBANd:SPAN? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<p><i>value</i>:</p> <p>Wavelength or frequency value corresponding to the span over which average loss and ripple will be calculated, as float value in meters or Hertz depending on the unit setting (see <i>:UNIT:X</i> on page 533).</p>
<b>Example(s)</b>	<p>:CALC:PAR:PBAN:SPAN 200PM</p> <p>:CALC:PAR:PBAN:SPAN? returns +2.00000000E-010</p>

**:CALCulate:PARameters:PBANd:THReshold**

<b>Description</b>	This command defines the <b>Detection Threshold</b> parameter for the Pass Band Test analysis tool (for more details, see <b>Average Loss &amp; Ripple Settings on page 180</b> ).
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARameters:CSElector:TYPE</i> on page 360 is set to PASS.</li> <li>➤ <i>:CALCulate:PARameters:PBANd:ARANge</i> on page 377 is set to PTDetection.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:PBANd:THReshold <wsp> <value>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Threshold in dB for the detection of in-band extreme peaks to be used as averaging range for loss and ripple calculation.</li> <li>➤ <i>MIN</i>: Minimum value: 0.01 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 50 dB.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:PBAN:THR 0.2

---



**:CALCulate:PARameters:PBANd:THReshold?**

<b>Description</b>	This query returns the <b>Detection Threshold</b> parameter set for the Pass Band Test analysis tool.
<b>Applicability</b>	<p>This query is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARameters:CSElector:TYPE</i> on page 360 is set to PASS.</li> <li>➤ <i>:CALCulate:PARameters:PBANd:ARANge</i> on page 377 is set to PTDetection.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:PBANd:THReshold? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<p><i>value</i>:</p> <p>Detection threshold in dB used as averaging range for loss and ripple calculation.</p>
<b>Example(s)</b>	<p>:CALC:PAR:PBAN:THR 0.2</p> <p>:CALC:PAR:PBAN:THR? returns +2.00000000E-001</p>

**:CALCulate:PARAmeters:PBANd:TRANSition**

<b>Description</b>	This command sets the <b>Transition Reference</b> parameter for the Pass Band Test analysis tool (for more details, see <b>Roll-Off &amp; Transition Band Settings on page 182</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:TRANSition<wsp><point>
<b>Parameter(s)</b>	<i>point</i> : Parameter set as <b>Transition Reference</b> , the reference point used to determine the spectral range over which the roll-off is calculated. The allowed values are: 0 INBand: sets the reference point to <b>In-Band</b> . 1 OUTBand: sets the reference point to <b>Out-Band</b> .
<b>Example(s)</b>	:CALC:PAR:PBAN:TRAN INB

**:CALCulate:PARAmeters:PBANd:TRANSition?**

<b>Description</b>	This query returns the <b>Transition Reference</b> parameter set for the Pass Band Test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PBANd:TRANSition?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<method>
<b>Response(s)</b>	<i>method</i> : Integer corresponding to the parameter used as <b>Transition Reference</b> : 0: the <b>In-Band</b> parameter is set. 1: the <b>Out-Band</b> parameter is set.
<b>Example(s)</b>	:CALC:PAR:PBAN:TRAN INB :CALC:PAR:PBAN:TRAN? returns 0

**:CALCulate:PARameters:PDL[:ACTivate]**

<b>Description</b>	This command enables/disables the PDL Analysis analysis tool.
<b>Applicability</b>	This command is only available if: <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:CALCulate:PARameters:PDL[:ACTivate]</i> <wsp> <state>
<b>Parameter(s)</b>	<i>state</i> : Activation state of the PDL Analysis tool. The allowed values are: 0 OFF: disables the tool. 1 ON: enables the tool.
<b>Example(s)</b>	<i>:CALC:PAR:PDL:ACT ON</i>

**:CALCulate:PARameters:PDL[:ACTivate]?**

<b>Description</b>	This query returns the activation state of the PDL Analysis analysis tool.
<b>Applicability</b>	This query is only available if: <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:CALCulate:PARameters:PDL[:ACTivate]?</i>
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : Integer corresponding to the activation state set for the PDL Analysis tool: 0: the tool is disabled. 1: the tool is enabled.
<b>Example(s)</b>	<i>:CALC:PAR:PDL:ACT OFF</i> <i>:CALC:PAR:PDL:ACT?</i> returns 0

**:CALCulate:PARameters:PDL:BPERCentage**

<b>Description</b>	<p>This command defines the % <b>Bandwidth 1</b> parameter of the <b>PDL Analysis</b> analysis tool.</p> <p>The corresponding GUI setting is % <b>Bandwidth</b> (<i>only if Frequency Range is set to % Bandwidth 1</i>) on page 168.</p>
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to WPCT</li> <li>➤ :CALCulate:PARameters:PDL:RANGe on page 398 is set to PBWidt</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:PDL:BPERCentage<wsp> <percentage>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>percentage</i>: Percentage of bandwidth calculated from Spectral Width 1 (centered on the grid wavelength/frequency) to use for calculation, in the range 0.1 to 100.</li> <li>➤ <i>MIN</i> Minimum programmable value: 0.1 %</li> <li>➤ <i>MAX</i>: Maximum programmable value: 100 %</li> </ul>
<b>Example(s)</b>	:CALC:PAR:PDL:BPERC 25.5

---

**:CALCulate:PARameters:PDL:BPERCentage?**

<b>Description</b>	This query returns the % <b>Bandwidth 1</b> parameter set for the <b>PDL Analysis</b> analysis tool.
<b>Applicability</b>	<p>This query is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT</li> <li>➤ <i>:CALCulate:PARameters:PDL:RANGe</i> on page 398 is set to PBWidth</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:PDL:BPERCentage? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ MIN The query returns the minimum programmable value.</li> <li>➤ MAX The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<i>&lt;percentage&gt;</i>
<b>Response(s)</b>	<p><i>percentage:</i></p> <p>Percentage of bandwidth calculated from Spectral Width 1 (centered on the grid wavelength/frequency) used for calculation.</p>
<b>Example(s)</b>	<p>:CALC:PAR:PDL:BPERCentage 25.5</p> <p>:CALC:PAR:PDL:BPERCentage? returns +2.55000000E+001</p>

**:CALCulate:PARameters:PDL:CPERCentage**

<b>Description</b>	<p>This command defines the % <b>Channel spacing</b> parameter of the <b>PDL Analysis</b> analysis tool.</p> <p>The corresponding GUI setting is % <b>Channel</b> (<i>only if Frequency Range is set to % Channel spacing</i>) on page 168.</p>
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to WPCT</li> <li>➤ :CALCulate:PARameters:PDL:RANGe on page 398 is set to PCWidth</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:PDL:CPERCentage<wsp> <percentage>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>percentage</i>: Percentage of the channel width to use for calculation, in the range 0.1 to 100.</li> <li>➤ <i>MIN</i> Minimum programmable value: 0.1 %</li> <li>➤ <i>MAX</i>: Maximum programmable value: 100 %</li> </ul>
<b>Example(s)</b>	:CALC:PAR:PDL:CPERC 30

---

**:CALCulate:PARameters:PDL:CPERcentage?**

<b>Description</b>	This query returns the % <b>Channel spacing</b> parameter set for the <b>PDL Analysis</b> analysis tool.
<b>Applicability</b>	<p>This query is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT</li> <li>➤ <i>:CALCulate:PARameters:PDL:RANGe</i> on page 398 is set to PCWidth</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:PDL:CPERcentage?[MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ MIN The query returns the minimum programmable value.</li> <li>➤ MAX The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<i>&lt;percentage&gt;</i>
<b>Response(s)</b>	<p><i>percentage:</i></p> <p>Percentage of the channel width used for calculations.</p>
<b>Example(s)</b>	<p>:CALC:PAR:PDL:CPERcentage 50</p> <p>:CALC:PAR:PDL:CPERcentage? returns +5.00000000E+001</p>

**:CALCulate:PARameters:PDL:RANGe**

<b>Description</b>	This command defines the <b>Frequency Range</b> parameter for the <b>PDL Analysis</b> analysis tool. The corresponding GUI setting is <b>Frequency Range</b> on page 167.
<b>Applicability</b>	This command is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:CALCulate:PARameters:PDL:RANGe</i> <wsp><method>
<b>Parameter(s)</b>	<i>method</i> : Method used to define the spectral range from which the maximum PDL level is measured. The allowed values are: 0 FIXed: a fixed span is used to define the spectral range. It is set using the command <i>:CALCulate:PARameters:PDL:SPAN</i> on page 399. 1 PBWidth: a percentage of bandwidth is used to define the spectral range, calculated using Spectral Width 1. It is set using the command <i>:CALCulate:PARameters:PDL:BPERCentage</i> on page 394. 2 PCWidth: a percentage of the channel bandwidth is used to define the spectral range. It is set using the command <i>:CALCulate:PARameters:PDL:CPERCentage</i> on page 396.
<b>Example(s)</b>	<i>:CALC:PAR:PDL:RANG PBW</i>

**:CALCulate:PARameters:PDL:RANGe?**

<b>Description</b>	This query returns the <b>Frequency Range</b> parameter set for the <b>PDL Analysis</b> analysis tool.
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:CALCulate:PARameters:PDL:RANGe?</i>
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Integer representing the method used to define the spectral range from which the maximum PDL level is measured.
<b>Example(s)</b>	<i>:CALC:PAR:PDL:RANG PBW</i> <i>:CALC:PAR:PDL:RANG?</i> returns 1



**:CALCulate:PARAmeters:PDL:SPAN**

<b>Description</b>	<p>This command defines the <b>Calculation Span</b> parameter of the <b>PDL Analysis</b> analysis tool.</p> <p>The corresponding GUI setting is <b>Calculation Span</b> (<i>only if Frequency Range is set to Fixed Range</i>) on page 168.</p>
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT</li> <li>➤ <i>:CALCulate:PARAmeters:PDL:RANGe</i> on page 398 is set to FIXed</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:CALCulate:PARAmeters:PDL:SPAN</i> <wsp><span> [<unit>]   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>span</i>: Wavelength or frequency distance (centered on the grid wavelength/frequency) to use for calculation, as float value in the range 0.01 to 100 nm or 0.001 to 12.085 THz.</li> <li>➤ <i>unit</i> Unit of the set value. The allowed units are PM NM M HZ GHZ THZ The default unit is meter or Hertz, depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</li> <li>➤ <i>MIN</i> Minimum programmable value: 0.01 nm or 0.001 THz</li> <li>➤ <i>MAX</i>: Maximum programmable value: 100 nm or 12.085 THz</li> </ul>
<b>Example(s)</b>	<i>:CALC:PAR:PDL:SPAN 200PM</i>

**:CALCulate:PARAmeters:PDL:SPAN?**

<b>Description</b>	This query returns the <b>Calculation span</b> parameter set for the <b>PDL Analysis</b> analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"><li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT</li><li>➤ <i>:CALCulate:PARAmeters:PDL:RANGe</i> on page 398 is set to FIXed</li></ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PDL:SPAN?[MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"><li>➤ MIN The query returns the minimum programmable value.</li><li>➤ MAX The query returns the maximum programmable value.</li></ul>
<b>Response Syntax</b>	<span>
<b>Response(s)</b>	<i>span</i> : Wavelength or frequency distance in meters or Hertz depending on the unit setting (set with command <i>:UNIT:X</i> on page 533)..
<b>Example(s)</b>	:CALC:PAR:PDL:SPAN 200PM :CALC:PAR:PDL:SPAN? returns +2.00000000E-010

---

**:CALCulate:PARAmeters:PTSearch:ANTHreshold**

<b>Description</b>	This command enable/disables the <b>Auto Noise Threshold</b> function for the Peak Trough Search analysis tool (see <b>Auto Noise Threshold</b> on page 160).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PTSearch:ANTHreshold <wsp> <state>
<b>Parameter(s)</b>	<i>state</i> : Activation state of the <b>Auto Noise Threshold</b> function. The allowed values are: 0 OFF: disables the function. 1 ON: enables the function.
<b>Example(s)</b>	:CALC:PAR:PTS:ANTH ON

**:CALCulate:PARAmeters:PTSearch:ANTHreshold?**

<b>Description</b>	This query returns the activation state of the <b>Auto Noise Threshold</b> function for the Peak Trough Search analysis tool.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PTSearch:ANTHreshold?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : Integer corresponding to the activation state set for the <b>Auto Noise Threshold</b> function: 0 OFF: the function is disabled. 1 ON: the function is enabled.
<b>Example(s)</b>	:CALC:PAR:PTS:ANTH ON :CALC:PAR:PTS:ANTH? returns 1

**:CALCulate:PARAmeters:PTSearch:DISPlay[:STATe]**

<b>Description</b>	This command sets the <b>Display on Graph</b> setting for the Peak Trough Search analysis tool.  The corresponding GUI setting is <b>Display on Graph</b> on page 160.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PTSearch:DISPlay[:STATe] <wsp> <state>
<b>Parameter(s)</b>	<i>state:</i>  State of the analysis graphical items visibility on graph. The allowed values are: 0 OFF: makes the analysis graphical items invisible on graph. 1 ON: displays the analysis graphical items on graph.
<b>Example(s)</b>	:CALC:PAR:PTS:DISP[:STAT] ON

**:CALCulate:PARAmeters:PTSearch:DISPlay[:STATe]?**

<b>Description</b>	This query returns the <b>Display on Graph</b> setting for the Peak Trough Search analysis tool.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PTSearch:DISPlay[:STATe]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state:</i>  State of the analysis graphical items visibility on graph: 0: the analysis graphical items are not displayed on graph. 1: the analysis graphical items are displayed on graph.
<b>Example(s)</b>	:CALC:PAR:PTS:DISP[:STAT] ON :CALC:PAR:PTS:DISP[:STAT]? returns 1

**:CALCulate:PARAmeters:PTSearch:DISPlay:SHOW**

<b>Description</b>	This command sets the <b>Show</b> setting for the Peak Trough Search analysis tool (see <b>Display on Graph on page 160</b> ).
<b>Applicability</b>	This command is only available if <i>:CALCulate:PARAmeters:PTSearch:DISPlay[:STATe]</i> on page 402 is set to ON.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PTSearch:DISPlay:SHOW<wsp> <type>
<b>Parameter(s)</b>	<i>type</i> : Type of graphical item to display on graph. The allowed values are: 0 PEAKs: displays graphical items on peaks. 1 TROUghs: displays graphical items on troughs. 2 BOTH: displays graphical items on peaks and troughs.
<b>Example(s)</b>	:CALC:PAR:PTS:DISP:SHOW TRO

**:CALCulate:PARAmeters:PTSearch:DISPlay:SHOW?**

<b>Description</b>	This query returns the setting of the <b>Show</b> parameter for the Peak Trough Search analysis tool.
<b>Applicability</b>	This query is only available if <i>:CALCulate:PARAmeters:PTSearch:DISPlay[:STATe]</i> on page 402 is set to ON.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PTSearch:DISPlay:SHOW?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<type>
<b>Response(s)</b>	<i>type</i> : Integer corresponding to the type of graphical item that is displayed on graph for the Peak Trough Search analysis tool: 0: graphical items are displayed on peaks. 1: graphical items are displayed on troughs. 2: graphical items are displayed on peaks and troughs.
<b>Example(s)</b>	:CALC:PAR:PTS:DISP:SHOW TRO :CALC:PAR:PTS:DISP:SHOW? returns 1

**:CALCulate:PARameters:PTSearch:MTHReshold**

<b>Description</b>	This command sets the <b>Mode Threshold</b> value for the Peak Trough Search analysis tool (see <b>Mode Threshold on page 159</b> ).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:PTSearch:MTHReshold<wsp><value>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Mode threshold as float value in dB, in the range 0.01 to 100.</li> <li>➤ <i>MIN</i>: Minimum value: 0.01 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 100 dB.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:PTS:MTHR 20

---

**:CALCulate:PARameters:PTSearch:MTHReshold?**

<b>Description</b>	This query returns the <b>Mode Threshold</b> value for the Peak Trough Search analysis tool.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:PTSearch:MTHReshold? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Value set for the Mode threshold parameter in dB.
<b>Example(s)</b>	:CALC:PAR:PTS:MTHR 20 :CALC:PAR:PTS:MTHR? returns +2.00000000E+001

---

**:CALCulate:PARAmeters:PTSearch:PTTHreshold**

<b>Description</b>	This command sets the <b>PT Threshold</b> value for the Peak Trough Search analysis tool (see <b>PT Threshold</b> on page 159).
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PTSearch:PTTHreshold<wsp><value>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: PT threshold as float value in dB, in the range 0.01 to 50.</li> <li>➤ <i>MIN</i>: Minimum value: 0.01 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 50 dB.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:PTS:PTTH 3

**:CALCulate:PARAmeters:PTSearch:PTTHreshold?**

<b>Description</b>	This query returns the <b>PT Threshold</b> value for the Peak Trough Search analysis tool.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:PTSearch:PTTHreshold? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Value set for the PT threshold parameter in dB.
<b>Example(s)</b>	:CALC:PAR:PTS:PTTH 3 :CALC:PAR:PTS:PTTH? returns +3.00000000E+000

**:CALCulate:PARAmeters:SBand[:ACTivate]**

<b>Description</b>	This command enables/disables the Stop Band analysis tool.
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBand[:ACTivate] <wsp> <state>
<b>Parameter(s)</b>	<i>state</i> : Activation state of the Stop Band tool. The allowed values are: 0 OFF: disables the tool. 1 ON: enables the tool.
<b>Example(s)</b>	:CALC:PAR:SBAN:ACT ON

**:CALCulate:PARAmeters:SBand[:ACTivate]?**

<b>Description</b>	This query returns the activation state of the Stop Band analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBand[:ACTivate]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : Integer corresponding to the activation state set for the Stop Band tool: 0: the tool is disabled. 1: the tool is enabled.
<b>Example(s)</b>	:CALC:PAR:SBAN:ACT OFF :CALC:PAR:SBAN:ACT? returns 0



**:CALCulate:PARAmeters:SBANd:ARANge**

<b>Description</b>	This command sets the <b>Averaging Range</b> parameter for the Stop Band Test analysis tool (for more details, see <b>Average Loss &amp; Ripple Settings on page 186</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:ARANge<wsp> <method>
<b>Parameter(s)</b>	<p><i>method</i>:</p> <p>Parameter set as <b>Averaging Range</b>, spectral range over which the average loss and ripple are calculated.</p> <p>The allowed values are:</p> <p>0 FIXed: sets the averaging range to <b>Fixed Range</b>. The corresponding fixed span value is defined with the following command :CALCulate:PARAmeters:SBANd:SPAN on page 419</p> <p>1 PBWidth: sets the averaging range to % <b>Bandwidth 1</b>. The corresponding percentage is defined with the following command :CALCulate:PARAmeters:SBANd:PERCentage on page 416.</p> <p>2 PTDetection: sets the averaging range to <b>PT Detection</b>. The corresponding value is defined with the following command :CALCulate:PARAmeters:SBANd:THReshold on page 421.</p>
<b>Example(s)</b>	:CALC:PAR:SBAN:ARAN PBW

**:CALCulate:PARameters:SBANd:ARANge?**

<b>Description</b>	This query returns the <b>Averaging Range</b> parameter set for the Stop Band Test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"><li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li><li>➤ <i>:CALCulate:PARameters:CSElector:TYPE</i> on page 360 is set to STOP.</li></ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:SBANd:ARANge?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<method>
<b>Response(s)</b>	<i>method</i> : Integer corresponding to the method used as <b>Averaging Range</b> : 0: the <b>Fixed Range</b> parameter is set as averaging range. 1: the <b>% Bandwidth 1</b> parameter is set as averaging range. 2: the <b>PT Detection</b> parameter is set as averaging range.
<b>Example(s)</b>	:CALC:PAR:SBAN:ARAN PBW :CALC:PAR:SBAN:ARAN? returns 1

---

<b>:CALCulate:PARAmeters:SBANd:BDIStance</b>	
<b>Description</b>	This command defines the <b>IN/OUT Band Distance</b> parameter for the Stop Band Test analysis tool (for more details, see <b>Isolation Depth Settings on page 185</b> ).
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ <b>:CALCulate:MODE</b> on page 325 is set to PCT.</li> <li>➤ <b>:CALCulate:PARAmeters:CSElector:TYPE</b> on page 360 is set to STOP.</li> <li>➤ <b>:CALCulate:PARAmeters:SBANd:BMETHOD</b> on page 411 is set to SET.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	<b>:CALCulate:PARAmeters:SBANd:BDIStance</b> <wsp> <value> [ <b>&lt;unit&gt;</b> ]   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <b>value:</b> Wavelength or frequency as float value corresponding to the distance between the in-band reference point and the out-band reference point.</li> <li>➤ <b>unit:</b> Unit of the distance. The allowed values are PM NM M HZ GHZ THZ The default unit is meter or hertz, depending on the unit setting (set with command <b>:UNIT:X</b> on page 533).</li> <li>➤ <b>MIN:</b> Minimum value: 0.05 nm or 0.006 THz.</li> <li>➤ <b>MAX:</b> Maximum value: 450 nm or 54.384 THz.</li> </ul>
<b>Example(s)</b>	<b>:CALC:PAR:SBAN:BDIS 5NM</b>

**:CALCulate:PARAmeters:SBANd:BDIStance?**

<b>Description</b>	This query returns the <b>IN/OUT Band Distance</b> parameter set for the Stop Band Test analysis tool.
<b>Applicability</b>	<p>This query is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> <li>➤ <i>:CALCulate:PARAmeters:SBANd:BMETHOD</i> on page 411 is set to SET.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:BDIStance? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<p><i>value</i>:</p> <p>Wavelength or frequency value corresponding to the distance between the in-band reference point and the out-band reference point, as float value in meters or Hertz depending on the unit setting (see <i>:UNIT:X</i> on page 533).</p>
<b>Example(s)</b>	<p>:CALC:PAR:SBAN:BDIS 5NM</p> <p>:CALC:PAR:SBAN:BDIS? returns +5.00000000E-009</p>

---

**:CALCulate:PARAmeters:SBANd:BMETHOD**

<b>Description</b>	This command sets the <b>IN/OUT Band Method</b> parameter for the Stop Band Test analysis tool (for more details, see <b>Isolation Depth Settings on page 185</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:BMETHOD <wsp> <method>
<b>Parameter(s)</b>	<i>method</i> : Parameter set as <b>IN/OUT Band Method</b> . The allowed values are: 0 BWIDth: sets the <b>Bandwidth 1</b> method as in/out band method. The out-band reference points are calculated using the <b>Notch Width 1</b> tool results (see <i>:CALCulate:DATA:NW1?</i> on page 335). 1 SET: sets the <b>Set Distance</b> method as in/out band method. The spacing value is the value defined using <i>:CALCulate:PARAmeters:SBANd:BDistance</i> on page 409.
<b>Example(s)</b>	:CALC:PAR:SBAN:BMET BWID

**:CALCulate:PARAmeters:SBANd:BMETHOD?**

<b>Description</b>	This query returns the <b>IN/OUT Band Method</b> parameter set for the Stop Band Test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:BMETHOD?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<method>
<b>Response(s)</b>	<i>method</i> : Integer corresponding to the method used as <b>IN/OUT Band Method</b> : 0: <b>Bandwidth 1</b> is set as in/out band method. 1: <b>Set Distance</b> is set as in/out band method.
<b>Example(s)</b>	:CALC:PAR:SBAN:BMET BWID :CALC:PAR:SBAN:BMET? returns 0

**:CALCulate:PARAmeters:SBANd:DISPlay**

<b>Description</b>	This command sets the <b>Display on Graph</b> setting for the Stop Band Test analysis tool.
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:DISPlay<wsp> <state>
<b>Parameter(s)</b>	<i>state</i> : State of the analysis graphical items visibility on graph. The allowed values are: 0 OFF: makes the analysis graphical items invisible on graph. 1 ON: displays the analysis graphical items on graph.
<b>Example(s)</b>	:CALC:PAR:SBAN:DISP ON

**:CALCulate:PARAmeters:SBANd:DISPlay?**

<b>Description</b>	This query returns the <b>Display on Graph</b> setting for the Stop Band Test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:DISPlay?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : State of the analysis graphical items visibility on graph: 0: the analysis graphical items are not displayed on graph. 1: the analysis graphical items are displayed on graph.
<b>Example(s)</b>	:CALC:PAR:SBAN:DISP ON :CALC:PAR:SBAN:DISP? returns 1

**:CALCulate:PARameters:SBANd:EXCLusion:MAXimum**

<b>Description</b>	This command defines the <b>Max Exclusion Thresh.</b> parameter for the Stop Band Test analysis tool (for more details, see <b>Roll-Off &amp; Transition Band Settings on page 188</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARameters:CSElector:TYPE</i> on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:SBANd:EXCLusion:MAXimum<wsp> <value>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Maximum threshold in dB under which you want the roll-off to be calculated.</li> <li>➤ <i>MIN</i>: Minimum value: 3.01 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 100 dB.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:SBAN:EXCL:MAX 20

---

**:CALCulate:PARameters:SBANd:EXCLusion:MAXimum?**

<b>Description</b>	This query returns the <b>Max Exclusion Thresh.</b> parameter set for the Stop Band Test analysis tool.
<b>Applicability</b>	<p>This query is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARameters:CSElector:TYPE</i> on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:CALCulate:PARameters:SBANd:EXCLusion:MAXimum?</i> [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<p><i>value</i>:</p> <p>Maximum threshold in dB under which the roll-off is calculated.</p>
<b>Example(s)</b>	<p><i>:CALC:PAR:SBAN:EXCL:MAX 20</i></p> <p><i>:CALC:PAR:SBAN:EXCL:MAX?</i> returns +2.00000000E+001</p>

---



**:CALCulate:PARAmeters:SBANd:EXCLusion:MINimum**

<b>Description</b>	This command defines the <b>Min Exclusion Thresh.</b> parameter for the Stop Band Test analysis tool (for more details, see <b>Roll-Off &amp; Transition Band Settings on page 188</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:EXCLusion:MINimum<wsp> <value>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Minimum threshold in dB above which you want the roll-off to be calculated.</li> <li>➤ <i>MIN</i>: Minimum value: 0 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 19.99 dB.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:SBAN:EXCL:MIN 3

**:CALCulate:PARAmeters:SBANd:EXCLusion:MINimum?**

<b>Description</b>	This query returns the <b>Min Exclusion Thresh.</b> parameter set for the Stop Band Test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:EXCLusion:MINimum? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Minimum threshold in dB above which the roll-off is calculated.
<b>Example(s)</b>	:CALC:PAR:SBAN:EXCL:MIN 3 :CALC:PAR:SBAN:EXCL:MIN? returns +3.00000000E+000

**:CALCulate:PARAmeters:SBANd:PERCentage**

<b>Description</b>	This command defines the % <b>Bandwidth</b> parameter for the Stop Band Test analysis tool (for more details, see <b>Average Loss &amp; Ripple Settings on page 186</b> ).
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> <li>➤ <i>:CALCulate:PARAmeters:SBANd:ARANge</i> on page 407 is set to PBWidth.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:PERCentage<wsp> <percentage>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>percentage</i>: Fraction in percent of <b>Bandwidth 1</b> calculated from Notch Width 1 tool (see <i>:CALCulate:DATA:NW1?</i> on page 335) to be used as a range for average loss and ripple calculation.</li> <li>➤ <i>MIN</i>: Minimum value: 0 %.</li> <li>➤ <i>MAX</i>: Maximum value: 100 %.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:SBAN:PERC 25.5

---

**:CALCulate:PARAmeters:SBANd:PERCentage?**

<b>Description</b>	This query returns the % <b>Bandwidth</b> parameter set for the Stop Band Test analysis tool.
<b>Applicability</b>	<p>This query is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> <li>➤ <i>:CALCulate:PARAmeters:SBANd:ARANge</i> on page 407 is set to PBWidth.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:PERCentage? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<percentage>
<b>Response(s)</b>	<p><i>percentage</i>:</p> <p>Percentage of <b>Bandwidth 1</b> calculated from Notch Width 1 tool used as a range for average loss and ripple calculation.</p>
<b>Example(s)</b>	<p>:CALC:PAR:SBAN:PERC 25.5</p> <p>:CALC:PAR:SBAN:PERC? returns +2.55000000E+001</p>

**:CALCulate:PARAmeters:SBANd:REFeRence**

<b>Description</b>	This command sets the <b>Reference</b> parameter for the Stop Band Test analysis tool (for more details, see <b>Isolation Depth Settings on page 185</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSELeCtor:TYPE</i> on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:REFeRence<wsp><point>
<b>Parameter(s)</b>	<p><i>point:</i></p> <p>In-band point to use as <b>Reference</b> point, calculated from the <b>Notch Width 1</b> tool results (see <i>:CALCulate:DATA:NW1?</i> on page 335). The allowed values are:</p> <p>0 TROUgh: sets the <b>Trough wavelength</b> as reference point.</p> <p>1 CENTer: sets the <b>Center wavelength</b> as reference point.</p>
<b>Example(s)</b>	:CALC:PAR:SBAN:REF TROU

**:CALCulate:PARAmeters:SBANd:REFeRence?**

<b>Description</b>	This query returns the <b>Reference</b> parameter set for the Stop Band Test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSELeCtor:TYPE</i> on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:REFeRence?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<point>
<b>Response(s)</b>	<p><i>point:</i></p> <p>Integer corresponding to the point used as <b>Reference</b> point:</p> <p>0: the <b>Trough wavelength</b> is set as reference point.</p> <p>1: the <b>Center wavelength</b> is set as reference point.</p>
<b>Example(s)</b>	<p>:CALC:PAR:SBAN:REF CENT</p> <p>:CALC:PAR:SBAN:REF? returns 1</p>

**:CALCulate:PARAmeters:SBANd:SPAN**

<b>Description</b>	This command defines the <b>Calculation Span</b> parameter for the Stop Band Test analysis tool (for more details, see <b>Average Loss &amp; Ripple Settings on page 186</b> ).
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> <li>➤ <i>:CALCulate:PARAmeters:SBANd:ARANge</i> on page 407 is set to FIXed.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:SPAN<wsp><value>[<unit>] MIN MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Wavelength or frequency as float value corresponding to the span over which average loss and ripple will be calculated, followed by the wanted unit.</li> <li>➤ <i>unit</i>: Unit of the span value. The allowed values are PM NM M HZ GHZ THZ The default unit is meter or hertz, depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</li> <li>➤ <i>MIN</i>: Minimum value: 0 nm or 0 THz.</li> <li>➤ <i>MAX</i>: Maximum value: 100 nm or 12.085 THz.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:SBAN:SPAN 200PM

**:CALCulate:PARAmeters:SBANd:SPAN?**

<b>Description</b>	This query returns the <b>Calculation Span</b> parameter set for the Stop Band Test analysis tool.
<b>Applicability</b>	<p>This query is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> <li>➤ <i>:CALCulate:PARAmeters:SBANd:ARANge</i> on page 407 is set to FIXed.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:SPAN? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<p><i>value</i>:</p> <p>Wavelength or frequency value corresponding to the span over which average loss and ripple will be calculated, as float value in meters or Hertz depending on the unit setting (see <i>:UNIT:X</i> on page 533).</p>
<b>Example(s)</b>	<p>:CALC:PAR:SBAN:SPAN 200PM</p> <p>:CALC:PAR:SBAN:SPAN? returns +2.00000000E-010</p>

---

**:CALCulate:PARAmeters:SBANd:THReshold**

<b>Description</b>	This command defines the <b>Detection Threshold</b> parameter for the Stop Band Test analysis tool (for more details, see <b>Average Loss &amp; Ripple Settings on page 186</b> ).
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> <li>➤ <i>:CALCulate:PARAmeters:SBANd:ARANge</i> on page 407 is set to PTDetection.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:CALCulate:PARAmeters:SBANd:THReshold</i> <wsp> <value>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Threshold in dB for the detection of in-band extreme peaks to be used as averaging range for loss and ripple calculation.</li> <li>➤ <i>MIN</i>: Minimum value: 0.01 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 50 dB.</li> </ul>
<b>Example(s)</b>	<i>:CALC:PAR:SBAN:THR 0.2</i>

**:CALCulate:PARameters:PBANd:THReshold?**

<b>Description</b>	This query returns the <b>Detection Threshold</b> parameter set for the Stop Band Test analysis tool.
<b>Applicability</b>	<p>This query is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARameters:CSElector:TYPE</i> on page 360 is set to STOP.</li> <li>➤ <i>:CALCulate:PARameters:SBANd:ARANge</i> on page 407 is set to PTDetection.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:SBANd:THReshold? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<p><i>value</i>:</p> <p>Detection threshold in dB used as averaging range for loss and ripple calculation.</p>
<b>Example(s)</b>	<p>:CALC:PAR:SBAN:THR 0.2</p> <p>:CALC:PAR:SBAN:THR? returns +2.00000000E-001</p>

---



**:CALCulate:PARAmeters:SBANd:TRANSition**

<b>Description</b>	This command sets the <b>Transition Reference</b> parameter for the Stop Band Test analysis tool (for more details, see <b>Roll-Off &amp; Transition Band Settings on page 188</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:TRANSition<wsp> <point>
<b>Parameter(s)</b>	<i>point</i> : Parameter set as <b>Transition Reference</b> , the reference point used to determine the spectral range over which the roll-off is calculated. The allowed values are: 0 INBand: sets the reference point to <b>In-Band</b> . 1 OUTBand: sets the reference point to <b>Out-Band</b> .
<b>Example(s)</b>	:CALC:PAR:SBAN:TRAN INB

**:CALCulate:PARAmeters:SBANd:TRANSition?**

<b>Description</b>	This query returns the <b>Transition Reference</b> parameter set for the Stop Band Test analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to STOP.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SBANd:TRANSition?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<method>
<b>Response(s)</b>	<i>method</i> : Integer corresponding to the parameter used as <b>Transition Reference</b> : 0: the <b>In-Band</b> parameter is set. 1: the <b>Out-Band</b> parameter is set.
<b>Example(s)</b>	:CALC:PAR:SBAN:TRAN INB :CALC:PAR:SBAN:TRAN? returns 0

**:CALCulate:PARameters:SW[1...3]:ALGorithm**

<b>Description</b>	This command sets the <b>Algorithm</b> setting for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool (for more details, see <b>Spectral Width Detection Settings (<i>PCT analysis mode</i>) on page 170</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARameters:CSElector:TYPE on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:SW[1...3]:ALGorithm<wsp> <algorithm>
<b>Parameter(s)</b>	<p><i>algorithm:</i></p> <p>Algorithm to use for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool. The allowed values are:</p> <p>0 THReshold: sets the <b>Threshold</b> algorithm.</p> <p>1 ENvelope: sets the <b>Envelope</b> algorithm.</p> <p>2 RMS: sets the <b>RMS</b> algorithm.</p> <p>3 RMSPeak: sets the <b>RMS Peak</b> algorithm.</p> <p>4 GFIT: sets the <b>Gaussian Fit</b> algorithm.</p> <p>5 LFIT: sets the <b>Lorentzian Fit</b> algorithm.</p>
<b>Example(s)</b>	:CALC:PAR:SW1:ALG GFIT

---

**:CALCulate:PARameters:SW[1...3]:ALGorithm?**

<b>Description</b>	This query returns the algorithm used for the calculation of the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARameters:CSElector:TYPE on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:SW[1...3]:ALGorithm?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<algorithm>
<b>Response(s)</b>	<p><i>algorithm:</i></p> <p>Integer corresponding to the algorithm used for calculation of the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool:</p> <p>0: the <b>Threshold</b> algorithm is used.</p> <p>1: the <b>Envelope</b> algorithm is used.</p> <p>2: the <b>RMS</b> algorithm is used.</p> <p>3: the <b>RMS Peak</b> algorithm is used.</p> <p>4: the <b>Gaussian Fit</b> algorithm is used.</p> <p>5: the <b>Lorentzian Fit</b> algorithm is used.</p>
<b>Example(s)</b>	:CALC:PAR:SW1:ALG GFIT :CALC:PAR:SW1:ALG? returns 4

**:CALCulate:PARAmeters:SW[1...3]:DISPlay**

<b>Description</b>	This command sets the <b>Display on Graph</b> setting for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool.
<b>Applicability</b>	This command is only available if <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SW[1...3]:DISPlay<wsp><state>
<b>Parameter(s)</b>	<i>state:</i> State of the analysis graphical items visibility on graph. The allowed values are: 0 OFF: makes the analysis graphical items invisible on graph. 1 ON: displays the analysis graphical items on graph.
<b>Example(s)</b>	:CALC:PAR:SW1:DISP ON :CALC:PAR:SW2:DISP ON :CALC:PAR:SW3:DISP OFF

---

**:CALCulate:PARAmeters:SW[1...3]:DISPlay?**

<b>Description</b>	This query returns the <b>Display on Graph</b> setting for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool.
<b>Applicability</b>	This query is only available if <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SW[1...3]:DISPlay?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state:</i> State of the analysis graphical items visibility on graph: 0: the analysis graphical items are not displayed on graph. 1: the analysis graphical items are displayed on graph.
<b>Example(s)</b>	CALC:PAR:SW2:DISP ON :CALC:PAR:SW2:DISP? returns 1

---

<b>:CALCulate:PARAmeters:SW[1...3]:FMODE</b>	
<b>Description</b>	This command enables/disables the <b>Fit to Mode</b> function for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool (for more details, see <b>Fitting Options on page 172</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:SW[1...3]:ALGorithm</i> on page 424 (for the corresponding tool) is set to THReshold.</li> <li>➤ <i>:CALCulate:PARAmeters:SW[1...3]:MANalysis</i> on page 428 (for the corresponding tool) is set to ON.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SW[1...3]:FMODE<wsp> <state>
<b>Parameter(s)</b>	<i>state</i> : Activation state of the <b>Fit to Mode</b> function. The allowed values are: 0 OFF: disables the function. 1 ON: enables the function.
<b>Example(s)</b>	:CALC:PAR:SW1:FMODE ON

<b>:CALCulate:PARAmeters:SW[1...3]:FMODE?</b>	
<b>Description</b>	This query returns the activation state of the <b>Fit to Mode</b> function for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:SW[1...3]:ALGorithm</i> on page 424 (for the corresponding tool) is set to THReshold.</li> <li>➤ <i>:CALCulate:PARAmeters:SW[1...3]:MANalysis</i> on page 428 (for the corresponding tool) is set to ON.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SW[1...3]:FMODE?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : Integer corresponding to the activation state set for the <b>Fit to Mode</b> function: 0: the function is disabled. 1: the function is enabled.
<b>Example(s)</b>	:CALC:PAR:SW1:FMODE ON :CALC:PAR:SW1:FMODE? returns 1

**:CALCulate:PARAmeters:SW[1...3]:MANalysis**

<b>Description</b>	This command enables/disables the <b>Modal Analysis</b> function for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool (for more details, see <b>Fitting Options on page 172</b> ).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:SW[1...3]:ALGorithm</i> on page 424 (for the corresponding tool) is set to THReshold, GFIT or LFIT.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SW[1...3]:MANalysis<wsp> <state>
<b>Parameter(s)</b>	<i>state</i> : Activation state of the <b>Modal Analysis</b> function. The allowed values are: 0 OFF: disables the function. 1 ON: enables the function.
<b>Example(s)</b>	:CALC:PAR:SW1:MAN ON

**:CALCulate:PARAmeters:SW[1...3]:MANalysis?**

<b>Description</b>	This query returns the activation state of the <b>Modal Analysis</b> function for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to PCT.</li> <li>➤ <i>:CALCulate:PARAmeters:SW[1...3]:ALGorithm</i> on page 424 (for the corresponding tool) is set to THReshold, GFIT or LFIT.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SW[1...3]:MANalysis?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : Integer corresponding to the activation state set for the <b>Modal Analysis</b> function: 0: the function is disabled. 1: the function is enabled.
<b>Example(s)</b>	:CALC:PAR:SW1:MAN OFF :CALC:PAR:SW1:MAN? returns 0

**:CALCulate:PARAmeters:SW[1...3]:METHod**

<b>Description</b>	This command sets the <b>Method</b> setting for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool (for more details, see <b>Spectral Width Detection Settings (PCT WDM analysis mode)</b> on page 173).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to WPCT.</li> <li>➤ :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SW[1...3]:METHod<wsp> <method>
<b>Parameter(s)</b>	<p><i>method</i>:</p> <p>Bandwidth calculation method to use for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool. The allowed values are:</p> <p>0 WTHReshold: sets the calculation method to <b>Width at Threshold</b>.</p> <p>1 G671: sets the calculation method to <b>ITU-T G.671</b>.</p>
<b>Example(s)</b>	:CALC:PAR:SW1:MET G671

**:CALCulate:PARAmeters:SW[1...3]:METHod?**

<b>Description</b>	This query returns the bandwidth calculation method used for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT.</li> <li>➤ <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SW[1...3]:METHod?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<method>
<b>Response(s)</b>	<i>method:</i> Integer corresponding to the method used for bandwidth calculation of the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool: 0: the <b>Width at Threshold</b> method is used. 1: the <b>ITU-T G.671</b> method is used.
<b>Example(s)</b>	:CALC:PAR:SW1:MET G671 :CALC:PAR:SW1:MET? returns 1

---



**:CALCulate:PARameters:SW[1...3]:MULTiplier**

<b>Description</b>	This command sets the <b>Multiplier</b> value for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool (for more details, see <b>Spectral Width Detection Settings (PCT analysis mode)</b> on page 170).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARameters:CSElector:TYPE on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:SW[1...3]:MULTiplier<wsp><value>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Multiplier factor as float value, in the range 1 to 10.</li> <li>➤ <i>MIN</i>: Minimum value: 1 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 10 dB.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:SW1:MULT 2.45

**:CALCulate:PARameters:SW[1...3]:MULTiplier?**

<b>Description</b>	This query returns the <b>Multiplier</b> value set for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to PCT.</li> <li>➤ :CALCulate:PARameters:CSElector:TYPE on page 360 is set to PASS.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:SW[1...3]:MULTiplier? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Value set for the Multiplier parameter.
<b>Example(s)</b>	:CALC:PAR:SW1:MULT 2.45 :CALC:PAR:SW1:MULT? returns +2.45000000E+000

**:CALCulate:PARAmeters:SW[1...3]:MTHReshold**

<b>Description</b>	This command sets the <b>Mode Threshold</b> value for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool (for more details, see <b>Spectral Width Detection Settings (PCT analysis mode)</b> on page 170).
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to <i>PCT</i>.</li> <li>➤ <i>:CALCulate:PARAmeters:SW[1...3]:ALGorithm</i> on page 424 (for the corresponding tool) is set to <i>ENVELOpe</i>, <i>GFIT</i> or <i>LFIT</i>.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SW[1...3]:MTHReshold<wsp><value> MIN MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Mode detection threshold as float value in dB, in the range 0.01 to 50.</li> <li>➤ <i>MIN</i>: Minimum value: 0.01 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 50 dB.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:SW1:MTHR 40

**:CALCulate:PARAmeters:SW[1...3]:MTHReshold?**

<b>Description</b>	This query returns the <b>Mode Threshold</b> value for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to <i>PCT</i>.</li> <li>➤ <i>:CALCulate:PARAmeters:SW[1...3]:ALGorithm</i> on page 424 (for the corresponding tool) is set to <i>ENVELOpe</i>, <i>GFIT</i> or <i>LFIT</i>.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SW[1...3]:MTHReshold? [MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Value set for the Mode threshold parameter in dB.
<b>Example(s)</b>	:CALC:PAR:SW1:MTHR 40 :CALC:PAR:SW1:MTHR? returns +4.00000000E+001

**:CALCulate:PARAmeters:SW[1...3]:WTHReshold**

<b>Description</b>	This command sets the <b>Width Threshold</b> value for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool (for more details, see <b>Spectral Width Detection Settings (PCT analysis mode)</b> on page 170).
<b>Applicability</b>	This command is only available if :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to PASS.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SW1[1...3]:WTHReshold<wsp> <value>   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Detection threshold for the measurement of width as float value in dB, in the range 0.01 to 50.</li> <li>➤ <i>MIN</i>: Minimum value: 0.01 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 50 dB.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:SW1:WTHR 10

**:CALCulate:PARAmeters:SW[1...3]:WTHReshold?**

<b>Description</b>	This query returns the <b>Width Threshold</b> value for the Spectral Width 1, Spectral Width 2 or Spectral Width 3 analysis tool.
<b>Applicability</b>	This query is only available if :CALCulate:PARAmeters:CSElector:TYPE on page 360 is set to PASS.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SW[1...3]:WTHReshold? [MIN   MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>MIN</i>: The query returns the minimum programmable value.</li> <li>➤ <i>MAX</i>: The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Value set for the Width threshold parameter in dB.
<b>Example(s)</b>	:CALC:PAR:SW1:WTHR 10 :CALC:PAR:SW1:WTHR? returns +1.00000000E+001

**:CALCulate:PARAmeters:SW2|SW3:[:ACTivate]**

<b>Description</b>	This command enables/disables the Spectral Width 2 or Spectral Width 3 analysis tool.
<b>Applicability</b>	This command is only available if: <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SW2 SW3:[:ACTivate] <wsp> <state>
<b>Parameter(s)</b>	<i>state:</i> Activation state of the Spectral Width 2 or Spectral Width 3 tool. The allowed values are: 0 OFF: disables the tool. 1 ON: enables the tool.
<b>Example(s)</b>	:CALC:PAR:SW2:ACT ON

---

**:CALCulate:PARAmeters:SW2|SW3:[:ACTivate]?**

<b>Description</b>	This query returns the activation state of the Spectral Width 2 or Spectral Width 3 analysis tool.
<b>Applicability</b>	This query is only available if: <i>:CALCulate:PARAmeters:CSElector:TYPE</i> on page 360 is set to PASS.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:SW2 SW3:[:ACTivate]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state:</i> Integer corresponding to the activation state set for the Spectral Width 2 or Spectral Width 3 tool: 0: the tool is disabled. 1: the tool is enabled.
<b>Example(s)</b>	:CALC:PAR:SW3:ACT OFF :CALC:PAR:SW3:ACT? returns 0

---

**:CALCulate:PARAmeters:WDMChannel:BAND**

<b>Description</b>	This command sets the <b>Band</b> setting for the Channel Detection analysis tool set to ITU Grid. The corresponding GUI setting is <b>Band on page 165</b> .
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to WPCT.</li> <li>➤ :CALCulate:PARAmeters:WDMChannel:MODE on page 441 is set to ITU.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:WDMChannel:BAND<wsp> <band>
<b>Parameter(s)</b>	<i>band</i> : Band value for the ITU grid. The allowed values are: 0   C-BAND: sets the ITU grid band to C-band. 1   L-BAND: sets the ITU grid band to L-band.
<b>Example(s)</b>	:CALC:PAR:WDMC:BAND C-BAND

**:CALCulate:PARAmeters:WDMChannel:BAND?**

<b>Description</b>	This query returns the <b>Band</b> setting for the Channel Detection analysis tool set to ITU Grid.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to WPCT.</li> <li>➤ :CALCulate:PARAmeters:WDMChannel:MODE on page 441 is set to ITU.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:WDMChannel:BAND?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	< <i>band</i> >
<b>Response(s)</b>	<i>band</i> : Integer corresponding to the ITU grid band in use: 0: the ITU grid is set to C-band. 1: the ITU grid is set to L-band.
<b>Example(s)</b>	:CALC:PAR:WDMC:BAND L-BAND :CALC:PAR:WDMC:BAND? returns 1

**:CALCulate:PARameters:WDMChannel:BTHReshold**

<b>Description</b>	This command sets the <b>Bandwidth Threshold</b> setting for the Channel Detection analysis tool. The corresponding GUI setting is <i>Bandwidth Threshold</i> .
<b>Applicability</b>	This command is only available if : <i>CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:WDMChannel:BTHReshold<wsp><threshold>  MIN MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>threshold</i>: Detection threshold in dB for the calculation of the central wavelength/frequency of the channel's signal, in the range 0.01 to 50.</li> <li>➤ <i>MIN</i>: Minimum value: 0.01 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 50 dB.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:WDMC:BTHR 3

---

**:CALCulate:PARameters:WDMChannel:BTHReshold?**

<b>Description</b>	This query returns the <b>Bandwidth Threshold</b> setting for the Channel Detection analysis tool.
<b>Applicability</b>	This query is only available if : <i>CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:WDMChannel:BTHReshold?[MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ MIN The query returns the minimum programmable value.</li> <li>➤ MAX The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<threshold>
<b>Response(s)</b>	<i>threshold</i> : Threshold as float value in dB.
<b>Example(s)</b>	:CALC:PAR:WDMC:BTHReshold 3 :CALC:PAR:WDMC:BTHReshold? returns +3.00000000E+000

---

**:CALCulate:PARAmeters:WDMChannel:DISPlay**

<b>Description</b>	This command sets the <b>Display on Graph</b> setting for the Channel Detection analysis tool.
<b>Applicability</b>	This command is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:WDMChannel:DISPlay<wsp><state>
<b>Parameter(s)</b>	<i>state</i> : State of the analysis graphical items visibility on graph. The allowed values are: 0   OFF: makes the analysis graphical items invisible on graph. 1   ON: displays the analysis graphical items on graph.
<b>Example(s)</b>	:CALC:PAR:WDMC:DISP ON

**:CALCulate:PARAmeters:WDMChannel:DISPlay?**

<b>Description</b>	This query returns the <b>Display on Graph</b> setting for the Pass Band Test analysis tool.
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:WDMChannel:DISPlay?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : State of the analysis graphical items visibility on graph: 0: the analysis graphical items are not displayed on graph. 1: the analysis graphical items are displayed on graph.
<b>Example(s)</b>	:CALC:PAR:WDMC:DISP ON :CALC:PAR:WDMC:DISP? returns 1

**:CALCulate:PARameters:WDMChannel:EChannels**

<b>Description</b>	This command sets the <b>Empty Channel</b> setting for the Channel Detection analysis tool. The corresponding GUI setting is <i>Empty Channels</i> .
<b>Applicability</b>	This command is only available if : <i>CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:WDMChannel:EChannels<wsp>< <i>display</i> >
<b>Parameter(s)</b>	<i>display</i> : State of the channel visibility in the analysis result table. The allowed values are: 0 HIDE: hides the empty channels from the analysis result table. 1 SHOW: shows the empty channels in the analysis result table.
<b>Example(s)</b>	:CALC:PAR:WDMC:ECH HIDE

---

**:CALCulate:PARameters:WDMChannel:EChannels?**

<b>Description</b>	This query returns the <b>Empty Channel</b> setting for the Channel Detection analysis tool.
<b>Applicability</b>	This query is only available if : <i>CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:WDMChannel:EChannels?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	< <i>display</i> >
<b>Response(s)</b>	<i>display</i> : Integer corresponding to the channel visibility in the result table: 0: the empty channels are hidden. 1: the empty channels are shown.
<b>Example(s)</b>	:CALC:PAR:WDMC:ECH HIDE :CALC:PAR:WDMC:ECH? returns 0

---



**:CALCulate:PARAmeters:WDMChannel:FCHannel**

<b>Description</b>	This command sets the <b>First Channel</b> setting for the Channel Detection analysis tool set to CWDM Grid. The corresponding GUI setting is <i>First Channel</i> on page 165.
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to WPCT.</li> <li>➤ :CALCulate:PARAmeters:WDMChannel:MODE on page 441 is set to CWDM.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:WDMChannel:FCHannel<wsp><channel>
<b>Parameter(s)</b>	<i>channel</i> : Center wavelength of the first channel of the CWDM grid. The allowed values are: 0 1270nm: sets the first channel to 1270 nm. 1 1271nm: sets the first channel to 1271 nm.
<b>Example(s)</b>	:CALC:PAR:WDMC:FCH 1270nm

**:CALCulate:PARAmeters:WDMChannel:FCHannel?**

<b>Description</b>	This query returns the <b>First Channel</b> setting for the Channel Detection analysis tool set to CWDM Grid.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ :CALCulate:MODE on page 325 is set to WPCT.</li> <li>➤ :CALCulate:PARAmeters:WDMChannel:MODE on page 441 is set to CWDM.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:WDMChannel:FCHannel?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<band>
<b>Response(s)</b>	<i>band</i> : Integer corresponding to the center wavelength of the first channel of the CWDM grid: 0: the first channel is set to 1270 nm. 1: the first channel is set to 1271 nm.
<b>Example(s)</b>	:CALC:PAR:WDMC:FCH 1271nm :CALC:PAR:WDMC:FCH? returns 1

**:CALCulate:PARameters:WDMChannel:GSPacing**

<b>Description</b>	This command sets the <b>Grid Spacing</b> setting for the Channel Detection analysis tool. The corresponding GUI setting is <b>Grid Spacing on page 164</b> .
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT.</li> <li>➤ <i>:CALCulate:PARameters:WDMChannel:MODE</i> on page 441 is set to CGRID.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:WDMChannel:GSPacing<wsp><spacing>  MIN MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>spacing</i>: Grid spacing in GHz, in the range 1 to 200.</li> <li>➤ <i>MIN</i>: Minimum value: 1 dB.</li> <li>➤ <i>MAX</i>: Maximum value: 200 dB.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:WDMC:GSP 12.5

**:CALCulate:PARameters:WDMChannel:GSPacing?**

<b>Description</b>	This query returns the <b>Grid Spacing</b> setting for the Channel Detection analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT.</li> <li>➤ <i>:CALCulate:PARameters:WDMChannel:MODE</i> on page 441 is set to CGRID.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:WDMChannel:GSPacing?[MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ MIN The query returns the minimum programmable value.</li> <li>➤ MAX The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<threshold>
<b>Response(s)</b>	<i>threshold</i> : Grid Spacing as float value in Hz.
<b>Example(s)</b>	:CALC:PAR:WDMC:GSP 12.5 :CALC:PAR:WDMC:GSP? returns +1.25000000E+010

**:CALCulate:PARAmeters:WDMChannel:MODE**

<b>Description</b>	This command sets the <b>WDM Channel Mode</b> setting for the Channel Detection analysis tool. The corresponding GUI setting is <b>WDM Display Mode on page 163</b> .
<b>Applicability</b>	This command is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:WDMChannel:MODE<wsp><mode>
<b>Parameter(s)</b>	<i>mode</i> : Method used for WDM channel detection. The allowed values are: 0 CGRID: sets the <b>Custom Grid</b> as WDM channel detection method. 1 ITU: sets the <b>ITU Grid</b> as WDM channel detection method. 2 CWDM: set the <b>CWDM</b> grid as WDM channel detection method.
<b>Example(s)</b>	:CALC:PAR:WDMC:MOD CGRID

**:CALCulate:PARAmeters:WDMChannel:MODE?**

<b>Description</b>	This query returns the <b>WDM Channel Mode</b> setting for the Channel Detection analysis tool.
<b>Applicability</b>	This query is only available if <i>:CALCulate:MODE</i> on page 325 is set to WPCT.
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:WDMChannel:MODE?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<mode>
<b>Response(s)</b>	<i>mode</i> : Integer corresponding to the method used for WDM channel detection: 0: the <b>Custom Grid</b> is set as WDM channel detection method. 1: the <b>ITU Grid</b> is set as WDM channel detection method. 2: the <b>CWDM</b> grid is set as WDM channel detection method.
<b>Example(s)</b>	:CALC:PAR:WDMC:MOD ITU :CALC:PAR:WDMC:MOD? returns 2

**:CALCulate:PARAmeters:WDMChannel:RFRequency**

<b>Description</b>	This command sets the <b>Reference Frequency</b> setting for the Channel Detection analysis tool set to Custom Grid. The corresponding GUI setting is <b>Reference Frequency</b> on page 164.
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT.</li> <li>➤ <i>:CALCulate:PARAmeters:WDMChannel:MODE</i> on page 441 is set to CGRID.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:WDMChannel:RFRequency<wsp><value>  MIN MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>value</i>: Reference frequency as float value in THz to use for the calculation of the grid channels, in the range 178.4479 to 241.7681 THz.</li> <li>➤ <i>MIN</i>: Minimum value: 178.4479 THz.</li> <li>➤ <i>MAX</i>: Maximum value: 241.7681 THz.</li> </ul>
<b>Example(s)</b>	:CALC:PAR:WDMC:RFR 193.1

**:CALCulate:PARAmeters:WDMChannel:RFRequency?**

<b>Description</b>	This query returns the <b>Reference Frequency</b> setting for the Channel Detection analysis tool.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT.</li> <li>➤ <i>:CALCulate:PARAmeters:WDMChannel:MODE</i> on page 441 is set to CGRID.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:WDMChannel:RFRequency?[MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ MIN The query returns the minimum programmable value.</li> <li>➤ MAX The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<value>
<b>Response(s)</b>	<i>value</i> : Reference frequency as float value in Hz.
<b>Example(s)</b>	:CALC:PAR:WDMC:RFR 193.1 :CALC:PAR:WDMC:RFR? returns +1.93100000E+014

**:CALCulate:PARameters:WDMChannel:SPACing**

<b>Description</b>	This command sets the <b>Spacing</b> setting for the Channel Detection analysis tool set to ITU Grid. The corresponding GUI setting is <b>Spacing on page 165</b> .
<b>Applicability</b>	This command is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT.</li> <li>➤ <i>:CALCulate:PARameters:WDMChannel:MODE</i> on page 441 is set to ITU.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:WDMChannel:SPACing<wsp> <spacing>
<b>Parameter(s)</b>	<i>spacing</i> : Grid spacing value for the ITU grid. The allowed values are: 0 25GHz: sets the spacing value for the ITU grid to 25 GHz. 1 50GHz: sets the spacing value for the ITU grid to 50 GHz. 2 100GHz: sets the spacing value for the ITU grid to 100GHz. 3 200GHz: sets the spacing value for the ITU grid to 200 GHz.
<b>Example(s)</b>	:CALC:PAR:WDMC:SPAC 25GHz

**:CALCulate:PARameters:WDMChannel:SPACing?**

<b>Description</b>	This query returns the <b>Spacing</b> setting for the Channel Detection analysis tool set to ITU Grid.
<b>Applicability</b>	This query is only available if: <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT.</li> <li>➤ <i>:CALCulate:PARameters:WDMChannel:MODE</i> on page 441 is set to ITU.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:WDMChannel:SPACing?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<spacing>
<b>Response(s)</b>	<i>spacing</i> : Integer corresponding to the ITU grid spacing value: 0: the spacing value for the ITU grid is set to 25 GHz. 1: the spacing value for the ITU grid is set to 50 GHz. 2: the spacing value for the ITU grid is set to 100GHz. 3: the spacing value for the ITU grid is set to 200 GHz.
<b>Example(s)</b>	:CALC:PAR:WDMC:SPAC 25GHz :CALC:PAR:WDMC:SPAC? returns 0

**:CALCulate:PARAmeters:WDMChannel:STARt**

<b>Description</b>	<p>This command defines the <b>Start Wavelength/Frequency</b> parameter of the Channel Detection analysis tool.</p> <p>The corresponding GUI setting is <b>Start Wavelength/Frequency</b> on <b>page 164</b>.</p>
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT</li> <li>➤ <i>:CALCulate:PARAmeters:IMEASurement:RANGe</i> on page 366 is set to FIXed</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:WDMChannel:STARt<wsp><start> [<unit>]   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>start</i>: Start wavelength or frequency for the generation of the grid, as float value in the range 1240 to 1679.99 nm or 178.448 to 241.767 THz.</li> <li>➤ <i>unit</i> Unit of the set value. The allowed units are PM NM M HZ GHZ THZ The default unit is meter or Hertz, depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</li> <li>➤ <i>MIN</i> Minimum programmable value: 1240 nm or 178.448 THz</li> <li>➤ <i>MAX</i>: Maximum programmable value: 1679.99 nm or 241.767 THZ</li> </ul>
<b>Example(s)</b>	:CALC:PAR:WDMC:STAR 1525NM

---

**:CALCulate:PARameters:WDMChannel:STARt?**

<b>Description</b>	This query returns the <b>Start Wavelength/Frequency</b> parameter of the Channel Detection analysis tool.
<b>Applicability</b>	<p>This query is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT</li> <li>➤ <i>:CALCulate:PARameters:IMEASurement:RANGe</i> on page 366 is set to FIXed</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:WDMChannel:STARt?[MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ MIN The query returns the minimum programmable value.</li> <li>➤ MAX The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<start>
<b>Response(s)</b>	<p><i>start:</i></p> <p>Wavelength or frequency start value in meters or Hertz depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</p>
<b>Example(s)</b>	<p>:CALC:PAR:WDMC:STAR 1525NM</p> <p>:CALC:PAR:WDMC:STAR? returns +1.52500000E-006</p>

---

**:CALCulate:PARameters:WDMChannel:STOP**

<b>Description</b>	<p>This command defines the <b>Stop Wavelength/Frequency</b> parameter of the Channel Detection analysis tool.</p> <p>The corresponding GUI setting is <b>Stop Wavelength/Frequency</b> on <b>page 164</b>.</p>
<b>Applicability</b>	<p>This command is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT</li> <li>➤ <i>:CALCulate:PARameters:IMEASurement:RANGe</i> on page 366 is set to FIXed</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARameters:WDMChannel:STOP<wsp><stop> [<unit>]   MIN   MAX
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>stop</i>: Start wavelength or frequency for the generation of the grid, as float value in the range 1240.01 to 1680 nm or 178.449 to 241.768 THz.</li> <li>➤ <i>unit</i> Unit of the set value. The allowed units are PM NM M HZ GHZ THZ The default unit is meter or Hertz, depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</li> <li>➤ <i>MIN</i> Minimum programmable value: 1240.01 nm or 178.449 THz</li> <li>➤ <i>MAX</i>: Maximum programmable value: 1680 nm or 241.768 THZ</li> </ul>
<b>Example(s)</b>	:CALC:PAR:WDM:STOP 1625NM

---



**:CALCulate:PARAmeters:WDMChannel:STOP?**

<b>Description</b>	This query returns the <b>Stop Wavelength/Frequency</b> parameter of the Channel Detection analysis tool.
<b>Applicability</b>	<p>This query is only available if:</p> <ul style="list-style-type: none"> <li>➤ <i>:CALCulate:MODE</i> on page 325 is set to WPCT</li> <li>➤ <i>:CALCulate:PARAmeters:IMEASurement:RANGe</i> on page 366 is set to FIXed</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:CALCulate:PARAmeters:WDMChannel:STOP?[MIN MAX]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ MIN The query returns the minimum programmable value.</li> <li>➤ MAX The query returns the maximum programmable value.</li> </ul>
<b>Response Syntax</b>	<stop>
<b>Response(s)</b>	<p><i>stop:</i></p> <p>Wavelength or frequency stop value in meters or Hertz depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</p>
<b>Example(s)</b>	<p>:CALC:PAR:WDMC:STOP 1525NM</p> <p>:CALC:PAR:WDMC:STOP? returns +1.62500000E-006</p>

## DISPlay Commands and Queries

### Quick Reference

Command Overview					Parameter(s)	Section
DISPlay	FOCUS				<category>, <trace> [, <channel>, <type> ]	see p. 449
	FOCUS?					see p. 450

### Commands and Queries

**:DISPlay:FOCUS**

<b>Description</b>	This command selects a trace for auto-scale, zooming operations and marker measurements.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:DISPlay:FOCUS<wsp><category>[,<trace>,<channel>,<type>]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>category</i>: Category of the trace to select: 0 NONE: no trace is selected. 1 SENse: trace linked to a measuring connector. 2 STORe: stored trace.</li> <li>➤ <i>trace</i>: For SENse traces: integer corresponding to the module identification number, which is the position of the module in the mainframe from left to right, in the range 1 to 20. For STORe traces: integer corresponding to the store trace identifier, in the range 1 to 20. To know the store trace identifier, use the command :TRACe:LIST:STORe? on page 507.</li> <li>➤ <i>channel</i>: For SENse traces only: integer corresponding to the detector identification number, which is the detector position on the module from top to bottom, in the range 1 to 6. This number is not taken into account for BR traces.</li> <li>➤ <i>type</i>: For SENse traces only: integer corresponding to the trace type, in the range 1 to 10 and 14 to 18: 1: TF live 2: TF max 3: TF min 4: TF average 5: TF roll average 6: BR live (only available on an IL RL OPM2 module) 7: BR max (only available on an IL RL OPM2 module) 8: BR min (only available on an IL RL OPM2 module) 9: BR average (only available on an IL RL OPM2 module) 10: BR roll average (only available on an IL RL OPM2 module) 14: PDL live (only available on an IL PDL or IL PDL OPM2 module) 15: PDL max (only available on an IL PDL or IL PDL OPM2 module) 16: PDL min (only available on an IL PDL or IL PDL OPM2 module) 17: PDL average (only available on an IL PDL or IL PDL OPM2 module) 18: PDL roll average (only available on an IL PDL or IL PDL OPM2 module)</li> </ul>
<b>Example(s)</b>	:DISP:FOCUS 1,2,5,3

:DISPlay:FOCUS?	
<b>Description</b>	This query returns the selected trace.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:DISPlay:FOCUS?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<category>,<trace>,<channel>,<type>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>category</i>: Category of the trace to select: 0 NONE: no trace is selected. 1 SENse: trace linked to a measuring connector. 2 STORE: stored trace.</li> <li>➤ <i>trace</i>: For SENse traces: integer corresponding to the module identification number, which is the position of the module in the mainframe from left to right, in the range 1 to 20.  For STORE traces: integer corresponding to the store trace identifier, in the range 1 to 20. To know the store trace identifier, use the command :TRACe:LIST:STORE? on page 507.</li> <li>➤ <i>channel</i>: For SENse traces only: integer corresponding to the detector identification number, which is the detector position on the module from top to bottom, in the range 1 to 6. This number is not taken into account for BR traces.</li> <li>➤ <i>type</i>: For SENse traces only: integer corresponding to the trace type, in the range 1 to 10 and 14 to 18: 1: TF live 2: TF max 3: TF min 4: TF average 5: TF roll average 6: BR live (only available on an IL RL OPM2 module) 7: BR max (only available on an IL RL OPM2 module) 8: BR min (only available on an IL RL OPM2 module) 9: BR average (only available on an IL RL OPM2 module) 10: BR roll average (only available on an IL RL OPM2 module) 14: PDL live (only available on an IL PDL or IL PDL OPM2 module) 15: PDL max (only available on an IL PDL or IL PDL OPM2 module) 16: PDL min (only available on an IL PDL or IL PDL OPM2 module) 17: PDL average (only available on an IL PDL or IL PDL OPM2 module) 18: PDL roll average (only available on an IL PDL or IL PDL OPM2 module)</li> </ul>
<b>Example(s)</b>	:DISP:FOCUS 2,15,0,0 :DISP:FOCUS? returns 2,15,0,0

## INITiate Commands and Queries

In INITiate:TLS[1...4]:

[1...4] designates the TLS in use in the subsystem (TLS1 to TLS4) to which you want to apply the command or query.

### Quick reference

Command Overview				Parameter(s)	Section
INITiate	[IMMediate]				see p. 452
	CURRent?				see p. 453
	DCHAINing	TRIGout[1...4]		<Secondary Trig in>	see p. 454
		TRIGout[1...4]?			see p. 454
	FBC	[SENSe]			see p. 455
		[SENSe?]			see p. 455
		INPut[1...4]		<TLS>	see p. 456
		INPut[1...4]?			see p. 457
	ILRL	[SENSe]		<slot>	see p. 458
		[SENSe?]			see p. 458
		TLSIn		<TLS>	see p. 459
		TLSIn?			see p. 460
	LASer	POWER		<power> [ <unit> ]	see p. 461
		POWER?			see p. 461
	PROGress?				see p. 462
	SCAN	ILPDL?			see p. 462
	SCANsync	[SENSe]		<slot>	see p. 463
		[SENSe?]			see p. 463
	SMODE			<mode>	see p. 465
	SMODE?				see p. 465
	SOP			<state of polarization>	see p. 466
	SOP?				see p. 467
	SOP	CURRent?			see p. 468
		DATA?		<format> [, <reduction> ]	see p. 469
	STABilization			<output> [, <duration> ]	see p. 471
	STABilization?				see p. 471
	STARtup	PROGress?			see p. 472
	TLS[1...4]	[IDentifier]		<identifier>	see p. 473
		[IDentifier?]			see p. 473
		ACTive		<state>	see p. 474

Command Overview				Parameter(s)	Section
		ACTive?			see p. 474
		AVG		<mode>[,<value>[<unit>]]	see p. 475
		AVG?			see p. 476
		POWer		<power>[<unit>]	see p. 477
		POWer?			see p. 477
		SPEed		<speed>	see p. 478
		SPEed?			see p. 478
		TRIGin		<trigger>	see p. 479
		TRIGin?			see p. 479
		WAVelength	START	<start value>[<unit>]	see p. 480
			START?		see p. 481
			STOP	<stop value>[<unit>]	see p. 482
			STOP?		see p. 483
	TMODE			<start mode>	see p. 484
	TMODE?				see p. 484
	WAVelength	SAMPling		<sampling>[PM]	see p. 485
		SAMPling?			see p. 485
		START		<start value>[<unit>]	see p. 486
		START?			see p. 486
		STOP		<stop value>[<unit>]	see p. 487
		STOP?			see p. 487

**Commands and Queries**

<b>:INITiate[:IMMediate]</b>	
<b>Description</b>	<p>This command performs a scan with the current parameters.</p> <p>You can stop the scan with the :STOP command.</p> <p>You can abort the scan with the :ABORT command.</p>
<b>Type</b>	<p>Overlapped, no query.</p> <p>When the system executes this command, the bit 2 "Scanning" is set in the Operational Status Condition Register (see :STATus:OPERation:CONDition? on page 251 and Operational / Questionable Status Reporting on page 205).</p>
<b>Syntax</b>	:INITiate[:IMMediate]
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:INIT

**:INITiate:CURRent?**

<b>Description</b>	This query returns the number of sweeps performed for the in progress acquisition.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:INITiate:CURRent?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<count>
<b>Response(s)</b>	<i>count</i> : Integer corresponding to the current number of sweeps.
<b>Example(s)</b>	:INIT:CURRent? returns 50

---

**:INITiate:DCHAINing:TRIGout[1...4]**

<b>Description</b>	This command sets the electrical trigger link between the Primary CTP10 and the Secondary CTP10. For more details on daisy chaining, see <i>Using Additional OPMs (Daisy Chaining mode)</i> on page 107
<b>Applicability</b>	This command is only available in Daisy chaining mode: the Daisy chaining connexion must have previously been open (response 1 to :CTP:DCHAINing:ID1:LINK? on page 262). In daisy chaining mode, this command is not available on Secondary CTP10s (response 2 to :CTP:DCHAINing:STATus? on page 265).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:DCHAINing:TRIGout[1...4]<wsp><Secondary TRIG IN>
<b>Parameter(s)</b>	[1...4] designates the TRIG OUT port (on the current CTP10) to use for daisy chaining. <i>Secondary TRIG IN:</i> Integer representing the identifier of the TRIG IN port of the Secondary CTP10 to use for daisy chaining, in the range 11 to 18: <ul style="list-style-type: none"> <li>➤ 0: no trigger input port is used.</li> <li>➤ 11 to 18: TRIG IN 1 to TRIG IN 8 input ports of the Secondary CTP10.</li> </ul>
<b>Example(s)</b>	:INIT:DCHAIN:TRIG3 11

**:INITiate:DCHAINing:TRIGout[1...4]?**

<b>Description</b>	This query returns the electrical trigger input used on the Secondary CTP10 for the given TRIG OUT port on the current CTP10.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:DCHAINing:TRIGout[1...4]?
<b>Parameter(s)</b>	None. [1...4] designates the TRIG OUT port (on the current CTP10) used for daisy chaining.
<b>Response Syntax</b>	<Secondary TRIG IN>
<b>Response(s)</b>	<i>Secondary TRIG IN:</i> Integer representing the identifier of the TRIG IN port of the Secondary CTP10 used for daisy chaining, in the range 11 to 18: <ul style="list-style-type: none"> <li>➤ 0: no trigger input port is used.</li> <li>➤ 11 to 18: TRIG IN 1 to TRIG IN 8 input ports of the Secondary CTP10.</li> </ul>
<b>Example(s)</b>	:INIT:DCHAIN:TRIG3 11 :INIT:DCHAIN:TRIG3 returns 11



**:INITiate:FBC[:SENSe]**

<b>Description</b>	This command defines the slot number of the FBC module in use in the CTP10 mainframe.
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:FBC[:SENSe] <wsp> <slot>
<b>Parameter(s)</b>	<i>slot</i> : Integer representing the position of the FBC module in the mainframe (from left to right), in the range 1 to 10. If no FBC module is in use, set 0.
<b>Example(s)</b>	:INIT:FBC:SENSe 2

**:INITiate:FBC[:SENSe]?**

<b>Description</b>	This query returns the slot number of the FBC module in use in the CTP10 mainframe.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:FBC[:SENSe]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<slot>
<b>Response(s)</b>	<i>slot</i> : Integer representing the position of the FBC module in the mainframe (from left to right), in the range 1 to 10. The query returns 0 if no IL RL OPM2 or IL PDL OPM2 module is defined.
<b>Example(s)</b>	:INIT:FBC:SENSe 2 :INIT:FBC:SENSe? returns 2

<b>:INITiate:FBC:INPut[1...4]</b>	
<b>Description</b>	<p>This command defines the TLS connected to the given TLS IN port of the FBC module in use in the CTP10 mainframe.</p> <p>[1...4] designates the TLS IN port of the FBC module to which the command applies.</p> <p>To modify the connection of a TLS previously connected to the FBC (to directly connect it to the IL RL OPM2 module for example), do not forget to cancel the connection by setting this command to 0 before setting the new connection of the TLS.</p>
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:FBC:INPut[1...4] <wsp> <TLS>
<b>Parameter(s)</b>	<p><i>TLS</i>:</p> <p>Integer representing the TLS connected to the given TLS IN port of the FBC module, in the range 0 to 4:</p> <p>0: no TLS is connected.</p> <p>1: laser set as TLS 1 in the subsystem (with command <i>:INITiate:TLS[1...4][:Identifier]</i> on page 473).</p> <p>2: laser set as TLS 2 in the subsystem (with command <i>:INITiate:TLS[1...4][:Identifier]</i> on page 473).</p> <p>3: laser set as TLS 3 in the subsystem (with command <i>:INITiate:TLS[1...4][:Identifier]</i> on page 473).</p> <p>4: laser set as TLS 4 in the subsystem (with command <i>:INITiate:TLS[1...4][:Identifier]</i> on page 473).</p>
<b>Example(s)</b>	:INIT:FBC:INP1 3

**:INITiate:FBC:INPut[1...4]?**

<b>Description</b>	This query returns the TLS connected to the given TLS IN port of the FBC module in use in the CTP10 mainframe.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:FBC:INPut[1...4]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<laser>
<b>Response(s)</b>	<i>laser</i> : Integer representing the TLS connected to the given TLS IN port of the FBC module, in the range 0 to 4: 0: no TLS is connected. 1: laser set as TLS 1 in the subsystem. 2: laser set as TLS 2 in the subsystem. 3: laser set as TLS 3 in the subsystem. 4: laser set as TLS 4 in the subsystem.
<b>Example(s)</b>	:INIT:FBC:INP1 3 :INIT:FBC:INP1? returns 3

---

**:INITiate:ILRL[:SENSe]**

<b>Description</b>	<p>This command defines the slot number of the IL RL OPM2 or IL PDL or IL PDL OPM2 measurement module in use in the CTP10 mainframe and sets the optical link from the Out to DUT port of this module to the input port of the DUT.</p> <p>If trace types are activated (see <i>:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10]/[14...18]:ACTive</i> on page 515), this command deletes traces that are not compatible with the selected module:</p> <ul style="list-style-type: none"> <li>➤ If you select an IL RL OPM2 module, all existing PDL trace types are deleted.</li> <li>➤ If you select an IL PDL or IL PDL OPM2 module, all existing BR trace types are deleted.</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:ILRL[:SENSe] <wsp> <slot>
<b>Parameter(s)</b>	<p><i>slot</i>:</p> <p>Integer representing the position of the IL RL OPM2 or IL PDL or IL PDL OPM2 measurement module in the mainframe (from left to right), in the range 1 to 10.</p> <p>If no IL RL OPM2 or IL PDL or IL PDL OPM2 module is in use, set 0.</p>
<b>Example(s)</b>	:INIT:ILRL:SENSe 4

**:INITiate:ILRL[:SENSe]?**

<b>Description</b>	This query returns the slot number of the IL RL OPM2 or IL PDL or IL PDL OPM2 module in use in the CTP10 mainframe.
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:ILRL[:SENSe]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<slot>
<b>Response(s)</b>	<p><i>slot</i>:</p> <p>Integer representing the position of the IL RL OPM2 or IL PDL or IL PDL OPM2 module in the mainframe (from left to right), in the range 1 to 10.</p> <p>The query returns 0 if no IL RL OPM2 or IL PDL or IL PDL OPM2 module is defined.</p>
<b>Example(s)</b>	<p>:INIT:ILRL:SENSe 4</p> <p>:INIT:ILRL:SENSe? returns 4</p>

**:INITiate:ILRL:TLsIn**

<b>Description</b>	<p>This command defines and sets the optical link to the TLS (or FBC module) connected to the input port of the IL RL OPM2 or IL PDL or IL PDL OPM2 module in use in the CTP10 mainframe.</p> <p>To modify the connection of a TLS previously connected to the IL RL OPM2 or IL PDL or IL PDL OPM2 module (to connect the IL RL OPM2 module to the FBC module for example), do not forget to cancel the connection by setting this command to 0 before setting the new connection of the TLS.</p>
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:ILRL:TLsIn<wsp> <TLS>
<b>Parameter(s)</b>	<p><i>laser:</i></p> <p>Integer representing the TLS or FBC output port connected to the TLS IN port of the IL RL OPM2 or IL PDL or IL PDL OPM2 module, in the range 0 to 5:</p> <p>0: no TLS is connected.</p> <p>1: laser set as TLS 1 in the subsystem (with <i>:INITiate:TLs[1...4][:IDentifier]</i> on page 473).</p> <p>2: laser set as TLS 2 in the subsystem (with <i>:INITiate:TLs[1...4][:IDentifier]</i> on page 473).</p> <p>3: laser set as TLS 3 in the subsystem (with <i>:INITiate:TLs[1...4][:IDentifier]</i> on page 473).</p> <p>4: laser set as TLS 4 in the subsystem (with <i>:INITiate:TLs[1...4][:IDentifier]</i> on page 473).</p> <p>5: only available with the IL RL OPM2 or IL PDL OPM2 module. Output port of the FBC module (FBC OUT).</p>
<b>Example(s)</b>	:INIT:ILRL:TLs 4

:INITiate:ILRL:TLSin?	
<b>Description</b>	This query returns the TLS (or FBC module) set as connected to the input port of the IL RL OPM2 or IL PDL or IL PDL OPM2 module in use in the CTP10 mainframe.
<b>Applicability</b>	In laser sharing mode, this query is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STaTus? on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:ILRL:TLSin?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<TLS>
<b>Response(s)</b>	<p><i>laser:</i></p> <p>Integer representing the TLS or FBC output port connected to the TLS IN port of the IL RL OPM2 or IL PDL or IL PDL OPM2 module, in the range 0 to 5:</p> <p>0: no laser is connected.</p> <p>1: laser set as TLS 1 in the subsystem.</p> <p>2: laser set as TLS 2 in the subsystem.</p> <p>3: laser set as TLS 3 in the subsystem.</p> <p>4: laser set as TLS 4 in the subsystem.</p> <p>5: output port of the FBC module (FBC OUT). Only available with the IL RL OPM2 or IL PDL OPM2 module.</p>
<b>Example(s)</b>	<p>:INIT:ILRL:TLSin 4</p> <p>:INIT:ILRL:TLSin? returns 4</p>

---

**:INITiate:LASer:POWer (Deprecated)**

<b>Description</b>	This command is deprecated, use <i>:INITiate:TLS[1...4]:POWer</i> on page 477 instead.  This command sets the power of all lasers used for the sweep.
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:INITiate:LASer:POWer</i> <wsp><power>[<unit>]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>power</i>: Laser power as float value for the sweep.</li> <li>➤ <i>unit</i>: Unit of the power value. The allowed units are DBm (dBm) or MW (mW). The default unit is dBm.</li> </ul>
<b>Example(s)</b>	<i>:INIT:LAS:POW 1DBM</i>

**:INITiate:LASer:POWer? (Deprecated)**

<b>Description</b>	This query is deprecated, use <i>:INITiate:TLS[1...4]:POWer?</i> on page 477 instead.  This query returns the laser power for the sweep, only if a single laser is used for the sweep.
<b>Type</b>	Overlapping.
<b>Syntax</b>	<i>:INITiate:LASer:POWer?</i>
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<power>
<b>Response(s)</b>	<i>power</i> :  Laser power set for the sweep in dBm or W depending on the unit setting (set with command <i>:UNIT:Y</i> on page 534).
<b>Example(s)</b>	<i>:INIT:LAS:POW 1DBM</i>  <i>:INIT:LAS:POW?</i> returns +1.00000000E+000

**:INITiate:PROGress?**

<b>Description</b>	This query returns the progress value of the current sweep.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:INITiate:PROGress?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<progress>
<b>Response(s)</b>	<i>progress:</i> Integer corresponding to the progress of the current sweep in percent.
<b>Example(s)</b>	:INIT:PROGress? returns 27

---

**:INITiate:SCAN:ILPDL?**

<b>Description</b>	This query returns the measurement scan type that will be performed at next scan, based on the current list of traces when the query is received.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:INITiate:SCAN:ILPDL?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<scan type>
<b>Response(s)</b>	<i>scan type:</i> Integer corresponding to the scan type that will be performed at next scan: 0: single-sweep scan (IL-only measurement scan) 1: 4-sweeps scan (IL/PDL or PDL-only measurement scan)
<b>Example(s)</b>	:INIT:SCAN:ILPDL? returns 1

---



**:INITiate:SCANsync[:SENSe]**

<b>Description</b>	This command defines the slot number of the SCAN SYNC module in use in the CTP10 mainframe and sets the optical link to the Out to SCAN SYNC (or OUT1) port of the IL RL OPM2 or Il PDL or IL PDL OPM2 module.
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:SCANsync[:SENSe] <wsp> <slot>
<b>Parameter(s)</b>	<i>slot</i> : Integer representing the position of the SCAN SYNC module in the mainframe (from left to right), in the range 1 to 10. If no SCAN SYNC module is in use, set 0.
<b>Example(s)</b>	:INIT:SCANsync:SENSe 5

**:INITiate:SCANsync[:SENSe]?**

<b>Description</b>	This query returns the slot number of the SCAN SYNC module in use in the CTP10 mainframe.
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:SCANsync[:SENSe]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<slot>
<b>Response(s)</b>	<i>slot</i> : Integer representing the position of the SCAN SYNC module in the mainframe (from left to right), in the range 1 to 10. The query returns 0 if no SCAN SYNC module is defined.
<b>Example(s)</b>	:INIT:SCAN:SENSe 5 :INIT:SCAN:SENSe? returns 5

**:INITiate:SINTerval (Deprecated)**

<b>Description</b>	This command is deprecated and will be removed from the next version.
	This command sets the sweep interval for continuous scans.
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10. (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276)
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:SINTerval<wsp><interval>[,<duration>]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>interval</i>: Activation state of the sweep interval. The allowed values are: 0 OFF: no pause between sweeps. 1 ON: sets a pause between sweeps in continuous scan mode, defined by the &lt;duration&gt; parameter (see below). In laser sharing mode, this parameter is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).</li> <li>➤ <i>duration</i>: Period of time between the beginning of two successive scans, in the range 1 to 999 seconds.</li> </ul>
<b>Example(s)</b>	:INIT:SINT ON,6.9

**:INITiate:SINTerval? (Deprecated)**

<b>Description</b>	This query is deprecated and will be removed from the next version.
	This query returns the sweep interval set for continuous scans.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:SINTerval?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<interval>,<duration>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>interval</i>: Activation state of the sweep interval: 0: no pause is set between sweeps. 1: a pause is observed between sweeps in continuous scan mode, defined by the &lt;duration&gt; value (see below).</li> <li>➤ <i>duration</i>: Period of time between the beginning of two successive scans.</li> </ul>
<b>Example(s)</b>	:INIT:SINT OFF,5.3 :INIT:SINT? returns 0,5.3

<b>:INITiate:SMODE</b>	
<b>Description</b>	This command sets the acquisition scanning mode. The corresponding GUI setting is <b>Scan mode</b> (see <b>Scan mode on page 122</b> ).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:SMODE<wsp> <mode>
<b>Parameter(s)</b>	<i>mode</i> : Scanning mode. The allowed values are: 0   SINGLE: single scan mode. 1   CONTinuous: continuous scan mode.
<b>Example(s)</b>	:INIT:SMOD SING

<b>:INITiate:SMODE?</b>	
<b>Description</b>	This query returns the acquisition scanning mode.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:SMODE?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<mode>
<b>Response(s)</b>	<i>mode</i> : Scanning mode: 0: single scan mode. 1: continuous scan mode.
<b>Example(s)</b>	:INIT:SMOD CONT :INIT:SMOD? returns 1

:INITiate:SOP	
<b>Description</b>	This command sets the state of polarization to use for the next IL only measurements with an IL PDL or IL PDL OPM2 module.
<b>Applicability</b>	This command is only available on setups using an IL PDL module.
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:SOP<wsp><state of polarization>
<b>Parameter(s)</b>	<i>state of polarization:</i> Integer representing the state of polarization. <ul style="list-style-type: none"> <li>➤ The allowed values on the IL PDL are:               <ul style="list-style-type: none"> <li>1: LVP Linearly vertical polarized.</li> <li>2: LHP Linearly horizontal polarized.</li> <li>3: L-45 Linear -45° polarized.</li> <li>4: RCP Right circularly polarized.</li> </ul> </li> <li>➤ The allowed values on the IL PDL OPM2 are:               <ul style="list-style-type: none"> <li>1: state of polarization #1</li> <li>2: state of polarization #2</li> <li>3: state of polarization #3</li> <li>4: state of polarization #4</li> </ul> </li> </ul>
<b>Example(s)</b>	:INIT:SOP 2

---

<b>:INITiate:SOP?</b>	
<b>Description</b>	This query returns the state of polarization used for the IL only measurements with an IL PDL or IL PDL OPM2 module.
<b>Applicability</b>	This command is only available on setups using an IL PDL module.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:SOP?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state of polarization>
<b>Response(s)</b>	<p><i>state of polarization:</i></p> <p>Integer corresponding to the state of polarization set.</p> <ul style="list-style-type: none"> <li>➤ On the IL PDL module: <ul style="list-style-type: none"> <li>1: LVP Linearly vertical polarized.</li> <li>2: LHP Linearly horizontal polarized.</li> <li>3: L-45 Linear -45° polarized.</li> <li>4: RCP Right circularly polarized.</li> <li>0: not applicable on the module.</li> </ul> </li> <li>➤ On the IL PDL OPM2 module: <ul style="list-style-type: none"> <li>1: state of polarization #1</li> <li>2: state of polarization #2</li> <li>3: state of polarization #3</li> <li>4: state of polarization #4</li> <li>0: not applicable on the module.</li> </ul> </li> </ul>
<b>Example(s)</b>	:INIT:SOP? returns 2

---

<b>:INITiate:SOP:CURRent?</b>	
<b>Description</b>	This query returns the current state of polarization used for the TF/PDL measurement in progress, with an IL PDL or IL PDL OPM2 module.
<b>Applicability</b>	This command is only available on setups using an IL PDL or IL PDL OPM2 module.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:INITiate:SOP:CURRent?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state of polarization>
<b>Response(s)</b>	<p><i>state of polarization:</i></p> <p>Integer corresponding to the state of polarization currently used during the TF/PDL measurement in progress.</p> <ul style="list-style-type: none"> <li>➤ On the IL PDL module: <ul style="list-style-type: none"> <li>0: not applicable</li> <li>1: LVP Linearly vertical polarized.</li> <li>2: LHP Linearly horizontal polarized.</li> <li>3: L-45 Linear -45° polarized.</li> <li>4: RCP Right circularly polarized.</li> </ul> </li> <li>➤ On the IL PDL OPM2 module: <ul style="list-style-type: none"> <li>0: not applicable.</li> <li>1: state of polarization #1</li> <li>2: state of polarization #2</li> <li>3: state of polarization #3</li> <li>4: state of polarization #4</li> </ul> </li> </ul>
<b>Example(s)</b>	:INITiate:SOP:CURRent? returns 2

---

**:INITiate:SOP:DATA?**

<b>Description</b>	<p>This query returns data that describe the state of polarization (SOP) of the last measurement performed with an IL PDL or IL PDL OPM2 module.</p> <ul style="list-style-type: none"> <li>➤ For a TF-only measurement, data retrieved corresponds to the state of polarization set using the <i>:INITiate:SOP</i> command (see <i>p. 466</i>), for each wavelength/frequency of the trace sample (or the default state of polarization if the <i>:INITiate:SOP</i> command has not been used).</li> <li>➤ For a 4 state IL-PDL measurement (4 sweeps), data retrieved corresponds to the four states of polarization.</li> </ul>
<b>Applicability</b>	This command is only available on setups using an IL PDL or IL PDL OPM2 module.
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:INITiate:SOP:DATA?</i> <wsp> <format> [, <reduction> ]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>format</i>            Format of the SOP data. The allowed values are:            0 ASCii: SOP data is formatted as ASCII values, such as &lt;value1&gt;, &lt;value2&gt;, &lt;value3&gt;, ...            1 BINary: SOP data is formatted as binary blocks such as:            # &lt;length&gt; &lt;Nb of bytes&gt; &lt;blocks&gt;            where:            &lt;length&gt;: number of subsequent bytes that you have to check to know the total length.            &lt;Nb of bytes&gt;: size of &lt;blocks&gt; in bytes.            &lt;blocks&gt;: float data bytes (packet of 4 bytes, big endian).            For example, data containing 12 data points will results in the header "#248&lt;blocks&gt;" as 48 bytes are needed to define the data and "48" length is 2.         </li> <li>➤ <i>reduction</i>            Reduction factor (optional), which decimates the number of data points for faster data retrieval. A reduction factor of 5 would select a point out of every 5 points available on the trace. The first value received always corresponds to the "start wavelength" data point.         </li> </ul>

**:INITiate:SOP:DATA?****Response Syntax** <SOP data>**Response(s)***SOP data:*

Triplets of values corresponding to the normalized Stokes parameters of the Stokes vector: &lt;S1&gt;,&lt;S2&gt;,&lt;S3&gt;

- If the <format> parameter is ASCii, the response data syntax for <data> is formatted as follows:  
<S1>,<S2>,<S3>,<S1>,<S2>,<S3> ...
- If the <format> parameter is BINary, the response data syntax for <data> is formatted as binary blocks.

On 4-state IL-PDL measurement (4 sweeps), the query returns SOP data of the four states of polarization one after another, formatted as follows: [[<S1>,<S2>,<S3>] trace SOP#1],[<S1>,<S2>,<S3>] trace SOP#2],[<S1>,<S2>,<S3>] trace SOP#3],[<S1>,<S2>,<S3>] trace SOP#4]

**Example(s)**

:INITiate:SOP:DATA? ASCII returns -1.0000,-0.0002,-0.0049,...



**:INITiate:STABilization**

<b>Description</b>	This command sets the output settings of the lasers used for the scan.
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10 (response 2 to <i>:CTP:LSHARing:STaTus?</i> on page 276)
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:STABilization<wsp><output>[,<duration>]
<b>Parameter(s)</b>	<p>➤ <i>output</i>:</p> <p>Activation state of the laser after scan stop. The allowed values are:</p> <p>0 OFF: disables the laser optical output when the scan stops.</p> <p>1 ON: sets the laser optical output to stay enabled after scan stop. In laser sharing mode, this parameter is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STaTus?</i> on page 276).</p> <p>The corresponding GUI setting is <b>Keep enabled after scan stop</b> (see <b>Keep enabled after scan stop on page 118</b>).</p> <p>➤ <i>duration</i>:</p> <p>Period of time during which you want the laser to stabilize before starting the acquisition, in the range 0 to 60 seconds.</p> <p>The corresponding GUI setting is <b>Stabilization Time</b> (see <b>Stabilization Time on page 118</b>).</p>
<b>Example(s)</b>	:INIT:STAB OFF,12.3

**:INITiate:STABilization?**

<b>Description</b>	This query returns the output settings of the lasers used for the scan.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:STABilization?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<output>,<duration>
<b>Response(s)</b>	<p>➤ <i>output</i>:</p> <p>Activation state of the laser after scan stop:</p> <p>0: the laser optical output is disabled when the scan stops.</p> <p>1: the laser optical output stays enabled after scan stop.</p> <p>➤ <i>duration</i>:</p> <p>Period of time during which you want the laser to stabilize before starting the acquisition.</p>
<b>Example(s)</b>	<p>:INIT:STAB ON,5.6</p> <p>:INIT:STAB? returns 1,5.6</p>

:INITiate:STARtup:PROGress?	
<b>Description</b>	This query returns the progress value of the scan initialization (for the current sweep).
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:INITiate:STARtup:PROGress?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<progress>
<b>Response(s)</b>	<i>progress:</i> Integer corresponding to the progress of the scan initialization in percent.
<b>Example(s)</b>	:INIT:STAR:PROG? returns 95

---

**:INITiate:TLS[1...4][:IDentifier]**

<b>Description</b>	<p>This command defines the identifier of the laser to use as a TLS in the subsystem.</p> <p>The corresponding GUI setting is the selection of a TLS in the <b>Subsystem setup</b> menu (see <i>Selecting/Removing the Laser(s)</i> on page 103).</p>
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:TLS[1...4][:IDentifier] <wsp> <identifier>
<b>Parameter(s)</b>	<p><i>identifier:</i></p> <p>Integer representing the identifier of the laser that you want to use as a TLS in the subsystem, in the range 0 to 10.</p> <p>0 means that the laser is not selected for use in the subsystem.</p> <p>The laser identification number is defined with the command <i>:CTP:RLASer[1...10]:TYPE</i> on page 287 (in the GUI, it corresponds to the position of the laser in the <b>Modules &amp; Lasers</b> window from left to right).</p>
<b>Example(s)</b>	:INIT:TLS1:IDentifier 4

**:INITiate:TLS[1...4][:IDentifier]?**

<b>Description</b>	This query returns the identifier of the selected laser in use in the subsystem.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:TLS[1...4][:IDentifier]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<identifier>
<b>Response(s)</b>	<p><i>identifier:</i></p> <p>Integer representing the identification number of the laser in use in the subsystem.</p> <p>0 means that the laser is not selected for use in the subsystem.</p>
<b>Example(s)</b>	<p>:INIT:TLS2:IDentifier 5</p> <p>:INIT:TLS2:IDentifier? returns 5</p>

**:INITiate:TLS[1...4]:ACTive**

<b>Description</b>	This command selects the TLS to use for the scan.  The corresponding GUI setting is the TLS selection check box in the <b>Scan</b> menu (see <i>Defining the Scanning Lasers</i> on page 116).
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:TLS[1...4]:ACTive<wsp><state>
<b>Parameter(s)</b>	[1...4] designates the identifier of the TLS in use in the subsystem.  <i>state:</i> Activation state of the given TLS. The allowed values are: 0 INACTive: clears the TLS selection for the scan. 1 ACTive: selects the TLS for the scan.
<b>Example(s)</b>	:INIT:TLS1:ACT 0

---

**:INITiate:TLS[1...4]:ACTive?**

<b>Description</b>	This query returns the scan activation state of the TLS in the subsystem.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:TLS[1...4]:ACTive?
<b>Parameter(s)</b>	None.  [1...4] designates the identifier of the TLS in use in the subsystem.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state:</i> Activation state of the given TLS: 0: the TLS is not used for the scan. 1: the TLS is used for the scan.
<b>Example(s)</b>	:INIT:TLS1:ACT 0  ::INIT:TLS1:ACT? returns 0

---

:INITiate:TLS[1...4]:AVG	
Description	<p>This command sets the averaging time of the sweep part defined for the given TLS.</p> <p>The corresponding GUI setting is <b>Averaging Time</b> on <a href="#">page 117</a>.</p>
Applicability	<p>In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATus? on <a href="#">page 276</a>).</p>
Type	<p>Sequential.</p>
Syntax	<p>:INITiate:TLS[1...4]:AVG&lt;wsp&gt;&lt;mode&gt;[,&lt;value&gt;[&lt;unit&gt;]]</p>
Parameter(s)	<p>➤ <i>mode</i>:</p> <p>Averaging time mode for the given TLS. The allowed values are:</p> <p>0 MANUAL: sets the averaging time to Manual. In this case, you must set the &lt;value&gt; parameter.</p> <p>1 AUTO: sets the averaging time to Automatic.</p> <p>➤ <i>value</i>:</p> <p>Averaging time value between 1μs and 1s as float value.</p> <p>➤ <i>unit</i>:</p> <p>Unit of the sweeping start value. The allowed values are: US (microsecond) or MS (millisecond).</p> <p>The default unit is microsecond.</p>
Example(s)	<p>:INIT:TLS1:AVG 0,100MS</p>

:INITiate:TLS[1...4]:AVG?	
Description	This query returns the averaging time mode and value of the sweep part defined for the given TLS.
Type	Overlapping.
Syntax	:INITiate:TLS[1...4]:AVG?
Parameter(s)	None. [1...4] designates the identifier of the TLS in use in the subsystem.
Response Syntax	<mode>,<value>
Response(s)	<div><div>➤ mode:</div><div>Averaging time mode for the given TLS: 0: the averaging time is set to Manual. 1: the averaging time is set to Automatic.</div><div>➤ value:</div><div>Averaging time value in second. If the averaging time is set to automatic, the query returns the automatically calculated value.</div></div>
Example(s)	:INIT:TLS1:AVG 0,100mS :INIT:TLS1:AVG? returns 0,+1.00000000E-001

**:INITiate:TLS[1...4]:POWer**

<b>Description</b>	This command sets the power of the TLS for the sweep. The corresponding GUI setting is <b>Power</b> on <a href="#">page 117</a> .
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on <a href="#">page 276</a> ).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:TLS[1...4]:POWer<wsp><power>[<unit>]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>power</i>: Laser power as float value for the sweep.</li> <li>➤ <i>unit</i>: Unit of the power value. The allowed units are DBM (dBm) or MW (mW). The default unit is dBm.</li> </ul>
<b>Example(s)</b>	:INIT:TLS1:POW 8 :INIT:TLS1:POW? returns +8.00000000E+000

**:INITiate:TLS[1...4]:POWer?**

<b>Description</b>	This query returns the laser power for the sweep.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:TLS[1...4]:POWer?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<power>
<b>Response(s)</b>	<i>power</i> : Laser power set for the sweep in dBm or W depending on the unit setting (set with command <i>:UNIT:Y</i> on <a href="#">page 534</a> ).
<b>Example(s)</b>	:INIT:TLS1:POW 8 :INIT:TLS1:POW? returns +8.00000000E+000

**:INITiate:TLS[1...4]:SPEed**

<b>Description</b>	This command sets the sweeping speed of the TLS for the scan. The corresponding GUI setting is <b>Speed on page 117</b> .
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:TLS[1...4]:SPEed<wsp><speed>
<b>Parameter(s)</b>	[1...4] designates the identifier of the TLS in use in the subsystem. <i>speed:</i> Sweeping speed of the given TLS in nm/s. The allowed values depend on the laser: EXFO T100S-HP: 5; 6; 7; 8; 9; 10; 11; 12; 13; 14; 15; 17; 18; 20; 22; 25; 29; 33; 40; 50; 67; 100. VIAVI mSWS-A1SLS: 5 to 100
<b>Example(s)</b>	:INIT:TLS2:SPE 100

---

**:INITiate:TLS[1...4]:SPEed?**

<b>Description</b>	This query returns the sweeping speed of the TLS for the scan.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:TLS[1...4]:SPEed?
<b>Parameter(s)</b>	None. [1...4] designates the identifier of the TLS in use in the subsystem.
<b>Response Syntax</b>	<speed>
<b>Response(s)</b>	<i>speed:</i> Sweeping speed of the given TLS in nm/s.
<b>Example(s)</b>	:INIT:TLS2:SPE 100 :INIT:TLS2:SPE? returns 100

---



<b>:INITiate:TLS[1...4]:TRIGin</b>	
<b>Description</b>	This command sets the electrical trigger input to use for the given laser, for Pulse trigger output.
<b>Applicability</b>	This command does not apply to VIAVI mSWS-AISLS lasers. In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:TLS[1...4]:TRIGin<wsp> <trigger>
<b>Parameter(s)</b>	[1...4] designates the identifier of the laser in use in the subsystem. <i>trigger:</i> Integer representing the identifier of the TRIG IN port to use for the laser, in the range 0 to 8: 0: no trigger input port is used. 1 to 8: TRIG IN 1 to TRIG IN 8 input ports.
<b>Example(s)</b>	:INIT:TLS1:TRIG 3

<b>:INITiate:TLS[1...4]:TRIGin?</b>	
<b>Description</b>	This query returns the electrical trigger input used (for Pulse trigger) for the given laser.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:TLS[1...4]:TRIGin?
<b>Parameter(s)</b>	None. [1...4] designates the identifier of the laser in use in the subsystem.
<b>Response Syntax</b>	<trigger>
<b>Response(s)</b>	<i>trigger:</i> Integer representing the identifier of the TRIG IN port used for the laser, in the range 0 to 8.
<b>Example(s)</b>	:INIT:TLS1:TRIG 3 :INIT:TLS1:TRIG? returns 3

**:INITiate:TLS[1...4]:WAVelength:STARt**

<b>Description</b>	<p>This command sets the sweeping start wavelength or frequency of the given TLS for the scan (the overall scan range is set with commands <i>:INITiate:WAVelength:STARt</i> on page 486 and <i>:INITiate:WAVelength:STOP</i> on page 487).</p> <p>The corresponding GUI setting is <b>Low wav./freq. on page 117</b>.</p> <p>As the TLS start and stop values are interdependent, this command may modify the already set stop value to ensure consistency and comply with the minimum and maximum limits of each command.</p>
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:INITiate:TLS[1...4]:WAVelength:STARt</i> <wsp><start value>[<unit>]
<b>Parameter(s)</b>	<p>[1...4] designates the identifier of the TLS in use in the subsystem.</p> <ul style="list-style-type: none"> <li>➤ <i>start value:</i> Start wavelength or frequency of the sweep part of the TLS.</li> <li>➤ <i>unit:</i> Unit of the sweeping start value. The allowed units are: PM NM M HZ GHZ THZ The default unit is meter or hertz, depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</li> </ul>
<b>Example(s)</b>	<i>:INIT:TLS2:WAV:STAR 1500NM</i>

---

**:INITiate:TLS[1...4]:WAVelength:STARt?**

<b>Description</b>	This query returns the sweeping start wavelength or frequency of the TLS for the scan.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:TLS[1...4]:WAVelength:STARt?
<b>Parameter(s)</b>	None. [1...4] designates the identifier of the TLS in use in the subsystem.
<b>Response Syntax</b>	<start value>
<b>Response(s)</b>	<i>start value:</i> Sweeping start wavelength or frequency of the TLS in meters or hertz depending on the unit setting (set with command :UNIT:X on page 533).
<b>Example(s)</b>	:INIT:TLS2:WAV:STAR 1500NM :INIT:TLS2:WAV:STAR? returns +1.50000000E-006

---

**:INITiate:TLS[1...4]:WAVelength:STOP**

<b>Description</b>	<p>This command sets the sweeping stop wavelength or frequency of the given TLS for the scan (the overall scan range is set with commands <i>:INITiate:WAVelength:START</i> on page 486 and <i>:INITiate:WAVelength:STOP</i> on page 487).</p> <p>The corresponding GUI setting is <b>High wav./freq. on page 117</b>.</p> <p>As the TLS start and stop values are interdependent, this command may modify the already set start value to ensure consistency and comply with the minimum and maximum limits of each command.</p>
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	<i>:INITiate:TLS[1...4]:WAVelength:STOP</i> <wsp> <stop value> [ <unit> ]
<b>Parameter(s)</b>	<p>[1...4] designates the identifier of the TLS in use in the subsystem.</p> <ul style="list-style-type: none"> <li>➤ <i>stop value:</i> Stop wavelength or frequency of the sweep part of the TLS.</li> <li>➤ <i>unit:</i> Unit of the sweeping stop value. The allowed units are: PM NM M HZ GHZ THZ The default unit is meter or hertz, depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</li> </ul>
<b>Example(s)</b>	<i>:INIT:TLS2:WAV:STOP 1650NM</i>

---

**:INITiate:TLS[1...4]:WAVelength:STOP?**

<b>Description</b>	This query returns the sweeping stop wavelength or frequency of the TLS for the scan.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:TLS[1...4]:WAVelength:STOP?
<b>Parameter(s)</b>	None. [1...4] designates the identifier of the TLS in use in the subsystem.
<b>Response Syntax</b>	<stop value>
<b>Response(s)</b>	<i>stop value:</i> Sweeping stop wavelength or frequency set for the TLS in meters or hertz depending on the unit settings (set with command :UNIT:X on page 533).
<b>Example(s)</b>	:INIT:TLS2:WAV:STOP 1650NM :INIT:TLS2:WAV:STOP? returns +1.65000000E-006

---

**:INITiate:TMODe**

<b>Description</b>	This command sets the acquisition scanning start mode. The corresponding GUI setting is <b>Scan start</b> (see <b>Scan start on page 122</b> ).
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10. (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276)
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:TMODe<wsp> <start mode>
<b>Parameter(s)</b>	<i>start mode</i> : Scanning start mode. The allowed values are: 0 MANual: manual scan start. 1 TRIGgered: triggered scan start. In laser sharing mode, this parameter is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Example(s)</b>	:INIT:TMODe MAN

**:INITiate:TMODe?**

<b>Description</b>	This query returns the acquisition scanning start mode.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:TMODe?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<start mode>
<b>Response(s)</b>	<i>start mode</i> : Scanning start mode: 0: manual scan start. 1: triggered scan start.
<b>Example(s)</b>	:INIT:TMODe MAN :INIT:TMODe? returns 0

**:INITiate:WAVelength:SAMPling**

<b>Description</b>	This command sets the scan sampling value. The corresponding GUI setting is <b>Sampling</b> on <a href="#">page 120</a> .
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on <a href="#">page 276</a> ).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:WAVelength:SAMPling<wsp> <sampling> [PM]
<b>Parameter(s)</b>	<i>sampling</i> : Scan sampling value in picometer in the range 1 to 250.
<b>Example(s)</b>	:INIT:WAVelength:SAMPling 20PM

---

**:INITiate:WAVelength:SAMPling?**

<b>Description</b>	This query returns the scan sampling value.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:WAVelength:SAMPling?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<sampling>
<b>Response(s)</b>	<i>sampling</i> : Scan sampling value in meters.
<b>Example(s)</b>	:INIT:WAVelength:SAMPling 20PM :INIT:WAVelength:SAMPling? returns +2.00000000E-011

---

**:INITiate:WAVelength:STARt**

<b>Description</b>	<p>This command sets the scan start wavelength or frequency.</p> <p>The corresponding GUI setting is <b>Start</b> (see <b>Start/Stop</b> on page 120).</p> <p>As the scan start and stop values are interdependent, this command may modify the already set stop value to ensure consistency and comply with the minimum and maximum limits of each command.</p>
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:WAVelength:STARt<wsp><start value> [ <unit> ]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>start value:</i> Scan start wavelength or frequency.</li> <li>➤ <i>unit:</i> Unit of the scan start value. The allowed units are: PM NM M HZ GHZ THZ The default unit is meter or hertz, depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</li> </ul>
<b>Example(s)</b>	:INIT:WAV:STAR 1500NM

**:INITiate:WAVelength:STARt?**

<b>Description</b>	This query returns the scan start wavelength or frequency.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:WAVelength:STARt?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<start value>
<b>Response(s)</b>	<p><i>start value:</i></p> <p>Scan start wavelength or frequency in meters or hertz depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</p>
<b>Example(s)</b>	<p>:INIT:WAV:STAR 1500NM</p> <p>:INIT:WAV:STAR? returns +1.50000000E-006</p>



**:INITiate:WAVelength:STOP**

<b>Description</b>	<p>This command sets the scan stop wavelength or frequency.</p> <p>The corresponding GUI setting is <b>Stop</b> (see <b>Start/Stop</b> on page 120).</p> <p>As the scan start and stop values are interdependent, this command may modify the already set start value to ensure consistency and comply with the minimum and maximum limits of each command.</p>
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to <i>:CTP:LSHARing:STATus?</i> on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:INITiate:WAVelength:STOP<wsp> <stop value> [<unit>]
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>stop value:</i> Scan stop wavelength or frequency.</li> <li>➤ <i>unit:</i> Unit of the scan stop value. The allowed units are: PM NM M HZ GHZ THZ The default unit is meter or hertz, depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</li> </ul>
<b>Example(s)</b>	:INIT:WAV:STOP 1650NM

**:INITiate:WAVelength:STOP?**

<b>Description</b>	This query returns the scan stop wavelength or frequency.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:INITiate:WAVelength:STOP?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<stop value>
<b>Response(s)</b>	<p><i>stop value:</i></p> <p>Scan stop wavelength or frequency in meters or hertz depending on the unit setting (set with command <i>:UNIT:X</i> on page 533).</p>
<b>Example(s)</b>	<p>:INIT:WAV:STOP 1650NM</p> <p>:INIT:WAV:STOP? returns +1.65000000E-006</p>

## MMEMory Commands and Queries

### Quick Reference

Command Overview			Parameter(s)	Section
MMEMory	CATalog	[IMMediate]?		see p. 489
		DRive?		see p. 490
	CDIRectory		<directory>	see p. 491
	CDIRectory?			see p. 491
	CDRive		<drive>	see p. 492
	CDRive?			see p. 492
	COPY		<pathname1>,<pathname2>	see p. 493
	DElete		<name>	see p. 493
	LOAD	DEfault		see p. 494
		SETTings	<filename>	see p. 494
		TRACe	<filename>	see p. 495
	MDIRectory		<directory>	see p. 495
	STORE	AREsults	<filename>	see p. 495
		SCREenshot	<filename>	see p. 496
		SETTings	<filename>	see p. 496

### Syntax of pathnames and filenames

- The path must be specified as follows: "<drive>:\<directory>\...\filename.ext" (double quotes can be omitted).
  - If <drive> is not specified, the current drive is used.
  - If the <directory>\...\ is also not specified, the current drive and directory is used.
- The file extension can be omitted when loading a file. In case it is omitted in a command to store a file, the default extension is applied.

## Commands and Queries

<b>:MMEMory:CATalog[:IMMediate]?</b>	
<b>Description</b>	This query returns the state of the current directory or drive and the list of files and folders that it contains.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:MMEMory:CATalog[:IMMediate]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<pathname>,<free space>,<occupied space>,<number of folders>,<number of files>,{<folder name>,DIR,-},{<file name>,<file type>,<file size>}
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>pathname:</i> Name of the current directory or drive.</li> <li>➤ <i>free space:</i> Directory memory size available on the drive in MB (1,048576 bytes).</li> <li>➤ <i>occupied space:</i> Memory size occupied by the files under the current directory in MB (1,048576 bytes).</li> <li>➤ <i>number of folders:</i> Number of folders contained in the current directory.</li> <li>➤ <i>number of files:</i> Number of folders contained in the current directory.</li> <li>➤ <i>folder name:</i> Name of a folder contained in the current directory or drive.</li> <li>➤ <i>file name:</i> Name of a file in the current directory or drive.</li> <li>➤ <i>file type:</i> Filename extension.</li> <li>➤ <i>file size:</i> File size in KB (1,024 bytes).</li> </ul>
<b>Example(s)</b>	MMEM:CAT? returns E:\SWEEPRESULT,+2.535152E+003,+1.302739E+001,12,46, TRACE1, csv , +2.14015000E+002 , ...

## :MMEMory:CATalog:DRive?

<b>Description</b>	This query returns the list of available storage drives connected to the instrument with their name, their type and the memory space available on them.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:MMEMory:CATalog:DRive?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<number of drives>{ <drive letter>,<drive size>,<drive free space>,<drive name>,<drive type> }
<b>Response(s)</b>	<ul style="list-style-type: none"><li>➤ <i>number of drives:</i> Number of drives connected to the CTP10.</li><li>➤ <i>drive letter:</i> Letter of (one of the) drive(s) connected to the CTP10.</li><li>➤ <i>drive size:</i> Connected drive memory size in MB (1,048576 Bytes).</li><li>➤ <i>drive free space:</i> Memory size available on the drive in MB (1,048576 Bytes).</li><li>➤ <i>drive name:</i> Name of the connected drive (if any). If the device has no name, the response is: "UNTITLED".</li><li>➤ <i>drive type:</i> Type of device connected to the CTP10: FIXED: the drive is the internal CTP10 drive. REMOTE: the drive is a network drive. REMOVABLE: the drive is an USB removable drive.</li></ul>
<b>Example(s)</b>	MMEM:CAT:DRIV? returns 2, D:\, +2.59401452E+003 , +2.25351452E+003, USER, FIXED, E:\, +1.90804500E+003, +5.31145148E+002, myUSBKey, REMOVABLE

**:MMEMory:CDIRectory**

<b>Description</b>	This command sets the current directory pathname.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:MMEMory:CDIRectory<wsp> <directory>
<b>Parameter(s)</b>	<i>directory</i> : Pathname of the directory that you want to set as current in the current drive (with or without outer backslashes).
<b>Example(s)</b>	MMEM:CDIR "NEWDUT\SAMPLES"

**:MMEMory:CDIRectory?**

<b>Description</b>	This query returns the current directory path.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:MMEMory:CDIRectory?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<directory>
<b>Response(s)</b>	<i>directory</i> : Current directory pathname, including the drive letter.
<b>Example(s)</b>	MMEM:CDIR "NEWDUT\SAMPLES" MMEM:CDIR? returns E:\NEWDUT\SAMPLES\

**:MMEMory:CDRive**

<b>Description</b>	This command sets the current drive letter.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:MMEMory:CDRive<wsp><drive>
<b>Parameter(s)</b>	<i>drive:</i> Letter of the drive that you want to set as current.
<b>Example(s)</b>	MMEM:CDR "E:"

**:MMEMory:CDRive?**

<b>Description</b>	This query returns the current drive letter.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:MMEMory:CDRive?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<drive>
<b>Response(s)</b>	<i>drive:</i> Drive letter.
<b>Example(s)</b>	MMEM:CDR "E:" MMEM:CDR? returns E: where E: is the current drive.

**:MMEMory:COpy**

<b>Description</b>	This command copies a specified file/folder from one directory and pastes it to another directory.
<b>Type</b>	Overlapping, no query.
<b>Syntax</b>	:MMEMory:COpy<wsp> <pathname1>,<pathname2>
<b>Parameter(s)</b>	<p>➤ <i>pathname1</i>:</p> <p>Source file/folder pathname (absolute or relative to current directory/drive) that you want to copy.</p> <p>➤ <i>pathname2</i>:</p> <p>Destination file/folder pathname (absolute or relative to current directory/drive) to which you want to paste the copied file/folder.</p> <p>The current drive or directory is not modified after command execution, even if you specify the full path.</p> <p>If you copy subsystem settings, make sure to place the corresponding trace folders in the same location as the copied setting file.</p>
<b>Example(s)</b>	MMEM:COpy "D:\TRACE1.csv","E:\SPECTRUM\SAMPLES\SAMPLE1\TRACE1.csv"

**:MMEMory:DELeTe**

<b>Description</b>	This command deletes a specified file or empty folder from the current directory.
<b>Type</b>	Overlapping, no query.
<b>Syntax</b>	:MMEMory:DELeTe<wsp> <name>
<b>Parameter(s)</b>	<p><i>name</i>:</p> <p>Name of the empty folder or file that you want to delete from the current directory.</p> <p>You cannot delete a folder that is not empty.</p>
<b>Example(s)</b>	MMEM:DEL "TRACE1.csv"

**:MMEMory:LOAD:DEFault**

<b>Description</b>	<p>This command loads the default subsystem settings (blank subsystem).</p> <p>This command deletes all unsaved data of the current subsystem. Make sure to save the current subsystem data and settings before executing this command (:MMEMory:STORe:SETTings on page 496).</p>
<b>Type</b>	<p>Overlapped, no query.</p> <p>When the system is loading default subsystem settings, the bit 12 "Loading/Saving" is set in the Operational Status Condition Register (see :STATus:OPERation:CONDition? on page 251 and <i>Operational / Questionable Status Reporting</i> on page 205).</p>
<b>Syntax</b>	:MMEMory:LOAD:DEFault
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	MMEM:LOAD:DEF

---

**:MMEMory:LOAD:SETTings**

<b>Description</b>	<p>This command loads the settings of an existing subsystem (*.CTP10 format) from a file (and folder) located in the current directory.</p>
<b>Type</b>	<p>Overlapped, no query.</p> <p>When the system is loading default subsystem settings, the bit 12 "Loading/Saving" is set in the Operational Status Condition Register (see :STATus:OPERation:CONDition? on page 251 and <i>Operational / Questionable Status Reporting</i> on page 205).</p>
<b>Syntax</b>	:MMEMory:LOAD:SETTings<wsp><filename>
<b>Parameter(s)</b>	<p><i>filename:</i></p> <p>Name of the subsystem file to load (in *.CTP10 format) from the current directory.</p> <p>This command deletes all unsaved data of the current subsystem. Make sure to save the current subsystem data and settings before executing this command (:MMEMory:STORe:SETTings on page 496).</p>
<b>Example(s)</b>	MMEM:LOAD:SETT "subsystemSettings.CTP10"

---



**:MMEMory:LOAD:TRACe**

<b>Description</b>	This command loads a trace file (*.tra format) located in the current directory at the end of the store trace list.
<b>Type</b>	Overlapped, no query.  When the system is loading a trace file, the bit 12 "Loading/Saving" is set in the Operational Status Condition Register (see <i>:STATus:OPERation:CONDition?</i> on page 251 and <i>Operational / Questionable Status Reporting</i> on page 205).
<b>Syntax</b>	:MMEMory:LOAD:TRACe<wsp> <filename>
<b>Parameter(s)</b>	<i>filename:</i>  Name of the trace file to load (in *.tra format) from the current directory.  The trace is loaded at the end of the store trace list.
<b>Example(s)</b>	MMEM:LOAD:TRAC "DUTCHANNEL1.tra"

**:MMEMory:MDIRectory**

<b>Description</b>	This command creates a new directory in the current drive or directory.
<b>Type</b>	Sequential, no query.
<b>Syntax</b>	:MMEMory:MDIRectory<wsp> <directory>
<b>Parameter(s)</b>	<i>directory:</i>  Directory name that you want to create.
<b>Example(s)</b>	MMEM:MDIR "\SAMPLE1\"

**:MMEMory:STORe:ARESUlts**

<b>Description</b>	This command saves the analysis results to a specific file in the current directory, in .csv format.
<b>Type</b>	Sequential, no query.
<b>Syntax</b>	:MMEMory:STORe:ARESUlts<wsp> <filename>
<b>Parameter(s)</b>	<i>filename:</i>  Name of the file to which you want to save the analysis results in csv format.
<b>Example(s)</b>	MMEM:STOR:ARES "results.csv"

**:MMEMory:STORe:SCREenshot**

<b>Description</b>	This command captures and saves a screenshot of the subsystem window to a specific file in the current directory.
<b>Type</b>	Sequential, no query.
<b>Syntax</b>	:MMEMory:STORe:SCREenshot<wsp><filename>
<b>Parameter(s)</b>	<i>filename:</i> Name of the file to which you want to save the screenshot in *.jpg or *.png format. Default file extension, if not specified: .jpg
<b>Example(s)</b>	MMEM:STOR:SCRE "Subsystem Screenshot.jpg"

**:MMEMory:STORe:SETTings**

<b>Description</b>	This command saves the entire subsystem settings into a file in the current directory to a specific file (and folder) in the current directory.
<b>Type</b>	Overlapped, no query.  When the system is saving subsystem settings, the bit 12 "Loading/Saving" is set in the Operational Status Condition Register (see :STATus:OPERation:CONDition? on page 251 and Operational / Questionable Status Reporting on page 205).
<b>Syntax</b>	:MMEMory:STORe:SETTings<wsp><filename>
<b>Parameter(s)</b>	<i>filename:</i> Name of the file to which you want to save the subsystem in *.CTP10 format. It also saves in a separate folder (same name as the settings file: <filename>.CTP10 Traces) all the traces in their current state (in *.tra format), analysis parameters (*.ana format file), analysis results (*.anaresu format file), detectors reference data (.trc format file) and detectors quick reference data (.trc format file).
<b>Example(s)</b>	MMEM:STOR:SETT "Subsystem Settings.CTP10"

## REference Commands and Queries

In REference:SENSe[1...20]:CHANnel[1...6]:

- [1...20] or [1...10] designates the module identification number, which is the position of the module in the mainframe from left to right.  
In Daisy chaining mode, the modules located on the Primary mainframe are identified using positions 1 to 10, and the modules located on the Secondary mainframe are identified using positions 11 to 20.
- [1...6] designates the detector identification number, which is the detector position on the module from top to bottom. This number is not taken into account for BR traces.

### Quick reference

Command Overview					Parameter(s)	Section
REference	CLEAR					see p. 497
	SENSe[1...20]	CHANnel[1...6]	INIT			see p. 498
			RESult?			see p. 499
	QUICK	CLEAR				see p. 499
		RESult?				see p. 500
		SENSe[1...10]	CHANnel[1...6]	INIT		see p. 501
	WAVelength	RESult?				see p. 502
		SENSe[1...10]	CHANnel[1...6]	INIT	<gas cell>	see p. 503

### Commands and Queries

:REference:CLEAR	
<b>Description</b>	This command clears all the references of the subsystem.
<b>Type</b>	Sequential, no query.
<b>Syntax</b>	:REference:CLEAR
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:REF:CLEAR

:REFeRence:SENSe[1...20]:CHANnel[1...6]:INIT	
<b>Description</b>	<p>This command performs a reference of the given detector.</p> <p>Before sending this command, make sure that the patch cord is properly connected to the given detector. For more details on the referencing operation, see <i>Referencing the Subsystem</i> on page 123.</p>
<b>Type</b>	<p>Overlapped, no query.</p> <p>When the system executes this command, the bit 6 "Referencing" is set in the Operational Status Condition Register (see <i>:STATus:OPERation:CONDition?</i> on page 251 and <i>Operational / Questionable Status Reporting</i> on page 205).</p>
<b>Syntax</b>	:REFeRence:SENSe[1...20]:CHANnel[1...6]:INIT
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:REFeRence:SENSe5:CHANnel1:INIT

---

**:REFeRence:SENSe[1...20]:CHANnel[1...6]:RESult?**

<b>Description</b>	This query returns the result of the referencing operation on the given detector.
<b>Type</b>	Sequential, query only.
<b>Syntax</b>	:REFeRence:SENSe[1...20]:CHANnel[1...6]:RESult?
<b>Response Syntax</b>	<state>,<type>,<date>,<time>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>state</i>: Result of the referencing operation on the detector: 0: there is no valid reference. 1: the reference is valid.</li> <li>➤ <i>type</i>: Type of the referencing operation on the detector: 0: TF reference (1 sweep) with the IL RL OPM2 module. 1: TF/PDL reference (4 sweeps) with the IL PDL or IL PDL OPM2 module. If the state is equal to 0: no value.</li> <li>➤ <i>date</i>: If the state is equal to 1: date of the referencing operation in YYYYMMDD format. If the state is equal to 0: no value.</li> <li>➤ <i>time</i>: If the state is equal to 1: time of the referencing operation in HHMMSS format. If the state is equal to 0: no value</li> </ul>
<b>Example(s)</b>	:REFeRence:SENS5:CHAN1:RESult? returns 1,0,20181024,173427 :REFeRence:SENS5:CHAN1:RESult? returns 0,,

**:REFeRence:QUICK:CLEAR**

<b>Description</b>	This command clears the quick reference of the subsystem.
<b>Type</b>	Sequential, no query.
<b>Syntax</b>	:REFeRence:QUICK:CLEAR
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:REFeRence:QUICK:CLEAR

<b>:REFEreNce:QUICk:RESulT?</b>	
<b>Description</b>	This query returns the result of the quick referencing operation.
<b>Type</b>	Sequential, query only.
<b>Syntax</b>	:REFEreNceQUICk:RESulT:RESulT?
<b>Response Syntax</b>	<state>,<date>,<time>,<module>,<detector>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>state</i>: Result of the quick referencing operation: 0: there is no valid quick reference. 1: the quick reference is valid.</li> <li>➤ <i>date</i>: If the state is equal to 1: date of the quick referencing operation in YYYYMMDD format. If the state is equal to 0: no value.</li> <li>➤ <i>time</i>: If the state is equal to 1: time of the quick referencing operation in HHMMSS format. If the state is equal to 0: no value.</li> <li>➤ <i>module</i>: If the state is equal to 1: identification number of the module used for the quick reference, in the range 1 to 10 (position of the module in the mainframe from left to right). If the state is equal to 0: no value.</li> <li>➤ <i>detector</i>: If the state is equal to 1: identification number of the detector used for the quick reference, in the range 1 to 6 (detector position on the module from top to bottom). If the state is equal to 0: no value.</li> </ul>
<b>Example(s)</b>	:REF:QUIC:RESUL? returns 1,20181024,173427,6,3

**:REFeRence:QUICk:SENSe[1...10]:CHANnel[1...6]:INIT**

<b>Description</b>	<p>This command performs a quick reference of the given detector.</p> <p>Before sending this command, make sure that the patch cord is properly connected to the given detector. For more details on the quick referencing operation, see <i>Referencing the Subsystem</i> on page 123.</p>
<b>Applicability</b>	This command is only available if you use an IL RL OPM2 module (not available with an IL PDL or IL PDL OPM2 module).
<b>Type</b>	<p>Overlapped, no query.</p> <p>When the system executes this command, the bit 7 "Quick referencing" is set in the Operational Status Condition Register (see <i>:STATus:OPERation:CONDition?</i> on page 251 and <i>Operational / Questionable Status Reporting</i> on page 205).</p>
<b>Syntax</b>	:REFeRence:QUICk:SENSe[1...10]:CHANnel[1...6]:INIT
<b>Parameter(s)</b>	None.
<b>Example(s)</b>	:REF:QUIC:SENS5:CHAN1:INIT

---

**:REference:WAVelength:RESult?**

<b>Description</b>	This query returns the result of the last wavelength referencing operation.
<b>Type</b>	Sequential, query only.
<b>Syntax</b>	:REference:WAVelength:RESult?
<b>Response Syntax</b>	<shift>,<date>,<time>
<b>Response(s)</b>	<ul style="list-style-type: none"><li>➤ <i>shift</i>: Frequency shift as a float value in Hertz.</li><li>➤ <i>date</i>: If the wavelength referencing is valid: date of the referencing operation in YYYYMMDD format. If there is no valid wavelength referencing: no value.</li><li>➤ <i>time</i>: If the wavelength referencing is valid: time of the referencing operation in HHMMSS format. If there is no valid wavelength referencing: no value.</li></ul>
<b>Example(s)</b>	:REference:WAVelength:RES? returns +193,28978594E+011,20181024,173427

---



**:REFeRence:WAVeLength:SENSe[1...10]:CHANnel[1...6]:INIT**

<b>Description</b>	<p>This command performs a wavelength referencing of the SCAN SYNC module.</p> <p>Before sending this command, make sure that the gas cell is properly connected to the given detector. For more details on the wavelength referencing operation, see <i>Performing Wavelength Referencing</i> on page 127.</p>
<b>Type</b>	<p>Sequential, no query.</p> <p>When the system executes this command, the bit 1 "Calibrating" is set in the Operational Status Condition Register (see <i>:STATus:OPERation:CONDition?</i> on page 251 and <i>Operational / Questionable Status Reporting</i> on page 205).</p>
<b>Syntax</b>	:REFeRence:WAVeLength:SENSe[1...10]:CHANnel[1...6]:INIT <gas cell>
<b>Parameter(s)</b>	<p><i>gas cell:</i></p> <p>Type of the connected gas cell:</p> <ul style="list-style-type: none"> <li>1: Acetylene C2H2 50 Torr</li> <li>2: Acetylene C2H2 200 Torr</li> <li>3: Hydrogen Fluoride HF</li> <li>4: Hydrogen Cyanide HCN 25 Torr</li> <li>5: Hydrogen Cyanide HCN 100 Torr</li> <li>6: Carbon Monoxide 12C16O 1000 Torr</li> <li>7: Carbon Monoxide 13C16O 1000 Torr</li> </ul>
<b>Example(s)</b>	:REFeRence:WAVeLength:SENSe5:CHANnel1:INIT 2

---

## TRACe Commands and Queries

In TRACe:STORe[1...n]:

[1...n] designates the store trace identifier. The store trace identifier, is available with the command :TRACe:LIST:STORe? on page 507.

In TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:

- [1...20] designates the module identification number, which is the position of the module in the mainframe from left to right.  
In Daisy chaining mode, the modules located on the Primary mainframe are identified using positions 1 to 10, and the modules located on the Secondary mainframe are identified using positions 11 to 20.
- [1...6] designates the detector identification number, which is the detector position on the module from top to bottom. This number is not taken into account for BR traces.
- [1...10] or [1...13] or [1...18] designates the trace type:
  - 1: TF live
  - 2: TF max
  - 3: TF min
  - 4: TF average
  - 5: TF roll average
  - 6: BR live (only available on an IL RL OPM2 module)
  - 7: BR max (only available on an IL RL OPM2 module)
  - 8: BR min (only available on an IL RL OPM2 module)
  - 9: BR average (only available on an IL RL OPM2 module)
  - 10: BR roll average (only available on an IL RL OPM2 module)
  - 11: Raw Live, which is the unreferenced "TF live" or "PDL live" trace type. For more details on this trace type, see *Retrieving Raw TF Data from a Detector* on page 136.
  - 12: Raw Reference, which is the reference trace of the "TF live" or "PDL live" trace type. For more details on this trace type, see *Retrieving Raw TF Data from a Detector* on page 136.
  - 13: Raw Quick Reference, which is the quick reference trace of the "TF live" trace type (only available with the IL RL OPM2 module). For more details on this trace type, see *Retrieving Raw TF Data from a Detector* on page 136.
  - 14: PDL live (only available on an IL PDL or IL PDL OPM2 module)
  - 15: PDL max (only available on an IL PDL or IL PDL OPM2 module)
  - 16: PDL min (only available on an IL PDL or IL PDL OPM2 module)
  - 17: PDL average (only available on an IL PDL or IL PDL OPM2 module)
  - 18: PDL roll average (only available on an IL PDL or IL PDL OPM2 module)

**Quick Reference**

Command Overview							Parameter(s)	Section
TRACe	LIST	SENSe?						see p. 506
		STORe?						see p. 507
	SENSe[1...20]	CHANnel [1...6]	TYPE[1...10]   [14...18]	ACTive			<state>	see p. 515
				ACTive?				see p. 516
				COLor			<red>,<green>,<blue>	see p. 513
				COLor?				see p. 513
			TYPE[1...18]	DATA	[Y]	[IMMediate]?	<format>, <unit>, <reduction>	see p. 511
					LENGth?			see p. 509
					SAMPling?			see p. 510
					STARt?			see p. 509
			TYPE[1...10]   [14...18]	DELete				see p. 519
				NOTE				see p. 514
				NOTE?				see p. 514
			TYPE5   10   18	RAVG			<count>	see p. 517
				RAVG?				see p. 517
			TYPE[1...18]	SAVE			<filename>	see p. 508
			TYPE[1...10]   [14...18]	STATe			<visibility>	see p. 518
				STATe?				see p. 518
	STORe[1...n]	COLor					<red>,<green>,<blue>	see p. 520
		COLor?						see p. 520
		DATA	[Y]	[IMMediate]?			<format>, <unit>, <reduction>	see p. 521
			LENGth?					see p. 522
			SAMPling?					see p. 522
			STARt?					see p. 523
		NOTE					<comment>	see p. 524
		NOTE?						see p. 524
		SAVE					<filename>	see p. 525

**Commands and Queries**

<b>:TRACe:LIST:SENSe?</b>	
<b>Description</b>	This query returns the list of traces of type sense (all traces that are not store traces).
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:TRACe:LIST:SENSe?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<list>
<b>Response(s)</b>	<i>list:</i> List of traces of type sense such as: {MOD<module number> DET<detector number> <trace name>}
<b>Example(s)</b>	:TRAC:LIST:SENS? returns MOD 1 DET 1 TF LIVE MOD 1 DET 1 TF MAX MOD 1 DET 1 TF MIN MOD 1 DET 1 TF AVERAGE MOD 1 DET 1 TF ROLL AVERAGE MOD 1 DET 2 TF LIVE MOD 1 DET 2 TF MAX MOD 1 DET 2 TF MIN MOD 1 DET 2 TF AVERAGE MOD 1 DET 2 TF ROLL AVERAGE MOD 4 DET 1 TF LIVE MOD 4 DET 1 TF MAX MOD 4 DET 1 TF MIN MOD 4 DET 1 TF AVERAGE MOD 4 DET 1 TF ROLL AVERAGE

---

**:TRACe:LIST:STORe?**

<b>Description</b>	This query returns the list of traces of type store.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:TRACe:LIST:STORe?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<list>
<b>Response(s)</b>	<i>list:</i> List of traces of type "store" such as: { <trace number> <tab> <trace name> }
<b>Example(s)</b>	:TRAC:LIST:STOR? returns 1 my TF trace 2 BR trace test2 3 TF mytrace3

---

**:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:SAVE**

<b>Description</b>	<p>This command saves the trace data into a trace file in the current directory.</p> <p>This query can only be executed if the CTP10 is in idle state (:STAT:OPER:COND? returns 0).</p>
<b>Applicability</b>	In Daisy chaining mode, the .csv saving format is not available on TYPE11 and TYPE12 on 4-state IL-PDL measurement (4 sweeps) on detectors located on the Secondary CTP10 (SENS11 to SENS20).
<b>Type</b>	<p>Overlapped, no query.</p> <p>When the system executes this command, the bit 12 "Loading/Saving" is set in the Operational Status Condition Register (see :STATus:OPERation:CONDition? on page 251 and Operational / Questionable Status Reporting on page 205).</p>
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:SAVE<wsp><filename>
<b>Parameter(s)</b>	<p><i>filename:</i></p> <p>Name of the file in which you want to save trace data, with or without quotes.</p> <p>Possible extensions are:</p> <ul style="list-style-type: none"> <li>➤ .tra (binary file) for trace types 1 to 10 only.</li> <li>➤ .csv (csv file) for all types of traces. For TYPE11 (raw live) and TYPE12 (raw reference) on 4-state IL-PDL measurement (4 sweeps), the four SOP traces are saved one after the other in the .csv file (SOP#1 to SOP#4).</li> </ul> <p>Default extension (if not specified): .tra</p>
<b>Example(s)</b>	:TRACe:SENS1:CHAN3:TYPE2:SAVE "trace.tra"

---

### :TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:DATA:STARt?

<b>Description</b>	This query returns the start wavelength of a trace.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:DATA:STARt?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<wavelength>
<b>Response(s)</b>	<i>wavelength:</i> Trace start wavelength in meters.
<b>Example(s)</b>	:TRAC:SENS1:CHAN3:TYPE2:DATA:STAR? returns +1.25000000E-006

### :TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:DATA:LENGth?

<b>Description</b>	This query returns the length of a trace.  This query can only be executed if the CTP10 is in idle state (:STAT:OPER:COND? returns 0).
<b>Type</b>	Sequential, query only.
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:DATA:LENGth?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<length>
<b>Response(s)</b>	<i>length:</i> Number of points in the trace.
<b>Example(s)</b>	:TRAC:SENS1:CHAN3:TYPE2:DATA:LENG? returns 225001

**:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:DATA  
:SAMPling?**

<b>Description</b>	This query returns the trace sampling interval.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:DATA :SAMPling?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<sampling>
<b>Response(s)</b>	<i>sampling</i> : Trace sampling interval in meters.
<b>Example(s)</b>	:TRAC:SENS1:CHAN3:TYPE2:DATA:SAMP? returns +2.00000000E-012

---



## :TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:DATA[:Y][:IMMediate]?

<b>Description</b>	<p>This query returns the wanted trace data.</p> <p>This query can only be executed if the CTP10 is in idle state (:STAT:OPER:COND? returns 0).</p>
<b>Type</b>	Sequential, query only.
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:DATA[:Y][:IMMediate]?<wsp><format>,<unit>[,<reduction>]
<b>Parameter(s)</b>	<p>➤ <i>format:</i></p> <p>Format of the trace data. The allowed values are:</p> <p>0 ASCIi: trace data is formatted as ASCII values, such as &lt;value1&gt;,&lt;value2&gt;,...</p> <p>1 BINary: trace data is formatted as binary blocks such as: #&lt;length&gt;&lt;Nb of bytes&gt;&lt;blocks&gt;</p> <p>where:</p> <p>&lt;length&gt;: number of subsequent bytes that you have to check to know the total length.</p> <p>&lt;Nb of bytes&gt;: size of &lt;blocks&gt; in bytes.</p> <p>&lt;blocks&gt;: float data bytes (packet of 4 bytes, big endian).</p> <p>For example, data containing 10 data points will results in the header "#240&lt;blocks&gt;" as 40 bytes are needed to define the data and "40" length is 2.</p> <p>➤ <i>unit:</i></p> <p>Unit of the trace data. The allowed values are:</p> <p>RATIO or 0: trace data is retrieved in ratio.</p> <p>DB or 1: trace data is retrieved in dB.</p> <p>➤ <i>reduction:</i></p> <p>Reduction factor (optional), which decimates the number of data points for faster data retrieval. A reduction factor of 5 would select a point out of every 5 points available on the trace. The first point received is always the "start wavelength" data point.</p>

## :TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...18]:DATA [:Y][:IMMediate]?

**Response Syntax**    <trace data>

**Response(s)**        *trace data:*

List of measured power data points.

- If the <format> parameter is ASCii, the response data syntax for <data> is formatted as follows: <data point 1>, <data point 2>, ...
- If the <format> parameter is BINary, the response data syntax for <data> is formatted as binary blocks, as explained above.

For TYPE11 (raw live) and TYPE12 (raw reference) on 4-state IL-PDL measurement (4 sweeps), the query returns data of four traces, formatted as follow: <SOP#1 trace data>, <SOP#2 trace data>, <SOP#3 trace data>, <SOP#4 trace data>.

**Example(s)**

```
:TRAC:SENS1:CHAN3:TYPE2:DATA? ASC,DB
returns -5.00000000E+000,-5.10000000E+000,...

:TRAC:SENS1:CHAN3:TYPE2:DATA? BIN,RATIO
returns #1821AÔ³Ë'³"12LÒ'2...
```

---

### **:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10] | [14...18]:COLor**

<b>Description</b>	This command defines the color of the given trace in RGB format.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10]   [14...18]:COLor<wsp> <red>, <green>, <blue>
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>red</i>: Integer corresponding to the level of red in the trace color, in the range 0 to 255.</li> <li>➤ <i>green</i>: Integer corresponding to the level of green in the trace color, in the range 0 to 255.</li> <li>➤ <i>blue</i>: Integer corresponding to the level of blue in the trace color, in the range 0 to 255.</li> </ul>
<b>Example(s)</b>	:TRAC:SENS5:CHAN3:TYPE8:COL 75,0,130

### **:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10] | [14...18]:COLor?**

<b>Description</b>	This query returns the color of the given trace in RGB format.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10]   [14...18]:COLor?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<red>, <green>, <blue>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>red</i>: Integer corresponding to the level of red in the trace color, in the range 0 to 255.</li> <li>➤ <i>green</i>: Integer corresponding to the level of green in the trace color, in the range 0 to 255.</li> <li>➤ <i>blue</i>: Integer corresponding to the level of blue in the trace color, in the range 0 to 255.</li> </ul>
<b>Example(s)</b>	:TRAC:SENS5:CHAN3:TYPE8:COL 75,0,130 :TRAC:SENS5:CHAN3:TYPE8:COL? returns 75,0,130

**:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10] |  
[14...18]:NOTE**

<b>Description</b>	This command adds a comment on the given trace.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10]   [14...18]:NOTE <wsp> <comment>
<b>Parameter(s)</b>	<i>comment</i> :  Comment to associate with the trace. It must be different from whitespace or empty (240 characters maximum, characters over this limit are ignored).
<b>Example(s)</b>	:TRAC:SENS6:CHAN4:TYPE3:NOTE my comment on the trace

---

**:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10] |  
[14...18]:NOTE?**

<b>Description</b>	This query returns the comment associated with the given trace.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10]   [14...18]:NOTE ?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<comment>
<b>Response(s)</b>	<i>comment</i> :  Comment associated with the trace, in upper case.
<b>Example(s)</b>	:TRAC:SENS6:CHAN4:TYPE3:NOTE my comment on the trace :TRAC:SENS6:CHAN4:TYPE3:NOTE? returns MY COMMENT ON THE TRACE

---

## :TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10] | [14...18]:ACTive

<b>Description</b>	<p>This command selects the trace type to create for the given detector and sets the optical link to the DUT output.</p> <p>In Daisy chaining mode, before using this command for a detector located on the Secondary CTP10, make sure that you have entered the Daisy chaining mode (response 1 to :CTP:DCHAINing:STATus? on page 265).</p>
<b>Applicability</b>	<p>The trace type to create must be compatible with the measurement module used in the subsystem (see :INITiate:ILRL[:SENSe] on page 458):</p> <ul style="list-style-type: none"> <li>➤ With IL RL OPM2 measurement module: TF traces (types 1 to 5) and BR traces (types 6 to 10).</li> <li>➤ With IL PDL and IL PDL OPM2 measurement modules: TF trace (types 1 to 5) and PDL traces (types 14 to 18).</li> </ul>
<b>Type</b>	Sequential.
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10]   [14...18]:ACTive <wsp> <state>
<b>Parameter(s)</b>	<p><i>state:</i></p> <p>Trace type selection state. The allowed values are:</p> <ul style="list-style-type: none"> <li>➤ 0: clears the trace type for the given detector. The link to the DUT output is not removed. To remove this link, you must load the default subsystem settings (see :MMEMory:LOAD:DEFault on page 494).</li> <li>➤ 1: creates the given trace type for the given detector. The connection link from the DUT to the given detector is automatically configured.</li> </ul>
<b>Example(s)</b>	:TRACe:SENSe1:CHANnel4:TYPE1:ACTive 1

## :TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10] | [14...18]:ACTive?

<b>Description</b>	This query returns the state of the trace.
<b>Type</b>	Sequential.
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10]   [14...18]:ACTive?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<i>state</i> : State of the trace: 0: the trace does not exist. 1: the trace is created.
<b>Example(s)</b>	:TRACe:SENSe1:CHANnel4:TYPE1:ACTive 1 :TRACe:SENSe3:CHANnel2:TYPE3:ACTive? returns 1

---

**:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE5|10|18:RAVG**

<b>Description</b>	This command only applies to traces of type "roll average" (TYPE5, TYPE10 and TYPE18). It sets the number of scans to take into account for the roll averaging calculation.
<b>Type</b>	Sequential.
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE5:RAVG<wsp> <count> :TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE10:RAVG<wsp> <count> :TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE18:RAVG<wsp> <count>
<b>Parameter(s)</b>	<i>count</i> : Integer corresponding to the number of scans to take into account for the roll averaging calculation, in the range 2 to 10.
<b>Example(s)</b>	:TRACe:SENSe1:CHANnel4:TYPE10:RAVG 4

**:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE5|10|18:RAVG?**

<b>Description</b>	This query only applies to traces of type "roll average" (TYPE5, TYPE10 and TYPE18). It returns the number of scans defined for the roll averaging calculation.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE5:RAVG? :TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE10:RAVG? :TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE18:RAVG?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<count>
<b>Response(s)</b>	<i>count</i> : Number of scans defined for the roll averaging calculation.
<b>Example(s)</b>	:TRACe:SENSe1:CHANnel4:TYPE5:RAVG 4 :TRACe:SENSe3:CHANnel2:TYPE5:RAVG? returns 4

**:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10] | [14...18]:STATe**

<b>Description</b>	This command makes the trace visible/invisible on graph.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10]   [14...18]:STATe <wsp> <visibility>
<b>Parameter(s)</b>	<i>visibility</i> : State of the trace visibility. The allowed values are: 0   OFF: makes the trace invisible on graph. 1   ON: makes the trace visible on graph.
<b>Example(s)</b>	:TRACe:SENSe1:CHANnel4:TYPE5:STAT ON

---

**:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10] | [14...18]:STATe?**

<b>Description</b>	This query returns the visibility state of the trace.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10]   [14...18]:STATe ?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<visibility>
<b>Response(s)</b>	<i>visibility</i> : State of the trace visibility: 0: the trace is not visible on graph. 1: the trace is visible on graph.
<b>Example(s)</b>	:TRACe:SENSe1:CHANnel4:TYPE5:STAT ON :TRACe:SENSe3:CHANnel2:TYPE3:STATe? returns 1

---



:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10]   [14...18]:DELeTe	
Description	This command clears the given trace data and all the associated analysis results (the trace type is not deleted).
Type	Sequential, no query.
Syntax	:TRACe:SENSe[1...20]:CHANnel[1...6]:TYPE[1...10]   [14...18]:DELeTe
Parameter(s)	None.
Example(s)	:TRACe:SENSe1:CHANnel4:TYPE5:DEL

**:TRACe:STORe[1...n]:COLor**

<b>Description</b>	This command defines the color of the given store trace in RGB format.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRACe:STORe[1...n]:COLor<wsp><red>,<green>,<blue>
<b>Parameter(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>red</i>: Integer corresponding to the level of red in the trace color, in the range 0 to 255.</li> <li>➤ <i>green</i>: Integer corresponding to the level of green in the trace color, in the range 0 to 255.</li> <li>➤ <i>blue</i>: Integer corresponding to the level of blue in the trace color, in the range 0 to 255.</li> </ul>
<b>Example(s)</b>	:TRAC:STOR3:COL 70,130,180

**:TRACe:STORe[1...n]:COLor?**

<b>Description</b>	This query returns the color of the given store trace in RGB format.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRACe:STORe[1...n]:COLor?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<red>,<green>,<blue>
<b>Response(s)</b>	<ul style="list-style-type: none"> <li>➤ <i>red</i>: Integer corresponding to the level of red in the trace color, in the range 0 to 255.</li> <li>➤ <i>green</i>: Integer corresponding to the level of green in the trace color, in the range 0 to 255.</li> <li>➤ <i>blue</i>: Integer corresponding to the level of blue in the trace color, in the range 0 to 255.</li> </ul>
<b>Example(s)</b>	:TRAC:STOR3:COL 70,130,180 :TRAC:STOR3:COL? returns 70,130,180

**:TRACe:STORe[1...n]:DATA[:Y][:IMMediate]?**

<b>Description</b>	<p>This query returns the store trace data.</p> <p>This query can only be executed if the CTP10 is in idle state (:STAT:OPER:COND? returns 0).</p>
<b>Type</b>	Sequential, query only.
<b>Syntax</b>	:TRACe:STORe[1...n]:DATA[:Y][:IMMediate]?<wsp><format>,<unit>[,<reduction>]
<b>Parameter(s)</b>	<p>➤ <i>format:</i></p> <p>Format of the trace data. The allowed values are:</p> <p>0 ASCii: trace data is formatted as ASCII values, such as &lt;value1&gt;,&lt;value2&gt;,...</p> <p>1 BINary: trace data is formatted as binary blocks such as: #&lt;length&gt;&lt;Nb of bytes&gt;&lt;blocks&gt;</p> <p>where:</p> <p>&lt;length&gt;: number of subsequent bytes that you have to check to know the total length.</p> <p>&lt;Nb of bytes&gt;: size of &lt;blocks&gt; in bytes.</p> <p>&lt;blocks&gt;: float data bytes (packet of 4 bytes, big endian).</p> <p>For example, data containing 10 data points will results in the header "#240&lt;blocks&gt;" as 40 bytes are needed to define the data and "40" length is 2.</p> <p>➤ <i>unit:</i></p> <p>Unit of the trace data. The allowed values are: RATIO   DB   0   1</p> <p>RATIO or 0: trace data is retrieved in ratio.</p> <p>DB or 1: trace data is retrieved in dB.</p> <p>➤ <i>reduction:</i></p> <p>Reduction factor (optional), which decimates the number of data points for faster data retrieval. A reduction factor of 5 would select a point out of every 5 points available on the trace. The first point received is always the "start wavelength" data point.</p>
<b>Response Syntax</b>	<data>
<b>Response(s)</b>	<p><i>data:</i></p> <p>If the &lt;format&gt; parameter is ASCii, the response data syntax for &lt;data&gt; is formatted as follows: &lt;value1&gt;,&lt;value2&gt;,...</p> <p>If the &lt;format&gt; parameter is BINary, the response data syntax for &lt;data&gt; is formatted as binary blocks.</p> <p>It corresponds to the trace data, which is the list of measured power data points.</p>
<b>Example(s)</b>	<p>:TRAC:STOR1:DATA? ASC,DB returns -5.00000000E+000,-5.10000000E+000,...</p> <p>:TRAC:STOR1:DATA? BIN,RATIO returns #1821AÔ³Ê'³"12LÒ`2...</p>

**:TRACe:STORe[1...n]:DATA:LENGth?**

<b>Description</b>	This query returns the length of a store trace. This query can only be executed if the CTP10 is in idle state (:STAT:OPER:COND? returns 0).
<b>Type</b>	Sequential, query only.
<b>Syntax</b>	:TRACe:STORe[1...n]:DATA:LENGth?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<length>
<b>Response(s)</b>	<i>length:</i> Number of points in the trace.
<b>Example(s)</b>	:TRAC:STOR1:DATA:LENG? returns 225001

---

**:TRACe:STORe[1...n]:DATA:SAMPing?**

<b>Description</b>	This query returns the trace sampling interval.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:TRACe:STORe[1...n]:DATA:SAMPing?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<sampling>
<b>Response(s)</b>	<i>sampling:</i> Trace sampling interval in meters.
<b>Example(s)</b>	:TRAC:STOR1:DATA:SAMP? returns +2.00000000E-012

---

**:TRACe:STORe[1...n]:DATA:STARt?**

<b>Description</b>	This query returns the start wavelength of a trace of type store.
<b>Type</b>	Overlapping, query only.
<b>Syntax</b>	:TRACe:STORe[1...n]:DATA:STARt?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<wavelength>
<b>Response(s)</b>	<i>wavelength</i> : Trace start wavelength in meters.
<b>Example(s)</b>	:TRAC:STOR1:DATA:STAR? returns +1.25000000E-006

---

**:TRACe:STORe[1...n]:NOTE**

<b>Description</b>	This command adds a comment on the given store trace.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRACe:STORe[1...n]:NOTE<wsp> <comment>
<b>Parameter(s)</b>	<i>comment:</i> Comment to associate with the trace with 240 characters maximum; characters over this limit are ignored. It must be different from whitespace and must not be empty.
<b>Example(s)</b>	:TRAC:STOR3:NOTE my comment on the trace

---

**:TRACe:STORe[1...n]:NOTE?**

<b>Description</b>	This query returns the comment associated with the given store trace.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRACe:STORe[1...n]:NOTE?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<comment>
<b>Response(s)</b>	<i>comment:</i> Comment associated with the trace, in upper case and enclosed in double quotes.
<b>Example(s)</b>	:TRAC:STOR3:NOTE my comment on the trace :TRAC:STOR3:NOTE? returns "MY COMMENT ON THE TRACE"

---

<b>:TRACe:STORe[1...n]:SAVE</b>	
<b>Description</b>	<p>This command saves a store trace data into a file in the current directory.</p> <p>This command can only be executed if the CTP10 is in idle state (:STAT:OPER:COND? returns 0).</p>
<b>Type</b>	<p>Overlapped, no query.</p> <p>When the system executes this command, the bit 12 "Loading/Saving" is set in the Operational Status Condition Register (see :STATus:OPERation:CONDition? on page 251 and Operational / Questionable Status Reporting on page 205).</p>
<b>Syntax</b>	:TRACe:STORe[1...n]:SAVE<wsp> <filename>
<b>Parameter(s)</b>	<p><i>filename:</i></p> <p>Name of the file in which you want to save trace data, with or without quotes.</p> <p>Possible extensions are .tra (binary file) and .csv (csv file).</p> <p>Default extension (if not specified): .tra</p>
<b>Example(s)</b>	:TRAC:STOR2:SAVE "mytrace.tra"

---

## TRIGger Commands and Queries

### Quick Reference

Command Overview			Parameter(s)	Section
TRIGger	IN	[INPUt]	<input>	see <i>p. 527</i>
		[INPUt]?		see <i>p. 527</i>
		SLOPe	<slope>	see <i>p. 528</i>
		SLOPe?		see <i>p. 528</i>
	OUT	[OUTPUt]	<output>	see <i>p. 529</i>
		[OUTPUt]?		see <i>p. 529</i>
		INVerted	<state>	see <i>p. 530</i>
		INVerted?		see <i>p. 530</i>
		LLOG?	<format> [, <SOP> ]	see <i>p. 531</i>
		TYPE	<type>	see <i>p. 532</i>
		TYPE?		see <i>p. 532</i>



## Commands and Queries

:TRIGger:IN[:INPUT]	
<b>Description</b>	This command defines the input trigger to use for the triggered optical acquisition. The corresponding GUI setting is <b>Source</b> (see <b>Scan start on page 122</b> ).
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATus? on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:TRIGger:IN[:INPUT] <wsp> <input>
<b>Parameter(s)</b>	<i>input</i> : TRIG IN port that provides the trigger signal for the optical acquisition, in the range 0 to 8. The allowed values are: 0: no TRIG IN port selected 1: TRIG IN 1 port 2: TRIG IN 2 port 3: TRIG IN 3 port 4: TRIG IN 4 port 5: TRIG IN 5 port 6: TRIG IN 6 port 7: TRIG IN 7 port 8: TRIG IN 8 port
<b>Example(s)</b>	:TRIG:IN 1

:TRIGger:IN[:INPUT]?	
<b>Description</b>	This query returns the input trigger used for the triggered optical acquisition.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRIGger:IN[:INPUT]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<input>
<b>Response(s)</b>	<i>input</i> : TRIG IN port number that provides the trigger signal for the optical acquisition. 0 means that no TRIG IN port is selected.
<b>Example(s)</b>	:TRIG:IN 1 :TRIG:IN? returns 1

:TRIGger:IN:SLOPe	
<b>Description</b>	This command defines the slope of the signal that triggers the scan.  The corresponding GUI setting is <b>Slope</b> (see <b>Scan start on page 122</b> ).
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STaTus? on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:TRIGger:IN:SLOPe<wsp><slope>
<b>Parameter(s)</b>	<i>slope</i> :  Slope of the signal that triggers the scan. The allowed values are: POSitive 0: the scan is performed when the received signal rises. NEGative 1: the scan is performed when the received signal falls.
<b>Example(s)</b>	:TRIG:IN:SLOP 0

:TRIGger:IN:SLOPe?	
<b>Description</b>	This query returns the slope of the signal that triggers the scan.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRIGger:IN:SLOPe?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<slope>
<b>Response(s)</b>	<i>slope</i> :  Slope of the signal that triggers the scan: 0: the scan is performed when the received signal rises. 1: the scan is performed when the received signal falls.
<b>Example(s)</b>	:TRIG:IN:SLOP NEG :TRIG:IN:SLOP? returns 1

**:TRIGger:OUT[:OUTPut]**

<b>Description</b>	This command defines the output trigger to use. The corresponding GUI setting is <b>Destination</b> (see <i>Generating Output Trigger Signals</i> on page 137).
<b>Type</b>	Sequential.
<b>Syntax</b>	:TRIGger:OUT[:OUTPut]<wsp><output>
<b>Parameter(s)</b>	<i>output:</i> TRIG OUT port that outputs the signal from the CTP10 when it scans, in the range 1 to 4. The allowed values are: 0: no TRIG OUT port is selected 1: TRIG OUT 1 port 2: TRIG OUT 2 port 3: TRIG OUT 3 port 4: TRIG OUT 4 port
<b>Example(s)</b>	:TRIG:OUT:OUTP 4

**:TRIGger:OUT[:OUTPut]?**

<b>Description</b>	This query returns the output trigger port used to output the signal from the CTP10 when it scans.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRIGger:OUT[:OUTPut]?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<output>
<b>Response(s)</b>	<i>output:</i> TRIG OUT port number that outputs the signal. 0 means that no TRIG OUT port is selected.
<b>Example(s)</b>	:TRIG:OUT:OUTP 2 :TRIG:OUT:OUTP? returns 2

:TRIGger:OUT:INVerted	
<b>Description</b>	<p>This command sets the state of the inverted logic of the output trigger signal.</p> <p>The corresponding GUI setting is <b>Inverted logic</b> (see <i>Generating Output Trigger Signals</i> on page 137).</p>
<b>Applicability</b>	<p>This command is only available if :TRIGger:OUT:TYPE on page 532 is set to WINdow.</p> <p>If :TRIGger:OUT:TYPE on page 532 is set to PULse, this command is forced to OFF.</p>
<b>Type</b>	Sequential.
<b>Syntax</b>	:TRIGger:OUT:INVerted<wsp> <state>
<b>Parameter(s)</b>	<p><i>state</i>:</p> <p>State of the inverted logic setting for the output trigger. The allowed values are:</p> <p>OFF 0: the CTP10 outputs a high level signal during the time of the scan.</p> <p>ON 1: the CTP10 outputs a low level signal during the time of the scan.</p>
<b>Example(s)</b>	:TRIG:OUT:INV ON

:TRIGger:OUT:INVerted?	
<b>Description</b>	This query returns the state of the inverted logic of the output trigger signal.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRIGger:OUT:INVerted?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<state>
<b>Response(s)</b>	<p><i>state</i>:</p> <p>State of the <b>Inverted logic</b> setting for the output trigger:</p> <p>0: the CTP10 outputs a high level signal during the time of the scan.</p> <p>1: the CTP10 outputs a low level signal during the time of the scan.</p>
<b>Example(s)</b>	<p>:TRIG:OUT:INVerted ON</p> <p>:TRIG:OUT:INVerted? returns 1</p>

**:TRIGger:OUT:LLOG?**

<b>Description</b>	This query returns the wavelength array corresponding to pulse triggers that have been generated during the sweep.
<b>Type</b>	Sequential.
<b>Syntax</b>	:TRIGger:OUT:LLOG? <wsp> <format> [, <SOP>]
<b>Parameter(s)</b>	<p>➤ <i>format</i></p> <p>Format of the wavelength array. The allowed values are:</p> <p>0 ASCIi: wavelength array is formatted as ASCII values, such as &lt;value1&gt;, &lt;value2&gt;, &lt;value3&gt;, ...</p> <p>1 BINary: wavelength data is formatted as binary blocks such as: #&lt;length&gt; &lt;Nb of bytes&gt; &lt;blocks&gt;</p> <p>where:</p> <p>&lt;length&gt;: number of subsequent bytes that you have to check to know the total length.</p> <p>&lt;Nb of bytes&gt;: size of &lt;blocks&gt; in bytes.</p> <p>&lt;blocks&gt;: float data bytes (packet of 4 bytes, big endian).</p> <p>For example, data containing 12 data points will results in the header "#248&lt;blocks&gt;" as 48 bytes are needed to define the data and "48" length is 2.</p> <p>➤ <i>SOP</i> (only used in case of PDL measurement)</p> <p>Integer representing the state of polarization from which you want to retrieve the wavelength array.</p> <p>The allowed values on the IL PDL module are:</p> <p>1: LVP Linearly vertical polarized.</p> <p>2: LHP Linearly horizontal polarized.</p> <p>3: L-45 Linear -45° polarized.</p> <p>4: RCP Right circularly polarized.</p> <p>The allowed values on the IL PDL OPM2 module are:</p> <p>1: state of polarization #1</p> <p>2: state of polarization #2</p> <p>3: state of polarization #3</p> <p>4: state of polarization #4</p>
<b>Response Syntax</b>	<wavelength array>
<b>Response(s)</b>	<p><i>wavelength array:</i></p> <p>Wavelength values in meters corresponding to the pulse triggers that have been generated during the sweep.</p> <p>If a trigger is a parasitic trigger (at the start or end of the sweep), the wavelength value is set to 0 in the array, which enables you to reject the parasitic data points.</p> <p>➤ If the &lt;format&gt; parameter is ASCII, the response data syntax is formatted as follows: &lt;value 1&gt;, &lt;value 2&gt;, ...</p> <p>➤ If the &lt;format&gt; parameter is BINary, the response data syntax is formatted as binary blocks, as explained above.</p>
<b>Example(s)</b>	<p>:TRIG:OUT:LLOG? ASCII returns</p> <p>+1.54999251E-006,+1.55000010E-006,+1.55000766E-006,...</p> <p>:TRIG:OUT:LLOG? ASCII,1 returns</p> <p>+1.54999251E-006,+1.55000010E-006,+1.55000766E-006,...</p>

**:TRIGger:OUT:TYPE**

<b>Description</b>	This command sets the type of the output trigger signal. The corresponding GUI setting is <b>Type</b> (see <i>Generating Output Trigger Signals</i> on page 137).
<b>Type</b>	Sequential.
<b>Syntax</b>	:TRIGger:OUT:TYPE<wsp> <type>
<b>Parameter(s)</b>	<i>type</i> : Type of the output trigger. The allowed values are: WINDow 0: the CTP10 outputs a window trigger. PULse 1: the CTP10 outputs pulse triggers. You can retrieve the corresponding wavelength array by using :TRIGger:OUT:LLOG? on page 531.
<b>Example(s)</b>	:TRIG:OUT:TYPE PUL

**:TRIGger:OUT:TYPE?**

<b>Description</b>	This query returns the type of the output trigger signal.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:TRIGger:OUT:TYPE?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<type>
<b>Response(s)</b>	<i>type</i> : Type of the output trigger: 0: the CTP10 outputs a window trigger. 1: the CTP10 outputs pulse triggers.
<b>Example(s)</b>	:TRIG:OUT:TYPE PUL :TRIG:OUT:TYPE? returns 1

## UNIT Commands and Queries

### Quick Reference

Command Overview		Parameter(s)	Section
UNIT	X	<unit>	see p. 533
	X?		see p. 533
	Y	<unit>	see p. 534
	Y?		see p. 534

### Commands and Queries

:UNIT:X	
<b>Description</b>	This command sets the spectral unit of the subsystem.
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATus? on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:UNIT:X<wsp><unit>
<b>Parameter(s)</b>	<i>unit:</i> Spectral unit of the entire subsystem. The allowed values are: WAVelength 0: sets the spectral unit to nm. FREQuency 1: sets the spectral unit to THz.
<b>Example(s)</b>	:UNIT:X WAV

:UNIT:X?	
<b>Description</b>	This query returns the spectral unit of the subsystem.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:UNIT:X?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<unit>
<b>Response(s)</b>	<i>unit:</i> Spectral unit used in the subsystem: 0: the spectral unit is set to nm. 1: the spectral unit is set to THz.
<b>Example(s)</b>	:UNIT:X WAV :UNIT:X? returns 0

:UNIT:Y	
<b>Description</b>	This command sets the power unit of the subsystem.
<b>Applicability</b>	In laser sharing mode, this command is not available on Distributed CTP10s (response 2 to :CTP:LSHARing:STATus? on page 276).
<b>Type</b>	Sequential.
<b>Syntax</b>	:UNIT:Y<wsp><unit>
<b>Parameter(s)</b>	<i>unit:</i> Power unit of the entire subsystem. The allowed values are: DB 0: sets the power unit to dB. RATIO 1: sets the power unit to ratio.
<b>Example(s)</b>	:UNIT:Y DB

:UNIT:Y?	
<b>Description</b>	This query returns the power unit of the subsystem.
<b>Type</b>	Overlapping.
<b>Syntax</b>	:UNIT:Y?
<b>Parameter(s)</b>	None.
<b>Response Syntax</b>	<unit>
<b>Response(s)</b>	<i>unit:</i> Power unit used in the subsystem: 0: the power unit is set to dB. 1: the power unit is set to ratio.
<b>Example(s)</b>	:UNIT:Y DB :UNIT:Y? returns 0



## B SCPI-Based Errors

This section describes:

- the instrument specific errors (-399 to -300),
- the instrument specific warnings (positive numbers).

All other command errors (range -199 to -100) and execution errors (range -299 to -200) are described in the Standard Commands for Programmable Instruments (SCPI) document available at [www.ivifoundation.org/docs/scpi-99.pdf](http://www.ivifoundation.org/docs/scpi-99.pdf)

Error number	Description	Probable cause
12	"Remote ip address dns related problem daisy chaining"	A problem occurred with the IP address used for Daisy chaining, which may be related to a DNS issue.
11	"Remote ip address dns related problem laser sharing"	A problem occurred with the IP address used for Laser sharing, which may be related to a DNS issue.
10	"Mode hop warning"	A mode hop occurred during a sweep. This warning can occur during scanning operation.
-300	"Device-specific error"	This is the generic device-dependent error for devices that cannot detect more specific errors. This code indicates only that a Device-Dependent Error as defined in IEEE 488.2, 11.5.1.1.6 has occurred.
-301	"CTP10 Scan State Busy"	The CTP10 is still scanning, stopping or aborting and is not in an idle state.
-302	"CTP10 Internal Timeout"	The command did not execute in the allowed period of time.  This error appears if you have launched an analysis (:CALCulate[:IMMEDIATE] on page 307) that takes more than 30 seconds: in this case, you should not take this error into account.
-303	"Identifier does not match any trace"	There is no trace associated with this identifier.
-304	"No data available"	There is no data available for this trace.
-305	"File save error"	An error occurred while saving the file.
-306	"Subsystem settings error"	The settings are inadequate.
-307	"Subsystem reference error"	The reference is inadequate or is not compatible with the settings, or an attempt to perform a quick reference without having performed a reference first has been detected.
-308	"Subsystem laser error"	A laser is missing, not connected or locked, or not supported in this subsystem setup.
-309	"Laser identifier error"	There is no laser for the given identifier.

Error number	Description	Probable cause
-310	"Zeroing error"	An error occurred during the zeroing of the detector. Maybe too much light on the input.
-311	"Cannot do zeroing"	There is no module or the module is initializing or there is no detector to zero.
-312	"Cannot switch"	There is no module or the module is initializing or this is not an FBC module.
-313	"Cannot set averaging time"	There is no module or the module is initializing or this is not a module with a detector.
-314	"Command not available for this module"	The module does not offer the functionality.
-315	"Module not ready"	There is no module in the given slot, the module is not locked or the module is initializing.
-316	"File load error"	The file does not exist or the file format is not good.
-317	"Wavelength referencing error"	The gas cell or the expected peaks are not properly detected, or the detector is not properly configured.
-318	"Cannot read switch"	There is no module or the module is initializing or the module is not an FBC module.
-319	"Cannot do selftest"	There is no module or the module is initializing.
-320	"Laser unavaible"	There is no laser connected or the laser does not exist.
-321	"Laser already connected"	The laser is already connected to another input.
-322	"Cannot add the trace"	The maximum number of traces has been reached, or the trace type you want to activate is not available with the measurement module used in the subsystem.
-323	"Not available in this laser sharing mode"	The command cannot be executed in laser sharing mode.
-324	"Laser sharing communication error"	An error occurred while trying to connect to a remote CTP10 in laser sharing mode.
-325	"Invalid port number"	The Controller or Distributed port is not valid for laser sharing configuration.
-326	"Invalid IP address"	The specified IP address is not valid for laser sharing configuration.
-327	"Remote CTP10 is already in use"	The remote CTP10 is already used in laser sharing mode (Controller or Distributed)
-328	"Remote CTP10 is busy"	Cannot connect to the remote CTP10 in laser sharing mode because the CTP10 is scanning or analyzing.
-330	"Incompatible laser sharing protocol version"	Cannot connect to the remote CTP10 because the version of its protocol is not compatible.
-331	"Not available in this daisy chaining mode"	The command cannot be executed in Daisy chaining mode.

Error number	Description	Probable cause
-332	"Daisy chaining communication error"	An error occurred while trying to connect to a remote CTP10 in daisy chaining mode.
-333	"Incompatible daisy chaining protocol version"	Cannot connect to the remote CTP10 because the version of its protocol is not compatible.
-334	"Detector not selected in subsystem"	The module position or detector number required is not selected in the subsystem.
-335	"No laser light detected on TLS IN"	The fiber is not connected to the TLS IN port of the IL RL OPM2, IL PDL, IL PDL OPM2 or SCAN SYNC module, or a shutter is not in the right state.
-336	"Laser referencing error"	The internal wavelength referencing of the laser has failed.
-337	"Laser connection error"	The connection to the connected laser cannot be open.
-338	"Traces compute error"	A problem was detected on the laser signal in the SCAN SYNC module, viable traces cannot be computed.
-339	"Settings for wavelength reference error"	The scan range of the TLS does not contain the range of the gas cell selected for wavelength reference.
-340	"Controller settings for wavelength reference error"	The scan range of the Controller CTP10 does not contain the range of the gas cell selected for wavelength reference.
-341	"Command not allowed in laser sharing distributed mode"	The requested settings can not be changed on a Distributed CTP10 in laser sharing mode.
-342	"IL PDL OPM2 module internal error"	The polarization state generator of the IL PDL OPM2 cannot reach the desired position, IL and PDL results may not be within specifications.
-343	"Trace acquisition error"	The laser signal acquisition on the SCAN SYNC module shows problems, viable traces can not be computed.
-344	"SCAN_SYNC calibration data problem"	The calibration file of the SCAN SYNC module is not correct.
-345	"Subsystem TLS settings error with trig out pulse activated"	Pulse trigger output is not supported in a setup with multiple lasers.
-346	"Subsystem speed settings error with trig out pulse activated"	Scanning with Pulse trigger output is not possible if the sweep speed is less than 10 nm/s.
-347	"Subsystem daisy chain settings error with trig out pulse activated"	Pulse trigger output is not supported in daisy chaining mode.



Error number	Description	Probable cause
-348	"Subsystem laser sharing settings error with trig out pulse activated"	Pulse trigger output is not supported in laser sharing mode.
-349	"Cannot open connection while scanning with an electrical trig out pulse"	Scanning with Pulse trigger output is not supported in laser sharing mode.
-350	"Error queue overflow"	A specific code entered into the queue in lieu of the code that caused the error. This code indicates that there is no room in the queue and an error occurred but was not recorded.
-351	"Subsystem settings TLS trigger missing with trig out pulse activated"	The trigger link between the TLS and the CTP10 (for Pulse trigger output) is missing in the 'Subsystem setup' menu.
-352	"Subsystem settings TLS model incompatible with trig out pulse activated"	The selected TLS is not compatible with the Pulse trigger output.
-353	"Command not supported by this laser type"	The command is not compatible with the selected laser type.
-354	"Command forbidden while connecting or connected to laser"	The command is only applicable if the specified laser is disconnected.
-355	"Cannot change laser type while connecting or connected to laser"	The command is only applicable if the specified laser is disconnected, or if the parameter is set to 0.

CHINESE REGULATION ON RESTRICTION OF HAZARDOUS SUBSTANCES (RoHS)  
中国关于有害物质限制的规定  
NAMES AND CONTENTS OF THE TOXIC OR HAZARDOUS SUBSTANCES OR ELEMENTS CONTAINED IN THIS EXFO  
PRODUCT  
包含在本 EXFO 产品中的有毒有害物质或元素的名称及含量

Part Name 部件名称	Lead 铅 (Pb)	Mercury 汞 (Hg)	Cadmium 镉 (Cd)	Hexavalent Chromium 六价铬 (Cr(VI))	Polybrominated biphenyls 多溴联苯 (PBB)	Polybrominated diphenyl ethers 多溴二苯醚 (PBDE)
Enclosure 外壳	O	O	O	O	O	O
Electronic and electrical sub-assembly 电子和电气组件	X	O	X	O	X	X
Optical sub-assembly <sup>a</sup> 光学组件 <sup>a</sup>	X	O	O	O	O	O
Mechanical sub-assembly <sup>a</sup> 机械组件 <sup>a</sup>	O	O	O	O	O	O

**Note:**  
注：  
This table is prepared in accordance with the provisions of SJ/T 11364.  
本表依据 SJ/T 11364 的规定编制。  
O: Indicates that said hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T 26572.  
O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 标准规定的限量要求以下。  
X: indicates that said hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement of GB/T 26572. Due to the limitations in current technologies, parts with the "X" mark cannot eliminate hazardous substances.  
X: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 标准规定的限量要求。  
标记“X”的部件，皆因全球技术发展水平限制而无法实现有害物质的替代。  
a. If applicable.  
如果适用。

MARKING REQUIREMENTS  
标注要求

Product 产品	Environmental protection uses period (years) 环境保护使用期限 (年)	Logo 标志
This EXFO product 本 EXFO 产品	10	
Battery <sup>a</sup> 电池 <sup>a</sup>	5	

a. If applicable.  
如果适用。



[www.EXFO.com](http://www.EXFO.com) · [info@exfo.com](mailto:info@exfo.com)

<b>CORPORATE HEADQUARTERS</b>	400 Godin Avenue	Quebec (Quebec) G1M 2K2 CANADA Tel.: 1 418 683-0211 · Fax: 1 418 683-2170
<b>TOLL-FREE</b>	(USA and Canada)	1 800 663-3936

